


# Vector inverter for lifts with synchronous/asynchronous motors

## ADL510

Functions description  
and parameters list

Language: English



## Information about this manual

---

This manual explains the functions and the description of the parameters.

The informations about mechanical installation, electrical connection and fast start-up can be found on the ADL550 HW+QS (Hardware and Quick start guide), it is available on WEG web site in the download section ([https://www.weg.net/catalog/weg/IT/en/p/MKT\\_WDC\\_GLOBAL\\_PRODUCT\\_INVERTER\\_FOR\\_ELEVATOR\\_ADL500](https://www.weg.net/catalog/weg/IT/en/p/MKT_WDC_GLOBAL_PRODUCT_INVERTER_FOR_ELEVATOR_ADL500)).

### Firmware version

This manual is updated according to:

- firmware version V 3.x.2
- lift application, EFC V 3.x.2

The firmware version identification number can be read in the data matrix (see section 2.3 of the ADL500 HW+QS manual) or in parameter **Firmware Version** PAR 174 (DRIVE INFO menu).

### General information

#### Note!

In industry, the terms "Inverter", "Regulator" and "Drive" are sometimes interchanged. In this document, the term "Drive" will be used.

Before using the product, read the safety instruction section carefully. Keep the manual in a safe place and available to engineering and installation personnel during the product functioning period.

WEG Automation Europe S.r.l. has the right to modify products, data and dimensions without notice. The data can only be used for the product description and they can not be understood as legally stated properties.

Thank you for choosing this WEG product.

We will be glad to receive any possible information which could help us improving this manual.

The e-mail address is the following: [techdoc@weg.net](mailto:techdoc@weg.net).

All rights reserved.

### Symbols used in the manual



Warning

Indicates a procedure, condition, or statement that, if not strictly observed, could result in personal injury or death.



Caution

Indicates a procedure, condition, or statement that, if not strictly observed, could result in damage to or destruction of equipment.



Attention

Indicates that the presence of electrostatic discharge could damage the appliance. When handling the boards, always wear a grounded bracelet.



#### Note !

Indicates a procedure, condition, or statement that should be strictly followed in order to optimize these applications.

## Table of Contents

---

<b>Information about this manual.....</b>	<b>2</b>
Symbols used in the manual.....	2
<b>A - Programming .....</b>	<b>5</b>
A.1 Menu display modes .....	5
A.2 Programming of “function block” analog and digital input signals .....	5
A.3 Variable interconnections mode .....	5
<b>B - Parameters and functions description .....</b>	<b>7</b>
Legend .....	7
DRIVE SETUP .....	8
1. STARTUP WIZARD .....	8
1.1 Communication mode selection (Set comm mode)? .....	8
1.2 Encoder configuration (Set encoder param)? .....	9
1.3 Motor data configuration (Set motor data)? .....	9
1.4 Mechanical data setting (Set mechanical data)? .....	10
1.5 Speed setting (Set speed)? .....	11
1.7 Run Autotune still? .....	12
1.8 Save parameters? .....	12
2. OPTIMIZATION WIZARD (OPTIMIZ. WIZARD) .....	12
3. TROUBLESHOOTING .....	14
3.1 Start .....	14
3.2 Rollback .....	14
3.3 Too fast acceleration (Too fast accel.) .....	15
3.4 Slow speed vibrations (Slow speed vibr.) .....	15
3.5 High speed vibrations (High speed vibr.) .....	16
3.6 Too fast deceleration (Too fast dec.) .....	16
3.7 Floor leveling .....	16
3.9 Vibration analyzer .....	17
4. DRIVE .....	17
4.1 DRIVE MONITOR .....	17
4.2 DRIVE INFO .....	19
4.3 DRIVE CONFIG .....	22
4.4 ALARM CONFIG .....	24
4.8 DIGITAL INPUTS .....	32
4.9 DIGITAL OUTPUTS .....	32
4.10 ANALOG INPUTS .....	33
4.11 ALARM LOG .....	35
4.12 LIFE TIME .....	35
5. LIFT .....	36
5.1 LIFT MONITOR .....	36
5.2 MECHANICAL DATA .....	38
5.3 SPEED .....	40
5.4 RAMPS .....	42
5.5 LIFT SEQUENCES .....	44
5.6 LIFT OUT .....	48
5.7 LIFT IN .....	49
5.8 PRE TORQUE .....	52
5.9 EMERGENCY MODE .....	53
5.10 LIFT ALARMS .....	55
5.11 DISTANCE .....	59
5.14 DIRECT CNT .....	63
6. COMMUNICATION .....	65
6.1 CONTROL COMM .....	65
6.6 NETWORK AND ACCESS .....	65
7. MOTOR DATA .....	67
8. ENCODER .....	69
9. SAFETY .....	72
10. REGULATION MENU .....	73
10.1 SPEED REGULATION GAINS (SPEED REG GAINS) .....	73
10.2 VF CONTROL .....	77
10.3 REGULATOR PARAM .....	80
10.4 TORQUE CONFIG .....	82
11. FUNCTIONS .....	84
11.1 DC BRAKING .....	84
11.2 INERTIA COMP .....	86
11.4 VIBRATION ANALYSIS (VIBR. ANALYSIS) .....	86
11.5 MOTOR OVERLOAD .....	87
11.6 BRAKING RESISTOR OVERLOAD (BRES OVERLOAD) .....	89
11.7 ENERGY SAVING (ENER. SAVING) .....	89
PARAMETERS ON SELECTION LISTS, BUT NOT DISPLAYED ON KEYPAD .....	90
<b>C - Parameters list .....</b>	<b>93</b>

<b>D - Selection lists .....</b>	<b>112</b>
L_DIGSEL1 .....	112
L_DIGSEL2 .....	112
L_DIGSEL3 .....	112
L_LIM .....	113
L_MLTREF .....	113
L_SCOPE .....	113
L_VREF .....	113
L_WDECOMP .....	113
LiftInputAdlCmd .....	114
LiftInputDoorCmd.....	115
LiftInputAdlCmdEBC.....	115
<b>E - Block diagrams .....</b>	<b>115</b>
Drive .....	115
Drive overview .....	115
Digital Inputs .....	115
Expansion digital inputs .....	116
Digital outputs .....	116
Analog Inputs .....	117
Lift .....	118
EFC Overview .....	118
Multispeed .....	118
Ramps .....	119
Start sequences .....	119
Stop sequences .....	120
Pre torque.....	120
Regulations .....	121
Speed reg gains .....	121
Torque config.....	121
Functions .....	122
Motor overload Servofan .....	122
Motor overload Autofan .....	122
Bres overload .....	123
DC braking stop .....	123
DC braking on command .....	124
DC braking on cmd & at stop .....	124
<b>F - Appendix 1 - Drive alarm handling .....</b>	<b>125</b>
F.1.1 Drive alarm handling.....	125

### A.1 Menu display modes

The programming menu can be displayed in four modes, which can be selected using the parameter 554 **Access level** (04 - DRIVE CONFIG menu):

- |                  |                                                                          |
|------------------|--------------------------------------------------------------------------|
| (0) Readonly     | The read-only parameters are displayed.                                  |
| (1) Easy         | Only the main parameters required for a basic start up are displayed.    |
| (2) Intermediate | Only the parameters for initial optimization are displayed.              |
| (3) Expert       | All parameters are displayed except for the menu and service parameters. |
| (4) Service      | All parameters are displayed. Reserved for service.                      |

### A.2 Programming of “function block” digital input signals

The signals, variables and parameters of each single “function block” of the drive are interconnected in order to achieve the configurations and controls inside the control system.

These can be managed and modified using the keypad, PC configurator or fieldbus programming.

The programming mode is based on the following logic:


**Src** (source; i.e.: **Fault reset src**, PAR: 4500)

This term defines **the source of the function block input**, i.e. the signal to be processed in the function block.

The different configurations are defined in the relative **selection lists**.

**Mon** (monitor; es.: **Mon ing digitale 1**, PAR: 1210)

Si definisce con tale denominazione **la variabile in uscita al blocco funzione, risultante dalle elaborazioni effettuate nel blocco stesso**.



### A.3 Variable interconnections mode

The **source (src)** allows the desired control signal to be assigned to the function block input.

This operation is performed by using specific selection lists.

Possible control signal sources:

#### 1 – Physical terminal

The analog and digital signals come from the terminal strip of the regulation card and/or from those of the expansion cards.

#### 2 – Drive internal variables

Internal drive control system variables, from “function block” calculations, sent via keypad, PC configurator or fieldbus.

#### Practical example


The following examples illustrate the philosophies and methods with which more or less complex operations are performed in the single “function blocks”, the results of which represent the output of the block.

##### • Example: Changing the digital outputs source

The main drive reference (in the default configuration) **Speed ref 1 mon** (PAR 660) is generated by the output of the function block **“Multispeed selector”**. Its default source is the multispeed 1, **Dig input 4 mon** signal (PAR 1216), from the output of the function block **“Digital Input 4 Block”**, which in this case refers to digital input 4 of the signal terminal strip.

##### • Example: Inverting the digital input signal “Start fwd cmd src”

To invert the “**Start fwd cmd src**” digital input signal the value of the parameter **Dig inp 4 inversion** (PAR 1246), which has a default setting of **Null** (nessuna operazione/no operation), must be changed by selecting the source of the command signal from among those listed in the L\_DIGSEL 2 selection list, for example **Dig inp 4 inversion (PAR 1246)**, **One** (function always enabled), etc.



The diagrams above illustrate the internal processing philosophy of the single “function blocks” and the result of these changes on the other interconnected “function blocks”.

#### Note!

This section contains a brief description of the functions of the other parameters in the function blocks not included for the changes in the example.

The parameter **Speed ref invert src** (PAR: 654) can be used to select the source for the command to reverse the “**Multispeed selector**” function block output.

The output signal from the “**Speed setpoint**” block is displayed in the parameter **Speed ref 1 mon** (PAR 660).

## B - Parameters and functions description

### Legend

0	1	2	3	4	5	6	7	8	9	10	11		
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.		
<b>4 DRIVE</b>											( Level 1 menu )		
<b>4.1 DRIVE MONITOR</b>											( Level 2 menu )		
4.1.1	250	Output current	A	FLOAT	16/32BIT	0	0	0	R	ALL			
<b>4.4 ALARM CONFIG</b>													
4.4.1	4500	Fault reset src		LINK	16BIT	6000	0	16384	RW	FVY			
Selection of the origin (source) of the signal to be used for the command to reset the drive after an alarm. The terminal that can be used for this function can be selected from among those listed in the "L_DIGSEL2" selection list. [*]													
0	Indexing of the menu and parameter												
1	Parameter identifier												
2	Parameter description												
3	UM: unit of measure												
4	Type of parameter	BIT	Boolean, from modbus seen as 16 bits										
		ENUM	Selection list, from modbus seen as 16 bits										
		FLOAT	Real, from modbus seen as 32 bits										
		INT16	Integer with sign 16 bits, from modbus seen as 16 bits										
		INT32	Integer with sign 32 bits, from modbus seen as 32 bits										
		ILINK	Selection list, from modbus seen as 16 bits										
		LINK	Selection list, from modbus seen as 16 bits										
		UINT16	Integer without sign 16 bits, from modbus seen as 16 bits										
		UINT32	Integer without sign 32 bits, from modbus seen as 32 bits										
		STRING16	16 character string										
		FBM2SIPA	IPA of the parameter received from the CAN master										
		FBF2MIPA	IPA of the parameter sent to the CAN master										
5	Format of data exchanged on Fieldbus		16=16BIT, 32=32BIT, 16/32= 16/32BIT										
6	Default value (1)		CALCF CALCI SIZE	Value calculated as a number with floating point									
7	Minimum value			Value calculated as a whole number									
8	Maximum value			Value depending on the size of the drive									
9	Accessibility		R W Z	Read									
				Write									
				Parameters that can be modified ONLY with the drive disabled									
10	Level		RO INT EXP SRV ESY	Read Only									
				Intermediate									
				Expert									
				Service									
				Easy									
11	Visibility		F V Y	Open loop V/f mode control, asynchronous motor (PAR 540 = ASY SSC, Default).									
				Field oriented vector mode control, asynchronous motor (PAR 540 = ASY FOC).									
				Field oriented vector mode control for permanent magnet synchronous motor (PAR 540 = SYN FOC).									
[*]	Selection lists: The "Source.../Src..." format parameters are linked to a selection list. The source of the signal that will control the parameter can be selected from the list indicated. The lists are indicated in paragraph D of this manual.												


- (1) The default value is usually common for Synchronous and Asynchronous versions. When it is different, the value of the synchronous version is indicated into brackets: e.g.: PAR 11012 Pulley diameter, Def= 0.6 (0.32), 0.6 = default ver. asynchronous, (0.32)= default ver. synchronous.

## DRIVE SETUP

Il SETUP DRIVE è una procedura che viene presentata all'utente solo alla prima accensione del drive e permette di modificare le impostazioni base.

Nel caso in cui si fosse completato il setup ma si desiderasse visualizzarlo nuovamente è necessario eseguire la procedura di ripristino (**Parametri di default**, PAR 580 e **Salva Parametri**, PAR 550) quindi spegnere e riaccendere il drive.

Tutti i parametri presenti nel setup sono anche disponibili all'interno dei vari menu del drive.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1	578	<b>Language select</b>		ENUM		GB			RW	INT	FVY
Setting of the drive programming language.											
<p>0 English 1 Italian 2 French 3 German 4 Spanish 5 Turkish</p>											
English and Italian are pre-installed in the drive, to select the Italian language set 1.											
To set a different language download from the WEG site ( <a href="https://www.weg.net/...">https://www.weg.net/...</a> , DRIVE SET-UP folder) the available language file (wizard available in the ADL500 HW+QS manual, section 8.2.8.1 Language selection):											
<ul style="list-style-type: none"><li>Unzip and save the files to on the PC where the WEG DriveLabs configurator is installed in a folder named "ADL500LN";</li><li>Start the language loading procedure, when finished the drive will be restarted;</li><li>Select parameter 578 Select language and set the new language.</li></ul>											
<b>Note!</b> The language file must be aligned to the firmware and application version of the drive, check the match!											
The new language will be loaded into the memory of the drive and will replace the Italian language. The English language cannot be replaced by another language.											
<b>Note!</b> The <b>Load Default</b> command (PAR 580) does not modify this parameter.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4	2132	<b>Encoder mode</b>		ENUM		None			RWZ	INT	FVSY
The drive has a built-in encoder card. The encoder mode can be selected according to the following table:											
<p>0 None 1 Digital 2 Sinus</p>											

## 1 STARTUP WIZARD

Following the step-by-step procedure from this menu, the drive can be started up by setting the main parameters relating to communication, feedback, motor, main system mechanical data, speed and motor self-tuning.

### 1.1 Set comm mode?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.1.1	4000	<b>Communication mode</b>		ENUM		Parallel			RW	INT	FVSY
Setting the type of communication to be used.											
<p>0 Parallel I/O</p>											

Setting **0** the drive communicates with the Controller through the **Parallel I/O** (analogue inputs and outputs).

## 1.2 Set encoder param?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.2.1</b>	<b>2102</b>	<b>Encoder supply</b>	V	FLOAT		5.2	5.2	20.0	RW	INT	FVY

Setting of the encoder supply voltage. Min and max values are modified according to the selection of parameter 2104 **Encoder input config** as follows:

PAR 2104 Encoder input config	Def	Min	Max
[0] HTL	5.2 V	5.2 V	20.0 V
[1] TTL	5.2 V	5.2 V	6.0 V

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.2.2</b>	<b>2132</b>	<b>Encoder mode</b>		ENUM		None			RWZ	INT	FVSY

The drive has an integrated encoder card. The encoder mode can be selected in accordance with the following table:

- 0** None
- 1** Digital
- 2** Sinus

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.2.3</b>	<b>2100</b>	<b>Encoder pulses</b>	ppr	UINT16		1024	4	16384	RWZ	INT	FVY

Setting of the number of feedback encoder impulses. During setup, for incremental sinusoidal encoders + absolute EnDat, encoder absolute EnDat Full digital and Hiperface encoders this value is set automatically by reading the number of incremental encoder impulses.

With the EnDat Full digital Encoder, the value set automatically may be below the minimum.

## 1.3 Set motor data?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.3.1</b>	<b>540</b>	<b>Control type</b>		ENUM		ASY_VF			RWZ	INT	FVSY

The control mode is displayed.

- 0** ASY SSC
- 1** ASY FOC

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.3.2</b>	<b>2000</b>	<b>Rated voltage</b>	V	FLOAT		SIZE	150	480	RWZ	INT	FVSY

Set the motor rated voltage as indicated on the data plate. This is the voltage the drive must supply at the motor rated frequency.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.3.3</b>	<b>2002</b>	<b>Rated current</b>	A	FLOAT		SIZE	1	1500	RWZ	INT	FVSY

The motor rated current at its rated power (kW / Hp) and voltage (indicated on the motor data plate).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.3.4</b>	<b>2004</b>	<b>Rated speed</b>	rpm	FLOAT		SIZE	10	32000	RWZ	INT	FVSY

Rated speed of the motor with full load in rpm. In some motors the synchronous speed (e.g. 1500 rpm for a 4-pole motor) and slippage, i.e. the loss of revolutions between the motor idling condition and the rated load condition (e.g. 80 rpm), is indicated. Enter the following: synchronous speed - slippage.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.3.5</b>	<b>2006</b>	<b>Rated frequency</b>	Hz	FLOAT		SIZE	1	1000	RWZ	INT	FVS

Rated frequency of the motor expressed in Hz.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>1.3.6</b>	<b>2008</b>	<b>Pole pairs</b>		UINT16		SIZE	1	60	RWZ	INT	FVSY
--------------	-------------	-------------------	--	--------	--	------	---	----	-----	-----	------

Motor pole pairs. The number of motor pole pairs is calculated using the motor plate data and applying the following formula:

$$p = \frac{60 [s] \times f [\text{Hz}]}{nN [\text{rpm}]}$$

Where: p = motor pole pairs; f = motor rated frequency (PAR 2006)

Vn = motor rated speed (PAR 2004).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>1.3.7</b>	<b>2010</b>	<b>Rated power</b>	kW	FLOAT		SIZE	0.1	1500	RWZ	INT	FVS
--------------	-------------	--------------------	----	-------	--	------	-----	------	-----	-----	-----

Rated power of the motor at the rated voltage and frequency. This value represents the mechanical power produced on the motor shaft.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>1.3.8</b>	<b>2012</b>	<b>Cos phi</b>		FLOAT		SIZE	0.6	0.95	RWZ	INT	FVS
--------------	-------------	----------------	--	-------	--	------	-----	------	-----	-----	-----

Motor power factor, as indicated on the data plate ( $\cos \phi$ ). This parameter is not always present on the motor data plate: in that case use the default value present in the drive.

## 1.4 Set mechanical data?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>1.4.1</b>	<b>11002</b>	<b>Travel units sel</b>		ENUM		Hz (m/s)			RWZ	INT	FVY
--------------	--------------	-------------------------	--	------	--	----------	--	--	-----	-----	-----

Selection of the unit of measure for speed references.

- 0** Hz (output frequency)
- 1** m/s (cabin speed and depends on the mechanical constant)
- 2** rpm (speed of the motor shaft)

When the unit of measure is modified the conversion constants are re-calculated, the units of measure are changed in the parameter list and the multispeed values are converted into the new unit of measure (the result may contain approximations due to the conversion calculations).

A variable representing the speed of the cabin in m/s (fpm) is always available (PAR 14242).

There are fixed units of measure for the acceleration and deceleration parameters  $m/s^2$ , and for jerks  $m/s^3$ .

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>1.4.2</b>	<b>11006</b>	<b>Cabin speed</b>	m/s	FLOAT		1	0	10	RWZ	INT	FVY
--------------	--------------	--------------------	-----	-------	--	---	---	----	-----	-----	-----

Sets the maximum speed of system operation. This is also used for the recalculation of the full scale speed (PAR 680, **Full scale speed**).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>1.4.3</b>	<b>11010</b>	<b>Gearbox ratio</b>		FLOAT		45 (1)	1	200	RW	INT	FVY
--------------	--------------	----------------------	--	-------	--	--------	---	-----	----	-----	-----

Sets the reduction ratio between motor and pulley.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>1.4.4</b>	<b>11164</b>	<b>Rope ratio</b>		FLOAT		1 (2)	1	10	RWZ	INT	FVY
--------------	--------------	-------------------	--	-------	--	-------	---	----	-----	-----	-----

Sets the reduction ratio due to rope windings.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>1.4.5</b>	<b>11012</b>	<b>Pulley diameter</b>	m	FLOAT		0.6 (0.32)	0	5	RWZ	INT	FVY
--------------	--------------	------------------------	---	-------	--	------------	---	---	-----	-----	-----

Impostazione del diametro della puleggia.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>1.4.6</b>	<b>11150</b>	<b>Car weight</b>	kg	FLOAT		400	0	10000	RW	INT	FVY
--------------	--------------	-------------------	----	-------	--	-----	---	-------	----	-----	-----

Setting of the weight of the cabin (intended as the total empty weight of everything hanging from the ropes: frame, walls, door operator, appliances, etc.).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.4.7	11152	Counter weight	kg	FLOAT		1000	0	10000	RW	INT	FVY
Setting of the weight of the counterweight, including its frame.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.4.8	11154	Load weight	kg	FLOAT		450	0	10000	RW	INT	FVY
Setting of the weight of the maximum load for system dimensions.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.4.9	11156	Rope weight	kg	FLOAT		20	0	1000	RW	INT	FVY
Setting of the weight of the cable (intended as the total weight of all car suspension ropes).											

## 1.5 Set speeds?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.1	11020	Multi speed 0		FLOAT		4.77 (0.1)	0	10000	RW	ESY	FVY
Setting of the multispeed 0 value. Can be selected via digital input, fieldbus, etc.											
The selected value is the reference for the S-shaped lift ramp. This setting is taken as the default low speed value. If the <b>Multi speed 0</b> value is changed, it will only be acquired when the drive is rebooted.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.2	11022	Multi speed 1		FLOAT		47.73 (1.0)	0	10000	RW	ESY	FVY
Setting of the multispeed 1 value. Can be selected via digital input, fieldbus, etc.											
The selected value is the reference for the S-shaped lift ramp. This setting is taken as the default high speed value.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.3	11024	Multi speed 2		FLOAT		21.48 (0.4)	0	10000	RW	ESY	FVY
Setting of the multispeed 2 value. Can be selected via digital input, fieldbus, etc.											
The selected value is the reference for the S-shaped lift ramp. This setting is taken as the default maintenance speed value.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.4	11026	Multi speed 3		FLOAT		0	0	10000	RW	ESY	FVY
Setting of the multispeed 3 value. Can be selected via digital input, fieldbus, etc.											
The selected value is the reference for the S-shaped lift ramp.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.5	11028	Multi speed 4		FLOAT		0	0	10000	RW	ESY	FVY
Setting of the multispeed 4 value. Can be selected via digital input, fieldbus, etc.											
The selected value is the reference for the S-shaped lift ramp.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.6	11030	Multi speed 5		FLOAT		0	0	10000	RW	ESY	FVY
Setting of the multispeed 5 value. Can be selected via digital input, fieldbus, etc.											
The selected value is the reference for the S-shaped lift ramp.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.7	11032	Multi speed 6		FLOAT		0	0	10000	RW	ESY	FVY
Setting of the multispeed 6 value. Can be selected via digital input, fieldbus, etc.											
The selected value is the reference for the S-shaped lift ramp.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.8	11034	Multi speed 7		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 7 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

#### Note!

By default, the multispeed 0, 1 and 2 have the values 5.00Hz, 47.73Hz and 20Hz respectively referred to a cabin speed of 1m/s.

The first three multispeeds take the values of 10%, 100% and 45% of the cabin speed each time the mechanical data is changed.

In addition, each time mechanical data is changed, the drive performs a multispeed congruity check that works as follows:

a) where a multispeed is greater than the nominal speed, it shall be limited to that speed;

b) if the mechanical values are changed further and the previously limited speeds are now lower than the nominal speed, these multispeeds are not changed (bearing in mind that the first 3 multispeeds always take the values in %).

By manually entering values of multispeed these are limited to the cabin speed, while following a change in the mechanical parameters that change the cabin speed, will be returned to the default values percentages.

## 1.7 Run autotune still?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.7.1	2032	Autotune		BIT		0	0	1	RWZ	INT	FVSY

Performs self-tuning with the motor having ropes already wound on the traction pulley.

The self-tuning procedure may cause limited rotation of the motor shaft. To perform self-tuning, follow the procedure described on parameter PAR 2020 **Take parameters**.

## 1.8 Save parameters?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.8.1	550	Save parameters		BIT		0	0	1	RW	INT	FVSY

Any changes to parameter values immediately affect drive operations, but are not automatically saved in the permanent memory.

The "Save Parameters" command is used to save current parameter values in the permanent memory.

Any changes that are not saved will be lost when the drive is switched off.

To save parameters press the **E** key to start the save parameters procedure and press **E** again to confirm.

## 2 OPTIMIZATION WIZARD (OPTIMIZ. WIZARD)

Through this menu it is possible to immediately optimize the control response in order to maximise cabin comfort.

In addition to the automatic procedure (**Learning Trip** function), three or five levels of optimization are available for each of the **Rollback**, **Comfort low speed**, **Comfort high speed** parameters.

To avoid possible vibrations, the optimization level should not be increased if not necessary.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
2.1	9720	Learning trip		BIT		0	0	1	RWZ	INT	VSY

Launch the "Learning Trip" function, an automatic procedure to simplify commissioning and optimise the drive according to the system's mechanical parameters.




Before enabling the function:

- run the **Startup wizard**,
- check cabin movement in inspection mode to rule out any macroscopic data entry errors.

The function can be performed from the keypad and via the WEG\_DriveLabs configurator (Wizard menu / Optimization Wizard).

To facilitate operations, the configurator/keypad suggests what actions are to be performed (e.g. up one floor, down one floor, etc.), intercepting any incorrect actions and communicating them (e.g. call to floor short, calls always in the same direction, etc.) so as to recommend the corrective action.

Once the sequences envisaged by the function have been completed, the basic speed regulator gains are automatically recalculated. Therefore the user can run a test travel to evaluate the improvement in performance obtained and, if still not satisfied, the Learning Trip procedure can be repeated or the deficient aspects improved using the appropriate sections of the optimisation wizard (Rollback, Comfort low speed, Comfort high speed).



- (1) You are prompted to perform the first run (up or down).
- (2) Perform the up run.
- (3) You are prompted to perform a down run.
- (4) Perform the down run.
- (5) Repeat the operations (1) (2) (3) (4) several times.
- (6) Procedure successfully completed.

Other possible messages:



Procedure not successfully completed.

Short run error.

Wrong direction error.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
2.2	12000	Rollback at start		UINT32		1	1	5	RW	ESY	FVY

In some applications, for a short time at the start of the stroke when the locking brake is lifted, the cab may move in the opposite direction to the controlled direction.

Selecting one of the five levels can reduce/eliminate the noise.

- 1 Basic level pre-selected as default level
- 2 Intermediate optimization level 2
- 3 Intermediate optimization level 3
- 4 Intermediate optimization level 4
- 5 High optimization level

To avoid possible vibrations, the optimization level should not be increased if not necessary.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
2.3	12006	Rollback at arrival		UINT32		1	1	3	RW	ESY	FVY

In some applications, an undesired displacement of the cab may occur for a short time at the end of the stroke when the engine is held still while waiting for the brake to close.

Selecting one of the five levels can reduce/eliminate the noise.

- 1 Basic level pre-selected as default level
- 2 Intermediate optimization level 2
- 3 Intermediate optimization level 3
- 4 Intermediate optimization level 4
- 5 High optimization level

To avoid possible vibrations, the optimization level should not be increased if not necessary.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
2.4	12002	Comfort high spd		UINT32		1	1	3	RW	ESY	FVY

During the high speed section there may be oscillations in the cabin or abrupt and sudden movements.

By selecting one of the five levels the disturbance can be reduced or eliminated.

- 1 Basic level pre-selected as default level
- 2 Intermediate optimization level 2
- 3 High optimization level

To avoid possible vibrations, the optimization level should not be increased if not necessary.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
2.5	12004	Comfort low spd		UINT32		1	1	3	RW	ESY	FVY

During the low speed section there may be oscillations in the cabin or abrupt and sudden movements.

By selecting one of the five levels the disturbance can be reduced or eliminated.

- 1 Basic level pre-selected as default level
- 2 Intermediate optimization level 2
- 3 High optimization level

To avoid possible vibrations, the optimization level should not be increased if not necessary.

## 3 TROUBLESHOOTING

For each typical problem of a Lift System, the parameter of the drive on which to act to solve the problem, are displayed by selecting the relative action.

### 3.1 Start

Problem				Solution							
The cabin doesn't start smoothly.				Increase the brake opening delay.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.1.1	11064	Brake open delay	ms	INT16/32		500	0	10000	RW	ESY	FVY

Setting of the brake opening delay time.

### 3.2 Rollback

Problem				Solution							
There is an unwanted movement of the cabin in the opposite direction to the commanded at the start.				Modify the proportional and /or integral speed gain at start.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.2.1	2200	Boost Voltage	%	FLOAT		3	0	20.0	RW	INT	F

Specifica il valore della tensione supplementare applicata ai morsetti del motore alle basse velocità al fine di incrementare la coppia erogata. Valori eccessivi producono un aumento della corrente assorbita e del riscaldamento del motore a causa delle perdite resistive nell'avvolgimento statorico.

Intervallo di valori possibili : 0...20% della tensione nominale del motore.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.2.2	2212	V/Hz Boost Mode		ENUM		Auto			RW	INT	F

This parameter can be used to select one of the following two boost voltage generation modes:

- 0 Fixed
- 1 Auto

In the "Fixed" mode, the boost voltage is defined by the user through parameter PAR 2200 **Boost voltage**.

At zero speed, the drive applies a voltage to the motor terminals equal to the value defined in parameter PAR 2200.

This additional voltage is gradually reduced for speeds higher than zero until it is eliminated for output frequencies above the threshold equal to half the rated frequency defined in parameter PAR 2204 **Base frequency** (see figure).

In "Auto" mode the boost voltage is dynamically adjusted by the drive.




Figure 11.4: V/f characteristic curve profile

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

3.2.3	2794	<b>SR-P gain at start</b>	%	FLOAT		150.0	0.0	400.0	RW	INT	VSY
-------	------	---------------------------	---	-------	--	-------	-----	-------	----	-----	-----

Defines the level of proportional control exercised by the PI regulator during the start phase.

In this initial phase the motor speed control loop must be sufficiently responsive to compensate for any load imbalance and thus counteract the roll-back effect.

An excessive increase of this parameter may generate system vibrations or unstable behaviour.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

3.2.4	2796	<b>SR-I gain at start</b>	%	FLOAT		110.0	0.0	400.0	RW	INT	VSY
-------	------	---------------------------	---	-------	--	-------	-----	-------	----	-----	-----

Defines the level of integral control exercised by the PI regulator during the start phase.

Increasing the value of this parameter improves the speed control response in compensating for any load imbalance when the brake is opened.

### 3.3 Too fast acceleration (Too fast accel.)

Problem				Solution							
The acceleration is too abrupt.				Decrease the value of the initial acceleration jerk and / or acceleration value.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

3.3.1	11040	<b>Accel initial jerk</b>	m/s <sup>3</sup>	FLOAT		0.2	0.001	20	RW	ESY	FVY
-------	-------	---------------------------	------------------	-------	--	-----	-------	----	----	-----	-----

Setting of the jerk value for the first part of the acceleration.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

3.3.2	11042	<b>Acceleration</b>	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY
-------	-------	---------------------	------------------	-------	--	-------	-------	----	----	-----	-----

Setting of the maximum acceleration value.

### 3.4 Slow speed vibrations (Slow speed vibr.)

Problem				Solution							
There are vibrations during the movement of the cabin at slow speed.				Modify the proportional and integral speed gain.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

3.4.1	2752	<b>SR-P gain low speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
-------	------	----------------------------	---	-------	--	-------	-----	-------	----	-----	-----

Defines the level of the proportional control action exercised by the PI regulator for operating speeds below the minimum threshold defined in parameter PAR 2760 **SR-low speed thrsd**.

For operating speeds above this threshold, the actual level of proportional action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2756 **SR-P gain high speed**.

In the speed range between the thresholds defined in PAR 2760 SR-low speed thrsd and PAR 2762 **SR-high speed thrsd** parameters, the weight of the proportional action varies linearly with the speed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

3.4.2	2754	<b>SR-I gain low speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
-------	------	----------------------------	---	-------	--	-------	-----	-------	----	-----	-----

Defines the level of the integral control action exercised by the PI regulator for operating speeds below the minimum

threshold defined in parameter PAR 2760 **SR-low speed thrsd**.

For operating speeds above this threshold, the actual level of integral action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2758 **SR-I gain high speed**.

In the speed range between the thresholds defined in PAR 2760 **SR-low speed thrsd** and PAR 2762 **SR-high speed thrsd** parameters, the weight of the proportional action varies linearly with the speed.

### 3.5 High speed vibrations (High speed vibr.)

Problem				Solution							
There are vibrations during the movement of the cabin at high speed.				Modify the proportional and integral speed gain.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.5.1	2756	<b>SR-P gain high speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY

Defines the level of the proportional control action exercised by the PI regulator for operating speeds above the maximum threshold defined in parameter PAR 2762 **SR-high speed thrsd**.

For operating speeds lower than this threshold, the actual level of proportional action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2752 **SR-P gain low speed**.

In the speed range between the minimum and maximum thresholds defined in PAR 2760 **SR-low speed thrsd** and PAR 2762 **SR-high speed thrsd** parameters, the weight of the proportional action varies linearly with the speed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.5.2	2758	<b>SR-I gain high speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY

Defines the level of the integral control action exercised by the PI regulator for operating speeds above the maximum threshold defined in parameter PAR 2760 **SR-low speed thrsd**.

For operating speeds lower than this threshold, the actual level of integral action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2754 **SR-I gain low speed**.

In the speed range between the thresholds defined in PAR 2760 **SR-low speed thrsd** and PAR 2762 **SR-high speed thrsd** parameters, the weight of the integral action varies linearly with the speed.

### 3.6 Too fast deceleration (Too fast dec.)

Problem				Solution							
The deceleration with which the cabin approaches the floor is too abrupt.				Decrease the value of the initial deceleration jerk and / or deceleration value.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.6.1	11046	<b>Decel initial jerk</b>	m/s <sup>3</sup>	FLOAT		0.6	0.001	20	RW	ESY	FVY

Setting of the jerk value for the first part of the deceleration.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.6.2	11048	<b>Deceleration</b>	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY

Setting of the maximum deceleration value.

### 3.7 Floor leveling

Problem				Solution							
During the arrival at the floor there is an abrupt stop.				Decrease the brake closing delay.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.7.1	11068	<b>Brake close delay</b>	ms	INT16/32		500	0	10000	RW	ESY	FVY

Setting of the delay time after closing the brake.

### 3.9 Vibration analyzer

Problem				Solution							
Vibration analyzer measures system vibration expressed in two most significant resonant frequencies.				Values greater than 0 may indicate system vibrations. Typical causes could be intrinsic resonances of the system itself. insufficient guides lubrication, ovalized guide wheels, etc. If you need any advice on vibration damping you can contact after-sale service.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.9.1	9464	<b>Vibratio freq. 1</b>	Hz	FLOAT		0	0.0	0.0	R	INT	VSY
Indicates the value in Hz of the first measured resonance frequency. If two frequencies have been detected, <b>Vibration freq. 1</b> will be the one with the higher amplitude. A "0" value indicates that no resonance frequency is present in the measurement band.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.9.2	9466	<b>Vibration freq. 2</b>	Hz	FLOAT		0	0.0	0.0	R	INT	VSY
Indicates the value in Hz of the second measured resonance frequency. If two frequencies have been detected, <b>Vibration freq. 2</b> will be the one with the lower amplitude. A "0" value indicates that no second resonance frequency is present in the measurement band.											

## 4 DRIVE

### 4.1 DRIVE MONITOR

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.1	250	<b>Output current</b>	A	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
The drive output current is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.2	252	<b>Output voltage</b>	V	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
The drive line voltage output is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.3	254	<b>Output frequency</b>	Hz	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
The drive output frequency is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.4	664	<b>Speed setpoint</b>	rpm	INT16	16BIT_H	0	0	0	R	ESY	FVSY
The motor speed reference is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.5	260	<b>Motor speed</b>	rpm	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
The actual output speed of the motor is displayed (in ASY FOC/SYN = speed measured by the encoder, in ASY VF = speed estimated by the drive).											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.6	270	<b>DC link voltage</b>	V	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
The direct voltage of the intermediate circuit capacitors is displayed (DC-Bus).											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.7	272	<b>Heatsink temperature</b>	degC	FLOAT	16BIT_L	0	0	0	R	ESY	FVSY
The temperature measured by the linear sensor integrated in the IGBT modules is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.9	280	<b>Torque current ref</b>	A	FLOAT	16BIT_H	0	0	0	R	EXP	FVSY
The current reference used for torque control is displayed (in the sensorless vector and field-oriented vector modes).											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.10	282	<b>Magnet current ref</b>	A	FLOAT	16BIT_H	0	0	0	R	EXP	FVSY
The magnetizing current reference is displayed (in the sensorless vector and field-oriented vector modes).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.11	284	<b>Torque current</b>	A	FLOAT	16BIT_H	0	0	0	R	INT	FVSY
The actual torque current value is displayed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.12	286	<b>Magnet current</b>	A	FLOAT	16BIT_H	0	0	0	R	INT	FVSY
The actual magnetizing current value is displayed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.13	3212	<b>Motor overload</b>	%	UINT16	16BIT_H	0	0	100	R	ESY	FVSY
The motor overload level is displayed (100% = alarm threshold).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.14	368	<b>Drive overload</b>	%	UINT16	16BIT_H	0	0	100	R	ESY	FVSY
The drive overload level is displayed. An instantaneous overload of 200% of the drive rated current is allowed for 10s. The thermal image $I^2t$ adjusts the drive output current thresholds. During normal operation, the instantaneous output current value can reach 200% of the drive rated current. When the overload level par. 368 <b>Drive overload</b> reaches 100%, the output current threshold is reduced to 100% of the rated current, and stays at that value until the $I^2t$ integrator cycle is complete. At this point the instantaneous overload of 200% or 150% (below 3Hz) will be re-activated.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.15	3260	<b>Bres overload</b>	%	UINT16	16BIT_H	0	0	100	R	ESY	FVSY
The braking resistor overload limit is displayed (100% = alarm threshold).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.16	1066	<b>Enable state mon</b>	UINT16	16BIT_L	0	0	1	R	ESY	FVSY	
The drive Enable command status is displayed. Voltage must be present on terminal 9, in the case of ADL550 also at the Safety enable terminals. The FR Forwardstart command is needed to start the inverter.											
1 Enabled Drive enabled 0 Disabled Drive disabled											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.17	1068	<b>Start state mon</b>	UINT16	16BIT_L	0	0	1	R	ESY	FVSY	
The drive <b>Start</b> command status is displayed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.18	1070	<b>FastStop state mon</b>	UINT16	16BIT_L	0	0	1	R	ESY	FVSY	
The drive <b>FastStop</b> command status is displayed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.19	2386	<b>Torque ref</b>	%	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY
The value of the torque reference is displayed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.20	2388	<b>Torque</b>	%	FLOAT	16BIT_H	0.0	0.0	0.0	R	INT	FVSY
Displays the current torque value.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.21	372	In use current limit	A	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
Displays the actual current limit.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.23	1200	Dig input mon		UINT16	16BIT_L	0	0	0	R	ESY	FVSY
The logic status of the digital inputs is displayed. It can also be read via a serial line or fieldbus. The data are contained in a word, where each bit is 1 if voltage is supplied to the corresponding input terminal.											
1 Input high. 0 Input low.											

Example:

0	0	0	0	0	0	0	0	0	1	1	
Enable DI 1											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.25	1400	Digital output mon		UINT16		0	0	0	R	ESY	FVSY
The status of the digital outputs is displayed. It can also be read via a serial line or fieldbus. The data are contained in a word, where each bit is 1 if the associated output relay is closed.											
1 Output enabled. 0 Output disabled.											

Example:

0	0	0	0	0	0	0	0	0	1	1	
DO 1 DO 2											

## 4.2 DRIVE INFO

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.2.1	172	Drive type		ENUM		ADL510			R	ESY	FVSY
The drive series identification code is displayed.											
1 ADL510 2 ADL530 3 ADL550											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.2.2	482	Drive size		UINT16		0	0	0	R	ESY	FVSY
The drive power size is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.2.3	484	Drive family		ENUM		No Power			R	INT	FVSY
The mains voltage range accepted by the drive is displayed (e.g. 230V..480V). The undervoltage alarm refers to this voltage value. The condition <b>No power</b> occurs when the regulation board has just left from production and has never been configured for any power.											
0 No power 1 230V..480V											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.2.4	488	Drive cont current	A	FLOAT		CALCF	0.0	0.0	R	ESY	FVSY
The current that the drive can deliver continuously according to size, supply voltage and programmed switching frequency is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.6</b>	<b>174</b>	<b>Firmware version</b>		UINT32		0	0	0	R	ESY	FVSY
The HMI firmware version operating in the drive is displayed in the X.X.X format: the first is the (X.X.X) firmware version, the second the (X.X.X) firmware release, and the third is the (X.X.X) firmware type.											
On the keypad these are displayed in the version.release format. The parameter reading from the serial communication device or fieldbus returns the version in the high byte and the release in the low byte.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.7</b>	<b>176</b>	<b>DSP Firmware version</b>		UINT32		0	0	0	R	ESY	FVSY
The firmware version of the DSP application operating in the drive is displayed in the X.X.X format: the first is the (X.X.X) firmware version, the second the (X.X.X) firmware release, and the third is the (X.X.X) firmware type..											
On the keypad these are displayed in the version.release format. The parameter reading from the serial communication device or fieldbus returns the version in the high byte and the release in the low byte.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.8</b>	<b>180</b>	<b>DSP Boot version</b>		UINT32		0	0	0	R	ESY	FVSY
Processor boot version.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.9</b>	<b>182</b>	<b>HMI Boot version</b>		UINT32		0	0	0	R	ESY	FVSY
Processor boot version.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.10</b>	<b>184</b>	<b>Application name</b>		STRING16		0	0	0	R	ESY	FVSY
Displays the name of the installed application.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.11</b>	<b>192</b>	<b>Application version</b>		UINT32		0	0	0	R	ESY	FVSY
The firmware version of the application operating in the drive is displayed in the XX.XX.XX format: the first is the (XX.XX.XX) firmware version, the second the (XX.XX.XX) firmware release, and the third is the (XX.XX.XX) firmware type.											
On the keypad these are displayed in the version.release format. The parameter reading from the serial communication device or fieldbus returns the version in the high byte and the release in the low byte.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.12</b>	<b>198</b>	<b>Hardware version</b>		UINT16		0	0	0	R	ESY	FVSY
The hardware version of the adjustment board is displayed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.13</b>	<b>520</b>	<b>Product S/N</b>		UINT32		0	0	0	R	ESY	FVSY
The drive serial number is displayed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.14</b>	<b>522</b>	<b>Regulation S/N</b>		UINT32		0	0	0	R	ESY	FVSY
The drive regulation card serial number is displayed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.15</b>	<b>524</b>	<b>Power S/N</b>		UINT32		0	0	0	R	ESY	FVSY
The drive power card serial number is displayed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.16</b>	<b>526</b>	<b>Power file ver.rel</b>		UINT16		0	0	0	R	ESY	FVSY
The drive power card configuration release is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.17</b>	<b>9562</b>	<b>IP address</b>		UINT32		0	0	0	R	ESY	FVSY

Displays the IP address in use.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.18</b>	<b>9600</b>	<b>MAC address</b>		STRING16		0	0	0	R	EXP	FVSY

Displays the drive's MAC address.

## 4.3 DRIVE CONFIG

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.1	550	<b>Save parameters</b>		BIT		0	0	1	RW	ESY	FVSY

Any changes to parameter values immediately affect drive operations, but are not automatically saved in the permanent memory. The “Save Parameters” command is used to save current parameter values in the permanent memory.

Any changes that are not saved will be lost when the drive is switched off.

To save parameters follow the procedure described in STEP 7 of the **Startup wizard**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.2	580	<b>Load default</b>		BIT		0	0	1	RWZ	ESY	FVSY

Transfers the standard factory settings to the drive memory (“Def” column in the parameters table).

This does not apply to the access level and password parameters, for which see the menu “6.6 NETWORK AND ACCESS” on page 87).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.3	540	<b>Control type</b>		ENUM		ASY_VF			RWZ	INT	FVSY

The ADL550 can operate in different control modes:

- 0 ASY SSC
- 1 ASY FOC

**ASY SSC**: the open loop V/f mode. It is the simplest type of asynchronous motor control, as the only parameters required are the rated voltage, current and frequency of the motor.

The ASY SSC control mode is factory-set and does not require any speed feedback. The natural variation in speed generated by machine load induction (slippage) can be compensated using PAR **2214 V/Hz Slip ctrl gain** and **2224 V/Hz slip filter constant**.

**ASY FOC**: in the **field oriented vector mode** an encoder is required for closed loop feedback. With this mode it is possible to achieve extremely high dynamic responses thanks to the regulation bandwidth, maximum torque even with the rotor blocked, speed and torque control. Numerous regulation parameters can be used to adjust the drive to each specific application, for instance adaptive gains, system inertia compensation, etc.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.4	554	<b>Access level</b>		ENUM		Intermediate			RW	ESY	FVSY

Determines the parameters that can be displayed and/or modified to suit the operator's needs and capabilities.

- 0 Readonly
- 1 Easy
- 2 INT
- 3 Expert
- 4 Service

**Readonly**: read-only level, where a limited number of parameters are displayed.

**Easy**: level that allows parameters to be displayed and modified for basic commissioning, in V/f control and without tuning.

**Intermediate**: level that allows parameters to be displayed and modified for complete commissioning and basic optimization.

**Expert**: level that allows parameters to be displayed and modified for advanced optimization.

**Service**: reserved for Service.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.5	568	<b>Enable password</b>		BIT		0	0	1	RW	EXP	FVSY

When this parameter is OFF (default), it is possible to change the selection of PAR 554 **Access level** (parameter access level, excluding Service level) without entering the password.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.7	560	<b>Mains voltage</b>		ENUM		400 V			RWZ	INT	FVSY

Setting of the available mains voltage value in Volts. Detection of the undervoltage alarm refers to this value.

- 2 380 V
- 3 400 V

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>4.3.8</b>	<b>448</b>	<b>Emergency UV</b>	V	FLOAT		CALCF	0	CALCF	RWZ	INT	FVSY
--------------	------------	---------------------	---	-------	--	-------	---	-------	-----	-----	------

This parameter enables for the undervoltage threshold to be configured during emergency conditions.

This parameter also identifies the voltage at which it is necessary to send the closing command of the precharge relay (which must take place when the voltage on the DC-link has exceeded approximately 70% of its final value). In the presence of batteries connected to the EM input, parameter 448 must be set manually to 70% of the minimum output voltage of the battery pack (or, more generally, of the power source used).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>4.3.9</b>	<b>450</b>	<b>Undervoltage</b>	V	FLOAT		300.0	0	0	RW	INT	FVSY
--------------	------------	---------------------	---	-------	--	-------	---	---	----	-----	------

Lets you change the Undervoltage value. Minimum and maximum default values depend on line voltage.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>4.3.10</b>	<b>2690</b>	<b>Chopper ON</b>	V	FLOAT		CALCF	0	CALCF	RW	EXP	FVY
---------------	-------------	-------------------	---	-------	--	-------	---	-------	----	-----	-----

Corresponds to the threshold of activation of the braking resistance. It's so possible to increase this value to the level of the overvoltage threshold.

(ADL500-...-4 = 802 Vdc, ADL500-...-2T = 396 Vdc, ADL500-...-2M = 396 Vdc).

The range is defined by the parameter 560 Mains voltage.

**Note!**

If the mains voltage parameter is set to the maximum possible value, the brake resistance activation threshold can only take the maximum value and cannot be changed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>4.3.11</b>	<b>1010</b>	<b>Fast Start disable</b>		BIT		1	0	1	RW	EXP	FVSY
---------------	-------------	---------------------------	--	-----	--	---	---	---	----	-----	------

Changes the engine start mode after a drive restart. In ON mode the drive, after switching on, starts only if the direction input is activated after the drive signal Ok. With OFF mode the drive, after switching on, starts after the OK drive signal seeing the status of the direction signal even if this has been activated before the OK drive signal becomes high.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>4.3.12</b>	<b>574</b>	<b>Startup display</b>		INT16		-1	-1	20000	RW	INT	FVSY
---------------	------------	------------------------	--	-------	--	----	----	-------	----	-----	------

It is possible to set the parameter number that will automatically be displayed when the drive is switched on.

If set to -1 the main menu is automatically displayed when the drive is turned on.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>4.3.13</b>	<b>576</b>	<b>Display backlight</b>		BIT		0	0	1	RW	INT	FVSY
---------------	------------	--------------------------	--	-----	--	---	---	---	----	-----	------

Enabling of the backlight on the drive display.

If set to 0 (Off) the display backlight will go off when the drive has been on for three minutes.

If set to 1 (On) the backlight will stay on for as long as the drive is powered.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>4.3.14</b>	<b>578</b>	<b>Language select</b>		ENUM		GB			RW	INT	FVSY
---------------	------------	------------------------	--	------	--	----	--	--	----	-----	------

Setting of the drive programming language.

**0** English

**1** Italian

**2** French

**3** German

**4** Spanish

**5** Turkish

English and Italian are pre-installed on the drive, to select Italian set **1**.

To set a different language, download the available languages file from the WEG site ([https://www.weg.net/...](https://www.weg.net/), DRIVE SET-UP folder) (wizard available in manual ADL500 HW+QS, section 8.2.8.1 Language selection):

- Unzip and save the files on a USB flash drive, in a folder called "ADL500LN".
- Insert the flash drive into the drive's USB port.
- Select the **Language Select** parameter 570 and set the new language,
- Start the language loading procedure, after which the drive will reboot.

**Note!**

The language file must be aligned with the version of both the drive firmware and application. Check correspondence.

The new language will be loaded into the drive memory and replace the Italian. English cannot be replaced by another language.

**Note!**

The Load Default command (par. 580) does not modify this parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.15	7200	<b>Password recovery</b>		BIT		0	0	1	RW	ESY	FVSY

If executed, it generates a code in PAR 7210 **Recovery code** to be communicated to WEG to obtain a temporary Expert password. To be used in case the password is lost.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.16	7210	<b>Recovery code</b>		UINT32		0.0	0	0	R	ESY	FVSY

This parameter is used to write the code to be communicated to WEG to obtain a temporary Expert password (see PAR 7200 **Password recovery**). To be used in case the password is lost.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.17	7220	<b>Alarm time</b>	min	UINT16		60	0	1092	RW	EXP	FVSY

Sets the drive logout time, in minutes, calculated from the first start-up.

Once the activity time set in this parameter has elapsed the drive will be reset to Readonly level.

If set to 0, automatic logout is disabled.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.18	590	<b>Save par from keypad</b>		BIT		0	0	1	RWZ	INT	FVSY

Transfers the parameters currently stored in the drive and saves them in the keypad memory.

## 4.4 ALARM CONFIG

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.1	4500	<b>Fault reset src</b>		LINK	16BIT_L	6000			RW	INT	FVSY

Selection of the origin (source) of the signal to be used for the command to reset the drive after an alarm. The terminal that can be used for this function can be selected from among those listed in the “L\_DIGSEL2” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.2	4502	<b>ExtFlt src</b>		LINK	16BIT_L	6000			RW	INT	FVSY

Selection of the origin (source) of the signal to be used as the input for the drive external fault alarm **External fault [21]**. The terminal that can be used for this function can be selected from among those listed in the “L\_DIGSEL2” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.3	4504	<b>ExtFlt activity</b>		ENUM		Disable			RW	INT	FVSY

Setting of the behaviour of the drive in the event of an external fault alarm **External fault [21]**. This alarm indicates the intervention of a drive external protection.

- 0** Ignore
- 1** Warning
- 2** Disable drive
- 3** Stop
- 4** Fast stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.4	4506	<b>ExtFlt restart</b>		ENUM		Disable			RW	EXP	FVSY

Enabling of automatic restart after the **External fault [21]** alarm.

- 0** Disable
- 1** Enable

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.5	4508	<b>ExtFlt restart time</b>	ms	UINT16		1000	120	30000	RW	EXP	FVSY
Setting of the time within which the <b>External fault [21]</b> alarm must be reset in order to perform automatic restart.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Liv.	Vis.
4.4.6	4510	<b>ExtFlt holdoff</b>	ms	UINT16		0	0	10000	RW	INT	FVSY
Setting of the delay between the signalling of the external fault alarm <b>External fault [21]</b> and enabling of the alarm. If an alarm condition occurs, the drive will wait for the set time before blocking is enabled. If the alarm is removed within the set time, the drive will not indicate any alarm condition.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.8	4520	<b>MotorOT src</b>		LINK	16BIT_L	6000			RW	INT	FVSY
Selection of the origin (source) of the signal to be used for the motor overtemperature alarm <b>MotorOT [12]</b> . The terminal that can be used for this function can be selected from among those listed in the “L_DIGSEL2” selection list”.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.9	4522	<b>MotorOT activity</b>		ENUM		Warning			RW	INT	FVSY
Setting of the behaviour of the drive in case of a motor overtemperature alarm <b>MotorOT [12]</b> . This alarm indicates that the motor temperature is too high.											
<ul style="list-style-type: none"> <li>0 Ignore</li> <li>1 Warning</li> <li>2 Disable drive</li> <li>3 Stop</li> </ul>											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.10	4524	<b>MotorOT restart</b>		ENUM		Disable			RW	EXP	FVSY
Enabling of automatic restart after the motor overtemperature alarm <b>Motor OT [12]</b> .											
<ul style="list-style-type: none"> <li>0 Disable</li> <li>1 Enable</li> </ul>											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.11	4526	<b>MotorOT restart time</b>	ms	UINT16		1000	120	30000	RW	EXP	FVSY
Setting of the time within which the <b>Motor OT [12]</b> alarm must be reset in order to perform automatic restart.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.12	4528	<b>MotorOT holdoff</b>	ms	UINT16		1000	0	30000	RW	EXP	FVSY
Setting of the delay between the signalling of the motor overtemperature alarm <b>MotorOT [12]</b> and enabling of the alarm. If an alarm condition occurs, the drive will wait for the set time before enabling the alarm. If the alarm is removed within the set time, the drive will not indicate any alarm condition											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.18	4540	<b>Overspeed threshold</b>	rpm	INT16		CALCI	0	16000	RW	INT	FVSY
Setting of the threshold above which the overspeed alarm <b>Overspeed [23]</b> is enabled.											
<b>Note!</b> The Overspeed threshold value (together with the Full scale speed PAR 680), is automatically recalculated each time the mechanical data parameters are modified.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.19	4542	<b>Overspeed activity</b>		ENUM		Disable			RW	INT	FVSY
Setting of the behaviour of the drive in case of a motor overspeed alarm <b>Overspeed [23]</b> . This alarm indicates that the motor speed has exceeded the threshold set in PAR 4540 <b>Overspeed threshold</b> .											
<ul style="list-style-type: none"> <li>0 Ignore</li> <li>1 Warning</li> <li>2 Disable drive</li> </ul>											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.20	4544	Overspeed holdoff	ms	UINT16		0	0	5000	RW	INT	FVSY

Setting of the delay between the signalling of the motor overspeed alarm **Overspeed** [23] and enabling of the alarm. If an alarm condition occurs, the drive will wait for the set time before enabling the alarm. If the alarm is removed within the set time, the drive will not indicate any alarm condition.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.21	4550	SpdRefLoss threshold	rpm	INT16		100 (*)	0	CALCI	RW	INT	FVSY

Setting of the threshold below which the speed reference loss alarm **Speed ref loss** [24] occurs.

(\*) Def: 100 = ASY FOC, 10 = SYN FOC

**Note!**

The Overspeed threshold value (together with the Full scale speed PAR 680), is automatically recalculated each time the mechanical data parameters are modified.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.22	4552	SpdRefLoss activity		ENUM		Disable			RW	INT	FVSY

Setting of the behaviour of the drive in case of a speed reference loss alarm **Speed ref loss** [24]. This alarm indicates that the difference between the speed regulator reference and the actual motor speed is more than 100 rpm.

This alarm must be disabled (= 0 Ignore) when parameter **2354** is set to a value other than zero.

- 0 Ignore
- 1 Warning
- 2 Disable drive

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.23	4554	SpdRefLoss holdoff	ms	UINT16		1000	0	10000	RW	INT	FVSY

The delay between the **Speed ref loss** [24] alarm condition signal and activation of the actual alarm. If an alarm condition occurs, the drive will wait for the set time before enabling the alarm. If the alarm is removed within the set time, the drive will not indicate any alarm condition.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.24	4560	SpdFbkLoss activity		ENUM		Disable			RW	INT	FVSY

Drive behaviour in case of the **Speed ref loss** [24] alarm is displayed. This alarm indicates the loss of the encoder feedback signals. Each type of encoder generates the **Speed ref loss** [24] alarm differently (incremental signal error, absolute signal error, serial error).

- 0 Ignore
- 1 Warning
- 2 Disable drive

For absolute Endat encoders and absolute Hiperface encoders, after the alarm is generated, the encoder reset command must be sent to the encoder: during this procedure the application verifies whether the encoder is signalling an encoder alarm condition to the drive and the alarm is acquired from this.

The causes of the **Speed ref loss** [24] alarm and the information acquired from the encoder are shown in the **SpdFbk-Loss code** parameter 2172.

**Note!**

See menu "8 ENCODER" for further information.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.25	4562	SpdFbkLoss holdoff	ms	UINT16		200	0	10000	RW	INT	FVSY

Setting of the delay between the signalling of the speed feedback loss alarm condition **Speed fbk loss** [22] and the enabling of the alarm. If an alarm condition occurs, the drive will wait for the set time before enabling the alarm. If the alarm is removed within the set time, the drive will not indicate any alarm condition.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.26	4564	SpdfbkLoss threshold	rpm	INT16	100	0	CALCI	RW	INT	FVSY	

Setting the minimum speed by which the **Speed fbk loss** [22] is bypassed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.27	4570	<b>Drive ovlD activity</b>		ENUM		Disable			RW	EXP	FVSY
Setting of the behaviour of the drive in case of a drive overload alarm <b>Drive ovlD</b> . This alarm indicates that the drive overload threshold has been reached.											
		0 Ignore									
		1 Warning									
		2 Disable drive									
		3 Stop									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.28	4572	<b>Motor ovlD activity</b>		ENUM		Warning			RW	EXP	FVSY
Setting of the behaviour of the drive in case of a motor overload alarm <b>Motor overload [14]</b> . This alarm indicates that the motor overload threshold has been reached.											
		0 Ignore									
		1 Warning									
		2 Disable drive									
		3 Stop									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.29	4574	<b>Bres ovlD activity</b>		ENUM		Disable			RW	EXP	FVSY
Setting of the behaviour of the drive in case of a braking resistor overload alarm <b>Bres overload [15]</b> . This alarm indicates that the braking resistor overload threshold has been reached.											
		0 Ignore									
		1 Warning									
		2 Disable drive									
		3 Stop									
		4 Fast stop									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.30	4582	<b>HTsens restart</b>		ENUM		Disable			RW	EXP	FVSY
Enabling of automatic restart after the drive heatsink overtemperature alarm <b>Heatsink OT [9]</b> .											
		0 Disable									
		1 Enable									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.31	4584	<b>HTsens restart time</b>	ms	UINT16		20000	120	60000	RW	EXP	FVSY
Setting of the time within which the <b>Heatsink OT [9]</b> alarm must be reset in order to perform automatic restart.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.32	4610	<b>Desat restart</b>		ENUM		Disable			RW	EXP	FVSY
Enabling of automatic restart after the desaturation alarm <b>Desaturation [5]</b> . This alarm indicates a short circuit between the motor phases or on the power bridge.											
		0 Disable									
		1 Enable									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.33	4612	<b>Desat restart time</b>	ms	UINT16		2000	1000	10000	RW	EXP	FVSY
Setting of the time within which the <b>Desaturation [5]</b> alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 1000 msec).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.34	4620	<b>IOverC restart</b>		ENUM		Disable			RW	EXP	FVSY
Enabling of automatic restart after the drive <b>Overcurrent [4]</b> alarm. This alarm indicates an overcurrent (or short circuit between phases or towards the ground).											
		0 Disable									
		1 Enable									

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.35	4622	IOverC restart time	ms	UINT16		2000	1000	10000	RW	EXP	FVSY
Setting of the time within which the <b>Overcurrent [4]</b> alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 1000 msec).											
4.4.36	4630	OverV restart		ENUM		Disable			RW	EXP	FVSY
Enabling of automatic restart after the <b>Oversupply voltage [1]</b> alarm. This alarm indicates an oversupply voltage on the intermediate circuit (DC link)											
	0	Disable									
	1	Enable									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.37	4632	OverV restart	ms	UINT16		2000	1000	10000	RW	EXP	FVSY
Setting of the time within which the <b>Oversupply voltage [1]</b> alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 1000 msec).											
4.4.38	4640	UnderV restart		ENUM		Enable			RW	EXP	FVSY
Enabling of automatic restart after the <b>Undervoltage [2]</b> alarm. This alarm indicates an undervoltage on the intermediate circuit (DC link).											
	0	Disable									
	1	Enable									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.39	4642	UnderV restart time	ms	UINT16		1000	120	10000	RW	EXP	FVSY
Setting of the time within which the <b>Undervoltage [2]</b> alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 100 msec).											
4.4.40	4650	UVRep attempts		UINT16		5	0	1000	RW	EXP	FVSY
Setting of the maximum number of attempts at automatic restart after the <b>Undervoltage [2]</b> alarm before a <b>Mult Undervoltage alarm</b> is generated. If this parameter is set to 1000 an infinite number of attempts are available.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.41	4652	UVRep delay	s	UINT16		240	0	300	RW	EXP	FVSY
Setting of the time within which, if no automatic restarts are executed after the <b>Undervoltage [2]</b> alarm, the attempts counter is reset. In this way the number of attempts set in PAR 4650 <b>Underv res attempts</b> are still available.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.42	4654	Phloss mov activity		ENUM		Warning	0	0	RW	EXP	FVSY
Setting the drive behavior in case of "PhLoss mov" alarm that signals the disconnection of a phase of the engine during running condition. The "PhLoss mov" function detects the disconnection of one or more phases of connection of the drive to the engine. This function is only operational when the motor is rotating. The configuration parameters of this function are IPA 4654, 4656, 4674.											
	0	Ignore									
	1	Warning									
	2	Disable									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.43	4656	Phloss mov holdoff	ms	UINT32		200	0	2000	R	EXP	FVSY
Represents the time for which the alarm condition must remain before the alarm is actually generated.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.44	4674	Phloss mov freq thr	hz	FLOAT		0.5	0.1	5	RW	EXP	FVSY
It represents the minimum frequency threshold exceeded which the function of PhLoss mov becomes operational. Below this threshold the function of PhLoss mov is inactive.											

It may be useful to increase this parameter to avoid false positives at low speeds.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.45	4678	<b>Phloss mov code</b>				0	0	0	W	EXP	FVSY
The hexadecimal value indicates which engine steps have been disconnected.											
0x001 Phase U disconnected 0x002 Phase V disconnected 0x004 Phase W disconnected 0x003 Phase U and V disconnected 0x005 Phase U and W disconnected 0x006 Phase V and W disconnected 0x007 Phase U, V, W disconnected											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.46	4670	<b>Optionbus activity</b>		ENUM		Disable			RW	EXP	FVSY
Setting of the behaviour of the drive in case of an <b>Opt Bus Fault [17]</b> alarm.											
0 Ignore 1 Warning 2 Disable drive 3 Stop 4 Fast stop											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.47	4660	<b>PhLoss in activity</b>		ENUM		Disable			RW	EXP	FVSY
Setting of the behaviour of the drive in case of a <b>Phaseloss in [16]</b> alarm. This alarm indicates the absence of a drive power supply phase											
0 Ignore 1 Warning 2 Disable drive											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.48	4662	<b>PhLoss in restart</b>		ENUM		Disable			RW	EXP	FVSY
Enabling of automatic restart after the <b>Phaseloss in [16]</b> alarm.											
0 Disable 1 Enable											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.49	4664	<b>PhLoss in rest time</b>	ms	UINT16		1000	120	10000	RW	EXP	FVSY
Setting of the time within which the <b>Phaseloss in [16]</b> alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 100 msec).											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.50	4668	<b>PhLoss output test</b>		ENUM		Enable			RW	EXP	FVSY
Enabling of the output phase loss test.											
0 Disabled 1 Enable 2 Powerup											
If set to 0 the test is disable If set to 1 the drive verifies the presence of all the output phases each time it receives the enable command. If set to 2 the drive only verifies the presence of all the output phases the first time the enable command is sent after powering											

**Note!** The motor brake must be closed while running this test!

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.51	4680	GroundFault thr		perc	FLOAT	10.0	0.0	150.0	RW	INT	FVSY

Setting of the threshold for the ground short circuit alarm **Ground fault [3]**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.52	4700	Alarm dig out 1 sel		ENUM		No alarm			RW	INT	FVSY
4.4.53	4702	Alarm dig out 2 sel		ENUM		No alarm			RW	INT	FVSY
4.4.54	4704	Alarm dig out 3 sel		ENUM		No alarm			RW	INT	FVSY
4.4.55	4706	Alarm dig out 4 sel		ENUM		No alarm			RW	INT	FVSY

Setting of the alarm signal to enable on a digital output. The digital output is selected using parameters **Alarm dig out 1 sel...4**, which can be enabled in the **L\_DIGSEL1** selection list.

- 0 No alarm
- 1 Overvoltage
- 2 Undervoltage
- 3 Ground fault
- 4 Overcurrent
- 5 Desaturation
- 6 MultiUndervolt
- 7 MultiOversurr
- 8 MultiDesat
- 9 Heatsink OT
- 10 HeatsinkS OTUT
- 11 Ptc failure
- 12 Motor OT
- 13 Drive overload
- 14 Motor overload
- 15 Bres overload
- 16 Phaseloss in
- 17 Opt Bus fault
- 18 Opt 1 IO fault
- 19 Precharge faul
- 20 Opt enc fault
- 21 External fault
- 22 Speed fbk loss
- 23 Overspeed
- 24 Speed ref loss
- 25 Emg stop alarm
- 26 Power down
- 27 Phaseloss out
- 28 OV safety
- 29 Safety failure
- 30 Phaseloss mov
- 31 Ropes change
- 32 Enable missing
- 33 Plc1 fault
- 34 Plc2 fault
- 35 Plc3 fault
- 36 Plc4 fault
- 37 Plc5 fault
- 38 Plc6 fault
- 39 Plc7 fault
- 40 Plc8 fault
- 41 Plc9 fault
- 42 Plc10 fault
  
- 43 Plc11 fault
- 44 Plc12 fault
- 45 Plc13 fault
- 46 Plc14 fault
- 47 Plc15 fault
- 48 Plc16 fault

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.56	4720	Alm autoreset time	s	FLOAT		0.0	0.0	60.0	RW	EXP	FVSY

Setting of the time interval that must pass before executing an automatic reset.

If no alarms are enabled the drive is set to restart.

If some alarms are still enabled the drive is set to execute a new attempt at automatic reset.

At each attempted reset a counter increases. If the limit set in the parameter **Alm autoreset number** (PAR 4722) is reached the drive is set to make no more attempts at reset and waits for a user reset.

The counter is set to zero when an automatic reset or user reset is performed and no alarms are enabled.

If the parameter is 0 the function is disabled.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.57	4722	<b>Alm autoreset number</b>		UINT16		3	0	100	RW	EXP	FVSY

Setting of the maximum number of attempted automatic resets.

## 4.8 DIGITAL INPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.1	1240	Dig inp 1 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.2	1242	Dig inp 2 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.3	1244	Dig inp 3 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.4	1246	Dig inp 4 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.5	1248	Dig inp 5 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.6	1250	Dig inp 6 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.7	1252	Dig inp 7 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.8	1254	Dig inp 8 inversion		BIT		0	0	1	RW	INT	FVSY

Inversion of the logic status of the function associated with the digital input.

0 Off  
1 On

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.13	1110	Dig input E mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY

These signals represent the state of the corresponding Enable digital input.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.14	1210	Dig input 1 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.15	1212	Dig input 2 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.16	1214	Dig input 3 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.17	1216	Dig input 4 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.18	1218	Dig input 5 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.19	1220	Dig input 6 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.20	1222	Dig input 7 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.21	1224	Dig input 8 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY

These signals represent the logic state of the corresponding digital input.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.26	1268	Dig input E dest		ILINK		0	0	0	R	EXP	FVSY
4.8.27	1270	Dig input 1 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.28	1272	Dig input 2 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.29	1274	Dig input 3 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.30	1276	Dig input 4 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.31	1278	Dig input 5 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.32	1280	Dig input 6 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.33	1282	Dig input 7 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.34	1284	Dig input 8 dest		ILINK		0	0	0	R	EXP	FVSY

Selection of the destination of the associated digital input.

## 4.9 DIGITAL OUTPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.9.1	1430	Dig out 1 inversion		BIT		0	0	1	RW	INT	FVSY
4.9.2	1432	Dig out 2 inversion		BIT		0	0	1	RW	INT	FVSY
4.9.3	1434	Dig out 3 inversion		BIT		0	0	1	RW	INT	FVSY
4.9.4	1436	Dig out 4 inversion		BIT		0	0	1	RW	INT	FVSY

Inversion of the logic status of the function associated with the digital output.

0 Off  
1 On

## 4.10 ANALOG INPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.1	1600	Analog input mon	cnt	INT16	16BIT_H	0	0	0	R	ESY	FVSY

The value of the voltage of the analog input is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.2	1602	Analog inp type		ENUM		-10V..+10V			RW	INT	FVSY

Selection of the type of input (voltage or current). Depending on the input signal, move the switches on the regulation card. The factory parameter is inputs set for differential voltage signals ( $\pm 10V$ ).

- 0 -10V..+10V
- 1 0.20mA , 0.10V
- 2 4..20mA


Select option **0** in order to connect a maximum voltage of  $\pm 12.5V$  (typically  $\pm 10V/5mA$ ) to the analog input. If the signal is used as a reference, reverse the direction of rotation by inverting the voltage polarity.

Select option **1** to connect a max voltage of 12.5V (typically 10V/5mA) or a signal in current from 0 ... 20 mA to the analog input. The signal must be positive.

Select option **2** to connect a current signal of 4...20 mA to the analog input. The signal must be positive.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.3	1604	Analog inp scale		FLOAT		1.0	-10.0	10.0	RW	INT	FVSY

Setting of a multiplier factor to be applied to the analog input.



### Example:

The speed reference of a drive is assigned with a max external voltage of 5V. With this value the drive must reach the maximum speed allowed (set using PAR 680 **Full scale speed**).

As the **Analog inp scale** parameter the scale factor of 2 is entered (10V : 5V).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.4	1606	An inp offset tune		BIT		0	0	1	RW	INT	FVSY

Self-tuning command for the offset of the analog input. Automatic fine tuning of the input. To perform self-tuning, set the input signal to its minimum value and execute the command. The conditions containing an offset can be compensated. When this command is sent, PAR 1606 **An inp offset tune** is automatically selected so that the available input signal corresponds to the zero value of the variable.

Automatic tuning can only be performed if the following condition is present:

- Input voltage less than 1V or input current less than 2 mA.

### **Note!**

The value that is obtained automatically can be changed manually, if necessary, using Offset ing an.

If the voltage setting on the analog input is more than 1V the “Input value too high” message is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.5	1608	An inp gain tune		BIT		0	0	1	RW	INT	FVSY

Self-tuning command for the analog input gain. Automatic fine tuning of the input. When this command is sent, **An inp gain tune** is automatically selected so that the available input signal corresponds to the maximum value of the variable.

Two conditions are necessary in order to perform automatic tuning:

- Input voltage greater than 1V or input current greater than 2 mA
- Positive polarity. The value that is found is automatically accepted for the other direction of rotation.

**Note!**

If necessary, the value obtained automatically can be changed manually via **An inp gain tune**.

To perform self-tuning, set the input signal to its maximum value and execute the command. A multiplier factor is calculated to apply to the input signal value (not considering the **An inp gain tune** parameter) to reach the full scale value.


If the voltage setting on the analog input is less than 1V the “**Input value too low**” message is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.6	1610	<b>Analog inp filter</b>	ms	FLOAT		10	2	100	RW	EXP	FVSY
Filter on the measurement of the analog input. This parameter can be used to control the response of the analog input and reduce any possible noise and interference.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.7	1612	<b>Analog inp top</b>	cnt	INT16		16384	-32768	+32767	RW	EXP	FVSY
Setting of the upper speed reference limit as a function of the voltage (or current) of the analog reference.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.8	1614	<b>Analog inp bottom</b>	cnt	INT16		-16384	-32768	+32767	RW	EXP	FVSY
Setting of the lower speed reference limit as a function of the voltage (or current) of the analog reference.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.9	1616	<b>Analog inp offset</b>	cnt	INT16		0	-32768	+32767	RW	EXP	FVSY
Setting of an offset value to algebraically add to the analog input.											



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.10	1618	<b>Analog inp gain</b>		FLOAT		1.0	-10.0	10.0	RW	EXP	FVSY
This parameter contains the value of the multiplier factor to apply to the analog reference calculated using the <b>Analog inp gain tune</b> function.											

Example :

An external analog reference only reaches a maximum of 9.8V instead of 10V. 1.020 (10V : 9.8V) is entered as the **An inp gain tune** (PAR 1608) parameter.

This parameter can be selected from the keypad menu. The maximum analog value available (in this case 9.8V) must be present on the terminal, with positive polarity. Press the **Enter** key on the keypad to start analog reference self-tuning.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.11	1626	<b>An inp sign src</b>		LINK	16BIT_L	6000			RW	INT	FVSY

Selection of the origin (source) of the signal to be assigned to the analog input for selecting the direction of rotation of the motor. The functions that can be associated with the outputs are listed in the “**L\_DIGSEL2**” selection list”.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.10.12</b>	<b>1632</b>	<b>Analog input dest</b>		ILINK		0	0	0	R	EXP	FVSY


The function for which the analog input has been programmed and on which it acts is displayed.

## 4.11 ALARM LOG

This is the menu in which the log of previous alarms is saved, with the time the alarm occurred (in relation to the PAR 510 **Time drive power on** parameter). The alarms are displayed starting from the most recent (No. 1) up to the furthest back in time (No. 30). Up to 30 alarm signals can be displayed.

The sub-code is used to identify the specific type of alarm.

Press the ▲ and ▼ keys to scroll the screen pages of the alarm log. The alarm log cannot be deleted.



## 4.12 LIFE TIME

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.12.1</b>	<b>510</b>	<b>Time drive power on</b>	h:min	UINT32		0	0	0	R	ESY	FVSY

The total time for which the drive has been powered is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.12.2</b>	<b>512</b>	<b>Time drive enable</b>	h:min	UINT32		0	0	0	R	ESY	FVSY

The time for which the drive has been enabled is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.12.3</b>	<b>514</b>	<b>Number power up</b>		UINT16		0	0	0	R	ESY	FVSY

The number of times the drive has been powered on is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.12.4</b>	<b>516</b>	<b>Time fan on</b>	h:min	UINT32		0	0	0	R	ESY	FVSY

The total time for which the drive fan has been running is displayed.

## 5 LIFT

### 5.1 LIFT MONITOR

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.1	14014	Trip number		UINT32			-	-	R	ESY	FVY

Displays the lift trip counter, which is incremented, when the Start lift signal is active, each time a start is signalled.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.2	14016	Sequence state		ENUM					R	ESY	FVY

View the logical state the drive is in.

The sequence of states where the drive can be found is listed below:

- 0 Idle
- 1 Cont close
- 2 Drive ready
- 3 Brake open
- 4 Smooth start
- 5 Multispeed
- 6 Waiting 0 spd
- 7 Zero speed
- 8 Brake close
- 9 Cont open
- 10 Not drive ok
- 91 SC cont mon


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.3	14030	Acceleration state	m	FLOAT			-	-	R	ESY	FVY

Displays the space required to accelerate from zero to the selected speed, considering the space due to the initial and final jerk. This does not include the space travelled at a constant speed due to activation of the soft start function.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.4	14032	Deceleration space	m	FLOAT			-	-	R	ESY	FVY

The distance necessary to stop from the high speed is displayed.

Different methods are used to calculate this distance, depending on the value of the relative parameters:




- **Case 1:** S-shaped ramp from high speed to zero speed

**Distance multispeed0** (PAR 11102) = 0, **Enable landing src** (PAR 11130) = Disabled, **Slow speed** (PAR 11120) = Zero.

**Deceleration space** (PAR 14032) the distance covered during the stop ramp from PAR 11142 **Calc space HiSpd sel** = (1) **Multispeed 1** (high speed) to zero speed.

The parameters that influence the calculation of this distance are: **Calc space HiSpd sel** (PAR 11142), **Percent dec factor** (PAR 11056), **Dec ini jerk** (PAR 11046), **Deceleration** (PAR 11048) and **Dec end jerk** (PAR 11050).




- **Case 2:** S-shaped ramp from high to low speed, low speed zone and subsequent stop

**Distance multispeed0** (PAR 11102) = 0, **Enable landing src** (PAR 11130) = Disabled, **Slow speed** (PAR 11120) = Multispeed 0.

**Deceleration space** (PAR 14032) is the distance covered during the slow down ramp from PAR 11142 **Calc space HiSpd sel** = (1) **Multispeed 1** (high speed) to PAR 11120 **Slow speed** and during the stop ramp from PAR 11120 **Slow speed** to zero speed.

If the sensors are positioned at a distance from the arrival floor greater than the distance indicated by PAR 14032 then a travel with low speed movement occurs with the value set in PAR 11120.

The parameters that influence the calculation of this distance are: **Calc space HiSpd sel** (PAR 11142), **Multispeed 0** (PAR 11120), **Percent dec factor** (PAR 11056), **Dec ini jerk** (PAR 11046), **Deceleration** (PAR 11048), **Dec end jerk** (PAR 11050) and **Stop deceleration** (PAR 11052).




- **Case 3:** S-shaped ramp from high to low speed, low speed zone and subsequent stop

**Distance multispeed0** (PAR 11102) ≠ 0 (es.0.5m), **Enable landing src** (PAR 11130) = Disabled, **Slow speed** (PAR 11120) = Multispeed 0.

**Deceleration space** (PAR 14032) is the distance covered during the slow down ramp from PAR 11142 **Calc space HiSpd sel** = (1) **Multispeed 1** to PAR 11120 **Slow speed** and during the stop ramp from PAR 11120 **Slow speed** to zero speed.

The parameters that influence the calculation of this distance are: **Calc space HiSpd sel** (PAR 11142), **Multispeed 0** (11020), **Percent dec factor** (PAR 11056), **Dec ini jerk** (PAR 11046), **Deceleration** (PAR 11048) and **Dec end jerk** (PAR 11050) and **Stop deceleration** (PAR 11052).



- **Case 4:** S-shaped ramp from high to low speed, low speed zone and subsequent stop with "landing control"

**Distance multispeed0** (PAR 11102) ≠ 0 (es.0.5m), **Enable landing src** (PAR 11130) = Enabled, **Slow speed** (PAR 11120) = Multispeed 0.

**Deceleration space** (PAR 14032) is the distance covered during the slow down ramp from **CPAR 11142 Calc space HiSpd sel** = (1) **Multispeed 1** (high speed) to PAR 11120 **Slow speed** plus **Landing zone dist** (PAR 11132).

The parameters that influence the calculation of this distance are: **Calc space HiSpd sel** (PAR 11142), **Multispeed 0** (PAR 11020), **Percent dec factor** (PAR 11056), **Dec ini jerk** (PAR 11046), **Deceleration** (PAR 11048) and **Dec end jerk** (PAR 11050).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.5	14034	Landing zone space	m	FLOAT			-	-	R	ESY	FVY

Displays the space required to reach the landing zone calculated from the deceleration and low speed values

(not multiplied by the percentage factor PAR 11056 **Percent dec factor**).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.6	14210	Actual speed ref	m/s	FLOAT			-	-	R	ESY	FVY

Displays the speed reference set in m/s.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.7	14242	Actual cabin spd	m/s	FLOAT			-	-	R	ESY	FVY

Displays the cabin speed in m/s. This speed value tends to follow the current speed reference.


## 5.2 MECHANICAL DATA

The parameters described in this menu are used to define the mechanical and physical features of the system.

### Mechanical constants

The mechanical constant defines the ratio between motor rpm and distance travelled by the cabin.

**Mechanical constant** = ( $\pi \times$  Pulley diameter)/Reduction ratio



The mechanical constant is calculated when the drive is turned on and re-calculated each time one of the parameters used to determine this value is modified (**Cabin speed**, **Pulley diameter**, **Gearbox ratio**).

The rewriting of the mechanical constant determines the recalculation of the full scale speed (PAR 680), which is set using the motor revs required to reach the maximum system speed through the mechanical ratios set.

### Weights and inertia

Entering the mechanical features of the system makes it possible to calculate the total inertia applied to the motor.

The calculated inertia value, is automatically written to the parameter (PAR 2240); this operation allows the basic speed loop gains to be recalculated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.2.1	11002	Travel unit sel		ENUM		Hz (m/s)	-	-	RWZ	INT	FVY

Selection of the unit of measure for speed references.

- 0 Hz (output frequency)
- 1 m/s (cabin speed and depends on the mechanical constant)
- 2 rpm (speed of the motor shaft)

When the unit of measure is modified the conversion constants are re-calculated, the units of measure are changed in the parameter list and the multispeed values are converted into the new unit of measure (the result may contain

approximations due to the conversion calculations). A variable representing the speed of the cabin in m/s (fpm) is always available (PAR 14242). There are fixed units of measure for the acceleration and deceleration parameters m/s<sup>2</sup>, and for jerks m/s<sup>3</sup>.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.2.2</b>	<b>11006</b>	<b>Cabin speed</b>	m/s	FLOAT		1	0	10	RWZ	INT	FVY
Sets the maximum speed of system operation. This is also used for the recalculation of the full scale speed (PAR 680).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.2.3</b>	<b>11010</b>	<b>Gearbox ratio</b>		FLOAT		45 (1)	1	200	RW	INT	FVY
Sets the reduction ratio between motor and pulley.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.2.4</b>	<b>11164</b>	<b>Rope ratio</b>		FLOAT		1 (2)	1	10	RWZ	INT	FVY
Sets the reduction ratio due to rope windings.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.2.5</b>	<b>11012</b>	<b>Pulley diameter</b>	m	FLOAT		0.6 (0.32)	0	5	RWZ	INT	FVY
Setting of the diameter of the pulley.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.2.6</b>	<b>11150</b>	<b>Car weight</b>	kg	FLOAT		400	0	10000	RW	INT	FVY
Setting of the weight of the cabin (intended as the total empty weight of everything hanging from the ropes: frame, walls, door operator, appliances, etc.).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.2.7</b>	<b>11152</b>	<b>Counter weight</b>	kg	FLOAT		1000	0	10000	RW	INT	FVY
Setting of the weight of the counterweight, including its frame.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.2.8</b>	<b>11154</b>	<b>Load weight</b>	kg	FLOAT		450	0	10000	RW	INT	FVY
Setting of the weight of the maximum load for system dimensions.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.2.9</b>	<b>11156</b>	<b>Rope weight</b>	kg	FLOAT		20	0	1000	RW	INT	FVY
Setting of the weight of the cable (intended as the total weight of all car suspension ropes).											

## 5.3 SPEED



### Multi speed configuration table

Through the combination of “MtlSpd S0” (Digital input 4), “MtlSpd S1” (Digital input 5) and “MtlSpd S2” (Digital input 6) commands, is possible to select Multi speed desired, according to next table:

MtlSpd S2	MtlSpd S1	MtlSpd S0	ACTIVE SPEED
0	0	0	Multi speed 0, PAR 11020
0	0	1	Multi speed 1, PAR 11022
0	1	0	Multi speed 2, PAR 11024
0	1	1	Multi speed 3, PAR 11026
1	0	0	Multi speed 4, PAR 11028
1	0	1	Multi speed 5, PAR 11030
1	1	0	Multi speed 6, PAR 11032
1	1	1	Multi speed 7, PAR 11034

### Note!

The Multi-speed unit of measure is set with PAR 11002 Travel units sel.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.1	11020	Multi speed 0		FLOAT		4.78 (0.1)	0	10000	RW	ESY	FVY

Setting of the multispeed 0 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

This setting is taken as the default low speed value.

If the **Multi speed 0** value is changed, it will only be acquired when the drive is rebooted.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.2	11022	Multi speed 1		FLOAT		47.78 (1.0)	0	10000	RW	ESY	FVY

Setting of the multispeed 1 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

This setting is taken as the default high speed value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.3	11024	Multi speed 2		FLOAT		21.50 (0.4)	0	10000	RW	ESY	FVY

Setting of the multispeed 2 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

This setting is taken as the default maintenance speed value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.4	11026	Multi speed 3		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 3 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.5	11028	Multi speed 4		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 4 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.6	11030	Multi speed 5		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 5 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.7	11032	Multi speed 6		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 6 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.8	11034	Multi speed 7		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 7 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.10	14010	Actual multi spd sel		ENUM					R	ESY	FVY

The currently selected speed is displayed.

- 0 Multispeed 0
- 1 Multispeed 1
- 2 Multispeed 2
- 3 Multispeed 3
- 4 Multispeed 4
- 5 Multispeed 5
- 6 Multispeed 6
- 7 Multispeed 7
- 8 Null

## 5.4 RAMPS

The lift application envisages an S-shaped ramp function with the possibility of setting 4 independent jerks and linear acceleration and deceleration factors, as in the standard profile illustrated in the figure below.



The PAR 11040 **Accel initial jerk**, PAR 11042 **Acceleration** and PAR 11044 **Accel end jerk** values used to execute the acceleration ramp are calculated by multiplying the corresponding parameters by the acceleration ramp factor (**Percent acc factor**), while the PAR 11046 **Decel initial jerk**, PAR 11048 **Deceleration** and PAR 11050 **Decel end jerk** values used to execute the deceleration ramp are calculated by multiplying the corresponding parameters by the deceleration ramp factor (**Percent dec factor**, PAR 11056).

When the **Start** command is removed, the reference speed is zero regardless of the reference selected in the multispeeds. In this final part of the profile the jerk deceleration values are used directly (not multiplied by **Percent dec factor**, PAR 11056) with the **Stop deceleration** parameter as the linear deceleration. The factors for the final section of the profile are also used in case of a Stop lift emergency condition.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.1	11040	Accel initial jerk	m/s <sup>3</sup>	FLOAT		0.2	0.001	20	RW	ESY	FVY

Setting of the jerk value for the first part of the acceleration.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.2	11042	Acceleration	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY

Setting of the maximum acceleration value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.3	11044	Accel end jerk	m/s <sup>3</sup>	FLOAT		0.6	0.001	20	RW	ESY	FVY

Setting of the jerk value for the last part of the acceleration.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.4	11054	Percent acc factor	%	FLOAT		100	10	1000	RW	INT	FVY

Setting of the acceleration factor multiplier.

If set to 100 the ramp uses the factors entered in the parameters.

If set to a value of less than 100 the lift will tend to accelerate over a longer distance.

If set to a value of more than 100 the lift will tend to accelerate over a shorter distance.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.5	11046	Decel initial jerk	m/s <sup>3</sup>	FLOAT		0.6	0.001	20	RW	ESY	FVY

Setting of the jerk value for the first part of the deceleration.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.6	11048	Deceleration	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY

Setting of the maximum deceleration value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.7	11050	Decel end jerk	m/s <sup>3</sup>	FLOAT		0.500	0.001	20	RW	ESY	FVY

Setting of the jerk value for the last part of the deceleration.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.8	11056	<b>Percent dec factor</b>	%	FLOAT		100	10	1000	RW	INT	FVY

Setting of the deceleration factor multiplier.

If set to 100 the ramp uses the factors entered in the parameters.

If set to a value of less than 100 the lift will tend to decelerate over a longer distance.


If set to a value of more than 100 the lift will tend to decelerate over a shorter distance.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.9	11052	<b>Stop deceleration</b>	m/s <sup>2</sup>	FLOAT		0.600	0.001	10.000	RW	ESY	FVY

Setting of the maximum deceleration value used when the start command is removed.

## 5.5 LIFT SEQUENCES

This menu shows the parameters used to manage and define the travel of the lift depending on the status of the inputs and alarms. The structure of the lift sequences is summarised below.



### Starting sequence:

- 1 Reading of the enable hardware input and checking for alarms (enabling is aborted in case of an alarm).
- 2 Detection of the **Enable** and **Start** commands as set in the **Sequence start stop** parameter.
- 3 When the **Start forward/reverse** command is received, a command is sent to close the contactors, depending on the direction of travel.
- 4 When the time set in **Contactor close dly** has elapsed the internal **Enable** lift signal is activated.
- 5 The system waits for the magnetisation signal from the drive (**Drive ready**).
- 6 At the end of magnetisation the open brake signal is activated.
- 7 The system waits for the brake to be opened (**Brake open delay**).
- 8 When the delay before opening the brake has elapsed the **Start** lift command is sent and movement is enabled.

#### **Sequence of movement:**

- 1 The motor is started and moves slowly at the speed set in Smooth start speed for the time indicated in **Smooth start delay** (PAR 11066).
- 2 At the end of **Smooth start time** (PAR 11066), movements are managed by the multispeeds and S-shaped ramp
- 3 When the set speed is exceeded, the **Brake mon** (PAR 3712) output signal can be used to check that the brake has actually been opened.
- 4 The EFC function with space control can be used to change to a slower speed.
- 5 When the **Start forward/reverse** signal is lowered the signal indicating arrival at the floor is enabled and the start lift signal is disabled.
- 6 The start command can be sent again until the drive reaches zero speed: the operating conditions are restored.

#### **Stopping sequence:**

- 1 When zero speed is reached the DC stop command is enabled (**ASY SSC** control).
- 2 The application waits the time needed to reach zero speed and sends the command to close brakes 1 and 2.
- 3 It waits the time necessary for the brakes to close ((**Brake close delay**, PAR 11068) and, if the current is to be reduced with a ramp, it waits for the current limit to reach zero. The internal **Enable lift**, arrival zone and DC brake signals are then lowered.
- 4 The application waits the time set in **Contactor open dly** (PAR 11072) and checks that the current supplied is zero, before sending a command to open the contactors.

It is essential to make sure that whenever a drive alarm condition is generated or the drive is disabled, the drive is stopped and a command is sent to open the contactors.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.1	<b>11060 Sequence start stop</b>			ENUM		Start fwd/rev -	-	-	RWZ	ESY	FVY

Setting the PAR 3702 **Run cont mon** command activation mode.

- 0 Start fwd/rev
- 1 Enable
- 2 Mltspd out !=0

When set to 0, output command PAR 3702 **Run cont mon** is activated, giving as input only signal PAR 11222 **Start fwd cmd src** or PAR 11224 **Start rev cmd src**.

When set to 1, output command PAR 3702 **Run cont mon** is activated, giving as input both the enable signal and signal PAR 11222 **Start fwd cmd src** or PAR 11224 **Start rev cmd src**.

When set to 2, output command PAR 3702 **Run cont mon** is activated, giving as input signal PAR 11222 **Start fwd cmd src** or PAR 11224 **Start rev cmd src** and selecting a speed other than zero using the multi-speed selectors.

#### **Note!**

The sequence of operation is the same whether you use a traditional brake or the EBC device.

#### **Note!**


If EBC is used, in the absence of CAN communication between EBC and ADL, if the lack of communication occurs before you exceed the maximum time of the brake open delay then the drive stops in EBC alarm failure if instead the lack of communication CAN occurs after this time the drive tries to carry on the whole sequence until the stop sequence where, The Run Contactor command is also removed at the brake closing command and the EBC failure alarm is activated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.5.2</b>	<b>11084</b>	<b>Smooth start mode</b>		ENUM		Variable jerk	-	-	RWZ	INT	FVY
--------------	--------------	--------------------------	--	------	--	---------------	---	---	-----	-----	-----

Setting of the soft start mode.

- 1 Speed constant
- 2 Jerk variable



If set to 1 the soft speed is automatically selected after the start command regardless of the selected multispeed. This setting is used in systems with a reducer, as it helps to overcome initial friction before starting with the profile.

If set to 2 it uses a variable value jerk and obtains a variable start acceleration that follows a parabolic trajectory, enabling extremely reduced variations in initial speed. This setting is mainly used in systems with gearless motors.

The Smooth speed duration is dependent on parameter PAR 11066 **Smooth start time**: if this parameter is set to zero, the selected multi-speed is used and not the "Smooth" speed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.5.3</b>	<b>11082</b>	<b>Smooth start speed</b>		FLOAT	0	0	0	10000	RW	INT	FVY
--------------	--------------	---------------------------	--	-------	---	---	---	-------	----	-----	-----

Setting of the speed in the smooth start phase.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.5.4</b>	<b>11066</b>	<b>Smooth start time</b>	ms	INT16/32		0	0	10000	RW	INT	FVY
--------------	--------------	--------------------------	----	----------	--	---	---	-------	----	-----	-----

Setting of the time for which the **Smooth start speed** (PAR 11082) is enabled. If this parameter is set to zero, the S-shaped profile is executed directly at the start, and the soft start function is excluded.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.5.5</b>	<b>11062</b>	<b>Contactor close dly</b>	ms	INT16/32		200	0	10000	RW	ESY	FVY
--------------	--------------	----------------------------	----	----------	--	-----	---	-------	----	-----	-----

Setting of the delay time after closing the contactor.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.5.6</b>	<b>11064</b>	<b>Brake open delay</b>	ms	INT16/32		500	0	10000	RW	ESY	FVY
--------------	--------------	-------------------------	----	----------	--	-----	---	-------	----	-----	-----

Setting of delay time after opening the brake.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.5.7</b>	<b>11078</b>	<b>Speed 0 threshold</b>	rpm	INT16		30 (1)	0	10000	RW	INT	FVY
--------------	--------------	--------------------------	-----	-------	--	--------	---	-------	----	-----	-----

Setting of the zero speed threshold, below which the zero speed signal is activated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.5.8</b>	<b>11080</b>	<b>Speed 0 delay</b>	ms	UINT16		400	0	10000	RW	INT	FVY
--------------	--------------	----------------------	----	--------	--	-----	---	-------	----	-----	-----

Setting of the zero speed delay. After the zero speed signal and after the time set in this parameter the zero speed signal is activated. These parameters are used to know the cabin stop.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.5.9</b>	<b>11086</b>	<b>Door open speed</b>	m/s	FLOAT		0	-10000	10000	RWZ	EXP	FVY
--------------	--------------	------------------------	-----	-------	--	---	--------	-------	-----	-----	-----

Setting of the door opening speed.

Source to enable brake release through the digital input. In standard sequence brake release is controlled by the drive and therefore this parameter is set to ONE. In case that brake release should be conditioned


by some external control (e.g. PLC), set this parameter to digital input controlled by PLC.

Internal sequence for brake release will wait until this input is asserted.

During run brake will be closed whenever this input becomes not asserted.

**Note!**

Under no circumstances can the drive bypass the safeties. This task is delegated to special safety modules external to the drive.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.11	11068	Brake close delay	ms	INT16/32		500	0	10000	RW	ESY	FVY

Setting of the delay time after closing the brake.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.12	11072	Contactor open dly	ms	INT16/32		200	0	10.000	RW	ESY	FVY

Setting of the contactor opening delay time.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.14	11826	Inspection behaviour		ENUM		None	-	-	RWZ	EXP	FVY

- 0 None
- 1 Fast Stop
- 2 Immediate

Manages the stop ramp in maintenance/inspection mode. If enabled, the function allows greater deceleration compared to nominal deceleration.

Setting **0**: function disabled (default). The car stops with the normal ramps inserted.

Setting **1**: the 200 ms stop function is enabled if the set maintenance speed (PAR 11828 **Inspection spd sel**) is below 0.63 m/s. If the set speed is higher it is automatically limited to 0.63 m/s.

Setting **3**: the car stops immediately (with no ramp and with closing the brake) when the button on the maintenance button panel is released.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.15	11828	Inspection spd sel		ENUM		Multispeed 2	-	-	RWZ	INT	FVY

Maintenance speed value.

- 0 Multispeed 0
- 1 Multispeed 1
- 2 Multispeed 2
- 3 Multispeed 3
- 4 Multispeed 4
- 5 Multispeed 5
- 6 Multispeed 6
- 7 Multispeed 7
- 8 Null

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.16	11244	Inversion motor rot		ENUM		Not inverted	-	-	RWZ	INT	FVY

Reversal of the motor rotation direction.

- 0 Not inverted
- 1 Inverted

Setting **0** does not reverse the direction of rotation.

Setting **1** reverses the direction of rotation.

International standards require that a positive reference corresponds to the motor rotating in a clockwise direction as seen from the drive side (shaft). For correct operation, the control algorithms provide that a positive speed reference corresponds to a positive speed measurement.

## 5.6 LIFT OUT

### Outputs

The lift control output signals are directly accessible from the selection lists used to configure the drive relay outputs, according to the following table:

PAR	Description
3700	Lift enable
3702	Run cont mon
3704	Up cont mon
3706	Down cont mon
3708	Brake cont mon
3710	Lift dc brake
3712	Brake mon
3714	Door open mon
3716	Lift start
3718	Safe Brake Test
3720	Lift statusWord
3722	Brake mon
3724	SC Cont mon
3726	Ramp down limit
3728	EBC Ok
3730	Lift wdec input

The set of lift output signals composes the “Lift statusWord”; below is the meaning of each single bit. This word is then indicated in parameter PAR 3720 **Lift statusWord** and in **DW1 fieldbus Tx**.

Bit	Description	Notes
0	LiftEnable	Enable lift command.
1	RunCont	Run command contactor
2	UpCont	Up command contactor
3	DownCont	Down command contactor
4	BrakeCont	Brake command contactor
5	LiftDcBrake	DC brake function command
6	Brake2	Brake control signal
7	DoorOpen	Open door command
8	Drive Ok	Drive not in alarm condition signal
9	SpeedIsZero	Speed less than 0 limit signal
10	SpeedRefIsZero	Speed reference less than 0 limit signal
11 ... 12		

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.6.1	1410	Dig output 1 src		LINK	16BIT_L	6000			RW	INT	
5.6.2	1412	Dig output 2 src		LINK	16BIT_L	6000			RW	INT	
5.6.3	1414	Dig output 3 src		LINK	16BIT_L	6000			RW	INT	
5.6.4	1416	Dig output 4 src		LINK	16BIT_L	6000			RW	INT	

Selection of the origin (source) of the destination associated with the digital output. The functions that can be associated with the digital outputs are listed in the “**L\_DIGSEL1**” selection list”.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.6.7	11016	LiftEnable out delay		FLOAT	0	0	0	5	RW	EXP	FVY

Setting of the delay time of the enable lift output.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.6.8	14104	Command output mon	Hex		UINT32				R	ESY	FVY

Hexadecimal display of the status of outputs, see description “Lift status word” (table beginning section) for the meaning of individual bits.

## 5.7 LIFT IN

### Inputs

The lift application input commands can be connected to a signal via a selector in order to choose from a series of possibilities available in the input list.

Generally speaking a signal can be connected to a digital input, to certain internal signals and to a bit of the Decomp word bit. This word is connected to a fieldbus processing channel (**PDC FieldBus M->S1**).

The set of digital inputs in a word is displayed in the Lift control word.

The commands used in the lift application are listed below.

Bit	Command	Description	Default source
0	<b>EnableCmd</b>	Enable command	Dig input enable
1	<b>StartFwdCmd</b>	Start forward command	Dig input 1x
2	<b>StartRevCmd</b>	Start reverse command	Dig input 2x
3	<b>MltSpd S0</b>	Multispeed 0 sel	Dig input 4x
4	<b>MltSpd S1</b>	Multispeed 1 sel	Dig input 5x
5	<b>MltSpd S2</b>	Multispeed 2 sel	Dig input 6x
6	<b>ContFbk</b>	Contactor close contact	Run cont mon
7	<b>BrakeFbk</b>	Brake close contact	Brake cont mon
8	<b>DoorOpenEna</b>	Source for enabling the door open function	Null
9	<b>DoorFbk</b>	Door close contact	Null
10	<b>Emergency mode</b>	Emergency operation command	Dig input 3x
11	<b>InvRampSrc</b>	Command to invert the speed direction	Null
12	<b>UpperLimit</b>	Travel upper limit signal	Null
13	<b>LowerLimit</b>	Travel lower limit signal	Null
14	<b>Brake fbk A3</b>	Brake failure signal	Null
15	<b>Brake 2 fbk</b>	Second brake failure signal	Brake cont mon

### Multi speed configuration table

Multi speed S2 sel	Multi speed S1 sel	Multi speed S0 sel	ACTIVE RAMP REF
0	0	0	Multi speed 0
0	0	1	Multi speed 1
0	1	0	Multi speed 2
0	1	1	Multi speed 3
1	0	0	Multi speed 4
1	0	1	Multi speed 5
1	1	0	Multi speed 6
1	1	1	Multi speed 7

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.7.1	11220	Lift enable cmd src		ENUM		Dig input E mon	-	-	RW	INT	FVY

Setting of the source for the enable command.

The list of functions that can be associated with the digital inputs are in the “**LiftInputAdICmd**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.7.2	11222	Start fwd cmd src		ENUM		Dig input 1 mon	-	-	RW	INT	FVY

Setting of the source for the start forward command.

The list of functions that can be associated with the digital inputs are in the “**LiftInputAdICmd**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.7.3	11224	Start rev cmd src		ENUM		Dig input 2 mon	-	-	RW	INT	FVY

Setting of the source for the start reverse command.

The list of functions that can be associated with the digital inputs are in the “**LiftInputAdICmd**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.7.4	11256	Speed ref src		ENUM		Multispeed	-	-	RW	INT	FVY

Selection of the origin (source) of the signal to be used for the speed reference.

The signals that can be used are multispeed, analog inputs or fieldbus (except the PAR **4020 Fieldbus M->S1 ipa**).

By using the analogue input as the speed reference source, the entire speed profile from the cabin's start to its stop will be generated only by this input, bypassing the functions implemented here.

<b>640</b>	Multispeed
<b>1600</b>	Analog in 1
<b>4034</b>	Fieldbus M->S2
<b>4044</b>	Fieldbus M->S3
<b>4054</b>	Fieldbus M->S4
<b>4064</b>	Fieldbus M->S5
<b>4074</b>	Fieldbus M->S6
<b>4084</b>	Fieldbus M->S7
<b>4094</b>	Fieldbus M->S8
<b>4104</b>	Fieldbus M->S9
<b>4114</b>	Fieldbus M->S10
<b>4124</b>	Fieldbus M->S11
<b>4134</b>	Fieldbus M->S12
<b>4144</b>	Fieldbus M->S13
<b>4154</b>	Fieldbus M->S14
<b>4164</b>	Fieldbus M->S15
<b>4174</b>	Fieldbus M->S16

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.5</b>	<b>11226</b>	<b>Multi speed S0 src</b>		ENUM		Dig input 4 mon	-	-	RW	ESY	FVY

Sets the source for the first bit for multi-speed selection.

The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.6</b>	<b>11228</b>	<b>Multi speed S1 src</b>		ENUM		Dig input 5 mon	-	-	RW	ESY	FVY

Sets the source for the second bit for multi-speed selection.

The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.7</b>	<b>11230</b>	<b>Multi speed S2 src</b>		ENUM		Dig input 6 mon	-	-	RW	ESY	FVY

Sets the source for the third bit for multi-speed selection.

The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.8</b>	<b>11232</b>	<b>Contactor fbk src</b>		ENUM		Run cont mon	-	-	RW	INT	FVY

Sets the source of contactor status signal.

The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.9</b>	<b>11236</b>	<b>Brake fbk src</b>		ENUM		Brake cont mon	-	-	RW	INT	FVY

Sets the source of brake status signal.

The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.10</b>	<b>10096</b>	<b>Brake 2 fbk src</b>		ENUM		Brake cont mon	-	-	RW	INT	FVY

Sets the source of the second brake status signal.

The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.11</b>	<b>11238</b>	<b>Door open src</b>		ENUM		Null	-	-	RW	EXP	FVY

Sets of source to enable early door opening control.

The list of functions that can be associated with the digital inputs are in the "**LiftInputDoorCmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.12</b>	<b>11240</b>	<b>Door feedback src</b>		ENUM		Null	-	-	RW	EXP	FVY

Setting of the source of the door status signal.

The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.7.13</b>	<b>11242</b>	<b>Emergency mode src</b>		ENUM		Dig input 3 mon -	-		RW	INT	FVY
---------------	--------------	---------------------------	--	------	--	-------------------	---	--	----	-----	-----

Setting of the source of the emergency operation signal.

The list of functions that can be associated with the digital inputs are in the “**LiftInputAdICmd**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.7.14</b>	<b>11246</b>	<b>Upper limit src</b>		ENUM		Null	-	-	RW	INT	FVY
---------------	--------------	------------------------	--	------	--	------	---	---	----	-----	-----

Setting of the source of the upper limit enabling signal.

The list of functions that can be associated with the digital inputs are in the “**LiftInputAdICmd**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.7.15</b>	<b>11248</b>	<b>Lower limit src</b>		ENUM		Null	-	-	RW	INT	FVY
---------------	--------------	------------------------	--	------	--	------	---	---	----	-----	-----

Setting of the source of the lower limit enabling signal.

The list of functions that can be associated with the digital inputs are in the “**LiftInputAdICmd**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.7.17</b>	<b>11274</b>	<b>Landing Cmd src</b>		ENUM		Null	-	-	RW	INT	FVY
---------------	--------------	------------------------	--	------	--	------	---	---	----	-----	-----

Sets the source of Landing command.

If you select Freeze inputs, the command is activated on the encoder inputs (see the ADL500 HW+QS manual to identify the encode Freeze inputs).

Rising (rising/positive edge) means active on the rising edge of the signal; Falling (falling/negative edge) active on the falling edge.

The list of functions that can be associated with the digital inputs are in the “**LiftInputAdICmd**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------


<b>5.7.20</b>	<b>14102</b>	<b>Command input mon</b>	Hex	UINT32			-	-	R	ESY	FVY
---------------	--------------	--------------------------	-----	--------	--	--	---	---	---	-----	-----

Hexadecimal display of input status, see “Lift control word” description (table at the beginning of this section).

## 5.8 PRE TORQUE

The Pre-torque function helps to guarantee a linear start without any initial jerk. This is possible by setting a torque value that corresponds to the load before opening the brake.

The initial torque value applied to the motor as well as the direction of the applied torque can be provided through an appropriately scaled analogue input (load cell on the lift cabin) or with a fixed torque value (in this case the value is optimised for one load condition only).



### Note!

The pre-torque function is active in the SYN FOC motor control mode only.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.1	11166	Pre-torque enable		BIT		Off	-	-	RWZ	EXP	VY
Enabling of the pre-torque function.											
	0	Off									
	1	On									

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.2	11168	Pre-torque source		ENUM		Init PreTorque	-	-	RW	EXP	VY
Selection of the origin (source) of the signal used for the pre-torque function.											
1600 Analog in 1 11170 Init pretorque											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.3	11170	Init pre-torque	%	INT16/32		0	-100	100	RWZ	EXP	VY
Setting of the reference value used in the pre-torque function only if the PAR 11168 <b>Pre-torque source</b> parameter is set to 11170 <b>Init pre-torque</b> .											
The value set in this parameter only enables the pre-torque function to be optimised for one load condition. The pre-torque function can also be optimised for different load conditions by using the fieldbus to modify the setting of this parameter.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.4	11172	Pre-torque ramp up	ms	INT16/32		0	0	10000	RWZ	EXP	VY
Setting of the ramp time for the rising edge of the torque value (before opening the brake): if this parameter is set to zero the constant feed-forward torque value is maintained during travel.											

## 5.9 EMERGENCY MODE

The possibility of operating on an emergency module power supply has been implemented in the drive, to overcome the problem of sudden power failures.

The emergency operation condition signal must be connected to the terminal relating to the source PAR 11242 **Emergency mode src**, which, if active, disables the antir rollback function (to limit power consumption) and the **Undervoltage [2]** alarm so that the drive can operate powered on the DC link by the EMS emergency module (which is in turn powered by a buffer battery pack).

In order to use batteries with a lower power rating, a function has been implemented to allow the desired direction of travel to be selected before starting an emergency start procedure.

The direction is carried out according to the selected mode (PAR 11262 **Autoselect direction**).

In case of a blackout the drive can be powered by an Emergency Module Supplier (EMS) or by an Uninterruptible Power Supply UPS.


### Operation with Emergency Module Supplier (EMS)

If the emergency mode is active, the Undervoltage [2] alarm will be disabled allowing the drive to operate powered on the DC link. See ADL500 HW+QS Manual section 7.3.3 and the EMS manual for the connection.

### EMS system management and monitoring function

This function allows the connection of the batteries to be checked.

This function is enabled with parameter PAR 11286 **Battery control**. If the batteries are disconnected for longer than the time set in parameter PAR 11852 **BatteryLow Hold off**, the [41] **No battery** alarm is tripped according to the action defined in parameter PAR 11852 **BatteryLow Activity**.



### Battery saving mode of operation

#### Operation with Uninterruptible Power Supply (UPS) Single-phase

When the emergency is activated, the Drive can be powered with 230V single-phase UPS. For connection see ADL500 HW+QS (Quick Start Guide) section 7.9.3.1.

The function can work with two modes: (3) "Battery Saving" and (4) "BattSav+Rec".

Depending on how you set the PAR 11262 **Autoselect direction** will be activated the first or the second new function.

The principle of operation of the function of replenishment to the floor in the event of a power outage with battery savings works as follows: with emergency input activated the drive tries to move the engine using only the imbalance as for a manoeuvre for unbalance that opens only the brake (and possibly also the gear switch setting the parameter PAR 11094 **Brake release type** = (1) Brake + Gear), if within a preset time from PAR 11092 **Em min spd time** the car moves and then stops once you reach the emergency speed set by PAR 11822 **Em max speed** (max speed in emergency) then the cabin continues for alternating imbalance to stop (when you reach the maximum speed in emergency). If, however, the cabin does not reach this speed within this time, the manoeuvre for imbalance is interrupted and then continue with the motor powered and with a maximum speed set through the parameter 11014 **Em max speed sav bat**.

Attention: the PAR 11824 **Brake lock time**, which defines the waiting time when the button is pressed between the release of the brake for reached max speed in emergency and the subsequent closing of the brake, must be less than PAR 11092 **Em min spd time** otherwise the maneuver turns into energized maneuver.

In the case of selection "Battery Saving" (3) the direction that the motor takes is that indicated by the input of ascent or descent.

In the case of selection "Battsav+Rec" (4) the direction taken by the motor is independent of the enabled input up or down and follows the recommended direction previously stored in the drive.

Summing up, in this maneuver first the emergency input must be activated, then the control board must command a movement of ascent or descent also enabling the enable as a normal maneuver (except that the multispeed inputs are not considered and the motor speed is regulated by the PAR 11260 **Emergency mode speed**), then the cabin will move for imbalance or so with energized motor.

Once the car has reached the floor is the control board that controls the engine stop by removing the climb or descent references and then the enable.

#### Manual emergency mode for imbalance

The purpose of the function is to allow the movement of the cabin when there is no network in order to bring it to the nearest floor by simple gravity.

The maneuver is possible only when the drive is in emergency condition, signaled by the control board through-towards the digital input "Emergency Mode". A digital input (Brake Open) must be connected to a "Brake Open" button in the control panel that enables the movement of the cab. The command can be activated by simultaneous activation of the inputs fw and rev after setting the parameter 11820 to the value "Av + Ind".

When the button is pressed, the inverter via the Relay output "Brake Contactor", will open the brake contactor. The PAR 11094 parameter set in "Brake + Gear" mode allows to activate also the output of the gear contactors located along the supply line of the brake coil.

The operator must press and hold the "Brake Open" button to move the car.

The PAR 11822 **Em max speed** sets the maximum speed that the car (or engine) can have during the maneuver.

If the car reaches the maximum speed allowed the drive locks the brake for the time T set in PAR 11824 **Brake lock time**, disabling the use of the button (even if pressed it does not release the brake).

By activating this operation, the display (both optional and integrated) displays the current cabin speed (or engine if rpm is set) and the Fwd or Rev direction. In case of an inspection, the manoeuvre is disabled.

#### Automatic emergency manoeuvre for imbalance

The manoeuvre is identical to the manual emergency manoeuvre and differs only in that input 11820 is activated automatically by the lift control board.

#### Emergency manoeuvre with engine energized by UPS or batteries + EMS module

Selecting in par 11262 the values 0 Off, 1 autosel or 2 Recommended, with emergency input activated, at the first driving control the drive controls a movement to the motor in the direction depending on the value chosen with the speed indicated in parameter 11260 **Emergency mode speed**.

#### Speed and direction display in case of emergency movement

In comparison to EN 81-20 in case of movement of the engine in emergency controlled by the drive, the keypad is always indicated the speed at which the motor is going and the direction of movement (through the positive or negative sign of speed). Both for closed-loop and open-loop configurations, the management of the arrival to the emergency plan is realized trying to optimize the power demand to the emergency modules.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.1	11286	Battery control		ENUM		Disable	-	-	RWZ	INT	FVY
Enables the continuous monitoring of the EMS system; in the event of a disconnection or low battery charge, the [41] <b>No battery</b> alarm is tripped, managed by the PAR 11850 <b>No battery activity</b> and the PAR 11852 <b>No battery hold off</b> parameters in the 5.10 LIFT ALARMS menu.											
0 Disable 1 Enable											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.2	11260	Emergency mode speed		FLOAT		4.77(0.1)	-10000	10000	RW	INT	FVY
Setting of the speed during movements in the emergency operation condition. The multi-speed is not considered.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.3	11262	Autoselect direction		ENUM		Recommended	-	-	RWZ	INT	FVY
Enables the automatic selection of the most favourable direction of movement before a start in the emergency mode.											

- 0 OFF
  - 1 AutoSelect
  - 2 Recommended
  - 3 Battery saving
  - 4 BattSav + Rec
- If 0 is selected: the drive does not calculate the more favorable direction, which is commanded manually.  
 If 1 is selected: as soon as the drive is in emergency condition it moves the motor with alternating forward and reverse movements, calculating the value of the current delivered in each direction, and selects the more favorable one (less current requested).  
 If 2 is selected: the drive assesses the most favourable direction based on the current supplied and the DC-Link voltage prior to the emergency. If the drive was in regenerative mode before the emergency, the same direction will be maintained even in an emergency, if the drive was not in regenerative mode but was supplying a current whose value is lower than the threshold set (PAR 11284 Detection Limit), it will maintain the same direction; otherwise, if the current supplied was higher than the threshold, the drive will reverse the direction of movement.  
 If 3 is selected: The "Battery saving" function allows you to manage the automatic return to the floor in an emergency by exploiting the movement of the car by gravity, and activating the motor only if necessary.  
 The maneuver is activated by configuring "Battery saving" (PAR 11262) as emergency mode and activating the Emergency function via the configured input.  
 The function works following this logic: a "manual release brake" maneuver is automatically launched, respecting the settings of the "manual release brake" function; if the car moves, the "manual release brake" maneuver continues, respecting

the conditions set by the function. If the car is in an equilibrium position or the car speed remains below the threshold (PAR 11090) for the pre-set time (PAR 11092) then the brake is closed and the electric running in emergency starts. The electric gear will take place following the commanded direction

If 4 is selected: The "BattSav + Rec" function allows you to manage the automatic return to the floor in an emergency, the maneuver takes place as in selection 3 "Battery saving" the difference is that in electric running in this mode it will take place following the recommended direction.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.5	11284	Detection Limit	%	UINT32		20	0	100	RWZ	INT	FVY

This is the current limit value delivered by the drive (expressed as a percentage of nominal current) to select the more favorable riding direction in **Recommended** mode (see PAR 11262).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.6	14282	Chosen direction		ENUM		-	-	-	R	INT	

Indicates the direction selected by the drive during the emergency.

- 0 No direction (selected)
- 1 Forward
- 2 Reverse

The association of Forward/Reverse and Up/Down depends on how the motor connection is made.

See PAR 11092 Em min spd time (def = 6 sec) on menu "9 SAFETY".

## 5.10 LIFT ALARMS

The drive manages and generates the following alarms:

Index	Error message shown on the display	Description
32	Enable missing	Condition: (ADL550 only) occurs if Enable is not activated within 4 seconds of the Safety Enable signal. Solution: <ul style="list-style-type: none"><li>• check the Enable signal.</li><li>• check the SAFETY connector, contacts 1 and 2.</li><li>• check the electrical level and Safety Enable signal current capacity.</li></ul>
33	Cont feedback	Condition: The contactor feedback signal does not match its command. Solution: Check contactor feedback wiring, check logic status of feedback input to drive, increase hold off time (PAR 11202).
34	Brake Feedback	Condition: The brake feedback signal does not match its command. Solution: Check brake feedback wiring, check logic status of feedback input to drive, increase hold off time (PAR 11206).
35	Door Feedback	Condition: The door feedback signal does not match its command. Solution: Check door feedback wiring, check logic status of feedback input to drive, increase hold off time (PAR 11212).
36	Brake Failure	Condition: Exceeding the Threshold A3 (PAR 11270). Solution: Reset alarm using the reset parameter (PAR 11268), check that brake is intact, increase threshold (PAR 11270).
37	Safe Brake Test	Condition: Safe Brake Test failed. Solution: Check that brake is intact, increase the maximum deviation threshold (PAR 11840).
38	Speed limit	Condition: Speed limitation warning to ensure stopping, enabling the DISTANCE function. Solution: Check multi-speed selected for current distance.
39	Up/low limit	Condition: Speed threshold exceeded in limit switches zone (sensors installed at the top and bottom of the lift/elevator shaft). Solution: Check speed set in limit switches zone, change speed limit (PAR 11216).
40	Lift ext fault	Condition: External alarm signal triggered (PAR 11258). Solution: Check causes enabling external alarm signal, increase hold off time (PAR 11266).
41	No battery	Condition: Battery monitoring alarm triggered. Solution: Check whether battery is properly connected to drive.
42	Batt assente	Condizione: Intervento dell'allarme di monitoraggio della batteria. Soluzione: Verificare se la batteria è correttamente collegata al drive.

All alarms are associated with a parameter to configure the action taken when the alarm is activated.

Activity: used to set the action to be performed after activation of the alarm, as follows.

Action

Ignore

The alarm is not included in the alarm list, it is not included in the alarm log, it is not signalled on the

		digital outputs, commands to the drive are not modified.
<b>Warning</b>		The alarm is included in the alarm list, it is included in the alarm log, it is signalled on the digital outputs, First alarm information is updated, Enabled alarms information is updated, commands to the drive are not modified.
<b>Disable drive</b>		The alarm is included in the alarm list, it is included in the alarm log, it is signalled on the digital outputs, First alarm information is updated, Enabled alarms information is updated, a stop command is sent, the motor is disabled and stops due to inertia.
<b>Fast Stop</b>		The alarm is included in the alarm list, it is included in the alarm log, it is signalled on the digital outputs, First alarm information is updated, Enabled alarms information is updated, a Stop command is sent. The drive is set to zero speed with the maximum available current; when the Speed 0 delay signal is activated the drive is disabled.
<b>Lift Fast stop</b>		When there is an alarm occurrence, lift will be stopped (ramp reference is set to zero) immediately with fast ramp, after that it will remain in alarm state. Attention: this will cause the cabin to stop out of floor !
<b>Lift stop</b>		When there is an alarm occurrence, lift will continue to run until next stop condition, after that it will remain in alarm state.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.10.1</b>	<b>11058</b>	<b>Lift fast stop fact</b>		FLOAT		10	1	50	RWZ	INT	FVY

Sets a multiplication factor that is applied to all ramps when the “Fast stop” alarm occurs.

Setting 1: Ramp values are not changed: 100% of the rated value is used

Setting 10: Ramp values are multiplied by 10: 1000% of the rated value is used.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.10.2</b>	<b>11200</b>	<b>Contactor activity</b>		ENUM		Disable			RWZ	INT	FVY

Sets the drive behaviour in case the **Cont feedback** alarm is tripped.

This alarm indicates that contactor command and feedback are mismatched.

- 0** Ignore
- 1** Warning
- 2** Disable drive
- 3** Fast stop
- 4** Lift fast stop
- 5** Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.10.3</b>	<b>11202</b>	<b>Cont hold off</b>	ms	INT32		1000	0	60000	RW	INT	FVY

Sets the allowed delay time if contactor command and feedback are mismatched.

If command and feedback are mismatched, the drive waits until the set time has elapsed before tripping the alarm.

If the alarm is removed within the set time, the drive will not activate the alarm.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.10.4</b>	<b>11204</b>	<b>Brake activity</b>		ENUM		Disable			RWZ	INT	FVY

Setting of drive behaviour in case of a **Brake Feedback** alarm.

This alarm indicates that brake command and feedback are mismatched.

- 0** Ignore
- 1** Warning
- 2** Disable drive
- 3** Fast stop
- 4** Lift fast stop
- 5** Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.10.5</b>	<b>11206</b>	<b>Brake hold off</b>	ms	INT32		1000	0	60000	RW	INT	FVY

Sets the delay time if brake command and feedback are mismatched.

If the alarm is removed within the set time, the drive will not activate the alarm.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.10.6</b>	<b>10094</b>	<b>Brake 2 hold off</b>	ms	INT32		1000	0	60000	RW	INT	FVY

Sets the delay time if second brake command and feedback are mismatched. If the alarm is removed within the set time,

the drive will not activate the alarm.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.7	11208	Brake run hold off		ENUM		Enable*	-	-	RW	INT	FVY

Setting of drive behaviour when a possible **Brake Feedback** alarm is detected.

- 0 Disable
- 1 Enable

If set to 0 the brake feedback alarm is indicated immediately.

If set to 1 the possible brake feedback alarm is indicated at the end of travel: this allows the cabin to reach the floor in case of a faulty brake status signal.

\* with ASY SSC motor, the default value is set to Disable.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.8	11210	Door activity		ENUM		Disable	-	-	RWZ	EXP	FVY

Setting of drive behaviour when a possible **Door Feedback** alarm is detected.


This alarm indicates that door command and feedback are mismatched.

- 0 Ignore
- 1 Warning
- 2 Disable drive
- 3 Fast stop
- 4 Lift fast stop
- 5 Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.9	11212	Door hold off	ms	INT32		1000	0	60000	RW	EXP	FVY

Sets the allowed delay time if contactor command and feedback are mismatched.

If command and feedback are mismatched, the drive waits for the set time to elapse before activating the alarm. If the alarm is removed within the set time, the drive will not activate the alarm.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.10	11214	Limit activity		ENUM		Lift fast stop	-	-	RWZ	INT	FVY

Setting of drive behaviour in case of the **Upper/Lower limit**.

The P AR 11246 **Upper limit src** and P AR 11248 **Lower limit src** digital inputs must be set to enable speed limit control. The **UpperLimit** must always correspond to the upper limit signal and the **LowerLimit** must always correspond to the lower limit signal.

This alarm occurs when the speed is greater than P AR 11216 **Limit speed thr** and are active sensors installed at the beginning and end of the space.

This function implemented in the drive provides an additional control to avoid overtravel.

The alarm condition is generated, when the set speed limit is exceeded.

- 0 Ignore
- 1 Warning
- 2 Disable drive
- 3 Fast stop
- 4 Lift fast stop
- 5 Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.11	11216	Limit speed thr	m/s	FLOAT		1	0	10	RW	INT	FVY

Sets the maximum speed allowed in the limit switches zone.

If this parameter is left at zero, the **Up/Low Limit** alarm will remain deactivated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.12	11218	Spd target activity		ENUM		Warning	-	-	RWZ	INT	FVY

Setting of drive behaviour in case of the **Speed limit** alarm.

This alarm is tripped if, when using the EFC function (see DISTANCE menu), the calculated deceleration distance is less than the actual available deceleration space.

The speed limiter is activated to always allow a correct stop.

- 0 Ignore
- 1 Warning
- 2 Disable drive
- 3 Fast stop
- 4 Lift fast stop
- 5 Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.13	11258	Lift EF alarm src		ENUM		Null	-	-	RWZ	INT	FVY

Selects the origin of the “**Lift External Fault**” alarm signal; the alarm is intended to put the drive into an alarm condition, for faults detected by external controllers.

The list of functions that can be associated with the digital inputs are in the “**LiftInputAdICmd**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.14	11264	Lift EF al activity		ENUM		Lift stop	-	-	RWZ	INT	FVY

Setting of “Lift EF alarm set” alarm.

- 0 Ignore
- 1 Warning
- 2 Disable drive
- 3 Fast stop
- 4 Lift fast stop
- 5 Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.15	11266	Lift EF hold off	ms	UINT32		1000	0	60000	RW	INT	FVY

Sets the delay time between when the “**Lift EF alarm**” is received and the execution of the selected activity.

If, within the time set in this parameter, the alarm is eliminated, the drive will not perform the action.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.17	11850	No battery activity		ENUM		Warning	-	-	RWZ	INT	FVY

Sets the drive behaviour in case the [41] **No battery** alarm is tripped.

If the battery management and monitoring function is used (see 5.9 EMERGENCY MODE menu).

- 0 Ignore
- 1 Warning
- 2 Disable drive
- 3 Fast stop
- 4 Lift fast stop
- 5 Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.18	11852	No battery hold off	ms	UINT32		1000	0	10000	RW	INT	FVY

Sets the delay time between when the [41] **No battery** alarm is received and the execution of the selected activity.


If the battery management and monitoring function is used (see 5.9 EMERGENCY MODE menu).

If, within the time set in this parameter, the alarm is eliminated, the drive will not perform the action.

## 5.11 DISTANCE


Use of the distances facilitates positioning of the deceleration sensors and is helpful for managing short floors.

The aim of the function that considers distances is to start decelerating from high speed in order to reach the approach speed in proximity to the landing zone.




Up to a maximum of 8 different slow down distances can be managed (real distance between the start of the sensor and the floor) associated with the different multispeeds. The distance to be used is selected after enabling the drive, before the cabin starts to move. Different distances cannot be selected while the cabin is travelling.

If the slow down distance is shorter than the real deceleration distance for the selected target speed, the speed is automatically limited so that the stop is always correct. When this speed limiter is enabled a **Speed Limit** alarm (warning) is generated.



If the slow down sensor is met during acceleration, the distance required to terminate the acceleration and deceleration phases may be greater than the distance available: in that case the last acceleration jerk is increased to enable correct landing.



Also note that when the position sensor is not enabled in the landing zone, its exact length is not known. To ensure correct deceleration this distance is estimated on the basis of the value entered in the PAR 11132 **Landing zone dist** parameter.

When this is equal to zero the distance is calculated on the basis of the value of the low speed and deceleration parameters and shown in the PAR 14034 **Landing zone space** parameter. The user should make sure this distance is approximately the real length of the landing zone.

In FOC mode the distance is calculated by reading the encoder position.

In the ASY SSC mode the distance is estimated ( $\text{SpdRef} \times \text{Time}$ ) and is thus subject to errors due to the difference between the real speed of the motor and the speed reference.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.1	11102	<b>Distance multispeed 0</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.2	11104	<b>Distance multispeed 1</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.3	11106	<b>Distance multispeed 2</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.4	11110	<b>Distance multispeed 3</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.5	11112	<b>Distance multispeed 4</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.6	11114	<b>Distance multispeed 5</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.7	11116	<b>Distance multispeed 6</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.8	11118	<b>Distance multispeed 7</b>	m	FLOAT		0.000	0	400	RW	INT	FVY

Setting of the value of the distance associated with **multispeed** (0...7).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.9	11120	<b>Slow speed</b>		ENUM		Autoselect	-	-	RW	INT	FVY

Setting of the floor approach speed.

The **Slow speed** is the speed of approach to the landing zone. When the multispeed associated with the **Slow speed** is selected the slow down space is checked in order to reach this speed in proximity to the landing zone.

- 0** Autoselect
- 1** Multispeed 0
- 2** Multispeed 1
- 3** Multispeed 2
- 4** Multispeed 3
- 5** Multispeed 4
- 6** Multispeed 5
- 7** Multispeed 6
- 8** Multispeed 7
- 9** Null

When mode **0 (Autoselect)** is selected, **Slow speed** is automatically connected to the multispeed with absolute value of less and other than zero. If repositioning speeds with a value of less than the **Slow speed** are used, the multispeed corresponding to the floor approach speed must be set.

When mode **9 (Null)** is selected the floor approach spaces are never controlled. In this case the profile depends exclusively on the multispeed selected.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.10	11130	<b>Enable landing src</b>		INT16		Off	-	-	RW	EXP	FVY

Setting for enabling space control in the landing zone.

This function enables the cabin to arrive exactly at floor level by controlling the position of the encoder in the landing zone sensor. Position control is only possible if an encoder is used (normally in SYN FOC). ASY SSC mode simply generate an appropriate profile on the position reference.

When the function is enabled, the speed at which the cabin enters the landing zone is that defined on PAR 11120 **Slow speed** and no longer depends on the relative multispeed but is calculated automatically according to the jerk and deceleration values to enable stopping without exceeding the set limits.

The value of **Slow speed** (PAR 11120 = 1...8) is calculated using the jerk and deceleration values not multiplied by the ramp factor.

Direct arrival at floor level is also possible, without using the **Slow speed**. This is done by setting the **Slow speed** multispeed value to zero.

- 0** Off
- 1** On

Given the solution that has been selected to calculate the speed profile, before enabling the landing zone function it is important to verify the exactness of the spaces that have been entered (for both slow down and landing), and of the mechanical constants. Incorrect spaces could result in sudden decelerations and errors in arrival at floor level.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.11	11132	Landing zone dist	m	FLOAT		0.120	0	10	RW	EXP	FVY

Setting of the landing zone distance.


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.12	11138	Out floor function		BIT		Off			RW	EXP	FVY

Enabling of the safe start function when not at floor level. This function enables recognition of arrival at floor level, which is assumed to be correct if the landing zone phase is performed.

If a correct stopping sequence is not recognised this means an emergency stop command has been sent, after which a low speed start is generated.

The restart procedure depends on the stop position as shown in the figure.

- 0 Off
- 1 On



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.13	11140	Delay acq time	ms	FLOAT		15	0	1000	RW	EXP	FVY

Setting of the delay time for sending the slow down signal.

The value of this parameter is used to compensate for the distance covered during the delay time between the passage of the cabin on the slow down sensor and receipt of the decelerate command by the drive. At high speeds this distance can have significant values: e.g. with a cabin travelling at 2 m/s and a delay time of 30 ms, the distance covered and to be

taken into consideration during the deceleration phase is 6 cm.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.14	11142	Calc space HiSpd sel		UINT16		Multispeed 1			RW	EXP	FVY

Setting of the high speed to be used to calculate distances.

- 0 Multispeed 0
- 1 Multispeed 1
- 2 Multispeed 2
- 3 Multispeed 3
- 4 Multispeed 4
- 5 Multispeed 5
- 6 Multispeed 6
- 7 Multispeed 7
- 8 Null

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.15	11276	Kp landing		FLOAT		0	0	100	RW	EXP	FVY


Lets you configure proportional gain to control the landing curve.

## 5.14 DIRECT CNT

The purpose of the “change ride direction count” function is to monitor the wear and tear of the ropes or belts, to indicate when to carry out the necessary maintenance/replacement and to stop the lift if the usage limits are reached. The change of direction counting function for coated ropes or belts is not required by EN 81.20 but it is up to the manufacturers of coated ropes and belts to define the method for indicating when replacement becomes mandatory. The most commonly used method is to count the changes of direction. To ensure that this count cannot be tampered with, the count itself must be protected against deletion. The most commonly used method is to use a password to gain access to data that cannot be deleted by mistake. There are two types of passwords: a password that is always valid until it is changed, and a password that becomes unusable after each use and must be regenerated using a decryption code. Passwords are not compulsory and the manufacturer can use whichever method he prefers to protect against accidental deletion, which is why the change counter can also be used without being put under a password.

A specific counter keeps count of direction changes and can be reset when the ropes are replaced.

The following signals, inserted in the L\_DIGSEL1 selection list, can be brought to a digital output: PAR 3420 **Ropes change req mon**, PAR 3422 **Dir change monitor** and PAR 3424 **Dir change cnt zero**.



### Firmware update

To keep them from being overwritten when using WEG\_DriveLabs, these parameters are not updated with the **Write all target parameters** operation.

### Replacing the drive

If the drive is replaced, you can save the configuration of the “Direction change count” function on a USB device (PAR 3434 **Save rope to USB**) and load it on the new drive (PAR 3436 **Load rope from USB**).

### Password

All parameters of this function, reserved for the lift maintenance mechanic, are only accessible at the Expert level, which can be password protected, see “6.6 NETWORK AND ACCESS”.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.14.1	3400	<b>Direction cnt enable</b>		ENUM		Disable			RW	EXP	FVSY
	0	Disable									
	1	Enable									

Enables the “Direction change count” function.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.14.2	3402	<b>Max direction cnt</b>		UINT32		0	0	2147483647	RW	EXP	FVSY

Sets the maximum allowed number of direction changes.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.14.3	3404	Rope change thr	%	UINT32		98	0	100	RW	EXP	FVSY
Sets a usage threshold beyond which the “Rope change” alarm is signalled to indicate that the ropes have to be replaced. When parameter 3412 <b>Ropes usage</b> exceeds this threshold, the drive keeps running but the alarm stays on to remind the operator to replace the ropes.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.14.4	3406	Direction cnt reset		BIT		0	0	1	RW	EXP	FVSY
<p>0 Disable 1 Enable</p> <p>Let you run a reset to return the direction change counter to the initial value of parameter 3402 <b>Max direction cnt</b> (value set by rope manufacturer).</p> <p>This operation is password-protected and must be run when the ropes are changed.</p> <p>Executing this command causes the following:</p> <ol style="list-style-type: none"> <li>the value of counter 3414 <b>Direction counter</b> is copied to parameter 3416 <b>Prev direct counter</b>,</li> <li>the value of parameter 3418 <b>No of cnt reset</b> is incremented,</li> <li>counter 3414 <b>Direction counter</b> is reset to value 3402 <b>Max direction cnt</b> and consequently parameter 3412 <b>Ropes usage</b> is reset to 0.</li> </ol>											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.14.5	3408	Dir cnt password		UINT32		0	0	999999	RW	EXP	FVSY
5.14.6	3410	Dir cnt new password		UINT32		0	0	999999	RW	EXP	FVSY
<p>With parameters 3408 and 3410 the modification of parameters 3400, 3402, 3404, 3406, 3410 is protected.</p> <p>The password is a numeric code of up to 6 digits.</p> <p>To set a password, it must be entered twice in parameter 3410.</p> <p>After the first entry, “Confirm password” is signalled, which means that the same value must be entered for confirmation.</p> <p>If the second value is different from the first, “Password mismatch” is signalled, otherwise the new password becomes operative.</p> <p>The password is retentive so it will not be necessary to save the parameters after changing it.</p> <p>To enable changes to the protected parameters, the password must be entered in parameter 3408, which must correspond to what was programmed in parameter 3410.</p> <p>The current values of parameters 3408 and 3410 are only visible while typing. When you press Enter, 0 is displayed to prevent them from being read by unauthorized persons.</p> <p>After having modified one of the parameters 3400, 3406 and 3410, the entered password is invalidated therefore if you want to continue with other modifications you have to enter it again.</p> <p>For one-time password management, see the instructions in the description of par 3440.</p>											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.14.7	3412	Ropes usage	%	UINT16	16BIT_L	0	0	0	R	EXP	FVSY
<p>Displays the ropes usage counter (as percentage) of parameter 3402 <b>Max direction cnt</b>.</p> <p>When PAR 3412 = 100% (corresponds to PAR 3414 = 0), the ropes have reached their useful life and must be replaced: the drive finishes the current travel and then locks.</p> <p>By switching the drive off and back on you can run a single travel to bring the car to a better position for the procedure.</p> <p>To eliminate the lock condition, reset the direction change counter.</p>											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.14.8	3414	Direction counter		UINT32	32BIT	0	0	0	R	EXP	FVSY
<p>Displays the countdown of direction changes remaining until useful life of the ropes is reached.</p> <p>When PAR 3414 = “0” the ropes must be replaced (corresponds to PAR 3412 = 100%): the drive finishes the current travel and then locks.</p> <p>By switching the drive off and back on you can run a single travel to bring the car to a better position for the procedure.</p> <p>To eliminate the lock condition, reset the direction change counter (see PAR 3406 <b>Direction cnt reset</b>).</p>											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.14.9	3416	Prev direct counter		UINT32	32BIT	0	0	0	R	EXP	FVSY
<p>Displays the number of direction changes remaining on the previous set of ropes (value of PAR 3414 <b>Direction counter</b> is copied before reset). This number will remain fixed until the next replacement of the ropes.</p>											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.14.10</b>	<b>3418</b>	<b>No of cnt reset</b>		UINT32	32BIT	0	0	0	R	EXP	FVSY

Displays the number of rope changes made.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.14.11</b>	<b>3420</b>	<b>Ropes change req mon</b>		BIT	16BIT_L	0	0	1	R	EXP	FVSY

Activates when the percentage of rope usage (set in PAR 3412 **Ropes usage**) exceeds the set threshold (PAR 3404 **Ropes change thr**).

This signal is inserted in the L\_DIGSEL1 selection list and can be brought to a digital output.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.14.12</b>	<b>3422</b>	<b>Dir change monitor</b>		BIT	16BIT_L	0	0	1	R	EXP	FVSY

This signal stays on for one second each time the drive detects a direction change and thus decrements the counter.

This signal is inserted in the L\_DIGSEL1 selection list and can be brought to a digital output.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.14.13</b>	<b>3424</b>	<b>Dir change cnt zero</b>		BIT	16BIT_L	0	0	1	R	EXP	FVSY

This signal activates when the drive is locked because 3414 **Direction counter** has reached 0.

This signal is inserted in the L\_DIGSEL1 selection list and can be brought to a digital output.

## 6 COMMUNICATION

### 6.1 CONTROL COMMUNICATION (CONTROL COMM)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>6.1.1</b>	<b>4000</b>	<b>Communication mode</b>		ENUM		Parallel			RW	INT	FVSY

Setting the type of communication to be used.

**0** Parallel I/O

Setting **0** the drive communicates with the Controller through Parallel I/O (physical inputs and outputs).

## 6.6 NETWORK AND ACCESS

To enable password protection for access levels, change parameter PAR 568 **Enable password** to "ON".

The user will then be asked to enter the password for their current access level; if the password has not been changed, its default value must be entered (visible in the DEFAULT column of the parameter description), then the user will be asked to enter a new password, which must be at least 8 characters long and alphanumeric.

For password recovery in the event of loss, see PAR 7200 **Password recovery**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>6.6.1</b>	<b>9610</b>	<b>Readonly Username</b>		STRING16		readonly	0	0	R	EXP	FVSY

Username assigned to the " Readonly" access level.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>6.6.2</b>	<b>9626</b>	<b>Easy Username</b>		STRING16		easy	0	0	R	EXP	FVSY

Username assigned to the " Easy" access level.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>6.6.3</b>	<b>9634</b>	<b>Easy Password</b>		STRING16		easy	0	0	RW	EXP	FVSY

Password used to access the " Easy" level.

Menu	PAR	Description	UM	Tipo	FB BIT	Def	Min	Max	Acc	Liv.	Vis.
<b>6.6.4</b>	<b>9642</b>	<b>Interm Username</b>		STRING16		interm	0	0	R	EXP	FVSY

Username assigned to the " INT" (Intermediate) access level.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.											
6.6.5	9650	<b>Interm Password</b>		STRING16		interm	0	0	RW	EXP	FVSY											
Password used to access the "INT" (Intermediate) access level.																						
Menu	PAR	Description	UM	Tipo	FB BIT	Def	Min	Max	Acc	Liv.	Vis.											
6.6.6	9658	<b>Expert Username</b>		STRING16		expert	0	0	RW	EXP	FVSY											
Username assigned to the "Expert" access level.																						
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.											
6.6.7	9666	<b>Expert Password</b>		STRING16		expert	0	0	RW	EXP	FVSY											
Password used to access the "Expert" level.																						
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.											
6.6.13	9556	<b>IP Address set</b>		UINT32		169.254.10.10	0	0	RW	EXP	FVSY											
Enters the network IP address.																						
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.											
6.6.14	9558	<b>IP Netmask set</b>		UINT32		255.255.0.0	0	0	RW	EXP	FVSY											
Enters the subnet IP address.																						
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.											
6.6.15	9560	<b>IP Gateway set</b>		UINT32		0.0.0.0	0	0	RW	EXP	FVSY											
Enters the gateway IP address.																						
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.											
6.6.16	9564	<b>IP Netmask</b>		UINT32		255.255.0.0	0	0	R	EXP	FVSY											
Subnet IP address in use.																						
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.											
6.6.17	9566	<b>IP Gateway</b>		UINT32		0.0.0.0	0	0	R	EXP	FVSY											
Gateway IP address in use.																						
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.											
6.6.18	9608	<b>IP Assignment</b>		ENUM		Static	0	0	RW	EXP	FVSY											
IP address assignment.																						
0	DHCP																					
1	Static																					
<b>DHCP:</b> the drive IP address is assigned by the network DHCP server. If no DHCP server is present, the drive waits for about 3 min, after which it takes the static address configured via parameter (PAR 9556 <b>IP Address set</b> , default = 169.254.10.10) as the IP address. Typical use: drive connected to a network with several devices.																						
<b>Static:</b> The drive IP address is assigned via parameter PAR 9556 <b>IP Address set</b> , default = 169.254.10.10. Typical use: drive connected directly to the PC.																						

## 7 MOTOR DATA

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.2	2000	<b>Rated voltage</b>	V	FLOAT		SIZE	150	480	RWZ	INT	FVSY
Set the motor rated voltage as indicated on the data plate. This is the voltage the drive must supply at the motor rated frequency.											
7.3	2002	<b>Rated current</b>	A	FLOAT		SIZE	1	1500	RWZ	INT	FVSY
The motor rated current at its rated power (kW / Hp) and voltage (indicated on the motor data plate).											
7.4	2004	<b>Rates speed</b>	rpm	FLOAT		SIZE	10	32000	RWZ	INT	FVY
Rated speed of the motor with full load in rpm. In some motors the asynchronous speed (e.g. 1500 rpm for a 4-pole motor) and slippage, i.e. the loss of revolutions between the motor idling condition and the rated load condition (e.g. 80 rpm), is indicated. Enter the following: synchronous speed - slippage.											
7.5	2006	<b>Rated frequency</b>	Hz	FLOAT		SIZE	1	1000	RWZ	INT	FVS
Rated frequency of the motor expressed in Hz.											
7.6	2008	<b>CPole pairs</b>		UINT16		SIZE	1	60	RWZ	INT	FVSY
Motor pole pairs. The number of motor pole pairs is calculated using the motor plate data and applying the following formula:											
$p = \frac{60 [s] \times f [\text{Hz}]}{Vn [\text{rpm}]}$											
Where: p = motor pole pairs; f = motor rated frequency (PAR 2006)											
nN = motor rated speed (PAR 2004).											
7.7	2010	<b>Rated power</b>	kW	FLOAT		SIZE	0.1	1500	RWZ	INT	FVS
Motor power factor, as indicated on the data plate ( $\cos \varphi$ ). This parameter is not always present on the motor data plate: in that case use the default value present in the drive.											
7.8	2012	<b>Rated power factor</b>		FLOAT		SIZE	0.6	0.95	RWZ	INT	FVS
Motor power factor, as indicated on the data plate ( $\cos \varphi$ ). This parameter is not always present on the motor data plate: in that case use the default value present in the drive.											
7.10	2020	<b>Take parameters</b>		BIT		0	0	1	RWZ	INT	FVSY
Saves the set motor data in the drive. This command must be supplied last after entering the appropriate values of all the parameters listed above. This means calculating the normalization factors (a) and estimated values for the motor parameters (b). The drive cannot be started until the <b>Take parameters</b> command has been set.											
Use of the Startup wizard is recommended.											
7.11	2022	<b>Autotune rotation</b>		BIT		0	0	1	RWZ	INT	FVS
Performs self-tuning in rotation: the motor must be uncoupled from the load or the transmission must not represent more than 5% of the load. This procedure allows the greatest degree of accuracy in measuring the motor parameters.											
To execute the command you must first open the hardware enabling. Self-tuning can now be performed.											
Close the hardware enabling. At the end of the self-tuning procedure, open the hardware enabling.											
7.12	2024	<b>Autotune still</b>		BIT		0	0	1	RWZ	INT	FVSY
Performs self-tuning with the motor coupled to the transmission. The self-tuning procedure may cause limited rotation of the motor shaft. To perform self-tuning, follow the procedure described for the previous parameter.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.13	2030	<b>Autotune status</b>		ENUM		Required			R	INT	FVSY
Indication of the status of parameter saving.											
0 Required 1 Done											
The parameter displays the <b>Required</b> message when the motor parameters that have been entered need to be saved. When they have been saved the parameter indicates <b>Done</b> .											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.14	2050	<b>Measured Rs</b>	ohm	FLOAT		0	0	200	RW	EXP	FVSY
Measured value of the rotor resistance.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.15	2052	<b>Measured DTL</b>	V	FLOAT		0	0	100	RW	EXP	FVY
Measured value of dead time compensation.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.16	2054	<b>Measured DTS</b>	V/A	FLOAT		0	0	100	RW	EXP	FVSY
Measured compensation gradient value.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.17	2056	<b>Measured Lsig</b>	mH	FLOAT		0.1	0.1	200	RW	EXP	FVS
Leakage inductance value measured (Only for asynchronous motors).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.20	2062	<b>Measured ImN</b>	A	FLOAT		CALCF	0	1000	RW	EXP	FVS
Measured value of the rated magnetising current.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.21	2066	<b>Measured FlxN</b>	Wb	FLOAT		CALCF	0	10	RW	EXP	FVS
Measured flux saturation value.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.22	2076	<b>Measured Rr</b>	ohm	FLOAT		CALCF	0	200	RW	EXP	FVS
Measured rotor resistance value.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.23	2078	<b>Take tune paramenters</b>		BIT		0	0	1	RW	INT	FVSY
Saves the motor data calculated by the self-tuning procedure in the drive.											

## 8 ENCODER

### Note!

The parameters of this menu will be available depending on the selection of parameter 2132 Encoder mode.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.1	2100	Encoder pulses	ppr	UINT16		1024	4	16384	RWZ	INT	

Setting of the number of feedback encoder impulses. During setup, for incremental sinusoidal encoders + absolute EnDat, encoder absolute EnDat Full digital and BiSS encoders this value is set automatically by reading the number of incremental encoder impulses.

With the EnDat Full digital Encoder, the value set automatically may be below the minimum.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.2	2102	Encoder supply	V	FLOAT		5.2	5.2	20.0	RW	INT	FVSY

Sets the encoder supply voltage. The min and max values will be changed depending on the selection of parameter 2104 **Encoder input config** as follows:

PAR 2104 Encoder input config	Def	Min	Max
[0] HTL	5.2 V	5.2 V	20.0 V
[1] TTL	5.2 V	5.2 V	6.0 V

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.3	2104	Encoder input config		ENUM		TTL			RWZ	INT	

Setting of the input configuration of the incremental digital encoder, TTL or HTL.

- 0 HTL
- 1 TTL

This parameter is automatically set to HTL when the value set in the **Encoder supply** parameter is more than 6.0V.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.4	2106	Encoder repetition		ENUM		No division			RWZ	INT	

Setting of the divider to apply to the encoder repeat output frequency.

- 0 No division
- 1 Divide 2
- 2 Divide 4
- 3 Divide 8
- 4 Divide16
- 5 Divide 32
- 6 Divide 64

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.5	2108	Encoder signal Vpp	V	FLOAT		0.8	0.5	1.2	RWZ	INT	

Setting of the peak-to-peak voltage value of the encoder signal. Incremental sinusoidal encoders and absolute SinCos encoders normally produce signals with a peak-to-peak voltage of 1 Vpp. Due to loss of voltage along the cable, the value of the peak-to-peak voltage signal received by the feedback card could be lower, generating a **Speed fbk loss [22]** alarm.

This parameter can be used to set the peak-to-peak voltage value of the incremental sinusoidal encoders and absolute SinCos encoders on the input terminals of the feedback card.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.6	2110	Encoder signal check		ENUM		Check A-B			RWZ	EXP	

Configuration of which incremental digital encoder channels are to be controlled in order to process the **Speed fbk loss [22]** alarm signal.

- 1 Check A-B
- 2 Check A-B-Z

Set 1 to check for signal on channels A-B

Set 2 to check for signal on channels A-B-Z

If the application detects the absence of feedback the **Speed fbk loss [22]** is generated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.7	2116	ENC signal Vpp inc	V	FLOAT		0	0	0	R	EXP	

Displays the Vpp signal of the incremental tracks of the connected encoder.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.9	2130	Encoder direction		ENUM		Not inverted			RWZ	INT	

Setting of the sign of the information obtained from the incremental or absolute encoder.

- 0 Not inverted
- 1 Inverted

By setting 0 the encoder feedback signals are not inverted.

By setting 1 the encoder feedback signals are inverted

According to international standards, positive references are associated with clockwise motor rotation, seen from the control side (shaft). To ensure correct operation, the regulation algorithms ensure that positive speed references correspond to positive speed measurements.

If the motor pulley is mounted on the side opposite the command side, it will turn in an anticlockwise direction when the speed is positive: to make the pulley turn in a clockwise direction, the motor phase sequence is modified, which inverts the speed measurement sign. To restore the correct speed measurement sign, invert the incremental encoder A+ and A-signals and the absolute encoder Sin+ and Sin- signals on the encoder connections. The absolute part cannot be inverted with Endat and Hiperface absolute encoders.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.10	2132	Encoder mode		ENUM		None			RWZ	INT	FVSY

The drive has an integrated encoder card. The encoder mode can be selected in accordance with the following table:

- 0 None
- 1 Digital
- 2 Sinus

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.11	2134	Encoder speed filter	ms	FLOAT		1.0	0.1	8.0	RW	EXP	

Setting of the time constant of the filter applied to the feedback encoder pulse reading. The parameter affects both the accuracy of the speed measurement and the dynamics obtainable in closed loop control. On the other hand, the use of a speed measurement filter introduces delays that do not permit high control loop dynamics. Low settings extend the regulation bandwidth but may accentuate any disturbance. The filter is applied to the speed reported in the **Encoder speed** (PAR 2150) parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.13	2150	Encoder speed	rpm	INT16	16BIT_H	0	0	0	R	ESY	

The motor speed measured by the incremental encoder is displayed, filtered by the PAR 2134 **Encoder speed filter** parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.14	2162	Encoder position	cnt	UINT16	16BIT_L	0	0	0	R	ESY	

The impulse count obtained from the incremental encoder reading is displayed: 1 encoder turn is equal to the value entered in Encoder pulses multiplied by 4.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.16	2172	SpdFbkLoss code		UINT16		0	0	0	R	EXP	

The **Speed fbk loss** [22] alarm generated by an encoder fault is displayed. Each type of encoder generates the alarm differently (incremental signal error, absolute signal error, serial error), so this parameter is used to display information about the alarm that has been activated. In case of several concurrent causes, these are shown in this parameter.

Bit	Value	Name
0	0x01	CHA
1	0x02	CHB
2	0x04	CHZ
3	0x08	MOD_INCR
4	0x10	MOD_ABS

5	0x20	CRC_CKS_P
6	0x40	ACK_TMO
7	0x80	DT1_ERR
8	0x100	Setup Error
10..15		Free
16..31		Encoder-dependent

For further details reference should be made to the description of the **Speed fbk loss [22]** alarm and the chapter 10.2 Speed fbk loss alarm according to the type of feedback (ADL500 HW+QS manual).

**Note!**

For the correct interpretation of the cause of the alarm trigger, it is necessary to transform the hex code indicated in parameter SpdFbkLoss code, PAR 2172 , in the corresponding binary and verify in the encoder table that the active bits and related description are used.

Example with encoder Endat:

PAR 2172 = A0H (hex value)

In the table "Speed fbk loss [22] alarm with absolute encoder EnDat" A0 is not indicated in the value column. A0 should be contemplated as a bitword with meaning A0 -> 10100000 -> bit 5 and bit 7 . The following causes simultaneously intervene:

Bit 5 = 20H Cause: the SSI signal interferences cause an error in the CKS or parity

Bit 7 = 80H Cause: The encoder has detected an incorrect operation and communicates it to the converter through the Error bit. Bits 16..31 present the type of incorrect encoder operation detected.

## 9 SAFETY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
9.3	11252	Brake fbk A3 sel		ENUM		Null	-	-	RW	INT	FVY
Selection of the <b>Brake failure</b> alarm In the default configuration the brake fault alarm function is disabled.											
Setting of the source to enable between those available in the “ <b>LiftInputAdICmd</b> ” selection list.											
<p><b>1110</b> Dig input E mon  <b>1210</b> Dig input 1 mon  <b>1212</b> Dig input 2 mon  <b>1214</b> Dig input 3 mon  <b>1216</b> Dig input 4 mon  <b>1218</b> Dig input 5 mon  <b>1220</b> Dig input 6 mon  <b>1222</b> Dig input 7 mon  <b>1224</b> Dig input 8 mon  <b>1230</b> Dig input 1x mon  <b>1232</b> Dig input 2x mon  <b>1234</b> Dig input 3x mon  <b>1236</b> Dig input 4x mon  <b>3702</b> Run cont mon  <b>3706</b> Down cont mon  <b>3708</b> Brake cont mon  <b>3714</b> Door open mon  <b>6000</b> Null  <b>6002</b> One  <b>8000</b> EBC SOK mon  <b>8002</b> EBC Warning mon  <b>8004</b> EBC Alarm mon  <b>12250</b> B0 Lift decomp  <b>12252</b> B1 Lift decomp  <b>12254</b> B2 Lift decomp  <b>12256</b> B3 Lift decomp  <b>12258</b> B4 Lift decomp  <b>12260</b> B5 Lift decomp  <b>12262</b> B6 Lift decomp  <b>12264</b> B7 Lift decomp  <b>12266</b> B8 Lift decomp  <b>12268</b> B9 Lift decomp  <b>12270</b> B10 Lift decomp  <b>12272</b> B11 Lift decomp  <b>12274</b> B12 Lift decomp  <b>12276</b> B13 Lift decomp  <b>12278</b> B14 Lift decomp  <b>12280</b> B15 Lift decomp       </p>											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
9.4	11268	Reset Brake Alarm		INT		0	-	-	RW	INT	FVY
Resets the <b>Brake feedback</b> alarm.											
Reset procedure:											
<ol style="list-style-type: none"> <li>1. Open menu 5.10 LIFT ALARMS, and check that the <b>Brake feedback</b> alarm is on.</li> <li>2. In the lift alarm menu, select parameter 11268 <b>Reset Brake Alarm</b> (default 0).</li> <li>3. The system asks for a code, enter release code 5313.</li> <li>4. Check again to see whether the <b>Brake feedback</b> alarm has been reset.</li> </ol>											

# 10 REGULATION MENU

## 10.1 SPEED REGULATION GAINS (SPEED REG GAINS)

### Speed Reg Gains

This menu contains the parameters specific to the motor (synchronous or asynchronous) speed control loop illustrated in the figure.





Figure 11.1: Motor speed control loop block diagram



PAR 2794 SR-P gain at start; PAR 2796 SR-I gain at start; PAR 2752 SR-P gain low speed; PAR 2754 SR-I gain low speed; (1) Linear change of gains;

Figure 11.2: Adaptation of the control loop gains as a function of the speed reference

### Torque Notch Filters

To attenuate possible resonance frequencies, in the 5...300Hz range, up to two cascade suppressor filters have been provided for. Both can be configured and enabled independently.




Figure 11.3: Suppressor filters in cascade

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.1	2240	<b>Inerzia</b>	$\text{kgm}^2$	FLOAT		0.8	0.001	1000	RW	INT	VSY
Specifies the actual value of the moment of inertia on the motor side.											
Based on the value defined in this parameter, the drive suitably sets the base gains of the Proportional + Integral controller of the speed control loop (PAR 2662 <b>SR-high speed thrsd</b> , PAR 2664 <b>SR-I time</b> ) to ensure stable operation.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.2	9702	<b>Learning trip out</b>	$\text{kgm}^2$	FLOAT		0	0	0	R	EXP	FVSY
Provides the value calculated by the Learning trip procedure (PAR 9720, menu 2 OPTIMIZ. WIZARD). At the end of the procedure, if successfully ending with the "Learning trip OK" message, this value is copied to parameter 2240 Inertia.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.3	2794	<b>SR-P gain at start</b>	%	FLOAT		150.0 (*)	0.0	400.0	RW	INT	VSY
Defines the level of proportional control exercised by the PI regulator during the start phase.											
In this initial phase the motor speed control loop must be sufficiently responsive to compensate for any load imbalance and thus counteract the roll-back effect.											
An excessive increase of this parameter may generate system vibrations or unstable behaviour.											
(*) Def: 150 = ASY FOC, 110 = SYN FOC											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.4	2796	<b>SR-I gain at start</b>	%	FLOAT		110.0	0.0	400.0	RW	INT	VSY
Defines the level of integral control exercised by the PI regulator during the start phase.											
Increasing the value of this parameter improves the speed control response in compensating for any load imbalance when the brake is opened.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.5	2752	<b>SR-P gain low speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
Defines the level of the proportional control exercised by the PI regulator for operating speeds below the minimum threshold defined in parameter PAR 2760 <b>SR-low speed thrsd</b> .											
For operating speeds above this threshold, the actual level of proportional action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2756 <b>SR-P gain high speed</b> .											
In the speed range between the thresholds defined in the PAR 2760 <b>SR-low speed thrsd</b> and the PAR 2762 <b>SR-high speed thrsd</b> parameters, the weight of the proportional action varies linearly with the speed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.6	2754	<b>SR-I gain low speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
Defines the level of the integral control exercised by the PI regulator for operating speeds below the minimum threshold defined in parameter PAR 2760 <b>SR-low speed thrsd</b> .											
For operating speeds above this threshold, the actual level of integral action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2758 <b>SR-I gain high speed</b> .											
In the speed range between the thresholds defined in the PAR 2760 <b>SR-low speed thrsd</b> and the PAR 2762 <b>SR-high speed thrsd</b> parameters, the weight of the integral action varies linearly with the speed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.7	2756	<b>SR-P gain high speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
Defines the level of the proportional control action exercised by the PI regulator for operating speeds above the maximum threshold defined in parameter PAR 2762 <b>SR-high speed thrsd</b> .											
For operating speeds lower than this threshold, the actual level of proportional action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2752 <b>SR-P gain low speed</b> .											
In the speed range between the minimum and maximum thresholds defined in PAR 2760 <b>SR-low speed thrsd</b> and PAR 2762 <b>SR-high speed thrsd</b> parameters, the weight of the proportional action varies linearly with the speed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.8	2758	<b>SR-I gain high speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
Defines the level of the integral control action exercised by the PI regulator for operating speeds above the maximum threshold defined in parameter PAR 2760 <b>SR-low speed thrsd</b> .											
For operating speeds lower than this threshold, the actual level of integral action becomes a linear combination between											

the value defined in this parameter and the value defined in parameter PAR 2754 **SR-I gain low speed**.  
 In the speed range between the thresholds defined in PAR 2760 **SR-low speed thrsd** and PAR 2762 **SR-high speed thrsd** parameters, the weight of the integral action varies linearly with the speed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.9	2760	<b>SR-low speed thrsd</b>	%	UINT16		30	1	100	RW	INT	VSY

Specifies the low speed threshold used for automatic gain adjustment of the speed controller.  
 The value is expressed as a percentage of the rated speed.  
 For motor speeds below this threshold, the speed controller uses the gains specified in the PAR 2752 **SR-P gain low speed** and the PAR 2754 **SR-I gain low speed** parameters.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.10	2762	<b>SR-high speed thrsd</b>	%	UINT16		70	1	100	RW	INT	VSY

Specifies the high speed threshold used for automatic gain adjustment of the speed controller.  
 The value is expressed as a percentage of the rated speed.  
 For motor speeds above this threshold, the speed controller uses the gains specified in the PAR 2756 **SR-P gain high speed** and the PAR 2758 **SR-I gain high speed** parameters.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.11	2662	<b>SR-P gain</b>	N/rpm	FLOAT		1.0	0	0	RW	INT	VSY

Specifies the base value of the speed controller's proportional gain.  
 Its value is calculated by the drive as a function of the total moment of inertia declared in parameter PAR 2240 **Inertia**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.12	2664	<b>SR-I time</b>	ms	FLOAT		1.0	0	0	RW	INT	VSY

Specifies the base value of the speed controller's integral time. Its default value is 100 ms.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.13	9446	<b>TNF1-frequency</b>	Hz	FLOAT		100.0	5.0	350.0	RW	EXP	VSY

Specifies the value of the central frequency of the first TNF1 suppressor filter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.14	9448	<b>TNF1-bandwidth</b>	Hz	FLOAT		4	1	20	RW	EXP	VSY

Defines the TNF1 suppressor filter's frequency band.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.15	9450	<b>TNF1-depth</b>		FLOAT		20	3	60	RW	EXP	VSY

Specifies the TNFR1 suppressor filter's attenuation value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.16	9458	<b>Torque Notch Fltr 1</b>		ENUM		Disable			RW	EXP	VSY

This parameter activates/deactivates the filtering function of the first optional TNF 1 filter applied to the torque reference generated by the PI speed regulator.

**0 - Disable**  
**1 - Enable**

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.17	9452	<b>TNF2-frequency</b>	Hz	FLOAT		100.0	5.0	350.0	RW	EXP	VSY

Specifies the value of the central frequency of the second TNF2 suppressor filter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis..
10.1.18	9454	<b>TNF2-bandwidth</b>	Hz	FLOAT		4	1	20	RW	EXP	VSY

Defines the TNF2 suppressor filter's frequency band.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.1.16</b>	<b>9456</b>	<b>TNF2-depth</b>		FLOAT		20	3	60	RW	EXP	VSY

Specifies the TNF2 suppressor filter's attenuation value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.1.20</b>	<b>9460</b>	<b>Torque Notch Fltr 2</b>		ENUM		Disable			RW	EXP	VSY

This parameter activates/deactivates the filtering function of the second optional TNF 2 filter applied to the torque reference generated by the PI speed regulator.

- 0** - Disable
- 1** - Enable

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.1.21</b>	<b>2806</b>	<b>SR-P gain in use</b>	%	FLOAT		100.0	0	0	R	INT	VSY

Read-only parameter. Contains the current value of the speed controller's proportional action level.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.1.22</b>	<b>2808</b>	<b>SR-I gain in use</b>	%	FLOAT		100.0	0	0	R	INT	VSY

Read-only parameter. Contains the current value of the speed controller's integral action level.

## 10.2 VF CONTROL

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.1	2200	<b>Boost voltage</b>	%	FLOAT		3	0	20.0	RW	ESY	F

Specifies the additional voltage value applied to the motor terminals at low speeds to increase the delivered torque. Excessive values produce an increase of current draw and motor heating due to the resistive losses in stator winding. Possible range of values: 0...20% of motor rated voltage.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.2	2202	<b>Base voltage</b>	V	FLOAT		0	0	0	RW	ESY	F

Specifies the maximum voltage value applicable to the motor terminals. This parameter's setting is defined by the drive automatically, based on the motor data plate, during the Wizard procedure.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.3	2204	<b>Base frequency</b>	Hz	FLOAT		0	0	0	RW	ESY	F

Specifies the rated motor frequency value at which the voltage applied to the motor terminals reaches the maximum value defined in parameter PAR 2202 **Base voltage**. For operating frequencies above this value the voltage applied to the motor is kept constant.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.4	2212	<b>V/Hz Boost most</b>		ENUM		Auto			RW	ESY	F

This parameter can be used to select one of the following two boost voltage generation modes:

- 0 Fixed
- 1 Auto

In the "Fixed" mode, the boost voltage is defined by the user through parameter PAR 2200 Boost voltage.

At zero speed, the drive applies a voltage to the motor terminals equal to the value defined in PAR 2200.

This additional voltage is gradually reduced for speeds higher than zero until it is eliminated for output frequencies above the threshold equal to half the rated frequency defined in PAR 2204 Base frequency (see figure).

In "Auto" mode the boost voltage is dynamically adjusted by the drive.




Figure 11.4: V/f characteristic curve profile

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.5	2214	<b>V/Hz Slip ctrl gain</b>		FLOAT		0	0	0	RW	EXP	F



This parameter influences the static accuracy of the open loop speed control. It is used for slip compensation under all load conditions. It is automatically defined by the drive based on the motor data plate and it can also be manually adjusted.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.6	2218	<b>V/Hz Stability gain</b>		FLOAT		0.0	0	0	RW	EXP	F

This parameter can be used to compensate for any current oscillations that may occur during travel and degrade comfort in the cabin. Its value is appropriately defined by the drive during the self-tuning procedure or after the "Take parameter" command.

V/f control can be made more stable by increasing this parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.2.7</b>	<b>2220</b>	<b>V/Hz Limiter Kp</b>	Hz/A	FLOAT		0.2	0	0	RW	EXP	F
		Defines the proportional gain of the current limiter in V/f mode. Its value is set by the drive after the self-tuning procedure or after the "Take parameter" command based on the motor data plate.									
<b>10.2.8</b>	<b>2222</b>	<b>V/Hz Limiter Ti</b>	ms	FLOAT		50.0	0	0	RW	EXP	F
		Defines the time constant of the integral action of the current limiter in V/f mode. Its value is set by the drive after the self-tuning procedure or after the "Take parameter" command based on the motor data plate.									
<b>10.2.9</b>	<b>2224</b>	<b>V/Hz slip fltr const</b>	ms	FLOAT		10.0	1.0	1000.0	RW	EXP	F
		Sets the filter for slip compensation. The value set in this parameter determines the reaction time of the slip compensation function. The lower this parameter's setting, the higher the slip compensation reaction. If this parameter is set too low, undesirable speed fluctuations.									
<b>10.2.10</b>	<b>2230</b>	<b>V/Hz Boost gain</b>	V	FLOAT		0.0	0	0	RW	EXP	F
		Defines the gain for automatic boost voltage adjustment in the "Automatic" mode.									
		It is defined directly by the drive after the self-tuning procedure or after the "Take parameter" command based on the motor data plate.									
<b>10.2.11</b>	<b>2480</b>	<b>Vf Min Freq</b>	Hz	FLOAT		0.5	0	5	RW	EXP	F
		Minimum frequency setting in VF control mode. This is the minimum output frequency value; below this value no frequency adjustment is effective.									
<b>10.2.12</b>	<b>2482</b>	<b>Vf Min Dly</b>	ms	FLOAT		800	0	5000	RW	EXP	F
		Delay setting for minimum frequency signal in VF control mode.									
<b>10.2.13</b>	<b>2206</b>	<b>Middle voltage</b>	V	FLOAT		0	0	0	RW	EXP	F
		Setting an intermediate voltage value for the customised V/f property.									
<b>10.2.14</b>	<b>2208</b>	<b>Middle frequency</b>	Hz	FLOAT		0	0	0	RW	EXP	F
		Setting an intermediate frequency value for the customised V/f property.									
<b>10.2.15</b>	<b>2232</b>	<b>Initial voltage</b>	V	FLOAT		0	0	60.0	RW	EXP	F
		Setting the value for the initial voltage applied at zero frequency when using the customised V/f property.									
<b>10.2.16</b>	<b>2210</b>	<b>V/Hz Profile type</b>		ENUM		Linear			RW	EXP	F
		Selection of the type of V/f property.									
	0	Linear									
	1	Custom									
		Setting 0 (Linear) gives a V/f property that is linear, with midpoints set to half the value of parameters 2202 <b>Base voltage</b> and 2204 <b>Base frequency</b> .									
		Setting 1 (Custom) provides a customised V/f property where the intermediate voltage and frequency values are defined by parameters 2206 <b>Middle voltage</b> and 2208 <b>Middle frequency</b> while the initial voltage (boost) value is given by parameter 2232 <b>Initial voltage</b> .									



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.17	2226	V/Hz Boost slope		FLOAT		0.0	0	0	RW	EXP	F

Slope of the initial section of the V/f property during which the boost voltage is applied.

Only valid for the linear V/f property. It is automatically defined by the drive following the self-tuning procedure.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.18	2228	Slip comp hold		ENUM			Disable		RW	EXP	F

Activates the slip compensation.

- 0 - Disable
- 1 - Enable

## 10.3 REGULATOR PARAM

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.1	2250	<b>CR-P gain</b>	V/A	FLOAT		1.0	0	0	RW	EXP	FVSY
Setting of the proportional gain of the current regulator (CR).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.2	2252	<b>CR-I time</b>	ms	FLOAT		1.0	0	0	RW	EXP	FVSY
Sets the integral time constant of the current regulator (CR).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.3	2260	<b>FR-P gain</b>	A/Wb	FLOAT		1.0	0	0	RW	EXP	FVSY
Sets the proportional gain value of the flux regulator (FR) used only in vector control ([1] ASY FOC, PAR 540 <b>Control type</b> ) for asynchronous motors.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.4	2262	<b>FR-I time</b>	ms	FLOAT		1.0	0	0	RW	EXP	FVSY
Sets the value of the integral time constant of the flux regulator (FR) used only in vector control ([1] ASY FOC, PAR 540 <b>Control type</b> ) for asynchronous motors.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.5	2272	<b>VR-I time</b>	ms	FLOAT		1.0	0	0	RW	EXP	FVSY
Sets the value of the integral time constant of the output voltage regulator (VR).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.6	2290	<b>Deflux voltage</b>	V	FLOAT		380	0	0	RW	EXP	FVSY
Defines the maximum AC voltage value applicable by the inverter. For speeds greater than the base speed (at the speed for which the applied voltage reaches its maximum value) the drive reduces the magnetic flux of the motor by entering the Flux weakening operating range.											
Flux reduction enables higher speeds to be reached at the expense of the maximum deliverable torque, which decreases accordingly.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.7	2292	<b>Voltage margin</b>	perc	FLOAT		5.0	0	30.0	RW	EXP	FVSY
Setting of the voltage regulation margin according to the available voltage. In case of a Deflux voltage setting close to or equal to the actual mains value, <b>Voltage margin</b> (PAR 2292) represents the margin allowable by the voltage regulation to perform rapid current variations when load steps are suddenly applied.											
A value of 5% allows a very fast response to load steps but with a loss of output voltage and thus power output (reduced power output).											
The minimum value (1%) allows a maximum output voltage (around 98%) of the mains voltage to be achieved but with loss of quality of the dynamic response.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.8	2308	<b>Over-flux level</b>	perc	FLOAT		100	100	150	RW	EXP	FVSY
The value is expressed as the percentage in excess of the rated flux.											
<p>The graph illustrates the relationship between Over-Flux level (%) and Over-flux spd thrsd (rpm). The Y-axis represents the Over-Flux level in percent, ranging from 80% to 120%. The X-axis represents the Over-flux spd thrsd in rpm, ranging from 200 to 1200. A horizontal line at 100% represents the rated flux. A vertical dashed line marks the Over-flux step (PAR 2314) at approximately 400 rpm. A horizontal dashed line extends from this point to the 120% level, indicating that for speeds above 400 rpm, the flux is increased to 120% of the rated value.</p>											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.3.9</b>	<b>2312</b>	<b>Over-flux spd thrsd</b>	rpm	FLOAT		400	1	1000	RW	EXP	FVSY
Speed limit below which the overflux value set in PAR 2308 <b>Over-flux level</b> .											
<b>10.3.10</b>	<b>2314</b>	<b>Over-flux step</b>		FLOAT		1	0.01	10	RW	EXP	FVSY
Setting of the ramp time in the transition between the rated flux and the overflux value set in PAR 2308 <b>Over-Flux level</b> .											
<b>10.3.11</b>	<b>2724</b>	<b>Defluxing curr lim</b>	A	FLOAT		0.0	0	0	RW	EXP	FVSY
This parameter specifies the maximum defluxing current (direct component of motor current) applicable by the drive in Flux Weakening operating range.											
Standard value 30% of the rated current. A null value disables the defluxing function.											

## 10.4 TORQUE CONFIG

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.1	2350	Torque curr lim Pos	A	FLOAT	16BIT_H	CALCF	0.0	CALCF	RW	EXP	FVSY

Setting of the active torque limit of the drive for the positive current direction (clockwise rotation and anti-clockwise braking).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.2	2352	Torque curr lim Neg	A	FLOAT	16BIT_H	CALCF	0.0	CALCF	RW	EXP	FVSY

Setting of the active torque limit of the drive for the negative current direction (anti-clockwise rotation and clockwise braking).


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.3	2354	Torque curr lim sel		ENUM		Off			RWZ	EXP	FVSY

Setting of the type of behaviour of the drive in the current limit condition.

- 0 Off
- 1 T clim +/-
- 2 T clim mot/gen
- 3 T limit src

If set to **0** no specific type of current limitation is set.

If set to **1** the active positive torque limit is **Torque curr lim Pos** (PAR 2350) and the active negative torque limit is **Torque curr lim Neg** (PAR 2352).



Torque limits with Torque curr lim Sel = 1

Torque limits with Torque curr lim sel = 2

If set to **2** three conditions are possible:

- 1 – If the motor speed is > +1% of **Rated speed** the active positive torque limit is **Torque curr lim Pos** (PAR 2350) and the active negative torque limit is **Torque curr lim Neg** (PAR 2352).
- 2 – If the motor speed is < -1% of **Rated speed** the active positive torque limit is **Torque curr lim Pos** (PAR 2350) and the active negative torque limit is **Torque curr lim Neg** (PAR 2352).
- 3 – If -1% of Motor non speed < motor speed < + 1% of **Rated speed** the active positive torque limit is **Torque curr lim Pos** (PAR 2350) and the active negative torque limit is **Torque curr lim Neg** (PAR 2352).

If set to **3** the torque limits are symmetrical. The torque limit is the value written in the source selected by **Torque limit src** (PAR 2358). This mode is not managed with ASY SSC control mode.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.4	2358	Torque limit src		LINK	16BIT_H	6000	0	2380	RWZ	EXP	FVSY

Selection of the origin (source) of the signal to be used for the torque current limit. The signals that can be associated with the function are listed in the “**L\_LIM**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.5	2360	Torque climPos Inuse	A	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY

The positive torque limit value currently being used is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.6	2362	Torque climNeg Inuse	A	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY

The negative torque limit value currently being used is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.7	2380	Dig torque ref	%	FLOAT	16BIT_H	0.0	-300.0	300.0	RW	EXP	FVSY

Setting of a digital torque reference. The current reference value is proportional to the active motor current and determines the torque value. The sign determines the torque direction.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.8	2382	Torque ref src		LINK	16BIT_H	65535	2380	2380	RWZ	EXP	FVSY

Selection of the origin (source) of the signal to be used for the torque reference. The signals that can be associated with the function are listed in the “L\_VREF” selection list.

# 11 FUNCTIONS

## 11.1 DC BRAKING

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.1	3150	DC braking cmd src		LINK	16BIT_L	6000			RW	INT	FVS

Selection of the origin (source) of the signal to be used for the **DC braking command**. The terminal or signal that can be used for this function can be defined from among those available in the “L\_DIGSEL2” selection list”.


- |   |                    |            |
|---|--------------------|------------|
| 0 | DC braking command | not enable |
| 1 | DC braking command | enable     |

In default conditions the origin of the **DC braking command** signal is 0 (not enable).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.2	3152	DC brake mode		ENUM		Off			RW	INT	FVS

This parameter can be used to configure the DC braking activation modes.

- |   |                |
|---|----------------|
| 0 | Off            |
| 1 | At Stop        |
| 2 | On Command     |
| 3 | OnCmd & AtStop |



In “Off” mode the direct current injection phase is never executed.

In “At stop” mode the direct current injection phase is executed when the stop command is sent and the speed reference threshold = zero has been reached.

Example:

With the motor running at any speed, when the stop command is enabled the ramp output decreases according to the selected ramp time, when the speed reference threshold = zero is reached PAR 934 **Ref is 0** the direct current injection phase is enabled. When the command is enabled after the delay configured in PAR 3154 **DC brake delay** direct current injection starts. PAR 3156 **DC brake time** is used to configure the duration of the injection phase and PAR 3158 **DC brake curr** is used to configure the intensity of the injection phase current.

In “At command” mode the direct current injection phase is executed when the **DC braking command** configured using parameter PAR 3150 **DC braking command src** is sent.

Example:

Motor running driven by load. When the drive is enabled and the **DC braking command** is sent the direct current injection phase is activated. When the command is enabled after the delay configured in PAR 3154 **DC brake delay** direct current injection starts. PAR 3156 **DC brake time** is used to configure the duration of the injection phase and PAR 3158 **DC brake curr** is used to configure the intensity of the injection phase current.

If the command is an impulse shorter than the time programmed with PAR 3156 **DC brake time**, the direct current injection phase continues at least for the time set in parameter **DC brake time**.

If the command is an impulse longer than the time programmed with 3156 **DC brake time**, the direct current injection phase continues for as long as the command is present.

In “OnCmd & AtStop” modes the direct current injection phase is executed when one of the two conditions described in the “At stop” or “On command” modes is present.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.3	3154	<b>DC brake delay</b>	s	FLOAT		0.01	0.01	30.0	RW	INT	FVS

This parameter is used to configure the delay in seconds between the moment DC braking is requested and the moment direct current injection starts.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.4	3156	<b>DC brake duration</b>	s	FLOAT		1.0	0.01	30.0	RW	INT	FVS

This parameter is used to configure the duration of direct current injection.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.5	3158	<b>DC brake current</b>	%	FLOAT		75	0.0	150.0	RW	INT	FVS

This parameter is used to configure the value of the injected direct current.

This is expressed as a percentage of the rated current (PAR 2002 **Rated Current**).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.6	3160	<b>DC brake state</b>		ENUM	16BIT_L	Not active			R	INT	FVS

The status of direct current braking is displayed.

- 0 Not active
- 1 Active

**Note!**

During braking the Enable command must be enabled. If this command is not present or is removed during the braking process, the drive blocks the inverter bridge and the motor stops due to inertia, without braking.

During the direct current injection phase the Run command should not be enabled. If the Run command is sent to the drive, the ramp output starts following the set reference; direct current output is produced in any case. The moment the DC braking command is removed there is immediately a speed step without performing a change in the ramp.

During the direct current injection phase, for the Jog command follow the instructions provided for the Run command.

## 11.2 INERTIA COMP

An increase in the dynamic response of the speed regulator to a variation in the reference, can be modified by changing the current value during the acceleration/deceleration phase, to counter the machine inertia.

These parameters are calculated by the speed loop autotuning procedure but can also be set manually by the user.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.2.1	3100	Inertia comp	kgm <sup>2</sup>	FLOAT		0.1	0	0	RW	EXP	FVSY

Total value of the inertia on the motor shaft in Kgm<sup>2</sup> identified during the self-tuning procedure. If known, this value can also be set manually by the user.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.2.2	3102	Inertia comp filter	ms	FLOAT		4.0	2.0	20.0	RW	EXP	FVSY

Setting of a filter on the torque compensation. The filter reduces noise due to speed differentiation in the inertia block.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.2.3	3104	Inertia comp mon	%	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY

The value of inertia compensation on the function block output is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.2.4	3106	Inertia comp fcn		ENUM		Disable			RW	EXP	FVSY

Enable inertia compensation mode.

- 0 Disable
- 1 Enable

## 11.4 VIBRATION ANALYSIS (VIBR. ANALYSIS)

This is a measurement tool that can be activated in FOC control modes, whether synchronous or asynchronous, to detect any mechanical vibration that occurs during movement at constant speed disturbing the comfort in the cabin. The measurement system for each movement is able to detect, if present, up to two resonance frequencies in the band between 5...300Hz and returns the values as output in two parameters. Any frequencies found can then be used to configure the notch filters in the SPEED REG GAINS menu.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.4.1	2288	Vibration analyzer		ENUM		Disable			RW	EXP	VSY

This parameter enables/disables the function for measuring resonance frequencies.

- 0 - Disable
- 1 - Enable

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.4.2	9464	Vibration freq. 1	Hz	FLOAT		0	0.0	0.0	R	EXP	VSY

Indicates the value in Hz of the first measured resonance frequency. If two frequencies have been detected, **Vibration freq. 1** will be the one with the higher amplitude.

A "0" value indicates that no resonance frequency is present in the measurement band.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.4.3	9466	Vibration freq. 2	Hz	FLOAT		0	0.0	0.0	R	EXP	VSY

Indicates the value in Hz of the second measured resonance frequency. If two frequencies have been detected, **Vibration freq. 2** will be the one with the lower amplitude.

A "0" value indicates that no second resonance frequency is present in the measurement band.

## 11.5 MOTOR OVERLOAD

The overload control function provides integrator logic to protect the motor against thermal overload. This protection emulates the thermal relay of the motor controlled by the ADL550 drive.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.1	3200	<b>Motor ovld enable</b>		ENUM		Off			RW	EXP	FVSY

Enabling of the motor overload control.

- 0 Off
- 1 On

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.2	3202	<b>Motor ovld factor</b>	%	FLOAT		150	100	300	RW	EXP	FVSY


Setting of the motor overload value. Percentage value of the motor rated current (PAR 2002 **Rated current**).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.3	3204	<b>Motor ovld time</b>	s	FLOAT		30	10	300	RW	EXP	FVSY

Setting of the motor overload duration in seconds. It represents the moment in which the protection ("Motor Overload") is enabled, if the motor current value is above the overload set in the PAR 3202 **Motor ovld factor** parameter.

This alarm can be assigned to a programmable digital output (PAR 3214 **Motor overload trip**).

The trip time depends on the motor current value and is as follows:



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.4	3206	<b>Motor service factor</b>	%	FLOAT		100	25	200	RW	EXP	FVSY

Setting of the motor service factor. This is the difference between the peak current and rated current. It is used to calculate the thermal image of the motor.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.5	3216	<b>Motor fan type</b>		ENUM		Auto fan			RW	EXP	FVSY

This parameter is used to set the type of motor cooling system.

- 0 Auto fan
- 1 Servo fan

**Auto fan** indicates the presence of a fan unit mounted on the motor shaft that therefore turns at a speed proportional to the motor speed. Cooling is not very effective at low motor speeds.

**Servo fan** indicates the presence of an independent fan unit that therefore always runs at the rated speed. It ensures optimum cooling efficiency at all motor speeds.

When the current motor speed is below (PAR 2004 **Rated speed** / 2) and PAR 3216 **Motor fan type** = Auto fan; , the MOTOR OVERLOAD protection intervention time must be reduced as cooling is insufficient.

At below (PAR 2004 **Rated speed** / 2) the protection intervention time is reduced by reducing the direct current of the MOTOR OVERLOAD function.

When the motor speed is equal to (PAR 2004 **Rated speed** / 2) the direct current of the MOTOR OVERLOAD function is equal to PAR 2002 **Rated current** \* PAR 3206 **Motor service factor**, whereas below that limit it is modified following a linear pattern until PAR 2002 **Rated current** \* 3206 **Motor service factor** \* PAR 3218 **Motor derat factor** when the motor speed reaches zero.

The overload current of the MOTOR OVERLOAD function is obtained by PAR 2002 **Rated current** \* 3206 **Motor service factor** \* PAR 3202 **Motor ovlid factor** and is the maximum current that can circulate in the motor. If the MOTOR OVERLOAD function is enabled the drive automatically sets the torque current limit so that lout max. does not exceed this value.

With the MOTOR OVERLOAD function a current equal to the Overload level is supplied to the motor for the maximum time set in PAR 3204 **Motor ovlid time**, The slower the motor speed, the shorter the time allowed (see figure at beginning of chapter).

After the set time, the MOTOR OVERLOAD function automatically sets the torque current limit so that lout max. does not exceed the direct current of the MOTOR OVERLOAD function.

When the motor current speed exceeds (PAR 2004 **Rated speed** / 2) and PAR 3216 **Motor fan type** = Auto fan, the direct current is not reduced as cooling is sufficient.

When PAR 3216 **Motor fan type** = Servo fan, the direct current is not reduced as cooling is sufficient.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.6	3218	<b>Motor derat factor</b>	%	FLOAT		50	0	100	RW	EXP	FVSY

This parameter is used to set the derating factor. The value is expressed as a percentage of PAR 2002 **Rated current** \* PAR 3206 **Motor service factor**.

When the current motor speed is below (PAR 2004 **Rated speed** / 2) and PAR 3216 **Motor fan type** = Auto fan, the protection intervention time must be reduced as cooling is insufficient.

At below (PAR 2004 **Rated speed** / 2) the protection intervention time is reduced by reducing the direct current of the MOTOR OVERLOAD function.

When the motor speed is equal to (PAR 2004 **Rated speed** / 2) the direct current of the MOTOR OVERLOAD function is equal to PAR 2002 **Rated current** \* PAR 3206 **Motor service factor**, whereas below that limit it is modified following a linear pattern until PAR 2002 **Rated current** \* PAR 3206 **Motor service factor** \* PAR 3218 **Motor derat factor** when the motor speed reaches zero.

The overload current of the MOTOR OVERLOAD function is obtained by PAR 2002 **Rated current** \* PAR 3206 **Motor service factor** \* PAR 3202 **Motor ovlid factor** and is the maximum current that can circulate in the motor. If the MOTOR OVERLOAD function is enabled the drive automatically sets the torque current limit so that lout max. does not exceed this value.

With the MOTOR OVERLOAD function a current equal to the Overload level is supplied to the motor for the maximum time set in PAR 3204 **Motor ovlid time**, The slower the motor speed, the shorter the time allowed (see graphs).

After the set time, the MOTOR OVERLOAD function automatically sets the torque current limit so that lout max. does not exceed the direct current of the MOTOR OVERLOAD function.

When the motor current speed exceeds (PAR 2004 **Rated speed** / 2) and PAR 3216 **Motor fan type** = Auto fan, the direct current is not reduced as cooling is sufficient.

When PAR 3216 **Motor fan type** = Servo fan, the direct current is not reduced as cooling is sufficient.

If the value of parameter 3202 **Motor ovlid factor** is 100 % the overload current of the Motor Overload function is equal to the continuous current of the Motor Overload function. In this case the drive behaves as if the overload cycle has been executed and so sets the torque current limit so that lout max is not more than the continuous current, i.e. **Rated current** (PAR 2002) \* **Motor service factor** (PAR 3206) \* **Motor derat factor** (PAR 3218).

We recommend setting parameter 3218 **Motor derat factor** to a value so that **Rated current** (PAR 2002) \* **Motor service factor** (PAR 3206) \* **Motor derat factor** (PAR 3218) produces a result that is more than the motor magnetisation current.

## 11.6 BRAKING RESISTOR OVERLOAD (BRES OVERLOAD)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.6.1	3250	<b>Bres control</b>		ENUM		On			RW	INT	FVSY
Enabling of the external braking resistance and relative overload control.											
	0	Off									
	1	On									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.6.2	3252	<b>Bres value</b>	ohm	FLOAT		7.0	7.0	1000.0	RW	INT	FVSY
Setting of the ohm value of the external braking resistor.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.6.3	3254	<b>Bres cont power</b>	kW	FLOAT		0.1	0.1	100.0	RW	INT	FVY
Setting of the power that can be continuously dissipated by the external braking resistor.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.6.4	3256	<b>Bres overload factor</b>	%	FLOAT		1.5	1.5	10.0	RW	INT	FVSY
Setting of the external resistor overload factor.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.6.5	3258	<b>Bres overload time</b>	s	FLOAT		0.5	0.5	50.0	RW	INT	FVSY
Setting of the intervention time of the external braking resistor overload.											

## 11.7 ENERGY SAVING (ENER. SAVING)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.7.1	3122	<b>Saved energy</b>	kWh	FLOAT		0	0	0	R	EXP	FVSY
Energy saved, starting from the first switch-on, by using the drive coupled with a regenerative unit. If the drive is not coupled to this product, the parameter calculates how much energy would have been saved.											
The displayed value is never reset even when the drive is switch-off.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.7.2	3124	<b>Set energy val</b>	kWh	FLOAT		0	0	0	RW	EXP	FVSY
Makes it possible to reset parameter 3122 <b>Saved energy</b> by entering "0" or a generic desired value.											
(e.g. if 10 kWh is entered, parameter 3122 is automatically updated to 10 kWh and continues to accumulate from this value).											

## PARAMETERS ON SELECTION LISTS, BUT NOT DISPLAYED ON KEYPAD

This list reports the parameters that are not displayed in the keyboard while they are part of the selection lists.

These parameters can be used as SOURCE of the input signals for the function block. (Refer to section A – Programming).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>262</b>	<b>Motor speed no filter</b>	rpm	INT16	16BIT_H	0	0	0	R	SRV	
Indicates the unfiltered motor speed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>626</b>	<b>Ramp ref out mon</b>	rpm	INT16	16BIT_H	0	0	0	R	SRV	
Displays the reference value output of the ramp reference function block.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>760</b>	<b>Ramp out mon</b>	rpm	INT16	16BIT_H	0	0	0	RW	SRV	
Displays the reference value output of the ramp function block.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>764</b>	<b>Ramp acc state</b>	BIT	16BIT_L	2	0	0	1	R	SRV	
Indicates whether the acceleration ramp is active.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>766</b>	<b>Ramp dec state</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
Indicates whether the deceleration ramp is active.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>934</b>	<b>Ref is 0</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
This signal is active when the reference is below the limit set in parameter 930 <b>Reference 0 threshold</b> .											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>936</b>	<b>Ref is 0 delay</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
It is active when the reference is below the threshold set in parameter 930 <b>Reference 0 threshold</b> . The signal is enabled after the delay set with parameter 932 <b>Reference delay 0</b> .											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>944</b>	<b>Speed is 0</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
It is active when the speed is below the threshold set in parameter 940 <b>Speed 0 threshold</b> .											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>946</b>	<b>Speed is 0 delay</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
It is active when the reference is below the threshold set in parameter 940 <b>Speed 0 threshold</b> . The signal is activated after the delay set in parameter 942 <b>Speed 0 delay</b> .											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>1024</b>	<b>Enable cmd mon</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
Enable signal monitor.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>1026</b>	<b>Start cmd mon</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
Start signal monitor.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>1028</b>	<b>FastStop cmd mon</b> Fast Stop signal monitor.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>1060</b>	<b>SM1 status</b> Status of DSP machine state.  255 - PSTART 0 - N_RDY_TO_SW_ON 64 - SWITCH_ON_DIS 33 - RDY_TO_SWT_ON 35 - SWITCHED_ON 39 - OPER_ENABLED 7 - QUICKSTOP_ACT 15 - FLT.REACT_ACT 8 - PFAULT		ENUM		PSTART			R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>1062</b>	<b>Drive OK</b> It is active when the drive is in the “OK” condition and no alarms are present.		UINT16	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>1064</b>	<b>Drive ready</b> It is active when the drive reference is in the “Ready” to run condition.		UINT16	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>3214</b>	<b>Motor overload trip</b> It is active when the drive is in the motor overload alarm condition.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>3262</b>	<b>Bres overload trip</b> It is active when the drive is in the braking resistor overload alarm condition.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>4708</b>	<b>Alm dig out mon 1</b> It is activated when the alarm configured in parameter 4700 <b>Alarm dig sel 1</b> is active.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>4710</b>	<b>Alm dig out mon 2</b> It is activated when the alarm configured in parameter 4702 <b>Alarm dig sel 2</b> is active.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>4712</b>	<b>Alm dig out mon 3</b> It is activated when the alarm configured in parameter 4704 <b>alarm dig sel 3</b> is active.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>4714</b>	<b>Alm dig out mon 4</b> It is activated when the alarm configured in parameter 4706 <b>alarm dig sel 4</b> is active.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>4770</b>	<b>First alarm</b> Displays the first alarm to be activated.		ENUM		No Alarms			R	SRV	

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>6000</b>	<b>Null</b>		UINT32	32BIT	0	0	0	R	SRV	

Forces the variable to the zero level (always disabled).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>6002</b>	<b>One</b>		UINT32	32BIT	1	1	1	R	SRV	

Forces the variable to level one (always active).

## C - Parameters Lists

### DRIVE SETUP

#### Access setup ?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
0.1	578	Language select		ENUM		GB			RW	INT	FVSY
				0 - English							
				1 - Italian							
				2 - French							
				3 - German							
				4 - Spanish							
				5 - Turkish							
0.2	390	Load Application		UINT16		-	-	4	RW	INT	FVY
				0 - No applicat.							
				1 - EFC							
0.3	598	Load from USB		BIT		0	0	1	RWZ	INT	
0.4	2132	Encoder mode		ENUM		None			RWZ	INT	
				0 - None							
				1 - Digital							
				2 - Sinus							
0.5	392	Select motor		BIT		0	0	1	RWZ	INT	

#### Leave setup ?

### 1 STARTUP WIZARD

#### 1.1 Set comm mode?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.1.1	4000	Communication mode		ENUM		Parallel			RW	INT	FVSY
				0 - Parallel I/O							

#### 1.2 Set encoder param?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.2.1	2102	Encoder supply	V	FLOAT		5.2	5.2	20.0	RW	INT	FVSY
1.2.2	2132	Encoder mode		ENUM		None			RWZ	INT	
				0 - None							
				1 - Digital							
				2 - Sinus							
1.2.3	2100	Encoder pulses	ppr	UINT16		1024	4	16384	RWZ	INT	

#### 1.3 Set motor data?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.3.1	540	Control type		ENUM		ASY_VF			RWZ	INT	FVSY
				0 - ASY SSC							
				1 - ASY FOC							
				2 - SYN FOC							
1.3.2	2000	Rated voltage	V	FLOAT		SIZE	150	480	RWZ	INT	FVSY
1.3.3	2002	Rated current	A	FLOAT		SIZE	1	1500	RWZ	INT	FVSY
1.3.4	2004	Rated speed	rpm	FLOAT		SIZE	10	32000	RWZ	INT	FVSY
1.3.5	2006	Rated frequency	Hz	FLOAT		SIZE	1	1000	RWZ	INT	FVS
1.3.6	2008	Pole pairs		UINT16		SIZE	1	60	RWZ	INT	FVSY
1.3.7	2010	Rated power	kW	FLOAT		SIZE	0.1	1500	RWZ	INT	FVS
1.3.8	2012	Rated power factor		FLOAT		SIZE	0.6	0.95	RWZ	INT	FVS

#### 1.4 Set mechanical data?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.4.1	11002	Travel units sel		ENUM		Hz (m/s)	-	-	RWZ	INT	FVY
				0 - Hz							

1 - m/s 2 - rpm										
1.4.2	11006	Cabin speed	m/s	FLOAT	1	0	10	RWZ	INT	FVY
1.4.3	11010	Gearbox ratio		FLOAT	45 (1)	1	200	RW	INT	FVY
1.4.4	11164	Rope ratio		FLOAT	1 (2)	1	10	RWZ	INT	FVY
1.4.5	11012	Pulley diameter	m	FLOAT	0.6 (0.32)	0	5	RWZ	INT	FVY
1.4.6	11150	Car weight	kg	FLOAT	400	0	10000	RW	INT	FVY
1.4.7	11152	Counter weight	kg	FLOAT	1000	0	10000	RW	INT	FVY
1.4.8	11154	Load weight	kg	FLOAT	450	0	10000	RW	INT	FVY
1.4.9	11156	Rope weight	kg	FLOAT	20	0	1000	RW	INT	FVY

## 1.5 Set speeds?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.1	11020	Multispeed 0		FLOAT		5 (0.1)	0	10000	RW	ESY	FVY
1.5.2	11022	Multispeed 1		FLOAT		47.73 (1.0)	0	10000	RW	ESY	FVY
1.5.3	11024	Multispeed 2		FLOAT		20 (0.4)	0	10000	RW	ESY	FVY
1.5.4	11026	Multispeed 3		FLOAT		0	0	10000	RW	ESY	FVY
1.5.5	11028	Multispeed 4		FLOAT		0	0	10000	RW	ESY	FVY
1.5.6	11030	Multispeed 5		FLOAT		0	0	10000	RW	ESY	FVY
1.5.7	11032	Multispeed 6		FLOAT		0	0	10000	RW	ESY	FVY
1.5.8	11034	Multispeed 7		FLOAT		0	0	10000	RW	ESY	FVY

## 1.7 Run autotune still?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.7.1	2032	Autotune		BIT		0	0	1	RWZ	INT	FVSY

## 1.8 Save parameters?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.8.1	550	Save parameters		BIT		0	0	1	RW	ESY	FVSY

## 2 OPTIMIZATION WIZARD

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
2.1	9720	Learning trip		BIT		0	0	1	RWZ	INT	VSY
2.2	12000	RollBack at start		UINT32		1	1	5	RW	ESY	FVY
2.3	12006	RollBack at arrival		UINT32		1	1	3	RW	ESY	FVY
2.4	12002	Comfort high spd		UINT32		1	1	3	RW	ESY	FVY
2.5	12004	Comfort low spd		UINT32		1	1	3	RW	INT	FVY

## 3 TROUBLESHOOTING

### 3.1 Start

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.1.1	11064	Brake open delay	ms	INT16/32		500	0	10000	RW	ESY	FVY

### 3.2 Rollback

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.2.1	2200	Boost voltage	%	FLOAT		3	0	20.0	RW	INT	F
3.2.2	2212	V/Hz Boost mode		ENUM		Auto			RW	INT	F
3.2.3	2794	SR-P gain at start	%	FLOAT		150.0	0.0	400.0	RW	INT	VSY
3.2.4	2796	SR-I gain at start	%	FLOAT		110.0	0.0	400.0	RW	INT	VSY

### 3.3 Too fast acceleration (Too fast accel.)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.3.1	11040	Accel initial jerk	m/s <sup>3</sup>	FLOAT		0.2	0.001	20	RW	ESY	FVY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.3.2	11042	Acceleration	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY

### 3.4 Slow speed vibrations (Slow speed vibr.)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.4.1	2752	SR-P gain low speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
3.4.2	2754	SR-I gain low speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY

### 3.5 High speed vibrations (High speed vibr.)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.5.1	2756	SR-P gain high speed	%	FLOAT		100	0.0	400.0	RW	INT	VSY
3.5.2	2758	SR-I gain high speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY

### 3.6 Too fast deceleration (Too fast dec.)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.6.1	11046	Decel initial jerk	m/s <sup>3</sup>	FLOAT		0.6	0.001	20	RW	ESY	FVY
3.6.2	11048	Deceleration	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY

### 3.7 Floor leveling

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.7.1	11068	Brake close delay	ms	INT16/32		500	0	10000	RW	ESY	FVY

### 3.9Vibrator analyzer

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.9.1	9464	Vibration freq. 1	Hz	FLOAT		0	0.0	0.0	R	INT	VSY
3.9.2	9466	Vibration freq. 2	Hz	FLOAT		0	0.0	0.0	R	INT	VSY

## 4 DRIVE

### 4.1 DRIVE MONITOR

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.1	250	Output current	A	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
4.1.2	252	Output voltage	V	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
4.1.3	254	Output frequency	Hz	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
4.1.4	664	Speed setpoint	rpm	INT16	16BIT_H	0	0	0	R	ESY	FVSY
4.1.5	260	Motor speed	rpm	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
4.1.6	270	DC link voltage	V	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
4.1.7	272	Heatsink temperature	degC	FLOAT	16BIT_L	0	0	0	R	ESY	FVSY
4.1.9	280	Torque current ref	A	FLOAT	16BIT_H	0	0	0	R	EXP	FVSY
4.1.10	282	Magnet current ref	A	FLOAT	16BIT_H	0	0	0	R	EXP	FVSY
4.1.11	284	Torque current	A	FLOAT	16BIT_H	0	0	0	R	INT	FVSY
4.1.12	286	Magnet current	A	FLOAT	16BIT_H	0	0	0	R	INT	FVSY
4.1.13	3212	Motor overload	%	UINT16	16BIT_H	0	0	100	R	ESY	FVSY
4.1.14	368	Drive overload	%	UINT16	16BIT_H	0	0	100	R	ESY	FVSY
4.1.15	3260	Bres overload	%	UINT16	16BIT_H	0	0	100	R	ESY	FVSY
4.1.16	1066	Enable state mon		UINT16	16BIT_L	0	0	1	R	ESY	FVSY
4.1.17	1068	Start state mon		UINT16	16BIT_L	0	0	1	R	ESY	FVSY
4.1.18	1070	FastStop state mon		UINT16	16BIT_L	0	0	1	R	ESY	FVSY
4.1.19	2386	Torque ref	%	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY
4.1.20	2388	Torque	%	FLOAT	16BIT_H	0.0	0.0	0.0	R	INT	FVSY
4.1.21	372	In use current limit	A	FLOAT	16BIT_H	0	0	0	R	EXP	FVSY
4.1.23	1200	Dig input mon		UINT16	16BIT_L	0	0	0	R	ESY	FVSY
4.1.25	1400	Digital output mon		UINT16		0	0	0	R	ESY	FVSY

## 4.2 DRIVE INFO

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.2.1	172	Drive type		ENUM		ADL510			R	ESY	FVSY
				1 - ADL510							
				2 - ADL530							
				3 - ADL550							
4.2.2	482	Drive Size		UINT16		0	0	0	R	ESY	FVSY
4.2.3	484	Drive Family		ENUM		No power			R	INT	FVSY
				0 - Ness Potenza							
				1 - 230V..480V							
4.2.4	488	Drive cont current	A	FLOAT	CALCF	0.0	0.0	R	ESY	FVSY	
4.2.6	174	Firmware version		UINT32	0	0	0	R	ESY	FVSY	
4.2.7	176	DSP Firmware version		UINT32	0	0	0	R	ESY	FVSY	
4.2.8	180	DSP Boot version		UINT32	0	0	0	R	ESY	FVSY	
4.2.9	182	HMI Boot version		UINT32	0	0	0	R	ESY	FVSY	
4.2.10	184	Application name		STRING16	0	0	0	R	ESY	FVSY	
4.2.11	192	Application version		UINT32	0	0	0	R	ESY	FVSY	
4.2.12	198	Versione Hardware		UINT16	0	0	0	R	ESY	FVSY	
4.2.13	520	Product S/N		UINT32	0	0	0	R	ESY	FVSY	
4.2.14	522	Regulation S/N		UINT32	0	0	0	R	ESY	FVSY	
4.2.15	524	Power S/N		UINT32	0	0	0	R	ESY	FVSY	
4.2.16	526	Power file ver.rel		UINT16	0	0	0	R	ESY	FVSY	
4.2.17	9562	IP address		UINT32	0	0	0	R	ESY	FVSY	
4.2.18	9600	Mac address		STRING16	0	0	0	R	EXP	FVSY	

## 4.3 DRIVE CONFIG \*

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.1	550	Save parameters		BIT		0	0	1	RWZ	ESY	FVSY
4.3.2	580	Load default		BIT		0	0	1	RWZ	ESY	FVSY
4.3.3	540	Control type		ENUM		ASY_VF			RWZ	INT	FVSY
				0 - ASY SSC							
				1 - ASY FOC							
				2 - SYN FOC							
4.3.4	554	Access level		ENUM		Intermediate			RW	ESY	FVSY
				0 - Readonly							
				1 - Easy							
				2 - INT							
				3 - Expert							
				4 - Service							
4.3.5	568	Enable Passwords		BIT		0	0	1	RW	EXP	FVSY
4.3.7	560	Mains voltage		ENUM		400 V			RWZ	INT	FVSY
				1 - 230 V							
				2 - 380 V							
				3 - 400 V							
				4 - 415 V							
				5 - 440 V							
				6 - 460 V							
				7 - 480 V							
4.3.8	448	Emergency UV	V	FLOAT	CALCF	0	CALCF	RWZ	INT	FVSY	
4.3.9	450	Undervoltage	V	FLOAT	300.0	0	0	RW	INT	FVSY	
4.3.10	2690	Chopper ON	V	FLOAT	CALCF	0	CALCF	RWZ	EXP	FVSY	
4.3.11	1010	Fast start disable		BIT	1	0	1	RW	EXP	FVSY	
4.3.12	574	Startup display		INT16	-1	-1	20000	RW	INT	FVSY	
4.3.13	576	Display backlight		BIT	0	0	1	RW	INT	FVSY	
4.3.14	578	Language select		ENUM		GB			RW	INT	FVSY
				0 - English							
				1 - Italian							
				2 - French							
				3 - German							
				4 - Spanish							
				5 - Turkish							
4.3.15	7200	Password recovery		BIT	0	0	1	RW	ESY	FVSY	
4.3.16	7210	Recovery code		UINT32	0.0	0	0	R	ESY	FVSY	
4.3.17	7220	Logout time	min	UINT16	60	0	1092	RW	EXP	FVSY	

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.18	590	Save par to keypad		BIT		0	0	1	RWZ	INT	FVSY

\* Parameters 578, 590, 592, 596, 598, 1560, 9548 are only visible on keypad.

## 4.4 ALARM CONFIG

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.1	4500	Fault reset src		LINK	16BIT_L	6000			RW	INT	FVSY
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.2	4502	ExtFlt src		LINK	16BIT_L	6000			RW	INT	FVSY
				L_DIGSEL2							
4.4.3	4504	ExtFlt activity		ENUM		Disable			RW	INT	FVSY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Stop							
				4 - Fast stop							
4.4.4	4506	ExtFlt restart		ENUM		Disable			RW	EXP	FVSY
				0 - Disable							
				1 - Enable							
4.4.5	4508	ExtFlt restart time	ms	UINT16		1000	120	30000	RW	EXP	FVSY
4.4.6	4510	ExtFlt holdoff	ms	UINT16		0	0	10000	RW	INT	FVSY
4.4.8	4520	MotorOT src		LINK	16BIT_L	6000			RW	INT	FVSY
				L_DIGSEL2							
4.4.9	4522	MotorOT activity		ENUM		Warning			RW	INT	FVSY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Stop							
				4 - Fast stop							
4.4.10	4524	MotorOT restart		ENUM		Disable			RW	EXP	FVSY
				0 - Disable							
				1 - Enable							
4.4.11	4526	MotorOT restart time	ms	UINT16		1000	120	30000	RW	EXP	FVSY
4.4.12	4528	MotorOT holdoff	ms	UINT16		1000	0	30000	RW	EXP	FVSY
4.4.18	4540	Overspeed threshold	rpm	INT16		CALCI	0	16000	RW	INT	FVSY
4.4.19	4542	Overspeed activity		ENUM		Disable			RW	INT	FVSY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
4.4.20	4544	Overspeed holdoff	ms	UINT16		0	0	5000	RW	INT	FVSY
4.4.21	4550	SpdRefLoss threshold	rpm	INT16		100	0	CALCI	RW	INT	FVSY
4.4.22	4552	SpdRefLoss activity		ENUM		Disable			RW	INT	FVSY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
4.4.23	4554	SpdRefLoss holdoff	ms	UINT16		1000	0	10000	RW	INT	FVSY
4.4.24	4560	SpdFbkLoss activity		ENUM		Disable			RW	INT	FVSY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
4.4.25	4562	SpdFbkLoss holdoff	ms	UINT16		200	0	10000	RW	INT	FVSY
4.4.26	4564	SpdFbkLoss Threshold	rpm	INT16		100	0	CALCI	RW	INT	FVSY
4.4.27	4570	Drive ovld activity		ENUM		Disable			RW	EXP	FVSY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Stop							
				4 - Fast stop							
4.4.28	4572	Motor ovld activity		ENUM		Warning			RW	EXP	FVSY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Stop							
				4 - Fast stop							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.29	4574	Bres ovld activity		ENUM 0 - Ignore 1 - Warning 2 - Disable drive 3 - Stop 4 - Fast stop		Disable			RW	EXP	FVSY
4.4.30	4582	HTsens restart		ENUM 0 - Disable 1 - Enable		Disable			RW	EXP	FVSY
4.4.31	4584	HTsens restart time	ms	UINT16		20000	120	60000	RW	EXP	FVSY
4.4.32	4610	Desat restart		ENUM 0 - Disable 1 - Enable		Disable			RW	EXP	FVSY
4.4.33	4612	Desat restart time	ms	UINT16		2000	1000	10000	RW	EXP	FVSY
4.4.34	4620	IOverC restart		ENUM 0 - Disable 1 - Enable		Disable			RW	EXP	FVSY
4.4.35	4622	IOverC restart time	ms	UINT16		2000	1000	10000	RW	EXP	FVSY
4.4.36	4630	OverV restart		ENUM 0 - Disable 1 - Enable		Disable			RW	EXP	FVSY
4.4.37	4632	OverV restart time	ms	UINT16		2000	1000	10000	RW	EXP	FVSY
4.4.38	4640	UnderV restart		ENUM 0 - Disable 1 - Enable		Enable			RW	EXP	FVSY
4.4.39	4642	UnderV restart time	ms	UINT16		1000	120	10000	RW	EXP	FVSY
4.4.40	4650	UVRep attempts		UINT16		5	0	1000	RW	EXP	FVSY
4.4.41	4652	UVRep delay	s	UINT16		240	0	300	RW	EXP	FVSY
4.4.42	4654	PhLoss mov activity		ENUM 0 - Ignore 1 - Warning 2 - Disable		Warning			RW	EXP	FVSY
4.4.43	4656	PhLoss mov HOLDOFF	ms	UINT32 0 - Ignore 1 - Warning 2 - Disable		200	0	2000	RW	EXP	FVSY
4.4.44	4674	PhLoss mov freq thr	Hz	FLOAT		0.5	0.1	5	RW	EXP	FVSY
4.4.45	4678	PhLoss mov freq thr	Hz	FLOAT		0	0	0	R	EXP	FVSY
4.4.46	4670	Optionbus activity		ENUM 0 - Ignore 1 - Warning 2 - Disable drive 3 - Stop 4 - Fast stop		Disable			RW	EXP	FVSY
4.4.47	4660	PhLoss in activity		ENUM 0 - Ignore 1 - Warning 2 - Disable drive		Disable			RW	EXP	FVSY
4.4.48	4662	PhLoss in restart		ENUM 0 - Disable 1 - Enable		Disable			RW	EXP	FVSY
4.4.49	4664	PhLoss in rest time	ms	UINT16		1000	120	10000	RW	EXP	FVSY
4.4.50	4668	PhLoss output test		ENUM 0 - Disabled 1 - Enable 2 - Powerup		Enable			RW	EXP	FVSY
4.4.51	4680	GroundFault thr	%	FLOAT		10.0	0.0	150.0	RW	INT	FVSY
4.4.52	4700	Alarm dig out 1 sel		ENUM		No alarm			RW	INT	FVSY
4.4.52	4702	Alarm dig out 2 sel		ENUM		No alarm			RW	INT	FVSY
4.4.53	4704	Alarm dig out 3 sel		ENUM		No alarm			RW	INT	FVSY
4.4.54	4706	Alarm dig out 4 sel		ENUM 0 - No alarm 1 - Overvoltage 2 - Undervoltage 3 - Ground fault 4 - Overcurrent		No alarm			RW	INT	FVSY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.	
					5 - Desaturation 6 - MultiUndervolt 7 - MultiOvcurr 8 - MultiDesat 9 - Heatsink OT 10 - HeatsinkS OTUT 11 - Ptc failure 12 - Motor OT 13 - Drive overload 14 - Motor overload 15 - Bres overload 16 - Phaseloss in 17 - Opt Bus fault 18 - Opt 1 IO fault 19 - Precharge faul 20 - Opt enc fault 21 - External fault 22 - Speed fbk loss 23 - Overspeed 24 - Speed ref loss 25 - Emg stop alarm 26 - Power down 27 - Phaseloss out 28 - OV safety 29 - Safety failure 30 - Phaseloss mov 31 - Ropes change 32 - Enable missing 33 - Plc1 fault 34 - Plc2 fault 35 - Plc3 fault 36 - Plc4 fault 37 - Plc5 fault 38 - Plc6 fault 39 - Plc7 fault 40 - Plc8 fault 41 - Plc9 fault 42 - Plc10 fault 43 - Plc11 fault 44 - Plc12 fault 45 - Plc13 fault 46 - Plc14 fault 47 - Plc15 fault 48 - Plc16 fault 49 - Watchdog 50 - Trap error 51 - System error 52 - User error 53 - Param error 54 - Load def par 55 - Plc cfg error 56 - Load def plc 57 - Key failed 58 - Encoder error 59 - Recovery mode							
4.4.55	4720	Alm autoreset time	s	FLOAT	0.0	0.0	60.0	RW	EXP	FVSY		
4.4.57	4722	Alm autoreset number		UINT16	3	0	100	RW	EXP	FVSY		

## 4.8 DIGITAL INPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.1	1240	Dig inp 1 inversion		BIT	0	0	1	RW	INT	FVSY	
4.8.2	1242	Dig inp 2 inversion		BIT	0	0	1	RW	INT	FVSY	
4.8.3	1244	Dig inp 3 inversion		BIT	0	0	1	RW	INT	FVSY	
4.8.4	1246	Dig inp 4 inversion		BIT	0	0	1	RW	INT	FVSY	
4.8.5	1248	Dig inp 5 inversion		BIT	0	0	1	RW	INT	FVSY	
4.8.6	1250	Dig inp 6 inversion		BIT	0	0	1	RW	INT	FVSY	
4.8.7	1252	Dig inp 7 inversion		BIT	0	0	1	RW	INT	FVSY	
4.8.8	1254	Dig inp 8 inversion		BIT	0	0	1	RW	INT	FVSY	
4.8.13	1110	Dig input E mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.14	1210	Dig input 1 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.15	1212	Dig input 2 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.16	1214	Dig input 3 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.17	1216	Dig input 4 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.18	1218	Dig input 5 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.19	1220	Dig input 6 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.20	1222	Dig input 7 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.21	1224	Dig input 8 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.26	1268	Dig input E dest		ILINK		0	0	0	R	EXP	FVSY
4.8.27	1270	Dig input 1 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.28	1272	Dig input 2 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.29	1274	Dig input 3 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.30	1276	Dig input 4 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.31	1278	Dig input 5 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.32	1280	Dig input 6 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.33	1282	Dig input 7 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.34	1284	Dig input 8 dest		ILINK		0	0	0	R	EXP	FVSY

## 4.9 DIGITAL OUTPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.9.1	1430	Dig out 1 inversion		BIT		0	0	1	RW	INT	FVSY
4.9.2	1432	Dig out 2 inversion		BIT		0	0	1	RW	INT	FVSY
4.9.3	1434	Dig out 3 inversion		BIT		0	0	1	RW	INT	FVSY
4.9.4	1436	Dig out 4 inversion		BIT		0	0	1	RW	INT	FVSY

## 4.10 ANALOG INPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.1	1600	Analog input mon	cnt	INT16	16BIT_H	0	0	0	R	ESY	FVSY
4.10.2	1602	Analog inp type		ENUM		-10V..+10V			RW	INT	FVSY
						0 - -10V..+10V					
						1 - 0.20mA , 0.10V					
						2 - 4..20mA					
4.10.3	1604	Analog inp scale		FLOAT		1.0	-10.0	10.0	RW	INT	FVSY
4.10.4	1606	An inp offset tune		BIT		0	0	1	RW	INT	FVSY
4.10.5	1608	An inp gain tune		BIT		0	0	1	RW	INT	FVSY
4.10.6	1610	Analog inp filter	ms	FLOAT		10	2	100	RW	EXP	FVSY
4.10.7	1612	Analog inp top	cnt	INT16		16384	-32768	+32767	RW	EXP	FVSY
4.10.8	1614	Analog inp bottom	cnt	INT16		-16384	-32768	+32767	RW	EXP	FVSY
4.10.9	1616	Analog inp offset	cnt	INT16		0	-32768	+32767	RW	EXP	FVSY
4.10.10	1618	Analog inp gain		FLOAT		1.0	-10.0	10.0	RW	EXP	FVSY
4.10.11	1626	An inp sign src		LINK	16BIT_L L_DIGSEL2	6000			RW	INT	FVSY
4.10.12	1632	Analog input dest		ILINK		0	0	0	R	EXP	FVSY

## 4.11 ALARM LOG

## 4.12 LIFE TIME

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.12.1	510	Time drive power on	h:min	UINT32		0	0	0	R	ESY	FVSY
4.12.2	512	Time drive enable	h:min	UINT32		0	0	0	R	ESY	FVSY
4.12.3	514	Number power up		UINT16		0	0	0	R	ESY	FVSY
4.12.4	516	Time fan on	h:min	UINT32		0	0	0	R	ESY	FVSY

## 5 LIFT

### 5.1 MONITOR

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.1	14014	Trip number		UINT32			-	-	R	ESY	FVY
5.1.2	14016	Sequence state		ENUM			-	-	R	ESY	FVY
						0 - Idle					
						1 - Cont close					

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
						2 - Drive ready 3 - Brake open 4 - Smooth start 5 - Multispeed 6 - Waiting 0 spd 7 - Zero speed 8 - Brake close 9 - Cont open 10 - Not drive ok 91- SC cont mon					
5.1.3	14030	Acceleration space	m	FLOAT			-	-	R	ESY	FVY
5.1.4	14032	Deceleration space	m	FLOAT			-	-	R	ESY	FVY
5.1.5	14034	Landing zone space	m	FLOAT			-	-	R	ESY	FVY
5.1.6	14210	Actual speed ref	m/s	FLOAT			-	-	R	ESY	FVY
5.1.7	14242	Actual cabin spd	m/s	FLOAT			-	-	R	ESY	FVY

## 5.2 MECHANICAL DATA

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.2.1	11002	Travel units sel		ENUM		Hz (m/s)	-	-	RWZ	INT	FVY
						0 - Hz 1 - m/s 2 - rpm					
5.2.2	11006	Cabin speed	m/s	FLOAT	1	0	10		RWZ	INT	FVY
5.2.3	11010	Gearbox ratio		FLOAT	45 (1)	1	200		RW	INT	FVY
5.2.4	11164	Rope ratio		FLOAT	1 (2)	1	10		RWZ	INT	FVY
5.2.5	11012	Pulley diameter	m	FLOAT	0.6 (0.32)	0	5		RWZ	INT	FVY
5.2.6	11150	Car weight	kg	FLOAT	400	0	10000		RW	INT	FVY
5.2.7	11152	Counter weight	kg	FLOAT	1000	0	10000		RW	INT	FVY
5.2.8	11154	Load weight	kg	FLOAT	450	0	10000		RW	INT	FVY
5.2.9	11156	Rope weight	kg	FLOAT	20	0	1000		RW	INT	FVY

## 5.3 SPEED

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.1	11020	Multi speed 0		FLOAT		5 (0.1)	0	10000	RW	ESY	FVY
5.3.2	11022	Multi speed 1		FLOAT		47.73 (1.0)	0	10000	RW	ESY	FVY
5.3.3	11024	Multi speed 2		FLOAT		20 (0.4)	0	10000	RW	ESY	FVY
5.3.4	11026	Multi speed 3		FLOAT		0	0	10000	RW	ESY	FVY
5.3.5	11028	Multi speed 4		FLOAT		0	0	10000	RW	ESY	FVY
5.3.6	11030	Multi speed 5		FLOAT		0	0	10000	RW	ESY	FVY
5.3.7	11032	Multi speed 6		FLOAT		0	0	10000	RW	ESY	FVY
5.3.8	11034	Multi speed 7		FLOAT		0	0	10000	RW	ESY	FVY
5.3.9	14010	Actual multi spd sel		ENUM		0 - Multispeed 0 1 - Multispeed 1 2 - Multispeed 2 3 - Multispeed 3 4 - Multispeed 4 5 - Multispeed 5 6 - Multispeed 6 7 - Multispeed 7 8 - Null			R	ESY	FVY

## 5.4 RAMPS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.1	11040	Accel initial jerk	m/s <sup>3</sup>	FLOAT	0.2	0.001	20		RW	ESY	FVY
5.4.2	11042	Acceleration	m/s <sup>2</sup>	FLOAT	0.600	0.001	10		RW	ESY	FVY
5.4.3	11044	Accel end jerk	m/s <sup>3</sup>	FLOAT	0.6	0.001	20		RW	ESY	FVY
5.4.4	11054	Percent acc factor	%	FLOAT	100	10	1000		RW	INT	FVY
5.4.5	11046	Decel initial jerk	m/s <sup>3</sup>	FLOAT	0.6	0.001	20		RW	ESY	FVY
5.4.6	11048	Deceleration	m/s <sup>2</sup>	FLOAT	0.600	0.001	10		RW	ESY	FVY
5.4.7	11050	Decel end jerk	m/s <sup>3</sup>	FLOAT	0.600	0.001	20		RW	ESY	FVY
5.4.8	11056	Percent dec factor	%	FLOAT	100	10	1000		RW	INT	FVY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.9	11052	Stop deceleration	m/s <sup>2</sup>	FLOAT		0.6	0.001	10000	RW	ESY	FVY

## 5.5 SEQUENCES

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.1	11060	Sequence start stop		ENUM		Start fwd/rev	-	-	RWZ	ESY	FVY
				0 - Start fwd/rev							
				1 - Enable							
				2 - Mltspd out !=0							
5.5.2	11084	Smooth start mode		ENUM		Variable jerk	-	-	RWZ	INT	FVY
				1 - Speed constant							
				2 - Jerk variable							
5.5.3	11082	Smooth start speed		FLOAT		0	0	10000	RW	INT	FVY
5.5.4	11066	Smooth start time	ms	INT16/32		0	0	10000	RW	INT	FVY
5.5.5	11062	Contactor close dly	ms	INT16/32		200	0	10000	RW	ESY	FVY
5.5.6	11064	Brake open delay	ms	INT16/32		500	0	10000	RW	ESY	FVY
5.5.7	11078	Speed 0 threshold	rpm	INT16		30 (1)	0	10000	RW	INT	FVY
5.5.8	11080	Speed 0 delay	ms	UINT16		400	0	10000	RW	INT	FVY
5.5.9	11086	Door open speed	m/s	FLOAT		0	-10000	10000	RWZ	EXP	FVY
5.5.11	11068	Brake close delay	ms	INT16/32		500	0	10000	RW	ESY	FVY
5.5.12	11072	Contactor open dly	ms	INT16/32		200	0	10.000	RW	ESY	FVY
5.5.14	11826	Inspection behaviour		ENUM		None	-	-	RWZ	EXP	FVY
				0 - None							
				1 - Fast Stop							
				2 - Immediate							
5.5.15	11828	Inspection spd sel		ENUM		Multispeed 2	-	-	RWZ	INT	FVY
				0 - Multispeed 0							
				1 - Multispeed 1							
				2 - Multispeed 2							
				3 - Multispeed 3							
				4 - Multispeed 4							
				5 - Multispeed 5							
				6 - Multispeed 6							
				7 - Multispeed 7							
				8 - Null							
5.5.16	11244	Inversion motor rot		LINK		Not inverted			RWZ	INT	FVY
				0 - Not inverted							
				1 - Inverted							

## 5.6 LIFT OUT

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.	
5.6.1	1410	Dig output 1 src		LINK	16BIT_L	6000			RW	INT	FVSY	
				L_DIGSEL1								
5.6.2	1412	Dig output 2 src		LINK	16BIT_L	6000			RW	INT	FVSY	
				L_DIGSEL1								
5.6.3	1414	Dig output 3 src		LINK	16BIT_L	6000			RW	INT	FVSY	
				L_DIGSEL1								
5.6.4	1416	Dig output 4 src		ENUM	16BIT_L	6000			RW	INT	FVSY	
				L_DIGSEL1								
5.6.7	11016	Rit uscita Abil Lift	ms	UINT	0	0	5000	RW	EXP	FVY		
5.6.8	14104	Command output mon	Hex	UINT32					R	ESY	FVY	

## 5.7 LIFT IN

Menu	PAR	Description	UM	Tipo	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.7.1	11220	Lift enable cmd src		ENUM		Dig input E mon	-	-	RW	INT	FVY
				LiftInputAdICmd							
5.7.2	11222	Start fwd cmd src		ENUM		Dig input 1 mon	-	-	RW	INT	FVY
				LiftInputAdICmd							
5.7.3	11224	Start rev cmd src		ENUM		Dig input 2 mon	-	-	RW	INT	FVY
				LiftInputAdICmd							
5.7.4	11256	Speed ref src		ENUM		Multispeed	-	-	RW	INT	FVY
				640 - Multispeed							
				1600 - Analog in 1							
				4034 - Fieldbus M->S2							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.	
						4044 - Fieldbus M->S3 4054 - Fieldbus M->S4 4064 - Fieldbus M->S5 4074 - Fieldbus M->S6 4084 - Fieldbus M->S7 4094 - Fieldbus M->S8 4104 - Fieldbus M->S9 4114 - Fieldbus M->S10 4124 - Fieldbus M->S11 4134 - Fieldbus M->S12 4144 - Fieldbus M->S13 4154 - Fieldbus M->S14 4164 - Fieldbus M->S15 4174 - Fieldbus M->S16						
5.7.5	11226	Multi speed S0 src		ENUM	Dig input 4 mon	-	-	-	RW	ESY	FVY	
					LiftInputAdlCmd							
5.7.6	11228	Multi speed S1 src		ENUM	Dig input 5 mon	-	-	-	RW	ESY	FVY	
					LiftInputAdlCmd							
5.7.7	11230	Multi speed S2 src		ENUM	Dig input 6 mon	-	-	-	RW	ESY	FVY	
					LiftInputAdlCmd							
5.7.8	11232	Contactor fbk src		ENUM	Run cont mon	-	-	-	RW	INT	FVY	
					LiftInputAdlCmd							
5.7.9	11236	Brake fbk src		ENUM	Brake cont mon	-	-	-	RW	INT	FVY	
					LiftInputAdlCmd							
5.7.10	10096	Brake 2 fbk src		ENUM	Brake cont mon	-	-	-	RW	INT	FVY	
					LiftInputAdlCmd							
5.7.11	11238	Door open src		ENUM	Null	-	-	-	RW	EXP	FVY	
					LiftInputDoorCmd							
5.7.12	11240	Door feedback src		ENUM	Null	-	-	-	RW	EXP	FVY	
					LiftInputAdlCmd							
5.7.13	11242	Emergency mode src		ENUM	Dig input 3 mon	-	-	-	RW	INT	FVY	
					LiftInputAdlCmd							
5.7.14	11246	Upper limit src		ENUM	Null	-	-	-	RW	INT	FVY	
					LiftInputAdlCmd							
5.7.15	11248	Lower limit src		ENUM	Null	-	-	-	RW	INT	FVY	
					LiftInputAdlCmd							
5.7.17	11274	Landing Cmd src		ENUM	Null	-	-	-	RW	INT	FVY	
					LiftInputAdlCmd							
5.7.18	11820	Brake release src		LINK	Null	-	-	-	RW	EXP	VY	
					LiftInputAdlCmd							
5.7.20	14102	Command input mon		Hex	UINT32		-	-	R	ESY	FVY	

## 5.8 PRE TORQUE

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.	
5.8.1	11166	Pre-torque enable		BIT	Off	-	-	-	RWZ	EXP	VY	
5.8.2	11168	Pre-torque source		ENUM	Init pretorque	-	-	-	RW	EXP	VY	
					1600 - Analog in 1 4034 - Fieldbus M->S2 4044 - Fieldbus M->S3 4054 - Fieldbus M->S4 4064 - Fieldbus M->S5 4074 - Fieldbus M->S6 4084 - Fieldbus M->S7 4094 - Fieldbus M->S8 4104 - Fieldbus M->S9 4114 - Fieldbus M->S10 4124 - Fieldbus M->S11 4134 - Fieldbus M->S12 4144 - Fieldbus M->S13 4154 - Fieldbus M->S14 4164 - Fieldbus M->S15 4174 - Fieldbus M->S16 11170 - Init pretorque							
5.8.3	11170	Init pre-torque	%	INT16/32	0	-100	100		RWZ	EXP	VY	
5.8.4	11172	Pre-torque ramp up	ms	INT16/32	0	0	10000		RWZ	EXP	VY	

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.5	11174	Pre-torque ramp down	ms	INT16/32		0	0	60000	RWZ	EXP	VY
5.8.6	11176	Pre-torque offset	%	FLOAT		0	-100	100	RWZ	EXP	VY
5.8.7	11178	Pre-torque gain		FLOAT		1.0	-100	100	RWZ	EXP	VY

## 5.9 LIFT EMERGENCY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.1	11286	Battery control		ENUM		Disable	-	-	RWZ	INT	FVY
				0 - Disable							
				1 - Enable							
5.9.2	11260	Emergency mode speed		FLOAT		4.77 (0.1)	-10000	10000	RW	INT	FVY
5.9.3	11262	Autoselect direction		ENUM		Recommended			RWZ	INT	FVY
				0 - OFF							
				1 - AutoSelect							
				2 - Recommended							
				3 - Battery saving							
				4 - BattSav + Rec							
5.9.4	11278	Em DC brk current	%	FLOAT		75.0	0	150	RW	INT	FV
5.9.5	11284	Detection limit	%	UINT32		20	0	100	RWZ	INT	FVY
5.9.6	14282	Chosen Direction		ENUM		-	-	-	R	INT	
				0 - No direction							
				1 - Forward							
				2 - Reverse							
5.9.7	11094	Brake release type		ENUM		Brake+Gear	-	-	RW	EXP	VY
				0 - Brake							
				1 - Brake+Gear							
5.9.8	11090	Em min speed		FLOAT		0.05	0	10000	RW	EXP	VY
5.9.9	11092	Em min spd time	s	INT16/32		6	1	30	RW	EXP	VY
5.9.10	11108	Delay mot sav bat	m/s	INT32		1000	0	5000	RW	EXP	VY
5.9.11	11822	Max vel em		UINT32		0.1	-	-	RW	EXP	VY
5.9.12	11014	Em mac speed sav bat	Hz	FLOAT		0.09	0.01	1000	RW	EXP	VY
5.9.13	11824	Brake lock time	s	UINT32		4	1	30	RW	EXP	VY

## 5.10 LIFT ALARMS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.1	11058	Lift fast stop fact		FLOAT		10	1	50	RWZ	INT	FVY
5.10.2	11200	Contactor activity		ENUM		Disable			RWZ	INT	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							
5.10.3	11202	Cont hold off	ms	INT32		1000	0	60000	RW	INT	FVY
5.10.4	11204	Brake activity		ENUM		Disable			RWZ	INT	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							
5.10.5	11206	Brake hold off	ms	INT32		1000	0	60000	RW	INT	FVY
5.10.6	10094	Brake 2 hold off	ms	INT32		1000	0	60000	RW	INT	FVY
5.10.7	11208	Brake run hold off		ENUM		Enable	-	-	RW	INT	FVY
				0 - Disable							
				1 - Enable							
5.10.8	11210	Door activity		ENUM		Disable	-	-	RWZ	EXP	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							
5.10.9	11212	Door hold off	ms	INT32		1000	0	60000	RW	EXP	FVY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.10	11214	Limit activity		ENUM		Lift fast stop	-	-	RWZ	INT	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							
5.10.11	11216	Limit speed thr	m/s	FLOAT		1	0	10	RW	INT	FVY
5.10.12	11218	Spd target activity		ENUM		Warning			RWZ	INT	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							
5.10.13	11258	Lift EF alarm src		ENUM		Null	-	-	RWZ	INT	FVY
				6000 - Null							
				6002 - One							
				12250 - B0 Lift decomp							
				12252 - B1 Lift decomp							
				12254 - B2 Lift decomp							
				12256 - B3 Lift decomp							
				12258 - B4 Lift decomp							
				12260 - B5 Lift decomp							
				12262 - B6 Lift decomp							
				12264 - B7 Lift decomp							
				12266 - B8 Lift decomp							
				12268 - B9 Lift decomp							
				12270 - B10 Lift decomp							
				12272 - B11 Lift decomp							
				12274 - B12 Lift decomp							
				12276 - B13 Lift decomp							
				12278 - B14 Lift decomp							
				12280 - B15 Lift decom							
				1110 - Dig input E mon							
				1210 - Dig input 1 mon							
				1212 - Dig input 2 mon							
				1214 - Dig input 3 mon							
				1216 - Dig input 4 mon							
				1218 - Dig input 5 mon							
				1220 - Dig input 6 mon							
				1222 - Dig input 7 mon							
				1224 - Dig input 8 mon							
				1230 - Dig input 1x mon							
				1232 - Dig input 2x mon							
				1234 - Dig input 3x mon							
				1236 - Dig input 4x mon							
				3702 - Run cont mon							
				3706 - Down cont mon							
				3708 - Brake cont mon							
				3714 - Door open mon							
5.10.14	11264	Lift EF al activity		ENUM		Lift stop	-	-	RWZ	INT	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							
5.10.15	11266	Lift EF hold off	ms	UINT32	1000	0	60000		RW	INT	FVY
5.10.17	11850	No battery activity		ENUM		Warning	-	-	RWZ	INT	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							
5.10.18	11852	No battery hold off	ms	UINT32	1000	0	10000		RW	INT	FVY

## 5.11 DISTANCE

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.1	11102	Distance multispeed0	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.2	11104	Distance multispeed1	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.3	11106	Distance multispeed2	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.4	11110	Distance multispeed3	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.5	11112	Distance multispeed4	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.6	11114	Distance multispeed5	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.7	11116	Distance multispeed6	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.8	11118	Distance multispeed7	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.9	11120	Slow speed		ENUM		Autoselect	-	-	RW	INT	FVY
						0 - Autoselect					
						1 - Multispeed 0					
						2 - Multispeed 1					
						3 - Multispeed 2					
						4 - Multispeed 3					
						5 - Multispeed 4					
						6 - Multispeed 5					
						7 - Multispeed 6					
						8 - Multispeed 7					
						9 - Null					
5.11.10	11130	Enable landing src		INT16		Off			RW	EXP	FVY
5.11.11	11132	Landing zone dist	m	FLOAT		0.120	0	10	RW	EXP	FVY
5.11.12	11138	Out floor function		BIT		Off			RW	EXP	FVY
5.11.13	11140	Delay acq time	ms	FLOAT		15	0	1000	RW	EXP	FVY
5.11.14	11142	Calc space HiSpd sel		UINT16		Multispeed 1	-	-	RW	EXP	FVY
						0 - Multispeed 0					
						1 - Multispeed 1					
						2 - Multispeed 2					
						3 - Multispeed 3					
						4 - Multispeed 4					
						5 - Multispeed 5					
						6 - Multispeed 6					
						7 - Multispeed 7					
						8 - Null					
5.11.15	11276	KP Landing		FLOAT		0	0	100	RW	EXP	FVY

## 5.14 DIRECTION CNT

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.14.1	3400	Direction cnt enable		ENUM		Disable			RW	EXP	FVSY
						0 - Off					
						1 - On					
5.14.2	3402	Max direcion cnt		UINT32		0	0	2147483647	RW	EXP	FVSY
5.14.3	3404	Ropes change thr	%	UINT32		98	0	100	RW	EXP	FVSY
5.14.4	3406	Direction cnt reset		BIT		0	0	1	RW	EXP	FVSY
						0 - Off					
						1 - On					
5.14.5	3408	Inser pssw dir cnt		UINT32		0	0	999999	RW	EXP	FVSY
5.14.6	3410	Nuova pssw dir cnt		UINT32		0	0	999999	RW	EXP	FVSY
5.14.7	3412	Ropes usage	%	UINT16	16BIT_L	0	0	0	R	EXP	FVSY
5.14.8	3414	Direction counter		UINT32	32BIT	0	0	0	R	EXP	FVSY
5.14.9	3416	Prev direct counter		UINT32	32BIT	0	0	0	R	EXP	FVSY
5.14.10	3418	No of cnt reset		UINT32	32BIT	0	0	0	R	EXP	FVSY
5.14.11	3420	Ropes change req mon		BIT	16BIT_L	0	0	1	R	EXP	FVSY
5.14.12	3422	Dir change monitor		BIT	16BIT_L	0	0	1	R	EXP	FVSY
5.14.13	3424	Dir change cnt zero		BIT	16BIT_L	0	0	1	R	EXP	FVSY
5.14.16	3440	Dircnt password type		ENUM		Static	-	-	RW	EXP	FVSY
5.14.17	3442	Pwd code build		BIT		0	0	1	RW	EXP	FVSY
5.14.18	3444	Pwd code		UINT32		0.0	0	0	R	EXP	

## 6 COMMUNICATION

### 6.1 CONTROL COMMUNICATION (CONTROL COMM)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.1.1	4000	Communication mode		ENUM 0 - Parallel I/O		Parallel			RW	INT	FVSY

### 6.6 NETWORK AND ACCESS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.6.1	9610	Readonly Username		STRING16		readonly	0	0	R	EXP	FVSY
6.6.2	9626	Easy Username		STRING16		easy	0	0	RW	EXP	FVSY
6.6.3	9634	Easy Password		STRING16		easy	0	0	RW	EXP	FVSY
6.6.4	9642	Interm Username		STRING16		interm	0	0	R	EXP	FVSY
6.6.5	9650	Interm Password		STRING16		interm	0	0	RW	EXP	FVSY
6.6.6	9658	Expert Username		STRING16		expert	0	0	R	EXP	FVSY
6.6.7	9666	Expert Password		STRING16		expert	0	0	RW	EXP	FVSY
6.6.13	9556	IP Address set		UINT32		169.254.10.10	0	0	RW	EXP	FVSY
6.6.14	9558	IP Netmask set		UINT32		255.255.0.0	0	0	RW	EXP	FVSY
6.6.15	9560	IP Gateway set		UINT32		0.0.0.0	0	0	RW	EXP	FVSY
6.6.16	9564	IP Netmask		UINT32		255.255.0.0	0	0	R	EXP	FVSY
6.6.17	9566	IP Gateway		UINT32		0.0.0.0	0	0	R	EXP	FVSY
6.6.18	9608	Ip Assignment		ENUM 0 - DHCP 1 - Static		Static	0	0	RW	EXP	FVSY

## 7 MOTOR DATA

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.2	2000	Rated voltage	V	FLOAT		SIZE	150	480	RWZ	INT	FVSY
7.3	2002	Rated current	A	FLOAT		SIZE	1	1500	RWZ	INT	FVSY
7.4	2004	Rated speed	rpm	FLOAT		SIZE	10	32000	RWZ	INT	FVSY
7.5	2006	Rated frequency	Hz	FLOAT		SIZE	1	1000	RWZ	INT	FVS
7.6	2008	Pole pairs		UINT16		SIZE	1	60	RWZ	INT	FVSY
7.7	2010	Rated power	kW	FLOAT		SIZE	0.1	1500	RWZ	INT	FVS
7.8	2012	Rated power factor		FLOAT		SIZE	0.6	0.95	RWZ	INT	FVS
7.10	2020	Take parameters		BIT		0	0	1	RWZ	INT	FVSY
7.11	2022	Autotune rotation		BIT		0	0	1	RWZ	INT	FVS
7.12	2024	Autotune still		BIT		0	0	1	RWZ	INT	FVSY
7.13	2030	Autotune status		ENUM 0 - Required 1 - Done		Required			R	INT	FVSY
7.14	2050	Measured Rs	ohm	FLOAT		0	0	200	RW	EXP	FVSY
7.15	2052	Measured DTL	V	FLOAT		0	0	100	RW	EXP	FVSY
7.16	2054	Measured DTS	V/A	FLOAT		0	0	100	RW	EXP	FVSY
7.17	2056	Measured Lsig	mH	FLOAT		0.1	0.1	200	RW	EXP	FVS
7.20	2062	Measured ImN	A	FLOAT		CALCF	0	1000	RW	EXP	FVS
7.21	2066	Measured FlxN	Wb	FLOAT		CALCF	0	10	RW	EXP	FVS
7.22	2076	Measured Rr	ohm	FLOAT		CALCF	0	200	RW	EXP	FVS
7.23	2078	Take tune parameters		BIT		0	0	1	RW	INT	FVSY

## 8 ENCODER

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.1	2100	Encoder pulses	ppr	UINT16		1024	4	16384	RWZ	INT	
8.2	2102	Encoder supply	V	FLOAT		5.2	5.2	20.0	RW	INT	FVSY
8.3	2104	Encoder input config		ENUM 0 - HTL 1 - TTL		TTL			RWZ	INT	
8.4	2106	Encoder repetition		ENUM 0 - No division		No division			RWZ	INT	

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
				1 - Divide 2 2 - Divide 4 3 - Divide 8 4 - Divide 16 5 - Divide 32 6 - Divide 64							
8.5	2108	Encoder signal Vpp	V	FLOAT		0.8	0.5	1.2	RWZ	INT	
8.6	2110	Encoder signal check		ENUM		Check A-B			RWZ	EXP	
				1 - Check A-B 2 - Check A-B-Z							
8.7	2116	ENC signal Vpp inc	V	FLOAT		0	0	0	R	EXP	
8.9	2130	Encoder direction		ENUM		Not inverted			RWZ	INT	
				0 - Not inverted 1 - Inverted							
8.10	2132	Encoder mode		ENUM		None			RWZ	INT	FVSY
				0 - None 1 - Digital 2 - Sinus 3 - Sinus SINCOS 4 - Sinus ENDAT 5 - Sinus BISS 6 - ENDAT 7 - BiSS 8 - Sinus SSI							
8.11	2134	Encoder speed filter	ms	FLOAT		1.0	0.1	8.0	RW	EXP	
8.13	2150	Encoder speed	rpm	INT16	16BIT_H	0	0	0	R	ESY	
8.14	2162	Encoder position	cnt	UINT16	16BIT_H	0	0	0	R	ESY	
8.16	2172	SpdFbkLoss code		UINT16		0	0	0	R	EXP	

## 9 SICUREZZA

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
9.3	11252	Brake fbk A3 sel		ENUM		Null	-	-	RW	INT	FVY
9.4	11268	Reset Brake Alarm		INT		0	-	-	RW	INT	FVY
9.5	11270	Threshold A3	m	FLOAT		0.1	0	2	RW	INT	VY

## 10 REGULATION MENU

### 10.1 SPEED REGULATION GAINS (SPEED REG GAINS)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.1	2240	Inertia	$\text{kgm}^2$	FLOAT		0.8	0.001	1000	RW	INT	VSY
10.1.2	9702	Learning trip out	$\text{kgm}^2$	FLOAT		0	0	0	R	EXP	FVSY
10.1.3	2794	SR-P gain at start	%	FLOAT		150.0	0.0	400.0	RW	INT	VSY
10.1.4	2796	SR-I gain at start	%	FLOAT		110.0	0.0	400.0	RW	INT	VSY
10.1.5	2752	SR-P gain low speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
10.1.6	2754	SR-I gain low speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
10.1.7	2756	SR-P gain high speed	%	FLOAT		80.0	0.0	400.0	RW	INT	VSY
10.1.8	2758	SR-I gain high speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
10.1.9	2760	SR-low speed thrsd	%	UINT16		30	1	100	RW	INT	VSY
10.1.10	2762	SR-high speed thrsd	%	UINT16		70	1	100	RW	INT	VSY
10.1.11	2662	SR-P gain	N/rpm	FLOAT		1.0	0	0	RW	INT	VSY
10.1.12	2664	SR-I time	ms	FLOAT		1.0	0	0	RW	INT	VSY
10.1.13	9446	TNF1-frequency	Hz	FLOAT		100.0	5.0	350.0	RW	EXP	VSY
10.1.14	9448	TNF1-bandwidth	Hz	FLOAT		4	1	20	RW	EXP	VSY
10.1.15	9450	TNF1-depth		FLOAT		20	3	60	RW	EXP	VSY
10.1.16	9458	Torque Notch Fltr 1		ENUM		Disable			RW	EXP	VSY
				0 - Disable 1 - Enable							
10.1.17	9452	TNF2-frequency	Hz	FLOAT		100.0	5.0	350.0	RW	EXP	VSY
10.1.18	9454	TNF2-bandwidth	Hz	FLOAT		4	1	20	RW	EXP	VSY
10.1.19	9456	TNF2-depth		FLOAT		20	3	60	RW	EXP	VSY
10.1.20	9460	Torque Notch Fltr 2		ENUM		Disable			RW	EXP	VSY
				0 - Disable							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1 - Enable											
10.1.21	2806	SR-P gain in use	%	FLOAT		100.0	0	0	R	INT	VSY
10.1.22	2808	SR-I gain in use	%	FLOAT		100.0	0	0	R	INT	VSY

## 10.2 VF CONTROL

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
0 - Fixed 1 - Auto											
10.2.1	2200	Boost voltage	%	FLOAT		3	0	20.0	RW	ESY	F
10.2.2	2202	Base voltage	V	FLOAT		0	0	0	RW	ESY	F
10.2.3	2204	Base frequency	Hz	FLOAT		0	0	0	RW	ESY	F
10.2.4	2212	V/Hz Boost mode		ENUM		Auto			RW	ESY	F
10.2.5	2214	V/Hz Slip ctrl gain		FLOAT		0	0	0	RW	EXP	F
10.2.6	2218	V/Hz Stability gain		FLOAT		0.0	0	0	RW	EXP	F
10.2.7	2220	V/Hz Limiter Kp	Hz/A	FLOAT		0.2	0	0	RW	EXP	F
10.2.8	2222	V/Hz Limiter Ti	ms	FLOAT		50.0	0	0	RW	EXP	F
10.2.9	2224	V/Hz slip fltr const	ms	FLOAT		10.0	1.0	1000.0	RW	EXP	F
10.2.10	2230	V/Hz Boost gain	V	FLOAT		0.0	0	0	RW	EXP	F
10.2.11	2480	Vf Min Freq	Hz	FLOAT		0.5	0	5	RW	EXP	F
10.2.12	2482	Vf Min Dly	ms	FLOAT		800	0	5000	RW	EXP	F
10.2.13	2206	Middle voltage	V	FLOAT		0	0	0	RW	EXP	F
10.2.14	2208	Middle frequency	Hz	FLOAT		0	0	0	RW	EXP	F
10.2.15	2232	Initial voltage	V	FLOAT		0	0	60.0	RW	EXP	F
10.2.16	2210	V/Hz Profile type		ENUM		Linear			RW	EXP	F
10.2.17	2226	V/Hz Boost slope		FLOAT		0.0	0	0	RW	EXP	F
10.2.18	2228	Slip comp hold		ENUM		Disable			RW	EXP	F
						0 - Disable 1 - Enable					

## 10.3 REGULATOR PARAM

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
0 - Linear 1 - Custom											
10.3.1	2250	CR-P gain	V/A	FLOAT		1.0	0	0	RW	EXP	FVSY
10.3.2	2252	CR-I time	ms	FLOAT		1.0	0	0	RW	EXP	FVSY
10.3.3	2260	FR-P gain	A/Wb	FLOAT		1.0	0	0	RW	EXP	FVSY
10.3.4	2262	FR-I time	ms	FLOAT		1.0	0	0	RW	EXP	FVSY
10.3.5	2272	VR-I time	ms	FLOAT		1.0	0	0	RW	EXP	FVSY
10.3.6	2290	Deflux voltage	V	FLOAT		380	0	0	RW	EXP	FVSY
10.3.7	2292	Voltage margin	%	FLOAT		5.0	0	30.0	RW	EXP	FVSY
10.3.8	2308	Over-flux level	%	FLOAT		100	100	150	RW	EXP	FVSY
10.3.9	2312	Over-flux spd thrsd	rpm	FLOAT		400	1	1000	RW	EXP	FVSY
10.3.10	2314	Over-flux step		FLOAT		1	0,01	10	RW	EXP	FVSY
10.3.11	2724	Defluxing curr lim	A	FLOAT		0.0	0	0	RW	EXP	FVSY

## 10.4 TORQUE CONFIG

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1 - T clim +/- 2 - T clim mot/gen 3 - T limit src											
10.4.1	2350	Torque curr lim Pos	A	FLOAT	16BIT_H	CALCF	0.0	CALCF	RW	EXP	FVSY
10.4.2	2352	Torque curr lim Neg	A	FLOAT	16BIT_H	CALCF	0.0	CALCF	RW	EXP	FVSY
10.4.3	2354	Torque curr lim sel		ENUM		Off			RWZ	EXP	FVSY
0 - Off											
10.4.4	2358	Torque limit src		LINK	16BIT_H	6000			RWZ	EXP	FVSY
				L_LIM							
10.4.5	2360	Torque climPos Inuse	A	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY
10.4.6	2362	Torque climNeg Inuse	A	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY
10.4.7	2380	Dig torque ref	%	FLOAT	16BIT_H	0.0	-300.0	300.0	RW	EXP	FVSY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.8	2382	Torque ref src		LINK L_VREF	16BIT_H	65535			RWZ	EXP	FVSY

## 11 FUNCTIONS

### 11.1 DC BRAKING

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.1	3150	DC braking cmd src		LINK L_DIGSEL2	16BIT_L	6000			RW	INT	FVS
11.1.2	3152	DC brake mode		ENUM 0 - Off 1 - At Stop 2 - On Command 3 - OnCmd & AtStop		Off			RW	INT	FVS
11.1.3	3154	DC brake delay	s	FLOAT		0.01	0.01	30.0	RW	INT	FVS
11.1.4	3156	DC brake duration	s	FLOAT		1.0	0.01	30.0	RW	INT	FVS
11.1.5	3158	DC brake current	%	FLOAT		75.0	0.0	150.0	RW	INT	FVS
11.1.6	3160	DC brake state		ENUM 0 - Not active 1 - Active	16BIT_L	Not active			R	INT	FVS

### 11.2 INERTIA COMP

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.2.1	3100	Inertia comp	$\text{kgm}^2$	FLOAT		0.1	0	0	RW	EXP	FVSY
11.2.2	3102	Inertia comp filter	ms	FLOAT		4.0	2.0	20.0	RW	EXP	FVSY
11.2.3	3104	Inertia comp mon	%	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY
11.2.4	3106	Inertia comp fcn		ENUM 0 - Disable 1 - Enable		Disable			RW	EXP	FVSY

### 11.4 VIBRATION ANALYSIS (VIBR. ANALYSIS)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.4.1	2288	Vibrations analyzer		ENUM 0 - Disable 1 - Enable		Disable			RW	EXP	VSY
11.4.2	9464	Vibration freq. 1	Hz	FLOAT		0	0.0	0.0	R	EXP	VSY
11.4.3	9466	Vibration freq. 2	Hz	FLOAT		0	0.0	0.0	R	EXP	VSY

### 11.5 MOTOR OVERLOAD

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.1	3200	Motor ovld enable		ENUM 0 - Off 1 - On		Off			RW	EXP	FVSY
11.5.2	3202	Motor ovld factor	%	FLOAT		150	100	300	RW	EXP	FVSY
11.5.3	3204	Motor ovld time	s	FLOAT		30	10	300	RW	EXP	FVSY
11.5.4	3206	Motor service factor	%	FLOAT		100	25	200	RW	EXP	FVSY
11.5.5	3216	Motor fan type		ENUM 0 - Auto fan 1 - Servo fan		Servo fan			RW	EXP	FVY
11.5.6	3218	Motor derat factor	%	FLOAT		50	0	100	RW	EXP	FVSY

### 11.6 BRAKING RESISTOR OVERLOAD (BRES OVERLOAD)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.6.1	3250	Bres control		ENUM 0 - Off 1 - On		On			RW	INT	FVSY
11.6.2	3252	Bres value	ohm	FLOAT		7.0	7.0	1000.0	RW	INT	FVSY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.6.3	3254	Bres cont power	kW	FLOAT		0.1	0.1	100.0	RW	INT	FVSY
11.6.4	3256	Bres overload factor		FLOAT		1.5	1.5	10.0	RW	INT	FVSY
11.6.5	3258	Bres overload time	s	FLOAT		0.5	0.5	50.0	RW	INT	FVSY

## 11.7 ENERGY SAVING (ENER. SAVING)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.7.1	3122	Energia recuperata	kWh	FLOAT		0	0	0	R	EXP	FVSY
11.7.2	3124	Set val. energia	kWh	FLOAT		0	0	0	RW	EXP	FVSY

## D - Selection Lists

### L\_DIGSEL1

PAR	Description	Menu
6000	Null	(*)
6002	One	(*)
1110	Dig input E mon	4.8.13
1210	Dig input 1 mon	4.8.14
1212	Dig input 2 mon	4.8.15
1214	Dig input 3 mon	4.8.16
1216	Dig input 4 mon	4.8.17
1218	Dig input 5 mon	4.8.18
1220	Dig input 6 mon	4.8.19
1222	Dig input 7 mon	4.8.20
1224	Dig input 8 mon	4.8.21
1230	Dig input 1x mon	4.8.22
1232	Dig input 2x mon	4.8.23
1234	Dig input 3x mon	4.8.24
1236	Dig input 4x mon	4.8.25
1062	Drive OK	4.7.14
1064	Drive ready	4.7.15
934	Ref is 0	(*)
936	Ref is 0 delay	(*)
944	Speed is 0	(*)
946	Speed is 0 delay	(*)
1066	Enable state mon	4.1.16
1068	Start state mon	4.1.17
1070	FastStop cmd mon	4.1.18
1024	Enable cmd mon	4.7.10
1026	Start cmd mon	4.7.11
1028	FastStop cmd mon	(*)
4708	Alm dig out mon 1	(*)
4710	Alm dig out mon 2	(*)
4712	Alm dig out mon 3	(*)
4714	Alm dig out mon 4	(*)
362	Drive overload trip	13.4.8
3214	Motor overload trip	(*)
3262	Bres overload trip	(*)
366	Drive overload 80%	13.4.9
4454	Bit0 decomp mon	6.5.3
4456	Bit1 decomp mon	6.5.4
4458	Bit2 decomp mon	6.5.5
4460	Bit3 decomp mon	6.5.6
4462	Bit4 decomp mon	6.5.7
4464	Bit5 decomp mon	6.5.8
4466	Bit6 decomp mon	6.5.9
4468	Bit7 decomp mon	6.5.10
4470	Bit8 decomp mon	6.5.11
4472	Bit9 decomp mon	6.5.12
4474	Bit10 decomp mon	6.5.13
4476	Bit11 decomp mon	6.5.14
4478	Bit12 decomp mon	6.5.15
4480	Bit13 decomp mon	6.5.16
4482	Bit14 decomp mon	6.5.17
4484	Bit15 decomp mon	6.5.18
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16
3732	Activation delay enable	13.7.17
3718	Safe brake test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe brake test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15

### L\_DIGSEL2

PAR	Description	Menu
6000	Null	(*)
6002	One	(*)
1110	Dig input E mon	4.8.13
1210	Dig input 1 mon	4.8.14
1212	Dig input 2 mon	4.8.15
1214	Dig input 3 mon	4.8.16
1216	Dig input 4 mon	4.8.17
1218	Dig input 5 mon	4.8.18
1220	Dig input 6 mon	4.8.19
1222	Dig input 7 mon	4.8.20
1224	Dig input 8 mon	4.8.21
1230	Dig input 1x mon	4.8.22
1232	Dig input 2x mon	4.8.23
1234	Dig input 3x mon	4.8.24
1236	Dig input 4x mon	4.8.25
1062	Drive OK	4.7.14
1064	Drive ready	4.7.15
934	Ref is 0	(*)
936	Ref is 0 delay	(*)
944	Speed is 0	(*)
946	Speed is 0 delay	(*)
1066	Enable state mon	4.1.16
1068	Start state mon	4.1.17
1070	FastStop state mon	4.1.18
1024	Enable cmd mon	4.7.10
1026	Start cmd mon	4.7.11
1028	FastStop cmd mon	(*)
4708	Alm dig out mon 1	(*)
4710	Alm dig out mon 2	(*)
4712	Alm dig out mon 3	(*)
4714	Alm dig out mon 4	(*)
362	Drive overload trip	13.4.8
3214	Motor overload trip	(*)
3262	Bres overload trip	(*)
366	Drive overload 80%	13.4.9
4454	Bit0 decomp mon	6.5.3
4456	Bit1 decomp mon	6.5.4
4458	Bit2 decomp mon	6.5.5
4460	Bit3 decomp mon	6.5.6
4462	Bit4 decomp mon	6.5.7
4464	Bit5 decomp mon	6.5.8
4466	Bit6 decomp mon	6.5.9
4468	Bit7 decomp mon	6.5.10
4470	Bit8 decomp mon	6.5.11
4472	Bit9 decomp mon	6.5.12
4474	Bit10 decomp mon	6.5.13
4476	Bit11 decomp mon	6.5.14
4478	Bit12 decomp mon	6.5.15
4480	Bit13 decomp mon	6.5.16
4482	Bit14 decomp mon	6.5.17
4484	Bit15 decomp mon	6.5.18
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16
3732	Activation delay enable	13.7.17
3718	Safe brake test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe brake test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15

### L\_DIGSEL3

PAR	Description	Menu
XXXX	( <sup>(2)</sup> )	
6000	Null	(*)
1218	Dig input 5 mon	4.8.18
1220	Dig input 6 mon	4.8.19
1014	Local/remote src	4.7.6
( <sup>(2)</sup> ) = 1012	Dig local/remote	4.7.5

<sup>(2)</sup> the XXXX parameter changes according to the src parameter used:

## D - Selection Lists

### L\_LIM

PAR	Description	Menu
6000	Null	(*)
1600	Analog input mon	4.10.1
4024	Fieldbus M->S1 mon	6.2.3
4034	Fieldbus M->S2 mon	6.2.7
4044	Fieldbus M->S3 mon	6.2.11
4054	Fieldbus M->S4 mon	6.2.15
4064	Fieldbus M->S5 mon	6.2.19
4074	Fieldbus M->S6 mon	6.2.23
4084	Fieldbus M->S7 mon	6.2.27
4094	Fieldbus M->S8 mon	6.2.31
4104	Fieldbus M->S9 mon	6.2.35
4114	Fieldbus M->S10 mon	6.2.39
4124	Fieldbus M->S11 mon	6.2.43
4134	Fieldbus M->S12 mon	6.2.47
4144	Fieldbus M->S13 mon	6.2.51
4154	Fieldbus M->S14 mon	6.2.55
4164	Fieldbus M->S15 mon	6.2.59
4174	Fieldbus M->S16 mon	6.2.63
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16

### L\_MLTREF

PAR	Description	Menu
XXXX	(*)	
1600	Analog input mon	4.10.1
2150	Encoder speed	8.13
4024	Fieldbus M->S1 mon	6.2.3
4034	Fieldbus M->S2 mon	6.2.7
4044	Fieldbus M->S3 mon	6.2.11
4054	Fieldbus M->S4 mon	6.2.15
4064	Fieldbus M->S5 mon	6.2.19
4074	Fieldbus M->S6 mon	6.2.23
4084	Fieldbus M->S7 mon	6.2.27
4094	Fieldbus M->S8 mon	6.2.31
4104	Fieldbus M->S9 mon	6.2.35
4114	Fieldbus M->S10 mon	6.2.39
4124	Fieldbus M->S11 mon	6.2.43
4134	Fieldbus M->S12 mon	6.2.47
4144	Fieldbus M->S13 mon	6.2.51
4154	Fieldbus M->S14 mon	6.2.55
4164	Fieldbus M->S15 mon	6.2.59
4174	Fieldbus M->S16 mon	6.2.63
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16
6000	Null	(*)
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16

3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16

(4) the XXXX parameter changes according to the src parameter used:

4452	Word decomp src	6.5.2
(6) = 4450	Dig word decomp	6.5.1

### L\_WDECOMP

PAR	Descrizione	Menu
XXXX	(6)	
6000	Null	(*)
6002	One	(*)
4432	Word comp mon	6.4.17
4024	Fieldbus M->S1 mon	6.2.3
4034	Fieldbus M->S2 mon	6.2.7
4044	Fieldbus M->S3 mon	6.2.11
4054	Fieldbus M->S4 mon	6.2.15
4064	Fieldbus M->S5 mon	6.2.19
4074	Fieldbus M->S6 mon	6.2.23
4084	Fieldbus M->S7 mon	6.2.27
4094	Fieldbus M->S8 mon	6.2.31
4104	Fieldbus M->S9 mon	6.2.35
4114	Fieldbus M->S10 mon	6.2.39
4124	Fieldbus M->S11 mon	6.2.43
4134	Fieldbus M->S12 mon	6.2.47
4144	Fieldbus M->S13 mon	6.2.51
4154	Fieldbus M->S14 mon	6.2.55
4164	Fieldbus M->S15 mon	6.2.59
4174	Fieldbus M->S16 mon	6.2.63
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16

### L\_SCOPE

PAR	Description	Menu
6000	Null	(*)

### L\_VREF

PAR	Description	Menu
XXXX	(6)	
1600	Analog input mon	4.10.1
4024	Fieldbus M->S1 mon	6.2.3
4034	Fieldbus M->S2 mon	6.2.7
4044	Fieldbus M->S3 mon	6.2.11
4054	Fieldbus M->S4 mon	6.2.15
4064	Fieldbus M->S5 mon	6.2.19
4074	Fieldbus M->S6 mon	6.2.23
4084	Fieldbus M->S7 mon	6.2.27
4094	Fieldbus M->S8 mon	6.2.31
4104	Fieldbus M->S9 mon	6.2.35
4114	Fieldbus M->S10 mon	6.2.39
4124	Fieldbus M->S11 mon	6.2.43
4134	Fieldbus M->S12 mon	6.2.47
4144	Fieldbus M->S13 mon	6.2.51
4154	Fieldbus M->S14 mon	6.2.55
4164	Fieldbus M->S15 mon	6.2.59
4174	Fieldbus M->S16 mon	6.2.63
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16
6000	Null	(*)

(6) the XXXX parameter changes according to the src parameter used:

4452	Word decomp src	6.5.2
(6) = 4450	Dig word decomp	6.5.1

### LIFTINPUTADLCMD

PAR	Description	Menu
1110	Dig input E	4.8.13
1210	Dig input 1	4.8.14
1212	Dig input 2	4.8.15
1214	Dig input 3	4.8.16
1216	Dig input 4	4.8.17
1218	Dig input 5	4.8.18
1220	Dig input 6	4.8.19
1222	Dig input 7	4.8.20
1224	Dig input 8	4.8.21
1230	Dig input 1x	4.8.22
1232	Dig input 2x	4.8.23
1234	Dig input 3x	4.8.24


## D - Liste di selezione

PAR	Description	Menu	LIFTINPUTADLCMDEBC		
PAR	Description	Menu	PAR	Description	Menu
1236	Dig input 4x	4.8.25	1110	Dig input E mon	4.8.13
3702	Run cont mon	12.7.2	1210	Dig input 1 mon	4.8.14
3706	Down cont mon	12.7.4	1212	Dig input 2 mon	4.8.15
3708	Brake cont mon	12.7.5	1214	Dig input 3 mon	4.8.16
3714	Door open mon	12.7.8	1216	Dig input 4 mon	4.8.17
6000	Null	(*)	1218	Dig input 5 mon	4.8.18
6002	One	(*)	1220	Dig input 6 mon	4.8.19
12250	B0 Lift decomp	(*)	1222	Dig input 7 mon	4.8.20
12252	B1 Lift decomp	(*)	1224	Dig input 8 mon	4.8.21
12254	B2 Lift decomp	(*)	1230	Dig input 1x mon	4.8.22
12256	B3 Lift decomp	(*)	1232	Dig input 2x mon	4.8.23
12258	B4 Lift decomp	(*)	1234	Dig input 3x mon	4.8.24
12260	B5 Lift decomp	(*)	1236	Dig input 4x mon	4.8.25
12262	B6 Lift decomp	(*)	3702	Run cont mon	13.7.2
12264	B7 Lift decomp	(*)	3706	Down cont mon	13.7.4
12266	B8 Lift decomp	(*)	3708	Brake cont mon	13.7.5
12268	B9 Lift decomp	(*)	3714	Door open mon	13.7.8
12270	B10 Lift dcomp	(*)	8000	EBC SOK mon	12.1.1
12272	B11 Lift dcomp	(*)	8002	EBC Warning mon	12.1.2
12274	B12 Lift dcomp	(*)	8004	EBC Alarm mon	12.1.3
12276	B13 Lift dcomp	(*)	6000	Null	(*)
12278	B14 Lift dcomp	(*)	6002	One	(*)
12280	B15 Lift dcomp	(*)	12250	B0 Lift decomp	(*)
			12252	B1 Lift decomp	(*)
			12254	B2 Lift decomp	(*)
			12256	B3 Lift decomp	(*)
			12258	B4 Lift decomp	(*)
			12260	B5 Lift decomp	(*)
			12262	B6 Lift decomp	(*)
			12264	B7 Lift decomp	(*)
			12266	B8 Lift decomp	(*)
			12268	B9 Lift decomp	(*)
			12270	B10 Lift dcomp	(*)
			12272	B11 Lift dcomp	(*)
			12274	B12 Lift dcomp	(*)
			12276	B13 Lift dcomp	(*)
			12278	B14 Lift dcomp	(*)
			12280	B15 Lift dcomp	(*)


(\*) Parameter not shown on the keypad. For information see the "PARAMETERS INCLUDED IN SELECTION LISTS BUT NOT SHOWN ON THE KEYPAD" section.

### DRIVE


#### DRIVE OVERVIEW




#### DIGITAL INPUTS




## EXPANSION DIGITAL INPUTS



## DIGITAL OUTPUTS




## ANALOG INPUTS




# LIFT


## EFC OVERVIEW




## MULTISPEED




## RAMPS



## START SEQUENCES




## STOP SEQUENCES



### Note!


\* In the ADL510, parameter 11068 is set = 0 and cannot be displayed.

## PRE-TORQUE




# REGULATIONS

## SPEED REG GAINS




## TORQUE CONFIG




# FUNCTIONS


## MOTOR OVERLOAD SEROVFAN




## MOTOR OVERLOAD AUTO FAN




## BRES OVERLOAD




## DC BRAKING AT STOP



## DC BRAKING ON COMMAND



## DC BRAKING ON CMD & AT STOP



### F.1.1 Drive alarm handling

Drive alarms are managed by means of an Emergency message containing the error code relating to the alarm that is generated, according to the table below:

Selezione	Codice
No alarm	0
Overvoltage	1
Undervoltage	2
Ground fault	3
Overcurrent	4
Desaturation	5
MultiUndervolt	6
MultiOvcurr	7
MultiDesat	8
Heatsink OT	9
HeatsinkS OTUT	10
PTC failure	11
Motor OT	12
Drive overload	13
Motor overload	14
Bres overload	15
Phaseloss	16
Opt Bus fault	17
Opt 1 IO fault	18
Precharge fault	19
Not used	20

Selezione	Codice
External fault	21
Speed fbk loss	22
Overspeed	23
Speed ref loss	24
Not used	25
Power down	26
Phaseloss out	27
OV safety	28
Safety failure	29
Mot phase loss	30
Ropes change	31
Enable missing	32
Cont feedback	33
Brake Feedback	34
Door Feedback	35
Brake Failure	36
Safe Brake Test	37
Speed limit	38
Up/low limit	39
Lift ext fault	40
EBC fault	41

Selezione	Codice
No battery	42
Plc10 fault	42
Plc11 fault	43
Plc12 fault	44
Plc13 fault	45
Plc14 fault	46
Plc15 fault	47
Plc16 fault	48
Watchdog	49
Trap error	50
System error	51
User error	52
Param error	53
Load def par	54
Plc cfg error	55
Load def plc	56
Key failed	57
Encoder error	58
Recovery mode	59

**Manuale SW**  
Serie: ADL510  
Revision: 1.0  
Data: 06/02/2024  
Codice: 1S91SWEN

[www.weg.net](http://www.weg.net)

**WEG Automation Europe S.r.l.**  
Via Giosuè Carducci, 24  
21040 Gerenzano (VA) · Italy

Technical Assistance: [technohelp@weg.net](mailto:technohelp@weg.net)  
Customer Service: [salesmotion@weg.net](mailto:salesmotion@weg.net)

**Driving efficiency and sustainability**

