


# Instruction Manual

## EXP-IO- SENS-1000-ADV

### I/O Expansion card

- 2 PT1000 / NI1000 / Analog Inputs
- 1 Klixon / PTC / KTY84 Input
- 1 Klixon / PTC / KTY84 Output
- 2 Analog Outputs



## 1 Drive Requirements

The EXP-IO-SENS-1000-ADV card is designed for the following drives:

- Drive Type: ADV200 WA (all versions); Recommended Firmware Release: 1.0 or later.
- Drive Type: ADV200 (all versions); Firmware Release: 7.0 or later.

## 2 Description

The EXP-IO-SENS-1000-ADV is an optional expansion card for the ADV200 and ADV200 WA product family. This card enables measurement of ambient temperature values via PT1000 or NI1000 external probe, and of motor temperatures via Klixon, PTC or KTY84 external probe. The following I/O terminals are available on the card:

- 2 x Inputs for temperature measurement via PT1000 or NI1000 probe within the range of  $-20^{\circ}\text{C} \div 150^{\circ}\text{C}$  /  $-4^{\circ}\text{F} \div 302^{\circ}\text{F}$  or alternately working as 2 x analog inputs for analog measurement (selection via software configuration)
- 1 x Input for temperature measurement via Klixon, PTC or KTY84 probe;
- 1 x Output for Klixon, PTC or KTY84 probe power supply;
- 2 x Analog Outputs.

About the Analog Outputs:

- The analog outputs are manually configurable by means of a dedicated dip switch to select current or voltage mode (see picture in the next paragraph);
- The analog outputs can work in current mode within the range of  $0 \div 20\text{mA}$  or in voltage mode within the range of  $0 \div 10\text{V}$ .



**NOTE** The drive can host one single card.





## 3 Connections

Card pinout details are shown below:


|    |    |    |    |    |    |    |    |     |     |    |    |    |    |    |     |     |     |     |
|----|----|----|----|----|----|----|----|-----|-----|----|----|----|----|----|-----|-----|-----|-----|
| 91 | 92 | 93 | 94 | 95 | 96 | 97 | 98 | S2+ | TMP | nu | 51 | 52 | 53 | 54 | 61+ | 61- | 62+ | 62- |
|----|----|----|----|----|----|----|----|-----|-----|----|----|----|----|----|-----|-----|-----|-----|

| <b>Terminal</b> | <b>Name</b>                           | <b>Function</b>   | <b>Max.</b>  |
|-----------------|---------------------------------------|---|--|
| 91              | I-source Thermistor 1                 | Output current Thermistor 1   | DO NOT CONNECT CURRENT OR VOLTAGE SOURCE<br>(max 11V@1.3mA)  |
| 92              | V+ Thermistor 1                       | Positive Input Voltage Thermistor 1   | DO NOT CONNECT CURRENT OR VOLTAGE SOURCE<br>(max 12V)        |
| 93              | V- Thermistor 1                       | Negative Input Voltage Thermistor 1   | DO NOT CONNECT CURRENT OR VOLTAGE SOURCE<br>(max 12V)        |
| 94              | I-sink Thermistor 1                   | Input current Thermistor 1  | DO NOT CONNECT CURRENT OR VOLTAGE SOURCE<br>(max 11V@-1.1mA) |
| 95              | I-source Thermistor 2                 | Output current Thermistor 2   | DO NOT CONNECT CURRENT OR VOLTAGE SOURCE<br>(max 11V@1.3mA)  |
| 96              | V+ Thermistor 2                       | Positive Input Voltage Thermistor 2   | DO NOT CONNECT CURRENT OR VOLTAGE SOURCE<br>(max 12V)        |
| 97              | V- Thermistor 2                       | Negative Input Voltage Thermistor 2   | DO NOT CONNECT CURRENT OR VOLTAGE SOURCE<br>(max 12V)        |
| 98              | I-sink Thermistor 2                   | Input current Thermistor 2  | DO NOT CONNECT CURRENT OR VOLTAGE SOURCE<br>(max 11V@-1.3mA) |
| S2+             | Power supply Klixon, PTC, KTY84       | Output Power supply @ 10V limited in current to the sensors.                        | Max 7mA@10.1V  |
| TMP             | Measurement sensor Klixon, PTC, KTY84 | Input for temperature measurement (PTC or KTY84) or switch for Klixon.              | DO NOT CONNECT CURRENT OR VOLTAGE SOURCE<br>(max 12V)        |
| nu              | NOT USED                              |   |  |
| 51              | V1+ or I1+ measurement                | Positive Analog Input 1 for Voltage measurement 0-10V or current measurement 0-20mA | Max 12V/24mA   |
| 52              | V1- or I1- measurement                | Negative Analog Input 1 for Voltage measurement 0-10V or current measurement 0-20mA | Max 12V/24mA   |
| 53              | V2+ or I2+ measurement                | Positive Analog Input 2 for Voltage measurement 0-10V or current measurement 0-20mA | Max 12V/24mA   |
| 54              | V2- or I2- measurement                | Negative Analog Input 2 for Voltage measurement 0-10V or current measurement 0-20mA | Max 12V/24mA   |
| 61+             | Analog Output 1                       | Positive Analog Output 1 for Voltage 0-10V or current 0-20mA                        | DO NOT CONNECT CURRENT OR VOLTAGE SOURCE<br>(max 11V@21mA)   |
| 61-             | Analog Output 1                       | Negative Analog Output 1 for Voltage 0-10V or current 0-20mA                        | DO NOT CONNECT CURRENT OR VOLTAGE SOURCE<br>(max 11V@-21mA)  |
| 62+             | Analog Output 2                       | Positive Analog Output 2 for Voltage 0-10V or current 0-20mA                        | DO NOT CONNECT CURRENT OR VOLTAGE SOURCE<br>(max 11V@21mA)   |
| 62-             | Analog Output 2                       | Negative Analog Output 2 for Voltage 0-10V or current 0-20mA                        | DO NOT CONNECT CURRENT OR VOLTAGE SOURCE<br>(max 11V@-21mA)  |

Analog Output 1 and 2 dip-switches for voltage or current selection:

|    |  |   |
|----|--|---|
| S1 |  V<br> I | Channel 1 analog output factory-configured for output 0 – 10V |
| S2 |  V<br> I | Channel 2 analog output factory-configured for output 0 – 10V |

## ④ Functional Block Diagram



### Note:


Terminals 92-93 and 96-97 can be used as ANALOG INPUT

Terminals 51-52 and 53-54 can be used as TEMPERATURE SENSOR INPUT

## 5 Probe Wiring Diagrams


This section describes the wiring schema for connecting thermistors, RTD and sensors with reference to the most frequently used configuration. If the distance between the probe and the drive is longer than 3 meters (9.84 feet) 4-wire configuration is advisable.

- **PT-1000 or NI1000 2-wire connection:**




where  $R_w$  is the resistance of the wire and  $R_t$  is the resistance of the probe. Use shielded cables to connect the PT1000/NI1000 to the card and shortcut the shield to the metal cover of the drive (System Ground).

- **PT-1000 or NI1000 3-wire connection:**




where  $R_w$  is the resistance of the wire and  $R_t$  is the resistance of the probe. Use two twisted pair shielded cables to connect the PT-1000/NI-1000 to the card and shortcut the shield to the metal cover of the drive (System Ground).

- **PT-1000 or NI1000 4-wire connection:**




**4-wire connection  
electrical diagram**




**4-wire connection  
physical diagram**

where  $R_w$  is the resistance of the wire and  $R_t$  is the resistance of the probe. Use two twisted pair shielded cables to connect the PT-1000/NI-1000 to the card and shortcut the shield to the metal cover of the drive (System Ground).

- **Klixon / PTC / KTY84 connections:**



**Electrical diagram**



**Physical diagram**

Use twisted pair shielded cables to connect the probes to the card and shortcut the shield to the metal cover of the drive (System Ground).


## ⑥ Installation

To install the card refer to the “*Installation of optional cards*” chapter in the “ADV200 WA & ADV200 Quick Start” installation handbook. This chapter describes the procedure for installing the card.

During installation bear in mind the following:



- Do not connect an external voltage or current generator to the ports as specified in the connections table;
- The analog I/O terminations have no mutual galvanic insulation. Galvanic insulation is only available between the terminations and the control card.
- **CAUTION: Use only the supplied screws !**

Power LED:



## 7 Commissioning

Once the card is installed, the commissioning phase can start. Use the keypad to go to menu 02, which will show that the card is properly recognized and ready to operate



### NOTE

**ADV200 WA fw 1.0:** I/O 6 identifies the EXP-IO-SENS-1000-ADV card.

**ADV200 WA fw 2.0 and higher:** I/O 8 identifies the EXP-IO-SENS-1000-ADV card.

**ADV200 fw 7.0 and higher:** I/O 8 identifies the EXP-IO-SENS-1000-ADV card.

The Slot where the card is plugged in is shown.

## 8 Ordering Information

When ordering the EXP-IO-SENS-1000-ADV card please quote commercial code: **S5L37**.

WEG Automation Europe S.r.l.  
Via Carducci, 24 - 21040 Gerenzano [VA] ITALY  
Ph. +39 02 967601 - Fax +39 02 9682653 - info.motion@weg.net - www.weg.net