

Quick Installation Guide

CFW503 Frequency Inverter



18256889

Document: 10012664198/01

1 SAFETY INSTRUCTIONS

This quick installation guide contains the basic information necessary to commission the CFW503. It has been written to be used by qualified personnel with suitable training or technical qualification for operating this type of equipment. The personnel shall follow all the safety instructions described in this manual defined by the local regulations. Failure to comply with the safety instructions may result in death, serious injury, and/or equipment damage.

2 SAFETY WARNINGS IN THIS GUIDE AND IN THE PRODUCT

DANGER!
The procedures recommended in this warning aim at protecting the user against death, serious injuries and considerable material damages.

ATTENTION!
The procedures recommended in this warning aim at preventing material damages.

NOTE!
The information mentioned in this warning is important for the proper understanding and good operation of the product.

High voltages present.

Components sensitive to electrostatic discharges.
Do not touch them.

The connection to the protection grounding is required (PE).

Connection of the shield to the grounding.

3 PRELIMINARY RECOMMENDATIONS

DANGER!
Always disconnect the general power supply before changing any electric component associated to the inverter. Many components may remain loaded with high voltages and/or moving (fans), even after the AC power supply input is disconnected or turned off. Wait for at least ten minutes in order to guarantee the full discharge of the capacitors. Always connect the grounding point of the inverter to the protection grounding.

NOTE!
Frequency Inverter may interfere with other electronic equipment. Follow the precautions recommended in manual available for download on the website: www.weg.net.

NOTE!
It is not the intention of this guide to present all the possibilities for the application of the CFW503, as well as WEG cannot take any liability for the use of the CFW503 which is not based on this guide.
For further information about installation, full parameter list and recommendations, visit the website www.weg.net.

Do not execute any applied potential test on the inverter!
If necessary, contact WEG.

ATTENTION!
Electronic boards have components sensitive to electrostatic discharges.
Do not touch directly on components or connectors. If necessary, first touch the grounding point of the inverter, which must be connected to the protection earth (PE) or use a proper grounding strap.

DANGER!
Crushing Hazard.
In order to ensure safety in load lifting applications, electric and/or mechanical devices must be installed outside the inverter for protection against accidental fall of load.

DANGER!
This product was not designed to be used as a safety element. Additional measures must be taken so as to avoid material and personal damages.
The product was manufactured under strict quality control, however, if installed in systems where its failure causes risks of material or personal damages, additional external safety devices must ensure a safety condition in case of a product failure, preventing accidents.

ATTENTION!
The operation of this equipment requires detailed installation and operation instructions provided in the user's manual, programming manual and communication manuals, available for download on the website: www.weg.net.

4 ABOUT THE CFW503

The frequency inverter CFW503 is a high-performance product which allows the speed and torque control of three-phase induction motors.

5 NOMENCLATURE

Product and Series	Identification of the Model				Protection Rate	Conducted Emission Level	Hardware Version	Special Software Version
	Frame Size	Rated Current	N° of Phases	Brake				
Ex: CFW503	A	02P6	T	4	20	C2	---	---
	Refer to Table 2.2 to the CFW503 user's manual. Available for download on the website: www.weg.net NB = without dynamic braking							
CFW503	DB = with dynamic braking				20		Blank = standard plug-in module	Blank = standard software
	20 = IP20							
							H00 = without plug-in	Blank = it does not meet the levels of standards for conducted emission C2 or C3 = as per category 2 (C2) or 3 (C3) of IEC/EN 61800-3, with internal RFI filter
Available options								

NOTE!
For models with a special software version (Sx in the smart code) and for specific applications, refer to the application manual available for download on www.weg.net.

6 IDENTIFICATION LABEL

Model (Smart code of the inverter)

Serial number

Manufacturing date

WEG stock item

Production order

Rated input data (voltage, current and frequency)

Rated output data (voltage, current and frequency)

(a) For frame sizes A to E

(b) For frame sizes F, G, H and I

Figure 6.1: (a) and (b) Description of the identification label on the CFW503

7 RECEIVING AND STORAGE

The CFW503 is supplied in a cardboard package up to frame size E. Models with larger enclosures are packed in a wooden box. On this package, there is an identification label which is the same as the one attached to the side of the inverter.

Follow the procedures below to open the package of models from frame size F up:

- Place the package on a table with the help of two people.
- Open the package.
- Remove the cardboard or styrofoam protection.

Check if:

- The identification of the CFW503 matches the model purchased.
- Any damages occurred during transportation.

Report any damage immediately to the carrier.

If the CFW503 is not installed soon, store it in a clean and dry location (temperature between -25 °C and 60 °C (-77 °F and 140 °F)), with a cover to prevent dust accumulation inside it.

ATTENTION!
When the inverter is stored for a long period, it becomes necessary to perform the capacitor reforming. Refer to the procedure recommended in the user's manual, available for download on the website: www.weg.net.

8 INSTALLATION AND CONNECTION

8.1 ENVIRONMENTAL CONDITIONS:

Avoid:

- Direct exposure to sunlight, rain, high humidity or sea-air.
- Inflammable or corrosive liquids or gases.
- Excessive vibration.
- Dust, metallic particles or oil mist.

Environmental conditions permitted for the operation of the inverter:

- Temperature around the inverter from -10 °C (14 °F) to the nominal temperature.
- Inverters with frame sizes A to I: for temperatures surrounding the inverter higher than the specifications in Table B.3 in the user's manual CFW503, available for download on the website: www.weg.net, it is necessary to apply 2 % of current derating for each Celsius degree, limited to an increase of 10 °C (50 °F).
- Air relative humidity: 5 % to 95 % non-condensing.
- Maximum altitude: up to 1,000 m (3,300 ft) - nominal conditions.
- 1,000 m to 4,000 m (3,300 ft to 13,200 ft) - 1 % of current derating for each 100 m (328 ft) above 1,000 m of altitude.
- From 2,000 m to 4,000 m (6,600 ft to 13,200 ft) above sea level - maximum voltage reduction of 1.1 % for each 100 m (330 ft) above 2,000 m (6,600 ft).
- Pollution degree: 2 (according to EN 50178), with non-conductive pollution. Condensation must not originate conduction through the accumulated residues.

8.2 POSITIONING AND MOUNTING

The external dimensions and the drilling for the mounting, as well as the net weight (mass) of the inverter are presented in Figure 8.2.

Mount the inverter in the upright position on a flat and vertical surface. First, put the screws on the surface where the inverter will be installed, install the inverter and then tighten the screws observing the maximum torque for the screws indicated in Figure 8.2.

Allow the minimum clearances indicated in Figure 8.2, in order to allow the cooling air circulation. Do not install heat sensitive components right above the inverter.

View of the mounting base

Front view

Side view

Frame Size	A	B	C	D	H	L	P	Weight	Mounting Bolt	Recommended Torque
	mm (in)	mm (in)	mm (in)	mm (in)	mm (in)	mm (in)	mm (in)	kg (lb)		N.m (lbf.in)
A	50.0 (1.97)	175.0 (6.89)	11.9 (0.47)	7.2 (0.28)	189.0 (7.44)	75.0 (2.95)	150.0 (5.91)	0.8 (1.76) ⁽¹⁾	M4	2 (17.7)
B	75.0 (2.95)	185.0 (7.30)	11.8 (0.46)	7.3 (0.29)	199.0 (7.83)	100.0 (3.94)	160.0 (6.30)	1.2 (2.65) ⁽¹⁾	M4	2 (17.7)
C	100.0 (3.94)	195.0 (7.70)	16.7 (0.66)	5.8 (0.23)	210.0 (8.27)	135.0 (5.31)	165.0 (6.50)	2 (4.4)	M5	3 (26.5)
D	125.0 (4.92)	290.0 (11.41)	27.5 (1.08)	10.2 (0.40)	306.6 (12.07)	180.0 (7.08)	166.5 (6.55)	4.3 (0.16)	M6	4.5 (39.82)
E	150.0 (5.90)	330.0 (12.99)	34.0 (1.34)	10.6 (0.42)	350.0 (13.78)	220.0 (8.66)	191.5 (7.54)	10 (22.05)	M6	4.5 (39.82)
F	200.0 (7.87)	525.0 (20.67)	42.5 (1.67)	15.0 (0.59)	550.0 (21.65)	300.0 (11.81)	254.0 (10.0)	26 (57.3)	M8	19 (168.16)
G	200.0 (7.87)	650.0 (25.59)	57.0 (2.24)	15.0 (0.59)	675.0 (26.57)	335.3 (13.2)	314.0 (12.36)	52 (114.64)	M8	20 (177)
H	125 (4.92)	1000 (39.37)	43 (1.69)	27 (1.06)	1074.3 (42.30)	370 (14.57)	360.1 (14.18)	78 (172)	M10	35 (309.78)
I	150 (5.91)	1200 (47.24)	48 (1.89)	27 (1.06)	1233.7 (48.57)	430 (16.93)	360.1 (14.18)	105 (231.5)	M10	35 (309.78)

Dimension tolerance: ±1.0 mm (±0.039 in).

(1) This value refers to the heaviest weight of the frame size.

(2) In the frame Frame size H there are 3 holes, therefore the total width between the holes is 250 mm (9.84 in).

(3) In frame size I there are 3 holes, therefore the total width between the holes is 300 mm (11.81 in).

Figure 8.1: Inverter dimensions for mechanical installation

(a) Surface mounting

(b) DIN rail mounting (Only Sizes A, B, C)

(c) Flange mounting - standard inverter

(d) Minimum ventilation free spaces

Frame Size	a3	b3	c3	d3	e3	A	B	C	D	Screw Torque ⁽¹⁾
	mm (in)	mm (in)	M	mm (in)	mm (in)	mm (in)	mm (in)	mm (in)	mm (in)	N.m (lbf.in)
A	-	-	-	-	-	15.0 (0.59)	40.0 (1.57)	30.0 (1.18)	10.0 (0.39)	-
B	-	-	-	-	-	35.0 (1.38)	50.0 (1.97)	40.0 (1.57)	15.0 (0.59)	-
C	-	-	-	-	-	40.0 (1.57)	50.0 (1.97)	50.0 (1.97)	30.0 (1.18)	-
D	-	-	-	-	-	40.0 (1.57)	50.0 (1.97)	50.0 (1.97)	40.0 (1.57)	-
E	-	-	-	-	-	110.0 (4.33)	130.0 (5.11)	50.0 (1.97)	40.0 (1.57)	-
F	275.0 (10.83)	517.0 (20.35)	M8	288.0 (11.34)	488.0 (19.21)	110.0 (4.33)	130.0 (5.11)	10.0 (0.39)	30.0 (1.18)	20.0 (177)
G	275.0 (10.83)	635.0 (25.0)	M8	314.0 (12.36)	617.0 (24.29)	150.0 (5.91)	250.0 (9.84)	20.0 (0.79)	80.0 (3.15)	20.0 (177)
H	270.0 (10.63)	994.0 (39.14)	M10	331.0 (13.03)	957.0 (37.68)	150 (5.9)	250 (9.84)	20 (0.79)	50 (1.18)	35 (309.78)
I	350 (13.78)	1183.6 (46.58)	M10	392.0 (15.43)	1147.6 (45.18)	150 (5.9)	250 (9.84)	20 (0.79)	50 (1.18)	35 (309.78)

Dimension tolerance: ±1.0 mm (±0.039 in).

(1) Recommended torque for fixing the inverter (valid for c3).

Figure 8.2: (a) to (d) Mechanical installation data (surface mounting, flange mounting and minimum ventilation free spaces)

ATTENTION!
When installing two or more inverters vertically, respect the minimum clearance A + B (as per Figure 3) and provide an air deflecting plate so that the heat rising up from the bottom inverter does not affect the top inverter.
Provide independent conduits for the physical separation of signal, control, and power cables (refer to the Chapter 9 ELECTRICAL INSTALLATION).

9 ELECTRICAL INSTALLATION

DANGER!
The following information is merely a guide for proper installation. Comply with applicable local regulations for electrical installations.
Make sure the power supply is disconnected before starting the installation.
The CFW503 must not be used as an emergency stop device. Provide other devices for that purpose.

ATTENTION!
Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with applicable local codes.

9.1 IDENTIFICATION OF THE POWER TERMINALS AND GROUNDING POINTS

The power terminals can be of different sizes and configurations, depending on the model of the inverter, according to Table 9.1. The maximum torque of the power terminals and grounding points must be checked in Table 9.1.

Table 9.1: Power terminals, grounding points and recommended tightening torque

Frame Size	Power Supply	Recommended Torque			
		Grounding Points		Power Terminals	
		N.m	Lbf.in	N.m	Lbf.in
A	380...480 V	0.5	4.43	0.5	4.43
B				0.5	4.43
C				1.8	15.93
D				1.76	15.58
E				3.05	27
F				5.5	48.68
G				M5: 3.5 M8: 10	M5: 31.0 M8: 88.5
H				M5: 3.5 M8: 10	M5: 31.10 M8: 88.5
I				M5: 3.5 M8: 10	M5: 31.10 M8: 88.5
				M10: 30	M10: 265.5

Description of the power terminals:

L1, L2 and L3 (R, S, T): AC power supply.
U, V, W: connection for the motor.
-UD: negative pole of the voltage of the DC Link.
+UD: positive pole of the voltage of the DC Link.
BR: connection of the brake resistor.
DCR: connection to the external DC Link inductor (optional). Only available for models 32 A, 37.1 A, 45 A, 58.5 A, 142 A, 180 A, 211 A, 315 A, 370 A, 480 A, 520 A and 600 A.

9.2 POWER AND GROUNDING WIRING, CIRCUIT BREAKERS AND FUSES

ATTENTION!

- Use proper cable lugs for the power and grounding connection cables. Refer to Table 14.1 for recommended wiring, circuit breakers and fuses.
- Keep sensitive equipment and wiring at a minimum distance of 0.25 m from the inverter and from the cables connecting the inverter to the motor.
- It is not recommended the use of mini circuit breakers (MDU), because of the actuation level of the magnet.



ATTENTION!
Residual Current Device (RCD):


- When installing an RCD to guard against electrical shock, only devices with a trip current of 300 mA should be used on the supply side of the inverter.
- Depending on the installation (motor cable length, cable type, multimotor configuration, etc.), the RCD protection may be activated. Contact the RCD manufacturer for selecting the most appropriate device to be used with inverters.



NOTE!

- The wire gauges listed in Table 14.1 are orientative values. Installation conditions and the maximum permitted voltage drop must be considered for the proper wiring sizing.

9.3 POWER CONNECTIONS



9.3.1 Input Connections



DANGER!
Provide a disconnect device for the inverter power supply. This device must cut off the power supply whenever necessary (during maintenance for instance).



ATTENTION!
The power supply that feeds the inverter must have a grounded neutral. In case of IT networks, follow the instructions described in the user's manual, available for download on the website: www.weg.net.



NOTE!
The input power supply voltage must be compatible with the inverter rated voltage. Power factor correction capacitors are not needed at the inverter input (L1, L2, L3 or R, S, T) and must not be installed at the output (U, V, W).

Power supply capacity

Suitable for use in circuits capable of delivering not more than 30,000 Arms symmetrical 480 V, when protected by fuses as specified in Table 5.

9.3.2 Dynamic Braking



NOTE!
The dynamic braking is available from frame size B for the CFW503. For installation information, refer to Item 3.2.3.4 Dynamic Braking of the user's manual, available for download on the website: www.weg.net.

9.3.3 Output Connections



ATTENTION!
The inverter has an electronic motor overload protection that must be adjusted according to the driven motor. When several motors are connected to the same inverter, install individual overload relays for each motor.
The motor overload protection available in the CFW503 is in accordance with the UL508C standard. Note the following information:
1. Trip current equal to 1.2 times the motor rated current (P0401).
2. When parameters P0156, P0157 and P0158 (Overload current at 100 %, 50 % and 5 % of the rated speed, respectively) are manually set, the maximum value to meet the condition 1 is 1.1 x P0401.



ATTENTION!
If a disconnect switch or a contactor is installed at the power supply between the inverter and the motor, never operate it with the motor turning or with voltage at the inverter output.

The characteristics of the cable used to connect the motor to the inverter, as well as its interconnection and routing, are extremely important to avoid electromagnetic interference in other equipment and not to affect the life cycle of windings and bearings of the controlled motors.

Keep motor cables away from other cables (signal cables, sensor cables, control cables, etc.), according to Item 9.3.6 Cable Separation Distance.

Connect a fourth cable between the motor ground and the inverter ground.

9.3.4 Grounding Connections



DANGER!

- The inverter must be connected to a protection grounding (PE).
- Use grounding wiring with a gauge at least equal to that indicated in Table 14.1.
- The maximum tightening torque of the grounding connections is of 1.7 N.m (15 lbf.in).
- Connect the grounding points of the inverter to a specific grounding rod, or specific grounding point or to the general grounding point (resistance ≤ 10 Ω).
- The neuter conductor that powers up the inverter must be solidly grounded; however, this conductor must not be used to ground the inverter.
- Do not share the grounding wiring with other equipment that operate with high currents (e.g. high power motors, soldering machines, etc.).

9.3.5 Control Connections

The control connections (analog input/output, digital input/output and interface RS485) must be performed according to the specification of the connector of the plug-in module connected to the CFW503. Refer to the guide of the plug-in module in the package of the product. The typical functions and connections for the CFW500-IOS standard plug-in module are shown in Figure 9.2.




Figure 9.2: Signals of the connector of the CFW500-IOS plug-in module

For the correct connection of the control, use:

1. Gauge of the cables: 0.5 mm² (20 AWG) to 1.5 mm² (14 AWG).
2. Maximum torque: 0.5 N.m (4.50 lbf.in).
3. Wiring of the plug-in module connector with shielded cable and separated from the other wiring (power, command in 110 V / 220 Vac, etc), according to Item 9.3.6 Cable Separation Distance.
4. Relays, contactors, solenoids or coils of electromechanical brake installed close to the inverters may occasionally generate interference in the control circuitry. To eliminate this effect, RC suppressors (with AC power supply) or freewheel diodes (with DC power supply) must be connected in parallel to the coils of these devices.
5. When using the external HMI, the cable that connects to the inverter must be separated from the other cables in the installation, keeping a minimum distance of 10 cm.
6. When using analog reference (AI1) and the frequency oscillates (problem of electromagnetic interference), interconnect the GND of the connector of the plug-in module to the inverter grounding connection.

9.3.6 Cable Separation Distance

Table 9.2: Cable separation distance


Inverter Output Rated Current	Length of the Cable(s)	Minimum Separation Distance
≤ 24 A	≤ 100 m (330 ft)	≥ 10 cm (3.94 in)
	> 100 m (330 ft)	≥ 25 cm (9.84 in)
≥ 28 A	≤ 30 m (100 ft)	≥ 10 cm (3.94 in)
	> 30 m (100 ft)	≥ 25 cm (9.84 in)

10 PREPARATION AND POWERING UP




DANGER!
Always disconnect the general power supply before making any connection.

1. Check if the power, grounding and control connections are correct and firm.
2. Remove all materials left from the inside of the inverter or drive.
3. Check if the motor connections and if the motor current and voltage match the inverter.
4. Mechanically uncouple the motor from the load. If the motor cannot be uncoupled, be sure that the turning in any direction (clockwise or counterclockwise) will not cause damages to the machine or risk of accidents.
5. Close the covers of the inverters or drive.
6. Measure the voltage of the input power supply and check if it is within the permitted range, as presented in Chapter
7. Power up the input: close the disconnecting switch.
8. Check the success of the powering up:



10.1 STARTUP

10.1.1 V/f Control Type (P0202 = 0)

Step	Indication on the Display/Action	Step	Indication on the Display/Action
1	 ■ Monitoring mode ■ Press the key ENTER/MENU to enter 1st level of programming mode	2	 ■ The PARAM group is selected, press the keys  or  until selecting the STARTUP group
3	 ■ When the STARTUP group is selected ■ Press the key ENTER/MENU	4	 ■ The parameter "P0317 – Oriented Start-up" is then selected, press the ENTER/MENU to get into the parameter content
5	 ■ Change the parameter P0317 to "1 - Yes", by using the  key	6	 ■ If necessary, press ENTER/MENU to modify the content of "P0202 - Control Type" for P0202 = 0 (V/f)
7	 ■ When the desired value is reached, press ENTER/MENU to save the modification ■ Press the key  for the next parameter	8	 ■ If necessary, modify the content of "P0401 - Motor Rated Current" ■ Press the key  for the next parameter
9	 ■ If necessary, modify the content of "P0402 - Motor Rated Speed" ■ Press the key  for the next parameter	10	 ■ If necessary, modify the content of "P0403 - Motor Rated Frequency" ■ Press the key  for the next parameter
11	 ■ To end the Start-up routine, press the key BACK/ESC ■ To return to the monitoring mode, press the key BACK/ESC again		

11 TECHNICAL SPECIFICATIONS

11.1 POWER DATA

Power Supply:

- Voltage Tolerance: -15 % to +10 % of nominal voltage.
- Frequency: 50/60 Hz (48 Hz to 62 Hz).
- Phase imbalance: ≤ 3 % of the rated phase-to-phase input voltage.
- Overvoltage according to Category III (IEC/EN 61010).
- Transient voltage according to Category III.
- Maximum of 10 connections (power up cycles - ON/OFF) per hour (1 every 6 minutes).
- Typical efficiency: ≥ 97 %.

12 CONSIDERED STANDARDS

Table 12.1: Considered standards

Safety standards	■ IEC/EN 61800-5-1 - safety requirements electrical, thermal and energy. ■ EN 50178 - electronic equipment for use in power installations. ■ IEC/EN 60204-1 - safety of machinery. Electrical equipment of machines. Part 1: general requirements. ■ Note: for the machine to comply with this standard, the manufacturer of the machine is responsible for installing an emergency stop device and equipment to disconnect the input power supply. ■ IEC/EN 60146 (IEC 146) - semiconductor converters. ■ IEC/EN 61800-2 - adjustable speed electrical power drive systems - part 2: general requirements - rating specifications for low voltage adjustable frequency AC power drive systems.
Electromagnetic compatibility (EMC) standards	■ IEC/EN 61800-3 - adjustable speed electrical power drive systems - part 3: EMC product standard including specific test methods. ■ CISPR 11 - industrial, scientific and medical (ISM) radio-frequency equipment - electromagnetic disturbance characteristics - limits and methods of measurement. ■ IEC/EN 61000-4-2 - electromagnetic compatibility (EMC) - part 4: testing and measurement techniques - section 2: electrostatic discharge immunity test. ■ IEC/EN 61000-4-3 - electromagnetic compatibility (EMC) - part 4: testing and measurement techniques - section 3: radiated, radio-frequency, electromagnetic field immunity test. ■ IEC/EN 61000-4-4 - electromagnetic compatibility (EMC) - part 4: testing and measurement techniques - section 4: electrical fast transient/burst immunity test. ■ IEC/EN 61000-4-5 - electromagnetic compatibility (EMC) - part 4: testing and measurement techniques - section 5: surge immunity test. ■ IEC/EN 61000-4-6 - electromagnetic compatibility (EMC) - part 4: testing and measurement techniques - section 6: immunity to conducted disturbances, induced by radio-frequency fields.
Mechanical construction standards	■ EN 60529 - degrees of protection provided by enclosures (IP code). ■ IEC/EN 60721-3-3 - classification of environmental conditions - part 3: classification of groups of environmental parameters and their severities - section 3: stationary use at weather protected locations level 3m4.

13 CERTIFICATIONS

Certifications (*)	Notes
CE	

(*) For updated information on certifications, please contact WEG.

14 LIST OF MODELS CFW503 SERIES

Table 14.1: List of models of CFW503 series, main electrical specifications - frame sizes A to I

Inverter	Power Supply Rated Voltage	Frame Size	Output Rated Current		Maximum Motor		Recommended Fuse			Circuit Breaker		Power Wire Size	Grounding Wire Size	Dynamic Braking			
														Maximum Current	Recommended Resistor	Braking rms Current	Power Wire Size for DC+ and BR Terminals
			[Vrms]	ND [Arms]	HD [Arms]	ND [HP/kW]	HD [HP/kW]	I²t [A²s]	Current [A]	Recommended WEG aR Fuse	[A]	WEG	mm² (AWG)	mm² (AWG)	(Imax) [A]	[Ω]	[A]
CFW503A01P0T4	380...480 V	A	1.0	1.0	0.25/0.18	0.25/0.18	450	20	FNH00-20K-A	1.6	MPW18i-3-D016 ^(a)	1.5 (16)	2.5 (14)	Dynamic braking not available			
1.6			1.6	0.5/0.37	0.5/0.37	450	20	FNH00-20K-A	2.5	MPW18i-3-D025 ^(a)	1.5 (16)	2.5 (14)					
2.6			2.6	1.5/1.1	1.5/1.1	450	20	FNH00-20K-A	4	MPW18i-3-U004 ^(a)	1.5 (16)	2.5 (14)					
6.1			5.0	3/2.2	2/1.5	450	20	FNH00-20K-A	10	MPW18i-3-U010 ^(a)	1.5 (16)	2.5 (14)					
8.2			7	5/3.7	3/2.2	1000	25	FNH00-25K-A	16	MPW18i-3-U016 ^(a)	2.5 (14)	2.5 (14)					
CFW503B02P6T4			B	2.6	2.6	1.5/1.1	1.5/1.1	450	20	FNH00-20K-A	4	MPW18i-3-U004 ^(a)	1.5 (16)	2.5 (14)	6	127	4.5
4.3		4.3		2/1.5	2/1.5	450	20	FNH00-20K-A	6.3	MPW18i-3-D063 ^(a)	1.5 (16)	2.5 (14)	6	127	4.5	1.5 (16)	
10		7		6/4.5	3/2.2	1000	25	FNH00-25K-A	16	MPW18i-3-U016 ^(a)	2.5 (14)	2.5 (14)	8	100	5.7	2.5 (14)	
CFW503B14P0T4		C	14	10	7.5/5.6	6/4.5	1000	35	FNH00-35K-A	20	MPW40i-3-U020 ^(a)	4.0 (12)	4.0 (12)	16	47	11.5	2.5 (14)
16			14	10/7.5	7.5/5.6	1000	35	FNH00-35K-A	25	MPW40i-3-U025 ^(a)	4.0 (12)	4.0 (12)	24	33	14	6 (10)	
18			16	10/7.5	10/7.5	1800	35	FNH00-35K-A	32	MPW40i-3-U032 ^(a)	6.0 (10)	6.0 (10)	24	33	14	6 (10)	
CFW503D32P0T4		D	32	25	20/15	15/11	1800	60	FNH00-63K-A	50	MPW80i-3-U050 ^(a)	10 (8)	10 (8)	34	22	21	10 (8)
37.1			32	25/18.5	20/15	2100	80	FNH00-80K-A	65	MPW80i-3-U065 ^(a)	10 (8)	10 (8)	48	18	27	10 (8)	
CFW503E45P0T4			E	45	39	30/22	25/18.5	13000	100	FNH00-100K-A	65	MPW80i-3-U080 ^(a)	10 (8)	10 (8)	78	8.6	39
CFW503E58P5T4		58.5		49	40/30	30/22	13000	125	FNH00-125K-A	90	MPW100-3-U100	16 (4)	16 (4)	78	8.6	39	10 (8)
CFW503F77P0T4		77		64	50/37	40/30	3050	100	FNH00-100K-A	100	DWB160N-100-3DX	25 (3)	16 (4)	66.7	12	43	10 (6)
CFW503F88P0T4		F	88	73	60/45	50/37	3050	125	FNH00-125K-A	100	DWB160N-100-3DX	35 (2)	16 (4)	66.7	12	43	10 (6)
CFW503F0105T4			105	88	75/55	60/45	5200	160 / 125 ⁽¹⁾	FNH1-160K-A / FNH1-125K-A ^{(b) (2)}	125	DWB160N-125-3DF	50 / 35 (1 / 2) ⁽¹⁾	16 (4)	129	6.2	63	25 (4)
CFW503G0142T4			142	115	100/75	75/55	135200	200	FNH00-200K-A	175	DWB250N-200-3DF	70 (2/0) / 50 (1/0) ⁽¹⁾	35 (2)	267	3	142	2x25 (2x4)
CFW503G0180T4		G	180	142	150/110	100/75	135200	315	FNH1-315K-A	225	DWB250N-250-3DF	2x35 (2x2) / 2x25 (2x4) ⁽¹⁾	50 (1)	267	3	180	2x35 (2x2)
CFW503G0211T4			211	190	175/132	150/110	135200	350	FNH1-350K-A	250	DWB250N-250-3DF	2x50 (2x1) / 2x35 (2x2) ⁽¹⁾	70 (2/0)	364	2.2	191.7	2x50 (2x1/0)
CFW503H0315T4		H	315	211	250	200	450000	800	FNH3-800K-A	800	UBW800H-FTU800-3A	2x85	95	Dynamic braking not available			
CFW503H0370T4			370	315	300	250	450000	800	FNH3-800K-A	800	UBW800H-FTU800-3A	2x120	120				
CFW503I0480T4		I	480	415	450	350	1080450	450	FNH3-450K-A ⁽⁴⁾	1200	UBW1200H-ELS1200-3A	2x185	2x50				
CFW503I0520T4			520	480	500/350	400	1080450	630	FNH3-630K-A ⁽⁴⁾	1200	UBW1200H-ELS1200-3A	3x95	2x50				
CFW503I0600T4	600		515	500/350	450	1080450	630	FNH3-630K-A ⁽⁴⁾	1200	UBW1200H-ELS1200-3A	3x150	2x70					


 **警告!**

- 对于电源和接地连接线，要使用合适的电缆接头。有关推荐的布线、断路器和保险丝，请参阅表 5。
- 敏感设备和布线与变压器和连接变频器到电动机的电缆之间至少要保持 0.25 米的最小距离。
- 由于磁铁的动作水平，不建议使用小型断路器（MDU）。

警告!
电流式漏电断路器 (RCD)：
■ 安装 RCD 以防止触电时，只有具备 300mA 跳闸电流的装置能在变频器的供电侧使用。
■ 根据安装（电机电缆长度、电缆类型、多电机配置等），RCD 可供激活。
联系 RCD 制造商，选择最适合用于变频器的设备。

注意!
■ 表 5 中列出的线规引导值。安装条件和最大允许压降必须考虑正确的布线线号。

9.3 电源连接



9.3.1 输入连接

危险!
提供变频器电源断开设备。必要时，设备必须切断电源 (例如，在维护期间)。

警告!
逆变器的供电电源必须正确接地。对于IT网络，请遵循《用户手册》(下载网址: www.weg.net) 中的说明。

注意!
■ 输入电源电压必须与变频器的额定电压兼容。
■ 在变频器输入端，不需要功率因数校正电容器 (L1、L2、L3 或 R、S、T)，且不能在输出端 (U、V、W) 安装。

电源容量

■ 如表 5 所示，受保险丝保护时，适用于提供不超过 30,000 A 对称 480 V 电流的电路使用。

9.3.2 直流环节电感/电源抗

注意!
机座号为B的 CFW503 逆变器可提供动态制动。有关安装信息，请参阅《用户手册》(下载网址: www.weg.net) 第 3.2.3.4 章节“动态制动”。

9.3.3 输出连接

警告!
此变频器具有一个电子式电机过载保护装置。该保护装置可根据其所驱动的电机进行调节。如果有多个电机同一台变频器连接 则需为每一台电机安装独立的过载继电器。
CFW503 可用电机过载保护是根据 UL508C 标准执行的。请注意以下信息：
1. 跳闸电流等于电机额定电流 (P0401) 的 1.2 倍。
2. 手动设置 P0156、P0157 和 P0158 (分别为额定转速 100 %、50 % 和 5%的过载电流) 参数时，满足条件 1 的最大值是 1.1×P0401。

警告!
如果执行电源断开动作的开关或接触器安装在变频器和电机之间，禁止在电机运行或变频器有输 电压时进行操作。

电缆（用于将电动机连接至变频器）的特性，以及它的互连和布线，在避免在其它设备的电磁干扰和不影响受控电机绕组和轴承寿命周期方面是极其重要的。

根据电缆间隔距离 9.3.6，将电机电缆与其它电缆（信号电缆、传感器电缆、控制电缆等）保持间隔。

使用第四根电缆连接电机接地和变频器接地。


9.3.4 接地连接

危险!
变频器必须连接到一个保护接地 (PE)。
■ 接地线的选择使用规格需至少等同于表5所示数据。
■ 接地连接的最大拧紧扭矩为 1.7 牛·米 (15 磅力·英寸)。
■ 将变频器的接地点连接到特定的接地棒，或特定的接地点，或一般的接地点（电阻≤10 Ω）。
■ 为变频器上电的中性导体必须直接接地；但是，该导体不能用于接地变频器。
■ 不要与其他大电流运行的设备共用接地线（例如：高功率电机、焊接机等）。

9.3.5 控制连接

控制连接（模拟输入/输出、数字输入/输出和 RS485 接口）必须根据连接至 CFW503 的插件模块连接器的规格来执行。

参考产品包中插件模块的指南。CFW500-IOS 标准插件模块的特色功能和连接如图 5 所示。



Quick Parameter Reference

CFW503 Frequency Inverter



18256889

Document: 10012664198/01



NOTE!
For further information, please, refer to the programming manual available for download at www.weg.net.

1 USE OF THE HMI TO OPERATE THE INVERTER

- When in the setting mode, level 1: press this key to return to the monitoring mode.

- When in the setting mode, level 2: press this key to return to level 1 of the setting mode.

- When in the setting mode, level 3: press this key to cancel the new value (new value is not saved) and return to level 2 of the setting mode.

- When in the monitoring mode: press this key to increase the speed.

- When in the setting mode, level 1: press this key to go to the previous group.

- When in the setting mode, level 2: press this key to go to the next parameter.

- When in the setting mode, level 3: press this key to increase the content of the parameter.

Press this key to define the motor rotation direction.

Active when:
P0223 = 2 or 3 in LOC and/or P0226 = 2 or 3 in REM.

Press this key to commute between LOCAL and REMOTE mode.

Active when:
P0220 = 2 or 3.

- When in the monitoring mode: press this key to enter the setting mode.

- When in the setting mode, level 1: press this key to select the desired parameter group – it shows the parameter group selected.

- When in the setting mode, level 2: press this key to show the parameter – it shows the content of the parameter in order to change the content.

- When in the setting mode, level 3: press this key to save the new content of the parameter – it returns to level 2 of the setting mode.

- When in the monitoring mode: press this key to decrease the speed.

- When in the setting mode, level 1: press this key to go to the next group.

- When in the setting mode, level 2: press this key to go to the previous parameter.

- When in the setting mode, level 3: press this key to decrease the content of the parameter.

Press this key to accelerate the motor within the time determined by the acceleration ramp.

Active when:
P0224 = 0 in LOC or P0227 = 0 in REM.

Press this key to decelerate the motor within the time determined by the deceleration ramp.

Active when:
P0224 = 0 in LOC or P0227 = 0 in REM.

Press this key to accelerate the motor up to the speed set in P0122 within the time determined by the acceleration ramp. The motor speed is kept while the key is pressed. When the key is released, the motor decelerates within the time determined by the deceleration ramp, until it stops. This function is active when all the conditions below are met:

1. Turn/Stop = Stop.
2. Enable general = Active.
3. P0225 = 1 in LOC and/or P0228 = 1 in REM.

1.1 INDICATIONS ON THE HMI DISPLAY

Menu (to select the parameter groups) – only one parameter group is shown at a time

Inverter status

Secondary indication

Measurement unit (it refers to the value of the main indication)

Main display

Bar graph

1.2 OPERATING MODES OF THE HMI

Monitoring Mode

- It is the initial status of the HMI after the powering, up and of the initialization screen , with default values
- The field Menu is not active in this mode
- The main display, secondary display and bar graph indicate the values of three parameters predefined by P0205, P0206 and P0207
- From the monitoring mode, when you press the key ENTER/MENU you commute to the setting mode

Setting Mode

- Level 1:
 - This is the first level of the setting mode. It is possible to choose the parameter group using the keys and .
 - The main display, secondary display, bar graph and measurement units are not shown
 - Press the key ENTER/MENU to go to level 2 of the setting mode - parameter selection
 - Press the key BACK/ESC to return to the monitoring mode
- Level 2:
 - The number of the parameter is shown on the main display and its content on the secondary display
 - Use the keys and to find the desired parameter
 - Press the key ENTER/MENU to go to level 3 of the setting mode – modification of the parameter content
 - Press the key BACK/ESC to return to level 1 of the setting mode
- Level 3:
 - The content of the parameter is shown on the main display and the number of the parameter is shown on the secondary display
 - Use the keys and to configure the new value for the selected parameter
 - Press the key ENTER/MENU to confirm the modification (save the new value) or BACK/ESC to cancel the modification (not save the new value). In both cases, the HMI returns to level 2 of the setting mode

2 MAIN PAREMETERS

NOTE!
ro = read only parameter.
V/f = parameter available in V/f mode.
cfg = configuration parameter, value can only be changed with the motor stopped.
VVW = parameter available in VVW mode.
VVW PM = parameter available in VVW PM mode.
Vector = parameter available in vector mode.
Sless = parameter available only in sensorless mode.
Enc = parameter available only in vector mode with encoder.

Param.	Description	Adjustable Range	Factory Setting	Propr.	Groups
P0000	Access to Parameters	0 to 9999	0		
P0001	Speed Reference	0 to 65535		ro	READ
P0002	Output Speed (Motor)	0 to 65535		ro	READ
P0003	Motor Current	0.0 to 200.0 A		ro	READ
P0004	DC Link Voltage (Ud)	0 to 2000 V		ro	READ
P0005	Output Frequency (Motor)	0.0 to 500.0 Hz		ro	READ
P0006	Inverter Status	0 = Ready 1 = Run 2 = Undervoltage 3 = Fault 4 = Self-Tuning 5 = Configuration 6 = DC-Braking 7 = STO 8 = Fire Mode 9 = Reserved 10 = Sleep Mode		ro	READ
P0007	Output Voltage	0 to 2000 V		ro	READ
P0010	Output Power	0.0 to 6553.5 kW		ro	READ
P0011	Power Factor	-1.00 to 1.00		ro	READ
P0012	DI8 to DI1 Status	Bit 0 = DI1 Bit 1 = DI2 Bit 2 = DI3 Bit 3 = DI4 Bit 4 = DI5 Bit 5 = DI6 Bit 6 = DI7 Bit 7 = DI8		ro	READ, I/O
P0013	DO5 to DO1 Status	Bit 0 = DO1 Bit 1 = DO2 Bit 2 = DO3 Bit 3 = DO4 Bit 4 = DO5		ro	READ, I/O
P0022	FI Hz Value	0 to 20000 Hz		ro	READ, I/O
P0023	Main SW Version	0.00 to 655.35		ro	READ
P0030	Heatsink Temperature	-20 to 150 °C		ro	READ
P0037	Motor Overload lxt	0 to 100 %		ro	READ
P0047	CONF Status	0 to 999		ro	READ
P0048	Present Alarm	0 to 999		ro	READ
P0049	Present Fault	0 to 999		ro	READ
P0050	Last Fault	0 to 999		ro	READ
P0100	Acceleration Time	0.1 to 999.0 s	10.0 s		BASIC
P0101	Deceleration Time	0.1 to 999.0 s	10.0 s		BASIC
P0120	Speed Ref. Backup	0 = Inactive 1 = Active 2 = Backup por P0121	1		
P0121	Keypad Reference	0.0 to 500.0 Hz	3.0 Hz		
P0133	Minimum Speed	0.0 to 500.0 Hz	3.0 Hz		BASIC
P0134	Maximum Speed	0.0 to 500.0 Hz	66.0 (55.0) Hz		BASIC
P0135	Max. Output Current	0.0 to 400.0 A	1.5 x Inom	V/f, VVW, VVW PM	BASIC, MOTOR
P0136	Manual Torque Boost	0.0 to 30.0 %	According to inverter model	V/f, VVW PM	BASIC, MOTOR
P0156	Overload Current 100 %	0.0 to 400.0 A	1.1 x Inom		
P0157	Overload Current 50 %	0.0 to 400.0 A	1.0 x Inom		
P0158	Overload Current 5 %	0.0 to 400.0 A	0.8 x Inom		
P0202	Type of Control	0 = V/f 1 and 2 = Not Used 3 = Sensorless 4 = Encoder 5 = VVW 6 and 7 = Not Used 8 = VVW PM	0	cfg	STARTUP
P0204	Load/Save Parameters	0 and 1 = Not Used 2 = Reset P0045 3 = Reset P0043 4 = Reset P0044 5 = Load WEG 60 Hz 6 = Load WEG 50 Hz 7 = Load User 1 8 = Load User 2 9 = Save User 1 10 = Save User 2 11 = Load Default SoftPLC 12 to 15 = Reserved	0	cfg	
P0220	LOC/REM Selection Src	0 = Always Local 1 = Always Remote 2 = HMI Key (LOC) 3 = HMI Key (REM) 4 = DIx 5 = Serial/USB (LOC) 6 = Serial/USB (REM) 7 and 8 = Not Used 9 = CO/DN/PB/Eth (LOC) 10 = CO/DN/PB/Eth (REM) 11 = SoftPLC	2	cfg	I/O
P0221	LOC Reference Sel.	0 = HMI Keys 1 = AI1 2 = AI2 3 = AI3 4 = FI 5 = AI1 + AI2 > 0 6 = AI1 + AI2 7 = E.P. 8 = Multispeed 9 = Serial/USB 10 = Not Used 11 = CO/DN/PB/Eth 12 = SoftPLC 13 = Not Used 14 = AI1 > 0 15 = AI2 > 0 16 = AI3 > 0 17 = FI > 0	0	cfg	I/O
P0222	REM Reference Sel.	See options in P0221	1	cfg	I/O
P0223	LOC FWD/REV Selection	0 = Clockwise 1 = Counterclockwise 2 = HMI Key (H) 3 = HMI Keys (AH) 4 = DIx 5 = Serial/USB (H) 6 = Serial/USB (AH) 7 and 8 = Not Used 9 = CO/DN/PB/Eth (H) 10 = CO/DN/PB/Eth (AH) 11 = Not Used 12 = SoftPLC	2	cfg	I/O
P0224	LOC Run/Stop Selection	0 = HMI Keys 1 = DIx 2 = Serial/USB 3 = Not Used 4 = CO/DN/PB/Eth 5 = SoftPLC	0	cfg	I/O
P0225	LOC JOG Selection	0 = Disable 1 = HMI Keys 2 = DIx 3 = Serial/USB 4 = Not Used 5 = CO/DN/PB/Eth 6 = SoftPLC	1	cfg	I/O
P0226	REM Rotation Selection	See options in P0223	4	cfg	I/O

Param.	Description	Adjustable Range	Factory Setting	Propr.	Groups
P0227	REM Run/Stop Selection	0 = Tecla HMI 1 = DIx 2 = Serial/USB 3 = Not Used 4 = CO/DN/PB/Eth 5 = SoftPLC	1	cfg	I/O
P0228	REM JOG Selection	See options in P0225	2	cfg	I/O
P0263	DI1 Function	0 = Not Used 1 = Run/Stop 2 = General Enable 3 = Quick Stop 4 = Forward Run 5 = Reverse Run 6 = Start 7 = Stop 8 = Clockwise 9 = LOC/REM Application 10 = JOG Application 11 = Accelerate E.P. 12 = Decelerate E.P. 13 = Multispeed 14 = 2 nd Ramp 15 to 17 = Not Used 18 = No Ext. Alarm 19 = No Ext. Fault 20 = Reset 21 = SoftPLC 22 = PID Man./Auto 23 = Not Used 24 = Disab.Flying Start 25 = DC Link Regulator 26 = Lock Prog. 27 = Load User 1 28 = Load User 2 29 = PTC 30 and 31 = Not Used 32 = 2 nd Ramp 33 = 2 nd Ramp E.P.Ac. 34 = 2 nd Ramp E.P.De 35 = 2 nd Ramp FWD Run 36 = 2 nd Ramp Rev Run 37 = Turn ON / Ac. E.P. 38 = De. E.P. / Turn OFF 39 = Function 1 Application 40 = Function 2 Application 41 = Function 3 Application 42 = Function 4 Application 43 = Function 5 Application 44 = Function 6 Application 45 = Function 7 Application 46 = Function 8 Application 47 = Auto/Man. PIDInt 48 = Auto/Man. PIDExt 49 = Bypass 50 = Fire Mode 51 = Run/Stop On-Lock 52 = FWDRun On-Lock 53 = RevRun On-Lock	1	cfg	I/O
P0264	DI2 Function	See Options in P0263	8	cfg	I/O
P0265	DI3 Function	See Options in P0263	20	cfg	I/O
P0266	DI4 Function	See Options in P0263	10	cfg	I/O
P0267	DI5 Function	See Options in P0263	0	cfg	I/O
P0268	DI6 Function	See Options in P0263	0	cfg	I/O
P0269	DI7 Function	See Options in P0263	0	cfg	I/O
P0270	DI8 Function	See Options in P0263	0	cfg	I/O
P0295	Inverter Rated Current	0.0 to 400.0 A	According to inverter model	ro	READ
P0296	Line Rated Voltage	0 = 200 - 240 V 1 = 380 V 2 = 400 - 415 V 3 = 440 - 460 V 4 = 480 V 5 = 500 - 525 V 6 = 550 - 575 V 7 = 600 V	According to inverter model	ro, cfg	READ
P0297	Switching Frequency	2500 to 15000 Hz	5000 Hz	cfg	
P0401	Motor Rated Current	0.0 to 400.0 A	1.0 x Inom	cfg	MOTOR, STARTUP
P0402	Motor Rated Speed	0 to 30000 rpm	1710 (1425) rpm	cfg	MOTOR, STARTUP
P0403	Motor Rated Frequency	0 to 500 Hz	60 (50) Hz	cfg	MOTOR, STARTUP

3 FAULTS AND ALARMS

Most common faults and alarms

Fault / Alarm	Description	Possible Causes
A0046 Motor Overload	Motor overload alarm	Settings of P0156, P0157, and P0158 are too low for the used motor Overload on the motor shaft
A0050 Power Module Overtemperature	Overtemperature alarm from the power module temperature sensor (NTC)	High ambient temperature around the inverter (> 40 °C (> 104 °F)) and high output current Blocked or defective fan Heatsink is too dirty, preventing the air flow
A0090 External Alarm	External alarm via DIx (option "No External Alarm" in P026x)	Wiring on DI1 to DI8 inputs are open or have poor contact
A0700 Communication Fault with Remote HMI	No communication with remote HMI, but there is no speed command or reference for this source	Check if the communication interface with the HMI is properly configured in parameter P0312 HMI cable disconnected
F0021 Undervoltage on the DC Link	Undervoltage fault on the intermediate circuit	Wrong voltage supply; check if the data on the inverter label comply with the power supply and parameter P0296 Supply voltage is too low, producing voltage on the DC link below the minimum value (in P0004): Ud < 360 Vdc in 380-480 Vac (P0296 = 1) Phase fault in the input Fault in the pre-charge circuit
F0022 Overvoltage on the DC Link	Overvoltage fault on the intermediate circuit	Wrong voltage supply; check if the data on the inverter label comply with the power supply and parameter P0296 Supply voltage is too high, producing voltage on the DC link above the maximum value (in P0004): Ud > 810 Vdc in 380-480 Vac (P0296 = 1) Load inertia is too high or deceleration ramp is too fast P0151, P0153 or P0185 setting is too high
F0031 Communication Fault with Plug-In Module	Main control cannot set a communication link with the Plug-In module	Plug-In module is damaged Plug-In module is not properly connected Problem in the identification of the Plug-In module; refer to P0027 for further information
F0051 IGBTs Overtemperature	Overtemperature fault measured on the temperature sensor of the power pack	High ambient temperature around the inverter (>40 °C (>104 °F)) and high output current Blocked or defective fan Heatsink is too dirty, preventing the air flow
F0070 Overcurrent/Short-Circuit	Overcurrent or short-circuit on the output, DC link or braking resistor	Short-circuit between two motor phases Short-circuit of the rheostatic braking resistor connecting cables IGBTs module in short-circuit or damaged Start with too short acceleration ramp Start with motor spinning without the flying-start function
F0072 Motor Overload	Motor overload fault (60 s in 1.5xInom)	P0156, P0157 and P0158 setting is too low in relation to the motor operating current Overload on the motor shaft
F0080 CPU Fault (Watchdog)	Fault related to the supervision algorithm of the inverter main CPU	Electric noise Inverter firmware fault

Fault / Alarm	Description	Possible Causes
F0084 Auto-Diagnosis Fault	Fault related to the automatic identification algorithm of the inverter hardware and Plug-In module	Poor contact in the connection between the main control and the power pack Hardware not compatible with the firmware version Defect on the internal circuits of the inverter
F0091 External Fault	External fault via DIx ("No External Fault" in P026x)	Wiring on DI1 to DI8 inputs are open or have poor contact
F0700 Remote HMI Communication Fault	No communication with remote HMI, but there is speed command or reference for this source	Check if the communication interface with the HMI is properly configured in parameter P0312 HMI cable disconnected

4 DEFAULT CONFIGURATION FOR SPEED REFERENCE AND COMMAND

The CFW503 is configured at the factory by setting its parameters so as to define the logical command and the speed reference in both LOCAL and REMOTE operating modes. This default setting can be restored by means of P0204 for both motors 60Hz and 50Hz (P0204 = 5 or 6).

In the LOCAL mode, the command and reference are directed to the HMI of the CFW503, allowing the commands Run/Stop, JOG and Direction of Rotation of the motor. In addition to these commands, the HMI keypad can also be used to select the LOCAL or REMOTE mode. The speed reference can be set in P0121 or by means of the and keys of the HMI in the monitoring mode.

In the REMOTE mode, the speed reference and command are directed to the product terminals; DI1 executes Run/Stop and DI2 the Direction of Rotation. The reference is executed by analog input AI1 in this mode.



快速参考引用

CFW503 变频器



18256889

文件: 10012664198/01

1 使用HMI操作变频器

- 当在设置模式时, 1级: 按下此键返回到监控模式。

- 当在设置模式时, 2级: 按下此键返回到设置模式的1级。

- 当在设置模式时, 3 级: 按下此键取消新值 (新值未保存) 并返回到设置模式的2级。

- 当在监控模式时: 按下此键加速。

- 当在设置模式时, 1级: 按下此键进入前一个组别。

- 当在设置模式时, 2级: 按下此键进入下一个参数。

- 当在设置模式时, 3级: 按下此键增加参数内容。

按下此键定义电机旋转方向。
当以下条件满足时, 启动:
P0223 = LOC 和/或P0226中的2或3 = REM 的2或3

按下此键切换本地模式和远程模式。
当以下条件满足时, 启动:
P0220 = 2或3。

按下此键, 将电机速度在加速转速决定的时间内加速至P0122中设置的速度值。按下该键时, 电机速度保持不变。放松该键时, 电机在减速转速决定的时间内减速, 直至停止。当以下所有条件都满足时, 该功能被启动。
1. 转/停止 = 停止。
2. 常规启用 = 启动。
3. P0225 = LOC和/或P0228中的1= REM的1。

- 当在监控模式时: 按下此键进入设置模式。

- 当在设置模式时, 1级: 按下此键选择想要的参数组别-它会显示已选择的组别。

- 当在设置模式时, 2级: 按下此键显示参数-它显示参数内容, 以改变内容。

- 当在设置模式时, 3级: 按下此键保存新参数内容-它返回到设置模式的2级。

- 当在监控模式时: 按下此键减速。

- 当在设置模式时, 1级: 按下此键进入下一个组别。

- 当在设置模式时, 2级: 按下此键进入前一个参数。

- 当在设置模式时, 3级: 按下此键减少参数内容。

按下此键, 将电机速度在加速转速决定的时间内加速至P0122中设置的速度值。按下该键时, 电机速度保持不变。放松该键时, 电机在减速转速决定的时间内减速, 直至停止。当以下所有条件都满足时, 该功能被启动。
1. 转/停止 = 停止。
2. 常规启用 = 启动。
3. P0225 = LOC和/或P0228中的1= REM的1。

1.1 HMI显示屏指示

变频器状态

菜单 (选择参数组别) - 一次只显示一个参数组别

主显示屏

二级指示

测量单位 (它参考主要指示值)

柱状图

1.2 HMI操作模式

监控模式

- 接入电源、初始化屏幕后, HMI的状态为初始状态, 含故障值
- 在这种模式中, 这个字段菜单未启动
- 主显示、二次显示和柱状图表明P0205、P0206和P0207预先定义的两个参数值。
- 当你按下进入/菜单键时, 你从监控模式切换到设置模式

设置模式

■ 级:

- 这是设置模式的 1 级。可以用 和 键来选择参数组别
- 未显示主显示、二次显示、柱状图和测量单位
- 按下 进入/菜单 键, 进入设置模式的 2级 - 参数选择
- 按下 返回/退出 键, 返回到监控模式

■ 级:

- 参数数量显示在主显示中, 参数内容显示在二次显示中
- 使用 和 键, 找到所需的参数
- 按下 进入/菜单 键, 进入设置模式的 3级 - 参数内容修改
- 按下 返回/退出 键, 返回到监控模式 1级

■ 级:

- 参数内容显示在主显示中, 参数数量显示在二次显示中
- 使用 和 键, 在所选参数中设置新值
- 按下 进入/菜单 键, 确定修改 (保存新值) 或按下 返回/退出 键, 取消修改 (未保存新值)。两种情况下, HMI 返回设置模式的 2级

监视器

进入菜单

返回退出

设置 1 级

返回退出

设置 2 级

返回退出

设置 3 级

进入菜单

2 主要参数

注意!

ro = 只读参数。

V/f = V/f 模式下可用参数。

cfg = 配置参数, 数值只能在电机停止后更改。

VVW = VVW模式中的可用参数。

矢量 = 矢量模式中的可用参数。

Sless = 仅是无传感器模式中的可用参数。

Enc = 含编码器矢量模式中的可用参数。

参数	描述	可调节范围	出厂设置	归属主体	组别
P0000	参数入口	0 至 9999	0		
P0001	速度参考值	速度参考值0 至 65535		ro	读取
P0002	输出速度 (电机)	0 至 65535		ro	读取
P0003	电机电流	0.0 至 200.0 A		ro	读取
P0004	直流环节电压 (Ud)	0 至 2000 V		ro	读取
P0005	输出频率 (电机)	0.0 至 500.0 Hz		ro	读取
P0006	变频器状态	0 = 就绪 1 = 运行 2 = 低压 3 = 故障 4 = 自动调谐 5 = 配置 6 = 直流制动 7 = STO 8 = 消防模式 9 = 预留模式 10 = 睡眠模式		ro	读取
P0007	输出电压	0 至 2000 V		ro	读取
P0010	输出功率	0.0 至 6553.5 kW		ro	读取
P0011	功率系数	-1.00 至 1.00		ro	读取
P0012	D18 至 D11 状态	0 位 = D11 1 位 = D12 2 位 = D13 3 位 = D14 4 位 = D15 5 位 = D16 6 位 = D17 7 位 = D18		ro	读取, 输入/输出
P0013	D05 至 D01 状态	0 位 = D01 1 位 = D02 2 位 = D03 3 位 = D04 4 位 = D05		ro	读取, 输入/输出
P0022	FI Hz 值	0 至 20000 Hz		ro	读取, 输入/输出
P0023	主要 SW 版本	0.00 至 655.35		ro	读取
P0030	散热器温度	-20 至 150°C		ro	读取
P0037	电机过载 Ixt	0 至 100 %		ro	读取
P0047	配置状态	0 至 999		ro	读取
P0048	当前警报	0 至 999		ro	读取
P0049	当前故障	0 至 999		ro	读取
P0050	上次故障	0 至 999		ro	读取
P0100	加速时间	0.1 至 999.0秒	10.0 s		基础
P0101	减速时间	0.1 至 999.0秒	10.0 s		基础
P0120	速度参考备份	0 = 无效 1 = 有效 2 = 经 P0121 备份	1		
P0121	键盘参考	0.0 至 500.0 Hz	3.0 Hz		
P0133	最低速度	0.0 至 500.0 Hz	3.0 Hz		基础
P0134	最高速度	0.0 至 500.0 Hz	66.0 (55.0) Hz		基础
P0135	最大输出电流	0.0 至 400.0 A	1.5 x Inom	V/f, VVW, VVW PM	基础, 电机
P0136	手动转矩提升	0.0 至 30.0 %	根据变频器型号	V/f, VVW PM	基础, 电机
P0156	过电流100%	0.0 至 400.0 A	1.1 x Inom		
P0157	过电流50 %	0.0 至 400.0 A	1.0 x Inom		
P0158	过电流5 %	0.0 至 400.0 A	0.8 x Inom		
P0202	控制类型	0 = V/f 1和2 = 未使用 3 = 无传感器 4 = 编码器 5 = V VW 6和7 = 未使用 8 = V VW PM	0	cfg	启动
P0204	负载/保存参数	0 和 1 = 未使用 2 = 重置 P0045 3 = 重置 P0043 4 = 重置 P0044 5 = 负载 WEG 60 Hz 6 = 负载 WEG 50 Hz 7 = 加载用户 1 8 = 加载用户 2 9 = 保存用户 1 10 = 保存用户 2 11 = 加载默认 SoftPLC 12 至 15 = 保留	0	cfg	
P0220	LOC/REM 选择 Src	0 = 始终本地 1 = 总是远程 2 = HMI键 (本地) 3 = HMI键 (远程) 4 = DIx 5 = 串口/USB端口 (LOC) (REM) 6 = 串口/USB (REM) 7 = 未使用 8 = 未使用 9 = CO/DN/PB/Eth (LOC) 10 = CO/DN/PB/Eth (REM) 11 = SoftPLC	2	cfg	输入/输出
P0221	LOC参考选择	LOC参考选择0 = HMI 键 9 = 串口/USB 1 = AI1 2 = AI2 3 = AI3 4 = FI 5 = AI1 + AI2 > 0 6 = AI1 + AI2 7 = E.P. 8 = 多速 10 = 未使用 11 = CO/DN/PB/Eth 12 = SoftPLC	0	cfg	输入/输出
P0222	REM参考选择	见P0221中的选项	1	cfg	输入/输出
P0223	LOC FWD/REV 选择	0 = 顺时针 1 = 逆时针 2 = HMI 键 (H) 3 = HMI 键 (AH) 4 = DIx 5 = 串口/USB (H) 6 = 串口/USB (AH) 7和8 = 未使用 9 = CO/DN/PB/Eth (H) 10 = CO/DN/PB/Eth (AH) 11 = 未使用 12 = SoftPLC	2	cfg	输入/输出
P0224	LOC 运行/停止 选择	0 = HMI 键 1 = DIx 2 = 串口/USB 3 = 未使用 4 = CO/DN/PB/Eth 5 = SoftPLC	0	cfg	输入/输出
P0225	LOC JOG 选择	0 = 禁用 1 = HMI 键 2 = DIx 3 = 串口/USB 4 = 未使用 5 = CO/DN/PB/Eth 6 = SoftPLC	1	cfg	输入/输出
P0226	REM 旋转选择	见P0223中的选项	4	cfg	输入/输出
P0227	REM 运行/停止 选择	0 = Tecla HMI 1 = DIx 2 = 串口/USB 3 = 未使用 4 = CO/DN/PB/Eth 5 = SoftPLC	1	cfg	输入/输出
P0228	REM JOG 选择	见P0225中的选项	2	cfg	输入/输出

参数	描述	可调节范围	出厂设置	归属主体	组别
P0263	D11 功能	0 = 未使用 1 = 运行/停止 2 = 常规启用 3 = 快速停止 4 = 快进 5 = 快速 6 = 启动 7 = 停止 8 = 顺时针旋转方向 9 = LOC/REM 10 = JOG 11 = 加速 E.P. 12 = 减速 E.P. 13 = 多速 14 = 第 2 斜坡 15至17 = 未使用 18 = 不延长警报 19 = 不延长故障 20 = 重新设置 21 = SoftPLC 22 = PID 手动/自动 23 = 未使用 24 = 禁用快速启动 25 = 直流环节调节器 26 = 锁定程序 27 = 加载用户 1 28 = 加载用户 2 29 = PTC 30和31 = 未使用 32 = 第 2 斜坡多速 33 = 第 2 斜坡 E.P.加速 34 = 第 2 斜坡 E.P.减速 35 = 第 2 斜坡向前运行 36 = 第 2 斜坡后退运行 37 = 开启/加速E.P. 38 = 减速E.P./关闭 39 = 功能 1 应用 40 = 功能 2 应用 41 = 功能 3 应用 42 = 功能 4 应用 43 = 功能 5 应用 44 = 功能 6 应用 45 = 功能 7 应用 46 = 功能 8 应用 47 = 自动/人工PIDInt 48 = 自动/手动PIDExt 49 = 绕过 50 = 火灾模式 51 = 运行/ S. 开锁 52 = FWD / 锁定运行 53 = 锁定时修订/运行	1	cfg	输入/输出
P0264	D12 功能	见P0263中的选项	8	cfg	输入/输出
P0265	D13 功能	见P0263中的选项	20	cfg	输入/输出
P0266	D14 功能	见P0263中的选项	10	cfg	输入/输出
P0267	D15 功能	见P0263中的选项	0	cfg	输入/输出
P0268	D16 功能	见P0263中的选项	0	cfg	输入/输出
P0269	D17 功能	见P0263中的选项	0	cfg	输入/输出
P0270	D18 功能	见P0263中的选项	0	cfg	输入/输出
P0295	变频器额定电流	0.0 至 400.0 A	根据变频器型号	ro	读取
P0296	线路额定电压	0 = 200 - 240 V 1 = 380 V 2 = 400 - 415 V 3 = 440 - 460 V 4 = 480 V 5 = 500 - 525 V 6 = 550 - 575 V 7 = 600 V	根据变频器型号	ro, cfg	读取
P0297	交换频率	2500 至 15000 Hz	5000 Hz	cfg	
P0401	电机额定电流	0.0 至 400.0 A	1,0 x Inom	cfg	电机, 启动
P0402	电机额定转速	0 至 30000 转/分	1710 (1425) 转/分	cfg	电机, 启动
P0403	电机额定频率	0 至 500 Hz	60 (50) Hz	cfg	电机, 启动

3 故障和警报

最常见故障和警报

故障/警报	描述	可能原因
A0046 电机过载	电机过载警报	■ P0156、P0157和P0158的设置值对于所用电机过低 ■ 电机轴过载
A0050 功率模块 过热	电源温度过高警报 模块温度传感器 (NTC)	■ 变频器周围高温 (> 40 °C (> 104 °F)) 及高额输出电流 ■ 风扇堵塞或故障 ■ 散热器太脏, 导致空气无法流通
A0090 外部警报	通过DIx (P026x中的“无外部警报”选项) 发出外部警报	■ DI1 至 DI8 输入接线断开或接触不良
A0700 远程HMI通信故障	远程HMI无通信, 但具有速度指令或参考值作为数据源	■ 检查 HMI 通信接口是否按参数 P0312 正确配置 ■ HMI 电缆断开
F0021 直流环节低压	中间电路超电压故障	■ 供电不符: 检查变频器标签上的数是否符合电源及参数 P0296 ■ 电源电压过低, 导致 DC Link 上的电压低于最小值 (P0004 中); ■ Ud < 360 Vdc 在 380-480 Vac (P0296 = 1) ■ 输入端相位故障 ■ 预充电电路故障
F0022 直流母线过电压	中间电路超电压故障	■ 供电不符: 检查变频器标签上的数是否符合电源及参数 P0296 ■ 供给电压太高时, 在 (P0004) 高于最大值的直流环节上产生电压; ■ Ud > 810 Vdc 在 380-480 Vac (P0296 = 1) ■ 负载惯量过高或减速斜坡太快 ■ P0151, P0153或P0185设置过高
F0031 插入模块通信故障	主控制器不能设置插入模块的通信连接	■ 插入模块被损坏 ■ 插入模块未能正确连接 ■ 识别插入模块问题: 参考P0027获取更多信息
F0051 IGBTs 过热	电源温度传感器过热故障	■ 变频器周围高温 (> 40 °C (> 104 °F)) 及高额输出电流 ■ 风扇堵塞或故障 ■ 散热器太脏, 导致空气无法流通
F0070 过载电流/短路	输出、直流环节或制动电阻器电流过载或短路	■ 两个电机相位间短路 ■ 制动电阻器连接电缆短路 ■ IGBTs 模块短路或损坏 ■ 启动加速斜坡过短 ■ 未使用快速启动功能启动电机旋转
F0072 电机过载	电机过载故障 (在 1.5xInom 内60 s)	■ 与电机操作电流相关的P0156、P0157和P0158的设置值过低 ■ 电机轴过载
F0080 CPU 故障 (监视器)	与变频器主CPU的监管算法相关的故障	■ 电子噪音 ■ 变频器固件故障
F0084 自动诊断故障	变频器硬件和插入模块自动识别算法相关的故障	■ 主要控制器件与电源组接触不良 ■ 硬件不兼容固件版本 ■ 变频器内部电路故障
F0091 外部故障	通过DIx (P026x中的“无外部故障”选项) 发出外部故障	■ DI1 至 DI8 输入接线断开或接触不良
F0700 远程HMI通信故障	远程HMI无通信, 但具有该数据源的速度指令或参考值	■ 检查 HMI 通信接口是否按参数 P0312 正确配置 ■ HMI 电缆断开

4 速度参考和指令默认配置

CFW503出厂时已设置好参数, 以便在本地和远程操作模式中定义逻辑指令和速度参考值。通过60Hz和50Hz 电机的 P0204存储该默认设置 (P0204= 5或6) 。

在本地模式中, 指令和参考指向CFW503的HMI, 允许指令 运行/停止、JOG和电机旋转方向。除了这些指令, HMI键盘还可以用于选择本地或远程模式。可在P0121或通过在监控模式下的HMI 和 两个键设置 速度参考值。

在远程模式中, 速度参考值和指令指向产品终端: DI1执行 运行/停止, DI2执行 旋转方向。参考值由该模式中的模拟输入AI1执行。