


CANopen

CFW300

User's Guide





CANopen User's Guide

Series: CFW300

Language: English

Document Number: 10003961610 / 00

Build 462*

Publication Date: 03/2016

Contents

About the Manual	5
Abbreviations and Definitions	5
Numerical Representation	5
Documents	5
1 CANopen Communication Introduction	6
1.1 CAN	6
1.1.1 Data Frame	6
1.1.2 Remote Frame	6
1.1.3 Access to the Network	6
1.1.4 Error Control	6
1.1.5 CAN and CANopen	7
1.2 CANopen Network Characteristics	7
1.3 Physical Layer	7
1.3.1 Address in the CANopen Network	7
1.3.2 Access to the Data	8
1.3.3 Data Transmission	8
1.3.4 Communication Objects - COB	8
1.3.5 COB-ID	9
1.3.6 Configuration File (EDS)	9
2 CANopen Communication Interface	10
2.1 CAN Interface Characteristics	10
2.2 Pin Assignment of the Connector	10
2.3 Power Supply	11
2.4 Indications	11
3 CANopen Network Installation	12
3.1 Baud Rate	12
3.2 Address in the CANopen Network	12
3.3 Termination Resistor	12
3.4 Cable	13
3.5 Connection in the Network	13
4 Parameterization	14
4.1 Symbols for the Properties Description	14
P105 – 1st/2nd ramp selection	14
P220 – Local/REMOTE Selection Source.....	14
P221 – Speed Reference Selection – LOCAL Situation	14
P222 – Speed Reference Selection – REMOTE Situation.....	14
P223 – FORWARD/REVERSE Selection – LOCAL Situation.....	14
P224 – Run/Stop Selection – LOCAL Situation	14
P225 – JOG Selection – LOCAL Situation	14
P226 – FORWARD/REVERSE Selection – REMOTE Situation	14
P227 – Run/Stop Selection – REMOTE Situation	14
P228 – JOG Selection – REMOTE Situation	14
P313 – Action in Case of Communication Error	15
P680 – Logical Status	15

P681 – Motor Speed in 13 Bits	16
P684 – Control Word	17
P685 – Speed Reference	17
P695 – Digital Outputs Setting	18
P696 - Value 1 for Analog Outputs.....	19
P697 - Value 2 for Analog Outputs	19
P700 – Can Protocol.....	19
P701 – CAN Address	20
P702 – CAN Baud Rate	20
P703 – Bus Off Reset.....	21
P705 – CAN Controller Status	21
P706 – Received CAN Telegram Counter	21
P707 – Transmitted CAN Telegram Counter	22
P708 – Bus Off Error Counter	22
P709 – Lost CAN Message Counter	22
P721 – CANopen Network Status	22
P722 – CANopen Node Status.....	22
5 Object Dictionary	24
5.1 Dictionary Structure	24
5.2 Data Type	24
5.3 Communication Profile - Communication Objects	24
5.4 Manufacturer Specific – CFW300 specific Objects	25
6 Communication Objects Description	26
6.1 Identification Object	26
6.1.1 Objeto 1000h - Device Type	26
6.1.2 Objeto 1001h - Error Register	26
6.1.3 Objeto 1018h - Identity Object	26
6.2 Service Data Objects - SDOS	27
6.2.1 Objeto 1200h - SDO Server	27
6.2.2 SDOs Operation	27
6.3 Process Data Objects - PDOS	29
6.3.1 PDO Mapping Objects	29
6.3.2 Receive PDOs	30
6.3.3 Transmit PDOs	32
6.4 Synchronization Object - Sync	33
6.5 Network Management - NMT	34
6.5.1 Slave State Control	34
6.5.2 Error Control - Node Guarding	35
6.5.3 Error Control - Heartbeat	37
6.6 Initialization Procedure	38
7 Faults and Alarms	40
A133/F233 - CAN Interface without Power Supply	40
A134/F234- Bus Off	40
A137/F237 - DeviceNet Connection Timeout	40

ABOUT THE MANUAL

This manual supplies the necessary information for the operation of the CFW300 frequency converter using the CANopen protocol. This manual must be used together with the CFW300 user's manual and programming manual.

ABBREVIATIONS AND DEFINITIONS

ASCII	American Standard Code for Information Interchange
CAN	Controller Area Network
CiA	CAN in Automation
CIP	Common Industrial Protocol
CRC	Cycling Redundancy Check
HMI	Human-Machine Interface
ISO	International Organization for Standardization
ODVA	Open DeviceNet Vendor Association
OSI	Open Systems Interconnection
PLC	Programmable Logic Controller
ro	Read only
rw	Read/write
RTR	Remote Transmission Request

NUMERICAL REPRESENTATION

Decimal numbers are represented by means of digits without suffix. Hexadecimal numbers are represented with the letter 'h' after the number. Binary numbers are represented with the letter 'b' after the number.

DOCUMENTS

The CANopen protocol was developed based on the following specifications and documents:

Document	Version	Source
CAN Specification	2.0	CiA
CiA DS 301 CANopen Application Layer and Communication Profile	4.02	CiA
CiA DRP 303-1 Cabling and Connector Pin Assignment	1.1.1	CiA
CiA DSP 306 Electronic Data Sheet Specification for CANopen	1.1	CiA
CiA DSP 402 Device Profile Drives and Motion Control	2.0	CiA
Planning and Installation Manual - DeviceNet Cable System	PUB00027R1	ODVA

1 CANOPEN COMMUNICATION INTRODUCTION

In order to operate the equipment in a CANopen network, it is necessary to know the manner this communication is performed. Therefore, this section brings a general description of the CANopen protocol operation, containing the functions used by the CFW300. Refer to the protocol specification for a detailed description.

1.1 CAN

CANopen is a network based on CAN, i.e., it uses CAN telegrams for exchanging data in the network.

The CAN protocol is a serial communication protocol that describes the services of layer 2 of the ISO/OSI model (data link layer)¹. This layer defines the different types of telegrams (frames), the error detection method, the validation and arbitration of messages.

1.1.1 Data Frame

CAN network data is transmitted by means of a data frame. This frame type is composed mainly by an 11 bits² identifier (arbitration field), and by a data field that may contain up to 8 data bytes.

Identifier	8 data bytes							
11 bits	byte 0	byte 1	byte 2	byte 3	byte 4	byte 5	byte 6	byte 7

1.1.2 Remote Frame

Besides the data frame, there is also the remote frame (RTR frame). This type of frame does not have a data field, but only the identifier. It works as a request, so that another network device transmits the desired data frame. The CANopen communication protocol does not use this type of frame.

1.1.3 Access to the Network

Any device in a CAN network can make an attempt to transmit a frame to the network in a certain moment. If two devices try to access the network simultaneously, the one that sends the message with the highest priority will be able to transmit. The message priority is defined by the CAN frame identifier, the smaller the value of this identifier, the higher the message priority. The telegram with the identifier 0 (zero) is the one with the highest priority.

1.1.4 Error Control

The CAN specification defines several error control mechanisms, which makes the network very reliable and with a very low undetected transmission error rate. Every network device must be able to identify the occurrence of these errors, and to inform the other elements that an error was detected.

A CAN network device has internal counters that are incremented every time a transmission or reception error is detected, and are decremented when a telegram is successfully transmitted or received. If a considerable amount of errors occurs, the device can be led to the following states:

¹In the CAN protocol specification, the ISO11898 standard is referenced as the definition of the layer 1 of this model (physical layer).

²The CAN 2.0 specification defines two data frame types, standard (11 bit) and extended (29 bit). For this implementation, only the standard frames are accepted.

- **Error Active:** the internal error counters are at a low level and the device operates normally in the CAN network. You can send and receive telegrams and act in the CAN network if it detects any error in the transmission of telegrams.
- **Warning:** when the counter exceeds a defined limit, the device enters the warning state, meaning the occurrence of a high error rate.
- **Error Passive:** when this value exceeds a higher limit, the device enters the error passive state, and it stops acting in the network when detecting that another device sent a telegram with an error.
- **Bus Off:** finally, we have the bus off state, in which the device will not send or receive telegrams any more. The device operates as if disconnected from the network.

1.1.5 CAN and CANopen

Only the definition of how to detect errors, create and transmit a frame, are not enough to define a meaning for the data transmitted via the network. It is necessary to have a specification that indicates how the identifier and the data must be assembled and how the information must be exchanged. Thus, the network elements can interpret the transmitted data correctly. In that sense, the CANopen specification defines exactly how to exchange data among the devices and how every one must interpret these data.

There are several other protocols based on CAN, as DeviceNet, J1939, etc., which use CAN frames for the communication. However, those protocols cannot be used together in the same network.

1.2 CANOPEN NETWORK CHARACTERISTICS

Because of using a CAN bus as telegram transmission means, all the CANopen network devices have the same right to access the network, where the identifier priority is responsible for solving conflict problems when simultaneous access occurs. This brings the benefit of making direct communication between slaves of the network possible, besides the fact that data can be made available in a more optimized manner without the need of a master that controls all the communication performing cyclic access to all the network devices for data updating.

Another important characteristic is the use of the producer/consumer model for data transmission. This means that a message that transits in the network does not have a fixed network address as a destination. This message has an identifier that indicates what data it is transporting. Any element of the network that needs to use that information for its operation logic will be able to consume it, therefore, one message can be used by several network elements at the same time.

1.3 PHYSICAL LAYER

The physical medium for signal transmission in a CANopen network is specified by the ISO 11898 standard. It defines as transmission bus a pair of twisted wires with differential electrical signal.

1.3.1 Address in the CANopen Network

Every CANopen network must have a master responsible for network management services, and it can also have a set of up to 127 slaves. Each network device can also be called node. Each slave is identified in a CANopen network by its address or Node-ID, which must be unique for each slave and may range from 1 to 127.

1.3.2 Access to the Data

Each slave of the CANopen network has a list called object dictionary that contains all the data accessible via network. Each object of this list is identified with an index, which is used during the equipment configuration as well as during message exchanges. This index is used to identify the object being transmitted.

1.3.3 Data Transmission

The transmission of numerical data via CANopen telegrams is done using a hexadecimal representation of the number, and sending the least significant data byte first.

E.g: The transmission of a 32 bit integer with sign (12345678h = 305419896 decimal), plus a 16 bit integer with sign (FF00h = -256 decimal), in a CAN frame.

Identifiyer	6 data bytes					
11 bits	32 bits integer				16 bits integer	
	byte 0	byte 1	byte 2	byte 3	byte 4	byte 5
	78h	56h	34h	12h	00h	FFh

1.3.4 Communication Objects - COB

There is a specific set of objects that are responsible for the communication among the network devices. Those objects are divided according to the type of data and the way they are sent or received by a device. The device supports the following communication objects (COB):

Table 1.1: Types of Communication Objects (COBs)

Type of object	Description
Service Data Object (SDO)	SDO are objects responsible for the direct access to the object dictionary of a device. By means of messages using SDO, it is possible to indicate explicitly (by the object index) what data is being handled. There are two SDO types: Client SDO, responsible for doing a read or write request to a network device, and the Server SDO, responsible for taking care of that request. Since SDO are usually used for the configuration of a network node, they have less priority than other types of message.
Process Data Object (PDO)	PDO are used for accessing equipment data without the need of indicating explicitly which dictionary object is being accessed. Therefore, it is necessary to configure previously which data the PDO will be transmitting (data mapping). There are also two types of PDO: Receive PDO and Transmit PDO. They are usually utilized for transmission and reception of data used in the device operation, and for that reason they have higher priority than the SDO.
Emergency Object (EMCY)	This object is responsible for sending messages to indicate the occurrence of errors in the device. When an error occurs in a specific device (EMCY producer), it can send a message to the network. In the case that any network device be monitoring that message (EMCY consumer), it can be programmed so that an action be taken (disabling the other devices, error reset, etc.).
Synchronization Object (SYNC)	In the CANopen network, it is possible to program a device (SYNC producer) to send periodically a synchronization message for all the network devices. Those devices (SYNC consumers) will then be able, for instance, to send a certain datum that needs to be made available periodically.
Network Management (NMT)	Every CANopen network needs a master that controls the other devices (slaves) in the network. This master will be responsible for a set of services that control the slave communications and their state in the CANopen network. The slaves are responsible for receiving the commands sent by the master and for executing the requested actions. The protocol describes two types of service that the master can use: device control service, with which the master controls the state of each network slave, and error control service (Node Guarding), with which the slave sends periodic messages to the master informing that the connection is active.

All the communication of the inverter with the network is performed using those objects, and the data that can be accessed are the existent in the device object dictionary.

1.3.5 COB-ID

A telegram of the CANopen network is always transmitted by a communication object (COB). Every COB has an identifier that indicates the type of data that is being transported. This identifier, called COB-ID has an 11 bit size, and it is transmitted in the identifier field of a CAN telegram. It can be subdivided in two parts:

Function Code				Address						
bit 10	bit 9	bit 8	bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0

- Function Code: indicates the type of object that is being transmitted.
- Address: indicates with which network device the telegram is linked.

A table with the standard values for the different communication objects available is presented next. Notice that the standard value of the object depends on the slave address, with the exception of the COB-ID for NMT and SYNC, which are common for all the network elements. Those values can also be changed during the device configuration stage.

Table 1.2: COB-ID for the different objects

COB	Function Code (bits 10-7)	COB-ID Resultant COB-ID(function + address)
NMT	0000	0
SYNC	0001	128 (80h)
EMCY	0001	129 - 255 (81h - FFh)
PDO1 (tx)	0011	385 - 511 (181h - 1FFh)
PDO1 (rx)	0100	513 - 639 (201h - 27Fh)
PDO2 (tx)	0101	641 - 767 (281h - 2FFh)
PDO2 (rx)	0110	769 - 895 (301h - 37Fh)
PDO3 (tx)	0111	897 - 1023 (381h - 3FFh)
PDO3 (rx)	1000	1025 - 1151 (401h - 47Fh)
PDO4 (tx)	1001	1153 - 1279 (481h - 4FFh)
PDO4 (rx)	1010	1281 - 1407 (501h - 57Fh)
SDO (tx)	1011	1409 - 1535 (581h - 5FFh)
SDO (rx)	1100	1537 - 1663 (601h - 67Fh)
Node Guarding/Heartbeat	1110	1793 - 1919 (701h - 77Fh)

1.3.6 Configuration File (EDS)

Each device in a CANopen network has an EDS configuration file that contains information about the device operation and must be registered in the network configuration software, for programming of devices present in the CANopen Network.

The EDS configuration file is supplied together with the product, and it can also be obtained from the website <http://www.weg.net>. It is necessary to observe the equipment software version, in order to use an EDS file that is compatible with that version.

2 CANOPEN COMMUNICATION INTERFACE

The standard CFW300 frequency converter features a CAN interface. It can be used for communication in Devicenet protocol as a network slave. The characteristics of this interface are described below.

2.1 CAN INTERFACE CHARACTERISTICS




Figure 2.1: Acessório CCAN

- Interface galvanically insulated and with differential signal, providing more robustness against electromagnetic interference.
- External power supply of 24 V.
- It allows the connection of up to 64 devices to the same segment. More devices can be connected by using repeaters³.
- Maximum bus length of 1000 meters.

2.2 PIN ASSIGNMENT OF THE CONNECTOR

The CAN interface has a 5-way connector with the following pin assignment:




Figure 2.2: Detalhe do conector CAN

Table 2.1: Pin assignment of connector for CAN interface

Pin	Name	Function
25	V-	Negative pole of the power supply
26	CAN_L	Communication signal CAN_L
27	Shield	Cable shield
28	CAN_H	Communication signal CAN_H
29	V+	Positive pole of the power supply

³The maximum number of devices that can be connected to the network also depends on the protocol used.

2.3 POWER SUPPLY

The CAN interfaces require an external power supply between pins 6 and 10 of the network connector. The data for individual consumption and input voltage are shown in the following table.

Table 2.2: Characteristics of the supply for the CAN interface

Power Supply (Vdc)		
Minimum	Maximum	Recomended
11	30	24
Current (mA)		
Typical		Maximum
30		50

2.4 INDICATIONS

The alarm, fault and status indications of the CANopen communication for the CFW300 frequency converter are made trough the HMI and parameters of the product.

3 CANOPEN NETWORK INSTALLATION

The CANopen network, such as several industrial communication networks, for being many times applied in aggressive environments with high exposure to electromagnetic interference, requires that certain precautions be taken in order to guarantee a low communication error rate during its operation. Recommendations to perform the connection of the product in this network are presented next.



NOTE!

Detailed recommendations on how to perform the installation are available at document "Planning and Installation Manual" (item Documents).

3.1 BAUD RATE

Equipments with CANopen interface generally allow the configuration of the desired baud rate, ranging from 10Kbit/s to 1Mbit/s. The baud rate that can be used by equipment depends on the length of the cable used in the installation. The next table shows the baud rates and the maximum cable length that can be used in the installation, according to the protocol recommendation ⁴.

Table 3.1: Supported baud rates and installation size

Baud Rate	Cable length
1Mbit/s	25m
800 Kbps	50 m
500 Kbps	100 m
250 Kbps	250 m
125 Kbps	500 m
100 Kbps	600 m
50 Kbps	1000 m
20 Kbps	1000 m
10 Kbps	1000 m

All network equipment must be programmed to use the same communication baud rate. At the CFW300 frequency converter the baud rate configuration is done through the P702 parameter.

3.2 ADDRESS IN THE CANOPEN NETWORK

Each CANopen network device must have an address or Node ID, and may range from 0 to 127. This address must be unique for each equipment. For CFW300 frequency converter the address configuration is done through the parameter P701.

3.3 TERMINATION RESISTOR

The CAN bus line must be terminated with resistors to avoid line reflection, which can impair the signal and cause communication errors. The extremes of the CAN bus must have a termination resistor with a 121Ω|0.25W value, connecting the CAN_H and CAN_L signals.

⁴Different products may have different maximum allowed cable length for installation

3.4 CABLE

The connection of CAN_L and CAN_H signals must be done with shielded twisted pair cable. The following table shows the recommended characteristics for the cable.

Table 3.2: CANopen cable characteristics

Cable Length (m)	Resistance per meter (Ω/m)	Conductor cross section (mm ²)
0 ... 40	70	0.25 ... 0.34
40 ... 300	<60	0.34 ... 0.60
300 ... 600	<40	0.50 ... 0.60
600 ... 1000	<26	0.75 ... 0.80

It is necessary to use a twisted pair cable to provide additional 24Vdc power supply to equipments that need this signal.

3.5 CONNECTION IN THE NETWORK

In order to interconnect the several network nodes, it is recommended to connect the equipment directly to the main line without using derivations. During the cable installation the passage near to power cables must be avoided, because, due to electromagnetic interference, this makes the occurrence of transmission errors possible. In order to avoid problems with current circulation caused by difference of potential among ground connections, it is necessary that all the devices be connected to the same ground point.




Figure 3.1: CANopen network installation example

To avoid voltage difference problems between the power supplies of the network devices, it is recommended that the network is fed by only one power supply and the signal is provided to all devices through the cable. If it is required more than one power supply, these should be referenced to the same point. Use the power supply to power the bus cable system only.

The maximum number of devices connected to a single segment of the network is limited to 64. Repeaters can be used for connecting a bigger number of devices.

4 PARAMETERIZATION

Next, the CFW300 frequency converter parameters related to the CANopen communication will be presented.

4.1 SYMBOLS FOR THE PROPERTIES DESCRIPTION

- **RO** Read-only parameter
- **CFG** Parameter that can be changed only with a stopped motor
- **CAN** Parâmetro visível através da HMI se o produto possuir interface CAN instalada

P105 – 1ST/2ND RAMP SELECTION

P220 – LOCAL/REMOTE SELECTION SOURCE

P221 – SPEED REFERENCE SELECTION – LOCAL SITUATION

P222 – SPEED REFERENCE SELECTION – REMOTE SITUATION

P223 – FORWARD/REVERSE SELECTION – LOCAL SITUATION

P224 – RUN/STOP SELECTION – LOCAL SITUATION

P225 – JOG SELECTION – LOCAL SITUATION

P226 – FORWARD/REVERSE SELECTION – REMOTE SITUATION

P227 – RUN/STOP SELECTION – REMOTE SITUATION

P228 – JOG SELECTION – REMOTE SITUATION

Description:

These parameters are used to configure the command sources for CFW300 frequency converter local and remote situations. To control the device through the CANopen interface, select the options 'CANopen(CO/DN/DP)' available in these parameters.

The detailed description of these parameters is found in the CFW300 programming manual.

P313 – ACTION IN CASE OF COMMUNICATION ERROR

Range:	0 = Inactive 1 = Disable via Run/Stop 2 = Disable via General Enable 3 = Change to Local 4 = Change to Local keeping commands and reference 5 = Causes a Fault	Default: 1
Properties:	CFG	

Description:

It allows the selection of the action performed by the device, if it is controlled via network and detects a communication error.

Table 4.1: P313 options

Options	Description
0 = Inactive	It takes no action and the device remains in the existing status.
1 = Disable via Run/Stop	It performs a stop command and the motor stops according to the programmed deceleration ramp.
2 = Disable via General Enable	The device is disabled by removing the General Enabling and the motor coasts to stop.
3 = Change to Local	The device commands change to Local.
4 = Change to Local keeping commands and reference	The device commands change to Local, but the enabling commands and speed reference received via network are kept, if the device has been programmed to use, in Local mode, the commands via HMI or 3-wire start/stop, and speed reference via either HMI or electronic potentiometer.
5 = Causes a Fault	Instead of an alarm, the communication error causes a device fault, so that a fault reset becomes necessary in order to restore normal operation.

The device consider the following events as communication errors:

- Alarm A133/Fault F233: CAN interface not powered.
- Alarm A134/Fault F234: bus off.
- Alarm A135/Fault F235: CANopen communication error (Node Guarding/Heartbeat).

The actions described in this parameter are done by means of the automatic writing of the selected actions in the respective bits of the interface control words. Therefore, in order that the commands written in this parameter be effective, it is necessary that the device be programmed to be controlled via the used network interface (with exception of option “Causes a Fault”, which blocks the equipment even if it is not controlled by network). This programming is achieved by means of parameters P220 to P228.

P680 – LOGICAL STATUS

Range:	0000h ... FFFFh	Default: -
Properties:	RO	

Description:

It allows the device status monitoring. Each bit represents a specific status:

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Function	Fault condition	Reserved	Undervoltage	LOC/REM	JOG	Speed direction	General enable active	Motor Running	Alarm condition	In configuration mode	Second ramp	Reserved	Reserved			

Table 4.2: P680 parameter bit functions

Bit	Value/Description
Bit 0 ... 3	Reserved
Bit 4 Quick stop active	0: The quick stop command is not active. 1: The drive is executing the quick stop command.
Bit 5 Second ramp	0: The drive is configured to use the first ramp values, programmed in P100 and P101, as the motor acceleration and deceleration ramp times. 1: The drive is configured to use the second ramp values, programmed in P102 and P103, as the motor acceleration and deceleration ramp times.
Bit 6 In configuration mode	0: The drive is operating normally. 1: The drive is in the configuration mode. It indicates a special condition during which the drive cannot be enabled: <ul style="list-style-type: none"> ▪ Running the self-tuning routine. ▪ Running the oriented start-up routine. ▪ Running the HMI copy function. ▪ Running the flash memory card self-guided routine. ▪ There is a parameter setting incompatibility. ▪ There is no power at the device power section.
Bit 7 Alarm condition	0: The drive is not in alarm condition. 1: The drive is in alarm condition.
Bit 8 Motor Running	0: The motor is stopped (or coast to stop). 1: The drive is running the motor at the set point speed, or executing either the acceleration or the deceleration ramp.
Bit 9 General enable active	0: General Enable is not active. 1: General Enable is active and the drive is ready to run the motor.
Bit 10 Speed direction	0: The motor is running in the reverse direction. 1: The motor is running in the forward direction.
Bit 11 JOG	0: JOG function disabled. 1: JOG function enabled.
Bit 12 LOC/REM	0: Drive in Local mode. 1: Drive in Remote mode.
Bit 13 Undervoltage	0: No Undervoltage. 1: With Undervoltage.
Bit 14 Automatic (PID)	0: PID in manual mode. 1: PID in Automatic mode.
Bit 15 Fault condition	0: The drive is not in a fault condition. 1: The drive has detected a fault.

P681 – MOTOR SPEED IN 13 BITS

Range:	-32768 ... 32767	Default: -
Properties:	RO	

Description:

It allows monitoring the motor speed. This word uses 13-bit resolution with signal to represent the motor rated frequency (P403):

$$\begin{aligned}
 P681 = 0000h \text{ (0 decimal)} & \rightarrow \text{motor speed} = 0 \\
 P681 = 2000h \text{ (8192 decimal)} & \rightarrow \text{motor speed} = \text{rated frequency (P403)}
 \end{aligned}$$

Intermediate or higher frequency values can be obtained by using this scale. E.g., for a 60Hz rated frequency motor, if the value read is 2048 (0800h), then, to obtain the value in Hz one must calculate:

$$\begin{aligned}
 8192 & \Rightarrow 60 \text{ Hz} \\
 2048 & \Rightarrow \text{Frequency} \\
 \text{Frequency} & = \frac{2048 \times 60}{8192} \\
 \text{Frequency} & = 15 \text{ Hz}
 \end{aligned}$$

Negative values in this parameter indicate that the motor is running in the reverse direction.


NOTE!

The values transmitted over the network have a scale limitation, allowing a maximum of 4 times the rated frequency of the motor, with saturation in 32767 (or -32768).

P684 – CONTROL WORD

Range:	0000h ... FFFFh	Default: 0000h
Properties:	CAN	

Description:

It is the device CANopen interface control word. This parameter can only be changed via CANopen interface. For the other sources (HMI, etc.) it behaves like a read-only parameter.

In order to have those commands executed, it is necessary to program the equipment to be controlled via CANopen. This programming is achieved by means of parameters P105 e P220 até P228.

Each bit of this word represents a command that can be executed.

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Function	Reserved								Fault Reset	Quick Stop	Second Ramp	LOC/REM	JOG	Speed direction	General Enable	Run/Stop

Table 4.3: parameter bit functions P684

Bit	Values
Bit 0 Run/Stop	0: It stops the motor with deceleration ramp. 1: The motor runs according to the acceleration ramp until reaching the speed reference value.
Bit 1 General Enable	0: It disables the drive, interrupting the supply for the motor. 1: It enables the drive allowing the motor operation.
Bit 2 Speed Direction	0: To run the motor in a direction opposed to the speed reference. 1: To run the motor in the direction indicated by the speed reference.
Bit 3 JOG	0: It disables the JOG function. 1: It enables the JOG function.
Bit 4 LOC/REM	0: The drive goes to the Local mode. 1: The drive goes to the Remote mode.
Bit 5 Second Ramp	0: The drive uses the first ramp values, programmed in P100 and P101, as the motor acceleration and deceleration ramp times. 1: The drive is configured to use the second ramp values, programmed in P102 and P103, as the motor acceleration and deceleration ramp times.
Bit 6 Quick Stop	0: Quick Stop command not activated. 1: Quick Stop command activated.
Bit 7 Fault Reset	0: no function. 1: If in a fault condition, then it executes the reset.
Bit 8...15	Reserved.

P685 – SPEED REFERENCE

Range:	-32768 ... 32767	Default: 0
Properties:	CAN	

Description:

It allows programming the motor speed reference via the CANopen interface. This parameter can only be changed via CANopen interface. For the other sources (HMI, etc.) it behaves like a read-only parameter.

In order that the reference written in this parameter be used, it is necessary that the drive be programmed to use the speed reference via CANopen/DeviceNet/Profibus DP. This programming is achieved by means of parameters P221 and P222.

This word uses a 13-bit resolution with signal to represent motor rated frequency (P403).

- P685 = 0000h (0 decimal) → speed reference = 0
- P685 = 2000h (8192 decimal) → speed reference = rated frequency (P403)

Intermediate or higher reference values can be programmed by using this scale. E.g.60Hz rated frequency, to obtain a speed reference of 30 Hz one must calculate:

60 Hz ⇒ 8192
 30 Hz ⇒ 13 bits reference

$$13 \text{ bits reference} = \frac{30 \times 8192}{60}$$

13 bits reference = 4096 ⇒ Value corresponding to 30 Hz in a 13 bit scale

This parameter also accepts negative values to revert the motor speed direction. The reference speed direction, however, depends also on the control word - P685- bit 2 setting:

- Bit 2 = 1 and P685 > 0: reference for forward direction
- Bit 2 = 1 and P685 < 0: reference for reverse direction
- Bit 2 = 0 and P685 > 0: reference for reverse direction
- Bit 2 = 0 and P685 < 0: reference for forward direction


NOTE!

Os valores transmitidos via rede apresentam uma limitação na escala utilizada, permitindo que no máximo seja programado uma referência de velocidade de 4 vezes a frequência nominal do motor.

P695 – DIGITAL OUTPUTS SETTING

Range:	0000b... 1111b	Default: 0000b
Properties:	RW	

Description:

It allows the control of the digital outputs by means of the network interfaces (CANopen, etc.). It is not possible to change this parameter via HMI.

Each bit of this parameter corresponds to the desired value for one digital output. In order to control the correspondent digital output according to this content, it is necessary that its function be programmed for “P0695 Content” at parameters to program digital outputs function.

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Function	Reserved											Reserved	Value for DO4	Value for DO3	Value for DO2	Value for DO1

Table 4.4: Bit function for parameter P0695

Bit	Valor/Descrição
Bit 0 Value for DO1	0: Open DO1. 1: Close DO1.
Bit 1 Value for DO2	0: Open DO2. 1: Close DO2.
Bit 2 Value for DO3	0: Open DO3 . 1: Close DO3.
Bit 3 Value for DO4	0: Open DO4. 1: Close DO4.
Bit 4...15	Reserved.

P696 - VALUE 1 FOR ANALOG OUTPUTS

P697 - VALUE 2 FOR ANALOG OUTPUTS

Range:	-32768 ... 32767	Default: 0
Properties:	rw	

Description:

They allow the control of the analog outputs by means of network interfaces (CANopen, etc.). It is not possible to change this parameter via HMI.

The value written in these parameters may control the analog output value, as long as you program the option “P0696 ... P0697 value” at the analog output function parameters.

The value must be written in a 15-bit⁵ scale (7FFFh = 32767) to represent 100 % of the output desired value, i.e.:

- P0696 = 0000h (0 decimal) → analog output value = 0 %
- P0696 = 7FFFh (32767 decimal) → analog output value = 100 %

The showed example was for P0696, but the same scale is also used for the other parameters. For instance, to control the analog output 1 via CANopen, the following programming must be done:

- Choose a parameter from P0696 ... P0697 to be the value used by the analog output 1. For this example, we are going to select P0696.
- Program the option “P0696 value” as the function for the analog output 1 in P0254.
- Using the network interface, write in P0696 the desired value for the analog output 1, between 0 and 100 %, according to the parameter scale.

P700 – CAN PROTOCOL

Range:	1 = CANopen 2 = DeviceNet	Default: 2
Properties:	CAN	

Description:

It allows selecting the desired protocol for the CAN interface. If this parameter is changed, the change takes effect only if the CAN interface is not powered, it is in auto-baud or after the equipment is switched off and on again.

⁵For the actual output resolution, refer to the product manual.

P701 – CAN ADDRESS

Range:	0 a 127	Default: 63
Properties:	CAN	

Description:

It allows programming the address used for the CAN communication. It is necessary that each element of the network has an address different from the others. The valid addresses for this parameter depend on the protocol programmed in P700:

- P700 = 1 (CANopen): valid addresses: 1 to 127.
- P700 = 2 (DeviceNet): valid addresses: 0 to 63.

If this parameter is changed, the change takes effect only if the CAN interface is not powered, auto-baud or after the equipment is switched off and on again.

P702 – CAN BAUD RATE

Range:	0 = 1 Mbit/s / Autobaud 1 = 800 Kbit/s / Autobaud 2 = 500 Kbit/s 3 = 250 Kbit/s 4 = 125 Kbit/s 5 = 100 Kbit/s / Autobaud 6 = 50 Kbit/s / Autobaud 7 = 20 Kbit/s / Autobaud 8 = 10 Kbit/s / Autobaud	Default: 0
Properties:	CAN	

Description:

It allows programming the desired baud rate for the CAN interface, in bits per second. This rate must be the same for all the devices connected to the network. The supported baud rates for the device depend on the protocol programmed in the parameter P700:

- P700 = 1 (CANopen): It is possible to use any rate specified in this parameter, but it does not have the automatic baud rate detection function – autobaud.
- P700 = 2 (DeviceNet): only the 500, 250 and 125 Kbit/s rates are supported. Other options will enable the automatic baud rate detection function – autobaud.

If this parameter is changed, the change takes effect only if the CAN interface is not powered or after the equipment is switched off and on again.

After a successful detection, the baud rate parameter (P702) changes automatically to the detected rate. In order to execute the autobaud function again, it is necessary to change the parameter P702 to one of the 'Autobaud' options.

P703 – BUS OFF RESET

Range:	0 = Manual 1 = Automatic	Default: 1
Properties:	CAN	

Description:

It allows programming the inverter behavior when detecting a bus off error at the CAN interface:

Table 4.5: Options for the parameter P703

Option	Description
0 = Manual Reset	If bus off occurs, the A134/F34 alarm will be indicated on the HMI, the action programmed in parameter P313 will be executed and the communication will be disabled. In order that the inverter communicates again through the CAN interface, it will be necessary to cycle the power of the inverter.
1 = Automatic Reset	If bus off occurs, the communication will be reinitiated automatically and the error will be ignored. In this case the alarm will not be indicated on the HMI and the inverter will not execute the action programmed in P313.

P705 – CAN CONTROLLER STATUS

Range:	0 = Disable 1 = Autobaud 2 = CAN Enabled 3 = Warning 4 = Error Passive 5 = Bus Off 6 = No Bus Power	Default: -
Properties:	RO	

Description:

It allows identifying if the CAN interface board is properly installed and if the communication presents errors.

Table 4.6: Indication of the parameter P705

Value	Description
0 = Disable	Inactive CAN interface. It occurs when CAN protocol is not programmed at P705.
1 = Autobaud	CAN controller is trying to detect baud rate of the network (only for CANopen communication protocol).
2 = CAN Enable	CAN interface is active and without errors.
3 = Warning	CAN controller has reached the warning state.
4 = Error PAssive	CCAN controller has reached the error passive state.
5 = Bus Off	CAN controller has reached the bus off state.
6 = Sem Alimentação	CAN interface does not have power supply between the pins 1 and 5 of the connector.

P706 – RECEIVED CAN TELEGRAM COUNTER

Range:	0 a 9999	Default: -
Properties:	RO	

Description:

This parameter works as a cyclic counter that is incremented every time a CAN telegram is received. It informs the operator if the device is being able to communicate with the network. This counter is reset every time the device is

switched off, a reset is performed or the parameter maximum limit is reached.

P707 – TRANSMITED CAN TELEGRAM COUNTER

Range:	0 a 9999	Default: -
Properties:	RO	

Description:

This parameter works as a cyclic counter that is incremented every time a CAN telegram is transmitted. It informs the operator if the device is being able to communicate with the network. This counter is reset every time the device is switched off, a reset is performed or the parameter maximum limit is reached.

P708 – BUS OFF ERROR COUNTER

Range:	0 a 9999	Default: -
Properties:	RO	

Description:

It is a cyclic counter that indicates the number of times the device entered the bus off state in the CAN network. This counter is reset every time the device is switched off, a reset is performed or the parameter maximum limit is reached.

P709 – LOST CAN MESSAGE COUNTER

Range:	0 a 9999	Default: -
Properties:	RO	

Description:

It is a cyclic counter that indicates the number of messages received by the CAN interface, but could not be processed by the device. In case that the number of lost messages is frequently incremented, it is recommended to reduce the baud rate used in the CAN network. This counter is reset every time the device is switched off, a reset is performed or the parameter maximum limit is reached.

P721 – CANOPEN NETWORK STATUS

Range:	0 = Disable 1 = Reserved 2 = Communication Enabled 3 = Error Control Enable 4 = Guarding Error 5 = Heartbeat Error	Default: -
Properties:	RO	

Description:

It indicates the board state regarding the CANopen network, informing if the protocol has been enabled and if the error control service is active (Node Guarding or Heartbeat).

P722 – CANOPEN NODE STATUS

Range:	0 = Disable 1 = Initialization 2 = Stopped 3 = Operational 4 = Preoperational	Default: -
Properties:	RO	

Description:

It operates as a slave of the CANopen network, and as such element it has a state machine that controls its behavior regarding the communication. This parameter indicates in which state the device is.

5 OBJECT DICTIONARY

The object dictionary is a list containing several equipment data which can be accessed via CANopen network. An object of this list is identified by means of a 16-bit index, and it is based in that list that all the data exchange between devices is performed.

The CiA DS 301 document defines a set of minimum objects that every CANopen network slave must have. The objects available in that list are grouped according to the type of function they execute. The objects are arranged in the dictionary in the following manner:

Table 5.1: Object dictionary groupings

Index	Objects	Description
0001h - 025Fh	Data type definition	Used as reference for the data type supported by the system.
1000h - 1FFFh	Communication objects	They are objects common to all the CANopen devices. They contain general information about the equipment and also data for the communication configuration.
2000h - 5FFFh	Manufacturer specific objects	In this range, each CANopen equipment manufacturer is free to define which data those objects will represent.
6000h - 9FFFh	Standardized device objects	This range is reserved to objects that describe the behavior of similar equipment, regardless of the manufacturer.

The other indexes that are not referred in this list are reserved for future use.

5.1 DICTIONARY STRUCTRE

The general structure of the dictionary has the following format:

Index	Object	Name	Type	Access
-------	--------	------	------	--------

- **Index:** indicates directly the object index in the dictionary.
- **Object:** describes which information the index stores (simple variable, array, record, etc.).
- **Name:** contains the name of the object in order to facilitate its identification.
- **Type:** indicates directly the stored data type. For simple variables, this type may be an integer, a float, etc. For arrays, it indicates the type of data contained in the array. For records, it indicates the record format according to the types described in the first part of the object dictionary (indexes 0001h – 0360h).
- **Access:** informs if the object in question is accessible only for reading (ro), for reading and writing (rw), or if it is a constant (const).

For objects of the array or record type, a sub-index that is not described in the dictionary structure is also necessary.

5.2 DATA TYPE

The first part of the object dictionary (index 0001h – 025Fh) describes the data types that can be accessed at a CANopen network device. They can be basic types, as integers and floats, or compound types formed by a set of entries, as records and arrays.

5.3 COMMUNICATION PROFILE - COMMUNICATION OBJECTS

The indexes from 1000h to 1FFFh in the object dictionary correspond to the part responsible for the CANopen network communication configuration. Those objects are common to all the devices, however only a few are obligatory. A list with the objects of this range that are supported by the frequency converter CFW300 is presented next.

Table 5.2: Object list – Communication Profile

Index	Object	Name	Type	Access
1000h	VAR	device type	UNSIGNED32	ro
1001h	VAR	error register	UNSIGNED8	ro
1005h	VAR	COB-ID SYNC	UNSIGNED32	rw
100Ch	VAR	guard time	UNSIGNED16	rw
100Dh	VAR	life time factor	UNSIGNED8	rw
1016h	ARRAY	consume heartbeat time	UNSIGNED32	rw
1017h	VAR	producer heartbeat time	UNSIGNED16	rw
1018h	RECORD	Identity Object	Identity	ro
Server SDO Parameter				
1200h	RECORD	1st Server SDO parameter	SDO Parameter	ro
Receive PDO Communication Parameter				
1400h	RECORD	1st receive PDO Parameter	PDO CommPar	rw
1401h	RECORD	2nd receive PDO Parameter	PDO CommPar	rw
Receive PDO Mapping Parameter				
1600	RECORD	1st receive PDO mapping	PDO Mapping	rw
1601	RECORD	2st receive PDO mapping	PDO Mapping	rw
Transmit PDO Communication Parameter				
1800h	RECORD	1st transmit PDO Parameter	PDO CommPar	rw
1801h	RECORD	2st transmit PDO Parameter	PDO CommPar	rw
Transmit PDO Mapping Parameter				
1A00h	RECORD	1st transmit PDO mapping	PDO Mapping	rw
1A01h	RECORD	1st transmit PDO mapping	PDO Mapping	rw

These objects can only be read and written via the CANopen network, it is not available via the keypad (HMI) or other network interface. The network master, in general, is the equipment responsible for setting up the equipment before starting the operation. The EDS configuration file brings the list of all supported communication objects.

Refer to item 6 for more details on the available objects in this range of the objects dictionary.

5.4 MANUFACTURER SPECIFIC – CFW300 SPECIFIC OBJECTS

For indexes from 2000h to 5FFFh, each manufacture is free to define which objects will be present, and also the type and function of each one. In the case of the CFW300, the whole list of parameters was made available in this object range. It is possible to operate the CFW300 by means of these parameters, carrying out any function that the inverter can execute. The parameters were made available starting from the index 2000h, and by adding their number to this index their position in the dictionary is obtained. The next table illustrates how the parameters are distributed in the object dictionary.

Table 5.3: CFW300 object list – Manufacturer Specific

Índice	Objeto	Nombre	Tipo	Acceso
2001h	VAR	P001 – Speed reference	INTEGER16	ro
2002h	VAR	P002 – Motor speed	INTEGER16	ro
2003h	VAR	P003 – Motor current	INTEGER16	ro
2004h	VAR	P004 – DC voltage	INTEGER16	ro
...
2064h	VAR	P100 – Acceleration time	INTEGER16	rw
2065h	VAR	P101 – Deceleration time	INTEGER16	rw
...

Refer to the CFW300 manual for a complete list of the parameters and their detailed description. In order to be able to program the inverter operation correctly via the CANopen network, it is necessary to know its operation through the parameters.

6 COMMUNICATION OBJECTS DESCRIPTION

This item describes in detail each of the communication objects available for the CFW300 frequency converter. It is necessary to know how to operate these objects to be able to use the available functions for the inverter communication.

6.1 IDENTIFICATION OBJECT

There is a set of objects in the dictionary which are used for equipment identification; however, they do not have influence on their behavior in the CANopen network.

6.1.1 Objeto 1000h - Device Type

This object gives a 32-bit code that describes the type of object and its functionality.

Index	Sub-index	Name	Type	Access	PDO Mapping	Value
1000h	0	Device Type	UNSIGNED32	RO	No	0

This code can be divided into two parts: 16 low-order bits describing the type of profile that the device uses, and 16 high-order bits indicating a specific function according to the specified profile.

6.1.2 Objeto 1001h - Error Register

This object indicates whether or not an error in the device occurred. The type of error registered for the frequency converter follows what is described in the table 6.1.

Index	Sub-index	Name	Type	Access	PDO Mapping	Value
1001h	0	Error register	UNSIGNED8	RO	yes	0

Table 6.1: Structure of the object Error Register

Bit	Meaning
0	Generic error
1	Current
2	Voltage
3	Temperature
4	Communication
5	Reserved (always 0)
6	Reserved (always 0)
7	Specific of the manufacturer

If the device presents any error, the equivalent bit must be activated. The first bit (generic error) must be activated with any error condition.

6.1.3 Objeto 1018h - Identity Object

It brings general information about the device.

Index	Sub-index	Name	Type	Access	PDO Mapping	Value
1018h	0	Number of the last sub-index	UNSIGNED8	RO	No	4
	1	Vendor ID	UNSIGNED32	RO	No	0000.0123h
	2	Product code	UNSIGNED32	RO	No	0000.0A00h
	3	Revision number	UNSIGNED32	RO	No	According to the equipment firmware version
	4	Serial number	UNSIGNED32	RO	No	Different for every CFW300

The vendor ID is the number that identifies the manufacturer at the CiA. The product code is defined by the manufacturer according to the type of product. The revision number represents the equipment firmware version. The sub-index 4 is a unique serial number for each frequency converter CFW300 in CANopen network.

6.2 SERVICE DATA OBJECTS - SDOs

The SDOs are responsible for the direct access to the object dictionary of a specific device in the network. They are used for the configuration and therefore have low priority, since they do not have to be used for communicating data necessary for the device operation.

There are two types of SDOs: client and server. Basically, the communication initiates with the client (usually the master of the network) making a read (upload) or write (download) request to a server, and then this server answers the request.




Figure 6.1: Communication between SDO client and server

6.2.1 Objeto 1200h - SDO Server

The frequency converter CFW300 has only one SDO of the server type, which makes it possible the access to its entire object dictionary. Through it, an SDO client can configure the communication, the parameters and the drive operation. Every SDO server has an object, of the SDO_PARAMETER type, for its configuration, having the following structure:

Index	Sub-index	Name	Type	Access	PDO Mapping	Value
1200h	0	Number of the last sub-index	UNSIGNED8	RO	No	2
	1	COB-ID Cliente - Server (rx)	UNSIGNED32	RO	No	600h + Node-ID
	2	COB-ID Servidor - Client (tx)	UNSIGNED32	RO	No	580h + Node-ID

6.2.2 SDOs Operation

A telegram sent by an SDO has an 8 byte size, with the following structure:

Identifier	8 data bytes							
11 bits	Command	Index		Subindex	Object data			
	byte 0	byte 1	byte 2	byte 3	byte 4	byte 5	byte 6	byte 7

The identifier depends on the transmission direction (rx or tx) and on the address (or Node-ID) of the destination server. For instance, a client that makes a request to a server which Node-ID is 1, must send a message with the identifier 601h. The server will receive this message and answer with a telegram which COB-ID is equal to 581h.

The command code depends on the used function type. For the transmissions from a client to a server, the following commands can be used:

Table 6.2: Command codes for SDO client

Command	Function	Description	Object Data
22h	Download	Write object	Not defined
23h	Download	Write object	4 byte
2Bh	Download	Write object	2 byte
2Fh	Download	Write object	1 byte
40h	Upload	Read object	Not used
60h ou 70h	Upload segment	Segmented read	Not used

When making a request, the client will indicate through its COB-ID, the address of the slave to which this request is destined. Only a slave (using its respective SDO server) will be able to answer the received telegram to the client. The answer telegram will have also the same structure of the request telegram, the commands however are different:

Table 6.3: Command codes for SDO server

Command	Function	Description	Object Data
60h	Download	Write object	Not used
43h	Upload	Write object	4 byte
4Bh	Upload	Write object	2 byte
4Fh	Upload	Write object	1 byte
41h	Upload segment	Initiates segmented response for read	4 byte
01h ou 0Dh	Upload segment	Last data segment for read	8 ... 2 bytes

For readings of up to four data bytes, a single message can be transmitted by the server; for the reading of a bigger quantity of bytes, it is necessary that the client and the server exchange multiple telegrams.

A telegram is only completed after the acknowledgement of the server to the request of the client. If any error is detected during telegram exchanges (for instance, no answer from the server), the client will be able to abort the process by means of a warning message with the command code equal to 80h.



NOTE!

When the SDO is used for writing in objects that represent the CFW300 parameters (objects starting from the index 2000h), this value is saved in the nonvolatile frequency inverter memory. Therefore, the configured values are not lost after the equipment is switched off or reset. For all the other objects these values are not saved automatically, so that it is necessary to rewrite the desired values.

E.g.: A client SDO requests for a CFW300 at address 1 the reading of the object identified by the index 2000h, sub-index 0 (zero), which represents an 16-bit integer. The master telegram has the following format:

Identifier	Command	Index	Subindex	Data
601h	40h	00h	20h	00h 00h 00h 00h

The CFW300 responds to the request indicating that the value of the referred object is equal to 999⁶:

⁶Do not forget that for any integer type of data, the byte transfer order is from the least significant to the most significant.

Identifier	Command	Index		Subindex	Data			
581h	4Bh	00h	20h	00h	E7h	03h	00h	00h

6.3 PROCESS DATA OBJECTS - PDOS

The PDOs are used to send and receive data used during the device operation, which must often be transmitted in a fast and efficient manner. Therefore, they have a higher priority than the SDOs.

In the PDOs only data are transmitted in the telegram (index and sub-index are omitted), and in this way it is possible to do a more efficient transmission, with larger volume of data in a single telegram. However it is necessary to configure previously what is being transmitted by the PDO, so that even without the indication of the index and sub-index, it is possible to know the content of the telegram.

There are two types of PDOs, the receive PDO and the transmit PDO. The transmit PDOs are responsible for sending data to the network, whereas the receive PDOs remain responsible for receiving and handling these data. In this way it is possible to have communication among slaves of the CANopen network, it is only necessary to configure one slave to transmit information and one or more slaves to receive this information.




Figure 6.2: Communication using PDOs



NOTE!

PDOs can only be transmitted or received when the device is in the operational state. The Figure 6.2 illustrates the available states for CANopen network node.

6.3.1 PDO Mapping Objects

In order to be able to be transmitted by a PDO, it is necessary that an object be mapped into this PDO content. In the description of communication objects (1000h – 1FFFh), the file “PDO Mapping” informs this possibility. Usually only information necessary for the operation of the device can be mapped, such as enabling commands, device status, reference, etc. Information on the device configuration are not accessible through PDOs, and if it is necessary to access them one must use the SDOs.

For CFW300 specific objects (2000h – 5FFFh), the next table presents some PDO mapping objects. Read-only parameters (ro) can be used only by transmit PDOs, whereas the other parameters can be used only by receive PDOs. The CFW300 EDS file brings the list of all the objects available for the inverter, informing whether the object can be mapped or not.

Table 6.4: Examples of PDO mapping parameters

Index	Object	Name	Type	Access
2002h	VAR	P002 – Motor speed	UNSIGNED16	ro
2003h	VAR	P003 – Motor current	UNSIGNED16	ro
2005h	VAR	P005 – Motor frequency	UNSIGNED16	ro
2006h	VAR	P006 – Inverter status	UNSIGNED16	ro
2007h	VAR	P007 – Output voltage	UNSIGNED16	ro
2009h	VAR	P009 – Motor torque	INTEGER16	ro
200Ch	VAR	P012 – DI1 to DI8 status	UNSIGNED16	ro
2012h	VAR	P018 – AI1 value	INTEGER16	ro
2064h	VAR	P100 – Acceleration time	UNSIGNED16	rw
2065h	VAR	P101 – Deceleration time	UNSIGNED16	rw
22A8h	VAR	P680 – Logical status	UNSIGNED16	ro
22A9h	VAR	P681 – Motor speed in 13 bits	INTEGER16	ro
22ACh	VAR	P684 – Control CANopen/DNet	UNSIGNED16	rw
22ADh	VAR	P685 – Speed reference CANopen/DNet	INTEGER16	rw

The EDS file brings the list of all available objects informing whether the object can be mapped or not.

6.3.2 Receive PDOs

The receive PDOs, or RPDOs, are responsible for receiving data that other devices send to the CANopen network. The frequency converter CFW300 has receive PDOs, each one being able to receive up to 8 bytes. Each RPDO has two parameters for its configuration, a PDO_COMM_PARAMETER and a PDO_MAPPING, as described next.

PDO_COMM_PARAMETER

Index	Sub index	Name	Type	Access	PDO Mapping	Value
1400h até 1401h	0	Number of the last sub-index	UNSIGNED8	RO	No	2
	1	COB-ID used by the PDO	UNSIGNED32	RW	No	200h/300h + Node-ID
	2	Transmission Type	UNSIGNED8	RW	No	254

The sub-index 1 contains the receive PDO COB-ID. Every time a message is sent to the network, this object will read the COB-ID of that message and, if it is equal to the value of this field, the message will be received by the device. This field is formed by an UNSIGNED32 with the following structure:

Table 6.5: COB-ID description

Bit	Value	Description
31 (MSB)	0	PDO is enabled
	1	PDO is disabled
30	0	RTR permitted
29	0	Identifier size = 11 bits
28 - 11	0	Not used, always 0
10 - 0 (LSB)	X	11-bit COB-ID

The bit 31 allows enabling or disabling the PDO. The bits 29 and 30 must be kept in 0 (zero), they indicate respectively that the PDO accepts remote frames (RTR frames) and that it uses an 11-bit identifier. Since the CFW300 frequency converter does not use 29-bit identifiers, the bits from 28 to 11 must be kept in 0 (zero), whereas the bits from 10 to 0 (zero) are used to configure the COB-ID for the PDO.

The sub-index 2 indicates the transmission type of this object, according to the next table.

Table 6.6: Descrição do tipo de transmissão

Type of transmission	PDOs transmission				
	Cyclic	Acyclic	Synchronous	Asynchronous	RTR
0		•	•		
1 - 240	•		•		
241 - 251	Reserved				
252			•		•
253				•	•
254				•	
255				•	

- **Values 0 – 240:** any RPDO programmed in this range presents the same performance. When detecting a message, it will receive the data; however it won't update the received values until detecting the next SYNC telegram.
- **Values 252 e 253:** not allowed for receive PDOs.
- **Values 254 e 255:** they indicated that there is no relationship with the synchronization object. When receiving a message, its values are updated immediately.

PDO_MAPPING

Index	Sub index	Name	Type	Access	PDO Mapping	Value
1600h até 1601h	0	Number of mapped objects	0 = disable 1-4=number of mapped objects	RO	No	0
	1 up to	1 up to object mapped in the PDO	UNSIGNED32	RW	No	According EDS file

This parameter indicates the mapped objects in the CFW300 receive PDOs. It is possible to map up to different objects for each RPDO, provided that the total length does not exceed eight bytes. The mapping of an object is done indicating its index, sub-index ⁷ and size (in bits) in an UNSIGNED32, field with the following format:

UNSIGNED32		
Index (16 bits)	Sub index (8 bits)	Objects size (8 bits)

For instance, analyzing the receive PDO standard mapping, we have:

- **Sub index 0 = 2:** This PDO has two mapped objects.
- **Sub index 1 = 22AC.0010h:** the first mapped object has an index equal to 22A8h, sub-index 0 (zero), and a size of 16 bits. This object corresponds to the parameter P0680 that is inverter status.
- **Sub index 2 = 22AD.0010h:** the second mapped object has an index equal to 22A9h, sub-index 0 (zero), and a size of 16 bits. This object corresponds to the parameter P0681 that is motor speed.

It is possible to modify this mapping by changing the quantity or the number of mapped objects. Remembering that only 4 objects or 8 bytes can be mapped at maximum.


NOTE!

- In order to change the mapped objects in a PDO, it is first necessary to write the value 0 (zero) in the sub-index 0 (zero). In that way the values of the sub-indexes 1 to can be changed. After the desired mapping has been done, one must write again in the sub-index 0 (zero) the number of objects that have been mapped, enabling again the PDO.
- Do not forget that PDOs can only be received if the CFW300 is in the operational state.

⁷If the object is of the VAR type and does not have sub-index, the value 0 (zero) must be indicated for the sub-index.

6.3.3 Transmit PDOs

The transmit PDOs, or TPDOs, as the name says, are responsible for transmitting data for the CANopen network. The frequency converter CFW300 has 2 transmit PDOs, each one being able to transmit up to 8 data bytes. In a manner similar to RPDOs, each TPDO has two parameters for its configuration, a PDO_COMM_PARAMETER and a PDO_MAPPING, as described next.

PDO_COMM_PARAMETER

Index	Subindex	Name	Type	Access	PDO Mapping	Value
1800h-1801h	0	Number of the last sub-index	UNSIGNED8	RO	No	5
	1	COB-ID used by the PDO	UNSIGNED32	RW	No	180h/280h + Node-ID
	2	Transmission Type	UNSIGNED8	RW	No	254
	3	Time between transmissions	UNSIGNED16	RW	No	-
	4	Reserved	UNSIGNED8	RW	No	-
	5	Event timer	UNSIGNED16	RW	No	0

The sub-index 1 contains the transmit PDO COB-ID. Every time this PDO sends a message to the network, the identifier of that message will be this COB-ID. The structure of this field is described in table 6.5.

The sub-index 2 indicates the transmission type of this object, which follows the table 6.6 description. Its working is however different for transmit PDOs:

- **Value 0:** indicates that the transmission must occur immediately after the reception of a SYNC telegram, but not periodically.
- **Values 1 – 240:** the PDO must be transmitted at each detected SYNC telegram (or multiple occurrences of SYNC, according to the number chosen between 1 and 240).
- **Value 252:** indicates that the message content must be updated (but not sent) after the reception of a SYNC telegram. The transmission of the message must be done after the reception of a remote frame (RTR frame).
- **Value 253:** the PDO must update and send a message as soon as it receives a remote frame.
- **Value 254:** The object must be transmitted according to the timer programmed in sub-index 5.
- **Value 255:** the object is transmitted automatically when the value of any of the objects mapped in this PDO is changed. It works by changing the state (Change of State). This type does also allow that the PDO be transmitted according to the timer programmed in sub-index 5.

In the sub-index 3 it is possible to program a minimum time (in multiples of 100µs) that must elapse after the a telegram has been sent, so that a new one can be sent by this PDO. The value 0 (zero) disables this function.

The sub-index 5 contains a value to enable a timer for the automatic sending of a PDO. Therefore, whenever a PDO is configured as the asynchronous type, it is possible to program the value of this timer (in multiples of 1ms), so that the PDO is transmitted periodically in the programmed time.



NOTE!

- The value of this timer must be programmed according to the used transmission rate. Very short times (close to the transmission time of the telegram) are able to monopolize the bus, causing indefinite retransmission of the PDO, and avoiding that other less priority objects transmit their data
- The minimum time allowed for this Function in the frequency converter CFW300 is 2ms.
- It is important to observe the time between transmissions programmed in the sub-index 3, especially when the PDO is programmed with the value 255 in the sub-index 2 (Change of State).
- Do not forget that PDOs can only be received if the CFW300 is in the operational state.

PDO_MAPPING

Index	Subindex	Name	Type	Access	PDO Mapping	Value
1A00h-1A01h	0	Number of the last sub-index	UNSIGNED8	RO	No	0
	1 - 4	1 up to 4 object mapped in the PDO	UNSIGNED32	RW	No	0

The PDO MAPPING for the transmission works in similar way than for the reception, however in this case the data to be transmitted by the PDO are defined. Each mapped object must be put in the list according to the description showed next:

UNSIGNED32		
Index (16 bits)	Subindex (8 bits)	Object size (8 bits)

For instance, analyzing the standard mapping of the fourth transmit PDO, we have:

- **Sub-índice 0 = 2:** This PDO has two mapped objects.
- **Sub-índice 1 = 22A8.0010h:** the first mapped object has an index equal to 22A8h, sub-index 0 (zero), and a size of 16 bits. This object corresponds to the parameter P0680 that is inverter status.
- **Sub-índice 2 = 22A9.0010h:** the second mapped object has an index equal to 22A9h, sub-index 0 (zero), and a size of 16 bits. This object corresponds to the parameter P0681 that is motor speed.

It is possible to modify this mapping by changing the quantity or the number of mapped objects. Remember that a maximum of 4 objects or 8 bytes can be mapped.



NOTE!

In order to change the mapped objects in a PDO, it is first necessary to write the value 0 (zero) in the sub-index 0 (zero). In that way the values of the sub-indexes 1 to 4 can be changed. After the desired mapping has been done, one must write again in the sub-index 0 (zero) the number of objects that have been mapped, enabling again the PDO.

6.4 SYNCHRONIZATION OBJECT - SYNC

This object is transmitted with the purpose of allowing the synchronization of events among the CANopen network devices. It is transmitted by a SYNC producer, and the devices that detect its transmission are named SYNC consumers

The frequency converter CFW300 has the function of a SYNC consumer and, therefore, it can program its PDOs to be synchronous. As described in table 6.6, synchronous PDOs are those related to the synchronization object, thus they can be programmed to be transmitted or updated based in this object.




Figure 6.3: SYNC

The SYNC message transmitted by the producer does not have any data in its data field, because its purpose is to provide a time base for the other objects. There is an object in the CFW300 for the configuration of the COB-ID of the SYNC consumer.

Index	Subindex	Name	Type	Access	PDO Mapping	Value
1015h	0	COB-ID SYNC	UNSIGNED32	RW	No	80h


NOTE!

The period of the SYNC telegrams must be programmed in the producer according to the transmission rate and the number of synchronous PDOs to be transmitted. There must be enough time for the transmission of these objects, and it is also recommended that there is a tolerance to make it possible the transmission of asynchronous messages, such as EMCY, asynchronous PDOs and SDOs.

6.5 NETWORK MANAGEMENT - NMT

The network management object is responsible for a series of services that control the communication of the device in a CANopen network. For the CFW300 the services of node control and error control are available (using Node Guarding or Heartbeat).

6.5.1 Slave State Control

With respect to the communication, a CANopen network device can be described by the following state machine:




Figure 6.4: CANopen node state diagram

Table 6.7: Transitions Description

Transition	Description
1	The device is switched on and initiates the initialization (automatic)
2	Initialization concluded, it goes to the preoperational state (automatic)
3	It receives the Start Node command for entering the operational state
4	It receives the Enter Pre-Operational command, and goes to the preoperational state
5	It receives the Stop Node command for entering the stopped state
6	It receives the Reset Node command, when it executes the device complete reset
7	It receives the Reset Communication command, when it reinitializes the object values and the CANopen device communication

During the initialization the Node-ID is defined, the objects are created and the interface with the CAN network is configured. Communication with the device is not possible during this stage, which is concluded automatically. At the end of this stage the slave sends to the network a telegram of the Boot-up Object, used only to indicate that the initialization has been concluded and that the slave has entered the preoperational state. This telegram has the identifier 700h + Node-ID, and only one data byte with value equal to 0 (zero).

In the preoperational state it is already possible to communicate with the slave, but its PDOs are not yet available for operation. In the operational state all the objects are available, whereas in the stopped state only the NMT object can receive or transmit telegrams to the network. The next table shows the objects available for each state.

Table 6.8: Objects accessible in each state

	Initialization	Préoperational	Operational	Stopped
PDO			•	
SDO		•	•	
SYNC		•	•	
EMCY		•	•	
Boot-up	•			
NMT		•	•	•

This state machine is controlled by the network master, which sends to each slave the commands so that the desired state change be executed. These telegrams do not have confirmation, what means that the slave does only receive the telegram without returning an answer to the master. The received telegrams have the following structure:

Identifier	byte 1	byte 2
00h	Command Code	Destination Node-ID

Table 6.9: Commands for the state transition

Command Code	Destination Node ID
1 = START node (transition 3)	0 = All the slaves
2 = STOP node (transition 4)	1 ... 127 = Specific slave
128 = Enter preoperational (transition 5)	
129 = Reset node (transition 6)	
130 = Reset communication (transition 7)	

The transitions indicated in the command code correspond to the state transitions executed by the node after receiving the command (according to the Figure 6.4). The Reset node command makes the CFW300 execute a complete reset of the device, while the Reset communication command causes the device to reinitialize only the objects pertinent to the CANopen communication.

6.5.2 Error Control - Node Guarding

This service is used to make it possible the monitoring of the communication with the CANopen network, both by the master and the slave as well. In this type of service the master sends periodical telegrams to the slave, which responds to the received telegram. If some error that interrupts the communication occurs, it will be possible to identify this error, because the master as well as the slave will be notified by the Timeout in the execution of this service. The error events are called Node Guarding for the master and Life Guarding for the slave.




Figure 6.5: Error control service – Node Guarding

There are two objects of the dictionary for the configuration of the error detection times for the Node Guarding service:

Index	Sub index	Name	Type	Access	PDO Mapping	Value
100Ch	0	Guard Time	UNSIGNED32	RW	No	0

Index	Sub index	Name	Type	Access	PDO Mapping	Value
100Dh	0	Life Time Factor	UNSIGNED8	RW	No	0

The 100Ch object allows programming the time necessary (in milliseconds) for a fault occurrence being detected, in case the CFW300 does not receive any telegram from the master. The 100Dh object indicates how many faults in sequence are necessary until it be considered that there was really a communication error. Therefore, the multiplication of these two values will result in the total necessary time for the communication error detection using this object. The value 0 (zero) disables this function.

Once configured, the CFW300 starts counting these times starting from the first Node Guarding telegram received from the network master. The master telegram is of the remote type, not having data bytes. The identifier is equal to 700h + Node-ID of the destination slave. However the slave response telegram has 1 data byte with the following structure:

Identificador	byte 1	
	bit 7	bit 6 ... 0
700h + Node ID	Toogle	Estado do Escravo

This telegram has one single data byte. This byte contains, in the seven least significant bits, a value to indicate the slave state (4 = stopped, 5 = operational and 127 = preoperational), and in the eighth bit, a value that must be changed at every telegram sent by the slave (toggle bit).



NOTE!

- This object is active even in the stopped state (see table 6.8).
- The value 0 (zero) in any of these two objects will disable this function.
- If after the error detection the service is enabled again, then the error indication will be removed from the HMI.
- The minimum value accepted by the CFW300 is 2ms, but considering the transmission rate and the number of nodes in the network, the times programmed for this function must be consistent, so that there is enough time for the transmission of the telegrams and also that the rest of the communication be able to be processed.
- For any every slave only one of the two services - Heartbeat or Node Guarding – can be enabled.

6.5.3 Error Control - Heartbeat

The error detection through the Heartbeat mechanism is done using two types of objects: the Heartbeat producer and the Heartbeat consumer. The producer is responsible for sending periodic telegrams to the network, simulating a heartbeat, indicating that the communication is active and without errors. One or more consumers can monitor these periodic telegrams, and if they cease occurring, it means that any communication problem occurred.




Figure 6.6: Error control service – Heartbeat

One device of the network can be both producer and consumer of heartbeat messages. For example, the network master can consume messages sent by a slave, making it possible to detect communication problems with the master, and simultaneously the slave can consume heartbeat messages sent by the master, also making it possible to the slave detect communication fault with the master.

The CFW300 has the producer and consumer of heartbeat services. As a consumer, it is possible to program up to 4 different producers to be monitored by the inverter.

Index	Sub index	Name	Type	Access	PDO Mapping	Value
1016h	0	Number of the last sub-index	UNSIGNED8	RO	No	4
	1 - 4	Consumer Heartbeat Time 1 – 4	UNSIGNED32	RW	No	0

At sub-indexes 1 to , it is possible to program the consumer by writing a value with the following format:

UNSIGNED32		
Reserved (8 bits)	Node-ID (8 bits)	HeartBeat time (16 bits)

- Node-ID: it allows programming the Node-ID for the heartbeat producer to be monitored.
- Heartbeat time: it allows programming the time, in 1 millisecond multiples, until the error detection if no message of the producer is received. The value 0 (zero) in this field disables the consumer.

Once configured, the heartbeat consumer initiates the monitoring after the reception of the first telegram sent by the producer. In case that an error is detected because the consumer stopped receiving messages from the heartbeat producer, the frequency converter will turn automatically to the preoperational state and indicate .

As a producer, the frequency converter CFW300 has an object for the configuration of that service:

Index	Sub index	Name	Type	Access	PDO Mapping	Value
1017h	0	Producer Heartbeat Time	UNSIGNED8	RW	No	0

The 1017h object allows programming the time in milliseconds during which the producer has to send a heartbeat telegram to the network. Once programmed, the inverter initiates the transmission of messages with the following format:

Identifier	byte 1	
	bit 7	bit 6 ... 0
700h + Node ID	Always 0	Slave State


NOTE!

- This object is active even in the stopped state (see table 6.8).
- The value 0 (zero) in any of these two objects will disable this function.
- If after the error detection the service is enabled again, then the error indication will be removed from the HMI.
- The minimum value accepted by the CFW300 is 2ms, but considering the transmission rate and the number of nodes in the network, the times programmed for this function must be consistent, so that there is enough time for the transmission of the telegrams and also that the rest of the communication be able to be processed.
- For any every slave only one of the two services - Heartbeat or Node Guarding – can be enabled.

6.6 INITIALIZATION PROCEDURE

Once the operation of the objects available for the frequency converter CFW300 is known, then it becomes necessary to program the different objects to operate combined in the network. In a general manner, the procedure for the initialization of the objects in a CANopen network follows the description of the next flowchart:




Figure 6.7: Initialization process flowchart

It is necessary to observe that the frequency converter CFW300 communication objects (1000h to 1FFFh) are not stored in the nonvolatile memory. Therefore, every time the equipment is reset or switched off, it is necessary to redo the communication objects parameter setting.

7 FAULTS AND ALARMS

A133/F233 - CAN INTERFACE WITHOUT POWER SUPPLY

Description:

It indicates that the CAN interface does not have power supply between the pins 25 and 29 of the connector.

Actuation:

In order that it be possible to send and receive telegrams through the CAN interface, it is necessary to supply external power to the interface circuit.

If the CAN interface is connected to the power supply and the absence of power is detected, the alarm A133 – or the fault F233, depending on the P313 programming, will be signaled through the HMI. If the circuit power supply is reestablished, the CAN communication will be reinitiated. In case of alarms, the alarm indication will also be removed from the HMI.

Possible Causes/Correction:

- Measure the voltage between the pins 6 and 10 of the CAN interface connector.
- Verify if the power supply cables have not been changed or inverted.
- Make sure there is no contact problem in the cable or in the CAN interface connector.

A134/F234- BUS OFF

Description:

The bus off error in the CAN interface has been detected.

Actuation:

If the number of reception or transmission errors detected by the CAN interface is too high , the CAN controller can be taken to the bus off state, where it interrupts the communication and disables the CAN interface.

In this case the alarm A134 – or the fault F234, depending on the P0313 programming, will be signaled through the HMI. In order that the communication be reestablished, it will be necessary to cycle the power of the product, or remove the power supply from the CAN interface and apply it again, so that the communication be reinitiated.

Possibles Causes/Correction:

- Verify if there is any short-circuit between the CAN circuit transmission cables.
- Verify if the cables have not been changed or inverted.
- Verify if all the network devices use the same baud rate.
- Verify if termination resistors with the correct values were installed only at the extremes of the main bus.
- Verify if the CAN network installation was carried out in proper manner.

A137/F237 - DEVICENET CONNECTION TIMEOUT

Description:

It is the alarm that indicates that one or more DeviceNet I/O connections have expired.

Actuation:

It occurs when, for any reason, after the cyclic communication of the master with the product is started, this communication is interrupted.

In this case the alarm A137 – or the fault F237, depending on the P0313 programming, will be signalized through the HMI. In case of alarms, if the connection with the master is reestablished, the alarm indication will be removed from the HMI.

Possíveis Causas/Correção:

- Check the status of the network master.
- Check the network installation, broken cable or failed/bad contact in the network connections.



WEG Drives & Controls - Automação LTDA.
Jaraguá do Sul – SC – Brazil
Phone 55 (47) 3276-4000 – Fax 55 (47) 3276-4020
São Paulo – SP – Brazil
Phone 55 (11) 5053-2300 – Fax 55 (11) 5052-4212
automacao@weg.net
www.weg.net