

Frequency Inverter

MVW3000 V3.04.XX

Programming Manual



Programming Manual

MVW3000

Software version: 3.04.XX

Document: 10013119048

Revision: 03

Date: 07/2026

SUMMARY OF REVISIONS

The information below describes the reviews made in this manual.

Version	Revision	Description
3.02.XX	R00	First edition
3.02.XX	R01	Support for up to 6 thermal protection relays
3.03.XX	R02	Thermal relay status monitoring Arc fault configuration Scalar control for permanent magnet motors

1	PARAMETER STRUCTURE	1-1
2	FAULTS AND ALARMS	2-1
2.1	FAULT AND ALARM TABLE	2-1
3	SAFETY INSTRUCTIONS	3-1
3.1	SAFETY NOTICES IN THE MANUAL	3-1
3.2	SAFETY NOTICES ON THE PRODUCT	3-1
3.3	PRELIMINARY RECOMMENDATIONS	3-1
4	ABOUT THIS MANUAL	4-1
4.1	TERMINOLOGY AND DEFINITIONS	4-1
4.1.1	Terms and definitions used in this manual	4-1
5	ABOUT THE MVW	5-1
5.1	AVAILABLE MODELS	5-1
6	SOFTWARE VERSIONS	6-1
7	S STATUS	7-1
S1	INVERTER	7-1
S1.1	Status	7-1
S1.2	Software version	7-3
S1.4	Accessory data	7-3
S1.5	Date/Hour	7-4
S1.6	Control words	7-5
S1.8	Cells	7-7
S1.9	Thermal protection relay	7-9
S2	MEASUREMENTS	7-10
S2.1	Motor speed	7-10
S2.2	Motor torque	7-10
S2.3	Inverter output	7-11
S2.4	Temperatures	7-12
S2.6	Inverter input	7-14
S2.7	DC link	7-15
S2.8	Torque current limitation	7-16
S3	I/OS	7-16
S3.1	Slot X status	7-16
S3.1.1	Analog inputs	7-16
S3.1.2	Analog outputs	7-17
S3.1.3	Digital inputs	7-17
S3.1.4	Digital outputs	7-18
S3.2	Slot A status	7-18
S3.2.1	Analog inputs	7-19
S3.2.2	Analog outputs	7-19
S3.2.3	Digital inputs	7-20
S3.2.4	Digital outputs	7-21
S3.2.6	Temperatures	7-22
S3.9	Control board	7-22
S3.9.1	Analog inputs	7-22
S3.9.2	Analog outputs	7-22
S3.9.3	Digital inputs	7-23
S3.9.4	Digital outputs	7-23
S3.9.5	Encoder	7-24
S5	COMMUNICATIONS	7-24

CONTENTS

S5.1 Status and commands	7-25
S5.2 Serial RS485	7-26
S5.3 Ethernet	7-28
S5.4 EtherNet/IP	7-30
S5.5 Modbus TCP	7-31
S5.6 Anybus	7-32
S5.7 CAN/CANopen/DNet	7-33
S6 SOFTPLC	7-36
S6.1 Program execution	7-36
S6.2 Control and references	7-36
8 D DIAGNOSTICS	8-1
D1 FAULTS	8-1
D2 ALARMS	8-3
D3 HOUR CONTROL	8-5
D4 INVERTER AND ACCESS.	8-5
D4.1 Inverter	8-5
D4.2 Accessories	8-7
9 C CONFIGURATIONS	9-1
C1 INVERTER AND POWER SUPPLY	9-1
C1.2 Inverter use	9-1
C1.6 Other inverter settings	9-3
C1.7 Control accessories	9-4
C1.8 Measurements	9-4
C1.9 Precharge	9-5
C1.10 Calibrations	9-7
C2 MOTOR	9-7
C2.1 Motor data	9-8
C2.2 Motor model	9-10
C3 CONTROL	9-11
C3.1 Configuration	9-11
C3.2 Scalar control	9-12
C3.3 Vector control	9-22
C3.4 Current limiter	9-31
C3.5 DC link	9-32
C3.8 Flying Start	9-36
C3.9 Ride-Through	9-38
C3.11 Synchronous transfer	9-41
C3.12 Bypass	9-44
C3.14 Zero speed disable	9-46
C4 COMMANDS AND REFERENCES	9-47
C4.1 LOC/REM mode config.	9-47
C4.2 Commands	9-49
C4.3 References	9-57
C5 I/OS	9-66
C5.1 Slot X	9-66
C5.1.1 Analog inputs	9-66
C5.1.2 Analog outputs	9-69
C5.1.3 Digital inputs	9-72
C5.1.4 Digital outputs	9-73
C5.1.5 Encoder	9-78
C5.2 Slot A	9-78
C5.9 DO operation levels	9-88
C5.10 DOs delay	9-90
C5.11 Control board	9-91
C5.11.1 Analog inputs	9-91

C5.11.2 Analog outputs	9-92
C5.11.4 Encoder	9-93
C6 RAMPS	9-95
C6.1 Speed control	9-95
C6.2 Torque control	9-97
C7 PROTECTIONS	9-98
C7.1 Power supply	9-98
C7.2 Ground fault	9-98
C7.3 Motor current	9-99
C7.4 Motor overload fault	9-100
C7.5 Over/Undertemperature	9-102
C7.6 DC link	9-102
C7.7 Motor overspeed	9-102
C7.9 Fault Auto-Reset	9-103
C7.10 External fault/Alarm	9-103
C7.11 Thermal management	9-104
C7.13 Input transformer	9-105
C7.15 Electric arc	9-106
C7.16 History	9-107
C9 COMMUNICATIONS	9-107
C9.1 Communication errors	9-107
C9.2 I/O data	9-109
C9.3 Serial RS485	9-110
C9.4 Ethernet	9-111
C9.5 EtherNet/IP	9-114
C9.6 Modbus TCP	9-115
C9.7 Anybus	9-116
C9.8 CAN/CANopen/DNet	9-118
C9.10 SymbiNet	9-121
C9.11 BACnet	9-128
C10 SOFTPLC	9-130
C10.1 Configuration	9-130
C10.2 Engineering unit	9-131
C12 BACKUP	9-133
C13 NOMINAL DATA	9-136
C13.1 Inverter	9-136
C13.2 Transformer	9-137
10 A APPLICATION	10-1
A1 USER PARAMETERS	10-1
A2 PID CONTROLLER	10-1
A2.1 Monitoring	10-2
A2.2 Regulation	10-4
A2.2.1 Setpoint	10-4
A2.2.2 Ganhos	10-4
A2.3 Configuration	10-5
A2.3.1 Control	10-5
A2.3.2 Setpoint	10-6
A2.3.3 Process variable	10-6
A2.3.4 Operation mode	10-8
A2.3.5 Command sources	10-9
A2.3.6 Faults and Alarms	10-19
A2.3.7 Sleep mode	10-20
A3 MILL	10-23
A3.1 Configurations	10-23
A3.2 Frozen charge detection	10-24
A3.3 Frozen charge release	10-27

1 PARAMETER STRUCTURE

S Status

- ─ S1 Inverter
 - ─ S1.1 Status
 - ─ S1.2 Software version
 - ─ S1.4 Accessory data
 - ─ S1.4.1 Backplane
 - ─ S1.4.2 Slot A
 - ─ S1.4.3 Slot B
 - ─ S1.4.4 Slot C
 - ─ S1.4.5 Slot D
 - ─ S1.4.6 Slot E
 - ─ S1.4.7 Slot F
 - ─ S1.4.8 Slot G
 - ─ S1.5 Date/Hour
 - ─ S1.6 Control words
 - ─ S1.8 Cells
 - ─ S1.9 Thermal protection relay
- ─ S2 Measurements
 - ─ S2.1 Motor speed
 - ─ S2.2 Motor torque
 - ─ S2.3 Inverter output
 - ─ S2.4 Temperatures
 - ─ S2.4.1 Overview
 - ─ S2.4.2 U phase
 - ─ S2.4.3 V phase
 - ─ S2.4.4 W phase
 - ─ S2.4.5 Thermal prot. relay 1
 - ─ S2.4.6 Thermal prot. relay 2
 - ─ S2.4.7 Thermal prot. relay 3
 - ─ S2.4.8 Thermal prot. relay 4
 - ─ S2.4.9 Thermal prot. relay 5
 - ─ S2.4.10 Thermal prot. relay 6
 - ─ S2.4.11 Temperature accessory
 - ─ S2.6 Inverter input
 - ─ S2.7 DC link
 - ─ S2.7.1 Overview
 - ─ S2.7.2 U phase
 - ─ S2.7.3 V phase
 - ─ S2.7.4 W phase
 - ─ S2.8 Torque current limitation
- ─ S3 I/Os
 - ─ S3.1 Slot X status
 - ─ S3.1.1 Analog inputs
 - ─ S3.1.2 Analog outputs

S Status (cont.)

- ─ S3 I/Os (cont.)
 - ─ S3.1 Slot X status (cont.)
 - ─ S3.1.3 Digital inputs
 - ─ S3.1.4 Digital outputs
 - ─ S3.2 Slot A status
 - ─ S3.2.1 Analog inputs
 - ─ S3.2.2 Analog outputs
 - ─ S3.2.3 Digital inputs
 - ─ S3.2.4 Digital outputs
 - ─ S3.2.6 Temperatures
 - ─ S3.3 Slot B status
 - ─ S3.4 Slot C status
 - ─ S3.5 Slot D status
 - ─ S3.6 Slot E status
 - ─ S3.7 Slot F status
 - ─ S3.8 Slot G status
 - ─ S3.9 Control board
 - ─ S3.9.1 Analog inputs
 - ─ S3.9.2 Analog outputs
 - ─ S3.9.3 Digital inputs
 - ─ S3.9.4 Digital outputs
 - ─ S3.9.5 Encoder
- ─ S5 Communications
 - ─ S5.1 Status and commands
 - ─ S5.2 Serial RS485
 - ─ S5.3 Ethernet
 - ─ S5.4 EtherNet/IP
 - ─ S5.5 Modbus TCP
 - ─ S5.6 Anybus
 - ─ S5.7 CAN/CANopen/DNet
- ─ S6 SoftPLC
 - ─ S6.1 Program execution
 - ─ S6.2 Control and references

D Diagnostics

- ─ D1 Faults
 - ─ D1.1 Current
 - ─ D1.3 History
- ─ D2 Alarms
 - ─ D2.1 Actual
 - ─ D2.3 History
- ─ D3 Hour control
- ─ D4 Inverter and access.

D Diagnostics (cont.)

- ─ D4 Inverter and access. (cont.)
 - ─ D4.1 Inverter
 - ─ D4.1.4 Control voltages
 - ─ D4.1.5 Mot.overl.fault
 - ─ D4.1.11 Configuration
 - ─ D4.1.12 Advanced
 - ─ D4.2 Accessories
 - ─ D4.2.1 Diag. Slot A
 - ─ D4.2.2 Diag. Slot B
 - ─ D4.2.3 Diag. Slot C
 - ─ D4.2.4 Diag. Slot D
 - ─ D4.2.5 Diag. Slot E
 - ─ D4.2.6 Diag. Slot F
 - ─ D4.2.7 Diag. Slot G

C Configurations

- ─ C1 Inverter and power supply
 - ─ C1.2 Inverter use
 - ─ C1.6 Other inverter settings
 - ─ C1.7 Control accessories
 - ─ C1.7.1 Slot A
 - ─ C1.7.2 Slot B
 - ─ C1.7.3 Slot C
 - ─ C1.7.4 Slot D
 - ─ C1.7.5 Slot E
 - ─ C1.7.6 Slot F
 - ─ C1.7.7 Slot G
 - ─ C1.8 Measurements
 - ─ C1.9 Precharge
 - ─ C1.10 Calibrations
- ─ C2 Motor
 - ─ C2.1 Motor data
 - ─ C2.2 Motor model
- ─ C3 Control
 - ─ C3.1 Configuration
 - ─ C3.2 Scalar control
 - ─ C3.2.1 V/f curve
 - ─ C3.2.2 Optimization
 - ─ C3.2.2.1 Induction motor
 - ─ C3.2.2.2 Permanent magnet sync.mot.
 - ─ C3.2.2.3 Sync.mot.external excitation
 - ─ C3.2.3 Current stabilization
 - ─ C3.2.4 Pre-magnetization

PARAMETER STRUCTURE

C Configurations (cont.)

- ─ C3 Control (cont.)
 - ─ C3.3 Vector control
 - ─ C3.3.1 Configuration
 - ─ C3.3.2 Regulators
 - ─ C3.3.2.1 Configuration
 - ─ C3.3.2.2 Speed regulator
 - ─ C3.3.2.3 Field weakening
 - ─ C3.3.2.4 Flux regulator
 - ─ C3.3.2.5 Current regulator
 - ─ C3.3.2.7 Speed estimator
 - ─ C3.3.4 Speed mode
 - ─ C3.3.4.1 Torque limiter
 - ─ C3.4 Current limiter
 - ─ C3.5 DC link
 - ─ C3.5.1 Voltage limit
 - ─ C3.5.3 Vector control
 - ─ C3.5.4 Modulation compensation
 - ─ C3.8 Flying Start
 - ─ C3.8.1 Configuration
 - ─ C3.8.2 Scalar control
 - ─ C3.8.3 Vector control
 - ─ C3.9 Ride-Through
 - ─ C3.9.1 Configuration
 - ─ C3.9.3 Vector control
 - ─ C3.11 Synchronous transfer
 - ─ C3.12 Bypass
 - ─ C3.14 Zero speed disable
- ─ C4 Commands and references
 - ─ C4.1 LOC/REM mode config.
 - ─ C4.2 Commands
 - ─ C4.2.1 Remote R1
 - ─ C4.2.2 Remote R2
 - ─ C4.2.3 DI for commands
 - ─ C4.2.4 Local HMI
 - ─ C4.3 References
 - ─ C4.3.1 Speed
 - ─ C4.3.1.1 Reference range
 - ─ C4.3.1.2 Reference source
 - ─ C4.3.1.3 Ref. HMI, Als and FIs
 - ─ C4.3.1.4 Electronic pot. ref.
 - ─ C4.3.1.5 Multispeed reference
 - ─ C4.3.1.6 Skip speed
 - ─ C4.3.2 JOG speed

C Configurations (cont.)

- ─ C4 Commands and references (cont.)
 - ─ C4.3 References (cont.)
 - ─ C4.3.3 Torque
- ─ C5 I/Os
 - ─ C5.1 Slot X
 - ─ C5.1.1 Analog inputs
 - ─ C5.1.2 Analog outputs
 - ─ C5.1.3 Digital inputs
 - ─ C5.1.4 Digital outputs
 - ─ C5.1.5 Encoder
 - ─ C5.2 Slot A
 - ─ C5.2.1 Analog inputs
 - ─ C5.2.2 Analog outputs
 - ─ C5.2.4 Digital outputs
 - ─ C5.2.5 Encoder
 - ─ C5.2.6 Temperatures
 - ─ C5.3 Slot B
 - ─ C5.3.1 Analog inputs
 - ─ C5.3.2 Analog outputs
 - ─ C5.3.4 Digital outputs
 - ─ C5.3.5 Encoder
 - ─ C5.3.6 Temperatures
 - ─ C5.4 Slot C
 - ─ C5.4.1 Analog inputs
 - ─ C5.4.2 Analog outputs
 - ─ C5.4.4 Digital outputs
 - ─ C5.4.5 Encoder
 - ─ C5.4.6 Temperatures
 - ─ C5.5 Slot D
 - ─ C5.5.1 Analog inputs
 - ─ C5.5.2 Analog outputs
 - ─ C5.5.4 Digital outputs
 - ─ C5.5.5 Encoder
 - ─ C5.5.6 Temperatures
 - ─ C5.6 Slot E
 - ─ C5.6.1 Analog inputs
 - ─ C5.6.2 Analog outputs
 - ─ C5.6.4 Digital outputs
 - ─ C5.6.5 Encoder
 - ─ C5.6.6 Temperatures
 - ─ C5.7 Slot F
 - ─ C5.7.1 Analog inputs
 - ─ C5.7.2 Analog outputs

C Configurations (cont.)

- ─ C5 I/Os (cont.)
 - ─ C5.7 Slot F (cont.)
 - ─ C5.7.4 Digital outputs
 - ─ C5.7.5 Encoder
 - ─ C5.7.6 Temperatures
 - ─ C5.8 Slot G
 - ─ C5.8.1 Analog inputs
 - ─ C5.8.2 Analog outputs
 - ─ C5.8.4 Digital outputs
 - ─ C5.8.5 Encoder
 - ─ C5.8.6 Temperatures
 - ─ C5.9 DO operation levels
 - ─ C5.10 DOs delay
 - ─ C5.11 Control board
 - ─ C5.11.1 Analog inputs
 - ─ C5.11.2 Analog outputs
 - ─ C5.11.4 Encoder
 - ─ C5.11.4.1 Absolute
 - ─ C5.11.4.2 Incremental
- ─ C6 Ramps
 - ─ C6.1 Speed control
 - ─ C6.2 Torque control
- ─ C7 Prot.
 - ─ C7.1 Power supply
 - ─ C7.2 Ground fault
 - ─ C7.3 Motor current
 - ─ C7.4 Motor overload fault
 - ─ C7.5 Over/Undertemperature
 - ─ C7.6 DC link
 - ─ C7.7 Motor overspeed
 - ─ C7.9 Fault Auto-Reset
 - ─ C7.10 External fault/Alarm
 - ─ C7.11 Thermal management
 - ─ C7.13 Input transformer
 - ─ C7.15 Electric arc
 - ─ C7.16 History
- ─ C9 Communications
 - ─ C9.1 Communication errors
 - ─ C9.1.1 Master offline
 - ─ C9.1.2 Master idle/Prog
 - ─ C9.2 I/O data
 - ─ C9.2.1 Reading data
 - ─ C9.2.2 Writing data

C Configurations (cont.)

- C9 Communications (cont.)
 - C9.3 Serial RS485
 - C9.4 Ethernet
 - C9.5 EtherNet/IP
 - C9.6 Modbus TCP
 - C9.7 Anybus
 - C9.8 CAN/CANopen/DNet
 - C9.10 SymbiNet
 - C9.11 BACnet
- C10 SoftPLC
 - C10.1 Configuration
 - C10.2 Engineering unit
- C12 Backup
- C13 Nominal data
 - C13.1 Inverter
 - C13.2 Transformer

A Application

- A1 User parameters
- A2 PID controller
 - A2.1 Monitoring
 - A2.2 Regulation
 - A2.2.1 Setpoint
 - A2.2.2 Ganhos
 - A2.3 Configuration
 - A2.3.1 Control
 - A2.3.2 Setpoint
 - A2.3.3 Process variable
 - A2.3.4 Operation mode
 - A2.3.5 Command sources
 - A2.3.6 Faults Alarms
 - A2.3.7 Sleep mode
- A3 Mill
 - A3.1 Configurations
 - A3.2 Frozen charge detection
 - A3.3 Frozen charge release

2 FAULTS AND ALARMS

Faults and Alarms are a functionality of the MVW that allows viewing events, helping troubleshooting or identifying improvements in the inverter parameter settings.

Actuation of Faults and Alarms:

- Faults actuate by disabling the motor and indicating on the HMI, in the MVW status word (S1.1.1) and in the diagnosis of actual fault (D1.1) the reason for its occurrence. They are only removed by resetting or turning off the inverter.
- The alarms actuate by displaying an indication on the HMI, in the MVW status word (S1.1.1) and the actual alarm diagnostics (D2.1). They are removed automatically after exiting the alarm condition.

Faults and Alarms are presented to the user through codes. The codes are made up of three or four numbers preceded by the letters F (for fault) and A (for alarm), as shown in [Table 2.1 on page 2-1](#). In this table it is also possible to obtain more details about its causes and possible solutions.



NOTE!

The cause of most of the faults and alarms can be checked and solved following the instructions in this chapter; otherwise, contact WEG technical support or a representative.

2.1 FAULT AND ALARM TABLE

Fault/Alarm	Description	Possible Causes
F0003: Under voltage / Phase loss	Inverter input voltage less than 70 %.	- Undervoltage in the power supply network. - Incorrect adjustment of the transformer primary taps.
A0008: Timeout in the synchronism with the input line	It was not possible to synchronize the inverter output voltage with the grid voltage.	
F0009: Incorrect status of the input circuit breaker	Incoherent wiring of DI3 and/or DI4 inputs on the PIC board.	- Improper maneuvering of the input circuit breaker. - Faulty input circuit breaker. - Faulty wiring.
F0013: Output contactor feedback	Output contactor failed to close or open.	- Defect in the DI6/DO8 connections of the output contactor drive and feedback function.
F0014: Input circuit breaker closing failure	Input circuit breaker does not close when commanded.	- Defective circuit breaker. - Wiring of the DI3 input of the PIC board (XC7:3) open (does not return +24 V) when closing the cubicle.
F0015: Input circuit breaker opening failure	Input circuit breaker does not open when commanded.	- Defective circuit breaker. - Wiring of the DI4 input of the PIC board (XC7:4) open (does not return +24 V) in the circuit breaker opening.
F0016: Shutdown by input circuit breaker protection	Actuation of the input circuit breaker protection related to the inverter main transformer.	- Wiring at input DI5 of the PIC board (XC7:5) open (does not return +24 V).
F0017: Inverter not ready to energize	Input circuit breaker not ready when commanded to close.	- Defective circuit breaker. - Attempt to turn on the circuit breaker via DI1, while the inverter is indicating via DO1 that it is not able to close the circuit breaker.
A0018: Inverter main transformer alarm	Alarm on the inverter main transformer.	- Wiring of input DI11 of the PIC board (XC7:16) open (does not return +24 V).
F0019: Inverter main transformer fault	Inverter main transformer failure.	- Wiring of the DI12 input of the PIC board (XC8:1) open (does not return +24 V).

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0020: Pre-charge fault	Voltages on the DC link did not rise to the level necessary to complete the pre-charge process within the specified time.	- Incorrect adjustment of the primary tap of the auxiliary transformer. - Low voltage or lack of phase in the auxiliary power supply. - Fault in the pre-charge circuit contactors. - Optical fiber communication of one of the cells not connected, broken or defective.
F0025: Inverter door locking fault	Attempt to energize the inverter with the panel doors unlocked.	- Unlocking the doors with the inverter enabled or with the DC link energized. - Wiring at DI16 input of PIC board (XC8:10) open (does not return +24 V with doors closed).
F0026: Input circuit breaker not ready fault	Input circuit breaker indicating via DI2 that it is not available for operation.	- Faulty input circuit breaker. - Wiring of the DI2 input of the PIC board (XC7:2) open (does not return +24 V).
F0027: Improper opening of the input circuit breaker	Command to open the input circuit breaker with the inverter enabled.	- Wiring of the DI1 input of the PIC board (XC7:1) open (does not return +24 V).
F0034: Sensor 1 - Electrical arcing detection fault	Arc flash detection by panel sensor 1.	- Optical fiber RX 26 of the CIB board of CN1 not connected, broken or defective.
F0035: Sensor 2 - Electrical arcing detection fault	Arc flash detection by panel sensor 2.	- Optical fiber RX 26 of the CN2 CIB board not connected, broken or defective.
F0036: Sensor 3 - Electrical arcing detection fault	Arc detection by sensor 3 on the panel.	- Optical fiber RX 25 of the CN2 CIB board not connected, broken or defective.
F0037: Sensor 4 - Electrical arcing detection fault	Arc flash detection by panel sensor 4.	- Optical fiber RX 24 of the CIB board of CN2 not connected, broken or defective.
F0038: Sensor 5 - Electrical arcing detection fault	Arc flash detection by panel sensor 5.	- Optical fiber RX 23 of the CN2 CIB board not connected, broken or defective.
F0041: Sensor A - Electrical arcing detection fault	Arc flash detection by panel sensor A.	- Optical fiber OPTO IN (3) of the CCE board not connected, broken or defective.
F0042: Sensor B - Electrical arcing detection fault	Arc flash detection by panel sensor B.	- Optical fiber OPTO IN (2) of the CCE board not connected, broken or defective.
F0043: Sensor C - Electrical arcing detection fault	Arc flash detection by sensor C on the panel.	- Optical fiber OPTO IN (1) of the CCE board not connected, broken or defective.
A0046: Motor ixt function overload	Motor shaft load too high.	- C7.4.3, C7.4.4 and C7.4.5 settings too low for the motor used. - C7.4.2 setting too low for the motor used. - C3.2.1.1 setting too high (valid for low speed operation).
F0048: Forced ventilation fault	Forced ventilation failure.	- Blocked fans. - Clogged air intake filters.
F0069: Calibration fault	This fault occurs when a calibration variable is saved out of the allowed range.	- Incorrect calibration procedure. - Defective ISOC.22 or ISOC2 board.
F0070: Overcurrent/short circuit	Instantaneous current at the inverter output greater than twice the nominal current (Hardware detection).	- Short circuit between two motor phases or power cables (hardware detection). - Load inertia too high or acceleration ramp too fast. - Incorrect regulation and/or configuration parameter(s). - Protection parameters set too high. - Cell IGBT modules short circuited.
F0072: Output over load ixt function	Motor shaft load too high.	- C7.4.3, C7.4.4 and C7.4.5 settings too low for the motor used. - C7.4.2 setting too low for the motor used. - C3.2.1.1 setting too high (valid for low speed operation).

Fault/Alarm	Description	Possible Causes
F0073: Iu overcurrent	Instantaneous current value above the permissible limit.	- Inverter output overload. - Sudden load variation. - Inadequate acceleration or deceleration ramp. - Defect in current sensors.
F0074: Iv overcurrent	Instantaneous current value above the permissible limit.	- Inverter output overload. - Sudden load variation. - Inadequate acceleration or deceleration ramp. - Defect in current sensors.
F0075: Iw overcurrent	Instantaneous current value above the permissible limit.	- Inverter output overload. - Sudden load variation. - Inadequate acceleration or deceleration ramp. - Defect in current sensors.
F0076: Output current unbalanced	Difference between output currents greater than 12.5 % of the nominal current for a time longer than permitted.	- Bad contact or cable disconnected from the motor. - Current feedback circuit failure.
F0078: Motor over temperature	Motor temperature higher than the fault level programmed in the thermal protection relay.	- Digital input signal, coming from the protection relay, programmed for "Motor failure" at low level.
F0079: Speed sensor	Faulty motor speed sensor signals.	- Defective wiring between motor speed sensor and inverter interface board. - Cable length greater than the specified maximum limit. - Motorspeed sensor mounting error. - Incorrect parameterization of the number of pulses per encoder revolution.
A0080: Speed sensor	Faulty motor speed sensor signals.	- Defective wiring between motor speed sensor and inverter interface board. - Cable length greater than the specified maximum limit. - Motorspeed sensor mounting error. - Incorrect parameterization of the number of pulses per encoder revolution.
F0085: Electronic power supply fault	Source monitoring signal remains indicating electronic sources not OK.	
F0087: Watchdog protection between control boards	Watchdog protection detected a break in the communication link between the control boards and restarted the system.	- Damaged communication cable and/or connector between control boards. - Cable disconnected or broken.
F0088: Watchdog protection on the control board	Watchdog protection detected an error and restarted the system.	
F0092: Pre-charge power supply	PIC board DI7 input wiring (XC7:16) open (does not return +24 V).	- Short circuit in the pre-charge system. - Defective pre-charge capacitors and/or resistors. - Pre-charge circuit breaker open. - Problems with the auxiliary pre-charge inverter.
A0094: Cooling system supply fault	Power alarm in the refrigeration system.	- Short circuit in the ventilation system. - Fan blocked. - Circuit breakers supplying the inverter ventilation assembly open. - Wiring of the DI10 input of the PIC board (XC7:15) open (does not return +24 V).
F0099: Invalid output current offset	Output current measurement offset outside the allowable range.	- Defect in the output current measurement circuit.
F0100: Control board self-diagnosis	The control board application had execution problems.	

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0101: Communication failure with AUI board	Communication with the AUI user interface board was not performed correctly.	- AUI user interface board disconnected from CCE control board. - Defective connection cable between AUI and CCE.
F0102: Communication timeout with the AUI board	The CCE control board detected a loss of telegrams in communication with the AUI user interface board.	- AUI user interface board disconnected from CCE control board. - Problem with the power supply of the control boards. - Defective connection cable between AUI and CCE.
F0112: Motor over speed	Motorspeed above programmed limit.	- High mechanical acceleration torque under load.
A0118: Pre-charge power supply	PIC board DI7 input wiring (XC7:16) open (does not return +24 V).	- Short circuit in the pre-charge system. - Defective pre-charge capacitors. - Defective pre-charge resistors. - Pre-charge circuit breaker open. - Problems with the auxiliary pre-charge inverter.
F0256: Output transformer fault	Digital input programmed for "Transformer OK" Open (does not return +24 V).	- For more details on the function of this DI, consult the inverter design.
F0257: Pressurization system fault	Digital input programmed for "Pressurization system OK" Open (does not return +24 V).	- For more details on the function of this DI, consult the inverter design.
F0258: Output filter fault	Digital input programmed for "Output Filter OK" Open (does not return +24 V).	- For more details on the function of this DI, consult the inverter design.
F0259: Exciter fault	Digital input programmed for "Exciter OK" Open (does not return +24 V).	- For more details on the function of this DI, consult the inverter design.
F0260: Communication with the position sensor	Faulty speed sensor.	- Defective wiring between motor speed sensor and inverter interface board. - Cable length greater than the specified maximum limit. - Motorspeed sensor mounting error. - Incorrect encoder parameterization.
A0261: Direction of rotation between input voltage and current is inverted	Inverted connections between the terminals of the transformer auxiliary windings and the input voltage measuring ISOC2.	- Input CTs mounted on the wrong phases of the transformers. - Incorrect connection of the current transformers of the transformers in ISOC2. - Inverted measurement fibers between the input ISOC2 and the control rack.
A0262: Direction of rotation between the output current and voltage is inverted	Inverted connections between the output terminals and the electronic output voltage measurement board.	- Output CTs mounted on the wrong output phases. - Incorrect connection of the output current transformers on the PIC board. - Inverted measurement fibers between the output voltage measurement electronic board and the control rack.
F0263: Timeout on output contactor activation	The condition for commanding the closing of the output contactor was not met.	- If configured to drive PM motors, the terminal voltage was higher than that supported by the DC link.
A0301: Input undervoltage	Inverter input voltage less than 75.0 %.	- Undervoltage in the power supply network. - Incorrect adjustment of the transformer primary taps.

Fault/Alarm	Description	Possible Causes
A0302: Input overvoltage	Inverter input voltage greater than 114 %.	- Overvoltage in the power supply network. - Incorrect adjustment of the transformer primary taps.
F0303: Input undervoltage	Inverter input voltage less than 70 %.	- Undervoltage in the power supply network. - Incorrect adjustment of the transformer primary taps.
F0304: Input overvoltage	Inverter input voltage greater than 117 %.	- Overvoltage in the power supply network. - Incorrect adjustment of the transformer primary taps.
F0305: Input unbalance/phase loss	Difference between the highest and lowest input voltage values greater than 25 p.u.. The parameter C7.1.2 defines the time the inverter must remain in fault condition for the protection to activate. It is not possible to adjust the fault level.	- Voltage difference between phases greater than 25% of the nominal value.
F0309: Timeout in Ride-Through state waiting line	Network return time greater than scheduled time. Voltage in any phase less than 30 % of nominal value.	- Inverter input voltage less than 80 %. - Undervoltage in the power supply network. - Incorrect adjustment of the transformer primary taps.
F0310: Short circuit on the transformer 1 secondary	Short circuit in the input transformer secondary cables.	- Short circuit in the input transformer secondary coils. - Defect in the transformer current measurement circuit. - Defect in the input voltage measurement circuit. - Incorrect configuration of input transformer parameters. - Inversion of the inverter input cables (RTS or 132 phase sequence).
A0315: Ground fault for neutral shift	Voltage between the motor virtual neutral and the system ground greater than 25 % of the motor phase voltage value.	- Failure in the ground insulation of the connection cables or the load driven by the inverter.
F0316: Ground fault for neutral shift	Voltage between the motor's virtual neutral and the system ground greater than 50 % of the motor's phase voltage value for a time greater than 0.5 s.	- Failure in the ground insulation of the connection cables or the load driven by the inverter.
F0317: Ground fault for current leak	The sum of the three output currents is greater than 12.5 % of the inverter's rated current.	- Failure of the ground insulation in the connection cables or in the load driven by the inverter with the presence of current leakage. - Defective output current measurement sensors.
F0320: Vab measurement feedback fault	Fault in the line voltage feedback circuit between phases A and B at the inverter input.	- Vab optical fiber not connected, inverted or defective.
F0321: Vbc measurement feedback fault	Fault in the line voltage feedback circuit between phases B and C at the inverter input.	- Vbc optical fiber not connected, inverted or defective.
F0323: Ib_1 measurement feedback fault	Fault in the B phase current feedback circuit at the inverter input.	- Optical fiber Ib_1 not connected, inverted or defective.
F0324: Ic_1 measurement feedback fault	Fault in the C phase current feedback circuit at the inverter input.	- Optical fiber Ic_1 not connected, inverted or defective.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0325: Vuv measurement feedback fault	Fault in the feedback circuit of the line voltage measured between phases U and V at the inverter output.	- Vuv optical fiber not connected, inverted or defective.
F0326: Vvw measurement feedback fault	Fault in the feedback circuit of the line voltage measured between phases V and W at the inverter output.	- Vvw optical fiber not connected, inverted or defective.
F0327: Vn_gnd measurement feedback fault	Fault in the voltage feedback circuit between the motor's virtual neutral and the system ground.	- Optical fiber N_GND not connected, inverted or defective.
F0328: Ib_2 measurement feedback fault	Fault in the B phase current feedback circuit at the inverter input.	- Optical fiber Ib_2 not connected, inverted or defective.
F0329: Ic_2 measurement feedback fault	Fault in the C phase current feedback circuit at the inverter input.	- Optical fiber Ic_2 not connected, inverted or defective.
F0330: Ib_3 measurement feedback fault	Fault in the B phase current feedback circuit at the inverter input.	- Optical fiber Ib_3 not connected, inverted or defective.
F0331: Ic_3 measurement feedback fault	Fault in the C phase current feedback circuit at the inverter input.	- Optical fiber Ic_3 not connected, inverted or defective.
F0333: Feedback failure in the Vab measurement of the connection to the output	Fault in the line voltage feedback circuit between phases A and B at the inverter output.	- Vab optical fiber not connected, inverted or defective.
F0334: Feedback failure in the Vbc measurement of the connection to the output	Fault in the line voltage feedback circuit between phases B and C at the inverter output.	- Vab optical fiber not connected, inverted or defective.
F0343: Short circuit on the transformer 2 secondary	Short circuit in the input transformer secondary cables.	- Short circuit in the input transformer secondary coils. - Defect in the transformer current measurement circuit. - Defect in the input voltage measurement circuit. - Incorrect configuration of input transformer parameters. - Inversion of the inverter input cables (RTS or 132 phase sequence).
F0346: Short circuit on the transformer 3 secondary	Short circuit in the input transformer secondary cables.	- Short circuit in the input transformer secondary coils. - Defect in the transformer current measurement circuit. - Defect in the input voltage measurement circuit. - Incorrect configuration of input transformer parameters. - Inversion of the inverter input cables (RTS or 132 phase sequence).
F0348: Execution of the cell bypass test command	It was not possible to start the bypass test routine for the specified cell.	- The maximum number of cells configured for the phases has been exceeded. - Problem in the cell fault management. - Pre-condition for performing the bypass routine not met.
F0349: Disabled cell connected	A cell that should be deactivated and disconnected is connected to the inverter.	- Cell connected improperly. - Incorrect parameterization of the inverter nominal voltage. - Cell configured for mechanical bypass remains connected.

Fault/Alarm	Description	Possible Causes
F0350: Invalid setting for the Bypass	Bypass situation where the arrangement of the operating power arms represents a combination that is not valid for operation.	- It is not possible to obtain a combination to supply a balanced three-phase voltage to the motor with the operational power arms available in the system. - The invalid arrangement condition occurs when the bypass function chosen is the option with neutral displacement.
F0351: Number of programmed cells exceeds the inverter capacity	The total number of cells resulting from the inverter configuration exceeds the communication capacity of the control rack, this number must be less than 36 cells.	- Invalid inverter configuration considering parameter setting: C13.1.1, C13.1.4 e C13.1.3.
F0353: Late response failure of CN1 connector cells	Cells linked to the CIB are showing inappropriate responses.	
F0354: Late response failure of CN2 connector cells	Cells linked to the CIB are showing inappropriate responses.	
F0355: CIB card incorrect response failure	The CIB board is responding inappropriately.	
F0356: Communication failure between CIB 1 and CCE	The CIB interface board's self-diagnosis routines detected communication problems with the CCE control board.	- Problems in the connection between the CIB and the CCE control board.
F0357: Communication failure between CIB 2 and CCE	The CIB interface board's self-diagnosis routines detected communication problems with the CCE control board.	- Problems in the connection between the CIB and the CCE control board.
F0358: CIB execution failure of CN1 connector	The CIB interface board's self-diagnosis routines have detected a critical problem.	
F0359: CIB execution failure of CN2 connector	The CIB interface board's self-diagnosis routines have detected a critical problem.	
F0360: Communication failure between CCE and CIB boards	The CCE control board's self-diagnosis routines have detected a critical problem in communication with the CIB interface board.	
F0361: Connection failure with CIB board 1	The connection to the CIB interface board is not working properly.	- CIB interface board disconnected. - Problems with the connector between the CIB board and the CCE.
F0362: Connection failure with CIB board 2	The connection to the CIB interface board is not working properly.	- CIB interface board disconnected. - Problems with the connector between the CIB board and the CCE. - Incorrect parameterization of the inverter nominal voltage, C13.1.1. - Incorrect parameterization of the number of cells in parallel, C13.1.3. - Incorrect parameterization of the number of redundant cells, C13.1.4. - Incorrect parameterization of the number of input transformers, C13.2.1.
F0363: Self-diagnosis of cell voltages	Voltage levels incompatible with the inverter model.	- Firmware programming incompatible with hardware. - Incorrect parameterization of the inverter's nominal voltage.
F0366: Improper connection of a CIB interface board	An unconfigured CIB interface board communicated with the CCE control board.	- CIB interface board improperly connected to the control board.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0367: Timeout na sincronização do paralelismo		
F0368: Timeout na comunicação do inversor em paralelo		
F0369: Inversor do paralelismo em estado de proteção		
F0370: Sincronismo no inversor seguidor		
F0400: Cell U1 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0401: Cell U2 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0402: Cell U3 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0403: Cell U4 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0404: Cell U5 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0405: Cell U6 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0406: Cell U7 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.

Fault/Alarm	Description	Possible Causes
F0407: Cell U8 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0408: Cell U9 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0409: Cell U10 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0410: Cell U11 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0411: Cell U12 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0412: Cell V1 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0413: Cell V2 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0414: Cell V3 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0415: Cell V4 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0416: Cell V5 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0417: Cell V6 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0418: Cell V7 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0419: Cell V8 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0420: Cell V9 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0421: Cell V10 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0422: Cell V11 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0423: Cell V12 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0424: Cell W1 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.

Fault/Alarm	Description	Possible Causes
F0425: Cell W2 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0426: Cell W3 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0427: Cell W4 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0428: Cell W5 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0429: Cell W6 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0430: Cell W7 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0431: Cell W8 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0432: Cell W9 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0433: Cell W10 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0434: Cell W11 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0435: Cell W12 DC link overvoltage	Cell DC link voltage greater than 1200 V.	- Incorrect adjustment of the Taps of the inverter's main transformer. - Voltage at the inverter input supply too high. - Load inertia too high or deceleration ramp too low. - Adjustment of the ratio between the primary voltage and the auxiliary output transformer too high.
F0436: Cell U1 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.
F0437: Cell U2 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.
F0438: Cell U3 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.
F0439: Cell U4 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.
F0440: Cell U5 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.
F0441: Cell U6 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.
F0442: Cell U7 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.
F0443: Cell U8 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.
F0444: Cell U9 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.
F0445: Cell U10 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.
F0446: Cell U11 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.
F0447: Cell U12 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.
F0448: Cell V1 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.
F0449: Cell V2 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.

[illegible]

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes																		
F0468: Cell W9 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.																		
F0469: Cell W10 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.																		
F0470: Cell W11 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.																		
F0471: Cell W12 DC link undervoltage	Cell DC link voltage less than 745 V or less than 652 V for vector control operation.	- Voltage at the inverter input supply too low. - Incorrect adjustment of the Taps of the main transformer of the inverter.																		
A0472: Overtemperature on cell U1 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0473: Overtemperature on cell U2 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0474: Overtemperature on cell U3 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0475: Overtemperature on cell U4 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			

Fault/Alarm	Description	Possible Causes																		
A0476: Overtemperature on cell U5 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0477: Overtemperature on cell U6 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0478: Overtemperature on cell U7 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0479: Overtemperature on cell U8 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0480: Overtemperature on cell U9 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes																		
A0481: Overtemperature on cell U10 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0482: Overtemperature on cell U11 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0483: Overtemperature on cell U12 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0484: Overtemperature on cell V1 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0485: Overtemperature on cell V2 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			

Fault/Alarm	Description	Possible Causes																		
A0486: Overtemperature on cell V3 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0487: Overtemperature on cell V4 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0488: Overtemperature on cell V5 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0489: Overtemperature on cell V6 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0490: Overtemperature on cell V7 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes																		
A0491: Overtemperature on cell V8 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0492: Overtemperature on cell V9 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0493: Overtemperature on cell V10 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0494: Overtemperature on cell V11 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0495: Overtemperature on cell V12 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			

Fault/Alarm	Description	Possible Causes																		
A0496: Overtemperature on cell W1 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0497: Overtemperature on cell W2 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0498: Overtemperature on cell W3 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0499: Overtemperature on cell W4 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0500: Overtemperature on cell W5 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes																		
A0501: Overtemperature on cell W6 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0502: Overtemperature on cell W7 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0503: Overtemperature on cell W8 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0504: Overtemperature on cell W9 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0505: Overtemperature on cell W10 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			

Fault/Alarm	Description	Possible Causes																		
A0506: Overtemperature on cell W11 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
A0507: Overtemperature on cell W12 IGBT module	Cell heatsink temperature higher than alarm level. <table><tr><th>Cell model</th><th>Alarm level</th></tr><tr><td>70 A</td><td>85 °C</td></tr><tr><td>140 A</td><td>85 °C</td></tr><tr><td>200 A</td><td>85 °C</td></tr><tr><td>265 A</td><td>85 °C</td></tr><tr><td>340 A</td><td>85 °C</td></tr><tr><td>450 A</td><td>90 °C</td></tr><tr><td>600 A</td><td>90 °C</td></tr><tr><td>800 A</td><td>100 °C</td></tr></table>	Cell model	Alarm level	70 A	85 °C	140 A	85 °C	200 A	85 °C	265 A	85 °C	340 A	85 °C	450 A	90 °C	600 A	90 °C	800 A	100 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Alarm level																			
70 A	85 °C																			
140 A	85 °C																			
200 A	85 °C																			
265 A	85 °C																			
340 A	85 °C																			
450 A	90 °C																			
600 A	90 °C																			
800 A	100 °C																			
F0508: Overtemperature on cell U1 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0509: Overtemperature on cell U2 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0510: Overtemperature on cell U3 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes																		
F0511: Overtemperature on cell U4 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0512: Overtemperature on cell U5 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0513: Overtemperature on cell U6 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0514: Overtemperature on cell U7 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0515: Overtemperature on cell U8 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			

Fault/Alarm	Description	Possible Causes																		
F0516: Overtemperature on cell U9 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0517: Overtemperature on cell U10 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0518: Overtemperature on cell U11 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0519: Overtemperature on cell U12 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0520: Overtemperature on cell V1 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes																		
F0521: Overtemperature on cell V2 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0522: Overtemperature on cell V3 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0523: Overtemperature on cell V4 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0524: Overtemperature on cell V5 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0525: Overtemperature on cell V6 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			

Fault/Alarm	Description	Possible Causes																		
F0526: Overtemperature on cell V7 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0527: Overtemperature on cell V8 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0528: Overtemperature on cell V9 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0529: Overtemperature on cell V10 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0530: Overtemperature on cell V11 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes																		
F0531: Overtemperature on cell V12 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0532: Overtemperature on cell W1 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0533: Overtemperature on cell W2 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0534: Overtemperature on cell W3 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0535: Overtemperature on cell W4 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			

Fault/Alarm	Description	Possible Causes																		
F0536: Overtemperature on cell W5 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0537: Overtemperature on cell W6 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0538: Overtemperature on cell W7 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0539: Overtemperature on cell W8 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0540: Overtemperature on cell W9 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes																		
F0541: Overtemperature on cell W10 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0542: Overtemperature on cell W11 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0543: Overtemperature on cell W12 IGBT module	Cell heatsink temperature higher than fault level. <table><tr><th>Cell model</th><th>Fault level</th></tr><tr><td>70 A</td><td>90 °C</td></tr><tr><td>140 A</td><td>90 °C</td></tr><tr><td>200 A</td><td>90 °C</td></tr><tr><td>265 A</td><td>90 °C</td></tr><tr><td>340 A</td><td>90 °C</td></tr><tr><td>450 A</td><td>95 °C</td></tr><tr><td>600 A</td><td>95 °C</td></tr><tr><td>800 A</td><td>105 °C</td></tr></table>	Cell model	Fault level	70 A	90 °C	140 A	90 °C	200 A	90 °C	265 A	90 °C	340 A	90 °C	450 A	95 °C	600 A	95 °C	800 A	105 °C	- Very high ambient temperature (> 40 °C) and high output current. - Blocked or defective fans. - Clogged air intake filters.
Cell model	Fault level																			
70 A	90 °C																			
140 A	90 °C																			
200 A	90 °C																			
265 A	90 °C																			
340 A	90 °C																			
450 A	95 °C																			
600 A	95 °C																			
800 A	105 °C																			
F0544: Undertemperature on cell U1 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.																		
F0545: Undertemperature on cell U2 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.																		
F0546: Undertemperature on cell U3 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.																		
F0547: Undertemperature on cell U4 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.																		
F0548: Undertemperature on cell U5 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.																		
F0549: Undertemperature on cell U6 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.																		
F0550: Undertemperature on cell U7 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.																		

Fault/Alarm	Description	Possible Causes
F0551: Undertemperature on cell U8 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0552: Undertemperature on cell U9 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0553: Undertemperature on cell U10 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0554: Undertemperature on cell U11 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0555: Undertemperature on cell U12 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0556: Undertemperature on cell V1 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0557: Undertemperature on cell V2 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0558: Undertemperature on cell V3 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0559: Undertemperature on cell V4 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0560: Undertemperature on cell V5 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0561: Undertemperature on cell V6 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0562: Undertemperature on cell V7 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0563: Undertemperature on cell V8 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0564: Undertemperature on cell V9 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0565: Undertemperature on cell V10 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0566: Undertemperature on cell V11 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0567: Undertemperature on cell V12 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0568: Undertemperature on cell W1 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0569: Undertemperature on cell W2 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0570: Undertemperature on cell W3 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0571: Undertemperature on cell W4 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0572: Undertemperature on cell W5 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0573: Undertemperature on cell W6 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0574: Undertemperature on cell W7 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0575: Undertemperature on cell W8 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0576: Undertemperature on cell W9 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0577: Undertemperature on cell W10 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0578: Undertemperature on cell W11 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0579: Undertemperature on cell W12 IGBT	Cell heatsink temperature less than -10°C.	- Defect in the cell temperature measurement sensor. - Cell temperature sensor disconnected.
F0580: Cell U1 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0581: Cell U2 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.

Fault/Alarm	Description	Possible Causes
F0582: Cell U3 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0583: Cell U4 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0584: Cell U5 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0585: Cell U6 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0586: Cell U7 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0587: Cell U8 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0588: Cell U9 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0589: Cell U10 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0590: Cell U11 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0591: Cell U12 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0592: Cell V1 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0593: Cell V2 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0594: Cell V3 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0595: Cell V4 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.

Fault/Alarm	Description	Possible Causes
F0596: Cell V5 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0597: Cell V6 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0598: Cell V7 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0599: Cell V8 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0600: Cell V9 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0601: Cell V10 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0602: Cell V11 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0603: Cell V12 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0604: Cell W1 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0605: Cell W2 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0606: Cell W3 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0607: Cell W4 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0608: Cell W5 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0609: Cell W6 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.

Fault/Alarm	Description	Possible Causes
F0610: Cell W7 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0611: Cell W8 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0612: Cell W9 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0613: Cell W10 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0614: Cell W11 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0615: Cell W12 phase IGBT	Failure in the IGBT of the respective cell phase.	- Short circuit at the inverter output. - The IGBT driver board for the phase arm of the cell is disconnected. - Cell phase arm IGBTs operating outside the saturation region. - Defective IGBTs or phase arm driver board of the cell. - Failure in the desaturation signal feedback or gate driver source.
F0616: Cell U1 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0617: Cell U2 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0618: Cell U3 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0619: Cell U4 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0620: Cell U5 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0621: Cell U6 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0622: Cell U7 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0623: Cell U8 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0624: Cell U9 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0625: Cell U10 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.

Fault/Alarm	Description	Possible Causes
F0626: Cell U11 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0627: Cell U12 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0628: Cell V1 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0629: Cell V2 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0630: Cell V3 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0631: Cell V4 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0632: Cell V5 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0633: Cell V6 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0634: Cell V7 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0635: Cell V8 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0636: Cell V9 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0637: Cell V10 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0638: Cell V11 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0639: Cell V12 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0640: Cell W1 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0641: Cell W2 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0642: Cell W3 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0643: Cell W4 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.

Fault/Alarm	Description	Possible Causes
F0644: Cell W5 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0645: Cell W6 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0646: Cell W7 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0647: Cell W8 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0648: Cell W9 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0649: Cell W10 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0650: Cell W11 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0651: Cell W12 neutral IGBT	Failure in the neutral IGBT of the respective cell.	- Short circuit at the inverter output. - Cell neutral arm IGBT driver board disconnected. - IGBTs of the neutral arm of the cell operating outside the saturation region. - Defective IGBTs or neutral cell driver board. - Failure in the desaturation signal feedback or gate driver source.
F0652: Cell U1 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0653: Cell U2 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0654: Cell U3 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0655: Cell U4 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0656: Cell U5 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0657: Cell U6 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0658: Cell U7 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0659: Cell U8 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0660: Cell U9 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0661: Cell U10 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0662: Cell U11 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0663: Cell U12 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0664: Cell V1 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.

Fault/Alarm	Description	Possible Causes
F0665: Cell V2 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0666: Cell V3 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0667: Cell V4 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0668: Cell V5 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0669: Cell V6 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0670: Cell V7 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0671: Cell V8 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0672: Cell V9 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0673: Cell V10 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0674: Cell V11 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0675: Cell V12 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0676: Cell W1 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0677: Cell W2 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0678: Cell W3 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0679: Cell W4 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0680: Cell W5 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0681: Cell W6 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0682: Cell W7 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0683: Cell W8 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0684: Cell W9 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0685: Cell W10 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0686: Cell W11 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F0687: Cell W12 phase pulse feedback	Failure to confirm switching of the cell phase arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the phase arm IGBTs disconnected or defective. - Defective IGBTs or phase arm driver board of the cell.
F1000: Cell U1 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.

Fault/Alarm	Description	Possible Causes
F1001: Cell U2 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1002: Cell U3 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1003: Cell U4 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1004: Cell U5 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1005: Cell U6 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1006: Cell U7 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1007: Cell U8 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1008: Cell U9 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1009: Cell U10 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1010: Cell U11 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1011: Cell U12 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1012: Cell V1 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1013: Cell V2 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1014: Cell V3 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1015: Cell V4 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1016: Cell V5 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1017: Cell V6 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1018: Cell V7 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1019: Cell V8 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1020: Cell V9 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1021: Cell V10 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1022: Cell V11 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1023: Cell V12 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1024: Cell W1 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1025: Cell W2 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1026: Cell W3 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1027: Cell W4 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1028: Cell W5 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1029: Cell W6 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1030: Cell W7 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1031: Cell W8 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1032: Cell W9 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1033: Cell W10 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1034: Cell W11 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1035: Cell W12 electronics power supply	Voltages of the cell's internal electronic circuits outside the operating level.	- Defect in the cell power supply.
F1036: Cell U1 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	

Fault/Alarm	Description	Possible Causes
F1037: Cell U2 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1038: Cell U3 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1039: Cell U4 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1040: Cell U5 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1041: Cell U6 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1042: Cell U7 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1043: Cell U8 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1044: Cell U9 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1045: Cell U10 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1046: Cell U11 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1047: Cell U12 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1048: Cell V1 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1049: Cell V2 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1050: Cell V3 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1051: Cell V4 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1052: Cell V5 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1053: Cell V6 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1054: Cell V7 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1055: Cell V8 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1056: Cell V9 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1057: Cell V10 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1058: Cell V11 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1059: Cell V12 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1060: Cell W1 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1061: Cell W2 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1062: Cell W3 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1063: Cell W4 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1064: Cell W5 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1065: Cell W6 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1066: Cell W7 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1067: Cell W8 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1068: Cell W9 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1069: Cell W10 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1070: Cell W11 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1071: Cell W12 modulation synchronism	Failure in synchronization between the cell control board and the inverter main control.	
F1072: Cell U1 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.

Fault/Alarm	Description	Possible Causes
F1073: Cell U2 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1074: Cell U3 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1075: Cell U4 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1076: Cell U5 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1077: Cell U6 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1078: Cell U7 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1079: Cell U8 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1080: Cell U9 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1081: Cell U10 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1082: Cell U11 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1083: Cell U12 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1084: Cell V1 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1085: Cell V2 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1086: Cell V3 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1087: Cell V4 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1088: Cell V5 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1089: Cell V6 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1090: Cell V7 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1091: Cell V8 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1092: Cell V9 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1093: Cell V10 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1094: Cell V11 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1095: Cell V12 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1096: Cell W1 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1097: Cell W2 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1098: Cell W3 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1099: Cell W4 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1100: Cell W5 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1101: Cell W6 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1102: Cell W7 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1103: Cell W8 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1104: Cell W9 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1105: Cell W10 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1106: Cell W11 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1107: Cell W12 Bypass system	Cell bypass system operation failure.	- Bypass system not connected or faulty.
F1108: Communication with cell U1	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1109: Communication with cell U2	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1110: Communication with cell U3	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1111: Communication with cell U4	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1112: Communication with cell U5	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1113: Communication with cell U6	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1114: Communication with cell U7	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1115: Communication with cell U8	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.

Fault/Alarm	Description	Possible Causes
F1116: Communication with cell U9	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1117: Communication with cell U10	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1118: Communication with cell U11	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1119: Communication with cell U12	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1120: Communication with cell V1	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1121: Communication with cell V2	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1122: Communication with cell V3	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1123: Communication with cell V4	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1124: Communication with cell V5	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1125: Communication with cell V6	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1126: Communication with cell V7	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1127: Communication with cell V8	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1128: Communication with cell V9	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1129: Communication with cell V10	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1130: Communication with cell V11	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1131: Communication with cell V12	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1132: Communication with cell W1	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1133: Communication with cell W2	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1134: Communication with cell W3	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1135: Communication with cell W4	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1136: Communication with cell W5	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1137: Communication with cell W6	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1138: Communication with cell W7	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1139: Communication with cell W8	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1140: Communication with cell W9	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1141: Communication with cell W10	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1142: Communication with cell W11	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1143: Communication with cell W12	Cell does not establish communication with the CIB board.	- Processor firmware update process failed. - Cell PLD reconfiguration failed.
F1144: Incompatible cell U1 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1145: Incompatible cell U2 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1146: Incompatible cell U3 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1147: Incompatible cell U4 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1148: Incompatible cell U5 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1149: Incompatible cell U6 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1150: Incompatible cell U7 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1151: Incompatible cell U8 firmware	Cell control board firmware version incompatible with that of the inverter main control.	

Fault/Alarm	Description	Possible Causes
F1152: Incompatible cell U9 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1153: Incompatible cell U10 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1154: Incompatible cell U11 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1155: Incompatible cell U12 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1156: Incompatible cell V1 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1157: Incompatible cell V2 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1158: Incompatible cell V3 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1159: Incompatible cell V4 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1160: Incompatible cell V5 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1161: Incompatible cell V6 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1162: Incompatible cell V7 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1163: Incompatible cell V8 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1164: Incompatible cell V9 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1165: Incompatible cell V10 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1166: Incompatible cell V11 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1167: Incompatible cell V12 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1168: Incompatible cell W1 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1169: Incompatible cell W2 firmware	Cell control board firmware version incompatible with that of the inverter main control.	

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1170: Incompatible cell W3 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1171: Incompatible cell W4 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1172: Incompatible cell W5 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1173: Incompatible cell W6 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1174: Incompatible cell W7 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1175: Incompatible cell W8 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1176: Incompatible cell W9 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1177: Incompatible cell W10 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1178: Incompatible cell W11 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1179: Incompatible cell W12 firmware	Cell control board firmware version incompatible with that of the inverter main control.	
F1180: Incompatible cell U1 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1181: Incompatible cell U2 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1182: Incompatible cell U3 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1183: Incompatible cell U4 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1184: Incompatible cell U5 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1185: Incompatible cell U6 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1186: Incompatible cell U7 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1187: Incompatible cell U8 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.

Fault/Alarm	Description	Possible Causes
F1188: Incompatible cell U9 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1189: Incompatible cell U10 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1190: Incompatible cell U11 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1191: Incompatible cell U12 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1192: Incompatible cell V1 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1193: Incompatible cell V2 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1194: Incompatible cell V3 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1195: Incompatible cell V4 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1196: Incompatible cell V5 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1197: Incompatible cell V6 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1198: Incompatible cell V7 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1199: Incompatible cell V8 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1200: Incompatible cell V9 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1201: Incompatible cell V10 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1202: Incompatible cell V11 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1203: Incompatible cell V12 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1204: Incompatible cell W1 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1205: Incompatible cell W2 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1206: Incompatible cell W3 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1207: Incompatible cell W4 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1208: Incompatible cell W5 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1209: Incompatible cell W6 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1210: Incompatible cell W7 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1211: Incompatible cell W8 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1212: Incompatible cell W9 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1213: Incompatible cell W10 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1214: Incompatible cell W11 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1215: Incompatible cell W12 model	Cell model incompatible or invalid with inverter model.	- Cell identifier code (MCC1 DIP) not configured.
F1216: Cell U1 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1217: Cell U2 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1218: Cell U3 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1219: Cell U4 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1220: Cell U5 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1221: Cell U6 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.

Fault/Alarm	Description	Possible Causes
F1222: Cell U7 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1223: Cell U8 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1224: Cell U9 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1225: Cell U10 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1226: Cell U11 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1227: Cell U12 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1228: Cell V1 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1229: Cell V2 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1230: Cell V3 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1231: Cell V4 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1232: Cell V5 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1233: Cell V6 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1234: Cell V7 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1235: Cell V8 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1236: Cell V9 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1237: Cell V10 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1238: Cell V11 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1239: Cell V12 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1240: Cell W1 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1241: Cell W2 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1242: Cell W3 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1243: Cell W4 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1244: Cell W5 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1245: Cell W6 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1246: Cell W7 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1247: Cell W8 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1248: Cell W9 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1249: Cell W10 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.

Fault/Alarm	Description	Possible Causes
F1250: Cell W11 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1251: Cell W12 insulation defective	Failure in the internal insulation of the cell.	- Contact between any energized point of the circuit and the housing. - Failure in the discharge resistors of the cell's DC link capacitors.
F1252: Firmware update or PLD cell U1	Processor firmware update process or cell PLD reconfiguration failed.	
F1253: Firmware update or PLD cell U2	Processor firmware update process or cell PLD reconfiguration failed.	
F1254: Firmware update or PLD cell U3	Processor firmware update process or cell PLD reconfiguration failed.	
F1255: Firmware update or PLD cell U4	Processor firmware update process or cell PLD reconfiguration failed.	
F1256: Firmware update or PLD cell U5	Processor firmware update process or cell PLD reconfiguration failed.	
F1257: Firmware update or PLD cell U6	Processor firmware update process or cell PLD reconfiguration failed.	
F1258: Firmware update or PLD cell U7	Processor firmware update process or cell PLD reconfiguration failed.	
F1259: Firmware update or PLD cell U8	Processor firmware update process or cell PLD reconfiguration failed.	
F1260: Firmware update or PLD cell U9	Processor firmware update process or cell PLD reconfiguration failed.	
F1261: Firmware update or PLD cell U10	Processor firmware update process or cell PLD reconfiguration failed.	
F1262: Firmware update or PLD cell U11	Processor firmware update process or cell PLD reconfiguration failed.	
F1263: Firmware update or PLD cell U12	Processor firmware update process or cell PLD reconfiguration failed.	
F1264: Firmware update or PLD cell V1	Processor firmware update process or cell PLD reconfiguration failed.	
F1265: Firmware update or PLD cell V2	Processor firmware update process or cell PLD reconfiguration failed.	
F1266: Firmware update or PLD cell V3	Processor firmware update process or cell PLD reconfiguration failed.	

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1267: Firmware update or PLD cell V4	Processor firmware update process or cell PLD reconfiguration failed.	
F1268: Firmware update or PLD cell V5	Processor firmware update process or cell PLD reconfiguration failed.	
F1269: Firmware update or PLD cell V6	Processor firmware update process or cell PLD reconfiguration failed.	
F1270: Firmware update or PLD cell V7	Processor firmware update process or cell PLD reconfiguration failed.	
F1271: Firmware update or PLD cell V8	Processor firmware update process or cell PLD reconfiguration failed.	
F1272: Firmware update or PLD cell V9	Processor firmware update process or cell PLD reconfiguration failed.	
F1273: Firmware update or PLD cell V10	Processor firmware update process or cell PLD reconfiguration failed.	
F1274: Firmware update or PLD cell V11	Processor firmware update process or cell PLD reconfiguration failed.	
F1275: Firmware update or PLD cell V12	Processor firmware update process or cell PLD reconfiguration failed.	
F1276: Firmware update or PLD cell W1	Processor firmware update process or cell PLD reconfiguration failed.	
F1277: Firmware update or PLD cell W2	Processor firmware update process or cell PLD reconfiguration failed.	
F1278: Firmware update or PLD cell W3	Processor firmware update process or cell PLD reconfiguration failed.	
F1279: Firmware update or PLD cell W4	Processor firmware update process or cell PLD reconfiguration failed.	
F1280: Firmware update or PLD cell W5	Processor firmware update process or cell PLD reconfiguration failed.	
F1281: Firmware update or PLD cell W6	Processor firmware update process or cell PLD reconfiguration failed.	
F1282: Firmware update or PLD cell W7	Processor firmware update process or cell PLD reconfiguration failed.	
F1283: Firmware update or PLD cell W8	Processor firmware update process or cell PLD reconfiguration failed.	
F1284: Firmware update or PLD cell W9	Processor firmware update process or cell PLD reconfiguration failed.	

Fault/Alarm	Description	Possible Causes
F1285: Firmware update or PLD cell W10	Processor firmware update process or cell PLD reconfiguration failed.	
F1286: Firmware update or PLD cell W11	Processor firmware update process or cell PLD reconfiguration failed.	
F1287: Firmware update or PLD cell W12	Processor firmware update process or cell PLD reconfiguration failed.	
F1288: Cell U1 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1289: Cell U2 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1290: Cell U3 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1291: Cell U4 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1292: Cell U5 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1293: Cell U6 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1294: Cell U7 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1295: Cell U8 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1296: Cell U9 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1297: Cell U10 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1298: Cell U11 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1299: Cell U12 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1300: Cell V1 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1301: Cell V2 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1302: Cell V3 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1303: Cell V4 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1304: Cell V5 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1305: Cell V6 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1306: Cell V7 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1307: Cell V8 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1308: Cell V9 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1309: Cell V10 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.

Fault/Alarm	Description	Possible Causes
F1310: Cell V11 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1311: Cell V12 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1312: Cell W1 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1313: Cell W2 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1314: Cell W3 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1315: Cell W4 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1316: Cell W5 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1317: Cell W6 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1318: Cell W7 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1319: Cell W8 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1320: Cell W9 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1321: Cell W10 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1322: Cell W11 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
F1323: Cell W12 neutral pulse feedback	Failure to confirm the switching of the cell neutral arm IGBTs.	- Circuit for measuring the confirmation signal for switching of the disconnected or defective neutral arm IGBTs. - IGBTs or the neutral arm driver board of the cell are defective.
A1388: Thermal protection relay 1 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
A1389: Thermal protection relay 2 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
A1390: Thermal protection relay 3 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
A1391: Thermal protection relay 4 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
A1392: Thermal protection relay 5 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
A1393: Thermal protection relay 6 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
F1394: Thermal protection relay 1 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
F1395: Thermal protection relay 2 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.

Fault/Alarm	Description	Possible Causes
F1396: Thermal protection relay 3 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
F1397: Thermal protection relay 4 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
F1398: Thermal protection relay 5 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
F1399: Thermal protection relay 6 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
A1400: Thermal protection relay 1 - CH1 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1401: Thermal protection relay 1 - CH2 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1402: Thermal protection relay 1 - CH3 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1403: Thermal protection relay 1 - CH4 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1404: Thermal protection relay 1 - CH5 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1405: Thermal protection relay 1 - CH6 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1406: Thermal protection relay 1 - CH7 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1407: Thermal protection relay 1 - CH8 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1408: Thermal protection relay 1 - Overtemperature detected on CH1	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1409: Thermal protection relay 1 - Overtemperature detected on CH2	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1410: Thermal protection relay 1 - Overtemperature detected on CH3	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1411: Thermal protection relay 1 - Overtemperature detected on CH4	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1412: Thermal protection relay 1 - Overtemperature detected on CH5	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1413: Thermal protection relay 1 - Overtemperature detected on CH6	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1414: Thermal protection relay 1 - Overtemperature detected on CH7	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1415: Thermal protection relay 1 - Overtemperature detected on CH8	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1416: Thermal protection relay 1 - Overtemperature detected on CH1	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1417: Thermal protection relay 1 - Overtemperature detected on CH2	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1418: Thermal protection relay 1 - Overtemperature detected on CH3	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1419: Thermal protection relay 1 - Overtemperature detected on CH4	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

Fault/Alarm	Description	Possible Causes
A1420: Thermal protection relay 1 - Overtemperature detected on CH5	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1421: Thermal protection relay 1 - Overtemperature detected on CH6	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1422: Thermal protection relay 1 - Overtemperature detected on CH7	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1423: Thermal protection relay 1 - Overtemperature detected on CH8	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1424: Thermal protection relay 2 - CH1 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1425: Thermal protection relay 2 - CH2 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1426: Thermal protection relay 2 - CH3 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1427: Thermal protection relay 2 - CH4 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1428: Thermal protection relay 2 - CH5 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1429: Thermal protection relay 2 - CH6 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1430: Thermal protection relay 2 - CH7 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1431: Thermal protection relay 2 - CH8 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
F1432: Thermal protection relay 2 - Overtemperature detected on CH1	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1433: Thermal protection relay 2 - Overtemperature detected on CH2	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1434: Thermal protection relay 2 - Overtemperature detected on CH3	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1435: Thermal protection relay 2 - Overtemperature detected on CH4	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1436: Thermal protection relay 2 - Overtemperature detected on CH5	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1437: Thermal protection relay 2 - Overtemperature detected on CH6	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1438: Thermal protection relay 2 - Overtemperature detected on CH7	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1439: Thermal protection relay 2 - Overtemperature detected on CH8	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1440: Thermal protection relay 2 - Overtemperature detected on CH1	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1441: Thermal protection relay 2 - Overtemperature detected on CH2	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1442: Thermal protection relay 2 - Overtemperature detected on CH3	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1443: Thermal protection relay 2 - Overtemperature detected on CH4	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1444: Thermal protection relay 2 - Overtemperature detected on CH5	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

Fault/Alarm	Description	Possible Causes
A1445: Thermal protection relay 2 - Overtemperature detected on CH6	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1446: Thermal protection relay 2 - Overtemperature detected on CH7	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1447: Thermal protection relay 2 - Overtemperature detected on CH8	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1448: Thermal protection relay 3 - CH1 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1449: Thermal protection relay 3 - CH2 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1450: Thermal protection relay 3 - CH3 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1451: Thermal protection relay 3 - CH4 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1452: Thermal protection relay 3 - CH5 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1453: Thermal protection relay 3 - CH6 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1454: Thermal protection relay 3 - CH7 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1455: Thermal protection relay 3 - CH8 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
F1456: Thermal protection relay 3 - Overtemperature detected on CH1	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1457: Thermal protection relay 3 - Overtemperature detected on CH2	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1458: Thermal protection relay 3 - Overtemperature detected on CH3	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1459: Thermal protection relay 3 - Overtemperature detected on CH4	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1460: Thermal protection relay 3 - Overtemperature detected on CH5	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1461: Thermal protection relay 3 - Overtemperature detected on CH6	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1462: Thermal protection relay 3 - Overtemperature detected on CH7	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1463: Thermal protection relay 3 - Overtemperature detected on CH8	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1464: Thermal protection relay 3 - Overtemperature detected on CH1	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1465: Thermal protection relay 3 - Overtemperature detected on CH2	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1466: Thermal protection relay 3 - Overtemperature detected on CH3	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1467: Thermal protection relay 3 - Overtemperature detected on CH4	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1468: Thermal protection relay 3 - Overtemperature detected on CH5	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1469: Thermal protection relay 3 - Overtemperature detected on CH6	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

Fault/Alarm	Description	Possible Causes
A1470: Thermal protection relay 3 - Overtemperature detected on CH7	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1471: Thermal protection relay 3 - Overtemperature detected on CH8	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1472: Thermal protection relay 4 - CH1 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1473: Thermal protection relay 4 - CH2 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1474: Thermal protection relay 4 - CH3 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1475: Thermal protection relay 4 - CH4 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1476: Thermal protection relay 4 - CH5 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1477: Thermal protection relay 4 - CH6 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1478: Thermal protection relay 4 - CH7 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1479: Thermal protection relay 4 - CH8 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
F1480: Thermal protection relay 4 - Overtemperature detected on CH1	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1481: Thermal protection relay 4 - Overtemperature detected on CH2	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1482: Thermal protection relay 4 - Overtemperature detected on CH3	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1483: Thermal protection relay 4 - Overtemperature detected on CH4	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1484: Thermal protection relay 4 - Overtemperature detected on CH5	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1485: Thermal protection relay 4 - Overtemperature detected on CH6	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1486: Thermal protection relay 4 - Overtemperature detected on CH7	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1487: Thermal protection relay 4 - Overtemperature detected on CH8	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1488: Thermal protection relay 4 - Overtemperature detected on CH1	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1489: Thermal protection relay 4 - Overtemperature detected on CH2	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1490: Thermal protection relay 4 - Overtemperature detected on CH3	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1491: Thermal protection relay 4 - Overtemperature detected on CH4	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1492: Thermal protection relay 4 - Overtemperature detected on CH5	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1493: Thermal protection relay 4 - Overtemperature detected on CH6	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1494: Thermal protection relay 4 - Overtemperature detected on CH7	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

Fault/Alarm	Description	Possible Causes
A1495: Thermal protection relay 4 - Overtemperature detected on CH8	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1496: Thermal protection relay 5 - CH1 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1497: Thermal protection relay 5 - CH2 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1498: Thermal protection relay 5 - CH3 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1499: Thermal protection relay 5 - CH4 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1500: Thermal protection relay 5 - CH5 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1501: Thermal protection relay 5 - CH6 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1502: Thermal protection relay 5 - CH7 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1503: Thermal protection relay 5 - CH8 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
F1504: Thermal protection relay 5 - Overtemperature detected on CH1	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1505: Thermal protection relay 5 - Overtemperature detected on CH2	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1506: Thermal protection relay 5 - Overtemperature detected on CH3	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1507: Thermal protection relay 5 - Overtemperature detected on CH4	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1508: Thermal protection relay 5 - Overtemperature detected on CH5	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1509: Thermal protection relay 5 - Overtemperature detected on CH6	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1510: Thermal protection relay 5 - Overtemperature detected on CH7	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1511: Thermal protection relay 5 - Overtemperature detected on CH8	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1512: Thermal protection relay 5 - Overtemperature detected on CH1	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1513: Thermal protection relay 5 - Overtemperature detected on CH2	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1514: Thermal protection relay 5 - Overtemperature detected on CH3	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1515: Thermal protection relay 5 - Overtemperature detected on CH4	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1516: Thermal protection relay 5 - Overtemperature detected on CH5	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1517: Thermal protection relay 5 - Overtemperature detected on CH6	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1518: Thermal protection relay 5 - Overtemperature detected on CH7	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1519: Thermal protection relay 5 - Overtemperature detected on CH8	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

Fault/Alarm	Description	Possible Causes
A1520: Thermal protection relay 6 - CH1 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1521: Thermal protection relay 6 - CH2 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1522: Thermal protection relay 6 - CH3 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1523: Thermal protection relay 6 - CH4 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1524: Thermal protection relay 6 - CH5 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1525: Thermal protection relay 6 - CH6 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1526: Thermal protection relay 6 - CH7 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1527: Thermal protection relay 6 - CH8 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
F1528: Thermal protection relay 6 - Overtemperature detected on CH1	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1529: Thermal protection relay 6 - Overtemperature detected on CH2	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1530: Thermal protection relay 6 - Overtemperature detected on CH3	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1531: Thermal protection relay 6 - Overtemperature detected on CH4	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1532: Thermal protection relay 6 - Overtemperature detected on CH5	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1533: Thermal protection relay 6 - Overtemperature detected on CH6	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1534: Thermal protection relay 6 - Overtemperature detected on CH7	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1535: Thermal protection relay 6 - Overtemperature detected on CH8	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1536: Thermal protection relay 6 - Overtemperature detected on CH1	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1537: Thermal protection relay 6 - Overtemperature detected on CH2	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1538: Thermal protection relay 6 - Overtemperature detected on CH3	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1539: Thermal protection relay 6 - Overtemperature detected on CH4	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1540: Thermal protection relay 6 - Overtemperature detected on CH5	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1541: Thermal protection relay 6 - Overtemperature detected on CH6	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1542: Thermal protection relay 6 - Overtemperature detected on CH7	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1543: Thermal protection relay 6 - Overtemperature detected on CH8	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F2201: Timeout when energizing the inverter	The energization command was executed and the inverter did not energize within the predetermined time.	- Problem in the wiring between the inverter and the input cubicle.

Fault/Alarm	Description	Possible Causes
F2203: Start command	The Start command was performed and the motor did not start.	- Incorrect parameterization.
F2205: Synchronization timeout reached	The Inverter was unable to synchronize the motor and grid voltages within the predetermined time.	
F2207: Disable command	The Inverter was not disabled after the motor synchronous transfer.	- Incorrect parameterization, check the electrical project.
F2209: Closing of the inverter output contactor	The inverter output contactor closing command was sent and the closed status was not received.	- Problem in the wiring between the inverter and the output contactor.
F2211: Opening of the inverter output contactor	The inverter output contactor opening command was sent and the open status was not received.	- Problem in the wiring between the inverter and the output contactor.
F2213: Incorrect state of inverter output contactor	The inverter output contactor status is neither open nor closed.	- Problem in the wiring between the inverter and the output contactor.
F2215: Inverter output contactor failure	The inverter output contactor is in fault state.	- Check the integrity of the inverter output contactor.
F2217: Closing of the transfer contactor to the grid	The transfer contactor close command to the mains was sent and the closed status was not received.	- Problem in the wiring between the inverter and the output contactor.
F2219: Opening of the transfer contactor to the grid	The transfer contactor open command to the mains was sent and the open status was not received.	- Problem in the wiring between the inverter and the output contactor.
F2221: Incorrect state of the transfer contactor to the grid	The status of the transfer contactor to the mains is neither open nor closed.	- Problem in the wiring between the inverter and the output contactor.
F2223: Fault in the transfer contactor to the grid	The transfer contactor to the mains is in a fault state.	- Problem in the wiring between the inverter and the output contactor.
F2225: Inverter is not ready to enable	PWM enable command received by the inverter with general enable inactive and/or the input circuit breaker open.	- Improper maneuvering of the input circuit breaker. - Faulty input circuit breaker. - Faulty wiring.
F2227: Emergency stop	Emergency button pressed while inverter is operating.	
F2229: Timeout in FIELDBUS communication	Loss of communication with the FIELDBUS communication network.	- Check the status of the network master. - Check the network installation, broken cable or poor contact in the network connections.
F2231: Incorrect parameterization	The inverter parameter setting is invalid.	- Check the incorrect parameter in the application HMI and parameterize as indicated in the electrical project.
F2233: Open doors	The inverter doors are open.	- Incorrect opening of the inverter doors. - Faulty wiring.
A2301: Low battery voltage	Low battery voltage.	- Replace the battery.
A2302: 24 Vdc power supply overvoltage	Overvoltage in the 24 Vdc power supply.	- Voltage of the 24 Vdc power supply that feeds the control above the maximum value of 26.4 Vdc.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A2303: 24 Vdc power supply undervoltage	Undervoltage in the 24 Vdc power supply.	- Voltage of the 24 Vdc power supply that feeds the control below the minimum value of 21.6 Vdc.
F2322: Encoder/Motor wiring reversed	Fault related to the phase relation of the encoder signals, if C3.1.1 = 2 and C3.3.2.1.1 = 0 or 2. Note: - It is not possible to reset this fault during the self-tuning. - In this case, de-energize the inverter, solve the problem and then energize it.	- U, V, W wiring to the motor is reversed. - Encoder channels A and B are reversed. - Error in the encoder assembly position. - Motor with locked rotor or being dragged at the start.
F2330: Self-diagnosis fault	Self-Diagnosis Fault.	- Defect on the inverter internal circuits.
A2331: External alarm	-External alarm via DI. Note: - Necessary to set the DI in C7.10.1.	- DI input wiring (set in C7.10.1 to generate external alarm) open.
F2332: External fault	External fault via DI. Note: - Necessary to set the DI in C7.10.2.	- DI input wiring (set in C7.10.2 to actuate external fault) open.
F2333: Communication failure with the CCE board	Communication with the CCE control board was not performed correctly.	- Defective connection cable between AUI and CCE.
A2335: Serial communication timeout	It indicates that the MVW stopped receiving telegrams on the serial interface for a period longer than the setting programmed in C9.3.5. Note: - Ensure that the master always sends telegrams to the equipment in a shorter time than that set in C9.3.5. - It can be disabled by setting C9.3.5=0.0 s.	- Check network installation, broken cable or fault/poor contact on the connections with the network, and grounding.
A2336: Anybus Module Off-line	Alarm that indicates interruption in the Anybus communication.	- PLC went to the idle state. - Programming error. Number of I/O words set on the slave differs from the setting on the master. - Loss of communication with the master (broken cable, connector disconnected etc.).
A2337: Anybus Module access error	Alarm that indicates error of access to the Anybus communication module.	- Faulty Anybus module, not recognized or incorrectly installed.
A2338: No power supply on the CAN interface	It actuates when the CAN interface is powered and lack of power supply to the interface is detected. Note: - Measure if there is voltage within the allowed range between pins 1 and 5 of the CAN interface connector.	- CAN interface without power supply between pins 1 and 5 of the connector. - Power cables mixed up or reversed. - Poor contact on the CAN interface cable or connector.
A2339: Bus Off	Bus off error detection on the CAN interface. If the number of reception or transmission errors detected by the CAN interface is too high, the CAN controller can be taken to the bus off state, where it interrupts the communication and disables the CAN interface. In order to restore communication, it is necessary to turn the product off and on again, or to remove and reconnect the power to the CAN interface, so that communication can be restarted.	- Short circuit in the CAN circuit transmission cables. - Changed or reversed cables. - Network devices with different baud rates. - Termination resistors with incorrect values. - Termination resistors installed at one end of the main bus only. - CAN network installation done improperly.

Fault/Alarm	Description	Possible Causes
A2340: CANopen off-line	It occurs if the state of the CANopen node changes from operational to pre-operational. Note: - Check the operation of the error control mechanisms (Heartbeat/Node Guarding).	- The master is not sending the guarding/heartbeat telegrams at the programmed time. - Communication problems caused by lost telegrams or transmission delays.
A2341: Master in Idle	It actuates when communicating with the network master in Run mode, and transition to Idle mode is detected.	- Set the switch that controls the master operation of the master to Run or the corresponding bit on the configuration word of the master software. For further explanations, see the documentation of the master in use.
A2342: DeviceNet connection timeout	It indicates that one or more DeviceNet I/O connections has expired. It occurs when the cyclic communication between the master and the product is interrupted.	- Check the status of the network master. - Check the network installation, broken cable or poor contact on the connections with the network.
A2347: SNTP connection timeout	It indicates that the inverter tried to connect to the NTP server and got no response. It occurs after starting connection with the NTP server and the server has not returned the response requested by the inverter.	- Check the configuration and IP address. - Check if the NTP server is active.
A2349: EtherNet/IP Communication Offline	It indicates communication error with EtherNet/IP master. It occurs when, for any reason, after the cyclic communication of the master with the product is started, this communication is interrupted. This is detected if the I/O Exclusive Owner connection times out.	- Check the status of the network master. - Check the network installation, broken cable or failed/bad contact in the network connections.
A2350: Modbus TCP Timeout	It indicates that the equipment stopped receiving valid telegrams for a period longer than the setting in C9.6.3. The time counting starts after the first valid telegram is received.	- Check the network installation, broken cable or poor contact on the connections with the network, grounding. - Ensure that the Modbus TCP client always sends telegrams to the equipment in a shorter time than the set in C9.6.3. - Disable the Timeout function in C9.6.3.
A2354: Control circuit overtemperature	High temperature in the control circuit. Note: - The alarm can be disabled by setting C7.5.1.	- High ambient temperature around the inverter (>50 °C) and high output current. - Locked or defective fan. - Inverter heatsink too dirty.
F2355: Control circuit overtemperature	Overtemperature in the control circuit.	- High ambient temperature around the inverter (>50 °C) and high output current. - Locked or defective fan.
A2356: Inverter undertemperature	Undertemperature measured at the sensors of the control below -30 °C. Note: - The alarm can be disabled by setting C7.5.1.	- Ambient temperature around the inverter $\leq$ -30 °C.
F2357: Inverter undertemperature	Undertemperature measured at the sensors of the IGBTs, rectifier, power and/or control below -30 °C.	- Ambient temperature around the inverter $\leq$ -30 °C.
F2358: Corrupted settings	Inverter settings are invalid. Note: - Restore the factory default in parameter C12.1. If the problem persists, contact WEG's technical support or representative.	- Parameter settings file cannot be restored correctly.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F2373: Serial communication timeout	It indicates that the MVW stopped receiving telegrams on the serial interface for a period longer than the setting programmed in C9.3.5. Note: - Ensure that the master always sends telegrams to the equipment in a shorter time than that set in C9.3.5. - It can be disabled by setting C9.3.5=0.0 s.	- Check network installation, broken cable or fault/poor contact on the connections with the network, and grounding.
F2374: Bus Off	Bus off error detection on the CAN interface. If the number of reception or transmission errors detected by the CAN interface is too high, the CAN controller can be taken to the bus off state, where it interrupts the communication and disables the CAN interface. In order to restore communication, it is necessary to turn the product off and on again, or to remove and reconnect the power to the CAN interface, so that communication can be restarted.	- Short circuit in the CAN circuit transmission cables. - Changed or reversed cables. - Network devices with different baud rates. - Termination resistors with incorrect values. - Termination resistors installed at one end of the main bus only. - CAN network installation done improperly.
F2375: Anybus Module Off-line	Fault that indicates interruption in the Anybus communication.	- PLC went to the idle state. - Programming error. Number of I/O words set on the slave differs from the setting on the master. - Loss of communication with the master (broken cable, connector disconnected etc.).
F2376: CANopen Off-line	It occurs if the state of the CANopen node changes from operational to pre-operational. Note: - Check the operation of the error control mechanisms (Heartbeat/Node Guarding).	- The master is not sending the guarding/heartbeat telegrams at the programmed time. - Communication problems caused by lost telegrams or transmission delays.
F2377: Anybus Module access error	Fault that indicates error of access to the Anybus communication module.	- Faulty Anybus-CC module, not recognized or incorrectly installed.
F2378: No power supply on the CAN interface	It actuates when the CAN interface is powered and lack of power supply to the interface is detected. Note: - Measure if there is voltage within the allowed range between pins 1 and 5 of the CAN interface connector.	- CAN interface without power supply between pins 1 and 5 of the connector. - Power cables mixed up or reversed. - Poor contact on the CAN interface cable or connector.
F2379: Master in Idle	It actuates when communicating with the network master in Run mode, and transition to Idle mode is detected.	- Set the switch that controls the master operation of the master to Run or the corresponding bit on the configuration word of the master software. For further explanations, see the documentation of the master in use.
F2380: DeviceNet connection timed out	It indicates that one or more DeviceNet I/O connections has expired. It occurs when the cyclic communication between the master and the product is interrupted.	- Check the status of the network master. - Check the network installation, broken cable or poor contact on the connections with the network.
F2385: EtherNet/IP communication offline	It indicates communication error with EtherNet/IP master. It occurs when, for any reason, after the cyclic communication of the master with the product is started, this communication is interrupted. This is detected if the I/O Exclusive Owner connection times out.	- Check the status of the network master. - Check the network installation, broken cable or failed/bad contact in the network connections.

Fault/Alarm	Description	Possible Causes
F2386: Modbus TCP Timeout	It indicates that the equipment stopped receiving valid telegrams for a period longer than the setting in C9.6.3. The time counting starts after the first valid telegram is received.	- Check the network installation, broken cable or poor contact on the connections with the network, grounding. - Ensure that the Modbus TCP client always sends telegrams to the equipment in a shorter time than the set in C9.6.3. - Disable the Timeout function in C9.6.3.
A2430: PID PV low level	It indicates that the control process variable (A2.1.3) is at a low level.	- Control process variable (A2.1.3) remained for 150 ms with the value lower than the value set in A2.3.6.2.
F2431: PID PV low level	It indicates the motor was switched off due to the low level of the control process variable	- Control process variable (A2.1.3) remained for a certain amount of time (A2.3.6.3) with the value lower than the value set in A2.3.6.2.
A2432: PID PV high level	It indicates that the control process variable (A2.1.3) is at a high level.	- Control process variable (A2.1.3) remained for 150 ms with the value higher than the value set in A2.3.6.5.
F2433: PID PV high level	It indicates the motor was switched off due to the high level of the control process variable	- Control process variable (A2.1.3) remained for a certain amount of time (A2.3.6.6) with the value higher than the value set in A2.3.6.5.
F2608: Code flow failure	Internal fault during inverter operation. Note: Reset the inverter. - Load the factory default.	- If the problem persists, please contact technical support.
A2610: Parameter storage full	There is no more space in memory to store new user parameters. Note: - Any parameter changes made while this alarm is active may not be kept after restarting the inverter. - During the next power-up of the product, a routine indicated by the memory usage optimization screen frees up memory space to allow new settings.	- Many changes in configuration parameters (regardless of whether via HMI, WPS, networks or application) without restarting the product. - Many user parameter downloads via SoftPLC without restarting the product.
A2702: Inverter Disabled	Indicates that the General Enable command is Inactive.	- Run/Stop command of the SoftPLC application equal to Run, or the movement block was enabled with the "General Enable" command disabled.
A2706: SPLC refer. not progr.	Indicates that the softPLC reference has not been programmed.	- It occurs when a movement block is enabled and the speed reference is not set for SoftPLC (check C4.3.1.2.1 or C4.3.1.2.2).
A2708: SoftPLC not running	Indicates that the SoftPLC application is not running.	- Check the SoftPLC status in S6.1.1 and the action configuration for application not running in C10.1.3.
F2709: SoftPLC not running	Indicates that the SoftPLC application is not running.	- Check the SoftPLC status in S6.1.1 and the action configuration for application not running in C10.1.3.
F3000: Error during accessory update	Error during accessory firmware update.	- Outdated inverter firmware version.
A3012: Slot X AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F3013: Slot X AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3014: Slot X AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3015: Slot X AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3100: Slot A incompatible accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3101: Slot A initialization error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3102: Slot A required accessory	Fault indicating that the type of accessory that should be connected to the slot does not match the connected accessory.	- Incorrect accessory connected to the slot. - Slot parameter C1.7.1.1 is incorrectly set.
F3103: Slot A accessory connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3104: Slot A high temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3105: Slot A overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3106: Slot A enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3107: Slot A enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3108: Slot A enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3109: Slot A enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.

Fault/Alarm	Description	Possible Causes
A3110: Slot A enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3111: Slot A enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3112: Slot A AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3113: Slot A AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3114: Slot A AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3115: Slot A AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3116: Slot A AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3117: Slot A AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3125: Slot A temp. sensor wrong HW config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3126: Slot A temperature sensor 1 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3127: Slot A temperature sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3128: High temperature on Slot A sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3129: Slot A sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A3130: Slot A temperature sensor 2 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3131: Slot A temperature sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3132: High temperature on Slot A sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3133: Slot A sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3134: Slot A temperature sensor 3 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3135: Slot A temperature sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3136: High temperature on Slot A sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3137: Slot A sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3138: Slot A temperature sensor 4 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3139: Slot A temperature sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3140: High temperature on Slot A sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3141: Slot A sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3142: Slot A temperature sensor 5 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3143: Slot A temperature sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3144: High temperature on Slot A sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3145: Slot A sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

Fault/Alarm	Description	Possible Causes
A3146: Slot A temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3147: Slot A temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3148: High temperature on Slot A sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3149: Slot A sensor 6 overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
F3200: Slot B incompatible accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3201: Slot B initialization error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3202: Slot B required accessory	Fault indicating that the type of accessory that should be connected to the slot does not match the connected accessory.	- Incorrect accessory connected to the slot. - Slot parameter C1.7.1.1 is incorrectly set.
F3203: Slot B accessory connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3204: Slot B high temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3205: Slot B overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3206: Slot B enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3207: Slot B enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3208: Slot B enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3209: Slot B enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A3210: Slot B enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3211: Slot B enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3212: Slot B AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3213: Slot B AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3214: Slot B AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3215: Slot B AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3216: Slot B AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3217: Slot B AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3225: Slot B temp. sensor wrong HW config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3226: Slot B temperature sensor 1 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3227: Slot B temperature sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3228: High temperature on Slot B sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3229: Slot B sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

Fault/Alarm	Description	Possible Causes
A3230: Slot B temperature sensor 2 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3231: Slot B temperature sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3232: High temperature on Slot B sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3233: Slot B sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3234: Slot B temperature sensor 3 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3235: Slot B temperature sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3236: High temperature on Slot B sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3237: Slot B sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3238: Slot B temperature sensor 4 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3239: Slot B temperature sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3240: High temperature on Slot B sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3241: Slot B sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3242: Slot B temperature sensor 5 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3243: Slot B temperature sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3244: High temperature on Slot B sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3245: Slot B sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A3246: Slot B temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3247: Slot B temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3248: High temperature on Slot B sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3249: Slot B sensor 6 overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
F3300: Slot C incompatible accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3301: Slot C initialization error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3302: Slot C required accessory	Fault indicating that the type of accessory that should be connected to the slot does not match the connected accessory.	- Incorrect accessory connected to the slot. - Slot parameter C1.7.1.1 is incorrectly set.
F3303: Slot C accessory connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3304: Slot C high temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3305: Slot C overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3306: Slot C enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3307: Slot C enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3308: Slot C enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3309: Slot C enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.

Fault/Alarm	Description	Possible Causes
A3310: Slot C enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3311: Slot C enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3312: Slot C AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3313: Slot C AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3314: Slot C AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3315: Slot C AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3316: Slot C AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3317: Slot C AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3325: Slot C temp. sensor wrong HW config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3326: Slot C temperature sensor 1 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3327: Slot C temperature sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3328: High temperature on Slot C sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3329: Slot C sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A3330: Slot C temperature sensor 2 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3331: Slot C temperature sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3332: High temperature on Slot C sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3333: Slot C sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3334: Slot C temperature sensor 3 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3335: Slot C temperature sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3336: High temperature on Slot C sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3337: Slot C sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3338: Slot C temperature sensor 4 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3339: Slot C temperature sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3340: High temperature on Slot C sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3341: Slot C sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3342: Slot C temperature sensor 5 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3343: Slot C temperature sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3344: High temperature on Slot C sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3345: Slot C sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

Fault/Alarm	Description	Possible Causes
A3346: Slot C temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3347: Slot C temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3348: High temperature on Slot C sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3349: Slot C sensor 6 overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
F3400: Slot D incompatible accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3401: Slot D initialization error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3402: Slot D required accessory	Fault indicating that the type of accessory that should be connected to the slot does not match the connected accessory.	- Incorrect accessory connected to the slot. - Slot parameter C1.7.1.1 is incorrectly set.
F3403: Slot D accessory connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3404: Slot D high temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3405: Slot D overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3406: Slot D enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3407: Slot D enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3408: Slot D enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3409: Slot D enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A3410: Slot D enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3411: Slot D enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3412: Slot D AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3413: Slot D AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3414: Slot D AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3415: Slot D AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3416: Slot D AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3417: Slot D AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3425: Slot D temp. sensor wrong HW config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3426: Slot D temperature sensor 1 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3427: Slot D temperature sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3428: High temperature on Slot D sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3429: Slot D sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

Fault/Alarm	Description	Possible Causes
A3430: Slot D temperature sensor 2 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3431: Slot D temperature sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3432: High temperature on Slot D sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3433: Slot D sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3434: Slot D temperature sensor 3 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3435: Slot D temperature sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3436: High temperature on Slot D sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3437: Slot D sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3438: Slot D temperature sensor 4 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3439: Slot D temperature sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3440: High temperature on Slot D sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3441: Slot D sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3442: Slot D temperature sensor 5 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3443: Slot D temperature sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3444: High temperature on Slot D sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3445: Slot D sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A3446: Slot D temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3447: Slot D temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3448: High temperature on Slot D sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3449: Slot D sensor 6 overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
F3500: Slot E incompatible accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3501: Slot E initialization error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3503: Slot E accessory connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3504: Slot E high temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3505: Slot E overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3506: Slot E enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3507: Slot E enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3508: Slot E enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3509: Slot E enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3510: Slot E enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.

Fault/Alarm	Description	Possible Causes
F3511: Slot E enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3512: Slot E AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3513: Slot E AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3514: Slot E AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3515: Slot E AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3516: Slot E AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3517: Slot E AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3525: Slot E temp. sensor wrong HW config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3526: Slot E temperature sensor 1 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3527: Slot E temperature sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3528: High temperature on Slot E sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3529: Slot E sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3530: Slot E temperature sensor 2 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F3531: Slot E temperature sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3532: High temperature on Slot E sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3533: Slot E sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3534: Slot E temperature sensor 3 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3535: Slot E temperature sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3536: High temperature on Slot E sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3537: Slot E sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3538: Slot E temperature sensor 4 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3539: Slot E temperature sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3540: High temperature on Slot E sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3541: Slot E sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3542: Slot E temperature sensor 5 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3543: Slot E temperature sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3544: High temperature on Slot E sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3545: Slot E sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3546: Slot E temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.

Fault/Alarm	Description	Possible Causes
F3547: Slot E temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3548: High temperature on Slot E sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3549: Slot E sensor 6 overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
F3600: Slot F incompatible accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3601: Slot F initialization error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3602: Slot F required accessory	Fault indicating that the type of accessory that should be connected to the slot does not match the connected accessory.	- Incorrect accessory connected to the slot. - Slot parameter C1.7.1.1 is incorrectly set.
F3603: Slot F accessory connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3604: Slot F high temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3605: Slot F overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3606: Slot F enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3607: Slot F enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3608: Slot F enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3609: Slot F enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3610: Slot F enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F3611: Slot F enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3612: Slot F AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3613: Slot F AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3614: Slot F AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3615: Slot F AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3616: Slot F AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3617: Slot F AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3625: Slot F temp. sensor wrong HW config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3626: Slot F temperature sensor 1 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3627: Slot F temperature sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3628: High temperature on Slot F sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3629: Slot F sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3630: Slot F temperature sensor 2 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.

Fault/Alarm	Description	Possible Causes
F3631: Slot F temperature sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3632: High temperature on Slot F sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3633: Slot F sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3634: Slot F temperature sensor 3 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3635: Slot F temperature sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3636: High temperature on Slot F sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3637: Slot F sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3638: Slot F temperature sensor 4 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3639: Slot F temperature sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3640: High temperature on Slot F sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3641: Slot F sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3642: Slot F temperature sensor 5 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3643: Slot F temperature sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3644: High temperature on Slot F sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3645: Slot F sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3646: Slot F temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F3647: Slot F temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3648: High temperature on Slot F sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3649: Slot F sensor 6 overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
F3700: Slot G incompatible accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3701: Slot G initialization error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3702: Slot G required accessory	Fault indicating that the type of accessory that should be connected to the slot does not match the connected accessory.	- Incorrect accessory connected to the slot. - Slot parameter C1.7.1.1 is incorrectly set.
F3703: Slot G accessory connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3704: Slot G high temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3705: Slot G overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3706: Slot G enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3707: Slot G enc. A cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3708: Slot G enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3709: Slot G enc. B cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3710: Slot G enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.

Fault/Alarm	Description	Possible Causes
F3711: Slot G enc. Z cable disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3712: Slot G AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3713: Slot G AI1 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3714: Slot G AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3715: Slot G AI2 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3716: Slot G AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3717: Slot G AI3 Cable disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3725: Slot G temp. sensor wrong HW config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3726: Slot G temperature sensor 1 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3727: Slot G temperature sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3728: High temperature on Slot G sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3729: Slot G sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3730: Slot G temperature sensor 2 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F3731: Slot G temperature sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3732: High temperature on Slot G sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3733: Slot G sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3734: Slot G temperature sensor 3 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3735: Slot G temperature sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3736: High temperature on Slot G sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3737: Slot G sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3738: Slot G temperature sensor 4 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3739: Slot G temperature sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3740: High temperature on Slot G sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3741: Slot G sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3742: Slot G temperature sensor 5 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3743: Slot G temperature sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3744: High temperature on Slot G sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3745: Slot G sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3746: Slot G temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.

Fault/Alarm	Description	Possible Causes
F3747: Slot G temperature sensor 6 error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3748: High temperature on Slot G sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3749: Slot G sensor 6 overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

3 SAFETY INSTRUCTIONS

This manual contains the information required to program the MVW frequency inverter. To put the product into operation correctly, it is necessary to follow the instructions in this manual and to have appropriate training or technical qualification.

3.1 SAFETY NOTICES IN THE MANUAL

The following safety notices are used in this manual:



DANGER!

This notice informs the user about the risk of death, serious injury, or considerable property damage.



ATTENTION!

This notice informs the user about possible considerable property damage.



NOTE!

The information in this notice is important for proper understanding and correct operation of the product.

3.2 SAFETY NOTICES ON THE PRODUCT

The following symbols are affixed to the product and serve as safety notices:



High voltages are present.



Components sensitive to electrostatic discharge. Do not touch them.



Mandatory connection to the protective earth (PE).



Connection of the shield to the ground.



Hot surface. Do not touch.

3.3 PRELIMINARY RECOMMENDATIONS



DANGER!

Only qualified personnel familiar with the MVW inverter and associated equipment must plan or perform the installation, commissioning, operation, and maintenance of this equipment. All safety instructions contained in this manual and/or defined by local regulations must be followed. Failure to follow the safety instructions may result in risk of death and/or damage to the equipment.



NOTE!

Read the MVW frequency inverter User Manual completely before installing or operating the MVW.

SAFETY INSTRUCTIONS



NOTE!

For the purposes of this manual, qualified persons are those trained to:

1. Install, ground, energize, and operate the MVW in accordance with this manual and applicable legal safety procedures.
2. Use protective equipment in accordance with the established standards.
3. Provide first aid.



DANGER!

Always disconnect the main power supply before touching any electrical component associated with the MVW inverter.

Many components may remain charged with high voltages and/or moving (e.g., fans) even after the AC input power supply has been disconnected or switched off.

Wait at least 10 minutes to ensure the capacitors are fully discharged.

Always connect the equipment enclosure to the protective earth (PE) at the appropriate point.



ATTENTION!

Electronic boards contain components sensitive to electrostatic discharge. Do not touch components or connectors directly. If necessary, first touch a grounded metal enclosure or use an appropriate grounding wrist strap.

Do not perform any dielectric withstand test on the MVW inverter!
If required, consult WEG.



NOTE!

Frequency inverters may interfere with other electronic equipment. Follow the precautions recommended in the Installation and Connection chapter of the User Manual to minimize these effects.

4 ABOUT THIS MANUAL

This manual provides the information required to configure the functions and parameters of the MVW frequency inverter. It must be used together with the MVW User Manual. Reproduction of this manual, in whole or in part, is prohibited without the manufacturer's written permission.

Due to the wide range of functions of this product, it can be applied in ways other than those presented here. This manual is not intended to cover all possible MVW applications. The manufacturer assumes no responsibility for MVW use that is not based on the instructions in this manual.



NOTE!

This text is intended to provide additional information to facilitate MVW use and programming in specific applications.

4.1 TERMINOLOGY AND DEFINITIONS

4.1.1 Terms and definitions used in this manual

Rectifier: Inverter input circuit that converts the AC input voltage to DC. Depending on the model, it may be diode-based or an active front end.

Pre-charge circuit: Charges the DC bus capacitors with limited current, reducing current peaks when the inverter is energized.

IGBT: Basic component of the output inverter bridge, short for "*Insulated Gate Bipolar Transistor*". It operates as an electronic switch in saturation (closed switch) and cutoff (open switch) modes.

PTC: Resistor whose resistance value in ohms increases with temperature; used as a temperature sensor in motors.

NTC: Resistor whose resistance value in ohms decreases as temperature increases; used as a temperature sensor in power modules.

HMI: Human-Machine Interface; device that allows motor control and parameter viewing/editing. It includes control keys, navigation keys, and a graphic LCD display.

RAM memory: Volatile random-access memory, short for "*Random Access Memory*".

FLASH memory: Non-volatile memory.

RFI filter: Filter that reduces radio-frequency interference, short for "*Radio Frequency Interference Filter*".

PWM: Pulse-width modulation, short for "*Pulse Width Modulation*". Pulsed voltage that feeds the motor.

Switching frequency: PWM carrier frequency used to generate the firing pulses for the inverter bridge IGBTs, usually specified in kHz.

General enable: When active, it accelerates the motor according to the acceleration ramp if Run/Stop = Run. When inactive, PWM pulses are immediately blocked. It can be commanded by a digital input programmed for this function, via communication networks, or via SoftPLC.

Run/Stop: Inverter function that, when active (Run), accelerates the motor according to the acceleration ramp up to the reference speed and, when inactive (Stop), decelerates the motor according to the deceleration ramp until it stops. It can be commanded via the HMI keys (🟢 = Run and 🔴 = Stop), by a digital input programmed for this function, via communication networks, or via SoftPLC.

WPS: Programming software, short for "*WEG Programming Suite*".

Forward: Rotation direction with a positive speed reference.

Reverse: Rotation direction opposite to forward.

SM: Synchronous machine, short for "*Synchronous Machine*".

PM: Permanent-magnet synchronous machine, short for "*Permanent-Magnet Synchronous Machine*".

IPSM: Interior permanent-magnet synchronous machine, short for "*Interior Permanent-Magnet Synchronous Machine*".

SPSM: Surface permanent-magnet synchronous machine, short for "*Surface Permanent-Magnet Synchronous Machine*".

HSRM: Hybrid synchronous reluctance machine assisted by magnets, short for "*Hybrid Synchronous Reluctance Machine*".

5 ABOUT THE MVW

The MVW can be customized (engineered) to meet our customers' needs and technical specifications. The information contained in this document may vary depending on size, technical recommendations, performance data, and the need to include optional components.

In addition to this manual, a detailed converter design is part of the documentation delivered to the customer. This design includes all electrical, mechanical, parameterization, and interface/installation information with other equipment for the supplied MVW.

The MVW, like other WEG products, is continuously evolving, both in its internal components (hardware) and in its programming (software/firmware). If you have any questions about the equipment and the accompanying documentation, please contact the communication channels provided by WEG.

WEG is not responsible for the improper use of the information contained in this manual.

5.1 AVAILABLE MODELS

The MVW medium-voltage inverter line includes different models, classified by voltage level and the rated current of the power cells. Different MVW models may have different mechanical designs and part codes. For construction details of the available mechanical designs, refer to the User Manual. For models with rated voltage above 8000 V, contact WEG.



Figure 5.1: General illustration of the panel (B10 mechanical design)



ATTENTION!

It is very important to check that the inverter software version matches the one indicated on the first page of this manual.

6 SOFTWARE VERSIONS

Software versions define the features and behavior of the MVW inverter. All software versions installed in the product are available for viewing. The set of all software is referred to as the package. The package, as per S1.2.1, identifies the set of software versions of all product microcontrollers and must be used as a reference to identify the product software version. This manual is updated according to the package version (indicated on the back cover).

Software versions follow the 00.00.00 format and the following evolution rules:




Figure 6.1: Software version format

- Group 1: the first two digits are updated when a major change is required, for example, a change in the inverter hardware that makes the software incompatible.
- Group 2: the middle two digits are updated when new features are added to the software, for example, a new function or a new parameter.
- Group 3: the last two digits are updated when the software receives fixes (*bug fixes*), for example, fixes to a specific feature or to the inverter's overall behavior.

7 S STATUS

This menu provides status information for the inverter, motor, control accessories, and networks. It also provides access to information related to the inverter functional safety. Allows viewing the MVW read-only variables.



NOTE!

All parameters in this menu are view-only on the HMI and cannot be changed by the user, except when they are linked to parameters in the **Settings** menu.

S1 INVERTER

It allows viewing the characteristics and status of the MVW.

S1.1 Status

It allows viewing the operating status of the MVW.

S1.1 Status

.1 Inverter	0 ... 10
.4 Config	0 ... 33
.5 Inverter parallel operation	0 ... 4 Bit

.1 Inverter It indicates one of the possible inverter status. The following table contains the description of each status.

Indication	Description
0 = Ready	It indicates that the inverter is ready to drive the motor Precharge OK, general enable active
1 = Run	It indicates that the inverter is driving the motor
2 = Undervoltage	It indicates that the inverter has insufficient supply voltage for operation (undervoltage) and will not accept a command to start the motor
3 = Fault	It indicates that the inverter has a fault active
4 ... 5 = Not used	Not used
6 = Booting	It indicates that communication with the power board has not been established
7 = Disabled	It indicates that the inverter is disabled Precharge OK, general enable inactive
8 ... 9 = Not used	Not used
10 = Sleep	It indicates that the sleep mode of the inverter PID controller is active

.4 Config It indicates if the MVW is in CONFIG status and, if so, which input condition is leading to this situation.

Indication	Description
0 = No Config	It indicates that the MVW is not in the CONFIG status
1 = Run/Stop DIx	It indicates that the Run/Stop command source of Remote 1 and/or Remote 2 mode has been set to Run/Stop via DI mode, but no DI has been specified
2 = Forward R1	It indicates that the Run/Stop command source of Remote 1 mode has been set to Forward/Reverse mode via DI, but no forward DI has been specified or the Direction of Rotation command source is not set to Forward/Reverse via DI mode
3 = Forward R2	It indicates that the Run/Stop command source of Remote 2 mode has been set to Forward/Reverse mode via DI, but but the forward DI was not specified
4 = Reverse R1	It indicates that the Run/Stop command source of Remote 1 mode has been set to Forward/Reverse mode via DI, but but the reverse DI was not specified
5 = Reverse R2	It indicates that the Run/Stop command source of Remote 2 mode has been set to Forward/Reverse mode via DI, but but the reverse DI was not specified
6 = 3-wire Start/Stop	It indicates that the Run/Stop command source of Remote 1 and/or Remote 2 mode has been set to 3-wire Start/Stop via DI mode, but no DI has been specified

Indication	Description
7 = Direction of Rotation Dlx	It indicates that the Direction of Rotation command source of Remote 1 and/or Remote 2 mode has been set to "Direction of Rotation DI", but no DI has been specified in C4.2.3.8
8 = JOG Dlx	It indicates that the JOG command source of Remote 1 and/or Remote 2 mode has been set to Digital Input (DI) mode, but no DI has been specified
9 = R1/R2 Dlx	It indicates that the selection command source between Remote 1 and Remote 2 modes has been set to Digital Input (DI) mode, but no DI has been specified
10 = Ramp selection Dlx	It indicates that the ramp selection command source has been set to Digital Input (DI) mode, but no DI has been specified
11 = Oriented Startup	It indicates that the Oriented Startup is running
12 = Backup	It indicates that the Parameter Copy functions are running
13 = Not used	Not used
14 = SS1 configuration	It indicates that the SS1 is not properly set
15 = Switching Frequency	It indicates that the user and/or minimum switching frequencies are not properly set
16 = Undefined model	It indicates that there is an incompatibility in the drive model recorded. Perform a factory default to fix this problem
17 = Encoder Vector Control	It indicates that the Vector Control with Encoder type has been selected, but there is no Encoder accessory defined in any slot
18 = ENC Acc. not configured	It indicates that the Encoder accessory was selected for one of the slots, but it is not connected or set to in the corresponding slot
19 = AIx/FIx Speed Ref.	It indicates that the speed reference source for Remote 1 and/or Remote 2 mode has been set to Analog Input (AI) or Frequency Input (FI) mode, but no AI or FI has been specified
20 = Not used	Not used
21 = General Enable Dlx	It indicates that the General Enable command source for Remote 1 and/or Remote 2 mode has been set to Digital Input (DI) mode, but no DI has been specified
22 = Multispeed	It indicates that the speed reference source of Remote 1 and/or Remote 2 mode has been set to Multispeed mode, but no DI has been specified
23 = Not used	Not used
24 = Electronic Potentiometer	It indicates that the speed reference source of Remote 1 and/or Remote 2 mode has been set to Electronic Potentiometer mode, but no DI has been specified
25 = FI used as DI	This status occurs when the user tries to configure some command that requires a DI with one that was previously configured to be an FI, and vice versa
26 = AIx/FIx Torque Ref.	It indicates that the torque reference source for Remote 1 and/or Remote 2 mode has been set to Analog Input (AI) or Frequency Input (FI) mode, but no AI or FI has been specified
27 = SP Source PID	It indicates that the PID Controller Setpoint source has been set to Analog Input (AI) mode, but no AI has been specified
28 = PV Source PID	It indicates that the PID Controller Process Variable source was set to Analog Input (AI) mode, but no AI was specified
29 = DI Source PID	It indicates that the Manual/Auto command source has been set to Digital Input (DI) mode, but no DI has been specified
30 = Supply Voltage	It indicates that the inverter supply voltage setting (type or rated voltage) is inappropriate for the model used
31 ... 33 = Not used	Not used

.5 Inverter parallel operation Indicates the state of inverter parallelism.

Bit	Value/Description
Bit 0 ... 1 Mode	0 = Disabled: The inverter is operating independently, without paralleling 1 = Master: The inverter is operating as the master in a set of inverters connected in parallel. 2 = Slave: The inverter is operating as a follower in the parallel inverter topology 3 = Master rack: The control unit (without the power stage) acts as the master in the parallel inverter set.
Bit 2 ... 4 Synchronization	0 = Desativado 1 = Awaiting communication 2 = Synchronizing 3 = Synchronized 4 = Ready
Bit 5 ... 7 Follower 1 status	0 = Desativado 1 = Awaiting communication 2 = Synchronizing 3 = Synchronized 4 = Ready 5 = PWM habilitado
Bit 8 ... 10 Follower 2 status	0 = Desativado 1 = Awaiting communication 2 = Synchronizing 3 = Synchronized 4 = Ready 5 = PWM habilitado
Bit 11 ... 13 Follower 3 status	0 = Desativado 1 = Awaiting communication 2 = Synchronizing 3 = Synchronized 4 = Ready 5 = PWM habilitado

S1.2 Software version

It indicates the software versions contained in all microcontrollers installed on the MVW.

S1.2 Software version

.1 AUI

.1 AUI It indicates the version of the software package, which is formed by the set of program files saved in the MVW microcontrollers.

S1.4 Accessory data

It presents the control accessories that are installed in the MVW.

S1.4.1 Backplane

It allows viewing the model of the Backplane that is connected to the MVW.

S1.4.1 Backplane

.1 Model 0 ... 2

.1 Model Model of the Backplane installed.

Indication	Description
0 = Disconnected	It indicates that there is no Backplane connected to the MVW
1 = 4 SLOTS	It indicates that the 4-position (Slot) Backplane is connected to the MVW
2 = 7 SLOTS	It indicates that the 7-position (Slot) Backplane is connected to the MVW

S1.4.2 Slot A to S1.4.8 Slot G

It allows viewing Slot accessory information.

S STATUS

S1.4.2 Slot A

S1.4.3 Slot B

S1.4.4 Slot C

S1.4.5 Slot D

S1.4.6 Slot E

S1.4.7 Slot F

S1.4.8 Slot G

.1 Accessory identified 0 ... 10

.1 Accessory identified Model of the accessory installed.

Indication	Description
0 = Unknown	The accessory installed in the Slot is not recognized by this firmware version
1 = No Accessory	It indicates that the Slot has no accessories
2 = IOAI-01	Accessory with analog inputs and outputs
3 = IOD-01	Accessory with digital inputs and outputs
4 = REL-01	Accessory with digital relay outputs
5 = TEMP-01	Accessory with isolated inputs for PTC/PT100/PT1000 sensors
6 = ENC-01	Accessory for incremental encoder connection
7 = Not used	Not used
8 = CCAN-W	Communication accessory for CAN interface
9 = C...-N (Anybus)	Communication accessory for Anybus-CC module
10 = Not used	Not used



NOTE!

Control accessories can be installed in any available slot. It is only possible to use one communication module of each type. Except for explicitly listed cases, up to 7 accessories of the same type can be used.

S1.5 Date/Hour

It allows viewing the date and time setting of the MVW.

S1.5 Date/Hour

.1 Actual YYYY-MM-DD HH:MM:SS
.2 Time zone 0 ... 52

.1 Actual It indicates the actual date (YYYY-MM-DD) and time (HH:MM:SS) of the MVW.

.2 Time zone Setting of the time zone where the product is applied.

The options are shown in the table below.

Table 7.5: Time zone where the product is applied

Time Zone Options					
0 = UTC-12:00	9 = UTC-07:30	18 = UTC-03:00	27 = UTC+01:30	36 = UTC+06:00	45 = UTC+10:30
1 = UTC-11:30	10 = UTC-07:00	19 = UTC-02:30	28 = UTC+02:00	37 = UTC+06:30	46 = UTC+11:00
2 = UTC-11:00	11 = UTC-06:30	20 = UTC-02:00	29 = UTC+02:30	38 = UTC+07:00	47 = UTC+11:30
3 = UTC-10:30	12 = UTC-06:00	21 = UTC-01:30	30 = UTC+03:00	39 = UTC+07:30	48 = UTC+12:00
4 = UTC-10:00	13 = UTC-05:30	22 = UTC-01:00	31 = UTC+03:30	40 = UTC+08:00	49 = UTC+12:30
5 = UTC-09:30	14 = UTC-05:00	23 = UTC-00:30	32 = UTC+04:00	41 = UTC+08:30	50 = UTC+13:00
6 = UTC-09:00	15 = UTC-04:30	24 = UTC+00:00	33 = UTC+04:30	42 = UTC+09:00	51 = UTC+13:30
7 = UTC-08:30	16 = UTC-04:00	25 = UTC+00:30	34 = UTC+05:00	43 = UTC+09:30	52 = UTC+14:00
8 = UTC-08:00	17 = UTC-03:30	26 = UTC+01:00	35 = UTC+05:30	44 = UTC+10:00	

S1.6 Control words

It allows viewing the status of the HMI, DI and global control words. Each bit of this word represents a command that can be executed on the inverter.

S1.6 Control words

.1 Global	0 ... 7 Bit
.2 HMI	0 ... 7 Bit
.3 DI	0 ... 7 Bit

.1 Global Indicates the status of the MVW global control word.

This is the effective command word for the MVW.

The global control word bits are generated from the specific control words of each source according to the command mode (Local/Remote) and the settings in the C4.2.1 and C4.2.2 menus.



NOTE!

The general enable command may contain a digital input that acts together with the chosen command source. Both must be active/inactive simultaneously for the command to take place. When parameter is set C4.2.3.1 to "Inactive", the general enable command is assigned only by the source set (C4.2.1.1 or C4.2.2.1).



NOTE!

The quick stop command may contain a digital input that acts together with the chosen command source. Both must be active/inactive simultaneously for the command to take place. When parameter C4.2.3.7 is set to "Inactive", the fast stop command is assigned only by the source set (C4.2.1.2 or C4.2.2.2).



NOTE!

The fault reset command occurs through any command source, regardless of the command mode (Local/Remote 1/Remote 2) or source set.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.2 HMI It indicates the status of the control word via HMI.

For the commands of this parameter to be executed, the inverter must be programmed to be controlled via HMI. This programming is done through the menu C4.

HMI Control Word:

S STATUS

- When pressing the HMI  key, the command Enable Ramp is set to 1.
- When pressing the HMI  key, the command Enable Ramp is set to 0.
- The General Enable command can be disabled when the key  of the HMI is pressed and the parameter C4.2.4.1 is set to coast to stop.
- When pressing the HMI key , the Run Reverse command is alternated.
- As long as the HMI  key is pressed, the Enable JOG command is kept at 1.
- When pressing the HMI key , the command mode is changed from local to remote or vice versa.
- The 2nd Ramp command is always kept at 0 (always 1st Ramp).
- The Quick Stop command can be activated when the key  of the HMI is pressed and the parameter C4.2.4.1 is set to quick stop.
- When there is an fault active, by pressing the HMI  key the Fault Reset command is set to 1.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 LOC/REM Mode	0 = REM: it selects the Remote command mode 1 = LOC: it selects the Local command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.3 DI It indicates the status of the control word via digital inputs.

For the commands written in this parameter to be executed, the inverter must be programmed to be controlled via Digital Input. This programming is done through the menus C4 and C4.2.3.

Control Word via DI:

- The Enable Ramp command depends on the configuration of parameters C4.2.1.2 or C4.2.2.2, according to options 7, 8 and 9 below.
 - For option 7: Run/Stop DI, the Enable Ramp command reflects the status of the digital input set in C4.2.3.2. Active DI means Enable Ramp and inactive DI means Disable Ramp.
 - For option 8: Forward/Reverse DI, the behavior of the Enable Ramp command is determined by a combination of the status of the digital inputs set in C4.2.3.5 and C4.2.3.6.
 - For option 9: 3-Wire Start/Stop DI, the Enable Ramp command has its behavior given by a combination of the status of the digital inputs set in C4.2.3.3 and C4.2.3.4.
- The General Enable command reflects the status of the digital input set in C4.2.3.1. Active DI means General Enabled and Inactive DI means General Disabled.
- The Run Reverse command depends on the settings made in parameters C4.2.1.3 and C4.2.2.3, according to options 7 and 8 below.
 - For option 7: Direction of Rotation DI, the Run Reverse command reflects the status of the digital input set in C4.2.3.8. Active DI means Reverse Direction and inactive DI means Forward Direction.

- For option 8: Forward/Reverse DI, the behavior of the Run Reverse command is determined by a combination of the status of the digital inputs set in C4.2.3.5 and C4.2.3.6.
- The Enable JOG command reflects the status of the digital input set in C4.2.3.9. DI active means Enable JOG and DI inactive means Disable JOG.
- The 2nd Ramp command reflects the status of the digital input set in C4.2.3.10. Active DI means 2nd Ramp and inactive DI means 1st Ramp.
- The Fast Stop command reflects the status of the digital input set in C4.2.3.7. Active DI means No Fast Stop and Inactive DI means With Fast Stop.
- The Fault Reset command reflects the status of the digital input set in C4.2.3.11. Active DI means Reset of Fault and inactive DI means No Action.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

S1.8 Cells

S1.8 Cells

.1 Bypass status of fase U	0 ... 11 Bit
.2 Bypass status of fase V	0 ... 11 Bit
.3 Bypass status of fase W	0 ... 11 Bit
.4 Status of U1...U4 cells	0 ... 3 Bit
.5 Status of U5...U8 cells	0 ... 3 Bit
.6 Status of U9...U12 cells	0 ... 3 Bit
.7 Status of V1...V4 cells	0 ... 3 Bit
.8 Status of V5...V8 cells	0 ... 3 Bit
.9 Status of V9...V12 cells	0 ... 3 Bit
.10 Status of W1...W4 cells	0 ... 3 Bit
.11 Status of W5...W8 cells	0 ... 3 Bit
.12 Status of W9...W12 cells	0 ... 3 Bit

.1 Bypass status of fase U to .3 Bypass status of fase W Indicates the bypass status of the cells.

S STATUS

Bit	Value/Description
Bit 0 Cell 1	0 = Inactive 1 = Active
Bit 1 Cell 2	0 = Inactive 1 = Active
Bit 2 Cell 3	0 = Inactive 1 = Active
Bit 3 Cell 4	0 = Inactive 1 = Active
Bit 4 Cell 5	0 = Inactive 1 = Active
Bit 5 Cell 6	0 = Inactive 1 = Active
Bit 6 Cell 7	0 = Inactive 1 = Active
Bit 7 Cell 8	0 = Inactive 1 = Active
Bit 8 Cell 9	0 = Inactive 1 = Active
Bit 9 Cell 10	0 = Inactive 1 = Active
Bit 10 Cell 11	0 = Inactive 1 = Active
Bit 11 Cell 12	0 = Inactive 1 = Active

.4 Status of U1...U4 cells to .12 Status of W9...W12 cells Shows the cell status according to the inverter configuration and the bypass system status of each cell.

Cells marked as inactive are those that, according to the inverter configuration, are not part of the panel. The inverter settings that determine whether a cell is inactive are: rated voltage C13.1.1, number of redundant cells C13.1.4, and number of cells in parallel C13.1.3.

For active cells, the status depends on whether the cell is in operation or in bypass. To return a cell to operation after the appropriate repairs and checks, or to manually command the bypass system, check parameters C3.12.3 to C3.12.8.

Bit	Value/Description
Bit 0 ... 2 Cell 9	0 = Inactive: The cell is not part of the panel 1 = In operation: Operational cell 2 = Automatic bypass due to a manageable fault: The bypass system started operating after a manageable fault occurred in the cell, removing it from the phase circuit. 3 = Automatic bypass due to parallel association: The bypass system has entered the activation of the cell's bypass system in parallel, removing it from the phase circuit 4 = Bypass manual: The cell bypass system was activated by the user via the corresponding parameter, removing it from the phase circuit. 5 = Mechanical bypass: The cell was removed from the panel and replaced with a mechanical bypass system.
Bit 3 ... 5 Cell 10	0 = Inactive: The cell is not part of the panel 1 = In operation: Operational cell 2 = Automatic bypass due to a manageable fault: The bypass system started operating after a manageable fault occurred in the cell, removing it from the phase circuit. 3 = Automatic bypass due to parallel association: The bypass system has entered the activation of the cell's bypass system in parallel, removing it from the phase circuit 4 = Bypass manual: The cell bypass system was activated by the user via the corresponding parameter, removing it from the phase circuit. 5 = Mechanical bypass: The cell was removed from the panel and replaced with a mechanical bypass system.
Bit 6 ... 8 Cell 11	0 = Inactive: The cell is not part of the panel 1 = In operation: Operational cell 2 = Automatic bypass due to a manageable fault: The bypass system started operating after a manageable fault occurred in the cell, removing it from the phase circuit. 3 = Automatic bypass due to parallel association: The bypass system has entered the activation of the cell's bypass system in parallel, removing it from the phase circuit 4 = Bypass manual: The cell bypass system was activated by the user via the corresponding parameter, removing it from the phase circuit. 5 = Mechanical bypass: The cell was removed from the panel and replaced with a mechanical bypass system.
Bit 9 ... 11 Cell 12	0 = Inactive: The cell is not part of the panel 1 = In operation: Operational cell 2 = Automatic bypass due to a manageable fault: The bypass system started operating after a manageable fault occurred in the cell, removing it from the phase circuit. 3 = Automatic bypass due to parallel association: The bypass system has entered the activation of the cell's bypass system in parallel, removing it from the phase circuit 4 = Bypass manual: The cell bypass system was activated by the user via the corresponding parameter, removing it from the phase circuit. 5 = Mechanical bypass: The cell was removed from the panel and replaced with a mechanical bypass system.

S1.9 Thermal protection relay

It indicates the information from the motor and transformer thermal protection relays.

S1.9 Thermal protection relay

.1 Relay 1	0 ... 7 Bit
.2 Relay 2	0 ... 7 Bit
.3 Relay 3	0 ... 7 Bit
.4 Relay 4	0 ... 7 Bit
.5 Relay 5	0 ... 7 Bit
.6 Relay 6	0 ... 7 Bit

.1 Relay 1 to .6 Relay 6 Indicates the status of the temperature monitoring channels of the respective thermal protection relay.

S STATUS

Bit	Value/Description
Bit 0 ... 1 Channel 1	0 = Inactive channel 1 = No fault 2 = Overtemperature fault 3 = Sensor failure
Bit 2 ... 3 Channel 2	0 = Inactive channel 1 = No fault 2 = Overtemperature fault 3 = Sensor failure
Bit 4 ... 5 Channel 3	0 = Inactive channel 1 = No fault 2 = Overtemperature fault 3 = Sensor failure
Bit 6 ... 7 Channel 4	0 = Inactive channel 1 = No fault 2 = Overtemperature fault 3 = Sensor failure
Bit 8 ... 9 Channel 5	0 = Inactive channel 1 = No fault 2 = Overtemperature fault 3 = Sensor failure
Bit 10 ... 11 Channel 6	0 = Inactive channel 1 = No fault 2 = Overtemperature fault 3 = Sensor failure
Bit 12 ... 13 Channel 7	0 = Inactive channel 1 = No fault 2 = Overtemperature fault 3 = Sensor failure
Bit 14 ... 15 Channel 8	0 = Inactive channel 1 = No fault 2 = Overtemperature fault 3 = Sensor failure

S2 MEASUREMENTS

It allows viewing the variables measured by the MVW.

S2.1 Motor speed

It indicates the variables related to the motor speed.

S2.1 Motor speed	
.1 Reference	0 ... 60000 rpm
.3 Motor speed	0 ... 60000 rpm
.4 Encoder	0 ... 65535 rpm
.5 Estimated value	0 ... 60000 rpm

.1 Reference It indicates the speed reference value in RPM.

.3 Motor speed It indicates the actual motor speed value in RPM used by the controller module.

This value considers the control type selected in C3.1.1 to use either the estimated value in S2.1.5 or the speed measured by the encoder in S2.1.4.

.4 Encoder It indicates the actual encoder speed in RPM.

.5 Estimated value It indicates the estimated motor speed value in RPM.

The estimation is based on the control type selected in C3.1.1, presenting the theoretical speed defined by the V/f curve or the value estimated by the speed observers.

S2.2 Motor torque

It indicates the variables related to the motor torque.

S2.2 Motor torque

.1 Reference	-400.0 ... 400.0 %
.2 Total reference	-400.0 ... 400.0 %
.3 Motor torque	-400.0 ... 400.0 %

.1 Reference It indicates the electrical torque reference on the motor in % based on the motor rated torque.

.2 Total reference It indicates the value of the motor torque reference after the ramp.

.3 Motor torque It indicates the estimated electrical torque on the motor in % based on the rated motor torque.

S2.3 Inverter output

It indicates the MVW output variables applied to the motor.

S2.3 Inverter output

.1 Motor current	0.0 ... 6553.5 A
.2 Iu current	0.0 ... 6553.5 A
to	
.4 Iw current	0.0 ... 6553.5 A
.5 Output voltage	0.00 ... 655.35 kV
.6 Output voltage Vuv	0.00 ... 655.35 kV
to	
.8 Output voltage Vwu	0.00 ... 655.35 kV
.9 Frequency	0.0 ... 1020.0 Hz
.10 cos phi	-1.00 ... 1.00
.11 Power	0 ... 65535 kW
.12 Energy GWh	0 ... 999 GWh
.13 Energy MWh	0 ... 999 MWh
.14 Energy kWh	0.0 ... 999.9 kWh
.17 Voltage between the virtual neutral of the motor and the GND	0.0 ... 6553.5 %
.18 Use of the modulation index	0.0 ... 100.0 %

.1 Motor current It indicates the RMS value of the fundamental component of the inverter output current, in Amperes (A).

.2 Iu current to .4 Iw current Indicates the RMS current of the respective inverter output phase, in amperes (A).

.5 Output voltage It indicates the inverter output voltage in Volts (V).

.6 Output voltage Vuv to .8 Output voltage Vwu Indicates the line-to-line voltage measured at the inverter input, in kV (RMS), for the respective phase.

.9 Frequency It indicates the motor synchronous frequency in Hz.

.10 cos phi It indicates the motor cos phi value.

.11 Power It indicates the electrical power at the inverter output in kW.

.12 Energy GWh It indicates the energy consumed by the motor in GWh.

.13 Energy MWh It indicates the energy consumed by the motor in MWh.

.14 Energy kWh It indicates the energy consumed by the motor in kWh.



NOTE!

The total energy consumed by the motor is the sum of the values given in GWh, MWh and kWh. However, these parameters are calculated indirectly and should not be used to measure energy consumption.

.17 Voltage between the virtual neutral of the motor and the GND It indicates the value of the voltage between the virtual motor neutral and the ground (GND) of the inverter, as a percentage of the nominal effective phase voltage of the inverter.

.18 Use of the modulation index Indicates the ratio between the current modulation index and the maximum allowed modulation index.

S2.4 Temperatures

Indicates the temperatures of the inverter, motor and transformer.

S2.4.1 Overview

S2.4.1 Overview	
.1 AUI CPU board	-50.0 ... 250.0 °C
.2 CCE Control board	-50.0 ... 250.0 °C
.3 Instantaneous minimum value of the cells	-200.0 ... 200.0 °C
.4 Instantaneous maximum value of the cells	-200.0 ... 200.0 °C

.1 AUI CPU board Indicates the temperature measured by the user interface board sensor.

This temperature is used, together with other measurements, in the control board overtemperature fault.

The user temperature offset setting affects this temperature value.

.2 CCE Control board Indicates the temperature measured by the main control board sensor.

.3 Instantaneous minimum value of the cells Indicates the lowest value among all IGBT module temperatures of the cells.

.4 Instantaneous maximum value of the cells Indicates the highest value among all IGBT module temperatures of the cells.

S2.4.2 U phase to S2.4.4 W phase

S2.4.2 U phase	
S2.4.3 V phase	
S2.4.4 W phase	
.1 Temperature on the power module of cell U1	-200.0 ... 200.0 °C
to	
.12 Temperature on the power module of cell U12	-200.0 ... 200.0 °C

.1 Temperature on the power module of cell U1 to .12 Temperature on the power module of cell U12 Indicates the temperature of the IGBT module, in degrees Celsius (°C), of the respective cell.

S2.4.5 Thermal protection relay 1 to S2.4.10 Thermal protection relay 6

Indicates the value of the temperature and the status of the thermal protection relay channels.

**ATTENTION!**

During the use of functions **PRG** (programming) and **VIS** (viewing) of the relay, data exchange is interrupted, which may cause a time-out error in the communication with the inverter.

S2.4.5 Thermal protection relay 1

S2.4.6 Thermal protection relay 2

S2.4.7 Thermal protection relay 3

S2.4.8 Thermal protection relay 4

S2.4.9 Thermal protection relay 5

S2.4.10 Thermal protection relay 6

.1 Relay 1 Temperature CH1	-10 ... 250 °C
to	
.8 Relay 1 Temperature CH8	-10 ... 250 °C
.9 Relé 1 Channel status	0 ... 7 Bit

.1 Relay 1 Temperature CH1 to .8 Relay 1 Temperature CH8 Indicates the value of the motor temperature measured by the thermal protection relay.

**ATTENTION!**

In case of sensor break (open circuit) in a temperature channel, the reading will indicate the full scale value.

.9 Relé 1 Channel status Indicates the status of the thermal protection relay temperature monitoring channels.

Bit	Value/Description
Bit 0 ... 1 Channel 1	0 = Inactive channel: Indicates that the channel is disabled 1 = Active, no faults: Indicates that the channel is active, with no overtemperature or sensor faults 2 = Active, overtemperature fault: Indicates that the channel temperature monitoring is active and in an overtemperature condition 3 = Active, sensor fault: Indicates that the channel temperature monitoring is active and that the sensor has a short-circuit or open-circuit fault.
Bit 2 ... 3 Channel 2	0 = Inactive channel: Indicates that the channel is disabled 1 = Active, no faults: Indicates that the channel is active, with no overtemperature or sensor faults 2 = Active, overtemperature fault: Indicates that the channel temperature monitoring is active and in an overtemperature condition 3 = Active, sensor fault: Indicates that the channel temperature monitoring is active and that the sensor has a short-circuit or open-circuit fault.
Bit 4 ... 5 Channel 3	0 = Inactive channel: Indicates that the channel is disabled 1 = Active, no faults: Indicates that the channel is active, with no overtemperature or sensor faults 2 = Active, overtemperature fault: Indicates that the channel temperature monitoring is active and in an overtemperature condition 3 = Active, sensor fault: Indicates that the channel temperature monitoring is active and that the sensor has a short-circuit or open-circuit fault.
Bit 6 ... 7 Channel 4	0 = Inactive channel: Indicates that the channel is disabled 1 = Active, no faults: Indicates that the channel is active, with no overtemperature or sensor faults 2 = Active, overtemperature fault: Indicates that the channel temperature monitoring is active and in an overtemperature condition 3 = Active, sensor fault: Indicates that the channel temperature monitoring is active and that the sensor has a short-circuit or open-circuit fault.
Bit 8 ... 9 Channel 5	0 = Inactive channel: Indicates that the channel is disabled 1 = Active, no faults: Indicates that the channel is active, with no overtemperature or sensor faults 2 = Active, overtemperature fault: Indicates that the channel temperature monitoring is active and in an overtemperature condition 3 = Active, sensor fault: Indicates that the channel temperature monitoring is active and that the sensor has a short-circuit or open-circuit fault.
Bit 10 ... 11 Channel 6	0 = Inactive channel: Indicates that the channel is disabled 1 = Active, no faults: Indicates that the channel is active, with no overtemperature or sensor faults 2 = Active, overtemperature fault: Indicates that the channel temperature monitoring is active and in an overtemperature condition 3 = Active, sensor fault: Indicates that the channel temperature monitoring is active and that the sensor has a short-circuit or open-circuit fault.
Bit 12 ... 13 Channel 7	0 = Inactive channel: Indicates that the channel is disabled 1 = Active, no faults: Indicates that the channel is active, with no overtemperature or sensor faults 2 = Active, overtemperature fault: Indicates that the channel temperature monitoring is active and in an overtemperature condition 3 = Active, sensor fault: Indicates that the channel temperature monitoring is active and that the sensor has a short-circuit or open-circuit fault.
Bit 14 ... 15 Channel 8	0 = Inactive channel: Indicates that the channel is disabled 1 = Active, no faults: Indicates that the channel is active, with no overtemperature or sensor faults 2 = Active, overtemperature fault: Indicates that the channel temperature monitoring is active and in an overtemperature condition 3 = Active, sensor fault: Indicates that the channel temperature monitoring is active and that the sensor has a short-circuit or open-circuit fault.

S2.4.11 Temperature accessory

S2.4.11 Temperature accessory

.3 Sensor measured value -100.0 ... 250.0 °C

.3 Sensor measured value It indicates the value of the motor temperature measured by the temperature accessory.

The value indicated considers the highest temperature measured by the first temperature accessory identified by the inverter. If no temperature accessory is identified, this parameter will remain hidden from view by the HMI.

S2.6 Inverter input

It indicates the current and voltage value of the inverter power supply.

S2.6 Inverter input

.3 Input current	0.0 ... 6553.5 A
.4 Input voltage	0.00 ... 655.35 kV
.5 Input voltage Vab to	0.00 ... 655.35 kV
.7 Input voltage Vca	0.00 ... 655.35 kV
.8 Transformer 1 current to	0.0 ... 6553.5 A
.10 Transformer 3 current	0.0 ... 6553.5 A
.11 Apparent power	-32768 ... 32767 kVA
.12 Active power	-32768 ... 32767 kW
.13 Reactive power	-32768 ... 32767 kVAr
.14 FP	0.00 ... 1.00
.15 Frequency	0.00 ... 100.00 Hz

.3 Input current It indicates the current reading at the inverter input, in amperes (A) effective value.

.4 Input voltage It indicates the voltage effective value at the inverter input, in kV.

.5 Input voltage Vab to .7 Input voltage Vca Indicates the line-to-line voltage measured at the inverter input, in kV (RMS), for the respective phase.

.8 Transformer 1 current to .10 Transformer 3 current It indicates the current measured at the inverter input, in amps (A) effective value, of the respective transformer.

.11 Apparent power Indicates the apparent power in the inverter input, in kVA.

.12 Active power Indicates the real power in the inverter input, in kW.

.13 Reactive power Indicates the reactive power in the inverter input, in kVAr.

.14 FP It indicates the cosine of the angle between the voltage and current at the inverter input.

.15 Frequency Indicates the input frequency of the inverter, in hertz (Hz).

S2.7 DC link

Allows viewing the measured DC bus voltages and the calculated indicators.

S2.7.1 Overview**S2.7.1 Overview**

.1 Global average of the DC link voltages	0 ... 2000 V
.2 Lowest global value of the DC bus voltages	0 ... 2000 V
.3 Highest global value of the DC link voltages	0 ... 2000 V
.4 U phase VDC link voltages sum to	0 ... 20000 V
.6 W phase VDC link voltages sum	0 ... 20000 V

.1 Global average of the DC link voltages Indicates the calculated value considering all cells currently active.

.2 Lowest global value of the DC bus voltages Indicates the lowest value among all cell DC link voltages.

.3 Highest global value of the DC link voltages Indicates the highest value among all cell DC bus voltages.

.4 U phase VDC link voltages sum to .6 W phase VDC link voltages sum Sum of the phase DC bus voltages.

S STATUS

S2.7.2 U phase to S2.7.4 W phase

S2.7.2 U phase	
S2.7.3 V phase	
S2.7.4 W phase	
.1 Voltage of cell U1	0 ... 2000 V
to	
.12 Voltage of cell U12	0 ... 2000 V

.1 Voltage of cell U1 to .12 Voltage of cell U12 It indicates the DC link voltage, in volts, of the respective cell.

S2.8 Torque current limitation

It allows viewing the parameters related to the motor torque limiter via Analog Input.

S2.8 Torque current limitation	
.1 Alx global torque	0.0 ... 400.0 %

.1 Alx global torque It defines the maximum torque value in the four quadrants of motor operation via Analog Input (selected in parameter C3.3.4.1.6). If it is necessary to control the torque in the four motor operation quadrants, parameters C3.3.4.1.2 to C3.3.4.1.5 must be used.

S3 I/OS

It allows viewing the status of the I/O accessories installed on the MVW.

S3.1 Slot X status

Allows viewing the status parameters of the selected slot.




Figure 7.1: IOS accessory, slot X

S3.1.1 Analog inputs

It allows viewing the value of the analog inputs of the accessory connected to the slot.

S3.1.1 Analog inputs

.1 AI1	-100.00 ... 100.00 %
.2 AI2	-100.00 ... 100.00 %

.1 AI1, .2 AI2, .1 Value of AI1 from the control board, .2 Value of AI2 from the control board Value of the analog input in percentage according to the type of signal configured.

Where 0 % = minimum value of the configured signal - includes gain and offsets (e.g. 4 mA for 4...20 mA signal) and 100 % = maximum value of the configured signal.

S3.1.2 Analog outputs

It allows viewing the value of the analog outputs of the accessory connected to the slot.

The data source for each output is independently configured through specific parameters described in C5.1.2. The status indication may have percentage values relative to the full scale values. Such values depend on the function selected for the analog output and are also described in detail in item C5.1.2.

S3.1.2 Analog outputs

.1 AO1	-100.00 ... 100.00 %
.2 AO1 Network	-100.00 ... 100.00 %
.3 AO1 SoftPLC	-100.00 ... 100.00 %
.4 AO2	-100.00 ... 100.00 %
.5 AO2 Network	-100.00 ... 100.00 %
.6 AO2 SoftPLC	-100.00 ... 100.00 %

.1 AO1, .4 AO2 Value of the analog output in percentage according to the type of signal configured.

.2 AO1 Network, .5 AO2 Network Value of the analog output, when controlled by communication network, in percentage according to the type of signal configured.

.3 AO1 SoftPLC, .6 AO2 SoftPLC Value of the analog output, when controlled by SoftPLC, in percentage according to the type of signal configured.

S3.1.3 Digital inputs

It allows viewing the value of the digital inputs of the accessory connected to the slot.

S3.1.3 Digital inputs

.1 DI	0 ... 5 Bit
.2 FI5	-100.00 ... 100.00 %
.3 FI5 (Hz)	0 ... 32000 Hz
.4 FI6	-100.00 ... 100.00 %
.5 FI6 (Hz)	0 ... 32000 Hz

.1 DI It indicates the status of digital inputs.

S STATUS

Bit	Value/Description
Bit 0 DI1	It indicates the status of Digital Input DI1. 0 = Inactive: It indicates that Digital Input DI1 is inactive 1 = Active: It indicates that Digital Input DI1 is active
Bit 1 DI2	It indicates the status of Digital Input DI2. 0 = Inactive: It indicates that Digital Input DI2 is inactive 1 = Active: It indicates that Digital Input DI2 is active
Bit 2 DI3	It indicates the status of Digital Input DI3. 0 = Inactive: It indicates that Digital Input DI3 is inactive 1 = Active: It indicates that Digital Input DI3 is active
Bit 3 DI4	It indicates the status of Digital Input DI4. 0 = Inactive: It indicates that Digital Input DI4 is inactive 1 = Active: It indicates that Digital Input DI4 is active
Bit 4 DI5	It indicates the status of Digital Input DI5. 0 = Inactive: It indicates that Digital Input DI5 is inactive 1 = Active: It indicates that Digital Input DI5 is active
Bit 5 DI6	It indicates that Digital Input DI6 is inactive. 0 = Inactive: It indicates that Digital Input DI6 is inactive 1 = Active: It indicates that Digital Input DI6 is active

.2 FI5, .4 FI6 It indicates (in percentage of the full scale) the actual value of frequency input.

.3 FI5 (Hz), .5 FI6 (Hz) It indicates (in Hz) the actual value of frequency input.

S3.1.4 Digital outputs

It allows viewing the value of the digital outputs of the accessory connected to the slot.

S3.1.4 Digital outputs	
.1 DO	0 ... 1 Bit
.4 FO1	-100.00 ... 100.00 %
.5 FO1 (Hz)	0 ... 32000 Hz
.6 FO1 Network	-100.00 ... 100.00 %
.7 FO1 SoftPLC	-100.00 ... 100.00 %
.8 FO2	-100.00 ... 100.00 %
.9 FO2 (Hz)	0 ... 32000 Hz
.10 FO2 Network	-100.00 ... 100.00 %
.11 FO2 SoftPLC	-100.00 ... 100.00 %

.1 DO It indicates the status of digital outputs.

Bit	Value/Description
Bit 0 DO1	It indicates the status of Digital Output DO1. 0 = Inactive: It indicates that Digital Output DO1 is inactive 1 = Active: It indicates that Digital Output DO1 is active
Bit 1 DO2	It indicates the status of Digital Output DO2. 0 = Inactive: It indicates that Digital Output DO2 is inactive 1 = Active: It indicates that Digital Output DO2 is active

.4 FO1, .8 FO2 It indicates (in percentage of the full scale) the actual value of frequency output.

.5 FO1 (Hz), .9 FO2 (Hz) It indicates (in Hz) the actual value of frequency output.

.6 FO1 Network, .10 FO2 Network It indicates (in percentage of the full scale) the actual value supplied via Networks to frequency output.

.7 FO1 SoftPLC, .11 FO2 SoftPLC It indicates (in percentage of the full scale) the actual value supplied via SoftPLC to frequency output.

S3.2 Slot A status

S3.3 Slot B status**S3.4 Slot C status****S3.5 Slot D status****S3.6 Slot E status****S3.7 Slot F status****S3.8 Slot G status**

It allows viewing the state of the slot status parameters.

S3.2.1 Analog inputs to S3.8.1 Analog inputs

It allows viewing the value of the analog inputs of the accessory connected to the slot.

S3.2.1 Analog inputs**S3.3.1 Analog inputs****S3.4.1 Analog inputs****S3.5.1 Analog inputs****S3.6.1 Analog inputs****S3.7.1 Analog inputs****S3.8.1 Analog inputs**

.1 AI1	-100.00 ... 100.00 %
to	
.3 AI3	-100.00 ... 100.00 %

.1 AI1, .2 AI2, .3 AI3 Value of the analog input in percentage according to the type of signal configured.

Where 0 % = minimum value of the configured signal - includes gain and offsets (e.g. 4 mA for 4...20 mA signal) and 100 % = maximum value of the configured signal.

S3.2.2 Analog outputs to S3.8.2 Analog outputs

It allows viewing the value of the analog outputs of the accessory connected to the slot.

The data source for each output is independently configured through specific parameters described in the configuration menu for the analog outputs of the accessory connected to the slot. Using Slot A as an example, the menu can be found in item C5.2. The status indication may have percentage values relative to the full scale values. Such values depend on the function selected for the analog output and are also described in detail in the menu of analog outputs of the accessory connected to the slot.

S3.2.2 Analog outputs

S3.3.2 Analog outputs

S3.4.2 Analog outputs

S3.5.2 Analog outputs

S3.6.2 Analog outputs

S3.7.2 Analog outputs

S3.8.2 Analog outputs

.1 AO1	-100.00 ... 100.00 %
.2 AO1 Network	-100.00 ... 100.00 %
.3 AO1 SoftPLC	-100.00 ... 100.00 %
.4 AO2	-100.00 ... 100.00 %
.5 AO2 Network	-100.00 ... 100.00 %
.6 AO2 SoftPLC	-100.00 ... 100.00 %

.1 AO1 , .4 AO2 Value of the analog output in percentage according to the type of signal configured.

.2 AO1 Network, .5 AO2 Network Value of the analog output, when controlled by communication network, in percentage according to the type of signal configured.

.3 AO1 SoftPLC, .6 AO2 SoftPLC Value of the analog output, when controlled by SoftPLC, in percentage according to the type of signal configured.

S3.2.3 Digital inputs to S3.8.3 Digital inputs

It allows viewing the value of the digital inputs of the accessory connected to the slot.

S3.2.3 Digital inputs

S3.3.3 Digital inputs

S3.4.3 Digital inputs

S3.5.3 Digital inputs

S3.6.3 Digital inputs

S3.7.3 Digital inputs

S3.8.3 Digital inputs

.1 DI	0 ... 7 Bit
-------	-------------

.1 DI It indicates the status of digital inputs.

Bit	Value/Description
Bit 0 DI1	It indicates the status of Digital Input DI1. 0 = Inactive: It indicates that Digital Input DI1 is inactive 1 = Active: It indicates that Digital Input DI1 is active
Bit 1 DI2	It indicates the status of Digital Input DI2. 0 = Inactive: It indicates that Digital Input DI2 is inactive 1 = Active: It indicates that Digital Input DI2 is active
Bit 2 DI3	It indicates the status of Digital Input DI3. 0 = Inactive: It indicates that Digital Input DI3 is inactive 1 = Active: It indicates that Digital Input DI3 is active
Bit 3 DI4	It indicates the status of Digital Input DI4. 0 = Inactive: It indicates that Digital Input DI4 is inactive 1 = Active: It indicates that Digital Input DI4 is active
Bit 4 DI5	It indicates the status of Digital Input DI5. 0 = Inactive: It indicates that Digital Input DI5 is inactive 1 = Active: It indicates that Digital Input DI5 is active
Bit 5 DI6	It indicates the status of Digital Input DI6. 0 = Inactive: It indicates that Digital Input DI6 is inactive 1 = Active: It indicates that Digital Input DI6 is active
Bit 6 DI7	It indicates the status of Digital Input DI7. 0 = Inactive: It indicates that Digital Input DI7 is inactive 1 = Active: It indicates that Digital Input DI7 is active
Bit 7 DI8	It indicates the status of Digital Input DI8. 0 = Inactive: It indicates that Digital Input DI8 is inactive 1 = Active: It indicates that Digital Input DI8 is active

S3.2.4 Digital outputs to S3.8.4 Digital outputs

It allows viewing the value of the digital outputs of the accessory connected to the slot.

S3.2.4 Digital outputs

S3.3.4 Digital outputs

S3.4.4 Digital outputs

S3.5.4 Digital outputs

S3.6.4 Digital outputs

S3.7.4 Digital outputs

S3.8.4 Digital outputs

.1 DO	0 ... 7 Bit
.2 DO network	0 ... 7 Bit
.3 DO SoftPLC	0 ... 7 Bit

.1 DO It indicates the status of digital outputs.

.2 DO network It indicates the Network command status to the digital outputs.

.3 DO SoftPLC It indicates the SoftPLC command status to the digital outputs.

S STATUS

Bit	Value/Description
Bit 0 DO1	It indicates the status of Digital Output DO1. 0 = Inactive: It indicates that Digital Output DO1 is inactive 1 = Active: It indicates that Digital Output DO1 is active
Bit 1 DO2	It indicates the status of Digital Output DO2. 0 = Inactive: It indicates that Digital Output DO2 is inactive 1 = Active: It indicates that Digital Output DO2 is active
Bit 2 DO3	It indicates the status of Digital Output DO3. 0 = Inactive: It indicates that Digital Output DO3 is inactive 1 = Active: It indicates that Digital Output DO3 is active
Bit 3 DO4	It indicates the status of Digital Output DO4. 0 = Inactive: It indicates that Digital Output DO4 is inactive 1 = Active: It indicates that Digital Output DO4 is active
Bit 4 DO5	It indicates the status of Digital Output DO5. 0 = Inactive: It indicates that Digital Output DO5 is inactive 1 = Active: It indicates that Digital Output DO5 is active
Bit 5 DO6	It indicates the status of Digital Output DO6. 0 = Inactive: It indicates that Digital Output DO6 is inactive 1 = Active: It indicates that Digital Output DO6 is active
Bit 6 DO7	It indicates the status of Digital Output DO7. 0 = Inactive: It indicates that Digital Output DO7 is inactive 1 = Active: It indicates that Digital Output DO7 is active
Bit 7 DO8	It indicates the status of Digital Output DO8. 0 = Inactive: It indicates that Digital Output DO8 is inactive 1 = Active: It indicates that Digital Output DO8 is active

S3.2.6 Temperatures to S3.8.6 Temperatures

It allows viewing the temperature of the sensors connected to the slot accessory in °C.

S3.2.6 Temperatures S3.3.6 Temperatures S3.4.6 Temperatures S3.5.6 Temperatures S3.6.6 Temperatures S3.7.6 Temperatures S3.8.6 Temperatures	
.1 Sensor 1	-100.0 ... 250.0 °C
to	
.6 Sensor 6	-100.0 ... 250.0 °C

.1 Sensor 1, .2 Sensor 2, .3 Sensor 3, .4 Sensor 4, .5 Sensor 5, .6 Sensor 6 It indicates the temperature at the Slot sensor (°C).

S3.9 Control board

Allows you to view the status of the digital and analog inputs and outputs used by the inverter control.

S3.9.1 Analog inputs

It allows viewing the value of the analog inputs of the accessory connected to the slot.

S3.9.1 Analog inputs	
.1 Value of AI1 from the control board	-250.00 ... 250.00 %
.2 Value of AI2 from the control board	-250.00 ... 250.00 %

S3.9.2 Analog outputs

It allows viewing the value of the analog outputs of the accessory connected to the slot.

The data source for each output is configured independently through specific parameters described in C5.11.2. The status indication can assume percentage values relative to the full-scale values.

S3.9.2 Analog outputs

.1 Value of AO1 from the control board	-100.00 ... 100.00 %
to	
.4 Value of AO4 from the control board	-100.00 ... 100.00 %

.1 Value of AO1 from the control board to .4 Value of AO4 from the control board It indicates the value of the respective analog output of the control board.

S3.9.3 Digital inputs

It allows viewing the value of the digital inputs of the accessory connected to the slot.

S3.9.3 Digital inputs

.1 Control board DI	0 ... 15 Bit
---------------------	--------------

.1 Control board DI Digital inputs located on the PIC board.

Bit	Value/Description
Bit 0 DI16 State of doors	0 = Inactive: Not mechanically locked 1 = Active: Mechanically locked
Bit 1 DI15	0 = Inactive 1 = Active
Bit 2 DI14 Exhaust	0 = Inactive 1 = Active
Bit 3 DI13 General enable	0 = Inactive: Enable signal: OFF 1 = Active: Enable signal: ON
Bit 4 DI12 Transformer fault	0 = Inactive: Inactive fault 1 = Active: Active fault
Bit 5 DI11 Transformer alarm	0 = Inactive: Alarm inactive 1 = Active: Alarm active
Bit 6 DI10 Cooling system supply fault	0 = Inactive: Alarm inactive 1 = Active: Alarm active
Bit 7 DI9	0 = Inactive 1 = Active
Bit 8 DI8	0 = Inactive 1 = Active
Bit 9 DI7 Pre-charge power supply	0 = Inactive: Precharge power failure 1 = Active: Precharge supply OK
Bit 10 DI6 RL8 Function	0 = Inactive: Signal inactive 1 = Active: Signal inactive
Bit 11 DI5 Input protection	0 = Inactive: Active protection 1 = Active: Normal operation
Bit 12 DI4 Circuit breaker OFF	0 = Inactive: Input circuit breaker: ON 1 = Active: Input circuit breaker: OFF
Bit 13 DI3 Circuit breaker ON	0 = Inactive: Input circuit breaker: OFF 1 = Active: Input circuit breaker: ON
Bit 14 DI2 Circuit breaker ready	0 = Inactive: Input circuit breaker is not ready 1 = Active: Input circuit breaker ready
Bit 15 DI1 Power ON	0 = Inactive: Power ON signal: OFF 1 = Active: Power ON signal: ON

S3.9.4 Digital outputs

It allows viewing the value of the digital outputs of the accessory connected to the slot.

S3.9.4 Digital outputs

.1 Control board DO	0 ... 7 Bit
---------------------	-------------

S STATUS

.1 Control board DO Digital outputs located on the PIC board.

Bit	Value/Description
Bit 0 RL8	0 = Inactive: Ventilation off 1 = Active: Inverter ventilation on
Bit 1 RL7 Inverter ventilation	0 = Inactive: Inverter ventilation off 1 = Active:
Bit 2 RL6 Circuit break	0 = Inactive: Input circuit breaker open 1 = Active: Input circuit breaker closed
Bit 3 RL5 2nd stage pre-charge	0 = Inactive: Second stage of precharge turned off 1 = Active: Second stage of precharge on
Bit 4 RL4 Turns off input circuit breaker	0 = Inactive: Input circuit breaker opening command: OFF 1 = Active: Input circuit breaker opening command: ON
Bit 5 RL3 Closes input circuit breaker	0 = Inactive: Input circuit breaker closing command: OFF 1 = Active: Input circuit breaker closing command: ON
Bit 6 RL2 1st stage pre-charge	0 = Inactive: First stage of precharge turned off 1 = Active: First stage of precharge on
Bit 7 RL1 Inverter Ready	0 = Inactive: Inverter not ready to drive motor 1 = Active: Inverter is ready to drive the motor

S3.9.5 Encoder

It allows viewing the actual status of the encoder signal measurements carried out by the accessory.

S3.9.5 Encoder		
.1 Number of revolutions	0 ... 65535	
.2 Revolution fraction	0 ... 65535	
.4 Speed	-60000 ... 60000 rpm	

.1 Number of revolutions Number of full revolutions measured by the encoder.

This parameter is initialized to 0 at power-up. After the zero search is completed, this parameter is reset to 0.

It increments when a full revolution is measured in the forward direction and decrements when a full revolution is measured in the reverse direction.

.2 Revolution fraction Value proportional (from 0 to 65535) to the fractional revolution (partial revolution) measured by the encoder.

This parameter is initialized to 0 at power-up. After the zero search is completed, this parameter is reset to 0.

It increments when pulses are measured in the forward direction and decrements when pulses are measured in the reverse direction.

For example, for a 1024-pulse encoder rotating 3.5 revolutions in the forward direction (3584 pulses), this parameter indicates 32768 (0.5 revolution). If the encoder shaft then rotates 0.75 revolution in the reverse direction, totaling 2.75 revolutions (2816 pulses), the parameter indicates 49152 (0.75 revolution).

.4 Speed It indicates the speed, in rpm, measured by the encoder.

The speed indicated in this parameter is calculated by counting the encoder pulses occurred in a time frame of 1 ms. This parameter is updated every 1 ms.

Positive values indicate forward rotation, and negative values indicate reverse rotation.

The value of this parameter is presented without filters.

S5 COMMUNICATIONS

It allows viewing the parameters used for monitoring and controlling the MVW inverter using communication

interfaces.

S5.1 Status and commands

It allows viewing the MVW logical status and commands.

S5.1 Status and commands

.1 Status word 1	0 ... 15 Bit
.2 Speed	-200.00 ... 200.00 %
.3 Status word 2	0 ... 15 Bit
.4 Status word 3	0 ... 4 Bit

.1 Status word 1 It indicates the operating status of the inverter. Each bit represents a status.

Bit	Value/Description
Bit 0 Not used	Not used
Bit 1 Run Command	0 = No: no run command active 1 = Yes: run command active
Bit 2 Local	0 = No: inverter in Remote command mode 1 = Yes: inverter in Local command mode (via HMI)
Bit 3 Not used	Not used
Bit 4 No Quick Stop	0 = No: quick stop command active 1 = Yes: no quick stop command active
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration by C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration by C6.1.4 and C6.1.5
Bit 6 Config. Mode	0 = No: inverter in normal operation 1 = Yes: inverter in configuration status. It indicates a special condition in which the inverter cannot be enabled
Bit 7 Alarm	0 = No: without alarm 1 = Yes: with alarm active
Bit 8 Running	0 = No: motor is stopped 1 = Yes: motor is running according to reference and command
Bit 9 Enabled	0 = No: inverter is general disabled 1 = Yes: inverter is general enabled
Bit 10 Reverse	0 = No: motor running in the forward direction 1 = Yes: motor running in the reverse direction
Bit 11 JOG	0 = No: no JOG command active 1 = Yes: JOG command is active
Bit 12 Remote 2	0 = No: inverter in Remote 1 command mode 1 = Yes: inverter in Remote 2 command mode
Bit 13 Not used	Not used
Bit 14 Not used	Not used
Bit 15 Fault	0 = No: normal operation 1 = Yes: fault acting

.2 Speed It indicates the actual speed of the motor driven by the inverter in percentage of the maximum speed.

- S5.1.2 = 0.00 % $\Rightarrow$ motor speed = 0 rpm
- S5.1.2 = 100.00 % $\Rightarrow$ motor speed = C4.3.1.1.2

Intermediate or higher speed values can be obtained by using this scale. For example, if the value read is 25.0 %, considering C4.3.1.1.2 = 1800 rpm, to obtain the value in rpm you must calculate:

100.00 % : 1800 rpm
25.00 % : Speed

$$\text{Speed} = \frac{25.00 \times 1800}{100.00}$$

S STATUS

Speed = 450 rpm

Negative values indicate motor rotating in the reverse direction of rotation.

.3 Status word 2 It indicates other status of the inverter functions. Each bit represents a status.

Bit	Value/Description
Bit 0 Self-tuning	0 = No: inverter is not running the Self-tuning routine 1 = Yes: inverter is running the Self-tuning routine for estimating motor parameters
Bit 1 Field Weakening	0 = No: Control is not in the field weakening region 1 = Yes: Control is in the field weakening region
Bit 2 Pre-Charge OK	0 = No: pre-charge of the DC link capacitors not completed 1 = Yes: pre-charge of the DC link capacitors completed
Bit 3 Not used	Not used
Bit 4 Zero Speed	0 = No: Sleep mode inactive 1 = Yes: Sleep mode active
Bit 5 Decel. Ramp	0 = No: no deceleration 1 = Yes: inverter decelerating
Bit 6 Acc. Ramp	0 = No: no acceleration 1 = Yes: inverter accelerating
Bit 7 Freeze Ramp	0 = No: ramp in normal operation 1 = Yes: the path of the ramp is frozen by some command source or internal function
Bit 8 Setpoint OK	0 = No: motor speed has not reached the reference yet 1 = Yes: motor speed has reached the reference
Bit 9 DC Voltage Limitation	0 = No: DC link limitation or current limitation inactive 1 = Yes: DC link limitation or current limitation active
Bit 10 Current Limitation	0 = No: current limitation inactive 1 = Yes: current limitation active
Bit 11 Torque Limitation	0 = No: torque limitation inactive 1 = Yes: torque limitation active
Bit 12 Ride-Through	0 = No: Ride-through not running 1 = Yes: running Ride-through
Bit 13 Flying Start	0 = No: Flying start not running 1 = Yes: running Flying start
Bit 14 Not used	Not used
Bit 15 PWM pulses	0 = No: PWM voltage pulses at the output disabled 1 = Yes: PWM voltage pulses at the output enabled

.4 Status word 3 Indicates other states of the inverter functions. Each bit represents a state.

Bit	Value/Description
Bit 0 SD Card	SD card is only detected during the inverter initialization, so the inverter will not detect SD card disconnection during operation. 0 = No: SD card not connected 1 = Yes: SD card connected
Bit 1 Not used	Not used
Bit 2 Param. Storage	Indicates the status of the storage memory for user parameter setting. When the memory reaches its maximum capacity, new parameter changes may not be retained after the inverter is restarted. The next time the product is powered on, a message will be displayed on the HMI, and memory space will be freed up to allow new parameter settings. The inverter operation is not affected when storage space is exhausted. 0 = Free: There is space available in the memory to store user parameters 1 = Limit: The memory for storing user parameters has reached its maximum capacity
Bit 3 Not used	Not used
Bit 4 Maximum frequency	0 = Limited (599 Hz): The maximum output frequency of the inverter is limited to 599 Hz. 1 = Not Limited: No limitation on the maximum output frequency of the inverter.

S5.2 Serial RS485

It allows viewing the status of the RS485 serial interface and the commands received by this interface.

S5.2 Serial RS485

.1 Interface status	0 ... 2
.2 Control word	0 ... 7 Bit
.3 Speed reference	-200.00 ... 200.00 %
.5 Received telegrams	0 ... 65535
.6 Transmitted telegrams	0 ... 65535
.7 Telegrams with error	0 ... 65535
.8 Reception errors	0 ... 65535

.1 Interface status It indicates the status of the RS485 serial interface.

Indication	Description
0 = Inactive	Not used
1 = Active	Serial interface active
2 = Timeout Error	It indicates that the MVW did not receive valid telegrams for a time longer than the limit set

.2 Control word It indicates the status of the control word via RS-485 serial interface. This parameter can only be changed via RS485 serial interface. For other sources, only read access is allowed.

For the commands written in this parameter to be executed, the inverter must be programmed to be commanded via Serial. This programming is done through menu C4.

Each bit of this word represents a command that can be executed on the inverter.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.3 Speed reference It indicates the speed reference sent via RS-485 Serial interface to the motor driven by the inverter in percentage of the maximum speed. This parameter can only be changed via RS485 serial interface. For other sources, only read access is allowed.

For the reference written in this parameter to be used, the inverter must be programmed to use the speed reference via Serial. This programming is done through menu C4.

- S5.2.3 = 0.00 % ⇒ speed reference = 0 rpm
- S5.2.3 = 100.00 % ⇒ speed reference = C4.3.1.1.2

Intermediate or higher speed values can be obtained by using this scale. For example, if the desired value for the reference is 900 rpm, considering C4.3.1.1.2 = 1800 rpm, it should be calculated:

100.00 % : 1800 rpm
Reference % : 900 rpm

S STATUS

$$\text{Reference \%} = \frac{900 \times 100.00}{1800}$$

Reference % = 50 %

Negative values can be used to reverse the direction of rotation of the motor. The direction of rotation of the motor, however, also depends on the value of the rotation direction command bit in S1.6.1:

- Bit Rotation Direction = 1 and S5.2.3 > 0: reference for the forward direction
- Bit Rotation Direction = 1 and S5.2.3 < 0: reference for the reverse direction
- Bit Rotation Direction = 0 and S5.2.3 > 0: reference for the reverse direction
- Bit Rotation Direction = 0 and S5.2.3 < 0: reference for the forward direction

.5 Received telegrams It indicates the number of telegrams received.

.6 Transmitted telegrams It indicates the number of telegrams transmitted.

.7 Telegrams with error It indicates the number of telegrams received with errors (CRC, Checksum).

.8 Reception errors It indicates the number of bytes received with errors.

The counters are cyclic, that is, when it reaches 65535, it returns to 0.



NOTE!

These counters start at 0 whenever the product is powered on. They also return to 0 whenever the maximum limit of the parameter is reached.

S5.3 Ethernet

It allows viewing the status of the Ethernet network interface and the commands received by this interface.

S5.3 Ethernet

.1 Interface status	0 ... 1 Bit
.2 Control word	0 ... 7 Bit
.3 Speed reference	-200.00 ... 200.00 %
.5 Actual IP address	0.0.0.0 ... 255.255.255.255
.6 MQTT status	0 ... 2
.7 Last public. MQTT	YYYY-MM-DD HH:MM:SS
.8 SNTP - Status	0 ... 2
.9 SNTP - Last update	YYYY-MM-DD HH:MM:SS
.10 SymbiNet: Groups status	0 ... 7 Bit

.1 Interface status It indicates the status of the Ethernet network interface. Each bit represents a state.

Bit	Value/Description
Bit 0 Link 1	0 = No: Link active at port 1 1 = Yes: Link active at port 1
Bit 1 Link 2	0 = No: No link at port 2 1 = Yes: Link active at port 2

.2 Control word It indicates the status of the control word via Ethernet network interface. This parameter can only be changed via Ethernet network interface. For other sources, only read access is allowed.

For the commands written in this parameter to be executed, the inverter must be programmed to be commanded via Ethernet. This programming is done through menu C4.

Each bit of this word represents a command that can be executed on the inverter.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.3 Speed reference It indicates the speed reference sent via Ethernet network interface to the motor driven by the inverter in percentage of the maximum speed. This parameter can only be changed via Ethernet network interface. For other sources, only read access is allowed.

For the reference written in this parameter to be used, the inverter must be programmed to use the speed reference via Ethernet. This programming is done through menu C4.

- S5.3.3 = 0.00 % $\Rightarrow$ speed reference = 0 rpm
- S5.3.3 = 100.00 % $\Rightarrow$ speed reference = C4.3.1.1.2

Intermediate or higher speed values can be obtained by using this scale. For example, if the desired value for the reference is 900 rpm, considering C4.3.1.1.2 = 1800 rpm, it should be calculated:

100.00 % : 1800 rpm
Reference % : 900 rpm

$$\text{Reference \%} = \frac{900 \times 100.00}{1800}$$

Reference % = 50 %

Negative values can be used to reverse the direction of rotation of the motor. The direction of rotation of the motor, however, also depends on the value of the rotation direction command bit in S5.3.2 or S1.6.1:

- Bit Rotation Direction = 0 and S5.3.3 > 0: reference for the forward direction
- Bit Rotation Direction = 0 and S5.3.3 < 0: reference for the reverse direction
- Bit Rotation Direction = 1 and S5.3.3 > 0: reference for the reverse direction
- Bit Rotation Direction = 1 and S5.3.3 < 0: reference for the forward direction

.5 Actual IP address It allows viewing the IP address in use by the device.

.6 MQTT status It indicates the status of the MQTT communication, regarding settings and the sending of data to the server.

Indication	Description
0 = Inactive	It indicates that the Embedded Drive Scan function is not set; it is disabled
1 = No Connection	It indicates that the Embedded Drive Scan function has been set and is enabled, but there is currently no active connection to the configured Broker
2 = Connected	It indicates that the Embedded Drive Scan function has been set up and is enabled, and has an active connection to the configured Broker

S STATUS

.7 Last public. MQTT It indicates the date and time of the last successful sending of collected data to the MQTT communication.

.8 SNTP - Status It indicates the status of the NTP server, regarding configuration and receiving data from the server.

Indication	Description
0 = Inactive	It indicates that the NTP server is not configured; it is disabled
1 = No Connection	It indicates that the NTP server has been set up and is enabled, but currently has no active connection
2 = Connected	It indicates that the NTP server has been set up and is enabled, and has active connection

.9 SNTP - Last update It indicates the date and time of the last NTP server update.

.10 SymbiNet: Groups status Indicates the communication status for the groups programmed for SymbiNet communication. Each bit represents the state of one group, where bit 0 indicates the state of group 1, and bit 7 indicates the state of group 8.

Bit	Value/Description
Bit 0 Group 1 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 1 Group 2 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 2 Group 3 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 3 Group 4 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 4 Group 5 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 5 Group 6 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 6 Group 7 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 7 Group 8 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update

S5.4 EtherNet/IP

It allows viewing information about the EtherNet/IP protocol.

S5.4 EtherNet/IP	
.1 EIP master status	0 ... 1
.2 Communication status	0 ... 4
.3 DLR topology	0 ... 1
.4 DLR status	0 ... 2

.1 EIP master status It indicates the status of the EtherNet/IP network master. It may be in operation mode (Run) or in configuration mode (Idle).

Indication	Description
0 = Run	Reading and writing telegrams are processed and updated normally by the master
1 = Idle	Only reading telegrams from the slaves are updated by the master. Writing, in this case, is disabled

.2 Communication status It indicates the status of the Ethernet/IP network interface.

Indication	Description
0 = Inactive	Not used
1 = No Connection	It indicates that the EtherNet/IP network interface has been initialized, but is not communicating with the network master
2 = Connected	It indicates that communication with the network master has been established, and I/O data is being successfully communicated
3 = I/O Connection Timeout	I/O type connection has expired
4 = Duplicate IP	Not used

.3 DLR topology Indicates the network topology.

Indication	Description
0 = Linear	Indicates linear topology
1 = Ring	Indicates ring topology

.4 DLR status Indicates the status of the network.

Indication	Description
0 = Idle State	Ring Node is in Idle state
1 = Normal State	Ring Node is in Normal state
2 = Fault State	Ring Node is in Fault state

S5.5 Modbus TCP

It allows viewing information about the Modbus TCP protocol.

S5.5 Modbus TCP

.1 Communication status	0 ... 3
.2 Received telegrams	0 ... 65535
.3 Transmitted telegrams	0 ... 65535
.4 Active connections	0 ... 8

.1 Communication status It allows to identify the communication status with Modbus TCP server.

Indication	Description
0 = Inactive	Not used
1 = No Connection	Communication enabled, but no Modbus TCP connection active
2 = Connected	At least one active Modbus TCP connection
3 = Timeout Error	The equipment detected timeout in the Modbus TCP communication

.2 Received telegrams It indicates the number of telegrams received by the device as a server in the Modbus TCP network.

.3 Transmitted telegrams It indicates the number of telegrams sent by the device as a server in the Modbus TCP network.



NOTE!

These counters start at 0 whenever the product is powered on. They also return to 0 whenever the maximum limit of the parameter is reached.

.4 Active connections It indicates the number of Modbus TCP connections active in the product.

S STATUS

S5.6 Anybus

It allows viewing the status of the Anybus interface, the accessory model and the commands sent to the MVW.

S5.6 Anybus

.1 Identification	0 ... 5
.2 Communication status	0 ... 4
.3 Control word	0 ... 7 Bit
.4 Speed reference	-200.00 ... 200.00 %

.1 Identification It identifies the model of the Anybus communication accessory connected to the MVW.

Indication	Description
0 = Inactive	No Anybus communication accessory installed
1 = PROFIBUS DP-V1	PROFIBUS DP accessory installed
2 = EtherCAT	EtherCAT accessory installed
3 = PROFINET IRT	PROFINET IRT active accessory installed
4 ... 5 = Not used	Not used

.2 Communication status It informs the status of the communication accessory.

Indication	Description
0 = Inactive	No Anybus communication accessory detected
1 = Not Supported	Anybus accessory detected is not supported by the MVW inverter
2 = Access Error	Problem detected in data access between the inverter and the Anybus communication accessory
3 = Offline	Anybus accessory reporting problems. There is no cyclical data exchange with the master
4 = Online	Normal Anybus accessory communication. Effective cyclic and acyclic data exchange between the MVW and the network master

.3 Control word It indicates the status of the control word via Anybus. This parameter can only be changed via Anybus. For other sources, only read access is allowed.

For the commands written in this parameter to be executed, the inverter must be programmed to be commanded via Anybus. This programming is done through the menu C4.

Each bit of this word represents a command that can be executed on the inverter.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.4 Speed reference Indicates the speed reference sent via the Anybus interface to the motor driven by the inverter, as a percentage of the maximum speed. This parameter can only be changed via the Anybus interface. For the other sources, read-only access is allowed.

For the reference written in this parameter to be used, the inverter must be programmed to use the speed

reference via Anybus. This configuration is performed through menu C4.

- S5.6.4 = 0.00 % → speed reference = 0 rpm
- S5.6.4 = 100.00 % → speed reference = C4.3.1.1.2

Intermediate or higher speed values can be obtained using this scaling. For example, if the desired reference value is 900 rpm and C4.3.1.1.2 = 1800 rpm, calculate:

100.00 % ⇒ 1800 rpm
Reference % ⇒ 900 rpm

$$\text{Reference \%} = \frac{900 \times 100.00}{1800}$$

Reference % = 50 %

Negative values can be used to reverse the motor rotation direction. However, the motor rotation direction also depends on the value of the rotation direction command bit in S1.6.1:

- Rotation Direction bit = 1 and S5.6.4 > 0: reference for forward direction.
- Rotation Direction bit = 1 and S5.6.4 < 0: reference for reverse direction.
- Rotation Direction bit = 0 and S5.6.4 > 0: reference for reverse direction.
- Rotation Direction bit = 0 and S5.6.4 < 0: reference for forward direction.

S5.7 CAN/CANopen/DNet

Status of the CAN communication accessory and the protocols that use this interface.

S5.7 CAN/CANopen/DNet

.1 CAN controller status	0 ... 6
.2 Control word	0 ... 7 Bit
.3 Speed reference	-200.00 ... 200.00 %
.5 Received telegrams	0 ... 65535
.6 Transmitted telegrams	0 ... 65535
.7 Bus off Counter	0 ... 65535
.8 Lost messages	0 ... 65535
.9 CANopen comm. status	0 ... 5
.10 CANopen node status	0 ... 4
.11 DNet network status	0 ... 5
.12 DNet master status	0 ... 1

.1 CAN controller status It allows identifying whether the CAN interface is properly installed, and whether the communication presents errors.

Indication	Description
0 = Inactive	CAN interface inactive. It occurs when the equipment does not have a CAN protocol programmed in C9.8.1
1 = Auto-Baud	Running function for automatic baud rate detection (only for DeviceNet protocol)
2 = CAN Active	CAN interface active and without error
3 = Warning	CAN controller has reached the warning status
4 = Error Passive	CAN controller has reached error passive status
5 = Bus Off	CAN controller has reached bus off status
6 = No Bus Power	The CAN interface has no power supply between pins 1 and 5 of the connector

S STATUS

.2 Control word It indicates the status of the control word via CAN interface. This parameter can only be changed via CAN interface. For other sources, only read access is allowed.

For the commands written in this parameter to be executed, the inverter must be programmed to be commanded via CAN/CO/DN. This programming is done through menu C4.

Each bit of this word represents a command that can be executed on the inverter.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.3 Speed reference It indicates the speed reference sent via CAN interface to the motor driven by the inverter in percentage of the maximum speed. This parameter can only be changed via CAN interface. For other sources, only read access is allowed.

For the reference written in this parameter to be used, the inverter must be programmed to use the speed reference via CAN/CO/DNET. This programming is done through menu C4.

- S5.7.3 = 0.00 % $\Rightarrow$ speed reference = 0 rpm
- S5.7.3 = 100.00 % $\Rightarrow$ speed reference = C4.3.1.1.2

Intermediate or higher speed values can be obtained by using this scale. For example, if the desired value for the reference is 900 rpm, considering C4.3.1.1.2 = 1800 rpm, it should be calculated:

100.00 % : 1800 rpm
Reference % : 900 rpm

$$\text{Reference \%} = \frac{900 \times 100.00}{1800}$$

Reference % = 50 %

Negative values can be used to reverse the direction of rotation of the motor. The direction of rotation of the motor, however, also depends on the value of the rotation direction command bit in S1.6.1:

- Bit Rotation Direction = 1 and S5.7.3 > 0: reference for the forward direction
- Bit Rotation Direction = 1 and S5.7.3 < 0: reference for the reverse direction
- Bit Rotation Direction = 0 and S5.7.3 > 0: reference for the reverse direction
- Bit Rotation Direction = 0 and S5.7.3 < 0: reference for the forward direction

.5 Received telegrams This parameter works as a cyclic counter that is incremented every time a CAN telegram is received. It provides feedback to the operator if the device is able to communicate with the network.

.6 Transmitted telegrams This parameter works as a cyclic counter that is incremented every time a CAN telegram is transmitted. It provides feedback to the operator if the device is able to communicate with the network.

.7 Bus off Counter Cyclic counter that indicates the number of times the equipment went into the bus off state on the CAN network.

.8 Lost messages It is a cyclic counter that indicates the number of messages the CAN interface received but could not be processed. In case the number of lost messages frequently increases, it is recommended to reduce the baud rate used in the CAN network.



NOTE!

These counters are reset to zero whenever the equipment is turned off, reset or reach the maximum limit set in the parameter.

.9 CANopen comm. status It indicates the status of the CAN accessory in relation to the CANopen network, informing if the protocol has been enabled and if the error control service is active (*Node Guarding* or *Heartbeat*).

Indication	Description
0 = Inactive	CANopen protocol disabled
1 = Not used	
2 = Comm. Enabled	Communication enabled
3 = Error Ctrl. Enab.	Communication enabled and error control enabled (Node Guarding/Heartbeat)
4 = Guarding Error	Node Guarding error occurred
5 = Heartbeat Error	Heartbeat error occurred

.10 CANopen node status Each slave in the CANopen network has a state machine that controls its behavior in relation to communication. This parameter indicates which state the device is in, according to the protocol specification.

Indication	Description
0 = Inactive	CANopen protocol disabled
1 = Initialization	Communication with the device is not possible during this stage, which is completed automatically
2 = Stopped	Only the NMT object is available
3 = Operational	All communication objects are available
4 = Pre-Operational	It is possible to communicate with the slave but the PDOs are not yet available for operation

.11 DNet network status It indicates the DeviceNet network status.

Indication	Description
0 = Offline	No power supply or not online. Communication cannot be established
1 = Online Not Connec.	Device online but not connected. Slave has successfully completed the MacID verification procedure. This means that the baud rate setting is correct (or correctly detected in case of using autobaud) and that there are no other nodes in the network with the same address. However, at this stage, there is still no communication with the master
2 = Online, Connected	Device operational and under normal conditions. Master allocated a set of I/O type connections with the slave. In this step, the data exchange takes place through I/O type connections
3 = Connection Timed Out	One or more I/O type connections timed out
4 = Link Failure	It indicates that the slave cannot enter the network due to address problems or due to bus off. Check if the address is not already being used by another device, if the baud rate selected is correct or if there are problems in the installation
5 = Auto-Baud	Equipment running routine of the autobaud mechanism

.12 DNet master status It indicates the status of the DeviceNet network master. It may be in "operation mode" (Run) or in "configuration mode" (Idle).

Indication	Description
0 = Run	Reading and writing telegrams are processed and updated normally by the master
1 = Idle	Only reading telegrams from the slaves are updated by the master. Writing, in this case, is disabled

S STATUS



NOTE!

When communication is disabled, this parameter does not represent the actual status of the master.

S6 SOFTPLC

The SoftPLC function provides the MVW inverter with the functionalities of a PLC (Programmable Logic Controller), adding flexibility to the product and allowing the users to develop their own applications (user programs). See the WPS (WEG Programming Suite) manual for more details regarding the programming of the MVW PLC functions, available at www.weg.net.

S6.1 Program execution

It allows viewing the status of the SoftPLC function status parameters.

S6.1 Program execution

.1 Status	0 ... 4
.2 Time	0 ... 65535 ms

.1 Status It allows the user to view the SoftPLC status.

Indication	Description
0 = No Program	It indicates that there is no program saved in the SoftPLC memory area. User parameters will not be shown on the HMI
1 = Saving Program	It indicates that the program is being saved in the SoftPLC memory area
2 = Invalid Program	It indicates that the program is saved in the SoftPLC memory area and is not compatible with the firmware version (S1.2.1) of the MVW. In this case, the user must recompile the project in the WPS software considering the new firmware version of the MVW and redo the "download"
3 = Program Stopped	It indicates that there is a valid program in the SoftPLC memory area, but it is not running, that is, it is stopped
4 = Program Running	It indicates that there is a valid program in the SoftPLC memory area and it is running

.2 Time It indicates the program runtime in milliseconds. The larger the program, the longer the runtime (scan) tends to be.

S6.2 Control and references

It allows viewing the control and reference parameter status of the SoftPLC function.

S6.2 Control and references

.1 Control word	0 ... 7 Bit
.3 Speed reference	-200.00 ... 200.00 %

.1 Control word It indicates the status of the control word via the SoftPLC function. This parameter can only be changed via SoftPLC function. For other sources, only read access is allowed.

For the commands written in this parameter to be executed, the inverter must be programmed to be commanded via SoftPLC. This programming is done through menu C4.

Each bit of this word represents a command that can be executed on the inverter.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.3 Speed reference It indicates the speed reference via SoftPLC function for the motor driven by the inverter in percentage of the maximum speed. This parameter can only be changed via SoftPLC function. For other sources, only read access is allowed.

For the reference written in this parameter to be used, the inverter must be programmed to use the speed reference via SoftPLC. This programming is done through menu C4.

- S6.2.3 = 0.00 % ⇒ speed reference = 0 rpm
- S6.2.3 = 100.00 % ⇒ speed reference = C4.3.1.1.2

Intermediate or higher speed values can be obtained by using this scale. For example, if the desired value for the reference is 900 rpm, considering C4.3.1.1.2 = 1800 rpm, it should be calculated:

100.00 % : 1800 rpm
Reference % : 900 rpm

$$\text{Reference \%} = \frac{900 \times 100.00}{1800}$$

Reference % = 50 %

Negative values can be used to reverse the direction of rotation of the motor. The direction of rotation of the motor, however, also depends on the value of the rotation direction command bit in S1.6.1:

- Bit Rotation Direction = 1 and S6.2.3 > 0: reference for the forward direction
- Bit Rotation Direction = 1 and S6.2.3 < 0: reference for the reverse direction
- Bit Rotation Direction = 0 and S6.2.3 > 0: reference for the reverse direction
- Bit Rotation Direction = 0 and S6.2.3 < 0: reference for the forward direction

8 D DIAGNOSTICS

It allows viewing variables and events that can help diagnose problems or improve the MVW operation.

D1 FAULTS

It allows viewing fault activation occurrences on the MVW.

D1.1 Current

It allows viewing the faults occurred on the MVW. If any fault is active, its number is displayed. If it is not active, 0 is displayed.

The faults act by disabling the motor. They are removed only with a reset or de-energizing command from the MVW control.

The fault occurrences are placed in a row following the sequence of the cause that generated them. In this menu the activation of up to 5 faults can be indicated simultaneously. Whenever a fault acts, it enters the first empty position and so on. The reset command will only reset Fault 1.

Visually on the HMI, if only one fault is activated, it will be in the first position (Fault 1).

D1.1 Current

.1 Fault 1	0 ... 4095
.2 Fault 2	0 ... 4095
.3 Fault 3	0 ... 4095
.4 Fault 4	0 ... 4095
.5 Fault 5	0 ... 4095

.1 Fault 1 First position of active fault indication.

.2 Fault 2 Second position of active fault indication.

.3 Fault 3 Third position of active fault indication.

.4 Fault 4 Fourth position of active fault indication.

.5 Fault 5 Fifth position of active fault indication.

D1.3 History

It indicates the code, date and time of the last 10 faults.

D1.3 History

.1 Last fault	0 ... 9999	
.2 Date and time last fault	YYYY-MM-DD	HH:MM:SS
.3 Second fault	0 ... 9999	
.4 Date and time second fault	YYYY-MM-DD	HH:MM:SS
.5 Third fault	0 ... 9999	
.6 Date and time third fault	YYYY-MM-DD	HH:MM:SS
.7 Fourth fault	0 ... 9999	
.8 Date and time fourth fault	YYYY-MM-DD	HH:MM:SS
.9 Fifth fault	0 ... 9999	
.10 Date and time fifth fault	YYYY-MM-DD	HH:MM:SS
.11 Sixth fault	0 ... 9999	
.12 Date and time sixth fault	YYYY-MM-DD	HH:MM:SS
.13 Seventh fault	0 ... 9999	
.14 Date and time seventh fault	YYYY-MM-DD	HH:MM:SS
.15 Eighth fault	0 ... 9999	
.16 Date and time eighth fault	YYYY-MM-DD	HH:MM:SS
.17 Ninth fault	0 ... 9999	
.18 Date and time ninth fault	YYYY-MM-DD	HH:MM:SS
.19 Tenth fault	0 ... 9999	
.20 Date and time tenth fault	YYYY-MM-DD	HH:MM:SS

.1 Last fault It indicates the code of the last fault that happened.

.2 Date and time last fault It indicates the date and time of the last fault that happened.

.3 Second fault It indicates the code of the second fault that happened.

.4 Date and time second fault It indicates the date and time of the second fault that happened.

.5 Third fault It indicates the code of the third fault that happened.

.6 Date and time third fault It indicates the date and time of the third fault that happened.

.7 Fourth fault It indicates the code of the fourth fault that happened.

.8 Date and time fourth fault It indicates the date and time of the fourth fault that happened.

.9 Fifth fault It indicates the code of the fifth fault that happened.

.10 Date and time fifth fault It indicates the date and time of the fifth fault that happened.

.11 Sixth fault It indicates the code of the sixth fault that happened.

.12 Date and time sixth fault It indicates the date and time of the sixth fault that happened.

.13 Seventh fault It indicates the code of the seventh fault that happened.

.14 Date and time seventh fault It indicates the date and time of the seventh fault that happened.

.15 Eighth fault It indicates the code of the eighth fault that happened.

.16 Date and time eighth fault It indicates the date and time of the eighth fault that happened.

.17 Ninth fault It indicates the code of the ninth fault that happened.

.18 Date and time ninth fault It indicates the date and time of the ninth fault that happened.

.19 Tenth fault It indicates the code of the tenth fault that happened.

.20 Date and time tenth fault It indicates the date and time of the tenth fault that happened.

D2 ALARMS

It allows viewing the alarms occurred in the MVW.

D2.1 Actual

It allows viewing the alarms occurred in the MVW. If any alarm is active, the alarm number is displayed; otherwise, 0 is displayed.

The alarms are displayed on the HMI and on the MVW status word. They are automatically removed after leaving the alarm condition.

Alarms are placed in a line, which can display up to 5 alarms simultaneously. Whenever an alarm occurs, it goes to the first empty position (if there is no indication of any previous alarm, it will be shown in Alarm 1).

Visually on the HMI, if only one alarm occurs, it will be in the first position (Alarm 1).

D2.1 Actual	
.1 Alarm 1	0 ... 4095
.2 Alarm 2	0 ... 4095
.3 Alarm 3	0 ... 4095
.4 Alarm 4	0 ... 4095
.5 Alarm 5	0 ... 4095

.1 Alarm 1 First position of alarm indication (Actual alarm).

.2 Alarm 2 Second position of alarm indication.

.3 Alarm 3 Third position of alarm indication.

.4 Alarm 4 Fourth position of alarm indication.

.5 Alarm 5 Fifth position of alarm indication.

D2.3 History

It indicates the code, date and time of the last 10 alarms.

D2.3 History

.1 Last alarm	0 ... 9999	
.2 Date and time last alarm	YYYY-MM-DD	HH:MM:SS
.3 Second alarm	0 ... 9999	
.4 Date and time second alarm	YYYY-MM-DD	HH:MM:SS
.5 Third alarm	0 ... 9999	
.6 Date and time third alarm	YYYY-MM-DD	HH:MM:SS
.7 Fourth alarm	0 ... 9999	
.8 Date and time fourth alarm	YYYY-MM-DD	HH:MM:SS
.9 Fifth alarm	0 ... 9999	
.10 Date and time fifth alarm	YYYY-MM-DD	HH:MM:SS
.11 Sixth alarm	0 ... 9999	
.12 Date and time sixth alarm	YYYY-MM-DD	HH:MM:SS
.13 Seventh alarm	0 ... 9999	
.14 Date and time seventh alarm	YYYY-MM-DD	HH:MM:SS
.15 Eighth alarm	0 ... 9999	
.16 Date and time eighth alarm	YYYY-MM-DD	HH:MM:SS
.17 Ninth alarm	0 ... 9999	
.18 Date and time ninth alarm	YYYY-MM-DD	HH:MM:SS
.19 Tenth alarm	0 ... 9999	
.20 Date and time tenth alarm	YYYY-MM-DD	HH:MM:SS

- .1 Last alarm** It indicates the code of the last alarm that happened.
- .2 Date and time last alarm** It indicates the date and time of the last alarm that happened.
- .3 Second alarm** It indicates the code of the second alarm that happened.
- .4 Date and time second alarm** It indicates the date and time of the second alarm that happened.
- .5 Third alarm** It indicates the code of the third alarm that happened.
- .6 Date and time third alarm** It indicates the date and time of the third alarm that happened.
- .7 Fourth alarm** It indicates the code of the fourth alarm that happened.
- .8 Date and time fourth alarm** It indicates the date and time of the fourth alarm that happened.
- .9 Fifth alarm** It indicates the code of the fifth alarm that happened.
- .10 Date and time fifth alarm** It indicates the date and time of the fifth alarm that happened.
- .11 Sixth alarm** It indicates the code of the sixth alarm that happened.
- .12 Date and time sixth alarm** It indicates the date and time of the sixth alarm that happened.
- .13 Seventh alarm** It indicates the code of the seventh alarm that happened.
- .14 Date and time seventh alarm** It indicates the date and time of the seventh alarm that happened.
- .15 Eighth alarm** It indicates the code of the eighth alarm that happened.
- .16 Date and time eighth alarm** It indicates the date and time of the eighth alarm that happened.
- .17 Ninth alarm** It indicates the code of the ninth alarm that happened.
- .18 Date and time ninth alarm** It indicates the date and time of the ninth alarm that happened.
- .19 Tenth alarm** It indicates the code of the tenth alarm that happened.
- .20 Date and time tenth alarm** It indicates the date and time of the tenth alarm that happened.

D3 HOUR CONTROL

It allows viewing the total running hours of some MVW conditions.

D3 Hour control

.1 Time powered	0 ... 65536 h
.2 Hours enabled	0 ... 65536 h

.1 Time powered It indicates the total hours that the inverter has been powered.

This value is kept even when the inverter is shut down.

.2 Hours enabled It indicates the total number of hours that the inverter remained enabled.

It indicates up to 65536 hours, and then it returns to zero.

Setting parameter C1.6.2 option 3, the value of parameter D3.2 goes to zero.

This value is kept even when the inverter is shut down.

D4 INVERTER AND ACCESS.

It allows viewing the measurement of the MVW operating conditions.

D4.1 Inverter

It allows viewing the measurement of operating conditions related to the inverter.

D4.1.4 Control voltages

It indicates the voltage of the MVW control board power supplies.

D4.1.4 Control voltages

.1 Voltage 24V IO	0.00 ... 655.35 V
.2 Battery voltage	0.00 ... 655.35 V
.3 Voltage 3.3V control	0.00 ... 655.35 V
.4 Voltage 24V control	0.00 ... 655.35 V
.5 Voltage 3.3V IO	0.00 ... 655.35 V
.6 Voltage 5V AUI	0.00 ... 655.35 V

.1 Voltage 24V IO It indicates the voltage value of the 24 V source for IO accessories (V).

.2 Battery voltage It indicates the battery voltage value (V).

.3 Voltage 3.3V control It indicates the 3.3 V source voltage value for the control board (V).

.4 Voltage 24V control It indicates the 24 V source voltage value for the control board (V).

.5 Voltage 3.3V IO It indicates the voltage value of the 3.3 V source for IO accessories (V).

.6 Voltage 5V AUI It indicates the AUI 5V voltage value (V).

D4.1.5 Motor overl. fault

It indicates the control variable of the motor overload fault function.

D4.1.5 Motor overl. fault

.1 Ixt Motor Level	0 ... 100 %
--------------------	-------------

D DIAGNOSTICS

.1 Ixt Motor Level It indicates the actual status of the motor overload.

D4.1.11 Configuration

It allows viewing the status of the user settings storage system.

D4.1.11 Configuration

.1 Last backup operation 0 ... 12

.1 Last backup operation Indicates the last backup operation performed.

Operations that are not completed successfully, such as operations with an SD card without the card being inserted in the product or loading settings that have not been previously saved, return the value of this parameter to "Not Used".

Indication	Description
0 = Not Used	Not used
1 = Default 60 Hz	It loads the MVW settings with the default content of the parameters
2 = Default 50 Hz	It loads the MVW settings with the default content of the parameters All parameters are loaded with the default value of 60 Hz, with the exception of the following cases: ■ C4.3.2.1 set at 125 rpm ■ C4.3.1.1.2 set at 1500 rpm ■ C4.3.1.3.1 set at 75 rpm ■ C5.9.3 set at 15 rpm ■ C4.3.1.5.1 set at 75 rpm ■ C5.9.4 set at 100 rpm ■ C4.3.1.5.2 set at 250 rpm ■ C5.9.5 set at 1500 rpm ■ C4.3.1.5.3 set at 500 rpm ■ C5.9.8 set at 15 rpm ■ C4.3.1.5.4 set at 750 rpm ■ C2.1.8 set at 1458 rpm ■ C4.3.1.5.5 set at 1000 rpm ■ C2.1.6 set at 50 Hz ■ C4.3.1.5.6 set at 1250 rpm ■ C4.3.1.5.7 set at 1500 rpm ■ C4.3.1.5.8 set at 1375 rpm ■ C4.3.1.1.1 set at 75 rpm
3 = Param. Set 1 -> MVW	It loads the MVW settings with the content of parameter set 1
4 = Param. Set 2 -> MVW	It loads the MVW settings with the content of parameter set 2
5 = Param. Set 3 -> MVW	It loads the MVW settings with the content of parameter set 3
6 = MVW -> Param. Set 1	It saves the content of the MVW current settings for parameter set 1
7 = MVW -> Param. Set 2	It saves the content of the MVW current settings for parameter set 2
8 = MVW -> Param. Set 3	It saves the content of the MVW current settings for parameter set 3
9 = SD Card -> MVW	It loads the MVW settings with the content of parameter set imported from the SD card Additionally, it imports the settings of parameter sets 1, 2 and 3 from the SD card to the inverter memory
10 = MVW -> SD Card	It saves the content of the actual MVW settings on the SD card Additionally, it exports the settings from parameter sets 1, 2 and 3 to the SD card
11 ... 12 = Not used	Not used

D4.1.12 Advanced

Allows viewing parameters with advanced information to aid the inverter diagnosis.

D4.1.12 Advanced

.1 Last assert	0 ... 4294967295
.2 Last reset reason (AUI)	0 ... 4294967295
.3 Code flow 2 Date time	YYYY-MM-DD HH:MM:SS
.4 Code Flow 1 Date Time	YYYY-MM-DD HH:MM:SS

.1 Last assert It indicates the code related to the last assert that happened.

8-digit hexadecimal number arranged as follows:

0xABBBBCCC

A = 0[none]; 1[AUI] B = File name identification C = Line number identification

.2 Last reset reason (AUI) It indicates the code related to the reason of the last CPU reset that happened.

8-digit hexadecimal number arranged as follows:

0xABBCCCCC

A = 0[none]; 1[AUI] B = Reset reason identification C = Additional information

.3 Code flow 2 Date time Indicates the date and time at which parameter D4.1.12.2 was last updated.

.4 Code Flow 1 Date Time Indicates the date and time at which parameter D4.1.12.1 was last updated.

D4.2 Accessories

It allows viewing the data for diagnosing the control accessories installed in the MVW.

D4.2.1 Diag. Slot A to D4.2.7 Diag. Slot G

It allows viewing the diagnostics data of the accessory connected to the slot.

D4.2.1 Diag. Slot A**D4.2.2 Diag. Slot B****D4.2.3 Diag. Slot C****D4.2.4 Diag. Slot D****D4.2.5 Diag. Slot E****D4.2.6 Diag. Slot F****D4.2.7 Diag. Slot G**

.1 Status	0 ... 3
.3 Temperature	-100.0 ... 250.0 °C

.1 Status It shows the accessory status.

Indication	Description
0 = Not Connected	There is no accessory connected
1 = Initializing	There is an accessory connected, and it is initializing
2 = Active	There is an accessory connected, and it is communicating properly
3 = Error	There is an accessory connected, and it is presenting some error in the communication with the MVW

.3 Temperature It indicates the control temperature measured by the accessory.

9 C CONFIGURATIONS

It allows changing the MVW configuration parameters. Depending on the parameter property, it is possible to set its value according to the table below.

Property	Description
Stopped	Parameter can only be changed with the motor stopped.
Model	Default value may change according to inverter model.



NOTE!
Parameter options with the description "Not used" are for WEG's exclusive use.

C1 INVERTER AND POWER SUPPLY

Configuration of inverter parameters related to power supply, utilization, switching frequency, fans and general settings.


C1.2 Inverter use

It allows setting the inverter operating duty.


C1.2 Inverter use		
C1.2.2 Inverter test mode		
Range:	0 ... 3	Default: 0
Properties:		

Description:
Enables and configures inverter operation in test mode.

The automatic cycle enables inverter operation with a variable output frequency and can be used to assist in diagnosing product faults.



(a) Without rotation direction reversal



(b) With rotation direction reversal

Figure 9.1: Automatic cycle

For the current measurement test, the analog outputs provide sinusoidal signals that, when connected to the current measurement inputs, allow testing the measurement channels. At the same time, earth-leakage protection remains active, allowing verification of its tripping operation.

Indication	Description
0 = Inactive	Test mode inactive. All communications, protections and inverter functions are enabled.
1 = No cells and no measurements	Test mode active. The inverter operates with cell communications and measurements disabled.
2 = No cells	Test mode active. The inverter operates with cell communications disabled.
3 = No measurements	Test mode active. The inverter operates with measurements disabled.

C1.2 Inverter use

C1.2.3 Fixed frequency operating mode

Range: 0 ... 1

Default: 0

Properties:

Description:

Selects the operating strategy used by the inverter to set the output voltage frequency when PWM is enabled.

In fixed-frequency mode, the output frequency is defined by the motor rated frequency value set in C2.1.6. The voltage amplitude varies according to the speed ramp and follows the U/f curve settings.

**NOTE!**

Fixed-frequency mode should be enabled when testing the inverter with purely reactive loads.

Indication	Description
0 = Inactive	The inverter operates with a variable output frequency.
1 = Active	The inverter operates with a constant output frequency.

C1.2 Inverter use**C1.2.4 Injected frequency**

Range: 0 ... 2 **Default:** 0
Properties:

Description:

Enables double-frequency injection in the motor under scalar control.

Indication	Description
0 = Inactive	Function disabled
1 = Active	The second frequency is constantly injected to stress the motor.
2 = Not used	Not used

C1.2 Inverter use**C1.2.5 Order of injected frequency**

Range: 0.10 ... 10.00 **Default:** 1.20
Properties:

Description:

Determines the order of the frequency injected by the inverter relative to the fundamental frequency.

$$f_{\text{injected}} = \text{Order} \times f_{\text{fundamental}}$$

If the second frequency value exceeds the maximum that the inverter can inject, it will be limited to the highest possible value.

C1.2 Inverter use**C1.2.6 Amplitude of the injected frequency**

Range: 0.0 ... 50.0 % **Default:** 0.0 %
Properties:

Description:

Determines the amplitude of the second frequency injected by the inverter relative to the fundamental amplitude.

$$V_{\text{injected}} = \text{Amplitude} \times V_{\text{fundamental}}$$

C1.6 Other inverter settings**C1.6 Other inverter settings****C1.6.2 Reset counters**

Range: 0 ... 3 **Default:** 0
Properties:

Description:

It allows resetting the values for the parameters of energy, fan running hours and inverter enabled hours.

C CONFIGURATIONS

Indication	Description
0 = Disabled	Disable function
1 = Energy	Reset energy parameters S2.3.12, S2.3.13 and S2.3.14
2 = Not used	Not used
3 = Inverter Enabled	Reset enabled inverter hours parameter D3.2

C1.7 Control accessories

General settings of the accessories installed on the MVW.

C1.7.1 Slot A to C1.7.7 Slot G

It allows viewing the status of the configuration parameters of the Slot.

C1.7.1 Slot A

C1.7.2 Slot B

C1.7.3 Slot C

C1.7.4 Slot D

C1.7.5 Slot E

C1.7.6 Slot F

C1.7.7 Slot G

.1 Request identification

Range: 0 ... 9

Default: 0

Properties: Stopped

Description:

It allows forcing the use of a certain accessory. If the accessory is not installed a fault will be generated.

Indication	Description
0 = Automatic	Automatic identification. It does not require using a certain accessory
1 = No Accessory	This Slot must not contain any accessory
2 = IOAI-01	Accessory with analog inputs and outputs
3 = IOD-01	Accessory with digital inputs and outputs
4 = REL-01	Accessory with digital relay outputs
5 = TEMP-01	Accessory with isolated inputs for PTC/PT100/PT1000 sensors
6 = ENC-01	Accessory for incremental encoder connection
7 = CFW900-CPDP-01	Communication accessory for Profibus-DP interface
8 = CCAN-W	Communication accessory for CAN interface
9 = C...-N (Anybus)	Communication accessory for Anybus-CC module

C1.8 Measurements

C1.8 Measurements

C1.8.2 Delay between I_{in} and V_{in} measurements

Range: -99.99 ... 99.99 ms

Default: 0.00 ms

Properties:

Description:

Adjusts the delay between the inverter input current and voltage measurements.

This parameter affects the input power measurements, acting directly on the relationship between active power and apparent power.



ATTENTION!

An incorrect setting may cause improper operation of the inverter input transformer protection.

C1.9 Precharge

During the first and second pre-charge stages, all active cells must reach 50% and 90% of the rated DC bus voltage, respectively.




Figure 9.2: Pre-charge stages

C1.9 Precharge		
C1.9.1 Maximum time for the first stage		
C1.9.2 Maximum time for the second stage		
Range:	0 ... 40 s	Default: 10 s (C1.9.1) 15 s (C1.9.2)
Properties:		

Description:
Define os limites de tempo para a conclusão dos estágios da pré-carga.




Figure 9.3: Exemplo de time-out na pré-carga

C1.9 Precharge		
C1.9.3 Maximum time for closing feedback		
C1.9.4 Maximum time for opening feedback		
Range:	0.0 ... 20.0 s	Default: 0.5 s
Properties:		

Description:
Defines the time limits for receiving the input cubicle closing confirmations before faults F0014 and F0015 trip.

C1.9 Precharge

C1.9.6 Operating mode

Range: 0 ... 1

Default: 0

Properties: Stopped

Description:

Defines the pre-charge strategy used.

In standard pre-charge mode, a voltage ramp is performed up to 90% of the rated DC bus voltage. Then, pre-charge is completed and the inverter commands closing of the input cubicle. Closing is a mechanical process with dynamics much slower than the control dynamics. For this reason, time-outs are used for commanded actions while the inverter monitors the cubicle feedback signals.




Figure 9.4: Standard pre-charge

In synchronous mode, after reaching 90% of the rated DC bus voltage, the mains synchronization process is started. After synchronization, the auxiliary inverter informs the MVW control, via DI15, that pre-charge is complete, allowing the input cubicle closing command to be issued.

After closing confirmation, pre-charge is finalized, eliminating current peaks associated with transformer *inrush*.




Figure 9.5: Synchronous pre-charge

Indication	Description
0 = Standard	Pre-charge with resistor bank or auxiliary inverter. In this mode, the command to close the input cubicle is performed by the CCE board.
1 = Synchronous	Pre-charge with auxiliary inverter synchronized with the electrical grid. In this mode, the command to close the input cubicle is performed by the auxiliary inverter.

C1.10 Calibrations

C1.10 Calibrations

C1.10.1 Calibration

Range: 0 ... 28

Default: 0

Properties:

Description:

Indicates the manual calibration value or the value resulting from the automatic calibration of the respective measurement.

Indication	Description
0 = Inactive	
1 = Ia Offset	
2 = Ia F.S.	
3 = Ib_1 Current - Offset	
4 = Ib_1 Current - Full Scale	
5 = Ic_1 Current - Offset	
6 = Ic_1 Current - Full Scale	
7 = Vab Voltage - Offset	
8 = Vab Voltage - Full Scale	
9 = Vbc Voltage - Offset	
10 = Vbc Voltage - Full Scale	
11 = Vuv Voltage - Offset	
12 = Vuv Voltage - Full Scale	
13 = Vvw Voltage - Offset	
14 = Vvw Voltage - Full Scale	
15 = Vn-gnd Voltage - Offset	
16 = Vn-gnd Voltage - Full Scale	
17 = Ib_2 Current - Offset	
18 = Ib_2 Current - Full Scale	
19 = Ic_2 Current - Offset	
20 = Ic_2 Current - Full Scale	
21 = Ib_3 Current - Offset	
22 = Ib_3 Current - Full Scale	
23 = Ic_3 Current - Offset	
24 = Ic_3 Current - Full Scale	
25 = Output voltage Vab - Offset	
26 = Output voltage Vab - Full scale	
27 = Output voltage Vbc - Offset	
28 = Output voltage Vbc - Full scale	

C2 MOTOR

Definition of the characteristics of the motor to be driven by the MVW inverter.

C CONFIGURATIONS

C2.1 Motor data

Definition of motor rated data.



NOTE!

The motor data set in C2.1 (from C2.1.1 to C2.1.12) must be exactly as shown on the motor nameplate.

C2.1 Motor data

C2.1.1 Motor type

Range:	0 ... 4	Default: 0
Properties:	Stopped	

Description:

Sets the type of motor to be driven by the inverter.

For Synchronous Machine Configuration

- IPSPM: Internal permanent magnet synchronous machine (Inductance L_q greater than L_d).
- SPSM: Surface permanent magnet synchronous machine (Inductance L_q equal to L_d).

If you do not know the type of synchronous machine that will be used, select the IPSPM option.

Indication	Description
0 = Induction	It selects that it is an induction motor
1 = Internal permanent magnet synchronous	Selects an interior permanent-magnet synchronous motor (L_q greater than L_d).
2 = Surface permanent magnet synchronous	Selects that it is a synchronous motor with surface permanent magnets, L_d and L_q equal
3 = EE synchronous with AC exciter	Selects that it is a synchronous motor with external excitation (EE) and field windings fed through an AC exciter
4 = EE synchronous with brushes	Selects that it is a synchronous motor with external excitation (EE) and field windings fed through brushes

C2.1 Motor data

C2.1.3 Rated power

Range:	0 ... 65000 kW	Default: 0 kW
Properties:	Stopped	

Description:

It sets the value of the motor rated power as per the motor nameplate data.

C2.1 Motor data

C2.1.4 Rated voltage

Range:	1 ... 19999 V	Default: 6600 V
Properties:	Stopped	

Description:

It sets the motor rated voltage value.

C2.1 Motor data

C2.1.5 Rated current

Range:	0.0 ... 3705.0 A	Default: 140.0 A
Properties:	Stopped	

Description:

It sets the motor rated current value. The value must be set according to the motor nameplate data.

C2.1 Motor data**C2.1.6 Rated frequency**

Range:	0.1 ... 500.0 Hz	Default: 60.0 Hz
Properties:	Stopped	

Description:

It sets the motor rated frequency value.

C2.1 Motor data**C2.1.7 Number of poles**

Range:	2 ... 180	Default: 4
Properties:	Stopped	

Description:

It sets the number of poles of the motor.

**NOTE!**

Parameter available only for synchronous motor.

C2.1 Motor data**C2.1.8 Rated speed**

Range:	0 ... 32000 rpm	Default: 1750 rpm
Properties:	Stopped	

Description:

It sets the motor rated speed value.

C2.1 Motor data**C2.1.9 Rated efficiency**

Range:	50.0 ... 99.9 %	Default: 99.9 %
Properties:	Stopped	

Description:

It sets the motor rated efficiency.

C2.1 Motor data**C2.1.10 Rated cos phi**

Range:	0.50 ... 0.99	Default: 0.82
Properties:	Stopped	

Description:

It sets the motor rated $\cos \varphi$.

C2.1 Motor data**C2.1.11 Service factor**

Range:	1.00 ... 1.50	Default: 1.15
Properties:	Stopped	

Description:

It sets the motor rated service factor (SF).

C CONFIGURATIONS

C2.1 Motor data

C2.1.12 Ventilation

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

It defines the motor ventilation system arrangement.

Indication	Description
0 = Self-ventilated	Motor uses its own ventilation
1 = Independent	Motor uses external ventilation

The value set in C2.1.12 automatically modifies the parameters related to the motor overload fault as follows:

Table 9.11: Change of the motor overload fault

C2.1.12	C7.4.3 (100 %)	C7.4.4 (50 %)	C7.4.5 (5 %)
0	1.00 x C2.1.5	0.86 x C2.1.5	0.62 x C2.1.5
1	1.00 x C2.1.5	1.00 x C2.1.5	1.00 x C2.1.5

C2.2 Motor model

It allows viewing and changing the motor electrical parameters estimated by the Self-Tuning routine. The user can manually set the data if they have the motor data sheet.

C2.2 Motor model

C2.2.1 Stator resistance

Range:	0.000 ... 30.000 Ω	Default: 1.000 Ω
Properties:		

Description:

It sets the motor stator resistance value.

C2.2 Motor model

C2.2.2 Magnetizing reactance

Range:	0.0 ... 800.0 Ω	Default: 1.0 Ω
Properties:		

Description:

It defines the motor magnetization reactance value.

C2.2 Motor model

C2.2.3 Leakage reactance

Range:	0.00 ... 100.00 Ω	Default: 1.00 Ω
Properties:		

Description:

It sets the motor leakage reactance value.

C2.2 Motor model

C2.2.4 Rotor resistance

Range:	0.000 ... 30.000 Ω	Default: 1.000 Ω
Properties:		

Description:

It sets the motor rotor resistance value.

C2.2 Motor model**C2.2.5 Rotor reactance****Range:** 0.00 ... 100.00 Ω **Default:** 1.00 Ω **Properties:****Description:**

It sets the motor rotor reactance value.

C2.2 Motor model**C2.2.6 Ld inductance****Range:** 0.00 ... 650.00 mH**Default:** 0.00 mH**Properties:****Description:**

It sets the value of the motor shaft Ld inductance.

C2.2 Motor model**C2.2.7 Lq inductance****Range:** 0.00 ... 650.00 mH**Default:** 0.00 mH**Properties:****Description:**

It sets the value of the motor shaft Lq inductance.

C2.2 Motor model**C2.2.8 Ke constant****Range:** 0.0 ... 3000.0**Default:** 0.0**Properties:****Description:**

It sets the value of the Ke voltage constant generated by the motor. The engineering unit used is V/krpm (Volts/1000 rpm).

C3 CONTROL

The inverter supplies the motor with variable voltage, current and frequency, which enables the motor speed and torque control. The values applied to the motor follow a control strategy, depending on the selected control type and the inverter parameter settings.

In this menu, choose the control type according to the static and dynamic torque and speed demands of the driven load.

Control Types:

Scalar: scalar control; simpler control type by imposed voltage/frequency; speed regulation in open loop or with slip compensation (programmable); it allows multiple motor operation.

Sensorless vector: field-oriented control; no motor speed sensor; able to drive standard motors; speed control in the range of 1:100; 0.5 % static accuracy of rated speed in speed control; high control dynamics.

Vector with encoder: field-oriented control; requires encoder on the motor and interface module for encoder on the inverter (ENC-01); speed control up to 0 rpm; 0.01 % static accuracy of rated speed in speed control; high static and dynamic performance of speed and torque control.

C3.1 Configuration

It allows setting the control type used to drive the motor.

C CONFIGURATIONS

C3.1 Configuration

C3.1.1 Control type

Range: 0 ... 3

Default: 0

Properties: Stopped

Description:

Defines the type of control that will be used to control the motor speed or torque.

Indication	Description
0 = Scalar or VVW+	Voltage/frequency scalar control. VVW+ control for PM motors
1 = Not used	Not used
2 = Encoder Vector	Vector control with encoder (with speed sensor)
3 = Sensorless Vector	Sensorless vector control (without speed sensor)

C3.2 Scalar control

SCALAR CONTROL FOR INDUCTION MOTOR

This is the classic control for a three-phase induction motor, based on a curve that relates output frequency and voltage. The inverter works as a variable voltage and frequency source, generating frequency and voltage values according to this curve. Figure 9.6 shows the scalar control block diagram.

The scalar control is recommended for the following cases:

- Drive of several motors with the same inverter (multiple motor drive).
- Energy saving in the drive of loads with quadratic torque/speed relationship.
- Motor rated current below 1/3 of the inverter rated current.
- For test purposes, the inverter is turned on without motor or with a small motor with no load.
- Applications where the load connected to the inverter is not a three-phase induction motor.




Figure 9.6: Block diagram of scalar control for induction motors

C3.2.1 V/f curve

It allows adjusting the curve defined by the inverter output voltage and frequency. Example of using this resource: when a transformer is used between the inverter and the motor, and you want to compensate the voltage drop in the cable used to connect the motor.

C3.2.1 V/f curve

C3.2.1.1 Manual torque boost

Range: 0.0 ... 20.0 %

Default: 0.0 %

Properties:

Description:

It acts at low frequencies, that is, in the range from 0 to C3.2.1.5, increasing the inverter output voltage to compensate for the voltage drop in the motor stator resistance in order to maintain a constant torque .

The optimum setting is the smallest value of C3.2.1.1 which allows the motor satisfactory start. A value greater than necessary will excessively increase the motor current at low speeds, which may lead the inverter to a fault condition (F0070 or F0072), as well as to the motor heating. Figure 9.7 shows the Torque Boost action region between points P₀ and P₁.




Figure 9.7: Torque boost region



NOTE!

This functionality is not used when induction motor are selected.



NOTE!

This functionality is not used during the motor deceleration process.

C3.2.1 V/f curve

C3.2.1.2 Low output voltage

Range: 0.0 ... 100.0 %

Default: 33.3 %

Properties: Stopped

Description:

It sets the voltage value of point P₁ to adjust the inverter V/F curve together with its pair C3.2.1.5.

C3.2.1 V/f curve

C3.2.1.3 Intermediate output voltage

Range: 0.0 ... 100.0 %

Default: 66.7 %

Properties: Stopped

Description:

It sets the voltage value of point P₂ to adjust the inverter V/F curve together with its pair C3.2.1.6.

C3.2.1 V/f curve

C3.2.1.4 Maximum output voltage

Range: 0.0 ... 100.0 %

Default: 100.0 %

Properties: Stopped

C CONFIGURATIONS

Description:

It sets the voltage value of point P_3 to adjust the inverter V/F curve together with its pair C3.2.1.7.



NOTE!

The maximum output voltage C3.2.1.4 at 100 % corresponds to the motor rated voltage C2.1.4. In cases where the inverter is being supplied with a line voltage above the motor rated voltage, the output voltage the inverter applies remains the value set in C2.1.4.

C3.2.1 V/f curve

C3.2.1.5 Low speed

Range: 0.0 ... 200.0 %

Default: 33.3 %

Properties: Stopped

Description:

It sets the speed value of point P_1 to adjust the inverter V/F curve together with its pair C3.2.1.2.

C3.2.1 V/f curve

C3.2.1.6 Intermediate speed

Range: 0.0 ... 200.0 %

Default: 66.7 %

Properties: Stopped

Description:

It sets the speed value of point P_2 to adjust the inverter V/F curve together with its pair C3.2.1.3.

C3.2.1 V/f curve

C3.2.1.7 Field weakening start speed

Range: 0.0 ... 200.0 %

Default: 100.0 %

Properties: Stopped

Description:

It sets the speed value of point P_3 to adjust the inverter V/F curve together with its pair C3.2.1.4.

C3.2.1 V/f curve

C3.2.1.8 Rated flux

Range: 0.0 ... 120.0 %

Default: 100.0 %

Properties:

Description:

For scalar control, it allows to adjust a percentage of the motor stator flux in relation to the nominal stator flux.



NOTE!

In the scalar control type, the parameter C3.2.1.8 allows for regulation of the inverter output voltage after setting the V/F curve. This can be useful in applications that require output voltage compensation or field weakening.

C3.2.2 Optimization

It allows adjustments to the Scalar control dynamics. The Scalar control is factory set to suit most applications. If an improvement in the dynamic behavior of the control is required for induction and PM motors, the parameters below are available.

C3.2.2.1 Induction motor

It allows setting the Scalar control parameters for induction motors.

C3.2.2.1 Induction motor**C3.2.2.1.1 Slip compensator gain****Range:** 0.00 ... 10.00**Default:** 1.00**Properties:****Description:**

It allows applying a gain to the slip estimator of the Scalar control.

**NOTE!**

This value should be adjusted gradually when there is a speed error in the system.

C3.2.2.1 Induction motor**C3.2.2.1.2 Voltage compensator gain****Range:** 0.00 ... 5.00**Default:** 1.00**Properties:****Description:**

It allows applying a gain to the Scalar control voltage compensator.

**NOTE!**

This value should be adjusted gradually when there is a voltage error in the system.

C3.2.2.1 Induction motor**C3.2.2.1.3 Filter****Range:** 1 ... 100 ms**Default:** 32 ms**Properties:****Description:**

This parameter sets the low-pass filter used in the speed slip signal.

C3.2.2.2 Permanent magnet synchronous motor

The MTPA function determines the high efficiency region of the PM motor operation. This function guides the motor voltage vector so that it operates with the ratio between the maximum torque applied to the PM motor and its lowest possible current.

**NOTE!**

Function available only for PM motor.

C3.2.2.2 Permanent magnet synchronous motor**C3.2.2.2.1 MTPA function****Range:** 0 ... 1**Default:** 1**Properties:****Description:**

It enables the MTPA function for Scalar control of synchronous machines.

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function

C CONFIGURATIONS

C3.2.2.2 Permanent magnet synchronous motor

C3.2.2.2.3 MTPA minimum speed

Range: 0 ... 100 %

Default: 2 %

Properties:

Description:

It sets a percentage of the motor rated speed to activate the MTPA function. If S2.1.1 is greater than C3.2.2.2.3 x C2.1.8, the motor MTPA function will be activated.

C3.2.2.2 Permanent magnet synchronous motor

C3.2.2.2.5 Kp MTPA gain

Range: 0.000 ... 1.000

Default: 0.010

Properties:

Description:

It sets the proportional gain value of the MTPA regulator.



NOTE!

The gain values of this controller are automatically adjusted by the inverter.

C3.2.2.2 Permanent magnet synchronous motor

C3.2.2.2.6 Ki MTPA gain

Range: 0.000 ... 1.000

Default: 0.002

Properties:

Description:

It sets the integral gain value of the MTPA regulator.



NOTE!

The gain values of this controller are automatically adjusted by the inverter.

C3.2.2.2 Permanent magnet synchronous motor

C3.2.2.2.8 MTPA minimum voltage

Range: 0 ... 100 %

Default: 100 %

Properties:

Description:

It defines the minimum voltage value at a given speed that will be applied to the motor when the MTPA function is active.

The minimum voltage value in Volts (V) is the percentage of the ratio $(C2.2.8 * S2.1.1)/1000$.

E.g.:

C2.2.8 (Motor model - Ke constant) = 120 V/kRPM.

S2.1.1 (Motor speed - Reference) = 900 RPM.

C3.2.2.2.8 (Permanent magnet synchronous motor - MTPA minimum voltage) = 50.0 %.

Minimum MTPA Voltage (V) = $(C3.2.2.2.8 / 100) * (C2.2.8 * S2.1.1) / 1000 = 54 \text{ V}$.

C3.2.2.2 Permanent magnet synchronous motor**C3.2.2.2.10 Manual reactive power increase reference**

Range:	-200.0 ... 200.0 %	Default: 0.0 %
Properties:		

Description:

Defines the manual reactive current reference for the control system.

The manual reference is added to the MTPA current reference, allowing the stator current to be increased at the same speed without changing the load torque.

Positive values lead the current (capacitive reactive), while negative values lag the current (inductive reactive).

C3.2.2.2 Permanent magnet synchronous motor**C3.2.2.2.11 Speed reference for synchronization**

Range:	0.0 ... 100.0 %	Default: 2.0 %
Properties:		

Description:

Defines the point at which the ramp is frozen for the period set in C3.2.2.2.12, helping to reach synchronous speed in open loop.

C3.2.2.2 Permanent magnet synchronous motor**C3.2.2.2.12 Period for synchronization**

Range:	0.00 ... 30.00 s	Default: 0.00 s
Properties:		

Description:

Defines the period during which the ramp will remain frozen at the synchronization speed reference (C3.2.2.2.13), helping to reach synchronous speed in open loop.

C3.2.2.2 Permanent magnet synchronous motor**C3.2.2.2.13 Speed reference for the waiting period**

Range:	0.0 ... 200.0 %	Default: 0.0 %
Properties:		

Description:

Defines the speed percentage at which the motor will remain frozen for the period set in C3.2.2.2.14.

C3.2.2.2 Permanent magnet synchronous motor**C3.2.2.2.14 Waiting period at speed**

Range:	0.00 ... 20.00 s	Default: 0.00 s
Properties:		

Description:

Defines the period during which the motor speed will remain frozen at the value set in C3.2.2.2.13.

C3.2.2.2 Permanent magnet synchronous motor**C3.2.2.2.15 Coefficient A for angular lag compensation**

Range:	-10000 ... 10000	Default: -1210
Properties:		

Description:

Sets the value of the quadratic delay coefficient (A) of the speed-based voltage angle.

C CONFIGURATIONS

C3.2.2.2 Permanent magnet synchronous motor

C3.2.2.2.16 Coefficient B for angular lag compensation

Range: -1000 ... 1000 μ S

Default: 280 μ S

Properties:

Description:

Sets the linear delay coefficient (B) value of the voltage angle based on speed.

C3.2.2.2 Permanent magnet synchronous motor

C3.2.2.2.17 Low-pass filter constant Tc

Range: 0 ... 1000 ms

Default: 0 ms

Properties:

Description:

Defines the value of the time constant of the low-pass filter of the motor currents Id/Iq.

C3.2.2.3 Synchronous motor with external excitation

Allows you to adjust the parameters related to the field regulation of the synchronous motor with external excitation, both with brushes and with a brushless AC exciter.

C3.2.2.3 Synchronous motor with external excitation

C3.2.2.3.1 Synchronous machine field controller

Range: 0 ... 1

Default: 1

Properties:

Description:

Enables the field controller of the synchronous machine with external excitation.

Indication	Description
0 = Inactive	
1 = Reactive controller	The field reference comes from the stator reactive controller, which seeks to maintain the reactive reference configured by the user While the reactive regulator acts in the field, the stator follows the V/f ratio according to the motor data and the configured curve.

C3.2.2.3 Synchronous motor with external excitation

C3.2.2.3.2 Stator reactive reference

Range: -2.00 ... 2.00

Default: 0.00

Properties:

Description:

Reactive current reference as a function of the motor's nominal current.

A negative reference value should result in a current lagging behind the voltage.

C3.2.2.3 Synchronous motor with external excitation

C3.2.2.3.3 Initial field reference

Range: 0.00 ... 1.00

Default: 0.20

Properties:

Description:

Defines the initial value of the field reference, which is applied before the field regulation step.

When enabling PWM, the field reference varies in a ramp, starting from zero, reaching the value configured in the initial reference parameter after the ramp time.

After the ramp is completed, the field reference value remains at the initial value until the frequency condition for starting regulation is met and the reactive controller starts regulating the field.

C3.2.2.3 Synchronous motor with external excitation

C3.2.2.3.4 Field entry ramp time

Range: 0.00 ... 200.00 s **Default:** 3.00 s

Properties:

Description:

Defines the ramp time applied to the field reference input.

During the ramp time the field reference varies from zero to the initial field reference.

The field input occurs when the PWM is ENABLED or when the RUN command occurs, according to the motor magnetization mode configuration.

C3.2.2.3 Synchronous motor with external excitation

C3.2.2.3.5 Minimum value of the field reference

C3.2.2.3.6 Maximum field reference value

Range: 0.00 ... 1.00 **Default:** 0.01 (C3.2.2.3.5)
1.00 (C3.2.2.3.6)

Properties:

Description:

Defines the range of the field reference, limiting the action of the reactive controller.

If the initial field reference exceeds the defined range, this will be used as the initial reference.

C3.2.2.3 Synchronous motor with external excitation

C3.2.2.3.7 Field regulation starting point

Range: 0.00 ... 2.00 **Default:** 0.05

Properties:

Description:

Defines the starting frequency of the closed-loop control of the field reference in relation to the nominal motor frequency.

Below the frequency defined by this parameter, the field reference is defined by the ramp. Even if the frequency condition is satisfied, regulation only starts after the input ramp is completed.

When the motor frequency drops below 90 % of the value set to start regulation, the ramp assumes the field reference, imposing the initial value again. This method seeks to ensure the proper behavior of the currents in stopping and reversing and motor speed.

C3.2.2.3 Synchronous motor with external excitation

C3.2.2.3.8 Field regulator gain

Range: 0.000 ... 9.999 **Default:** 0.070

Properties:

Description:

Sets the gain of the field reference regulator.

C3.2.2.3 Synchronous motor with external excitation

C3.2.2.3.9 Field regulator full time

Range: 0.000 ... 50.000 s **Default:** 0.030 s

Properties:

C CONFIGURATIONS

Description:

Sets the integral time of the field regulator.

C3.2.3 Current stabilization

The Current Stabilization function is used to dampen electromechanical oscillations present in the motor when it is operating with a low load level and at low frequencies. These oscillations cause instability in the system that, in some occasions, can cause the overcurrent fault.

C3.2.3 Current stabilization		
C3.2.3.4 Stabilization saturation		
Range:	0.0 ... 5.0 %	Default: 0.5 %
Properties:		

Description:

It sets the saturation level of the motor current stabilization regulator output.

C3.2.3 Current stabilization		
C3.2.3.5 High-pass filter gain		
C3.2.3.6 High-pass filter Tc		
Range:	0.000 ... 9.999 ms	Default: 0.050 ms (C3.2.3.5) 318 ms (C3.2.3.6)
Properties:		

Description:

Defines the values of the gain and time constant of the current stabilization loop through the high-pass filter.

C3.2.3 Current stabilization		
C3.2.3.7 Maximum operating frequency		
Range:	0 ... 300 %	Default: 0 %
Properties:		

Description:

It disables the Current Stabilization function after the speed exceeds the value set in this parameter. When the value is set to zero, this functionality is disabled. This parameter is only available for induction motors.

C3.2.3 Current stabilization		
C3.2.3.8 Current stabilization input frequency		
Range:	0 ... 300 %	Default: 5 %
Properties:		

Description:

Keeps current stabilization disabled until the motor frequency exceeds the value set in this parameter.

When this value is set to zero, stabilization is always enabled.

C3.2.4 Pre-magnetization

The Pre-Magnetization function improves the dynamic behavior of the motor start when subjected to a very high load.

Figure 9.8 shows the operation flow of the Pre-Magnetization function together with the motor drive. In this activation, before the motor accelerates, the stator is magnetized so that it has energy for starting with load. Magnetization is performed by injecting a direct current (C3.2.4.2) for a programmed time (C3.2.4.3). The voltage boost during motor acceleration can be controlled by setting C3.2.4.4.




Figure 9.8: Illustrative diagram of the operation of the pre-magnetization function

C3.2.4 Pre-magnetization

C3.2.4.1 Enable function

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

It enables the motor pre-magnetization function.

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function

C3.2.4 Pre-magnetization

C3.2.4.2 Current

Range:	0 ... 350 %	Default: 100 %
Properties:		

Description:

It allows setting the current level applied during the motor pre-magnetization process. The full scale is the rated motor current set in C2.1.5.



NOTE! If the value set in C3.2.4.2 is greater than the inverter current, it will be automatically limited to the inverter maximum current capacity.

C CONFIGURATIONS

C3.2.4 Pre-magnetization

C3.2.4.3 Time

Range: 0 ... 5000 ms

Default: 2000 ms

Properties:

Description:

It allows setting the motor pre-magnetization time, which is the time that the inverter considers to indicate that the motor is general enabled (or magnetized) after receiving the general enable command.

C3.2.4 Pre-magnetization

C3.2.4.4 Gain

Range: 1.0 ... 7.0

Default: 3.5

Properties:

Description:

It allows setting the voltage boost applied during the motor acceleration. See Figure 9.8 for further details.

C3.3 Vector control

VECTOR CONTROL FOR INDUCTION MOTOR

It is the type of control based on the separation of the motor current in two components:

- Direct current I_d (oriented with the electromagnetic flux vector of the motor);
- Quadrature current I_q (perpendicular to the flux vector of the motor).

The direct current is related to the motor electromagnetic flux, while quadrature current is directly related to the electromagnetic torque produced in the motor shaft. With this strategy you have the so-called decoupling, that is, you can independently control the flux and torque in the motor by controlling the currents I_d and I_q , respectively.

As these currents are represented by vectors that spin at synchronous speed, when viewed from a stationary frame of reference, the frame is transformed to change them for a synchronous frame of reference. In the synchronous frame, these vectors are turned into DC values proportional to the amplitude of the respective vectors. This considerably simplifies the control circuit.

When vector I_d is aligned with the motor flux, we can say that the vector control is oriented. To that end, it is necessary that the motor parameters be correctly set. These parameters must be set according to the motor nameplate data and other information obtained automatically by the Self-Tuning, or through the motor data sheet provided by the manufacturer.

Figures 9.9 and 9.10, on the page 9-23, show the block diagram for the vector control with encoder and sensorless in the speed and torque operating modes, respectively. The speed information, as well as the currents measured by the inverter, will be used to obtain the correct direction of the vectors. In the case of vector control with encoder, the speed is obtained directly from the encoder signal, while in sensorless vector control there is an algorithm that estimates the speed based on the output currents and voltages.

The vector control measures the currents, separates the components into direct and quadrature portions and transforms these variables for the synchronous frame of reference. The motor is controlled by imposing the desired currents and comparing them to the actual values.




Figure 9.9: Block diagram of induction motor vector control in speed mode




Figure 9.10: Block diagram of induction motor vector control in torque mode

SENSORLESS VECTOR CONTROL

The Sensorless Vector Control is recommended for most applications as it allows operation in a 1:100 speed range, 0.5 % speed control accuracy of the rated speed, high starting torque and fast dynamic response.

Another advantage of this kind of control is greater robustness against sudden voltage variations of the power supply and load, preventing unnecessary shutdowns by overcurrent.

The necessary settings for the proper operation of the sensorless control are made automatically. To that end, the motor to be used must be connected to the MVW.

VECTOR CONTROL WITH ENCODER

The Vector Control with Encoder on the motor presents the same advantages as those of the sensorless previously mentioned with the following additional benefits:

- Speed and torque control up to 0 (zero) rpm.
- Precision of 0.01 % in the speed control (if digital references are used, for example, via HMI, Profibus DP, DeviceNet, etc.).

Vector control with encoder requires accessory for interfacing with incremental encoder (E.g. ENC-01). For more installation and connection details, refer to the accessory manual.

C CONFIGURATIONS

In order to perform the Self-tuning in the Running mode, it is necessary that the rotor shaft is free to spin (without application of load on the shaft). During this process, the motor will spin up to half the motor rated speed set in C2.1.8.

During the Self-tuning process in Stop mode, there may be small movements in the rotor during the identification of parameter T_r (rotor time constant). Therefore, if the application is sensitive to these small movements, it is recommended that the Self-tuning process be carried out with the motor disconnected from the system.

C3.3.1 Configuration

It defines some settings of the vector control.

C3.3.1 Configuration

C3.3.1.3 Magnetization mode

Range: 0 ... 1

Default: 1

Properties:

Description:

Defines which command will be used to initiate motor magnetization.

In the Run/Stop option:

For synchronous machines, the process of identifying the initial rotor position will be performed whenever the RUN command is executed with the motor stopped. There will be no voltage or current signal applied to the motor when the motor is stopped or the inverter is in the READY state.

For induction machines, there will be no magnetizing current with the motor stopped. When the RUN command is executed, the motor will be magnetized and then the speed or torque reference ramp will be released.

In the General Enable option:

For synchronous machines, a high-frequency signal will be applied when the motor is stopped. The process The initial rotor position identification test will be performed only once.

For induction machines, a direct current (magnetizing current) will be applied to the motor when it is stopped.



NOTE!

For applications with on-load starts, the General-enabled option is recommended.

Indication	Description
0 = General Enable	Applies magnetizing current after General Enable ON.
1 = Run/Stop	It applies magnetizing current after Run/Stop = Run

C3.3.1 Configuration

C3.3.1.4 Maximum output voltage

Range: 0.0 ... 120.0 %

Default: 100.0 %

Properties:

Description:

Allows setting the value of the maximum output voltage. The value set in this parameter corresponds to a percentage in relation to the motor rated voltage set in C2.1.4.

C3.3.1 Configuration

C3.3.1.5 Field weakening starting point

Range: 0 ... 120 %

Default: 90 %

Properties:

Description:

Expresses the percentage of the modulation index from which the motor field weakening occurs.

C3.3.1 Configuration**C3.3.1.6 field weakening feedback****Range:** 0 ... 1**Default:** 0**Properties:****Description:**

Indication	Description
0 = Voltage reference	The current regulators output itself is fed back to field weakening
1 = Highest modulation index	The field weakening regulator receives the highest modulation rate among the phases, directly from the modulator This value already takes into account the maximum modulation index and the saturations that may occur within the modulator.

C3.3.1 Configuration**C3.3.1.7 Speed filter time constant ($\omega f1$)****Range:** 1 ... 1000 ms**Default:** 12 ms**Properties:****Description:**

It sets the low-pass filter time constant value of the speed signal used in the Speed Regulator.

**NOTE!**

In general, this parameter must not be changed. Increasing its value makes the system response slower.

C3.3.1 Configuration**C3.3.1.8 Speed filter time constant ($\omega f2$)****Range:** 0.5 ... 12.0 ms**Default:** 2.0 ms**Properties:****Description:**

Time constant of the filter used in the speed feedback of the current model.

C3.3.1 Configuration**C3.3.1.9 Minimum flux****Range:** 0 ... 120 %**Default:** 0 %**Properties:** Stopped**Description:**

It sets the value of flow reference for vector control. This value is a reference in percentage of the motor rated flux value.

C3.3.1 Configuration**C3.3.1.10 Rated flux****Range:** 0 ... 120 %**Default:** 100 %**Properties:** Stopped**Description:**

It sets the value of flow reference for vector control. This value is a reference in percentage of the motor rated flux value.

C CONFIGURATIONS

C3.3.1 Configuration

C3.3.1.11 Maximum flux

Range:	0 ... 200 %	Default: 120 %
Properties:	Stopped	

Description:

It sets the value of flow reference for vector control. This value is a reference in percentage of the motor rated flux value.

C3.3.2 Regulators

It allows viewing and changing the parameters related to the vector control flux, current and speed regulators.

C3.3.2.1 Configuration

Before executing the Self-tuning function it is recommended to program an emergency option such a digital input programmed for general enable.

During the execution of the Self-tuning function, no other operations must be performed on the inverter, such as: setting, copying and loading the factory default parameters, downloading parameters via WPS, executing commands, etc.

C3.3.2.1 Configuration

C3.3.2.1.1 Auto-gain

Range:	0 ... 2	Default: 0
Properties:	Stopped	

Description:

Defines the motor parameter identification mode. After selected the identification method, self-tuning starts executing the steps automatically.

Indication	Description
0 = No	Function disabled.
1 = Stopped	Self-tuning with the motor stopped
2 = Running	Self-tuning with the motor running

C3.3.2.2 Speed regulator

Regulator responsible for setting the motor speed dynamics. The speed regulator gains are automatically calculated according to parameter C2.2.5. Changing C2.2.5, parameters C3.3.2.2.1 and C3.3.2.2.2 are modified proportionally; however, these gains can be manually set to optimize the dynamic speed response.

The proportional gain (C3.3.2.2.1) stabilizes sudden changes in speed or reference, while the Integral gain (C3.3.2.2.2) corrects the error between reference and speed and improves torque response at low speeds.

Manual Adjustment Procedure for Speed Regulator Optimization:

1. Select the acceleration (C6.1.1 or C6.1.4) and/or deceleration (C6.1.2 or C6.1.5) time according to the application.
2. Set the speed reference to 75 % of the maximum value.
3. Using the WPS software, set a trend to the "Effective Speed" variable.
4. Lock the speed ramp (Run/Stop = Stop) and wait for the motor to stop.
5. Release the speed ramp (Run/Stop = Run). Observe the motor speed signal with the WPS trend.
6. Check among the options in Figure 9.11 which waveform best represents the read signal.




Figure 9.11: (a), (b) and (c) - Types of speed regulator response

7. Set C3.3.2.2.1 and C3.3.2.2.2 according to the type of response shown in Figure 9.11.

- a. Decrease the proportional gain (C3.3.2.2.1) and/or increase the integral gain (C3.3.2.2.2).
- b. Speed regulator optimized.
- c. Increase the proportional gain (C3.3.2.2.1) and/or decrease the integral gain (C3.3.2.2.2).

In sensorless vector control the maximum typical value of the proportional gain C3.3.2.2.1 must not be greater than 9.0. Otherwise, strange behaviors can be observed in the motor, such as: motor remains still or spins at low speed, despite the output current being different from zero. It is recommended to reduce the setting in C3.3.2.2.1 until the motor behaves correctly.

C3.3.2.2 Speed regulator		
C3.3.2.2.1 Proportional gain (Kp)		
Range:	0.0 ... 50.0	Default: 5.0
Properties:		

Description:

It sets the value of the Speed Regulator proportional gain. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

NOTE!

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.3.2.2.2.

C3.3.2.2 Speed regulator		
C3.3.2.2.2 Integral constant (Ti)		
Range:	0.001 ... 1.000	Default: 0.100
Properties:		

Description:

It sets the value of the Speed Regulator integral gain. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

C3.3.2.3 Field weakening

It allows viewing and changing the parameters related to the output voltage limiter for proper control in the field weakening region.

C CONFIGURATIONS

The Output Voltage Limiter prevents the voltage imposed by the inverter from exceeding a preset value set in C3.3.1.4. This will prevent electrical damage to the motor stator. This region of operation is commonly known as the field weakening region, because, in this region, the motor magnetic field is weakened to ensure that the voltage imposed on the stator be limited to the value C3.3.1.4. This will occur whenever the value set in C3.3.1.4 is equal to or greater than the value of the motor rated voltage (C2.1.4).

C3.3.2.3 Field weakening

C3.3.2.3.1 Proportional gain (Kp)

Range: 0.00 ... 5.00

Default: 0.02

Properties:

Description:

It sets the proportional gain value of the Voltage Limiter regulator. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.



NOTE!

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.3.2.3.2.

C3.3.2.3 Field weakening

C3.3.2.3.2 Integral constant (Ti)

Range: 0.00 ... 100.00

Default: 0.62

Properties:

Description:

It sets the integral gain value of the Voltage Limiter regulator. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

C3.3.2.4 Flux regulator

It allows viewing and changing the parameters related to the vector control flux regulator.

C3.3.2.4 Flux regulator

C3.3.2.4.1 Proportional gain

Range: 0.0 ... 999.9

Default: 50.0

Properties:

Description:

It sets the value of the Flux Regulator proportional gain. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.



NOTE!

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.3.2.4.2.

C3.3.2.4 Flux regulator

C3.3.2.4.2 Integral time

Range: 0.001 ... 50.000 s

Default: 0.900 s

Properties:

Description:

It sets the value of the Flux Regulator integral gain. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

C3.3.2.5 Current regulator

It allows viewing and changing the parameters related to the vector control current regulator.

C3.3.2.5 Current regulator		
C3.3.2.5.1 Proportional gain (Kp)		
Range:	0.000 ... 9.999	Default: 0.080
Properties:		

Description:

C3.3.2.5 Current regulator		
C3.3.2.5.2 Integral constant (Ti)		
Range:	0.001 ... 65.535 s	Default: 0.123 s
Properties:		

Description:

C3.3.2.7 Speed estimator

C3.3.2.7 Speed estimator		
C3.3.2.7.1 Speed estimator proportional gain (Kp)		
C3.3.2.7.2 Speed estimator integral time constant (Ti)		
Range:	0.000 ... 9.999	Default: 0.165 (C3.3.2.7.1) 0.942 (C3.3.2.7.2)
Properties:		

Description:

Induction motor speed observer PI regulator parameters.

C3.3.4 Speed mode

Settings for the speed mode in vector control.

C3.3.4.1 Torque limiter

Allows viewing and changing the parameters related to the motor torque limiter.

Parameters C3.3.4.1.2 (Torque Q1), C3.3.4.1.3 (Torque Q2), C3.3.4.1.4 (Torque Q3), and C3.3.4.1.5 (Torque Q4) limit torque independently in each motor operating quadrant (Fig. 9.12).




Figure 9.12: Motor torque limiter convention in the four operating quadrants

C CONFIGURATIONS

Motor torque can also be limited using parameter C3.3.4.1.1 (Global Torque). This parameter has priority over the others and acts simultaneously in all four quadrants. Figure 9.13 shows the motor torque being monitored to prevent it from exceeding the values set in C3.3.4.1.2 to C3.3.4.1.5. If torque limiting is reached, the motor speed will be reduced.




Figure 9.13: Torque limiting behavior according to the configured values

C3.3.4.1 Torque limiter		
C3.3.4.1.1 Global torque		
Range:	0.0 ... 400.0 %	Default: 125.0 %
Properties:		

Description:
It sets the maximum torque in the four motor operating quadrants. If it is necessary to control the torque in the four motor operating quadrants, parameters C3.3.4.1.2 to C3.3.4.1.5 must be used.

C3.3.4.1 Torque limiter		
C3.3.4.1.2 Torque Q1		
C3.3.4.1.3 Torque Q2		
C3.3.4.1.4 Torque Q3		
C3.3.4.1.5 Torque Q4		
Range:	0.0 ... 400.0 %	Default: 400.0 %
Properties:		

Description:
It sets the maximum torque of the motor running in the forward direction and in the 'motoring' operating condition.

C3.3.4.1 Torque limiter		
C3.3.4.1.6 Global torque AI config.		
Range:	0 ... 30	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the analog input that will be used to limit the motor maximum torque. Table 9.19 on page 9-31 shows the options.

Table 9.19: Values assigned to the Analog Inputs of X and A...G Slots

Analog Inputs options for X and A...G Slots								
Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
AI1	X-1 (1)	A-1 (3)	B-1 (7)	C-1 (11)	D-1 (15)	E-1 (19)	F-1 (23)	G-1 (27)
AI2	X-2 (2)	A-2 (4)	B-2 (8)	C-2 (12)	D-2 (16)	E-2 (20)	F-2 (24)	G-2 (28)
AI3	—	A-3 (5)	B-3 (9)	C-3 (13)	D-3 (17)	E-3 (21)	F-3 (25)	G-3 (29)

**NOTE!**

Example: To choose Analog Input AI3 from Slot D, select D-3 (17) option.

C3.4 Current limiter

Allows viewing and changing the parameters related to the motor current limiter.

The current limiting function prevents faults by avoiding the inverter overcurrent fault during starts or stops with very short ramps. This function also helps protect the motor in case of overload while operating at constant speed.

1 – Current limiting characteristics during acceleration or deceleration:

Current limiting acts whenever the motor current exceeds the value set in C3.4.1. During acceleration or deceleration, the function adjusts the speed rate of change to prevent the motor current from exceeding the value in C3.4.1. Figure 9.14 illustrates the function operation during motor acceleration and deceleration.




Figure 9.14: Current limiting during acceleration and deceleration

2 – Current limiting characteristics at constant speed:

In steady state, with the motor operating at constant speed, the current limiting function acts on the speed reference to prevent the motor current from exceeding the value set in C3.4.1. Therefore, when the system is overloaded and the motor current exceeds the value in C3.4.1, the motor starts a controlled deceleration to reduce current. When the overload condition ends, the motor accelerates again to restore the reference speed. Figure 9.15 shows the function operation when the motor is running at constant speed.




Figure 9.15: Current limiting with the motor running at constant speed

C3.4 Current limiter		
C3.4.1 Actuation level		
Range:	0 ... 300 %	Default: 125 %
Properties:		

Description:
This parameter defines the maximum value of current in the motor during system operation. The full-scale is the nominal current of the motor defined in C2.1.5.



NOTE!
If the value set in C3.4.1 is greater than the inverter current, it will be automatically limited to the maximum current capacity of the inverter.

C3.4 Current limiter		
C3.4.2 Overcurrent fault level		
Range:	100 ... 250 %	Default: 180 %
Properties:		

Description:
It sets the current level to generate the software overcurrent fault - F0073. Thus, when the motor current is greater than the value set in (C3.4.2), an overcurrent fault will be enabled. The full scale is the rated motor current set in C2.1.5.

C3.5 DC link

It allows viewing and changing the parameters related to the DC link limiting function.

During very short stops, in systems with high inertia, it is natural that the load regenerates a great amount of energy to the DC link, causing an increase in the DC voltage level. The DC link limiting function prevents the bus voltage from exceeding the value set in C3.5.1.2 and causing overvoltage on the inverter.

1 - Characteristics of the DC link limiting function when the motor is decelerating:

The DC link limiting function changes the motor deceleration rate to control the increase in the bus voltage during the motor deceleration. Figure 9.16 illustrates the behavior of the function during the motor deceleration.




Figure 9.16: DC link limitation during deceleration process

2 - Characteristics of the DC link limiting function when the motor is operating at constant speed:

In certain applications, it is common for the load to operate in regenerative mode and the motor to be operating at constant speed. In this case, the DC link limiting function protects the inverter against bus overvoltage. Figure 9.17 illustrates the behavior of the function when the motor is operating at constant speed and the load in regenerative mode. In this situation, the DC link limiting function decelerates the motor in a controlled manner to prevent the bus voltage from exceeding the value set in C3.5.1.2. After the DC link voltage level returns to its rated value, the function accelerates the motor so that it returns to the speed set in S2.1.1.




Figure 9.17: DC link limitation when the motor is operating at constant speed

C3.5.1 Voltage limit

It allows setting the DC link voltage limiting function for all control types.

C CONFIGURATIONS

C3.5.1 Voltage limit

C3.5.1.1 Enable function

Range: 0 ... 1

Default: 1

Properties:

Description:

It enables the DC Link Limiting function.

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function

C3.5.1 Voltage limit

C3.5.1.2 DC link voltage limit - Level

Range: 105.0 ... 130.0 %

Default: 120.0 %

Properties:

Description:

Defines the actuation level of the DC link limitation function.

Adjustment of the value of C3.5.1.2:

The value of C3.5.1.2 corresponds to a percentage of the Nominal DC Bus Voltage.

The nominal DC link voltage of the cells is given by $690V \times 1.35 = 931V$.

If the inverter continues to block due to overvoltage on the DC link during deceleration, gradually reduce the value of C3.5.1.2 or increase the deceleration ramp time C6.1.2 or C6.1.5.

If the power supply is permanently at such a voltage level that it results in a DC link voltage value greater than the setting of C3.5.1.2, it will not be possible to decelerate the motor. In this case, reduce the mains voltage or increase the value of C3.5.1.2.

C3.5.3 Vector control

It allows viewing and changing parameters related to vector control.

C3.5.3 Vector control

C3.5.3.1 Optim. braking func. enable

Range: 0 ... 1

Default: 0

Properties:

Description:

It selects the type of braking used in the vector control for induction machines. Braking with losses (Optimal Braking) increases the stator current in the motor to increase losses during the deceleration period.



NOTE!

The process carried out by this type of braking increases the acoustic noise in the environment.

Indication	Description
0 = No	Disable function
1 = Yes	It enables function

C3.5.3 Vector control**C3.5.3.3 DC link limitation - Kp gain****Range:** 0.00 ... 6.39**Default:** 0.80**Properties:****Description:**

It sets the value of the DC link voltage regulator proportional gain.

The gain values of this controller are automatically adjusted by the inverter and do not need to be adjusted for general purpose applications. For applications with very short deceleration ramps, a small adjustment in the gains may be necessary. In this case, it is recommended that you gradually increase their value.

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.5.3.4.

C3.5.3 Vector control**C3.5.3.4 DC link limitation - Ki gain****Range:** 0.000 ... 1.000**Default:** 0.400**Properties:****Description:**

It sets the integral gain value of the DC link voltage regulator.

The gain values of this controller are automatically adjusted by the inverter and do not need to be adjusted for general purpose applications. For applications with very short deceleration ramps, a small adjustment in the gains may be necessary. In this case, it is recommended that you gradually increase their value.

C3.5.3 Vector control**C3.5.3.5 Ramp behavior during voltage limiting****Range:** 0 ... 1**Default:** 0**Properties:****Description:**

Defines the behavior of the ramp freeze function when the inverter is operating in vector control without DC link regulation due to overvoltage.

The option “1 = Hold with ramp readjustment” is recommended for cases where loads have high moments of inertia, which can generate overvoltage events during deceleration.

Indication	Description
0 = Standard hold	When the overvoltage detection level is reached, the ramp is frozen. Depending on the load and the speed regulator settings, the bus voltage may continue to rise until the speed controller reaches the reference.
1 = Hold with ramp readjustment	When the overvoltage detection level is reached, the ramp is reset to the speed regulator feedback value and frozen. This configuration resets the speed regulator error, causing the torque command to cease quickly, decreasing the bus rise rate after entering hold.

C3.5.3 Vector control**C3.5.3.6 Controller initial state****Range:** 0 ... 2**Default:** 0**Properties:****Description:**

Defines the initial state of the DC bus controller when voltage-limiting regulation starts.

Indication	Description
0 = Smooth entry	The DC link controller action starts with the same value as the speed regulator control action, avoiding a sudden transition of the torque regulator.
1 = Zero initial torque	The initial conditions of the DC link voltage controller are adjusted so that the torque reference at the time regulation starts is zero.

C CONFIGURATIONS

Indication	Description
2 = Standard start	The DC link controller starts with zero initial conditions, applying a control action according to the error.

C3.5.3 Vector control

C3.5.3.7 DC link controller filter time constant

Range:	2 ... 100 ms	Default: 25 ms
Properties:		

Description:

Defines the time constant of the voltage feedback filter of the DC bus controller.

C3.5.3 Vector control

C3.5.3.8 Reference for DC link regulation

Range:	90 ... 110 %	Default: 100 %
Properties:		

Description:

Defines the voltage reference for DC bus regulation as a function of the voltage limit value (C3.5.1.2).

$$V_{dc,ref} = C3.5.3.8 \times C3.5.1.2 \quad (1)$$

C3.5.4 Modulation compensation

Allows you to view and change parameters related to modulation compensation.

C3.5.4 Modulation compensation

C3.5.4.1 Output voltage compensation

Range:	0 ... 1	Default: 1
Properties:		

Description:

Output voltage compensation applied to the motor as a function of the DC link voltages.

Indication	Description
0 = Inactive	Function inactive
1 = Active	Compensation executed considering the total voltage of each phase.

C3.5.4 Modulation compensation

C3.5.4.2 DC link filter time constant

Range:	0.0 ... 999.9 ms	Default: 13.3 ms
Properties:		

Description:

Adjusts the time constant of the first order filter applied to the total DC-link voltage signal.

Each phase has an individual DC-link; consequently, there will be three filters - one for each phase.

If the parameter value is null, the DC-link voltage will no longer be filtered, that is, its instant value will be used in the compensation.

Not used if parameter C3.5.4.1 = Inative.

C3.8 Flying Start

The Flying Star function allows driving a motor that is in free spinning, accelerating it from the speed in which it

is. This function is suitable for applications in which the system inertia is very high, and the time for the motor to stop is very high. In this case, if the motor is started, there may be a high energy regeneration to the DC link. Such energy regeneration may cause overcurrent and thus the actuation of the overcurrent fault at the start. Thus, the Flying Start function must be used to identify the actual rotor speed and, from that, start the motor from the actual rotor speed. Figure 9.18 illustrates the Flying Start function actuation process in a simplified way.




Figure 9.18: Illustrative scheme of the Flying Start function

The Flying Start function performs a scan by applying a speed reference to determine the rotor speed. Figure 9.19 illustrates the method that the Flying Start function uses to determine the rotor speed. The scan starts from the value defined in C4.3.1.1.2 (maximum speed) and ends at zero. The first scan is carried out in the same direction as the motor direction of rotation command. If the rotor speed is not determined, a second scan is performed in the opposite direction of the direction of rotation command. At the end of this process, if the rotor speed is not determined, the function considers that the motor is stopped and ends the determination process.




Figure 9.19: Illustrative scheme of the rotor speed determination by the Flying Start function

C3.8.1 Configuration

It allows configuring the Flying Start function according to the system application type.

C3.8.1 Configuration		
C3.8.1.1 Enable function		
Range:	0 ... 1	Default: 0
Properties:		

Description:
It enables the Flying Start function.

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function

C CONFIGURATIONS

C3.8.1 Configuration

C3.8.1.4 Ramp

Range:	0.2 ... 60.0 s	Default: 10.0 s
Properties:		

Description:

It sets the rotor speed determination time. See Figure 9.19 for more details.

C3.8.1 Configuration

C3.8.1.6 Dead time

Range:	1.0 ... 40.0 s	Default: 10.0 s
Properties:		

Description:

Defines the motor dead time (coast time).

This time represents the period during which the motor rotor remains magnetized after the power supply is removed.

For a Flying Start, the coast time is counted before the motor can be started again after PWM has been disabled.

C3.8.2 Scalar control

Flying Start function settings for scalar control.

C3.8.2 Scalar control

C3.8.2.1 Current

Range:	0.0 ... 100.0 %	Default: 70.0 %
Properties:		

Description:

Inverter current limitation during execution of the flying start function.

The current is expressed as a percentage of the motor's nominal current, defined in C2.1.5.

If the motor's rated current is greater than the inverter's rated current, the inverter's rated current will be used as a basis, seeking to avoid the occurrence of overcurrent faults.

C3.8.3 Vector control

Flying Start function settings for vector control.

C3.8.3 Vector control

C3.8.3.1 Flux reference

Range:	0.0 ... 100.0 %	Default: 85.0 %
Properties:		

Description:

It defines the reference flux level that the Flying Start function will impose on the motor during the determination process. The flux level is a percentage of the motor rated flux.

C3.9 Ride-Through

Ride-Through without interruption:

The Ride-Through function makes it possible to recover the inverter, without undervoltage lockout, when there is a drop in the power supply for a short time.

Figure 9.20 illustrates the behavior of the Ride-Through function during a period of voltage drop in the power supply. At this moment, the inverter DC link voltage starts to decrease. Thus, the Ride-Through function starts decelerating the motor in a controlled way to regenerate energy to the DC link and keep the inverter active for a short period of time. After the power supply is restored, the motor is accelerated to the value set in C4.3.1.




Figure 9.20: Illustrative diagram of the Ride-Through function operation

Ride-Through with interruption:

In scalar control or after the end of the Ride-Through without interruption without the return of the grid, the inverter will execute the Ride-Through routine with PWM interruption.

When reaching the undervoltage level, the inverter disables the PWM and starts the pre-charge sequence automatically. After finishing the pre-charge, the inverter waits for the return of the grid to restart the motor automatically.

The time programmed in C3.9.1.3 is the maximum time that the inverter waits for the return of the grid before a fault occurs. The parameter C3.8.1.1 defines whether the restart after the network return will be with flying start.

C3.9.1 Configuration

Settings of the Ride-Through function for all control types.

C3.9.1 Configuration		
C3.9.1.1 Function enable		
Range:	0 ... 1	Default: 0
Properties:		

Description:

It allows enabling the Ride-Through function.

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function

C CONFIGURATIONS

C3.9.1 Configuration		
C3.9.1.3 Maximum Ride-Through time		
Range:	0.5 ... 100.0 s	Default: 20.0 s
Properties:		

Description:
Defines the maximum time the inverter can remain in a *ride-through* condition before fault F0309 occurs.




Figure 9.21: Mains return time-out

The time count starts when the *ride-through* entry condition occurs (see C3.9.1.1 and C7.6.1).
If the maximum time is reached during pre-charge while the inverter performs interrupted *ride-through*, the time-out will be extended until after the mains return check at the end of pre-charge.

C3.9.3 Vector control

Settings of the Ride-Through function for vector control.

C3.9.3 Vector control		
C3.9.3.1 DC link voltage - Ride-Through		
Range:	76.0 ... 95.0 %	Default: 82.5 %
Properties:		

Description:
It sets the voltage regulation level on the DC link for the Ride-Through function, which allows the inverter to keep running.

The value of C3.9.3.1 corresponds to a percentage of the DC Link Rated Voltage.

NOTE!
This parameter works together with parameters C3.9.3.2 and C3.9.3.3 for the Ride-Through function in vector control.

NOTE!
The DC link undervoltage fault occurs at 70 % of the DC Link Rated Voltage.

C3.9.3 Vector control		
C3.9.3.2 Ride-Through-Gain Kp		
Range:	0.00 ... 2.00	Default: 0.10
Properties:		

Description:
I sets the proportional gain value of the DC link voltage regulator of the Ride-Through function.

The gain values of this controller are automatically adjusted by the inverter and do not need to be adjusted for general purpose applications. For applications with very short deceleration ramps, a small adjustment in the gains may be necessary. In this case, it is recommended that you gradually increase their value.

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.9.3.3.

C3.9.3 Vector control		
C3.9.3.3 Ride-Through-Gain Ki		
Range:	0.000 ... 1.000	Default: 0.050
Properties:		

Description:
This parameter sets the integral gain of the DC link voltage regulator of the Ride-Through function.

The gain values of this controller are automatically adjusted by the inverter and do not need to be adjusted for general purpose applications. For applications with very short acceleration or deceleration ramps, a small adjustment in the gains may be necessary. In this case, it is recommended that you gradually increase their value.

C3.11 Synchronous transfer

The synchronous transfer function allows the motor to be accelerated by the inverter up to the rated operating frequency and then transferred to the supply mains.

This eliminates the effects of inrush current associated with direct-on-line starting.




Figure 9.22: Synchronous transfer diagram




Figure 9.23: Synchronous transfer function operating diagram

C CONFIGURATIONS

C3.11 Synchronous transfer

C3.11.1 Enable function

Range: 0 ... 2

Default: 0

Properties:

Description:

Allows you to enable the synchronous transfer function.

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function
2 = Enable with regulation	Enables function with speed regulation.

C3.11 Synchronous transfer

C3.11.2 Synchronism time

Range: 0.0 ... 20.0 s

Default: 1.0 s

Properties:

Description:

Defines the minimum time during which the phase error between the mains voltage and the inverter output voltage must remain below the programmed value to indicate "Sync OK".

C3.11 Synchronous transfer

C3.11.3 Synchronism timeout

Range: 20 ... 240 s

Default: 60 s

Properties:

Description:

Grid synchronization timeout.

C3.11 Synchronous transfer

C3.11.4 Delay

Range: 1 ... 3000 ms

Default: 170 ms

Properties:

Description:

Delay to disable the inverter after the transfer command to the grid, preventing the motor from remaining without voltage for a period of time.

C3.11 Synchronous transfer

C3.11.5 Maximum phase error

Range: 0.0 ... 60.0 °

Default: 5.0 °

Properties:

Description:

Defines the phase error between the mains voltage and the inverter output voltage, used together with the synchronization time to indicate "Sync OK".

C3.11 Synchronous transfer

C3.11.6 Speed limit

Range: 0 ... 400

Default: 18

Properties:

Description:

Defines the maximum speed for synchronous transfer search, based on the motor rated frequency.

C3.11 Synchronous transfer**C3.11.7 Kp****Range:** 1 ... 500**Default:** 200**Properties:****Description:**

Proportional gain of the output voltage synchronization regulator with the mains voltage.

C3.11 Synchronous transfer**C3.11.8 Ti****Range:** 0.01 ... 20.00**Default:** 0.20**Properties:****Description:**

Integral time of the output voltage synchronization regulator with the mains voltage.

C3.11 Synchronous transfer**C3.11.9 Phase adjustment****Range:** -180.0 ... 180.0 °**Default:** 0.0 °**Properties:****Description:**

It compensates for the phase error between the voltage that the inverter uses as a reference for synchronization and the actual voltage at the point where the transfer will occur.

C3.11 Synchronous transfer**C3.11.10 Minimum angle error to start the search****Range:** 0 ... 360 °**Default:** 10 °**Properties:****Description:****C3.11 Synchronous transfer****C3.11.11 Status****Range:** 0 ... 4 Bit**Default:** 0**Properties:****Description:**

Bit	Value/Description
Bit 0 Function enabled	0 = No: Synchronous transfer disabled. 1 = Yes: Synchronous transfer enabled.
Bit 1 Synchronization command	0 = Not used: Not used 1 = Not used: Not used
Bit 2 ... 4 Synchronization status	0 = Inactive: Function disabled or missing synchronization command 1 = Checking synchronization: Waiting for minimum conditions for synchronization, minimum speed and in the same direction between input and output 2 = Pre-speed regulation: Adjusting the output frequency to reduce error relative to the input 3 = Pre-angular position regulation: Perturbing the output frequency to reduce the absolute error of the angle between output and input 4 = Angular position regulation: Perturbing the output frequency to reduce the absolute error of the angle between output and input 5 = Synchronized: Output angular position equal to input 6 = Timeout: Unable to adjust angle within maximum configured time

C CONFIGURATIONS

C3.12 Bypass

Allows removing and/or isolating damaged cells while keeping the inverter operating at reduced power.

Depending on the fault type, the low-voltage cells must be removed from the motor supply circuit.



ATTENTION!

Only cells with the bypass system installed can operate in bypass mode. Contact WEG for further details.

C3.12 Bypass

C3.12.1 Bypass configuration

Range: 0 ... 6 Bit

Default: 0

Properties:

Description:

Configures the action to be taken by the inverter when a cell must be removed from operation. Sets the action to be taken by the inverter when it is necessary to take one of the cells out of operation.

Bit	Value/Description
Bit 0 ... 1 Automatic Bypass	The Bypass function automatically reorganizes the set, removing the damaged cells and returning the system to operation. 0 = Inactive: In any situation of cell failure, the entire system is blocked 1 = Active with Flying Start: The restart method used is Flying Start, the time for closing the bypass contactor is half the dead time of Flying Start 2 = Active with fast re-entry : Monitors the output terminals to determine when to close the cell bypass contactor and resume operation in sync with the motor. Monitorea los terminales de salida para determinar cuándo cerrar el contactor de bypass de la celda y reanudar la operación en sincronía con el motor.
Bit 2 Balancing method	Defines the line-to-line voltage balancing method when the inverter operates with an uneven number of cells among phases. 0 = Amplitude readjustment: Keeps the phase voltages balanced, with the same amplitude and a 120° phase shift, limiting the amplitude based on the phase with the lowest number of cells. 1 = Angles readjustment: Keeps line voltages balanced by readjusting the phase angles to a value other than 120°
Bit 3 ... 6 Bypassed cells limit	Defines the maximum number of cells per phase that can be placed in automatic bypass. 0 = 0 cell 1 = 1 cell 2 = 2 cells 3 = 3 cells 4 = 4 cells 5 = 5 cells 6 = 6 cells 7 = 7 cells 8 = 8 cells 9 = 9 cells 10 = 10 cells 11 = 11 cells 12 = 12 cells

C3.12 Bypass

C3.12.3 Bypass command for cells U1...U6

C3.12.5 Bypass command for cells V1...V6

C3.12.7 Bypass command for cells W1...W6

Range: 0 ... 11 Bit

Default: 0

Properties:

Description:

Defines the power cell bypass system command.

The command can be assigned to the inverter control system or set manually.

This parameter must also be used to reset the command of a cell that has automatically entered bypass, allowing it to return to operation.

The state of a cell can be checked through the parameters S1.8.4 to S1.8.12.



ATTENTION!

The mechanical bypass option must only be configured after the user checks whether the cell in question is mounted in the set and whether it has the bypass system.

Bit	Value/Description
Bit 0 ... 1 Cell U1	0 = Defined by control: The cell bypass system is managed by the inverter control 1 = Mechanical bypass: Cell replaced by a mechanical bypass cell (<i>dummy</i>) 2 = Manual activation: Keeps the cell bypass system permanently commanded while the cell is energized and communicating with the control 3 = Automatic bypass reset: Resets the bypass system status and command of a cell that has entered automatic bypass
Bit 2 ... 3 Cell U2	0 = Defined by control: The cell bypass system is managed by the inverter control 1 = Mechanical bypass: Cell replaced by a mechanical bypass cell (<i>dummy</i>) 2 = Manual activation: Keeps the cell bypass system permanently commanded while the cell is energized and communicating with the control 3 = Automatic bypass reset: Resets the bypass system status and command of a cell that has entered automatic bypass
Bit 4 ... 5 Cell U3	0 = Defined by control: The cell bypass system is managed by the inverter control 1 = Mechanical bypass: Cell replaced by a mechanical bypass cell (<i>dummy</i>) 2 = Manual activation: Keeps the cell bypass system permanently commanded while the cell is energized and communicating with the control 3 = Automatic bypass reset: Resets the bypass system status and command of a cell that has entered automatic bypass
Bit 6 ... 7 Cell U4	0 = Defined by control: The cell bypass system is managed by the inverter control 1 = Mechanical bypass: Cell replaced by a mechanical bypass cell (<i>dummy</i>) 2 = Manual activation: Keeps the cell bypass system permanently commanded while the cell is energized and communicating with the control 3 = Automatic bypass reset: Resets the bypass system status and command of a cell that has entered automatic bypass
Bit 8 ... 9 Cell U5	0 = Defined by control: The cell bypass system is managed by the inverter control 1 = Mechanical bypass: Cell replaced by a mechanical bypass cell (<i>dummy</i>) 2 = Manual activation: Keeps the cell bypass system permanently commanded while the cell is energized and communicating with the control 3 = Automatic bypass reset: Resets the bypass system status and command of a cell that has entered automatic bypass
Bit 10 ... 11 Cell U6	0 = Defined by control: The cell bypass system is managed by the inverter control 1 = Mechanical bypass: Cell replaced by a mechanical bypass cell (<i>dummy</i>) 2 = Manual activation: Keeps the cell bypass system permanently commanded while the cell is energized and communicating with the control 3 = Automatic bypass reset: Resets the bypass system status and command of a cell that has entered automatic bypass

C3.12 Bypass

C3.12.4 Bypass command for cells U7...U12

C3.12.6 Bypass command for cells V7...V12

C3.12.8 Bypass command for cells W7...W12

Range: 0 ... 11 Bit

Default: 0

Properties:

Description:

Defines the power cell bypass system command.

The command can be assigned to the inverter control system or set manually.

This parameter must also be used to reset the command of a cell that has automatically entered bypass, allowing it to return to operation.

The state of a cell can be checked through the parameters S1.8.4 to S1.8.12.



ATTENTION!

The mechanical bypass option must only be configured after the user checks whether the cell in question is mounted in the set and whether it has the bypass system.

C CONFIGURATIONS

Bit	Value/Description
Bit 0 ... 1 Cell U7	0 = Defined by control: The cell bypass system is managed by the inverter control 1 = Mechanical bypass: Cell replaced by a mechanical bypass cell (<i>dummy</i>) 2 = Manual activation: Keeps the cell bypass system permanently commanded while the cell is energized and communicating with the control 3 = Automatic bypass reset: Resets the bypass system status and command of a cell that has entered automatic bypass
Bit 2 ... 3 Cell U8	0 = Defined by control: The cell bypass system is managed by the inverter control 1 = Mechanical bypass: Cell replaced by a mechanical bypass cell (<i>dummy</i>) 2 = Manual activation: Keeps the cell bypass system permanently commanded while the cell is energized and communicating with the control 3 = Automatic bypass reset: Resets the bypass system status and command of a cell that has entered automatic bypass
Bit 4 ... 5 Cell U9	0 = Defined by control: The cell bypass system is managed by the inverter control 1 = Mechanical bypass: Cell replaced by a mechanical bypass cell (<i>dummy</i>) 2 = Manual activation: Keeps the cell bypass system permanently commanded while the cell is energized and communicating with the control 3 = Automatic bypass reset: Resets the bypass system status and command of a cell that has entered automatic bypass
Bit 6 ... 7 Cell U10	0 = Defined by control: The cell bypass system is managed by the inverter control 1 = Mechanical bypass: Cell replaced by a mechanical bypass cell (<i>dummy</i>) 2 = Manual activation: Keeps the cell bypass system permanently commanded while the cell is energized and communicating with the control 3 = Automatic bypass reset: Resets the bypass system status and command of a cell that has entered automatic bypass
Bit 8 ... 9 Cell U11	0 = Defined by control: The cell bypass system is managed by the inverter control 1 = Mechanical bypass: Cell replaced by a mechanical bypass cell (<i>dummy</i>) 2 = Manual activation: Keeps the cell bypass system permanently commanded while the cell is energized and communicating with the control 3 = Automatic bypass reset: Resets the bypass system status and command of a cell that has entered automatic bypass
Bit 10 ... 11 Cell U12	0 = Defined by control: The cell bypass system is managed by the inverter control 1 = Mechanical bypass: Cell replaced by a mechanical bypass cell (<i>dummy</i>) 2 = Manual activation: Keeps the cell bypass system permanently commanded while the cell is energized and communicating with the control 3 = Automatic bypass reset: Resets the bypass system status and command of a cell that has entered automatic bypass

C3.14 Zero speed disable

The zero-speed condition determines whether the inverter is at zero speed based on the RUN command, the speed ramp status, the speed reference, and the measured speed, according to the function settings.

C3.14 Zero speed disable

C3.14.1 Configuration

Range:	0 ... 2	Default: 1
Properties:		

Description:

Allows you to configure the zero speed condition to enable the inverter PWM.

Indication	Description
0 = Inactive	PWM is enabled according to the user's PWM enable commands..
1 = Reference and speed detection	The condition to enable PWM depends on the user's ENABLE command and the zero speed condition based on the RUN command, the reference and the measured speed
2 = Detection by reference	The condition to enable PWM depends on the user's ENABLE command and the zero speed condition based on the RUN command and the speed reference

C3.14 Zero speed disable

C3.14.2 Level for zero speed

Range:	0.0 ... 100.0 %	Default: 1.0 %
Properties:		

Description:

Determines the reference and measured speed level for detecting the zero-speed condition.

The value is expressed as a percentage of the motor synchronous speed.

C3.14 Zero speed disable**C3.14.3 Time to block**

Range: 0.00 ... 600.00 s

Default: 0.00 s

Properties:

Description:

Determines how long the zero-speed condition must remain active for PWM to be disabled.

If the condition is interrupted, the timer is restarted when the configured conditions are met again.

C4 COMMANDS AND REFERENCES

It allows configuring the source of the frequency inverter commands and references in Local or Remote control mode.

The MVW has two control modes:

- **Local Mode:** When the inverter is operating in local control mode, all commands and reference are made via HMI (see S1.6.2 and C4.3.1.3.1). The HMI LOC/REM key allows switching between Local and Remote 1 / Remote 2 control modes. It can be set in C4.1.3.
- **Remote 1 / Remote 2 Mode:** In Remote 1 or Remote 2 mode, you can configure the inverter reference and command sources from the following options: communication networks, HMI, digital input and/or analog input.

C4.1 LOC/REM mode config.

It allows configuring what will define the local and remote operating mode. If set via digital input, you can choose the specific digital input for this function.

Options that do not depend on operating modes will be explained later.

C4.1 LOC/REM mode config.**C4.1.1 Command mode**

Range: 0 ... 9

Default: 9

Properties: Stopped

Description:

It defines a fixed command mode (Local, Remote 1 or Remote 2) or the source that can change between Remote 1 and Remote 2 modes. Local mode can be only accessed through this parameter when it is set to Always Local. All other sources can only switch between Remote 1 and Remote 2 modes.

Indication	Description
0 = Always Local	Fixed in Local command mode
1 = Remote 1	Fixed in Remote 1 command mode
2 = Remote 2	Fixed in Remote 2 command mode
3 = Serial	Change via R1/R2 Mode command of the RS-485 Serial Control Word (S5.2.2)
4 = Anybus	Change via R1/R2 Mode command of the Anybus-CC Control Word
5 = CAN/CO/DN	Change via R1/R2 Mode command of the CAN/CANop/DNet Control Word (S5.7.2)
6 = SoftPLC	Change via SoftPLC command
7 = Not used	Not used
8 = Ethernet	Change via R1/R2 Mode command of the Ethernet Control Word (S5.3.2)

C CONFIGURATIONS

Indication	Description
9 = Digital Input (DI)	Change via commandrol of the digital input chosen by the user The digital input can be configured in C4.1.2



NOTE!

Example: By selecting the command source of this parameter as Serial, the Mode R1/R2 bit of the RS-485 Serial command word in S5.2.2 will cause the inverter to transition between Remote 1 and Remote 2.

C4.1 LOC/REM mode config.

C4.1.2 DI remote 1/Remote 2

Range:	0 ... 62	Default: 2
Properties:	Stopped	

Description:

Defines which digital input will transition between Remote 1 or Remote 2 mode or vice versa.

Table 9.30: Values assigned to the Digital Inputs of X and A...G Slots for Remote 1 / Remote 2 mode setting

Digital Inputs options for X and A...G Slots

Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
DI1	X-1 (1)	A-1 (7)	B-1 (15)	C-1 (23)	D-1 (31)	E-1 (39)	F-1 (47)	G-1 (55)
DI2	X-2 (2)	A-2 (8)	B-2 (16)	C-2 (24)	D-2 (32)	E-2 (40)	F-2 (48)	G-2 (56)
DI3	X-3 (3)	A-3 (9)	B-3 (17)	C-3 (25)	D-3 (33)	E-3 (41)	F-3 (49)	G-3 (57)
DI4	X-4 (4)	A-4 (10)	B-4 (18)	C-4 (26)	D-4 (34)	E-4 (42)	F-4 (50)	G-4 (58)
DI5	X-5 (5)	A-5 (11)	B-5 (19)	C-5 (27)	D-5 (35)	E-5 (43)	F-5 (51)	G-5 (59)
DI6	X-6 (6)	A-6 (12)	B-6 (20)	C-6 (28)	D-6 (36)	E-6 (44)	F-6 (52)	G-6 (60)
DI7	—	A-7 (13)	B-7 (21)	C-7 (29)	D-7 (37)	E-7 (45)	F-7 (53)	G-7 (61)
DI8	—	A-8 (14)	B-8 (22)	C-8 (30)	D-8 (38)	E-8 (46)	F-8 (54)	G-8 (62)



NOTE!

Example: To choose digital input 2 of Slot B to switch between Remote 1 / Remote 2 mode, the parameter must be assigned the value B-2 (16).

C4.1 LOC/REM mode config.

C4.1.3 HMI LOC/REM key

Range:	0 ... 1	Default: 1
Properties:	Stopped	

Description:

It sets the function for the HMI LOC/REM key. The  key, when pressed, allows switching between Local (HMI) control mode and the mode defined according to the setting made in C4.1.1 (Remote 1 or Remote 2). When the selected command mode is Local, all commands and references will be performed via the HMI.

Indication	Description
0 = Disable	The  key is disabled
1 = Enable	The  key, toggles between Local and Remote command mode.

C4.2 Commands

It allows setting the command source of the frequency inverter to Remote 1 or Remote 2 mode.

C4.2.1 Remote R1

C4.2.2 Remote R2

It allows setting the source to the command mode.

C4.2.1 Remote R1

C4.2.2 Remote R2

.1 General enable

Range:	0 ... 9	Default: 1 (C4.2.1.1)
		0 (C4.2.2.1)
Properties:	Stopped	

Description:

It sets the source for the general enable command.




Figure 9.24: Operation of the general enable command



ATTENTION!

The general enable command can contain a digital input (C4.2.3.1) that works together with the command source chosen in this menu. Both must be active/inactive simultaneously for the command to take place. For example, when you choose the command source as serial in the Remote 1 situation and any digital input, for the inverter to be enabled, the digital input and the serial input must be active. If either input (digital or serial) is inactive, the inverter will be general disabled. See S1.6.1.

Indication	Description
0 = Always enabled	General Enable command is always active Regardless of the digital input configured in C4.2.3.1
1 = HMI	General Enable command via HMI is always active
2 = Serial	General Enable command via RS-485 Serial Control Word
3 = Anybus	General Enable command via Anybus-CC Control Word
4 = CAN/CO/DN	General Enable command via CAN/CANop/DNet Control Word
5 = SoftPLC	General Enable command via SoftPLC function
6 = Not used	Not used
7 = Ethernet	General Enable command via Ethernet Control Word
8 = Digital Input (DI)	General Enable command via digital input chosen by the user Digital input can be configured in C4.2.3.1
9 = Not used	Not used

C4.2.1 Remote R1		
C4.2.2 Remote R2		
.2 Run/Stop		
Range:	0 ... 10	Default: 0 (C4.2.1.2) 7 (C4.2.2.2)
Properties:	Stopped	

Description:
Sets the source for the start and stop commands, which encompass run/stop and quick stop.




Figure 9.25: Operation of the run/stop command




Figure 9.26: Operation of the quick stop command



ATTENTION!
The quick stop command may contain a digital input (C4.2.3.7) which acts in conjunction with the command source chosen in this menu. Both must be active/inactive simultaneously for the command to take place. For example, when you choose the command source as serial in Remote 1 mode and any digital input, for the inverter to be without quick stop, the digital input and the serial input must be active. If either input (digital or serial) is inactive, the quick stop command is executed. See S1.6.1.

Indication	Description
0 = HMI I/O Keys	Run/Stop command via HMI keys  and  In this case, the stop mode is always by ramp
1 = Serial	Enable Ramp and Quick Stop Command via RS-485 Serial Control Word
2 = Anybus	Enable Ramp and Quick Stop Command via Anybus-CC Control Word
3 = CAN/CO/DN	Enable Ramp and Quick Stop Command via CAN/CANop/DNet Control Word
4 = SoftPLC	Enable Ramp and Quick Stop Command via SoftPLC function

Indication	Description
5 = Not used	Not used
6 = Ethernet	Enable Ramp and Quick Stop Command via Ethernet Control Word
7 = Run/Stop DI	Run/Stop command via digital input chosen by the user The digital input can be set in C4.2.3.2
8 = Forward/Reverse DI	Run/Stop command selected when using the Forward/Reverse function via digital inputs Digital inputs can be set in C4.2.3.5 and C4.2.3.6
9 = 3-Wire Start/Stop DI	Run/Stop command selected when using the 3-Wire Start/Stop function Digital inputs can be set in C4.2.3.3 and C4.2.3.4
10 = Not used	Not used

C4.2.1 Remote R1**C4.2.2 Remote R2****.3 Direction of rotation**

Range:	0 ... 11	Default: 1 (C4.2.1.3) 0 (C4.2.2.3)
Properties:	Stopped	

Description:

It sets the source for the direction of rotation command.




Figure 9.27: Operation of the direction of rotation command

Indication	Description
0 = Forward	Forward direction of rotation only. It is not possible to reverse the direction of rotation
1 = HMI DR Key	Rotation Direction control via HMI key  Forward Direction is selected at power up
2 = Serial	Reverse Command via RS-485 Serial Control Word
3 = Anybus	
4 = CAN/CO/DN	Reverse Command via CAN/CANop/DNet Control Word
5 = SoftPLC	Direction of Rotation Command via SoftPLC function
6 = Not used	Not used
7 = Ethernet	Reverse Command via Ethernet Control Word
8 = Direction of Rotation DI	Direction of Rotation command via user-selected digital input The digital input can be configured at C4.2.3.8
9 = Forward/Reverse DI	Direction of Rotation command selected when using the Forward/Reverse function via digital inputs The digital inputs can be configured in C4.2.3.5 and C4.2.3.6
10 = Speed Reference	Direction of Rotation command defined by the polarity of the speed reference
11 = Not used	Not used



NOTE!
When set to forward, if there is an attempt to set the speed reference to a negative value, the reference is limited to zero.

C4.2.1 Remote R1		
C4.2.2 Remote R2		
.4 JOG		
Range:	0 ... 9	Default: 1 (C4.2.1.4) 0 (C4.2.2.4)
Properties:	Stopped	

Description:
It sets the source for the JOG command.




Figure 9.28: Operation of the JOG command

Indication	Description
0 = Inactive	JOG command disabled
1 = HMI JOG Key	JOG command via HMI key
2 = Serial	JOG command via RS-485 Serial Control Word
3 = Anybus	JOG command via Anybus-CC Control Word
4 = CAN/CO/DN	JOG command via CAN/CANop/DNet Control Word
5 = SoftPLC	JOG command via SoftPLC function
6 = Not used	Not used
7 = Ethernet	JOG command via Ethernet Control Word
8 = Digital Input (DI)	JOG command via digital input chosen by the user The digital input can be set in C4.2.3.9
9 = Not used	Not used

C4.2.3 DI for commands

It allows defining the digital input used for each command with source via digital input. For further information on the control word via DI, see S1.6.3.

C4.2.3 DI for commands		
C4.2.3.1 General enable		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

Enables use and defines the digital input that will be used to enable the drive to run.

Table 9.36: Values assigned to the Digital Inputs of X and A...G Slots for defining command activation

Digital Inputs options for X and A...G Slots								
Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
DI1	X-1 (1)	A-1 (7)	B-1 (15)	C-1 (23)	D-1 (31)	E-1 (39)	F-1 (47)	G-1 (55)
DI2	X-2 (2)	A-2 (8)	B-2 (16)	C-2 (24)	D-2 (32)	E-2 (40)	F-2 (48)	G-2 (56)
DI3	X-3 (3)	A-3 (9)	B-3 (17)	C-3 (25)	D-3 (33)	E-3 (41)	F-3 (49)	G-3 (57)
DI4	X-4 (4)	A-4 (10)	B-4 (18)	C-4 (26)	D-4 (34)	E-4 (42)	F-4 (50)	G-4 (58)
DI5	X-5 (5)	A-5 (11)	B-5 (19)	C-5 (27)	D-5 (35)	E-5 (43)	F-5 (51)	G-5 (59)
DI6	X-6 (6)	A-6 (12)	B-6 (20)	C-6 (28)	D-6 (36)	E-6 (44)	F-6 (52)	G-6 (60)
DI7	–	A-7 (13)	B-7 (21)	C-7 (29)	D-7 (37)	E-7 (45)	F-7 (53)	G-7 (61)
DI8	–	A-8 (14)	B-8 (22)	C-8 (30)	D-8 (38)	E-8 (46)	F-8 (54)	G-8 (62)

**NOTE!**

Example: To choose digital input 4 of Slot C to trigger a command, the parameter must be assigned the value C-4 (26).

C4.2.3 DI for commands**C4.2.3.2 Run/Stop**

Range:	0 ... 62	Default: 1
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used to execute the start and stop commands. The options are shown in Table 9.36 on page 9-53.

C4.2.3 DI for commands**C4.2.3.3 3-Wire start**

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used to execute the "Start" command of the 3-wire Start/Stop function. The options are shown in Table 9.36 on page 9-53.




Figure 9.29: 3-wire Start/Stop function via digital input

C4.2.3 DI for commands		
C4.2.3.4 3-Wire stop		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the "Stop" command of the 3-wire Start/Stop function. The options are shown in Table 9.36 on page 9-53.

Figure 9.29 on page 9-53 illustrates the operation of the Start/Stop function.

C4.2.3 DI for commands		
C4.2.3.5 Forward		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the "Forward" command of the Forward/Reverse function.




Figure 9.30: Forward and Reverse function via digital input

C4.2.3 DI for commands		
C4.2.3.6 Reverse		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the "Reverse" command of the Forward/Reverse function. Table 9.36 on page 9-53 shows the options.

Figure 9.30 on page 9-54 illustrates the operation of the Forward/Reverse function.



NOTE!
When using the Forward/Reverse function, set C4.2.1.2 and C4.2.1.3= 8 or C4.2.2.2 and C4.2.2.3 = 8.

C4.2.3 DI for commands		
C4.2.3.7 Quick stop		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the inverter quick stop. Table 9.36 on page 9-53 shows the options.

The Quick Stop consists of executing the "Stop" with null deceleration ramp command (C6.1.6 = 0s) or close to this value, regardless of the setting in C6.1.2 or C6.1.5. It is not recommended to use this function in scalar control type.




Figure 9.31: Operation of the Quick Stop command

C4.2.3 DI for commands		
C4.2.3.8 Direction of rotation		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the direction of rotation command. Table 9.36 on page 9-53 shows the options.

C4.2.3 DI for commands		
C4.2.3.9 JOG		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the JOG command. Table 9.36 on page 9-53 shows the options.

C4.2.3 DI for commands		
C4.2.3.10 Ramp selection		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the Second Ramp command. Table 9.36 on page 9-53 shows the options.

C4.2.3 DI for commands		
C4.2.3.11 Fault reset		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used for the Fault Reset command. Table 9.36 on page 9-53 shows the options.

When a transition from 0 to 1 occurs on the digital input programmed for Fault Reset, the present fault reset command is executed. If the fault condition is still present, the reset will not be performed. Figure 9.32 on page 9-56 illustrates that.




Figure 9.32: Operation of the Fault Reset command

C4.2.4 Local HMI

It allows defining the behavior of commands via HMI.

C4.2.4 Local HMI		
C4.2.4.1 Stop key function		
Range:	0 ... 2	Default: 0
Properties:	Stopped	

Description:
It sets the motor stop mode for the HMI stop key.

This parameter indicates the method to be performed to stop the motor when the inverter is programmed to be commanded via HMI key.

The available stop modes are:

- Ramp to stop: the inverter uses the time defined in parameter C6.1.2 or C6.1.5 to perform the deceleration ramp.
- General Enable to Stop: the inverter instantly deactivates the general enable. In this mode, there is no set time for the motor to stop.
- Quick stop: the inverter uses the time set in parameter C6.1.6 to perform the deceleration ramp.

**NOTE!**
The general enable to stop mode works only if the general enable parameter (C4.2.1.1 for R1 mode and C4.2.2.1 for R2 mode) is set to HMI.

C4.2.4 Local HMI**C4.2.4.2 Reset all faults**

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

This parameter resets all inverter protections.

**NOTE!**

The general fault reset can also be used via communication networks to facilitate resuming operation after the causes that triggered the protections have been cleared.

Indication	Description
0 = Inactive	
1 = Active	

C4.3 References

It allows configuring the source and the speed and torque reference values for Remote 1 and Remote 2 modes. In Local mode, the speed reference via HMI will always be used.

C4.3.1 Speed

It allows setting the reference values for the motor speed.

C4.3.1.1 Reference range

It allows setting minimum and maximum speed reference values for any reference signal. If the reference signal set to be followed by the inverter is less than the minimum reference setting in C4.3.1.1.1, the inverter will limit to C4.3.1.1.1. If the reference signal set to be followed by the inverter is greater than the maximum reference setting in C4.3.1.1.2, the inverter will limit to C4.3.1.1.2.

C4.3.1.1 Reference range**C4.3.1.1.1 Minimum reference value**

Range:	0 ... 60000 rpm	Default: 90 rpm
Properties:		

Description:

It sets the minimum motor speed reference limit value when the inverter is enabled. Valid for any type of reference signal.

C4.3.1.1 Reference range**C4.3.1.1.2 Maximum reference**

Range:	1 ... 60000 rpm	Default: 1800 rpm
Properties:		

Description:

It sets the maximum motor speed reference limit value when the inverter is enabled. Valid for any type of reference signal.

C4.3.1.2 Reference source

It allows setting the source for the speed reference in the Remote 1 and Remote 2 modes.

C CONFIGURATIONS

C4.3.1.2 Reference source

C4.3.1.2.1 Remote 1 Mode

Range:	0 ... 14	Default: 0
Properties:	Stopped	

Description:

It sets the source for the speed reference for Remote 1 mode.

Indication	Description
0 = HMI	Reference via HMI speed reference parameter (C4.3.1.3.1)
1 = E.P.	Reference via Electronic Potentiometer function
2 = Multispeed	Reference via Multispeed function
3 = Serial	Reference via RS-485 Serial speed reference parameter (S5.2.3)
4 = Anybus	Reference via Anybus-CC speed reference parameter (S5.6.4)
5 = CAN/CO/DN	Reference via CAN/CANop/DNet speed reference parameter (S5.7.3)
6 = Ethernet	Reference via Ethernet speed reference parameter (S5.3.3)
7 = Not used	Not used
8 = SoftPLC	Reference via SoftPLC function
9 = Analog Input (AI)	Reference via analog input chosen by the user The analog input can be set in C4.3.1.3.2
10 = Frequency Input (FI)	Reference via frequency input chosen by the user The frequency input can be set in C4.3.1.3.3
11 = PID Controller	Reference via PID controller output parameter (A2.1.5)
12 = Sum AIs	Reference via sum of analog inputs AI X-1 and AI X-2
13 = Sum AIs > 0	Reference via sum of analog inputs AI X-1 and AI X-2 Negative results are stapled to 0.0 %
14 = Not used	Not used

C4.3.1.2 Reference source

C4.3.1.2.2 Remote 2 Mode

Range:	0 ... 14	Default: 9
Properties:	Stopped	

Description:

It sets the source for the speed reference for Remote 2 mode.

Indication	Description
0 = HMI	Reference via HMI speed reference parameter (C4.3.1.3.1)
1 = E.P.	Reference via Electronic Potentiometer function
2 = Multispeed	Reference via Multispeed function
3 = Serial	Reference via RS-485 Serial speed reference parameter (S5.2.3)
4 = Anybus	Reference via Anybus-CC speed reference parameter (S5.6.4)
5 = CAN/CO/DN	Reference via CAN/CANop/DNet speed reference parameter (S5.7.3)
6 = Ethernet	Reference via Ethernet speed reference parameter (S5.3.3)
7 = Not used	Not used
8 = SoftPLC	Reference via SoftPLC function
9 = Analog Input (AI)	Reference via analog input chosen by the user The analog input can be set in C4.3.1.3.2
10 = Frequency Input (FI)	Reference via frequency input chosen by the user The frequency input can be set in C4.3.1.3.3
11 = PID Controller	Reference via PID controller output parameter (A2.1.5)
12 = Sum AIs	Reference via sum of analog inputs AI X-1 and AI X-2
13 = Sum AIs > 0	Reference via sum of analog inputs AI X-1 and AI X-2 Negative results are stapled to 0.0 %
14 = Not used	Not used

C4.3.1.3 Reference HMI, AIs and FIs

It allows setting the speed reference value when the reference is HMI or analog input (AI) or frequency input (FI).

C4.3.1.3 Reference HMI, AIs and FIs

C4.3.1.3.1 Speed reference via HMI

Range: 0 ... 60000 rpm

Default: 90 rpm

Properties:

Description:

Sets the motor speed reference value when the reference source is the HMI.

C4.3.1.3 Reference HMI, AIs and FIs

C4.3.1.3.2 R1 Speed ref. AI config.

Range: 0 ... 30

Default: 1

Properties: Stopped

Description:

Defines the analog input that will be used as the motor speed reference when the reference source is the Analog Input (AI).

Table 9.40: Values assigned to the Analog Inputs of X and A...G Slots

Analog Inputs options for X and A...G Slots								
Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
AI1	X-1 (1)	A-1 (3)	B-1 (7)	C-1 (11)	D-1 (15)	E-1 (19)	F-1 (23)	G-1 (27)
AI2	X-2 (2)	A-2 (4)	B-2 (8)	C-2 (12)	D-2 (16)	E-2 (20)	F-2 (24)	G-2 (28)
AI3	–	A-3 (5)	B-3 (9)	C-3 (13)	D-3 (17)	E-3 (21)	F-3 (25)	G-3 (29)



NOTE!

Example: To choose Analog Input AI3 from Slot D, select D-3 (17) option.

C4.3.1.3 Reference HMI, AIs and FIs

C4.3.1.3.3 Speed ref. FI config.

Range: 0 ... 2

Default: 1

Properties: Stopped

Description:

It defines the frequency input that will be used as the motor speed reference when the reference source is the Frequency Input (FI).

C4.3.1.3 Reference HMI, AIs and FIs

C4.3.1.3.4 R2 Speed ref. AI config.

Range: 0 ... 30

Default: 1

Properties: Stopped

Description:

It defines the analog input that will be used as a motor speed reference in Remote 2 mode when the reference source is the Analog Input (AI). The options are shown in Table 9.19 on page 9-31.

C4.3.1.4 Electronic potentiometer reference

The Electronic Potentiometer function (E.P.) allows the speed reference to be set by means of two digital inputs (one to increment it and another to decrement it).

To enable this function, you must first configure the speed reference via Electronic Potentiometer by setting C4.3.1.2.1 = E.P. and/or C4.3.1.2.2 = E.P. Next, you must also program which digital inputs will act as the “INCREASE” and “DECREASE” commands in parameters C4.3.1.4.1 and C4.3.1.4.2 respectively.

During the “INCREASE” command, the motor accelerates following the acceleration ramp until reaching the maximum speed reference defined in C4.3.1.1.2 if the command is not removed before. During “DECREASE” command, the motor decelerates following the deceleration ramp until reaching the minimum speed reference defined in C4.3.1.1.1 if the command is not removed before. If the “INCREASE” or “DECREASE” commands are removed before reaching the maximum or minimum speed reference, the new speed reference will be the instantaneous value of the output speed at the instant the command is removed.

The “INCREASE” or “DECREASE” commands are effective only when the Run/Stop command is active.

Figure 9.33 on page 9-60 illustrates the operation of this function. The reference increment is done by applying 24 V to the “INCREASE” digital input, while the decrement is done by applying 0 V to the “DECREASE” digital input.

To reset the reference to zero, apply 24 V to the “INCREASE” digital input and 0 V to the “DECREASE” digital input simultaneously with the MVW disabled.

If no digital inputs are set to the “INCREASE” and/or “DECREASE” function and the reference source selection is set to Electronic Potentiometer (C4.3.1.2.1 = E.P. and/or C4.3.1.2.2 = E.P.), the MVW will go to CONFIG status. See parameter S1.1.4.




Figure 9.33: Electronic Potentiometer (E.P.) function

C4.3.1.4 Electronic potentiometer reference**C4.3.1.4.1 DI increase E.P.**

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used as "INCREASE" command by the Electronic Potentiometer. Table 9.36 on page 9-53 shows the options.

C4.3.1.4 Electronic potentiometer reference**C4.3.1.4.2 DI decrease E.P.**

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used as "DECREASE" command by the Electronic Potentiometer. Table 9.36 on page 9-53 shows the options.

C4.3.1.5 Multispeed reference

With the Multispeed function it is possible to select one of up to eight preset fixed speed references. The selection of one of the references is made according to the logical combination of the status of up to three digital inputs. This behavior can be seen in Figure 9.34 and in Table 9.41 on page 9-62.

To activate the Multispeed function it is necessary to configure parameter C4.3.1.2.1 = Multispeed and/or C4.3.1.2.2 = Multispeed (reference source selection).

It is possible to use only one or two digital inputs and thus select between up to two or four Multispeed references respectively. Digital inputs not configured for the Multispeed function are considered as 0 V in Table 9.41.

If no digital inputs are set to the Multispeed function and the reference source selection is set to Multispeed (C4.3.1.2.1 = Multispeed and/or C4.3.1.2.2 = Multispeed), the MVW will go to the CONFIG status. See parameter S1.1.4.

The Multispeed function provides the advantages of stability of the fixed preset references and immunity against electric noises (isolated digital inputs).




Figure 9.34: Multispeed

Below is a table with the selection of the speed reference according to the logical state of the digital inputs:

Table 9.41: Multispeed Reference

8 speed references			
4 speed references			
2 speed references			
3rd DI	2nd DI	1st DI	Speed Reference
0 V	0 V	0 V	C4.3.1.5.1
0 V	0 V	24 V	C4.3.1.5.2
0 V	24 V	0 V	C4.3.1.5.3
0 V	24 V	24 V	C4.3.1.5.4
24 V	0 V	0 V	C4.3.1.5.5
24 V	0 V	24 V	C4.3.1.5.6
24 V	24 V	0 V	C4.3.1.5.7
24 V	24 V	24 V	C4.3.1.5.8

C4.3.1.5 Multispeed reference

C4.3.1.5.1 Multispeed ref. 1

C4.3.1.5.2 Multispeed ref. 2

C4.3.1.5.3 Multispeed ref. 3

C4.3.1.5.4 Multispeed ref. 4

C4.3.1.5.5 Multispeed ref. 5

C4.3.1.5.6 Multispeed ref. 6

C4.3.1.5.7 Multispeed ref. 7

C4.3.1.5.8 Multispeed ref. 8

Range:	0 ... 60000 rpm	Default: 90 rpm (C4.3.1.5.1)
		300 rpm (C4.3.1.5.2)
		600 rpm (C4.3.1.5.3)
		900 rpm (C4.3.1.5.4)
		1200 rpm (C4.3.1.5.5)
		1500 rpm (C4.3.1.5.6)
		1800 rpm (C4.3.1.5.7)
		1650 rpm (C4.3.1.5.8)

Properties:

Description:

It sets the value of the multispeed speed reference according to the logical combination of the digital inputs. The digital inputs logics are presented in the Table 9.41.

C4.3.1.5 Multispeed reference

C4.3.1.5.9 Multispeed 1 DI config.

C4.3.1.5.10 Multispeed 2 DI config.

C4.3.1.5.11 Multispeed 3 DI config.

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used for selecting the multispeed speed reference. Table 9.36 on page 9-53 shows the options.

C4.3.1.6 Skip speed

It allows setting up to three speed ranges in which the motor cannot operate continuously; for example, in a mechanical system that goes into resonance (causing excessive vibration or noise). Figure 9.35 on page 9-63 details the operation of this function.




Figure 9.35: Operation curve of the “Skip Speeds”

The function is disabled for C4.3.1.6.4=0.

The passage through the skip speed range (2 x C4.3.1.6.4) is done following the acceleration or deceleration ramp.

If the speed reference is within the range to be skipped, the new reference will go to the lower limit of the range in question.

In case of overlapping ranges, a single range will be considered, with limits defined by the smallest lowest limit and the highest upper limit.

If the range limits exceed the minimum and/or maximum reference values (C4.3.1.1.1 and C4.3.1.1.2), these limits will be saturated in the values of C4.3.1.1.1 and/or C4.3.1.1.2.

NOTE!

If only one or two of the skip speed ranges are to be used, two or one of the ranges must be overlapped. For example, to use only one skip speed range, set parameters C4.3.1.6.1, C4.3.1.6.2 and C4.3.1.6.3 to the same value (overlapping ranges 1, 2 and 3).

C4.3.1.6 Skip speed		
C4.3.1.6.1 Speed 1		
Range:	0 ... 60000 rpm	Default: 600 rpm
Properties:		

Description:
It sets the value of skip speed 1.

C4.3.1.6 Skip speed		
C4.3.1.6.2 Speed 2		
Range:	0 ... 60000 rpm	Default: 900 rpm
Properties:		

Description:
It sets the value of skip speed 2.

C CONFIGURATIONS

C4.3.1.6 Skip speed

C4.3.1.6.3 Speed 3

Range: 0 ... 60000 rpm

Default: 1200 rpm

Properties:

Description:

It sets the value of skip speed 3.

C4.3.1.6 Skip speed

C4.3.1.6.4 Skip range

Range: 0 ... 750 rpm

Default: 0 rpm

Properties:

Description:

Sets the value of the speed range that should be skipped. This value is subtracted and added to the value of the skipped speed, thus setting a range around the defined speed.

C4.3.2 JOG speed

It allows setting the speed reference for the JOG command.

C4.3.2 JOG speed

C4.3.2.1 JOG reference

Range: 0 ... 60000 rpm

Default: 150 rpm

Properties:

Description:

It sets the motor speed reference value when the JOG command is executed.

During the JOG command, the motor accelerates following the acceleration ramp set until reaching the speed defined in this reference. The JOG command is only effective when the Run/Stop command is inactive.

C4.3.3 Torque

It allows setting the torque reference to operate in Torque Control mode.



NOTE!

The torque reference is only active when the control type is set to Vector with Encoder (C3.1.1 = 2).

C4.3.3 Torque

C4.3.3.1 Torque reference via HMI

Range: -400.0 ... 400.0 %

Default: 0.0 %

Properties:

Description:

It sets the torque reference value when the reference source is the HMI.

C4.3.3 Torque

C4.3.3.2 Maximum torque

Range: 0.0 ... 400.0 %

Default: 400.0 %

Properties:

Description:

It allows you to set maximum torque reference value for any reference signal. If the reference signal configured to be followed by the inverter is greater than the maximum reference set in C4.3.3.2, the inverter will limit in C4.3.3.2.

C4.3.3 Torque**C4.3.3.3 Minimum torque**

Range: 0.0 ... 400.0 %

Default: 0.0 %

Properties:

Description:

It allows you to set minimum torque reference value for any reference signal. If the reference signal configured to be followed by the inverter is less than the minimum reference set in C4.3.3.3, the inverter will limit in C4.3.3.3.

C4.3.3 Torque**C4.3.3.4 Torque ref. source**

Range: 0 ... 2

Default: 0

Properties: Stopped

Description:

It defines which source will determine the reference for torque control.

Indication	Description
0 = HMI	Torque Reference via HMI parameter (C4.3.3.1)
1 = Analog Input (AI)	Torque Reference via analog input chosen by the user The analog input can be set in C4.3.3.5
2 = Frequency Input (FI)	Torque Reference via frequency input chosen by the user The frequency input can be set in C4.3.3.6

**NOTE!**

If it is necessary to set the torque reference via Communication Networks or SoftPLC, this parameter must be set to HMI and the reference value set in C4.3.3.1.

C4.3.3 Torque**C4.3.3.5 Torque ref. AI config.**

Range: 0 ... 30

Default: 0

Properties: Stopped

Description:

Defines which analog input will be used as reference for torque control. Table 9.43 on page 9-65 shows the options.

Analog Inputs options for X and A...G Slots

Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
AI1	X-1 (1)	A-1 (3)	B-1 (7)	C-1 (11)	D-1 (15)	E-1 (19)	F-1 (23)	G-1 (27)
AI2	X-2 (2)	A-2 (4)	B-2 (8)	C-2 (12)	D-2 (16)	E-2 (20)	F-2 (24)	G-2 (28)
AI3	—	A-3 (5)	B-3 (9)	C-3 (13)	D-3 (17)	E-3 (21)	F-3 (25)	G-3 (29)

Table 9.43: Values assigned to the Analog Inputs of X and A...G Slots

**NOTE!**

Example: To choose Analog Input AI3 from Slot D, select D-3 (17) option.

C4.3.3 Torque		
C4.3.3.6 Torque ref. FI config.		
Range:	0 ... 2	Default: 0
Properties:	Stopped	

Description:
It defines which frequency input will be used as reference for torque control.

Indication	Description
0 = Inactive	It disables the use of the frequency input in this function
1 = FI X-5	It enables the use of frequency input FI5 of Slot X
2 = FI X-6	It enables the use of frequency input FI6 of Slot X

C5 I/OS

It allows configuring the I/O accessories installed on the MVW.

C5.1 Slot X

Allows you to view the status of the slot configuration parameters.




Figure 9.36: IOS Accessory, Slot X

C5.1.1 Analog inputs

It allows setting the analog inputs of the accessory connected to the corresponding slot.

Figure 9.37 on page 9-67 illustrates how the analog input works.




Figure 9.37: Block diagram of the analog input

Figure 9.38 on page 9-67 illustrates the analog input behavior for different configurations of gain, offset and dead zone with signal type set to 0 to 10 V. In addition, it is presented how saturation works for each configuration. The behavior of the signal may change slightly according to the signal type selected, but the effects of the settings shown remain the same.




Figure 9.38: Analog input signal types

C5.1.1 Analog inputs		
C5.1.1.1 AI1 Settings		
C5.1.1.6 AI2 Settings		
Range:	0 ... 5 Bit	Default: 16
Properties:		

Description:

It allows to configure the action to be taken in case of a broken wire and also the type of signal that is expected at the terminals.

C CONFIGURATIONS

Bit	Value/Description
Bit 0 ... 1 Detect Disconnection	Enabling broken wire detection when the analog input signal type is 4 to 20 mA or 20 to 4 mA. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 2 ... 5 Signal Config.	Selection of the analog input signal type. 0 = 0 to 20 mA: It indicates that the analog input signal is of 0 to 20 mA type 1 = 4 to 20 mA: It indicates that the analog input signal is of 4 to 20 mA type 2 = 20 to 0 mA: It indicates that the analog input signal is of 20 to 0 mA type 3 = 20 to 4 mA: It indicates that the analog input signal is of 20 to 4 mA type 4 = 0 to 10 V: It indicates that the analog input signal is of 0 to 10 mA type 5 = 10 to 0 V: It indicates that the analog input signal is of 10 to 0 V type 6 = -10 to 10 V: It indicates that the analog input signal is of -10 to 10 V type 7 = 10 to -10 V: It indicates that the analog input signal is of 10 to -10 V type 8 = Not used: Not used

C5.1.1 Analog inputs

C5.1.1.2 AI1 Filter

C5.1.1.7 AI2 Filter

Range: 0.00 ... 16.00 s

Default: 0.10 s

Properties:

Description:

It allows to configure the RC constant of the low-pass filter present at the analog input.



NOTE!

The analog input signal is filtered before applying gain and offset to the signal.

C5.1.1 Analog inputs

C5.1.1.3 AI1 Gain

C5.1.1.8 AI2 Gain

Range: 0.000 ... 9.999

Default: 1.000

Properties:

Description:

Gain setting for analog input.

C5.1.1 Analog inputs

C5.1.1.4 AI1 Offset

C5.1.1.9 AI2 Offset

Range: -100.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Offset setting for analog input.

C5.1.1 Analog inputs

C5.1.1.5 AI1 Dead zone

C5.1.1.10 AI2 Dead zone

Range: 0.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Dead zone setting for analog input.

C5.1.2 Analog outputs

It allows setting the analog outputs of the accessory connected to the slot.

Figure 9.39 on page 9-69 illustrates how the analog output works.




Figure 9.39: Block diagram of the analog output

C5.1.2 Analog outputs		
C5.1.2.1 AO1 Signal type		
C5.1.2.5 AO2 Signal type		
Range:	0 ... 5	Default: 4
Properties:		

Description:
It allows to configure the signal type of analog output.

To set the type of output, it is also necessary to correctly position the "DIP switches" present on the accessory.
For further details, refer to the specific accessory manual.

Indication	Description
0 = 0 to 20 mA	It indicates that the Analog Output signal of Slot X is 0 to 20 mA
1 = 4 to 20 mA	It indicates that the Analog Output signal of Slot X is 4 to 20 mA type
2 = 20 to 0 mA	It indicates that the Analog Output signal of Slot X is 20 to 0 mA type
3 = 20 to 4 mA	It indicates that the Analog Output signal of Slot X is 20 to 4 mA type
4 = 0 to 10 V	It indicates that the Analog Output signal of Slot X is 0 to 10 V type
5 = 10 to 0 V	It indicates that the Analog Output signal of Slot X is 10 to 0 V type

C5.1.2 Analog outputs		
C5.1.2.2 AO1 Gain		
C5.1.2.6 AO2 Gain		
Range:	0.000 ... 9.999	Default: 1.000
Properties:		

Description:
Gain setting for analog output.

C5.1.2 Analog outputs

C5.1.2.3 AO1 Function

C5.1.2.7 AO2 Function

Range: 0 ... 21 **Default:** 4 (C5.1.2.3)
7 (C5.1.2.7)

Properties:

Description:

Setting of the function to be used for the analog output.

Indication	Description
0 = Off (0%)	It imposes 0 % on the output, regardless of the set gain and offset values
1 = On (100%)	It imposes 100 % on the output, regardless of the set gain and offset values
2 = Speed Ref.	It imposes on the output a value proportional to the speed reference (S2.1.1)
3 = Inverter temperature	It imposes on the output a value proportional to the highest temperature value between the inverter cells, see S2.4.1.4
4 = Real Speed	It imposes on the output a value proportional to the current motor speed used by the control module (S2.1.3)
5 ... 6 = Not used	Not used
7 = Output Current	It imposes on the output a value proportional to the RMS value of the fundamental component of the inverter output current (S2.3.1)
8 = Process Var.	Process Variable
9 = Not used	Not used
10 = Output Power	It imposes on the output a value proportional to the electrical power at the inverter output (S2.3.11)
11 = PID Setpoint	PID Setpoint
12 = Not used	Not used
13 = Motor Torque	It imposes on the output a value proportional to the estimated electrical torque on the motor based on the nominal torque (S2.2.3)
14 = SoftPLC	It imposes on the output the value sent by SoftPLC. Gain and offset values do not affect the output
15 = PTC	It imposes on the output the recommended value for powering a PTC temperature sensor (10 %). Gain and offset values do not affect the output
16 = Motor Ixt	It imposes on the output a value proportional to the motor overload level (D4.1.5.1)
17 = Encoder Speed	It imposes on the output a value proportional to the encoder current speed (S2.1.4)
18 = Network	It imposes on the output the value sent by the network. Gain and offset values do not affect the output
19 = Not used	Not used
20 = Torque Ref.	It imposes on the output a value proportional to the electrical torque reference on the motor based on the nominal torque (S2.2.1)
21 = Total Torque Ref.	It imposes on the output a value proportional to the electrical torque reference of the motor after the ramp (S2.2.2)

Table 9.47 on page 9-71 illustrates the full scale of analog output functions.

Table 9.47: Full scale of AO functions

Scale of the analog outputs indications	
Variable	Full scale
Speed Ref. Total Speed Ref.	Maximum Speed Reference (C4.3.1.1.2)
Real Speed Encoder Speed	$2.0 \times [\text{Maximum Speed Reference (C4.3.1.1.2)}]$
Output Current	$1.5 \times [\text{Rated Current (C13.1.2)}]$
Output Power	$1.5 \times \sqrt{3} \times [\text{Rated Current (C13.1.2)}] \times [\text{Rated Voltage (C13.1.1)}]$
Torque Ref. Total Torque Ref.	Maximum Torque Reference (C4.3.3.2)
Motor Torque	400 %
Motor Ixt Network	100 %
SoftPLC	32767
Process Var. PID Setpoint	Process Variable Maximum Level (A2.3.3.5)

The analog outputs cannot reproduce negative values at their terminals even if the HMI status shows negative values. This is because all analog output signal types are not bipolar. If it is necessary to represent these negative values using analog outputs, it is possible to set an offset of +100 % and a gain of 0.500. The analog output will keep reproducing only non-negative values, but it will be possible to differentiate positive from negative values. Figure 9.40 on page 9-71 illustrates this behavior for torque reference function and signal type set to 0 to 10 V. This setting can be useful when the analog output function is set to any function that can return a negative value, such as motor torque and torque reference.




Figure 9.40: AO configurations to represent negative values

C5.1.2 Analog outputs

C5.1.2.4 AO1 Offset

C5.1.2.8 AO2 Offset

Range: -100.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Offset setting for analog output.

C CONFIGURATIONS

C5.1.3 Digital inputs

It allows configuring the digital inputs of the accessory connected to the slot.

Table 9.48: Values assigned to the Digital Inputs of X and A...G Slots for defining the Control Mode

Digital Inputs options for X and A...G Slots								
Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
DI1	X-1 (1)	A-1 (7)	B-1 (15)	C-1 (23)	D-1 (31)	E-1 (39)	F-1 (47)	G-1 (55)
DI2	X-2 (2)	A-2 (8)	B-2 (16)	C-2 (24)	D-2 (32)	E-2 (40)	F-2 (48)	G-2 (56)
DI3	X-3 (3)	A-3 (9)	B-3 (17)	C-3 (25)	D-3 (33)	E-3 (41)	F-3 (49)	G-3 (57)
DI4	X-4 (4)	A-4 (10)	B-4 (18)	C-4 (26)	D-4 (34)	E-4 (42)	F-4 (50)	G-4 (58)
DI5	X-5 (5)	A-5 (11)	B-5 (19)	C-5 (27)	D-5 (35)	E-5 (43)	F-5 (51)	G-5 (59)
DI6	X-6 (6)	A-6 (12)	B-6 (20)	C-6 (28)	D-6 (36)	E-6 (44)	F-6 (52)	G-6 (60)
DI7	—	A-7 (13)	B-7 (21)	C-7 (29)	D-7 (37)	E-7 (45)	F-7 (53)	G-7 (61)
DI8	—	A-8 (14)	B-8 (22)	C-8 (30)	D-8 (38)	E-8 (46)	F-8 (54)	G-8 (62)

Figure 9.41 on page 9-72 illustrates how the frequency input works.




Figure 9.41: Frequency input block diagram

C5.1.3 Digital inputs

C5.1.3.4 DI5 Operation mode

C5.1.3.9 DI6 Operation mode

Range: 0 ... 3

Default: 0

Properties: Stopped

Description:

It allows to configure the operating mode of the digital input.

**NOTE!**

When the digital input is configured as a frequency input, it must be ensured that no command via DI is configured to use this same input. An example of a configuration that should be avoided would be to set the DI5 parameter of the Slot-X (C5.1.3.4) as frequency input and then set the general enable command parameter via DI (C4.2.3.1) to use this same input.

Indication	Description
0 = Polling	It indicates that the Digital Input is set for reading via scanning
1 = Not used	Not used
2 = Frequency	It indicates that the Digital Input is set to frequency input
3 = Encoder	It indicates that the Digital Input is set for reading the input signal frequency

C5.1.3 Digital inputs**C5.1.3.5 FI5 Min frequency****C5.1.3.10 FI6 Min frequency**

Range:	0 ... 32000 Hz	Default: 0 Hz
Properties:	Stopped	

Description:

It allows to configure the zero scale of the frequency input.

C5.1.3 Digital inputs**C5.1.3.6 FI5 Max frequency****C5.1.3.11 FI6 Max frequency**

Range:	0 ... 32000 Hz	Default: 32000 Hz
Properties:	Stopped	

Description:

It allows to configure the full scale of the frequency input.

C5.1.3 Digital inputs**C5.1.3.7 FI5 Gain****C5.1.3.12 FI6 Gain**

Range:	0.000 ... 9.999	Default: 1.000
Properties:	Stopped	

Description:

Frequency input gain setting.

C5.1.3 Digital inputs**C5.1.3.8 FI5 Offset****C5.1.3.13 FI6 Offset**

Range:	-100.00 ... 100.00 %	Default: 0.00 %
Properties:	Stopped	

Description:

Frequency input offset setting.

C5.1.4 Digital outputs

It allows configuring the digital outputs of the accessory connected to the slot.

Figure 9.42 on page 9-74 illustrates how the frequency output works.




Figure 9.42: Frequency output block diagram

C5.1.4 Digital outputs

C5.1.4.1 DO1 Operation mode

C5.1.4.10 DO2 Operation mode

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

It allows to configure the operating mode of the digital output.

Indication	Description
0 = Polling	It indicates that the Digital Output is set to the ON/OFF mode
1 = Frequency	It indicates that the Digital Output is set to the Frequency Output mode

C5.1.4 Digital outputs

C5.1.4.2 DO1 Function

C5.1.4.11 DO2 Function

Range:	0 ... 34	Default: 22 (C5.1.4.2) 19 (C5.1.4.11)
--------	----------	--

Properties:

Description:

Setting of the function to be used for the digital output.

Indication	Description
0 = Off	The Digital Output will always go to the inactive status
1 = On	The Digital Output will always go to the active status
2 = $N^* > N_x$	The Digital Output will go to the active status when the speed reference (N^*) is greater than the value set in N_x
3 = $N > N_x$	The Digital Output will go to the active status when the motor speed (N) is greater than the value set in N_x
4 = $N < N_y$	The Digital Output will go to the active status when the motor speed (N) is smaller than the value set in N_y
5 = $N = N^*$	The Digital Output will go to the active status when the motor speed (N) equals the speed reference value (N^*)
6 = Zero Speed	The Digital Output will go to the active status when the motor speed (N) is smaller than the value set in Zero Speed
7 = Not used	Not used
8 = $F > F_x$	The Digital Output will go to the active status when the motor frequency (F) is greater than the value set in F_x

Indication	Description
9 = Is > Ix	The Digital Output will go to the active status when the output current (Is) is greater than the value set in Ix
10 = Is < Ix	The Digital Output will go to the active status when the output current (Is) is smaller than the value set in Ix
11 = Torque > Tx	The Digital Output will go to the active status when the motor torque (Torque) is greater than the value set in Tx
12 = Torque < Tx	The Digital Output will go to the active status when the motor torque (Torque) is smaller than the value set in Tx
13 = Hours Enabled > Hx	The Digital Output will go to the active status when the enabled hour counter is greater than the value set in Hx
14 ... 15 = Not used	Not used
16 = Local Mode	The Digital Output will go to the active status when the commands and references are defined by the Local mode
17 = Remote 1 Mode	The Digital Output will go to the active status when the commands and references are defined by the Remote 1 mode
18 = Remote 2 Mode	The Digital Output will go to the active status when the commands and references are defined by the Remote 2 mode
19 = Run	The Digital Output will go to the active status when the inverter is in the Run status
20 = Ready	The Digital Output will go to the active state when the inverter is in the Ready state, indicating that the pre-charge has been completed, the inverter is enabled and ready to receive the RUN command.
21 = STO	The Digital Output will go to the active status when the inverter is in the STO status
22 = No Fault	The Digital Output will go to the active status when the inverter does not have a fault acting
23 = With Fault	The Digital Output will go to the active status when any fault acts on the inverter
24 = No Alarm	The Digital Output will go to the active status when the inverter is not indicating an alarm
25 = No Fault and Alarm	The Digital Output will go to the active status when a fault is not acting and is not indicating an alarm in the inverter
26 = Network	The Digital Output will go to the active status when the command received via Network is active
27 = SoftPLC	The Digital Output will go to the active status when the command received via SoftPLC is active
28 = Forward Direction	The Digital Output will go to the active state when the inverter is running in the forward direction
29 = Ride-Through	The Digital Output will go to the active status when the Ride-Through function is acting
30 = Pre-Charge OK	The Digital Output will go into the active state when the Pre-charge function indicates that it has been successfully executed
31 = Ready to start	The Digital Output will go to the active state when the inverter has completed the pre-charge and without a RUN command.
32 = Alarm/Fault 1	The Digital Output will go to the active state when the Fault or Alarm selected in parameter C5.9.11 is active.
33 = Alarm/Fault 2	The Digital Output will go to the active state when the Fault or Alarm selected in parameter C5.9.12 is active.
34 = Alarm/Fault 3	The Digital Output will go to the active state when the Fault or Alarm selected in parameter C5.9.13 is active.

C5.1.4 Digital outputs

C5.1.4.3 FO1 Function

C5.1.4.12 FO2 Function

Range: 0 ... 21

Default: 0

Properties: Stopped

Description:

Setting of the function to be used for the frequency output.

Indication	Description
0 = Off (0%)	It imposes 0 % on the output, regardless of the set gain and offset values
1 = On (100%)	It imposes 100 % on the output, regardless of the set gain and offset values
2 = Speed Ref.	It imposes on the output a value proportional to the speed reference (S2.1.1)

Indication	Description
3 = Total Speed Ref.	It imposes on the output a value proportional to the highest temperature value between the inverter cells, see S2.4.1.4
4 = Real Speed	It imposes on the output a value proportional to the current motor speed used by the control module (S2.1.3)
5 ... 6 = Not used	Not used
7 = Output Current	It imposes on the output a value proportional to the RMS value of the fundamental component of the inverter output current (S2.3.1)
8 = Process Var.	Process Variable
9 = Not used	Not used
10 = Output Power	It imposes on the output a value proportional to the electrical power at the inverter output (S2.3.11)
11 = PID Setpoint	PID Setpoint
12 = Not used	Not used
13 = Motor Torque	It imposes on the output a value proportional to the estimated electrical torque on the motor based on the nominal torque (S2.2.3)
14 = SoftPLC	It imposes on the output the value sent by SoftPLC. Gain and offset values do not affect the output
15 = Not used	Not used
16 = Motor lxt	It imposes on the output a value proportional to the motor overload level (D4.1.5.1)
17 = Encoder Speed	It imposes on the output a value proportional to the encoder current speed (S2.1.4)
18 = Network	It imposes on the output the value sent by the network. Gain and offset values do not affect the output
19 = Not used	Not used
20 = Torque Ref.	It imposes on the output a value proportional to the electrical torque reference on the motor based on the nominal torque (S2.2.1)
21 = Total Torque Ref.	It imposes on the output a value proportional to the electrical torque reference of the motor after the ramp (S2.2.2)

Table 9.53 on page 9-76 illustrates the full scale of frequency output functions.

Table 9.53: Full scale of FO functions

Scale of frequency output indications	
Variable	Full scale
Speed Ref. Total Speed Ref.	Maximum Speed Reference (C4.3.1.1.2)
Real Speed Encoder Speed	$2.0 \times [\text{Maximum Speed Reference (C4.3.1.1.2)}]$
Inverter temperature	200°C
Output Current	$1.5 \times [\text{Rated Current (C13.1.2)}]$
Output Power	$1.5 \times \sqrt{3} \times [\text{Rated Current (C13.1.2)}] \times [\text{Rated Voltage (C13.1.1)}]$
Torque Ref. Total Torque Ref.	Maximum Torque Reference (C4.3.3.2)
Motor Torque	400 %
Motor lxt Network	100 %
SoftPLC	32767
Process Var. PID Setpoint	Process Variable Maximum Level (A2.3.3.5)

The frequency outputs cannot reproduce negative values at their terminals even if the HMI status shows negative values. That happens because all frequency outputs respect their minimum value, and this value is reached at 0 %. If it is necessary to represent these negative values using frequency outputs, it is possible to set an offset of +100 % and a gain of 0.500. The frequency output will keep reproducing only non-negative values, but it will be possible to differentiate positive from negative values. Figure 9.43 on page 9-77 illustrates this behavior for torque reference function. The minimum and maximum frequency limits are set according to the default value setting. This setting can be useful when the frequency output function is set to any function that can return a negative value, such as motor torque and torque reference.




Figure 9.43: FO configurations to represent negative values

C5.1.4 Digital outputs

C5.1.4.4 FO1 Min frequency

C5.1.4.13 FO2 Min frequency

Range:	0 ... 32000 Hz	Default: 0 Hz
Properties:	Stopped	

Description:

It allows to configure the frequency output zero scale.

C5.1.4 Digital outputs

C5.1.4.5 FO1 Max frequency

C5.1.4.14 FO2 Max frequency

Range:	0 ... 32000 Hz	Default: 32000 Hz
Properties:	Stopped	

Description:

It allows to configure the full scale for frequency output.

C5.1.4 Digital outputs

C5.1.4.6 FO1 Gain

C5.1.4.15 FO2 Gain

Range:	0.000 ... 9.999	Default: 1.000
Properties:	Stopped	

Description:

Frequency output gain setting.

C5.1.4 Digital outputs

C5.1.4.7 FO1 Offset

C5.1.4.16 FO2 Offset

Range:	-100.00 ... 100.00 %	Default: 0.00 %
Properties:	Stopped	

C CONFIGURATIONS

Description:

Frequency output offset setting.

C5.1.5 Encoder

Allows you to configure the encoder accessory connected to the slot.



ATTENTION!

This encoder only allows motor speed monitoring; for vector control, see C5.11.4.

C5.1.5 Encoder

C5.1.5.1 Number of pulses

Range: 1 ... 65535 ppr

Default: 1024 ppr

Properties: Stopped

Description:

Setting of the number of pulses that the connected encoder generates during one complete revolution.

C5.2 Slot A

It allows viewing the status of the configuration parameters of the Slot.

C5.2.1 Analog inputs to C5.8.1 Analog inputs

It allows setting the analog inputs of the accessory connected to the corresponding slot.

C5.2.1 Analog inputs

C5.3.1 Analog inputs

C5.4.1 Analog inputs

C5.5.1 Analog inputs

C5.6.1 Analog inputs

C5.7.1 Analog inputs

C5.8.1 Analog inputs

1 AI1 Settings

6 AI2 Settings

11 AI3 Settings

Range: 0 ... 5 Bit

Default: 16

Properties:

Description:

It allows to configure the action to be taken in case of a broken wire and also the type of signal that is expected at the terminals.

Bit	Value/Description
Bit 0 ... 1 Detect Disconnection	Enabling broken wire detection when the analog input signal type is 4 to 20 mA or 20 to 4 mA. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 2 ... 5 Signal Config.	Selection of the analog input signal type. 0 = 0 to 20 mA: It indicates that the analog input signal is of 0 to 20 mA type 1 = 4 to 20 mA: It indicates that the analog input signal is of 4 to 20 mA type 2 = 20 to 0 mA: It indicates that the analog input signal is of 20 to 0 mA type 3 = 20 to 4 mA: It indicates that the analog input signal is of 20 to 4 mA type 4 = 0 to 10 V: It indicates that the analog input signal is of 0 to 10 V type 5 = 10 to 0 V: It indicates that the analog input signal is of 10 to 0 V type 6 = -10 to 10 V: It indicates that the analog input signal is of -10 to 10 V type 7 = 10 to -10 V: It indicates that the analog input signal is of 10 to -10 V type 8 = PTC: It indicates that the analog input signal is of the PTC type

C5.2.1 Analog inputs
 C5.3.1 Analog inputs
 C5.4.1 Analog inputs
 C5.5.1 Analog inputs
 C5.6.1 Analog inputs
 C5.7.1 Analog inputs
 C5.8.1 Analog inputs

.2 AI1 Filter
 .7 AI2 Filter
 .12 AI3 Filter

Range: 0.00 ... 16.00 s

Default: 0.10 s

Properties:

Description:

It allows to configure the RC constant of the low-pass filter present at the analog input.



NOTE!

The analog input signal is filtered before applying gain and offset to the signal.

C5.2.1 Analog inputs
 C5.3.1 Analog inputs
 C5.4.1 Analog inputs
 C5.5.1 Analog inputs
 C5.6.1 Analog inputs
 C5.7.1 Analog inputs
 C5.8.1 Analog inputs

.3 AI1 Gain
 .8 AI2 Gain
 .13 AI3 Gain

Range: 0.000 ... 9.999

Default: 1.000

Properties:

Description:

Gain setting for analog input.

C5.2.1 Analog inputs
 C5.3.1 Analog inputs
 C5.4.1 Analog inputs
 C5.5.1 Analog inputs
 C5.6.1 Analog inputs
 C5.7.1 Analog inputs
 C5.8.1 Analog inputs

.4 AI1 Offset
 .9 AI2 Offset
 .14 AI3 Offset

Range: -100.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Offset setting for analog input.

C5.2.1 Analog inputs

C5.3.1 Analog inputs

C5.4.1 Analog inputs

C5.5.1 Analog inputs

C5.6.1 Analog inputs

C5.7.1 Analog inputs

C5.8.1 Analog inputs

.5 AI1 Dead zone

.10 AI2 Dead zone

.15 AI3 Dead zone

Range: 0.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Dead zone setting for analog input.

C5.2.2 Analog outputs to C5.8.2 Analog outputs

It allows setting the analog outputs of the accessory connected to the slot.

C5.2.2 Analog outputs

C5.3.2 Analog outputs

C5.4.2 Analog outputs

C5.5.2 Analog outputs

C5.6.2 Analog outputs

C5.7.2 Analog outputs

C5.8.2 Analog outputs

.1 AO1 Signal type

.5 AO2 Signal type

Range: 0 ... 7

Default: 4

Properties:

Description:

It allows to configure the signal type of analog output.

To set the type of output, it is also necessary to correctly position the "DIP switches" present on the accessory. For further details, refer to the specific accessory manual.

Indication	Description
0 = 0 to 20 mA	It indicates that the Analog Output signal is 0 to 20 mA type
1 = 4 to 20 mA	It indicates that the Analog Output signal is 4 to 20 mA type
2 = 20 to 0 mA	It indicates that the Analog Output signal is 20 to 0 mA type
3 = 20 to 4 mA	It indicates that the Analog Output signal is 20 to 4 mA type
4 = 0 to 10 V	It indicates that the Analog Output signal is 0 a 10 V type
5 = 10 to 0 V	It indicates that the Analog Output signal is 10 a 0 V type
6 ... 7 = Not used	Not used

C5.2.2 Analog outputs
 C5.3.2 Analog outputs
 C5.4.2 Analog outputs
 C5.5.2 Analog outputs
 C5.6.2 Analog outputs
 C5.7.2 Analog outputs
 C5.8.2 Analog outputs

.2 AO1 Gain

.6 AO2 Gain

Range: 0.000 ... 9.999

Default: 1.000

Properties:

Description:

Gain setting for analog output.

C5.2.2 Analog outputs
 C5.3.2 Analog outputs
 C5.4.2 Analog outputs
 C5.5.2 Analog outputs
 C5.6.2 Analog outputs
 C5.7.2 Analog outputs
 C5.8.2 Analog outputs

.3 AO1 Function

.7 AO2 Function

Range: 0 ... 21

Default: 0

Properties:

Description:

Setting of the function to be used for the analog output.

Indication	Description
0 = Off (0%)	It imposes 0 % on the output, regardless of the set gain and offset values
1 = On (100%)	It imposes 100 % on the output, regardless of the set gain and offset values
2 = Speed Ref.	It imposes on the output a value proportional to the speed reference (S2.1.1)
3 = Inverter temperature	It imposes on the output a value proportional to the highest temperature value between the inverter cells, see S2.4.1.4
4 = Real Speed	It imposes on the output a value proportional to the current motor speed used by the control module (S2.1.3)
5 ... 6 = Not used	Not used
7 = Output Current	It imposes on the output a value proportional to the RMS value of the fundamental component of the inverter output current (S2.3.1)
8 = Process Var.	Process Variable
9 = Not used	Not used
10 = Output Power	It imposes on the output a value proportional to the electrical power at the inverter output (S2.3.11)
11 = PID Setpoint	PID Setpoint
12 = Not used	Not used
13 = Motor Torque	It imposes on the output a value proportional to the estimated electrical torque on the motor based on the nominal torque (S2.2.3)
14 = SoftPLC	It imposes on the output the value sent by SoftPLC. Gain and offset values do not affect the output
15 = PTC	It imposes on the output the recommended value for powering a PTC temperature sensor (10 %). Gain and offset values do not affect the output
16 = Motor Ixt	It imposes on the output a value proportional to the motor overload level (D4.1.5.1)
17 = Encoder Speed	It imposes on the output a value proportional to the encoder current speed (S2.1.4)
18 = Network	It imposes on the output the value sent by the network. Gain and offset values do not affect the output

C CONFIGURATIONS

Indication	Description
19 = Not used	Not used
20 = Torque Ref.	It imposes on the output a value proportional to the electrical torque reference on the motor based on the nominal torque (S2.2.1)
21 = Total Torque Ref.	It imposes on the output a value proportional to the electrical torque reference of the motor after the ramp (S2.2.2)

C5.2.2 Analog outputs

C5.3.2 Analog outputs

C5.4.2 Analog outputs

C5.5.2 Analog outputs

C5.6.2 Analog outputs

C5.7.2 Analog outputs

C5.8.2 Analog outputs

.4 AO1 Offset

.8 AO2 Offset

Range: -100.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Offset setting for analog output.

C5.2.4 Digital outputs to C5.8.4 Digital outputs

It allows configuring the digital outputs of the accessory connected to the slot.

C5.2.4 Digital outputs

C5.3.4 Digital outputs

C5.4.4 Digital outputs

C5.5.4 Digital outputs

C5.6.4 Digital outputs

C5.7.4 Digital outputs

C5.8.4 Digital outputs

.1 DO1 Function

.4 DO2 Function

.7 DO3 Function

.10 DO4 Function

.13 DO5 function

.16 DO6 function

.19 DO7 function

.22 DO8 function

Range: 0 ... 34

Default: 22 (C5.2.4.1)

3 (C5.2.4.4)

2 (C5.2.4.7)

0 (Others)

Properties: Stopped

Description:

Setting of the function to be used for the digital output.

Indication	Description
0 = Off	The Digital Output will always go to the inactive status
1 = On	The Digital Output will always go to the active status

Indication	Description
2 = $N^* > N_x$	The Digital Output will go to the active status when the speed reference (N^*) is greater than the value set in N_x
3 = $N > N_x$	The Digital Output will go to the active status when the motor speed (N) is greater than the value set in N_x
4 = $N < N_y$	The Digital Output will go to the active status when the motor speed (N) is smaller than the value set in N_y
5 = $N = N^*$	The Digital Output will go to the active status when the motor speed (N) equals the speed reference value (N^*)
6 = Zero Speed	The Digital Output will go to the active status when the motor speed (N) is smaller than the value set in Zero Speed
7 = Not used	Not used
8 = $F > F_x$	The Digital Output will go to the active status when the motor frequency (F) is greater than the value set in F_x
9 = $I_s > I_x$	The Digital Output will go to the active status when the output current (I_s) is greater than the value set in I_x
10 = $I_s < I_x$	The Digital Output will go to the active status when the output current (I_s) is smaller than the value set in I_x
11 = Torque > T_x	The Digital Output will go to the active status when the motor torque (Torque) is greater than the value set in T_x
12 = Torque < T_x	The Digital Output will go to the active status when the motor torque (Torque) is smaller than the value set in T_x
13 = Hours Enabled > H_x	The Digital Output will go to the active status when the enabled hour counter is greater than the value set in H_x
14 ... 15 = Not used	Not used
16 = Local Mode	The Digital Output will go to the active status when the commands and references are defined by the Local mode
17 = Remote 1 Mode	The Digital Output will go to the active status when the commands and references are defined by the Remote 1 mode
18 = Remote 2 Mode	The Digital Output will go to the active status when the commands and references are defined by the Remote 2 mode
19 = Run	The Digital Output will go to the active status when the inverter is in the Run status
20 = Ready	The Digital Output will go to the active state when the inverter is in the Ready state, indicating that the pre-charge has been completed, the inverter is enabled and ready to receive the RUN command.
21 = STO	The Digital Output will go to the active status when the inverter is in the STO status
22 = No Fault	The Digital Output will go to the active status when the inverter does not have a fault acting
23 = With Fault	The Digital Output will go to the active status when any fault acts on the inverter
24 = No Alarm	The Digital Output will go to the active status when the inverter is not indicating an alarm
25 = No Fault and Alarm	The Digital Output will go to the active status when a fault is not acting and is not indicating an alarm in the inverter
26 = Network	The Digital Output will go to the active status when the command received via Network is active
27 = SoftPLC	The Digital Output will go to the active status when the command received via SoftPLC is active
28 = Forward Direction	The Digital Output will go to the active state when the inverter is running in the forward direction
29 = Ride-Through	The Digital Output will go to the active status when the Ride-Through function is acting
30 = Pre-Charge OK	The Digital Output will go into the active state when the Pre-charge function indicates that it has been successfully executed
31 = Ready to start	The Digital Output will go to the active state when the inverter has completed the pre-charge and without a RUN command.
32 = Alarm/Fault 1	The Digital Output will go to the active state when the Fault or Alarm selected in parameter C5.9.11 is active.
33 = Alarm/Fault 2	The Digital Output will go to the active state when the Fault or Alarm selected in parameter C5.9.12 is active.
34 = Alarm/Fault 3	The Digital Output will go to the active state when the Fault or Alarm selected in parameter C5.9.13 is active.

C CONFIGURATIONS

C5.2.5 Encoder to C5.8.5 Encoder

It allows configuring the encoder accessory connected to the slot.

C5.2.5 Encoder

C5.3.5 Encoder

C5.4.5 Encoder

C5.5.5 Encoder

C5.6.5 Encoder

C5.7.5 Encoder

C5.8.5 Encoder

.1 Number of pulses

Range: 1 ... 65535 ppr

Default: 1024 ppr

Properties: Stopped

Description:

Setting of the number of pulses that the connected encoder generates during one complete revolution.

C5.2.5 Encoder

C5.3.5 Encoder

C5.4.5 Encoder

C5.5.5 Encoder

C5.6.5 Encoder

C5.7.5 Encoder

C5.8.5 Encoder

.2 Settings

Range: 0 ... 7 Bit

Default: 0

Properties:

Description:

It allows to configure the broken cable detection, zero search function, and encoder signal direction.

Bit	Value/Description
Bit 0 ... 1 Broken Cable A	Allows configuring fault action and alarm generation if an encoder cable break is detected. Refer to the User Manual for details on the technique used to detect a broken cable. 0 = Fault: The Inverter will generate a fault if a broken encoder cable is detected 1 = Alarm: The Inverter will indicate an alarm if a broken encoder cable is detected 2 = Inactive: The broken cable detection is disabled
Bit 2 ... 3 Broken Cable B	Allows configuring fault action and alarm generation if an encoder cable break is detected. Refer to the User Manual for details on the technique used to detect a broken cable. 0 = Fault: The Inverter will generate a fault if a broken encoder cable is detected 1 = Alarm: The Inverter will indicate an alarm if a broken encoder cable is detected 2 = Inactive: The broken cable detection is disabled
Bit 4 ... 5 Broken Cable Z	Allows configuring fault action and alarm generation if an encoder cable break is detected. Refer to the User Manual for details on the technique used to detect a broken cable. 0 = Fault: The Inverter will generate a fault if a broken encoder cable is detected 1 = Alarm: The Inverter will indicate an alarm if a broken encoder cable is detected 2 = Inactive: The broken cable detection is disabled
Bit 6 Search Zero	It allows starting the execution of the search zero function. When the search zero function is activated, the number of revolutions and the fraction of revolution measured will be zeroed at the next occurrence of a pulse in the encoder Z signal. This bit will be changed to 0 after the function has been completed. 0 = Disabled: Function disabled 1 = Enabled: Function enabled
Bit 7 Signal Direction	It allows selecting the sequence of signals A and B that represent the forward direction of rotation 0 = A/B: Forward direction when rising edge of A occurs before the rising edge of B 1 = B/A: Forward direction when rising edge of B occurs before the rising edge of A

C5.2.6 Temperatures to C5.8.6 Temperatures

It allows configuring the temperature accessory connected to the slot.

C5.2.6 Temperatures

C5.3.6 Temperatures

C5.4.6 Temperatures

C5.5.6 Temperatures

C5.6.6 Temperatures

C5.7.6 Temperatures

C5.8.6 Temperatures

.1 Sensor type

Range: 0 ... 3 **Default: 0**

Properties: Stopped

Description:

It sets the sensor type that will be connected to the accessory.



NOTE!

Individual selection by sensor is not possible. All sensors connected to the same accessory must be of the same type.

Indication	Description
0 = PT100	PT100 Sensor
1 = PT1000	PT1000 Sensor
2 = Single PTC	Single PTC Sensor
3 = Triple PTC	Triple PTC Sensor

C5.2.6 Temperatures

C5.3.6 Temperatures

C5.4.6 Temperatures

C5.5.6 Temperatures

C5.6.6 Temperatures

C5.7.6 Temperatures

C5.8.6 Temperatures

.2 Overtemperature config.

Range: 0 ... 11 Bit **Default: 0**

Properties: Stopped

Description:

It enables the overtemperature faults for each temperature sensor.

C CONFIGURATIONS

Bit	Value/Description
Bit 0 ... 1 S1 Sensor F/A	It enables the overtemperature faults for temperature sensor 1. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Alarm and Fault: Alarm and fault enabled 3 = Inactive: Faults and alarms disabled
Bit 2 ... 3 S2 Sensor F/A	It enables the overtemperature faults for temperature sensor 2. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Alarm and Fault: Alarm and fault enabled 3 = Inactive: Faults and alarms disabled
Bit 4 ... 5 S3 Sensor F/A	It enables the overtemperature faults for temperature sensor 3. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Alarm and Fault: Alarm and fault enabled 3 = Inactive: Faults and alarms disabled
Bit 6 ... 7 S4 Sensor F/A	It enables the overtemperature faults for temperature sensor 4. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Alarm and Fault: Alarm and fault enabled 3 = Inactive: Faults and alarms disabled
Bit 8 ... 9 S5 Sensor F/A	It enables the overtemperature faults for temperature sensor 5. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Alarm and Fault: Alarm and fault enabled 3 = Inactive: Faults and alarms disabled
Bit 10 ... 11 S6 Sensor F/A	It enables the overtemperature faults for temperature sensor 6. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Alarm and Fault: Alarm and fault enabled 3 = Inactive: Faults and alarms disabled

C5.2.6 Temperatures

C5.3.6 Temperatures

C5.4.6 Temperatures

C5.5.6 Temperatures

C5.6.6 Temperatures

C5.7.6 Temperatures

C5.8.6 Temperatures

.3 Measurement error config.

Range:	0 ... 11 Bit	Default: 0
Properties:	Stopped	

Description:

It enables measurement error faults (broken sensor cable, short-circuit sensor) for each temperature sensor.



NOTE!

Faults and alarms will occur when the temperature read on the sensors is less than or equal to -20 °C during a 5 minute interval. Resetting of faults and alarms is enabled for temperature values greater than -15 °C.

Bit	Value/Description
Bit 0 ... 1 S1 Sensor F/A	It enables measurement error faults in the temperature sensor 1. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 2 ... 3 S2 Sensor F/A	It enables measurement error faults of temperature sensor 2. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 4 ... 5 S3 Sensor F/A	It enables measurement error faults of temperature sensor 3. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 6 ... 7 S4 Sensor F/A	It enables measurement error faults of temperature sensor 4. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 8 ... 9 S5 Sensor F/A	It enables error faults in the measurement of temperature sensor 5. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 10 ... 11 S6 Sensor F/A	It enables error faults in the measurement of temperature sensor 6. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled

C5.2.6 Temperatures**C5.3.6 Temperatures****C5.4.6 Temperatures****C5.5.6 Temperatures****C5.6.6 Temperatures****C5.7.6 Temperatures****C5.8.6 Temperatures****.4 Sensor 1 Temp. setpoint****.5 Sensor 2 Temp. setpoint****.6 Sensor 3 Temp. setpoint****.7 Sensor 4 Temp. setpoint****.8 Sensor 5 Temp. setpoint****.9 Sensor 6 temp. setpoint****Range:** -100.0 ... 250.0 °C**Default:** 0.0 °C**Properties:** Stopped**Description:**

It allows to configure the sensor overtemperature fault setpoint.

C5.3 Slot B

It allows viewing the status of the configuration parameters of the Slot.

C5.4 Slot C

It allows viewing the status of the configuration parameters of the Slot.

C5.5 Slot D

It allows viewing the status of the configuration parameters of the Slot.

C5.6 Slot E

It allows viewing the status of the configuration parameters of the Slot.

C CONFIGURATIONS

C5.7 Slot F

It allows viewing the status of the configuration parameters of the Slot.

C5.8 Slot G

It allows viewing the status of the configuration parameters of the Slot.

C5.9 DO operation levels

It allows viewing and configuring the operation conditions of the digital outputs (DOs).

C5.9 DO operation levels		
C5.9.1 Fx frequency		
Range:	0.0 ... 300.0 Hz	Default: 4.0 Hz
Properties:		

Description:

It allows viewing and setting the frequency level (Fx) used in function ($F > F_x$) for Digital Outputs.

C5.9 DO operation levels		
C5.9.2 Fx hysteresis		
Range:	0.0 ... 15.0 Hz	Default: 2.0 Hz
Properties:		

Description:

It allows viewing and setting the frequency hysteresis level used in function ($F > F_x$) for Digital Outputs.

C5.9 DO operation levels		
C5.9.3 Nx/Ny hysteresis		
Range:	0 ... 900 rpm	Default: 18 rpm
Properties:		

Description:

It allows viewing and setting the speed hysteresis level used in functions ($N^* > N_x$), ($N > N_x$), ($N < N_y$) and ($N > N_x$ and $N_t > N_x$) for Digital Outputs.

C5.9 DO operation levels		
C5.9.4 Nx speed		
Range:	0 ... 30000 rpm	Default: 120 rpm
Properties:		

Description:

It allows viewing and setting the speed level (N_x) used in function ($N > N_x$) for Digital Outputs.

C5.9 DO operation levels		
C5.9.5 Ny speed		
Range:	0 ... 30000 rpm	Default: 1800 rpm
Properties:		

Description:

It allows viewing and setting the speed level (N_y) used in function ($N < N_y$) for Digital Outputs.

C5.9 DO operation levels**C5.9.6 Ix current**

Range:	0.0 ... 200.0 %	Default: 100.0 %
Properties:		

Description:

It allows viewing and setting the current level (Ix) used in functions ($I > I_x$) and ($I < I_x$) for Digital Outputs.

C5.9 DO operation levels**C5.9.8 N = N* Band**

Range:	0 ... 30000 rpm	Default: 18 rpm
Properties:		

Description:

It allows viewing and setting the speed range within which the reference and speed will be considered to be at the same value. Used in function ($N^* = N$) for Digital Outputs.

C5.9 DO operation levels**C5.9.9 Tx torque**

Range:	0.0 ... 200.0 %	Default: 100.0 %
Properties:		

Description:

It allows viewing and setting the torque level (Tx) used in functions ($T > T_x$) and ($T < T_x$) for Digital Outputs.

C5.9 DO operation levels**C5.9.10 Hx hours**

Range:	0 ... 65536 h	Default: 4320 h
Properties:		

Description:

It allows viewing and setting the number of hours (Hx) used in function (Hours enabled $> H_x$) for Digital Outputs.

C5.9 DO operation levels**C5.9.11 Alarm/Fault 1**

Range:	0 ... 9999	Default: 0
Properties:		

Description:

Selects Fault or Alarm used in the function (Alarm/Fault 1) for Digital Outputs. If set to 0, the Digital Output configured for the function (Alarm/Fault 1) will remain permanently inactive.

C5.9 DO operation levels**C5.9.12 Alarm/Fault 2**

Range:	0 ... 9999	Default: 0
Properties:		

Description:

Selects Fault or Alarm used in the function (Alarm/Fault 2) for Digital Outputs. If set to 0, the Digital Output configured for the function (Alarm/Fault 2) will remain permanently inactive.

C5.9 DO operation levels**C5.9.13 Alarm/Fault 3**

Range:	0 ... 9999	Default: 0
Properties:		

C CONFIGURATIONS

Description:

Selects Fault or Alarm used in the function (Alarm/Fault 3) for Digital Outputs. If set to 0, the Digital Output configured for the function (Alarm/Fault 3) will remain permanently inactive.

C5.10 DOs delay

It allows setting a delay in the change of state of the digital outputs.

When the timing function is enabled, and the digital output function source undergoes a transition, the digital output will be enabled/disabled according to the time set in the timer.

Figure 9.44 on page 9-90 illustrates this behavior.




Figure 9.44: Example of digital output timer actuation



NOTE!

If more than one timer is set for the same digital output, only the first timer will actuate.

C5.10 DOs delay

C5.10.1 Timer 1 DO

C5.10.4 Timer 2 DO

C5.10.7 Timer 3 DO

Range: 0 ... 58

Default: 0

Properties:

Description:

It defines on which digital output the timer will be used. The options are shown in Table 9.58 on page 9-90.

Table 9.58: Selection of Digital Outputs from Slots X and A...G to set the timer

Digital Output Options for Slots X and A...G								
Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
DO1	X-1 (1)	A-1 (3)	B-1 (11)	C-1 (19)	D-1 (27)	E-1 (35)	F-1 (43)	G-1 (51)
DO2	X-2 (2)	A-2 (4)	B-2 (12)	C-2 (20)	D-2 (28)	E-2 (36)	F-2 (44)	G-2 (52)
DO3	—	A-3 (5)	B-3 (13)	C-3 (21)	D-3 (29)	E-3 (37)	F-3 (45)	G-3 (53)
DO4	—	A-4 (6)	B-4 (14)	C-4 (22)	D-4 (30)	E-4 (38)	F-4 (46)	G-4 (54)
DO5	—	A-5 (7)	B-5 (15)	C-5 (23)	D-5 (31)	E-5 (39)	F-5 (47)	G-5 (55)
DO6	—	A-6 (8)	B-6 (16)	C-6 (24)	D-6 (32)	E-6 (40)	F-6 (48)	G-6 (56)
DO7	—	A-7 (9)	B-7 (17)	C-7 (25)	D-7 (33)	E-7 (41)	F-7 (49)	G-7 (57)
DO8	—	A-8 (10)	B-8 (18)	C-8 (26)	D-8 (34)	E-8 (42)	F-8 (50)	G-8 (58)

C5.10 DOs delay**C5.10.2 T1 Delay ON****C5.10.5 T2 Delay ON****C5.10.8 T3 Delay ON****Range:** 0.0 ... 300.0 s**Default:** 0.0 s**Properties:****Description:**

It defines the time in seconds for activation of the digital output after a positive transition of the command (depending on the function of the digital output).

After a positive command transition, for the programmed output to be enabled, the command must remain active for at least the time set in this parameter. Otherwise, the timer will be reset and the output will not be enabled. See Figure 9.44 on page 9-90.

C5.10 DOs delay**C5.10.3 T1 Delay OFF****C5.10.6 T2 Delay OFF****C5.10.9 T3 Delay OFF****Range:** 0.0 ... 300.0 s**Default:** 0.0 s**Properties:****Description:**

It defines the time in seconds for disabling the digital output after a negative transition of the command (depending on the function of the digital output).

After a negative transition of the command, for the programmed output to be disabled, the command must remain inactive for at least the time set in this parameter. Otherwise, the timer will be reset and the output will remain enabled. See Figure 9.44 on page 9-90.

C5.11 Control board

Allows you to configure the analog outputs and inputs of the control board.

C5.11.1 Analog inputs**C5.11.1 Analog inputs****C5.11.1.1 AI1 function****C5.11.1.4 AI2 function****Range:** 0 ... 3**Default:** 0**Properties:****Description:**

Selects the function to be used by the analog input.

Indication	Description
0 = Not used	
1 = Torque reference	
2 = Limit current	
3 = Field current	

C CONFIGURATIONS

C5.11.1 Analog inputs

C5.11.1.2 AI1 Gain

C5.11.1.5 AI2 Gain

Range: 0.000 ... 9.999

Default: 1.000

Properties:

Description:

Gain setting for analog input.

C5.11.1 Analog inputs

C5.11.1.3 AI1 Offset

C5.11.1.6 AI2 Offset

Range: -100.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Offset setting for analog input.

C5.11.2 Analog outputs

C5.11.2 Analog outputs

C5.11.2.1 AO1 function

C5.11.2.4 AO2 function

C5.11.2.7 AO3 function

C5.11.2.10 AO4 function

Range: 0 ... 254

Default: 0

Properties:

Description:

Selects the function to be used by the analog output.

Indication	Description
0 = 0 V	Constant 0 V
1 = 5 V	Constant 5 V
2 = -5 V	Constant -5 V
3 = 10 V	Constant 10 V
4 = -10 V	Constant -10 V
5 = Modulation index	Modulation index
6 = Frequency	Inverter output frequency
7 = Iout	Output current amplitude
8 = Ramp	Ramp output
12 = Speed	Motor speed
23 = Lowest VDC	Lowest cell DC voltage
24 = Highest VDC	Highest cell DC voltage
34 = Ib	Input current, phase B
35 = Ic	Input current, phase C
42 = Vab	Input line-to-line voltage AB
43 = Vbc	Input line-to-line voltage BC
45 = Ixt	Motor thermal overload protection value
86 = Pout (kW)	Output active power
88 = Pout (kVAr)	Output reactive power
89 = Pout (kVA)	Output apparent power
90 = FPout	Output power factor
91 = Torque	Motor torque
93 = Pin (kW)	Input active power
94 = Pin (kVAr)	Input reactive power

Indication	Description
95 = Pin (kVA)	Input apparent power
96 = FPin	Input power factor
100 = Vout RMS	Output voltage RMS value
101 = Vin RMS	Input voltage RMS value
107 = Iout RMS	Output current RMS value
111 = Iin RMS	Input current RMS value

C5.11.2 Analog outputs**C5.11.2.2 AO1 gain****C5.11.2.5 AO2 gain****C5.11.2.8 AO3 gain****C5.11.2.11 AO4 gain**

Range: 0.000 ... 9.999 **Default:** 1.000

Properties:

Description:

Gain setting for analog output.

C5.11.2 Analog outputs**C5.11.2.3 AO1 offset****C5.11.2.6 AO2 offset****C5.11.2.9 AO3 offset****C5.11.2.12 AO3 offset**

Range: -100.00 ... 100.00 % **Default:** 0.00 %

Properties:

Description:

Offset setting for analog output.

C5.11.4 Encoder

Allows configuring the encoder connected to the control board.

C5.11.4.1 Absolute

The encoder baud rate is limited by the cable length in the SSI encoder connection and/or by the presence of other transducers on the same communication line.

The longer the cable between the interface board and the encoder, the lower the baud rate must be.

C5.11.4.1 Absolute**C5.11.4.1.1 Measurement offset**

Range: 0.0 ... 360.0 ° **Default:** 0.0 °

Properties:

Description:

Offset of the motor angular position measurement.

C5.11.4.1 Absolute**C5.11.4.1.2 Configuration**

Range: 0 ... 10 Bit **Default:** 0

Properties: Stopped

C CONFIGURATIONS

Description:
Absolute encoder SSI interface configuration.

Bit	Value/Description
Bit 0 ... 2 Clock frequency	Sets the communication clock frequency. 0 = 100 kHz 1 = 150 kHz 2 = 200 kHz 3 = 250 kHz 4 = 500 kHz
Bit 3 ... 6 Data bits	Sets the number of bits in the data packets. 0 = 8 bits 1 = 9 bits 2 = 10 bits 3 = 11 bits 4 = 12 bits 5 = 13 bits 6 = 14 bits 7 = 15 bits 8 = 16 bits 9 = 17 bits 10 = 18 bits 11 = 19 bits 12 = 20 bits
Bit 7 ... 8 Parity	Sets the telegram parity check. 0 = None 1 = Even 2 = Odd
Bit 9 Encoding	Sets the data packet encoding. 0 = Binary 1 = Gray
Bit 10 Direction of rotation	Defines the rotation direction of the speed sensor. 0 = Reverse: Sensor installed at the rear of the load 1 = Direct: Sensor installed at the rear of the motor

C5.11.4.2 Incremental

Encoder accessory for the control board expansion slot. For encoder-based vector control, this accessory must be used.




Figure 9.45: Encoder accessory for speed control (ACCE-ENC item 16584196)

C5.11.4.2 Incremental		
C5.11.4.2.1 Number of pulses		
Range:	1 ... 65535 ppr	Default: 1024 ppr
Properties:	Stopped	

Description:
Setting of the number of pulses that the connected encoder generates during one complete revolution.

C5.11.4.2 Incremental**C5.11.4.2.2 Settings**

Range:	0 ... 3 Bit	Default: 8
Properties:	Stopped	

Description:

It allows to configure the broken cable detection, zero search function, and encoder signal direction.

Bit	Value/Description
Bit 0 ... 1 Broken cable	Allows configuring fault action and alarm generation if an encoder cable break is detected. Refer to the User Manual for details on the technique used to detect a broken cable. 0 = Fault: The Inverter will generate a fault if a broken encoder cable is detected 1 = Alarm: The Inverter will indicate an alarm if a broken encoder cable is detected 2 = Inactive: The broken cable detection is disabled
Bit 2 Not used	Not used
Bit 3 Direction of rotation	Defines the rotation direction of the speed sensor. 0 = Reverse: Sensor installed at the rear of the load 1 = Direct: Sensor installed at the rear of the motor

C6 RAMPS

It allows setting the acceleration and deceleration times for the speed or torque reference, defining the command selection between “1st Ramp” and “2nd Ramp” and selecting the desired ramp profile.

C6.1 Speed control

Setting of the speed ramps.

C6.1 Speed control**C6.1.1 Acceleration time**

Range:	0.1 ... 1999.9 s	Default: 100.0 s
Properties:		

Description:

It sets the “1st Ramp” acceleration time for the speed reference. This value corresponds to the time that the ramp varies from 0 rpm to the maximum value C4.3.1.1.2.

C6.1 Speed control**C6.1.2 Deceleration time**

Range:	0.1 ... 1999.9 s	Default: 180.0 s
Properties:		

Description:

It sets the “1st Ramp” deceleration time for the speed reference. This value corresponds to the time that the ramp varies from the maximum value C4.3.1.1.2 to 0 rpm.

C6.1 Speed control**C6.1.3 1st/2nd ramp selection**

Range:	0 ... 9	Default: 0
Properties:	Stopped	

C CONFIGURATIONS

Description:

It sets the source of the command for acceleration ramps that will select between the “1st Ramp” and the “2nd Ramp”.

- “1st Ramp” means that the acceleration and deceleration ramps are following the values set in C6.1.1 and C6.1.2 respectively.
- “2nd Ramp” means that the acceleration and deceleration ramps are following the values set in C6.1.4 and C6.1.5 respectively.




Figure 9.46: Command operation 1st/2nd ramp

Indication	Description
0 = 1st Ramp	Fixed at 1st Ramp
1 = 2nd Ramp	Fixed at 2nd Ramp
2 = Serial	Change via 2nd Ramp command of the RS-485 Serial Control Word
3 = Not used	Not used
4 = CAN/CO/DN	Change via 2nd Ramp command of the CAN/CANop/DNet Control Word
5 = SoftPLC	Change via SoftPLC function command
6 = Not used	Not used
7 = Ethernet	Change via 2nd Ramp command of the Ethernet Control Word
8 = DI Ramp Selection	Change via digital input command chosen by the user The digital input can be set in C4.2.3.10
9 = Not used	Not used

C6.1 Speed control

C6.1.4 2nd ramp acceleration time

Range: 0.1 ... 1999.9 s

Default: 100.0 s

Properties:

Description:

It sets the “2nd ramp” acceleration time for the speed reference. This value corresponds to the time that the ramp varies from 0 rpm to the maximum value C4.3.1.1.2.

C6.1 Speed control

C6.1.5 2nd ramp deceleration time

Range: 0.1 ... 1999.9 s

Default: 180.0 s

Properties:

Description:

It sets the “2nd ramp” deceleration time for the speed reference. This value corresponds to the time that the ramp varies from the maximum value C4.3.1.1.2 to 0 rpm.

C6.1 Speed control

C6.1.6 Quick stop time

Range:	0.1 ... 999.9 s	Default: 5.0 s
Properties:		

Description:
It sets the time to linearly decelerate from the maximum speed (defined in C4.3.1.1.2) to 0 when the “Quick Stop” command is activated.

C6.1 Speed control

C6.1.7 Ramp type

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:
It sets the reference ramp type: Linear or “S” Curve.

Indication	Description
0 = Linear	It selects the linear profile for the motor acceleration and deceleration ramps
1 = S Ramp	It selects the “S” profile for the motor acceleration and deceleration ramps The “S” ramp reduces mechanical shock during acceleration/deceleration




Figure 9.47: “S” Curve or Linear

C6.2 Torque control

It sets the acceleration and deceleration times of the torque reference signal.

C6.2 Torque control

C6.2.1 Increment ramp

Range:	0.1 ... 999.9 s	Default: 20.0 s
Properties:		

Description:
It sets the acceleration time for the torque reference ramp. This value corresponds to the time that the ramp varies from the minimum value C4.3.3.3 to the maximum value C4.3.3.2.

C6.2 Torque control

C6.2.2 Decrement ramp

Range:	0.1 ... 999.9 s	Default: 20.0 s
Properties:		

C CONFIGURATIONS

Description:

It sets the deceleration time for the torque reference ramp. This value corresponds to the time that the ramp varies from the maximum value C4.3.3.2 to the minimum value C4.3.3.3.

C7 PROTECTIONS

It allows configuring the operation, levels and tripping time of the MVW and motor protections.

C7.1 Power supply

It allows configuring the protections related to the power supply voltage.

C7.1 Power supply

C7.1.1 Protection configuration

Range: 0 ... 1

Default: 1

Properties:

Description:

Enables falha de falta de fase de rede.

Indication	Description
0 = Disabled	Protection disabled
1 = Enabled	Protection enabled The phase loss detector is authorized to operate when: 1. Inverter enabled. 2. Precharge complete.

C7.1 Power supply

C7.1.2 Protection delay time

Range: 0.1 ... 60.0 s

Default: 0.1 s

Properties:

Description:

Defines the minimum time the power supply network must remain in an anomalous condition for the fault to be considered valid (F0303, F0304 and F0305).

C7.1 Power supply

C7.1.3 Phase imbalance level

C7.1.4 Overvoltage level

C7.1.5 Undervoltage level

Range: 10.0 ... 70.0 %

Default: 10.0 % (C7.1.3)

117.0 % (C7.1.4)

70.0 % (C7.1.5)

Properties:

Description:

It sets the protection tripping level.

C7.2 Ground fault

It allows setting the Ground Fault protection.

C7.2 Ground fault**C7.2.1 Maximum operating time****Range:** 0.5 ... 60.0 s**Default:** 0.5 s**Properties:****Description:**

Maximum time that the inverter will continue to operate after the value of S2.3.17 becomes greater than the value of C7.2.2.

If the value equal to 60.0 s is programmed, F0316 will no longer be indicated.

C7.2 Ground fault**C7.2.2 Voltage leakage alarm level****C7.2.3 Voltage leakage fault level****Range:** 5.0 ... 50.0 %**Default:** 25.0 % (C7.2.2)

50.0 % (C7.2.3)

Properties:**Description:**

Defines the comparison levels against S2.3.17 for indications A0315 and F0316.

C7.2 Ground fault**C7.2.4 Current leakage fault level****Range:** 1 ... 100 %**Default:** 25 %**Properties:****Description:**

Defines the comparison level against the sum (filtered with a 2 ms time constant) of the three inverter output currents to indicate a ground fault.

The fault current level is expressed as a percentage of the inverter rated current.

See F0317.

C7.3 Motor current

Allows configuring the motor overcurrent protection.

C7.3 Motor current**C7.3.1 Current imbalance****Range:** 0 ... 1**Default:** 0**Properties:****Description:**

Defines whether the function for detecting unbalanced motor current will be active or not. This function will be responsible for generating fault F076.

This function will be released to act when the conditions below are simultaneously satisfied for more than 2 seconds:

1. C7.3.1 = Active.
2. Inverter disabled.
3. Speed reference above 3 %.
4. $|I_u - I_v|$ or $|I_u - I_w|$ or $|I_v - I_w| > 0.125 \times C2.2.1.2$.

C CONFIGURATIONS

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function

C7.3 Motor current

C7.3.2 Motor overcurrent

Range:	0 ... 1	Default: 1
Properties:		

Description:

Setting instantaneous overcurrent protection by software.

Indication	Description
0 = Inactive	Protection inactive
1 = Active	If the current in the motor reaches the set level, the fault (F0073, F0074 or F0075) will actuate, disabling the inverter

C7.4 Motor overload fault

It allows setting the Motor Overload fault.

C7.4 Motor overload fault

C7.4.1 Enable fault

Range:	0 ... 3	Default: 1
Properties:	Stopped	

Description:

It enables the fault and alarm of the motor overload function.

Indication	Description
0 = Disable	Overload fault is disabled. No faults or alarms will be generated for the motor operation in the overload condition
1 = Fault and Alarm	The inverter will display an alarm (A0046) when the motor overload reaches the level programmed in C7.4.2, and the fault will trip (F0072) when the motor overcurrent reaches the value set in the overload fault. Once the fault activates, the inverter will be disabled
2 = Fault	The fault will be activated (F0072) without generating alarms, when the motor overload reaches the level set in the overload fault and the inverter will be disabled
3 = Alarm	Only alarm (A0046) will be generated when the motor current reaches the value programmed in C7.4.2; the inverter will continue operating

C7.4 Motor overload fault

C7.4.2 Alarm level

Range:	10 ... 100 %	Default: 70 %
Properties:	Stopped	

Description:

It defines the motor overload fault alarm tripping level (A0046). It is expressed as a percentage of the Overload time limit value.

It will only be effective when C7.4.1 is set to 1 (Fault/Alarm) or 3 (Alarm).

C7.4 Motor overload fault

C7.4.3 Factor @ 100% Rat. speed

Range:	0 ... 200 %	Default: 100 %
Properties:		

Description:

It sets the value of the motor current used for the motor overload fault with 100 % of the rated speed. The full scale of this parameter is the rated motor current C2.1.5.

C7.4 Motor overload fault		
C7.4.4 Factor @ 50% Rat. speed		
Range:	0 ... 200 %	Default: 86 %
Properties:		

Description:

It sets the value of the motor current used for the motor overload fault with 50 % of the rated speed. The full scale of this parameter is the rated motor current C2.1.5.

C7.4 Motor overload fault		
C7.4.5 Factor @ 5% Rat, Speed		
Range:	0 ... 200 %	Default: 62 %
Properties:		

Description:

It sets the value of the motor current used for the motor overload fault with 5 % of the rated speed. The full scale of this parameter is the rated motor current C2.1.5.

The motor overload current is the current value at which the inverter will understand that the motor is operating under overload, and it is given as a function of the speed being applied to the motor. Parameters C7.4.3, C7.4.4 and C7.4.5 are the three points used to form this curve, as shown in Figure 9.48 on page 9-101.

By adjusting the overload current curve, it is possible to set an overload value that varies according to the motor operating speed (this is the factory default setting), improving the fault for self-ventilated motors. It is also possible to set a constant overload level for any speed applied to the motor for motors with independent ventilation.




Figure 9.48: Overload fault levels



NOTE!

The greater the difference between the motor current and the overload current, the faster the fault is activated F0072.

C CONFIGURATIONS

C7.5 Over/Undertemperature

It allows configuring the Overtemperature and Undertemperature faults.

C7.5 Over/Undertemperature

C7.5.1 Configuration

Range:	0 ... 5 Bit	Default: 0
Properties:	Stopped	

Description:

It configure the inverter overtemperature and undertemperature faults.

By default, both fault and alarm are enabled. Also, overtemperature faults cannot be disabled.

Bit	Value/Description
Bit 0 Not used	Not used
Bit 1 Not used	Not used
Bit 2 Not used	Not used
Bit 3 Cont. Circ. Overtemp.	Enables the control overtemperature faults. 0 = Alarm and Fault: Overtemperature fault and alarm enabled 1 = Fault: Only overtemperature fault enabled
Bit 4 ... 5 Undertemperature	It enables the undertemperature faults. 0 = Alarm and Fault: Undertemperature fault and alarm enabled 1 = Fault: Only undertemperature fault enabled 2 = Alarm: Only undertemperature alarm enabled 3 = Disabled: Undertemperature fault and alarm disabled

C7.6 DC link

Allows you to configure the fault of the inverter's DC link undervoltage.

C7.6 DC link

C7.6.1 Undervoltage level

Range:	50 ... 100 %	Default: 70 %
Properties:		

Description:

Sets the level for the DC link undervoltage fault to occur.

When the ride-through feature is enabled (see C3.9.1.1), this is the level for ride-through entry.

C7.7 Motor overspeed

It allows setting the Motor Overspeed fault.

C7.7 Motor overspeed

C7.7.1 Maximum overspeed level

Range:	0 ... 100 %	Default: 10 %
Properties:	Stopped	

Description:

It sets the highest speed value the motor can operate at, and should be set as a percentage of the maximum speed limit. The maximum speed limit can be set in C4.3.1.1.2.

When the effective speed exceeds the value of C4.3.1.1.2 + C7.7.1 for more than 20 ms, the MVW will disable the PWM pulses and indicate fault (F0112).

If you want to disable this function, set C7.7.1 = 100 %.

C7.9 Fault Auto-Reset

It allows configuring the inverter Auto-Reset function.

C7.9 Fault Auto-Reset

C7.9.1 Time

Range:	0 ... 3600 s	Default: 0 s
Properties:		

Description:

It sets the time value for an automatic reset when a fault occurs.

After the auto-reset is performed, if the same fault actuates again for three consecutive times, the auto-reset function will be inhibited. The actuation of a fault is considered as recurrent if this same fault actuates again within 30 seconds after the auto-reset is performed. Therefore, if a fault operates four consecutive times, the inverter will remain disabled (general disable) and the fault will continue to be actuated.

If $C7.9.1 \leq 2$, no auto-reset will occur.

C7.10 External fault/Alarm

It allows configuring the External Fault and Alarm functions activated via digital input.

C7.10 External fault/Alarm

C7.10.1 External alarm DI

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

Enables use and defines the digital input that will be used for the No External Alarm function.

When a transition from 1 to 0 occurs in the digital input programmed for the function No External Alarm, alarm A2331 will be indicated. On transition from 0 to 1 on the programmed digital input, the alarm will be cleared. The motor continues to run normally, regardless of the status of the digital input.

The options are shown in the Table 9.48 on page 9-72.

C7.10 External fault/Alarm

C7.10.2 External fault DI

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used to disable the External Fault function. Table 9.48 on page 9-72 shows the options.

When a transition from 1 to 0 occurs on the digital input programmed for External Fault, the inverter goes into fault indicating fault F2332 as shown in Figure 9.49 on page 9-104.




Figure 9.49: External fault via digital input

C7.11 Thermal management

The thermal management function is a set of faults and actions that the inverter performs as a function of measured and estimated temperatures to protect the equipment integrity and functionality.

C7.11 Thermal management

C7.11.14 Thermal protection relay 1

C7.11.15 Thermal protection relay 2

C7.11.16 Thermal protection relay 3

C7.11.17 Thermal protection relay 4

C7.11.18 Thermal protection relay 5

C7.11.19 Thermal protection relay 6

Range: 0 ... 13 Bit

Default: 1021

Properties:

Description:

This parameter enables communication with the thermal protection relay and defines the inverter action upon detecting overtemperature or sensor fault.

If a channel temperature reaches the limit configured in the relay, the inverter will act according to the programming (e.g., disable the motor). The system indicates the fault, preventing overheating that could degrade insulation materials, damage the equipment, or cause accidents.

These relays are an integral part of the inverter protection system, playing a fundamental role in the safety and reliability of the electrical installation.

The module serial communication must be configured with the following parameters:

- Baudrate: 9600 bps
- Address: 1, 2, 3, 4, 5 or 6
- Parity: Even
- Stop bits: 1



ATTENTION!

During the use of functions **PRG** (programming) and **VIS** (viewing) of the relay, data exchange is interrupted, which may cause a time-out error in the communication with the inverter.



ATTENTION!

In case of sensor break (open circuit) in a temperature channel, the reading will indicate the full scale value.

Bit	Value/Description
Bit 0 Communication	Enables communication with the thermal protection relay. 0 = Disable: Communication with relay disabled 1 = Enable: Communication enabled. In case of overtemperature, the inverter will protect the equipment according to the fault configuration of the respective channel.
Bit 1 Communication action	0 = Fault trip: In the event of a communication loss, the inverter trips to fault and a fault reset is required to return to normal operation. 1 = Alarm: In case of loss of communication, it signals an alarm.
Bit 2 CH1 faults	0 = Inactive: Overtemperature protection inactive 1 = Active: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 3 CH2 faults	0 = Inactive: Overtemperature protection inactive 1 = Active: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 4 CH3 faults	0 = Inactive: Overtemperature protection inactive 1 = Active: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 5 CH4 faults	0 = Inactive: Overtemperature protection inactive 1 = Active: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 6 CH5 faults	0 = Inactive: Overtemperature protection inactive 1 = Active: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 7 CH6 faults	0 = Inactive: Overtemperature protection inactive 1 = Active: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 8 CH7 faults	0 = Inactive: Overtemperature protection inactive 1 = Active: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 9 CH8 faults	0 = Inactive: Overtemperature protection inactive 1 = Active: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 10 ... 13 Sensor installation location	0 = General use 1 = Transformer 1 2 = Transformer 2 3 = Motor 4 = Motor windings 5 = Motor bearings

C7.13 Input transformer




Figure 9.50: Sets the failure protection level in the input transformer secondary

C7.13 Input transformer

C7.13.1 Transformer 1 model offset

C7.13.3 Transformer 2 model offset

C7.13.5 Transformer 3 model offset

Range: 0.00 ... 1.00

Default: 0.09

Properties:

Description:

Adjusts the offset of the inverter input transformer model.

C CONFIGURATIONS

C7.13 Input transformer

C7.13.2 Transformer 1 model constant

C7.13.4 Transformer 2 model constant

C7.13.6 Transformer 3 model constant

Range: 0.00 ... 9.90

Default: 0.60

Properties:

Description:

Adjusts the constant of the inverter input transformer model.

C7.13 Input transformer

C7.13.7 Transformer fault protection level

Range: 0.0 ... 1.0

Default: 0.5

Properties:

Description:

Adjusts the protection level for the inverter input transformer secondary fault.

C7.13 Input transformer

C7.13.8 Transformer failure detection integrator gain

Range: 0.00 ... 99.99

Default: 0.75

Properties:

Description:

Adjusts the gain of the integrator used to detect the inverter input transformer secondary fault.

C7.13 Input transformer

C7.13.9 Transformer curve adjustment

Range: 0 ... 2

Default: 0

Properties:

Description:

Automatically adjusts the transformer protection curve parameters according to the selected option.

Indication	Description
0 = Disabled	Function inactive
1 = Offset - minimum load	Automatic adjustment of the transformer model offset parameters. This option must be used with pre-charge completed and PWM disabled, a condition in which the transformer is under the lowest possible load.
2 = Constant - maximum load	Automatic adjustment of transformer model constant parameters This option must be used with the inverter operating at nominal output power.

C7.15 Electric arc

Configures protections related to arc fault detection in the panel

C7.15 Electric arc

C7.15.1 Electric arc detection

Range: 0 ... 7 Bit

Default: 255

Properties:

Description:

Allows configuring the arc-fault detection function through the fiber-optic receivers on the CCE and CIB boards.

The corresponding fields must be configured according to the sensor used in the detection process.

Bit	Value/Description
Bit 0 Sensor A	Electric arc detection by sensor A connected to the optical fiber OPTO IN (1) (F0043) on the CCE board 0 = Disabled: Function disabled 1 = Enabled: Enabled function
Bit 1 Sensor B	Electric arc detection by sensor B connected to the optical fiber OPTO IN (2) (F0042) on the CCE board 0 = Disabled: Function disabled 1 = Enabled: Enabled function
Bit 2 Sensor C	Electric arc detection by sensor C connected to the optical fiber OPTO IN (3) (F0041) on the CCE board 0 = Disabled: Function disabled 1 = Enabled: Enabled function
Bit 3 Sensor 1	Electric arc detection by the sensor connected to the RX 26 optical fiber (F0034) of the CN1 CIB board 0 = Disabled: Function disabled 1 = Enabled: Enabled function
Bit 4 Sensor 2	Electric arc detection by the sensor connected to the RX 26 optical fiber (F0035) of the CN2 CIB board 0 = Disabled: Function disabled 1 = Enabled: Enabled function
Bit 5 Sensor 3	Electric arc detection by the sensor connected to the RX 25 optical fiber (F0036) of the CN2 CIB board 0 = Disabled: Function disabled 1 = Enabled: Enabled function
Bit 6 Sensor 4	Electric arc detection by the sensor connected to the RX 24 optical fiber (F0037) of the CN2 CIB board 0 = Disabled: Function disabled 1 = Enabled: Enabled function
Bit 7 Sensor 5	Electric arc detection by the sensor connected to the RX 23 optical fiber (F0038) of the CN2 CIB board 0 = Disabled: Function disabled 1 = Enabled: Enabled function

C7.16 History

It allows setting options related to alarm history.

C7.16 History

C7.16.1 Enable alarm hist.

Range: 0 ... 2

Default: 0

Properties:

Description:

It enables the recording of alarms in the history.

If disabled, new entries will not be saved in the product memory.



NOTE!

Viewing the history captured before this parameter was disabled remains available for viewing via HMI or reading via WPS.

Indication	Description
0 = Disabled	It indicates that the alarm history is disabled New alarms are not saved in memory and only existing entries in the history are displayed on the HMI and read by the WPS
1 = Enabled	It indicates that the alarm history is enabled
2 = Limited	It indicates that the alarm history is enabled. Alarms that occur while the inverter is under-voltage or with the power switched off will not be recorded in the alarm history.

C9 COMMUNICATIONS

It sets the MVW to exchange information via communication network.

C9.1 Communication errors

It allows setting the operation of the fault for the communication interfaces and related protocols.

C CONFIGURATIONS

C9.1.1 Master offline

Communication interruption fault with the network master.

If for some reason the communication between the product and the network master is interrupted, a communication error will be issued, an alarm or fault will be displayed on the HMI, depending on the programming of this menu.

It only occurs after the device is online.

C9.1.1 Master offline

C9.1.1.1 Mode

Range: 0 ... 2

Default: 2

Properties:

Description:

It allows configuring the fault tripping mode against interruption in the communication with the network master.

Indication	Description
0 = Inactive	Alarm and fault disabled
1 = Fault	Only fault enabled. It disables the motor
2 = Alarm	Alarm enabled. Acts as described in C9.1.1.2

C9.1.1 Master offline

C9.1.1.2 Alarm action

Range: 0 ... 4

Default: 2

Properties:

Description:

Action for offline communication alarm for any network interface - A2335, A2339, A2337, A2338, A2339, A2340, A2342, A2349 and A2350.

The actions described in this parameter are performed by writing the respective bits in the control word of the communication/interface protocol. Thus, for the commands to take effect, the equipment must be programmed to be controlled by the network interface used. This programming is done through menu C4.

Indication	Description
0 = Off	No action is taken; the equipment remains in the current status
1 = Stop by Ramp	The ramp to stop command is executed, and the motor stops according to the programmed deceleration ramp
2 = General Disable	The equipment is general disabled and the motor stops by inertia
3 = Go to R1	The equipment is commanded to the remote 1 status
4 = Go to R2	The equipment is commanded to the remote 2 status



NOTE!

The alarm action will only have a function if the error tripping mode in C9.1.1.1 is programmed for Alarm.

C9.1.2 Master idle/Prog

Network master status fault.

If there is a transition of the network master status from the operation mode (Run) to the configuration mode (Idle/Prog), a communication error will be issued, an alarm or fault will be displayed on the HMI, depending on the programming made in this menu.

It only occurs after the network master Run mode is detected. The way to detect this condition depends on the communication protocol and the network master.

C9.1.2 Master idle/Prog**C9.1.2.1 Mode****Range:** 0 ... 2**Default:** 2**Properties:****Description:**

It allows configuring the fault tripping mode when the network master is placed in programming mode (Idle/Prog).

Indication	Description
0 = Inactive	Alarm and fault disabled
1 = Fault	Only fault enabled. It disables the motor
2 = Alarm	Acts as an alarm. Action described in C9.1.2.2

C9.1.2 Master idle/Prog**C9.1.2.2 Alarm action****Range:** 0 ... 4**Default:** 2**Properties:****Description:**

Action for master alarm in programming mode (Idle/Prog) - A2341.

The actions described in this parameter are performed by writing the respective bits in the control word of the communication/interface protocol. Thus, for the commands to take effect, the equipment must be programmed to be controlled by the network interface used. This programming is done through menu C4.

Indication	Description
0 = Off	No action is taken; the equipment remains in the current status
1 = Stop by Ramp	The ramp to stop command is executed, and the motor stops according to the programmed deceleration ramp
2 = General Disable	The equipment is general disabled and the motor stops by inertia
3 = Go to R1	The equipment is commanded to the remote 1 status
4 = Go to R2	The equipment is commanded to the remote 2 status

**NOTE!**

The alarm action will only have a function if the error tripping mode in C9.1.2.1 is programmed for Alarm.

C9.2 I/O data

It sets the cyclic data exchange area of the communication networks.

C9.2.1 Reading data

It configures a set of 16-bit parameters to be read via communication network.

C9.2.1 Reading data**C9.2.1.1 Word #1**

C9.2.1.1 to C9.2.1.100

C9.2.1 Reading data**C9.2.1.100 Word #100****Range:** 0 ... 9999**Default:** 0**Properties:** Stopped

C CONFIGURATIONS

Description:

It selects the address (Net Id) of the parameter whose content should be provided in the reading area for the fieldbus interfaces (input: sent to the network master).

The size of the referenced parameter must be taken into account. If the data size is greater than 16 bits, the configuration parameter of the next programmable word must be set to the same address.

C9.2.2 Writing data

It configures a set of 16-bit parameters to be written via communication network.

C9.2.2 Writing data		
C9.2.2.1 Update delay		
Range:	0.0 ... 999.0 s	Default: 0.0 s
Properties:		

Description:

Whenever there is a transition from offline (without cyclic data) to online (with cyclic writing data), the data received via communication network (writing words) is ignored during this programmed time, remaining in the status it was before the beginning of the reception.




Figure 9.51: Delay in the update of the I/O words

C9.2.2 Writing data	
C9.2.2.2 Word #1	

C9.2.2.2 to C9.2.2.101

C9.2.2 Writing data		
C9.2.2.101 Word #100		
Range:	0 ... 9999	Default: 0
Properties:	Stopped	

Description:

It selects the address (Net Id) of the parameter whose content should be provided in the writing area for the fieldbus interfaces (output: received from the network master).

The size of the referenced parameter must be taken into account. If the data size is greater than 16 bits, the configuration parameter of the next programmable word must be set to the same address.

C9.3 Serial RS485

Configuration for the RS485 communication interface and the protocols that use this interface.

For a detailed description, refer to the MVW Modbus-RTU Communication Manual, available in electronic format.

C9.3 Serial RS485**C9.3.2 Address**

Range:	1 ... 247	Default: 1
Properties:	Stopped	

Description:

It select the address used for the serial communication.

It is necessary that each device on the network has a different address from all the others.

C9.3 Serial RS485**C9.3.3 Baud rate**

Range:	0 ... 5	Default: 1
Properties:	Stopped	

Description:

Select the desired value for the baud rate of the serial interface in bit per second. This rate must be the same for all devices connected to the network.

Indication	Description
0 = 9600 bit/s	Rate of 9600 bits per second
1 = 19200 bit/s	Rate of 19200 bits per second
2 = 38400 bit/s	Rate of 38400 bits per second
3 = 57600 bit/s	Rate of 57600 bits per second
4 = 76800 bit/s	Rate of 76800 bits per second.
5 = Not used	Not used

C9.3 Serial RS485**C9.3.4 Bytes configuration**

Range:	0 ... 5	Default: 1
Properties:	Stopped	

Description:

Select the settings for the number of data bits, parity and stop bits in the serial interface bytes. This setting must be identical for all the devices connected to the network.

Indication	Description
0 = 8-bits, no, 1	8 bits, no parity, 1 stop bit
1 = 8-bits, even, 1	8 bits, with even parity, 1 stop bit
2 = 8-bits, odd, 1	8 bits, with odd parity, 1 stop bit
3 = 8-bits, no, 2	8 bits, no parity, 2 stop bit
4 = 8-bits, even, 2	8 bits, with even parity, 2 stop bit
5 = 8-bits, odd, 2	8 bits, with odd parity, 2 stop bit

C9.3 Serial RS485**C9.3.5 RS485 Timeout**

Range:	0.0 ... 999.0 s	Default: 0.0 s
Properties:	Stopped	

Description:

Maximum time without communication.

C9.4 Ethernet

Settings for the product built-in Ethernet port.

For a detailed description, refer to the MVW Modbus TCP Communication Manual, available in electronic format.

C CONFIGURATIONS

C9.4 Ethernet

C9.4.1 IP address settings

Range:	0 ... 1	Default: 1
Properties:	Stopped	

Description:

It allows setting the IP address for the built-in Ethernet interface.

Indication	Description
0 = Parameters	The IP address, subnet mask and gateway must be set through the product parameters
1 = DHCP	It enables the DHCP function. The IP address and other network settings are received from a DHCP server via network

C9.4 Ethernet

C9.4.2 IP address

Range:	0.0.0.0 ... 255.255.255.255	Default: 192.168.0.10
Properties:	Stopped	

Description:

It allows programming the IP address of the Ethernet interface. It only takes effect if the address was set via parameters.

C9.4 Ethernet

C9.4.3 Network mask

Range:	0 ... 31	Default: 24
Properties:	Stopped	

Description:

It allows programming the subnet mask used for the Ethernet interface. It only takes effect if the address was set via parameters.

The following table shows the allowable values for CIDR and the equivalent dot-separated notation for the subnet mask:

Indication	Description
0 = Not used	Subnet mask
1 = 128.0.0.0	Subnet mask
2 = 192.0.0.0	Subnet mask
3 = 224.0.0.0	Subnet mask
4 = 240.0.0.0	Subnet mask
5 = 248.0.0.0	Subnet mask
6 = 252.0.0.0	Subnet mask
7 = 254.0.0.0	Subnet mask
8 = 255.0.0.0	Subnet mask
9 = 255.128.0.0	Subnet mask
10 = 255.192.0.0	Subnet mask
11 = 255.224.0.0	Subnet mask
12 = 255.240.0.0	Subnet mask
13 = 255.248.0.0	Subnet mask
14 = 255.252.0.0	Subnet mask
15 = 255.254.0.0	Subnet mask
16 = 255.255.0.0	Subnet mask
17 = 255.255.128.0	Subnet mask
18 = 255.255.192.0	Subnet mask
19 = 255.255.224.0	Subnet mask
20 = 255.255.240.0	Subnet mask

Indication	Description
21 = 255.255.248.0	Subnet mask
22 = 255.255.252.0	Subnet mask
23 = 255.255.254.0	Subnet mask
24 = 255.255.255.0	Subnet mask. Factory setting
25 = 255.255.255.128	Subnet mask
26 = 255.255.255.192	Subnet mask
27 = 255.255.255.224	Subnet mask
28 = 255.255.255.240	Subnet mask
29 = 255.255.255.248	Subnet mask
30 = 255.255.255.252	Subnet mask
31 = 255.255.255.254	Subnet mask

C9.4 Ethernet**C9.4.4 Gateway**

Range:	0.0.0.0 ... 255.255.255.255	Default: 0.0.0.0
Properties:	Stopped	

Description:

It allows programming the IP address of the default gateway used by the Ethernet interface. It only takes effect if the address was set via parameters.

C9.4 Ethernet**C9.4.5 SNTP - Server 1**

Range:	0.0.0.0 ... 255.255.255.255	Default: 0.0.0.0
Properties:	Stopped	

Description:

It allows programming the IP address of the NTP primary server. If the value is zero, the NTP client is disabled.

C9.4 Ethernet**C9.4.6 SNTP - Server 2**

Range:	0.0.0.0 ... 255.255.255.255	Default: 0.0.0.0
Properties:	Stopped	

Description:

It allows programming the IP address of the NTP secondary server.

C9.4 Ethernet**C9.4.7 SNTP - Update**

Range:	0 ... 65535	Default: 0
Properties:	Stopped	

Description:

It indicates the NTP server date and time update interval. If the value is zero, the NTP client is disabled. The minimum interval is 15 seconds.

C9.4 Ethernet**C9.4.8 Enable protocols**

Range:	0 ... 2 Bit	Default: 3
Properties:		

C CONFIGURATIONS

Description:

It allows enabling and disabling functionalities of some protocols, limiting the exposure of the inverter via network.

Bit	Value/Description
Bit 0 Web Server	0 = Disabled: Protocol disabled 1 = Enabled: Protocol enabled
Bit 1 Not used	Not used
Bit 2 Not used	Not used

C9.5 EtherNet/IP

It allows programming how the EtherNet/IP network protocol writing and reading data exchange should be using the MVW built-in Ethernet port.

C9.5 EtherNet/IP

C9.5.1 EtherNet/IP I/O instances

Range:	0 ... 10	Default: 0
Properties:	Stopped	

Description:

It allows selecting the Assembly class instance used during the exchange of I/O data with the network master.

The MVW frequency inverter has eleven setting options. Four of them follow the standard defined in the ODVA AC/DC Drive Profile. The others represent specific words for the MVW frequency inverter. The table below detail each of these control and status words.

Indication	Description
0 = 20/70 CIP	Basic Speed, these instances represent the simplest operation interface of a device according to the AC/DC Drive Profile
1 = 21/71 CIP	Extended Speed, these instances represent a slightly improved interface for operating the device that follows the AC/DC Device Profile
2 ... 3 = Not used	Not used
4 = 120/170 CIP + I/O data	They have the same data format as the 20/70 CIP Basic Speed Control instances In addition, it is possible to program up to 48 parameters of the equipment itself for reading and/or 48 for writing via network
5 = 121/171 CIP + I/O data	They have the same data format as the 21/71 CIP Extended Speed Control instances It is possible to program up to 48 parameters of the device itself for reading and/or 48 for writing via network
6 ... 7 = Not used	Not used
8 = 100/150 Manuf. + I/O data	These instances represent the operating interface of the device according to the MVW frequency inverter profile Besides the control and status words, speed reference and effective value, it is possible to program up to 48 parameters of the device itself for reading and/or writing via network
9 = 101/151 Manuf. + I/O data	These instances represent an interface very similar to the 100/150 Manufacturer Speed Control + configurable I/O data, with the only difference being the possibility of sending the torque limit
10 = 102/152 Config I/O data	In these instances it is possible to program up to 50 parameters of the equipment itself for reading and/or 50 for writing via network

C9.5 EtherNet/IP

C9.5.2 Readings 1st word

Range:	1 ... 100	Default: 1
Properties:	Stopped	

Description:

Sets the index of the first programmable reading word for data exchange with the network (input to the network master).

C9.5 EtherNet/IP**C9.5.3 Readings quantity**

Range:	0 ... 50	Default: 0
Properties:	Stopped	

Description:

Sets the number of programmable reading words for data exchange with the network (input to the network master), from the first word set in C8.4.1.

C9.5 EtherNet/IP**C9.5.4 Writings 1st word**

Range:	1 ... 100	Default: 1
Properties:	Stopped	

Description:

Sets the index of the first programmable writing word for data exchange with the network (output to the network master).

C9.5 EtherNet/IP**C9.5.5 Writings quantity**

Range:	0 ... 50	Default: 0
Properties:	Stopped	

Description:

Sets the number of programmable writing words for data exchange with the network (output to the network master), from the first word set in C8.4.3.

C9.6 Modbus TCP

It allows setting the Modbus TCP network protocol using the MVW built-in Ethernet port.

C9.6 Modbus TCP**C9.6.1 TCP port**

Range:	0 ... 65535	Default: 0
Properties:	Stopped	

Description:

It allows setting the number of the TCP port used for Modbus TCP connections.

Port 502 is the default TCP port for Modbus TCP connections, and it is always available. If you want an additional port to establish Modbus TCP connections, you can set the number of another TCP port in this parameter.

**NOTE!**

After changing this property, the device must be turned off and back on to effect the modifications.

C9.6 Modbus TCP**C9.6.3 Timeout**

Range:	0.0 ... 999.0 s	Default: 0.0 s
Properties:	Stopped	

Description:

Time to detect interruption in Modbus TCP communication.

After the Modbus TCP communication is started, if the device stops receiving valid telegrams for a period longer than the one programmed in this parameter, it will consider that the communication has been interrupted, and will indicate alarm/fault. For the case of an alarm, the action for communication error will also be performed.

C CONFIGURATIONS

Time counting will start from the first valid telegram received. The value 0.0 disables this function.

C9.7 Anybus

Settings for the Anybus communication accessory and the protocols that use this interface.

For a detailed description, see the MVW Anybus Communication Manual, provided in electronic format.

C9.7 Anybus		
C9.7.1 Readings 1st word		
Range:	1 ... 100	Default: 1
Properties:	Stopped	

Description:

It sets the index of the first programmable reading word for data exchange with the network (input to the network master).

C9.7 Anybus		
C9.7.2 Readings quantity		
Range:	2 ... 50	Default: 2
Properties:	Stopped	

Description:

It sets the number of programmable reading words for data exchange with the network (input to the network master), from the first word set in C8.6.2.

C9.7 Anybus		
C9.7.3 Writings 1st word		
Range:	1 ... 100	Default: 1
Properties:	Stopped	

Description:

It sets the index of the first programmable writing word for data exchange with the network (output to the network master).

C9.7 Anybus		
C9.7.4 Writings quantity		
Range:	2 ... 50	Default: 2
Properties:	Stopped	

Description:

It sets the number of programmable writing words for data exchange with the network (output to the network master), from the first word set in C8.6.4.

C9.7 Anybus		
C9.7.5 Address		
Range:	0 ... 255	Default: 0
Properties:	Stopped	

Description:

It selects the address used by the Anybus module on the network.

It is necessary that each device on the network have a different address from all the others. This setting is only used for Anybus PROFIBUS module. Allowed range of values is from 1 to 126.

**NOTE!**

After changing this configuration, for the change to take effect, the equipment must be turned off and on again, or the settings must be updated via C8.3.1.

C9.7 Anybus**C9.7.8 IP address settings**

Range:	0 ... 2	Default: 1
Properties:	Stopped	

Description:

It allows setting the IP address configuration for the Anybus EtherNet/IP, Modbus TCP and PROFINET IO modules.

Indication	Description
0 = Parameters	The IP address, subnet mask and gateway must be set through the product parameters.
1 = DHCP	Enables the DHCP function. The IP address and other network settings are received from a DHCP server via network.
2 = DCP	The IP address and other network settings are programmed in the PLC. Valid only for PROFINET.

C9.7 Anybus**C9.7.9 IP address**

Range:	0.0.0.0 ... 255.255.255.255	Default: 192.168.0.10
Properties:	Stopped	

Description:

It allows programming the IP address of the Anybus EtherCAT or PROFINET IRT module. It only takes effect if C9.7.9 = Parameters.

**NOTE!**

After changing this configuration, for the change to take effect, the equipment must be turned off and on again, or the settings must be updated via C9.7.1.

C9.7 Anybus**C9.7.10 CIDR Subnet**

Range:	0 ... 31	Default: 24
Properties:	Stopped	

Description:

It allows programming the subnet mask used by the Anybus-CC EtherCAT or PROFINET IRT module. It only takes effect if C9.7.9 = Parameters.

Indication	Description
0 = Not used	Subnet mask
1 = 128.0.0.0	Subnet mask
2 = 192.0.0.0	Subnet mask
3 = 224.0.0.0	Subnet mask
4 = 240.0.0.0	Subnet mask
5 = 248.0.0.0	Subnet mask
6 = 252.0.0.0	Subnet mask
7 = 254.0.0.0	Subnet mask
8 = 255.0.0.0	Subnet mask
9 = 255.128.0.0	Subnet mask
10 = 255.192.0.0	Subnet mask

C CONFIGURATIONS

Indication	Description
11 = 255.224.0.0	Subnet mask
12 = 255.240.0.0	Subnet mask
13 = 255.248.0.0	Subnet mask
14 = 255.252.0.0	Subnet mask
15 = 255.254.0.0	Subnet mask
16 = 255.255.0.0	Subnet mask
17 = 255.255.128.0	Subnet mask
18 = 255.255.192.0	Subnet mask
19 = 255.255.224.0	Subnet mask
20 = 255.255.240.0	Subnet mask
21 = 255.255.248.0	Subnet mask
22 = 255.255.252.0	Subnet mask
23 = 255.255.254.0	Subnet mask
24 = 255.255.255.0	Subnet mask. Factory setting
25 = 255.255.255.128	Subnet mask
26 = 255.255.255.192	Subnet mask
27 = 255.255.255.224	Subnet mask
28 = 255.255.255.240	Subnet mask
29 = 255.255.255.248	Subnet mask
30 = 255.255.255.252	Subnet mask
31 = 255.255.255.254	Subnet mask

C9.7 Anybus

C9.7.11 Gateway

Range:	0.0.0.0 ... 255.255.255.255	Default: 0.0.0.0
Properties:	Stopped	

Description:

It allows programming the IP address of the default gateway used by the Anybus EtherCAT or PROFINET IRT module. It only takes effect if C9.7.9 = Parameters.



NOTE!

After changing this configuration, for the modification to be effective, the equipment must be turned off and on again, or the settings must be updated via C9.7.1.

C9.8 CAN/CANopen/DNet

It configures CAN communication accessory and protocols that use this interface.

C9.8 CAN/CANopen/DNet

C9.8.1 Protocol

Range:	0 ... 2	Default: 2
Properties:	Stopped	

Description:

It allows selecting the desired protocol for the CAN interface.

Indication	Description
0 = Disabled	It disables the CAN interface
1 = CANopen	It enables the CAN interface with CANopen protocol
2 = DeviceNet	It enables the CAN interface with DeviceNet protocol

C9.8 CAN/CANopen/DNet**C9.8.2 Address**

Range:	0 ... 127	Default: 63
Properties:	Stopped	

Description:

It allows programming the address used for CAN communication of the device. It is necessary that each device on the network has a different address from the others. Valid addresses for this parameter depend on the protocol selected in C9.8.1:

- C9.8.1 = 1 (CANopen): valid addresses: 1 to 127.
- C9.8.1 = 2 (DeviceNet): valid addresses: 0 to 63.

**NOTE!**

After changing this configuration, the modification will only take effect if the CAN interface is not exchanging cyclical data with the network.

C9.8 CAN/CANopen/DNet**C9.8.3 Baud rate**

Range:	0 ... 5	Default: 0
Properties:	Stopped	

Description:

It allows programming the desired value for the baud rate of the CAN interface in bit per second. This rate must be the same for all devices connected to the network. The supported baud rates for the device depend on the protocol set in C9.8.1:

- C9.8.1 = 1 (CANopen): any rate indicated in this parameter can be used, but it does not have the automatic rate detection function (autobaud).
- C9.8.1 = 2 (DeviceNet): Only rates of 500, 250 and 125 Kbit/s are supported. Other options enable the automatic rate detection function (autobaud).

For the autobaud function, after a successful detection, the baud rate parameter (C9.8.3) automatically changes to the detected rate. To run the autobaud function again, it is necessary to change the parameter C9.8.3 to one of the autobaud options.

Indication	Description
0 = 1 Mbps/Auto	CAN baud rate (automatic detection for DeviceNet)
1 = Not used/Auto	Automatic detection for DeviceNet
2 = 500 Kbps	CAN baud rate
3 = 250 Kbps	CAN baud rate
4 = 125 Kbps	CAN baud rate
5 = 100 Kbps/Auto	CAN baud rate (automatic detection for DeviceNet)

**NOTE!**

After changing this configuration, the modification will only take effect if the CAN interface is not exchanging cyclical data with the network.

C CONFIGURATIONS

C9.8 CAN/CANopen/DNet

C9.8.4 Bus off Reset

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

It allows programming the behavior of the equipment when detecting a bus off error on the CAN interface.

Indication	Description
0 = Manual	If bus off occurs, A2134/F2234 will be displayed on the HMI and the communication will be disabled. In case of alarm, the action programmed in parameter C9.1.2.2 will be executed. For the equipment to communicate again via CAN interface, it will be necessary to disable and enable the interface, or restart the product
1 = Automatic	If bus off occurs, the communication will be automatically restarted, and the error will be ignored. In this case the alarm will not be displayed on the HMI and the device will not execute the action described in C9.1.2.2

C9.8 CAN/CANopen/DNet

C9.8.5 DeviceNet I/O instances

Range:	0 ... 10	Default: 0
Properties:	Stopped	

Description:

It allows selecting the Assembly class instance used during the exchange of I/O data with the network master.

The MVW frequency inverter has eleven setting options. Four of them follow the standard defined in the ODVA AC/DC Drive Profile. The others represent specific words for the MVW frequency inverter. The table below detail each of these control and status words.

Indication	Description
0 = 20/70 CIP	Basic Speed, these instances represent the simplest operation interface of a device according to the AC/DC Drive Profile
1 = 21/71 CIP	Extended Speed, these instances represent a slightly improved interface for operating the device that follows the AC/DC Device Profile
2 ... 3 = Not used	Not used
4 = 120/170 CIP + I/O data	They have the same data format as the 20/70 CIP Basic Speed Control instances. In addition, it is possible to program up to 48 parameters of the equipment itself for reading and/or 48 for writing via network
5 = 121/171 CIP + I/O data	They have the same data format as the 21/71 CIP Extended Speed Control instances. It is possible to program up to 48 parameters of the device itself for reading and/or 48 for writing via network
6 ... 7 = Not used	Not used
8 = 100/150 Manuf. + I/O data	These instances represent the operating interface of the device according to the MVW frequency inverter profile. Besides the control and status words, speed reference and effective value, it is possible to program up to 48 parameters of the device itself for reading and/or writing via network
9 = 101/151 Manuf. + I/O data	These instances represent an interface very similar to the 100/150 Manufacturer Speed Control + configurable I/O data, with the only difference being the possibility of sending the torque limit
10 = 102/152 Config I/O data	In these instances it is possible to program up to 50 parameters of the equipment itself for reading and/or 50 for writing via network



NOTE!

After changing this configuration, the modification will only take effect if the CAN interface is not exchanging cyclical data with the network.

C9.8 CAN/CANopen/DNet**C9.8.6 DNet reading 1st word**

Range:	1 ... 100	Default: 1
Properties:	Stopped	

Description:

It sets the index of the first programmable reading word for data exchange with the network (input to the network master).

C9.8 CAN/CANopen/DNet**C9.8.7 DNet reading quantity**

Range:	0 ... 50	Default: 0
Properties:	Stopped	

Description:

It sets the number of programmable reading words for data exchange with the network (input to the network master), from the first configured word.

C9.8 CAN/CANopen/DNet**C9.8.8 DNet writing 1st word**

Range:	1 ... 100	Default: 1
Properties:	Stopped	

Description:

It sets the index of the first programmable writing word for data exchange with the network (output to the network master).

C9.8 CAN/CANopen/DNet**C9.8.9 DNet writing quantity**

Range:	0 ... 50	Default: 0
Properties:	Stopped	

Description:

It sets the number of programmable writing words for data exchange with the network (output to the network master), from the first configured word.

C9.10 SymbiNet

SymbiNet is a communication protocol that enables information exchange directly between devices that support such protocol. For the MVW, the communication is performed via Ethernet interface.

Characteristics:

- All data exchange is done directly between the devices in the network without the need of a master to manage communication.
- All the communication programming can be performed using parameters without the need of a configuration tool.
- Programming for data exchange is based on existing Modbus registers for the device. Therefore, the list of Modbus registers must be known for correct data addressing during programming.
- It uses the Publisher/Subscriber mechanism, where each device publishes its data so that one or more subscribers receive this information. Besides optimizing communication, it allows a decentralized communication control, allowing each device to identify problems and continue communication even if failures occur with one or more members of the network.

Typical applications:

C CONFIGURATIONS

- Load division.
- Pumping system with multiple pumps.
- Speed follower.

SymbiNet communication normally operates in conjunction with SoftPLC, or with product embedded applications, such as load sharing or multipump functions, which make use of this communication to exchange the necessary data between products.

Operation principle:

To program data exchange, each member of the network has a set of data groups. Each group represents a sequence of data that the local station must receive from another network member. It means, when programming these groups, the user must indicate which data the local station must receive from the other stations.

The programming must be made for each member of the network, indicating all the groups that this member needs to receive from the other participants, and where this data must be saved locally. Once the groups are programmed in all the members, the devices themselves are responsible for establishing connections and requests for data exchange.

Each programmed group has a status indication, informing if the data received by that group is up to date. If any member of the network is powered off or disconnected, it stops transmitting the published data, and the groups that should receive data from this member will be flagged as outdated. The local application can use this information to perform some action relevant to that indication.

Restrictions:

- For the Ethernet network, all the members of the network must belong to the same sub-net, since the address programming is done by indicating only the last octet of the IP address of the remote stations.
- Each equipment has 8 data groups that can be programmed to request data from other stations, and each equipment can also respond to up to 8 different data groups requested by other stations.
- Some product features and applications make use of this communication, and cannot operate in conjunction with the protocol itself, programmed through parameters.

C9.10 SymbiNet

C9.10.1 Enable protocol

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

Allows enabling SymbiNet protocol over Ethernet interface, for data exchange among SymbiNet devices.

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function

C9.10 SymbiNet

C9.10.2 Publication time

Range:	2 ... 100 ms	Default: 20 ms
Properties:		

Description:

Allows you to program, in milliseconds, the time of publication of the data requested by the remote stations.

This time is also used as a basis for timeout detection of locally programmed groups. If the data programmed for a group is no longer received for more than 10 times the time programmed in this parameter, the group status is marked as inactive.

It is recommended that all participants of the SymbiNet network have equal times.

C9.10 SymbiNet

C9.10.3 Grp1: Source addr.

Range: 0 ... 254

Default: 0

Properties:

Description:

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet

C9.10.4 Grp1: Source reg.

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet

C9.10.5 Grp1: Dest. reg.

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet

C9.10.6 Grp1: Num. of registers

Range: 0 ... 8

Default: 0

Properties:

Description:

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet

C9.10.7 Grp2: Source addr.

Range: 0 ... 254

Default: 0

Properties:

Description:

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet

C9.10.8 Grp2: Source reg.

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C CONFIGURATIONS

C9.10 SymbiNet

C9.10.9 Grp2: Dest. reg.

Range: 0 ... 65535 Default: 0
Properties:

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet

C9.10.10 Grp2: Num. of registers

Range: 0 ... 8 Default: 0
Properties:

Description:

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet

C9.10.11 Grp3: Source addr.

Range: 0 ... 254 Default: 0
Properties:

Description:

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet

C9.10.12 Grp3: Source reg.

Range: 0 ... 65535 Default: 0
Properties:

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet

C9.10.13 Grp3: Dest. reg.

Range: 0 ... 65535 Default: 0
Properties:

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet

C9.10.14 Grp3: Num. of registers

Range: 0 ... 8 Default: 0
Properties:

Description:

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet

C9.10.15 Grp4: Source addr.

Range: 0 ... 254 Default: 0
Properties:

Description:

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet**C9.10.16 Grp4: Source reg.**

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet**C9.10.17 Grp4: Dest. reg.**

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet**C9.10.18 Grp4: Num. of registers**

Range: 0 ... 8

Default: 0

Properties:

Description:

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet**C9.10.19 Grp5: Source addr.**

Range: 0 ... 254

Default: 0

Properties:

Description:

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet**C9.10.20 Grp5: Source reg.**

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet**C9.10.21 Grp5: Dest. reg.**

Range: 0 ... 65535

Default: 0

Properties:

C CONFIGURATIONS

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet		
C9.10.22 Grp5: Num. of registers		
Range:	0 ... 8	Default: 0
Properties:		

Description:

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet		
C9.10.23 Grp6: Source addr.		
Range:	0 ... 254	Default: 0
Properties:		

Description:

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet		
C9.10.24 Grp6: Source reg.		
Range:	0 ... 65535	Default: 0
Properties:		

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet		
C9.10.25 Grp6: Dest. reg.		
Range:	0 ... 65535	Default: 0
Properties:		

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet		
C9.10.26 Grp6: Num. of registers		
Range:	0 ... 8	Default: 0
Properties:		

Description:

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet		
C9.10.27 Grp7: Source addr.		
Range:	0 ... 254	Default: 0
Properties:		

Description:

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet

C9.10.28 Grp7: Source reg.

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet

C9.10.29 Grp7: Dest. reg.

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet

C9.10.30 Grp7: Num. of registers

Range: 0 ... 8

Default: 0

Properties:

Description:

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet

C9.10.31 Grp8: Source addr.

Range: 0 ... 254

Default: 0

Properties:

Description:

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet

C9.10.32 Grp8: Source reg.

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet

C9.10.33 Grp8: Dest. reg.

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C CONFIGURATIONS

C9.10 SymbiNet

C9.10.34 Grp8: Num. of registers

Range: 0 ... 8

Default: 0

Properties:

Description:

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.11 BACnet

Allows programming the BACnet network protocol settings using the built-in RS-485 serial port of the CFW900.

C9.11 BACnet

C9.11.1 BACnet Instance - High

Range: 0 ... 419

Default: 0

Properties:

Description:

Defines the high part of the BACnet device instance.



NOTE!

After changing this property, the device must be turned off and back on to effect the modifications.

C9.11 BACnet

C9.11.2 BACnet Instance - Low

Range: 0 ... 9999

Default: 0

Properties:

Description:

Defines the low part of the BACnet device instance.

The BACnet standard requires that the device instance be unique on the network and have a value between 0 and 4194304. The BACnet instance forms the Object Identifier property of the DEVICE object, which defines the device characteristics on the network. The BACnet instance can be set automatically or manually:

Automatically:

If the values of parameters C9.11.1 and C9.11.2 are 0 (factory default), the inverter automatically creates the BACnet instance based on the manufacturer's BACnet ID (WEG BACnet ID = 359) and on the serial address. In this configuration, the user only needs to enter the serial address in parameter C5.10.1. BACnet instance = BACnet ID + Serial Address

Example 1: serial address = 102

Instance = 359102

Example 2: serial address = 15

Instance = 359015

Manually:

The BACnet instance is defined using parameters C9.11.1 and C9.11.2. The content of the parameter C9.11.1 is multiplied by 10000 and added to the content of parameter C9.11.2.

Example 1: Instance = 542786

$542786 / 10000 = 54.2786$

C9.11.1 = 54 (integer part)

C9.11.2 = 2786 (decimal part)

Example 2: Instance = 66789

$66789 / 10000 = 6.6789$

C9.11.1 = 6 (integer part)

C9.11.2 = 6789 (decimal part)

Example 3: Instance = 35478

$35478 / 10000 = 3.5478$

C9.11.1 = 3 (integer part)

C9.11.2 = 5478 (decimal part)



NOTE!

After changing this property, the device must be turned off and back on to effect the modifications.

C9.11 BACnet

C9.11.3 Max BACnet Master

Range: 0 ... 127

Default: 127

Properties:

Description:

Defines the highest address used by the master.



NOTE!

After changing this property, the device must be turned off and back on to effect the modifications.

C9.11 BACnet

C9.11.4 Max Number of Frames

Range: 0 ... 255

Default: 1

Properties:

Description:

Defines the number of telegrams that the station can transmit when it receives the token. After that, it must transmit the token to the next station.



NOTE!

After changing this property, the device must be turned off and back on to effect the modifications.

C9.11 BACnet

C9.11.5 I Am Transmission

Range: 0 ... 1

Default: 0

Properties:

Description:

The I-Am telegram is used to identify the station on the BACnet network. When set to 1 (Continuous), the inverter transmits an I-Am telegram every 200 ms.

C CONFIGURATIONS

Indication	Description
0 = Power Up	The I-Am telegram is sent upon product power-up.
1 = Continuous	The I-Am telegram is sent continuously every 200ms.

**NOTE!**

After changing this property, the device must be turned off and back on to effect the modifications.

C9.11 BACnet

C9.11.6 BACnet Password

Range: 0 ... 9999

Default: 5

Properties:

Description:

Defines a password to validate the execution of the DM-RD-B service.

**NOTE!**

After changing this property, the device must be turned off and back on to effect the modifications.

C9.11 BACnet

C9.11.7 BACnet Device Name

Default: CFW900

Properties:

Description:

Configures the BACnet device name.

By default, the device name is CFW900.

The device name must consist of 1 to 15 alphanumeric characters.

**NOTE!**

After changing this property, the device must be turned off and back on to effect the modifications.

C10 SOFTPLC

The SoftPLC provides the inverter with PLC functions (Programmable Logical Controller). For more details regarding the programming of these functions in the MVW, refer to the Help texts in the WPS software (WEG Programming Suite).

C10.1 Configuration

It allows setting parameters of the SoftPLC function.

C10.1 Configuration

C10.1.1 Command

Range: 0 ... 5

Default: 0

Properties: Stopped

Description:

Allow the user to execute commands for the application.

Indication	Description
0 = Stop	For the active application
1 = Run	It runs the active application
2 ... 4 = Not used	
5 = Erase	It deletes the active user application

C10.1 Configuration**C10.1.2 Active application**

Range:	0 ... 6	Default: 0
Properties:	Stopped	

Description:

It allows the user to select the active application.

Indication	Description
0 = User Application 1	When selected, it is possible to download, stop, run or delete the user application configured in the WPS software
1 = User Application 2	When selected, it is possible to download, stop, execute or delete another user program
2 ... 6 = Not used	Not used

C10.1 Configuration**C10.1.3 Application stopped action**

Range:	0 ... 2	Default: 0
Properties:		

Description:

Allow the user to set the action for when the SoftPLC application is not running.

Indication	Description
0 = Inactive	No action
1 = Generate Alarm	It generates the alarm A2708
2 = Trip Fault	It trips fault F2709.

C10.2 Engineering unit**C10.2 Engineering unit****C10.2.1 Engineering unit 1**

Range:	0 ... 64	Default: 0
Properties:		

Description:

This parameter selects the engineering unit displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (engineering unit) will be displayed in this format.

The options are shown in the table below.

C CONFIGURATIONS

Engineering Unit Options					
0 = No Unit	11 = m ³ /h	22 = gal/s	33 = kgf/m ²	44 = mca	55 = Nm
1 = A	12 = m ³ /min	23 = H	34 = kl/h	45 = m	56 = Pa
2 = bar	13 = m ³ /s	24 = Hz	35 = kPa	46 = m/h	57 = %
3 = °C	14 = °F	25 = HP	36 = kW	47 = m/min	58 = psi
4 = CPM	15 = ft	26 = h	37 = kWh	48 = m/s	59 = rpm
5 = CV	16 = ft/h	27 = in	38 = l	49 = mbar	60 = s
6 = ft ³	17 = ft/min	28 = lnWC	39 = l/h	50 = ms	61 = V
7 = ft ³ /h	18 = ft/s	29 = K	40 = l/min	51 = min	62 = W
8 = ft ³ /min	19 = gal	30 = kg	41 = l/s	52 = MPa	63 = W/m ²
9 = ft ³ /s	20 = gal/h	31 = kgf	42 = lbf	53 = mwc	64 = Wh/m ²
10 = m ³	21 = gal/min	32 = kgf/cm ²	43 = mA	54 = N	

Table 9.89: Engineering Units associated with the SoftPLC user parameter

C10.2 Engineering unit		
C10.2.2 Dec. point eng. unit 1		
Range:	0 ... 3	Default: 1
Properties:		

Description:

This parameter selects the decimal point displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (decimal point) will be displayed in this format.

C10.2 Engineering unit		
C10.2.3 Engineering unit 2		
Range:	0 ... 64	Default: 0
Properties:		

Description:

This parameter selects the engineering unit displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (engineering unit) will be displayed in this format.

Table 9.89 on page 9-132 shows the options.

C10.2 Engineering unit		
C10.2.4 Dec. point eng. unit 2		
Range:	0 ... 3	Default: 1
Properties:		

Description:

This parameter selects the decimal point displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (decimal point) will be displayed in this format.

C10.2 Engineering unit		
C10.2.5 Engineering unit 3		
Range:	0 ... 64	Default: 0
Properties:		

Description:

This parameter selects the engineering unit displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (engineering unit) will be displayed in this format.

Table 9.89 on page 9-132 shows the options.

C10.2 Engineering unit**C10.2.6 Dec. point eng. unit 3****Range:** 0 ... 3**Default:** 1**Properties:****Description:**

This parameter selects the decimal point displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (decimal point) will be displayed in this format.

C10.2 Engineering unit**C10.2.7 Engineering unit 4****Range:** 0 ... 64**Default:** 0**Properties:****Description:**

This parameter selects the engineering unit displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (engineering unit) will be displayed in this format.

Table 9.89 on page 9-132 shows the options.

C10.2 Engineering unit**C10.2.8 Dec. point eng. unit 4****Range:** 0 ... 3**Default:** 1**Properties:****Description:**

This parameter selects the decimal point displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (decimal point) will be displayed in this format.

C12 BACKUP

It allows to perform operations related to copying or restoring MVW parameter sets. Among these operations are loading the factory default values and export of parameter sets via SD card and HMI.

C12 Backup**C12.1 Load parameters****Range:** 0 ... 12**Default:** 0**Properties:** Stopped**Description:**

It selects what to load or save in the MVW settings.

It allows you to restore the factory default, as well as load or save parameter sets 1, 2, 3, SD card and HMI.

Indication	Description
0 = Not Used	Not used
1 = Default 60 Hz	It loads the MVW settings with the default content of the parameters

C CONFIGURATIONS

Indication	Description
2 = Default 50 Hz	It loads the MVW settings with the default content of the parameters All parameters are loaded with the default value of 60 Hz, with the exception of the following cases: ■ C4.3.2.1 set at 125 rpm ■ C4.3.1.1.2 set at 1500 rpm ■ C4.3.1.3.1 set at 75 rpm ■ C5.9.3 set at 15 rpm ■ C4.3.1.5.1 set at 75 rpm ■ C5.9.4 set at 100 rpm ■ C4.3.1.5.2 set at 250 rpm ■ C5.9.5 set at 1500 rpm ■ C4.3.1.5.3 set at 500 rpm ■ C5.9.8 set at 15 rpm ■ C4.3.1.5.4 set at 750 rpm ■ C2.1.8 set at 1458 rpm ■ C4.3.1.5.5 set at 1000 rpm ■ C2.1.6 set at 50 Hz ■ C4.3.1.5.6 set at 1250 rpm ■ C4.3.1.5.7 set at 1500 rpm ■ C4.3.1.5.8 set at 1375 rpm ■ C4.3.1.1.1 set at 75 rpm
3 = Param. Set 1 -> MVW	It loads the MVW settings with the content of parameter set 1
4 = Param. Set 2 -> MVW	It loads the MVW settings with the content of parameter set 2
5 = Param. Set 3 -> MVW	It loads the MVW settings with the content of parameter set 3
6 = MVW -> Param. Set 1	It saves the content of the MVW current settings for parameter set 1
7 = MVW -> Param. Set 2	It saves the content of the MVW current settings for parameter set 2
8 = MVW -> Param. Set 3	It saves the content of the MVW current settings for parameter set 3
9 = SD Card -> MVW	It loads the MVW settings with the content of parameter set imported from the SD card Additionally, it imports the settings of parameter sets 1, 2 and 3 from the SD card to the inverter memory
10 = MVW -> SD Card	It saves the content of the actual MVW settings on the SD card Additionally, it exports the settings from parameter sets 1, 2 and 3 to the SD card
11 ... 12 = Not used	Not used

Figure 9.52 on page 9-135 illustrates the operation of copying and restoring parameters. The current configuration is represented by the inverter. Each of the arrows indicates a possible operation. The side without the arrowhead indicates the parameter set to be copied, and the side with the arrowhead indicates the destination for this set. The parameter set that is already saved in the destination is overwritten during the operation.




Figure 9.52: Load settings



NOTE!
If the parameter set to be loaded is incompatible with the inverter version, the parameters are not loaded. If the parameter set to be loaded is from a different inverter model, model-specific parameters are not loaded.



ATTENTION!
Do not turn off the inverter while the parameter copy or restore command is being executed. If this happens, it is recommended that the command be carried out again.

C12 Backup

C12.2 Load set 1 DI

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to load the MVW settings with the contents of user memory 1. Table 9.48 on page 9-72 shows the options.

The loading process is carried out when the DIx status changes from low level to high level (transition from 0 to 24 V), provided that the content of the MVW current settings has been previously transferred to user memory 1.

C12 Backup

C12.3 Load set 2 DI

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to load the MVW settings with the contents of user memory 2. Table 9.48 on page 9-72 shows the options.

C CONFIGURATIONS

The loading process is carried out when the DIx status changes from low level to high level (transition from 0 to 24 V), provided that the content of the MVW current settings has been previously transferred to user memory 2.

C12 Backup		
C12.4 Load set 3 DI		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used to load the MVW settings with the contents of user memory 3. Table 9.48 on page 9-72 shows the options.

The loading process is carried out when the DIx status changes from low level to high level (transition from 0 to 24 V), provided that the content of the MVW current settings has been previously transferred to user memory 3.

C12 Backup		
C12.5 Load sets 1/2 DI		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

Enables the use and defines the digital input that will be used to load the inverter settings with the contents of parameter group 1 or 2.

Parameter group 1 is loaded when the DIx state changes from low to high (0 to 24 V transition), while parameter group 2 is loaded when the DIx state changes from high to low (24 to 0 V transition). In both cases, loading is only performed if the contents of the current inverter settings have previously been transferred to the parameter group in question.

The options are shown in Table 9.48 on page 9-72.



NOTE!

If the digital input is powered by the IOS board voltage source, when the inverter is de-energized, the DI power supply will also be removed. A high-to-low transition can occur moments before the inverter is completely de-energized. The operation to load the parameter group will only be performed partially, resulting in unwanted parameter settings. Parameter D4.1.11.1 will indicate "Not Used". If this situation occurs, it is necessary to reload the desired parameter group.

C13 NOMINAL DATA

Allows configuring the inverter rated data.

C13.1 Inverter

Inverter rated data.

C13.1 Inverter		
C13.1.1 Rated output voltage		
Range:	0 ... 14	Default: 14
Properties:		

Description:

It defines the inverter rated voltage according to the available models.

Indication	Description
0 = 1150 V	
1 = 2300 V	
2 = 3300 V	
3 = 4160 V	
4 = 5500 V	
5 = 6300 V	
6 = 6900 V	
7 = 7200 V	
8 = 8000 V	
9 = 9000 V	
10 = 10000 V	
11 = 11000 V	
12 = 12000 V	
13 = 13200 V	
14 = 13800 V	

C13.1 Inverter**C13.1.2 Rated current****Range:** 24 ... 65530 A**Default:** 140 A**Properties:** Stopped**Description:**

It defines the inverter rated current.

C13.1 Inverter**C13.1.3 Cells in parallel****Range:** 0 ... 2**Default:** 0**Properties:****Description:**

Defines the number of cells operating in parallel.

Indication	Description
0 = No parallelism	
1 = 2 cells in parallel	
2 = 3 cells in parallel	

C13.1 Inverter**C13.1.4 Number of redundant cells per phase****Range:** 0 ... 11**Default:** 0**Properties:****Description:**

This parameter specifies the amount of redundant cells in each phase of the inverter.

C13.2 Transformer

Nominal transformer data.

Adjust according to the nameplate data of the transformer used.

C CONFIGURATIONS

C13.2 Transformer

C13.2.1 Transformers at the input

Range: 0 ... 2

Default: 1

Properties:

Description:

Number of transformers at the inverter input.

Indication	Description
0 = 1 transformer	
1 = 2 transformers	
2 = 3 transformers	

C13.2 Transformer

C13.2.2 Transformers rated voltage

Range: 0.00 ... 99.99 kV

Default: 6.60 kV

Properties:

Description:

Input transformer rated line-to-line voltage.

C13.2 Transformer

C13.2.3 Transformers rated frequency

Range: 0 ... 100 Hz

Default: 60 Hz

Properties:

Description:

Input transformer rated frequency.

C13.2 Transformer

C13.2.4 Ratio between the primary and the auxiliary of the transformer 1

Range: 1.00 ... 90.00

Default: 18.14

Properties:

Description:

Voltage ratio between the primary and the auxiliary output of the input transformer.

C13.2 Transformer

C13.2.5 Transformer 1 CT ratio

C13.2.6 Transformer 2 CT ratio

C13.2.7 Transformer 3 CT ratio

Range: 1 ... 20000

Default: 200

Properties:

Description:

Sets the current transformer (CT) ratio used to measure the inverter input current.

Set according to the CT nameplate data.

Notes:

It is recommended that the CT primary current be greater than or equal to the transformer primary rated current.

The CT primary current must be less than 1.95 times the transformer primary rated current.

C13.2 Transformer		
C13.2.8 Taps of transformer 1		
C13.2.9 Taps of transformer 2		
C13.2.10 Taps of transformer 3		
Range:	-5.00 ... 5.00 %	Default: 0.00 %
Properties:		

Description:
Adjusts the variation applied to the voltage supplied to the inverter cells.

C13.2 Transformer		
C13.2.11 Transformer 1 rated power		
C13.2.12 Transformer 2 rated power		
C13.2.13 Transformer 3 rated power		
Range:	0 ... 10000 kVA	Default: 1500 kVA
Properties:		

Description:
Input transformer rated power.

10 A APPLICATION

User applications.

Special functions for motor control, processes or user program.

A1 USER PARAMETERS

SoftPLC user parameter setting.

This menu is accessible on the HMI only if there is a program saved in the SoftPLC memory area with valid configuration of the user parameters.



NOTE!

Minimum, maximum, current and default values are not displayed on the HMI for user parameters whose value can exceed six digits.

A2 PID CONTROLLER

The PID CONTROLLER application can be used to control a process in closed loop. This application places a proportional, integral and derivative controller superimposed on the normal speed control of the MVW, with selection options for:

- Control setpoint source.
- Process variable source.
- Manual or automatic operation mode.
- Alarms due to low or high level of the process variable.
- Configuration of forward or reverse control action.
- Setting conditions to activate the sleep and wake mode.

Basically, the PID CONTROLLER application compares the control setpoint to the process variable and controls the motor speed to try to eliminate any errors so as to keep the process variable equal to the control setpoint required by the user. The setting of the gains P, I and D determine the speed at which the inverter will respond to eliminate that error. Figure 10.1 on page 10-1 shows the block diagram of the PID controller.




Figure 10.1: Block diagram of the PID controller

A APPLICATION

Application examples of the PID controller:

- Flow or pressure control in a pipe system.
- Temperature of a furnace or oven.
- Dosing of chemicals in tanks.

Academic PID Controller

The PID controller implemented on the MVW is academic. See below the equations that characterize the Academic PID controller, which is the base of this function algorithm.

The transfer function in the frequency domain of the Academic PID controller is:

$$y(s) = k_p \times e(s) \times \left[1 + \frac{1}{sT_i} + sT_d \right]$$

Replacing the integrator by a sum and the derivative by the incremental quotient, we obtain the approximation for the discrete (recursive) transfer equation presented below:

$$y(k) = i(k-1) + k_p \left[\left(1 + K_i T_a + \frac{K_d}{T_a} \right) . e(k) - \left(\frac{K_d}{T_a} \right) . e(k-1) \right]$$

where:

$y(k)$: PID controller actual output;

$i(k-1)$: integral value in the previous state of the PID controller;

k_p : Proportional gain = A2.2.2.1;

K_i : Integral gain = A2.2.2.2 = $\left[\frac{1}{T_i(s)} \right]$;

K_d : Differential Gain = A2.2.2.3 = $[T_d(s)]$;

T_a : PID controller sampling period = A2.3.1.2;

$e(k)$: actual error, being $[SP(k) - PV(k)]$ for forward action, and $[PV(k)] - SP(k)]$ for reverse action;

$e(k-1)$: previous error, being $[SP(k-1) - PV(k-1)]$ for forward action, and $[PV(k-1)] - SP(k-1)]$ for reverse action;

SP : actual control setpoint of the PID controller;

PV : PID controller process variable

A2.1 Monitoring

It allows viewing the reading parameters of the PID controller.

A2.1 Monitoring		
A2.1.1 Setpoint		
Range:	-32768 ... 32767	Default: 0
Properties:		

Description:

It indicates the PID controller setpoint value in automatic mode. Its source is defined by parameter A2.3.2.1, engineering unit by parameter A2.3.3.2, decimal place by parameter A2.3.3.3, and scale by parameters A2.3.3.4 and A2.3.3.5.

A2.1 Monitoring		
A2.1.2 Setpoint (%)		
Range:	0.00 ... 100.00 %	Default: 0.00 %
Properties:		

Description:

Indicates the control setpoint (reference) value of the PID Controller in %.

A2.1 Monitoring**A2.1.3 Process variable**

Range: -32768 ... 32767

Default: 0

Properties:

Description:

It indicates the PID controller process variable value. Its source is defined by parameter A2.3.3.1, engineering unit by parameter A2.3.3.2, decimal place by parameter A2.3.3.3, and scale by parameters A2.3.3.4 and A2.3.3.5.

The conversion of the value read by the analog input in percentage into the value of the process variable shown in A2.1.3 according to the scale is done through the following formula:

$$A2.1.3 = [ValueAI(\%) \times (A2.3.3.5 - A2.3.3.4)] + [A2.3.3.4]$$

A2.1 Monitoring**A2.1.4 Process variable**

Range: 0.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Indicates the value of the PID controller process variable in percentage and according to the source defined in A2.3.3.1.

A2.1 Monitoring**A2.1.5 Controller output**

Range: 0 ... 60000 rpm

Default: 0 rpm

Properties:

Description:

It indicates the output value of the PID controller. This value is applied to the speed reference when the PID controller is operating in both automatic or manual mode. The PID controller operates (active state) when the motor is running (Run) and the speed reference source defined in C4.3.1.2.1 or C4.3.1.2.2 is in PID Controller.

A2.1 Monitoring**A2.1.6 Logical status**

Range: 0 ... 6 Bit

Default: 0

Properties:

Description:

It allows monitoring the logical status of the PID Controller application. Each bit represents a status.

A APPLICATION

Bit	Value/Description
Bit 0 Operation State	0 = Inactive: It indicates that the PID controller is not controlling the process variable neither sending speed reference 1 = Active: It indicates that the PID controller is controlling the process variable in automatic or manual mode and sending speed reference
Bit 1 Sleep Mode	0 = No: It indicates that the PID controller is not in the sleep mode 1 = Yes: It indicates that the PID controller is in the sleep mode
Bit 2 Automatic Mode	0 = No: PID controller operating in manual mode 1 = Yes: PID controller operating in automatic mode
Bit 3 PV Low Level Alarm	0 = No: Inverter is not with alarm A2430 1 = Yes: Inverter is with alarm A2430
Bit 4 PV Low Level Fault	0 = No: Inverter is not with fault F2431 1 = Yes: Inverter is with fault F2431
Bit 5 PV High Level Alarm	0 = No: Inverter is not with alarm A2432 1 = Yes: Inverter is with alarm A2432
Bit 6 PV High Level Fault	0 = No: Inverter is not with fault F2433 1 = Yes: Inverter is with fault F2433

A2.2 Regulation

It allows setting the setpoint values and gains of the PID controller.

A2.2.1 Setpoint

A2.2.1 Setpoint

A2.2.1.1 Automatic mode

Range: -32768 ... 32767

Default: 0

Properties:

Description:

It defines the PID controller setpoint value when it is in automatic mode, and the control source is programmed to be via parameter (A2.3.2.1 = 0).

A2.2.1 Setpoint

A2.2.1.2 Manual mode

Range: 0 ... 60000 rpm

Default: 0 rpm

Properties:

Description:

It defines the value of the PID controller output when it is in the manual mode, that is, when the PID controller works in manual mode, the value defined as manual setpoint is transferred directly to the PID controller output.

A2.2.1 Setpoint

A2.2.1.3 Filter

Range: 0.000 ... 9.999 s

Default: 0.150 s

Properties:

Description:

It sets the time constant of the 1st order filter to be applied to the PID controller control setpoint and has the purpose of reducing sudden changes in the setpoint value.

A2.2.2 Ganhos

A2.2.2 Ganhos

A2.2.2.1 Proportional

Range: 0.00 ... 99.99

Default: 1.00

Properties:

Description:

They define the gains of the PID controller and must be set according to the quantity or process that is being controlled. Table 10.2 on page 10-6 shows suggestions for initial gain setting values for the PID controller according to the process to be controlled.

A2.2.2 Ganhos**A2.2.2.2 Integral****Range:** 0.00 ... 99.99**Default:** 5.00**Properties:****Description:**

They define the gains of the PID controller and must be set according to the quantity or process that is being controlled. Table 10.2 on page 10-6 shows suggestions for initial gain setting values for the PID controller according to the process to be controlled.

A2.2.2 Ganhos**A2.2.2.3 Derivative****Range:** 0.00 ... 99.99**Default:** 0.00**Properties:****Description:**

They define the gains of the PID controller and must be set according to the quantity or process that is being controlled. Table 10.2 on page 10-6 shows suggestions for initial gain setting values for the PID controller according to the process to be controlled.

A2.3 Configuration

It allows configuring how the PID controller will act in the control of the process variable.

A2.3.1 Control

It allows configuring the PID controller control.

A2.3.1 Control**A2.3.1.1 Action control selection****Range:** 0 ... 1**Default:** 0**Properties:** Stopped**Description:**

It defines how the control action of the PID controller will be.

Indication	Description
0 = Direct	It defines that the PID controller will be enabled and the control or regulation action will be direct. That is, the error will be the value of the control setpoint (A2.1.1) minus the value of the control process variable (A2.1.3)
1 = Reverse	It defines that the PID controller will be enabled and the control or regulation action will be reversed. That is, the error will be the value of the control process variable (A2.1.3) minus the control setpoint value (A2.1.1)



NOTE!

The control action of the PID controller must be direct when, in order to increase the value of the process variable, it is necessary to increase the output of the PID controller. E.g.: Pump driven by an inverter filling a tank. For the level of the tank (process variable) to rise, the flow rate must increase, which is achieved by increasing the motor speed.

The control action of the PID controller must be reversed when, to increase the value of the process variable, it is necessary to decrease the output of the PID controller. E.g.: Fan driven by an inverter cooling a cooling tower. When an increase in temperature is desired (process variable), it is necessary to reduce the ventilation by reducing the motor speed.

A2.3.1 Control

A2.3.1.2 Sampling period

Range:	0.050 ... 9.999 s	Default: 0.100 s
Properties:	Stopped	

Description:

It defines the PID controller sampling period. Table 10.2 on page 10-6 shows the suggestions of initial values of the sampling period for the PID controller according to the process to be controlled.

Table 10.2: Suggestions of setting the PID controller gains and sampling period

Quantity	Sampling Period A2.3.1.2	Gains		
		Proportional A2.2.2.1	Integral A2.2.2.2	Derivative A2.2.2.3
Pressure in pneumatic system	0,10 s	0,10	5,00	0,00
Flow in pneumatic system	0,10 s	0,10	5,00	0,00
Pressure in hydraulic system	0,10 s	0,10	5,00	0,00
Flow in hydraulic system	0,10 s	0,10	5,00	0,00
Temperature	0,50 s	0,20	0,50	0,10

A2.3.2 Setpoint

It allows setting the PID controller setpoint.

A2.3.2 Setpoint

A2.3.2.1 Source selection

Range:	0 ... 2	Default: 0
Properties:	Stopped	

Description:

It defines the control setpoint source in automatic mode of the PID controller.

Indication	Description
0 = Parameter	It defines that the PID controller control setpoint source in automatic mode will be the value set in parameter A2.2.1.1 through the MVW frequency inverter HMI or written via communication networks or SoftPLC
1 = Analog Input	It defines that the PID controller control setpoint source in automatic mode will be the value read by the analog input configured in A2.3.5.1
2 = Not used	Not used

A2.3.3 Process variable

It allows setting the PID controller process variable.

A2.3.3 Process variable**A2.3.3.1 Source selection**

Range:	0 ... 2	Default: 0
Properties:	Stopped	

Description:

It defines the source of the PID controller process variable.

Indication	Description
0 = Analog Input	It defines that the source of the process variable will be the value read by the analog input configured in A2.3.5.3 and displayed in parameter A2.1.3
1 = Not used	Not used
2 = AI Differential	It defines that the source of the process variable will be the value read by the analog input configured in A2.3.5.3 minus the value read by the analog input configured in A2.3.5.4 and displayed in parameter A2.1.3

A2.3.3 Process variable**A2.3.3.2 Unit**

Properties:	Default: %
--------------------	-------------------

Description:

It defines the engineering unit of the PID controller process variable. It can have up to 7 ASCII characters.

A2.3.3 Process variable**A2.3.3.3 Decimal places**

Range:	0 ... 3	Default: 0
Properties:		

Description:

It sets the number of decimal places for values with engineering unit of the PID controller.

Indication	Description
0 = wxyz	No decimal places
1 = wxy.z	One decimal place
2 = wx.yz	Two decimal places
3 = w.xyz	Three decimal places

A2.3.3 Process variable**A2.3.3.4 Minimum level**

Range:	-32768 ... 32767	Default: 0
Properties:	Stopped	

Description:

It defines the minimum value of the process variable in engineering units of the PID controller.

A2.3.3 Process variable**A2.3.3.5 Maximum level**

Range:	-32768 ... 32767	Default: 10000
Properties:	Stopped	

Description:

Torque offset It defines the maximum value of the process variable in engineering units of the PID controller.

A APPLICATION



NOTE!

Example: If a temperature sensor, with an operating range between -20 and +70 °C and a signal between 4 and 20 mA, is used by an analog input also set to 4 to 20 mA for obtaining the value of the process variable, the values that must be set in these parameters are -20 °C and 70 °C respectively.

A2.3.4 Operation mode

It allows configuring the PID controller operating mode.

A2.3.4 Operation mode

A2.3.4.1 MAN/AUTO source

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

It defines the source of the PID controller operating mode.

- Manual mode: Speed reference defined directly by the manual setpoint set in A2.2.1.2.
- Automatic mode: Speed reference obtained through the PID controller based on the automatic setpoint displayed in A2.1.1.

Indication	Description
0 = Parameter	It defines that the PID controller operates in manual or automatic mode according to the parameter configured in A2.3.4.2
1 = Selection via DI	It defines that the PID controller operates in manual or automatic mode according to the state of the digital input configured in A2.3.5.6. That is, if the digital input is at logic level "0", the PID controller will operate in manual mode; if the digital input is at logic level "1", the PID controller will operate in automatic mode



NOTE!

The change from an operation mode to another with the motor running may cause disturbances on the system control. That can be optimized according to the automatic adjustment mode of the PID controller setpoint defined in parameter A2.3.4.3 together with the bumpless transfer characteristic from the manual mode to the automatic mode.

Bumpless transfer is merely making the transfer from the manual mode to the automatic mode without causing variation in the PID controller output. In other words, when the transition from the manual mode to the automatic mode occurs, the PID controller output value in manual mode is used to start the integral part of the PID controller in automatic mode. That ensures that the output will start from this value

A2.3.4 Operation mode

A2.3.4.2 MAN/AUTO selection

Range:	0 ... 1	Default: 0
Properties:		

Description:

It defines the PID controller operating mode in case A2.3.4.1 = 0.

Indication	Description
0 = Manual	It defines that the PID controller will operate in manual mode. In this mode, the manual mode setpoint value (A2.2.1.2) will be applied as the PID controller speed reference
1 = Automatic	It defines that the PID controller will operate in automatic mode. In this mode, the automatic mode setpoint value will be used as input to the PID controller to control the process variable

A2.3.4 Operation mode**A2.3.4.3 SP automatic setting****Range:** 0 ... 3**Default:** 0**Properties:****Description:**

It defines whether the PID controller setpoint in automatic mode (A2.2.1.1) and/or manual mode (A2.2.1.2) will be changed or set automatically when the PID controller operating mode changes.

Indication	Description
0 = Both SP Inactive	It defines that the setpoint values in manual and automatic mode will not be modified
1 = Active Automatic SP	It defines that when the PID controller operating mode transitions from manual to automatic, the control setpoint value will be loaded with the current value of the control process variable (A2.1.3)
2 = Active Manual SP	It defines that in the transition of the PID controller operation mode from automatic to manual, the value of the PID controller setpoint in manual mode (A2.2.1.2) will be loaded with the actual motor speed value (S2.1.3)
3 = Both SP Active	It defines that in the transition of the PID controller operation mode from manual to automatic, the control setpoint value (A2.2.1.1) will be loaded with the current value of the control process variable (A2.1.3); and that in the transition of the PID controller operating mode from automatic to manual, the PID controller setpoint value in manual mode (A2.2.1.2) will be loaded with the current motor speed value (S2.1.3)

**NOTE!**

Setting the control setpoint in automatic mode is only valid when the source of the control setpoint is parameters (A2.3.2.1 = 0). For other control setpoint sources, the automatic adjustment is not executed.

A2.3.5 Command sources

It allows defining the analog or digital input used for each PID controller command.

A2.3.5 Command sources**A2.3.5.1 AI for setpoint****Range:** 0 ... 30**Default:** 0**Properties:** Stopped**Description:**

It defines the analog input that will be used as a setpoint in the PID controller automatic mode. The options are shown in Table 9.19 on page 9-31.

Indication	Description
0 = Inactive	It disables the use of the analog input in this function
1 = AI X-1	Enable use of analog input AI1 of Slot X
2 = AI X-2	Enable use of analog input AI2 of Slot X
3 = AI A-1	Enable use of analog input AI1 of Slot A
4 = AI A-2	Enable use of analog input AI2 of Slot A
5 = AI A-3	Enable use of analog input AI3 of Slot A
6 = Not used	Not used
7 = AI B-1	Enable use of analog input AI1 of Slot B
8 = AI B-2	Enable use of analog input AI2 of Slot B
9 = AI B-3	Enable use of analog input AI3 of Slot B
10 = Not used	Not used
11 = AI C-1	Enable use of analog input AI1 of Slot C
12 = AI C-2	Enable use of analog input AI2 of Slot C
13 = AI C-3	Enable use of analog input AI3 of Slot C
14 = Not used	Not used
15 = AI D-1	Enable use of analog input AI1 of Slot D

A APPLICATION

Indication	Description
16 = AI D-2	Enable use of analog input AI2 of Slot D
17 = AI D-3	Enable use of analog input AI3 of Slot D
18 = Not used	Not used
19 = AI E-1	Enable use of analog input AI1 of Slot E
20 = AI E-2	Enable use of analog input AI2 of Slot E
21 = AI E-3	Enable use of analog input AI3 of Slot E
22 = Not used	Not used
23 = AI F-1	Enable use of analog input AI1 of Slot F
24 = AI F-2	Enable use of analog input AI2 of Slot F
25 = AI F-3	Enable use of analog input AI3 of Slot F
26 = Not used	Not used
27 = AI G-1	Enable use of analog input AI1 of Slot G
28 = AI G-2	Enable use of analog input AI2 of Slot G
29 = AI G-3	Enable use of analog input AI3 of Slot G
30 = Not used	Not used

A2.3.5 Command sources

A2.3.5.2 FI for setpoint

Range:	0 ... 2	Default: 0
Properties:	Stopped	

Description:

It defines the frequency input that will be used as a setpoint in PID controller automatic mode.

Indication	Description
0 = Inactive	It disables the use of the frequency input in this function
1 = FI X-5	It enables the use of frequency input FI5 of Slot X
2 = FI X-6	It enables the use of frequency input FI6 of Slot X

A2.3.5 Command sources

A2.3.5.3 AI for process var. 1

Range:	0 ... 30	Default: 1
Properties:	Stopped	

Description:

It defines the analog input that will be used as the PID controller process variable if the variable source selection is configured for analog input or difference between analog inputs (A2.3.3.1 = 0 or 2). The options are shown in Table 9.19 on page 9-31.

Indication	Description
0 = Inactive	It disables the use of the analog input in this function
1 = AI X-1	Enable use of analog input AI1 of Slot X
2 = AI X-2	Enable use of analog input AI2 of Slot X
3 = AI A-1	Enable use of analog input AI1 of Slot A
4 = AI A-2	Enable use of analog input AI2 of Slot A
5 = AI A-3	Enable use of analog input AI3 of Slot A
6 = Not used	Not used
7 = AI B-1	Enable use of analog input AI1 of Slot B
8 = AI B-2	Enable use of analog input AI2 of Slot B
9 = AI B-3	Enable use of analog input AI3 of Slot B
10 = Not used	Not used
11 = AI C-1	Enable use of analog input AI1 of Slot C
12 = AI C-2	Enable use of analog input AI2 of Slot C
13 = AI C-3	Enable use of analog input AI3 of Slot C
14 = Not used	Not used

Indication	Description
15 = AI D-1	Enable use of analog input AI1 of Slot D
16 = AI D-2	Enable use of analog input AI2 of Slot D
17 = AI D-3	Enable use of analog input AI3 of Slot D
18 = Not used	Not used
19 = AI E-1	Enable use of analog input AI1 of Slot E
20 = AI E-2	Enable use of analog input AI2 of Slot E
21 = AI E-3	Enable use of analog input AI3 of Slot E
22 = Not used	Not used
23 = AI F-1	Enable use of analog input AI1 of Slot F
24 = AI F-2	Enable use of analog input AI2 of Slot F
25 = AI F-3	Enable use of analog input AI3 of Slot F
26 = Not used	Not used
27 = AI G-1	Enable use of analog input AI1 of Slot G
28 = AI G-2	Enable use of analog input AI2 of Slot G
29 = AI G-3	Enable use of analog input AI3 of Slot G
30 = Not used	Not used

A2.3.5 Command sources

A2.3.5.4 AI for process var. 2

Range: 0 ... 30

Default: 0

Properties: Stopped

Description:

It defines the analog input that will be used for calculating the value of the PID controller process variable if the variable source selection is configured for differences between analog inputs (A2.3.3.1 = 2). The options are shown in Table 9.19 on page 9-31.

Indication	Description
0 = Inactive	It disables the use of the analog input in this function
1 = AI X-1	Enable use of analog input AI1 of Slot X
2 = AI X-2	Enable use of analog input AI2 of Slot X
3 = AI A-1	Enable use of analog input AI1 of Slot A
4 = AI A-2	Enable use of analog input AI2 of Slot A
5 = AI A-3	Enable use of analog input AI3 of Slot A
6 = Not used	Not used
7 = AI B-1	Enable use of analog input AI1 of Slot B
8 = AI B-2	Enable use of analog input AI2 of Slot B
9 = AI B-3	Enable use of analog input AI3 of Slot B
10 = Not used	Not used
11 = AI C-1	Enable use of analog input AI1 of Slot C
12 = AI C-2	Enable use of analog input AI2 of Slot C
13 = AI C-3	Enable use of analog input AI3 of Slot C
14 = Not used	Not used
15 = AI D-1	Enable use of analog input AI1 of Slot D
16 = AI D-2	Enable use of analog input AI2 of Slot D
17 = AI D-3	Enable use of analog input AI3 of Slot D
18 = Not used	Not used
19 = AI E-1	Enable use of analog input AI1 of Slot E
20 = AI E-2	Enable use of analog input AI2 of Slot E
21 = AI E-3	Enable use of analog input AI3 of Slot E
22 = Not used	Not used
23 = AI F-1	Enable use of analog input AI1 of Slot F
24 = AI F-2	Enable use of analog input AI2 of Slot F
25 = AI F-3	Enable use of analog input AI3 of Slot F
26 = Not used	Not used

A APPLICATION

Indication	Description
27 = AI G-1	Enable use of analog input AI1 of Slot G
28 = AI G-2	Enable use of analog input AI2 of Slot G
29 = AI G-3	Enable use of analog input AI3 of Slot G
30 = Not used	Not used

A2.3.5 Command sources

A2.3.5.5 FI for process var.

Range:	0 ... 2	Default: 0
Properties:	Stopped	

Description:

It defines the frequency input that will be used as the PID controller process variable if the variable source selection is configured for frequency input (A2.3.3.1 = 1).

Indication	Description
0 = Inactive	It disables the use of the frequency input in this function
1 = FI X-5	It enables the use of frequency input FI5 of Slot X
2 = FI X-6	It enables the use of frequency input FI6 of Slot X

A2.3.5 Command sources

A2.3.5.6 DI for manual/Automatic

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It defines the digital input that will be used for manual and automatic mode selection of the PID controller if parameter A2.3.4.1 is so configured (A2.3.4.1 = 1). The options are shown in Table 9.48 on page 9-72.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X
7 = DI A-1	Enable use of digital input DI1 of Slot A
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C

Indication	Description
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G
62 = DI G-8	Enable use of digital input DI8 of Slot G

A2.3.5 Command sources

A2.3.5.7 DI for increment SP

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It defines the digital input that will be used to increase the value of the PID controller setpoint if parameter A2.3.2.1 is so configured. The options are shown in Table 9.48 on page 9-72.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X

A APPLICATION

Indication	Description
7 = DI A-1	Enable use of digital input DI1 of Slot A
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G

Indication	Description
62 = DI G-8	Enable use of digital input DI8 of Slot G

A2.3.5 Command sources

A2.3.5.8 DI for decrement SP

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It defines the digital input that will be used to decrease the value of the PID controller setpoint if parameter A2.3.2.1 is so configured. The options are shown in Table 9.48 on page 9-72.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X
7 = DI A-1	Enable use of digital input DI1 of Slot A
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E

Indication	Description
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G
62 = DI G-8	Enable use of digital input DI8 of Slot G

A2.3.5 Command sources

A2.3.5.9 DI for multi SP 1

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It defines the digital input that will be used for the multisetpoint mode if parameter A2.3.2.1 is so configured. The options are shown in Table 9.48 on page 9-72.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X
7 = DI A-1	Enable use of digital input DI1 of Slot A
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C

Indication	Description
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G
62 = DI G-8	Enable use of digital input DI8 of Slot G

A2.3.5 Command sources

A2.3.5.10 DI for multi SP 2

Range: 0 ... 62

Default: 0

Properties: Stopped

Description:

It defines the digital input that will be used for the multisetpoint mode if parameter A2.3.2.1 is so configured. The options are shown in Table 9.48 on page 9-72.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X

A APPLICATION

Indication	Description
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X
7 = DI A-1	Enable use of digital input DI1 of Slot A
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G

Indication	Description
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G
62 = DI G-8	Enable use of digital input DI8 of Slot G

A2.3.6 Faults and Alarms

It allows configuring the performance of the PID controller faults and alarms.

A2.3.6 Faults and Alarms

A2.3.6.1 Config. for PV low level

Range: 0 ... 3 Default: 0

Properties:

Description:

It defines whether the alarm and protection should actuate when the process variable level is low (A2.1.3 < A2.3.6.2).

Indication	Description
0 = Inactive	It defines that the process variable fault and alarm should not actuate when the limit is exceeded
1 = Alarm	It defines that only the process variable alarm should actuated when the limit is exceeded
2 = Fault	It defines that the process variable fault should actuate when the limit is exceeded
3 = Alarm and Fault	It defines that the process variable fault and alarm should actuate when the limit is exceeded

A2.3.6 Faults and Alarms

A2.3.6.2 Value for PV low level

Range: -32768 ... 32767 Default: 0

Properties:

Description:

Defines the value below which the low level alarm for the control process variable will be generated (A2430).

A2.3.6 Faults and Alarms

A2.3.6.3 Time for PV low level

Range: 0.0 ... 999.9 s Default: 0.0 s

Properties:

Description:

Time for low level fault for the control process variable.

A2.3.6 Faults and Alarms

A2.3.6.4 Config. for PV high level

Range: 0 ... 3 Default: 0

Properties:

Description:

It defines whether the alarm and protection should actuate when the process variable level is high (A2.1.3 > A2.3.6.5).

Indication	Description
0 = Inactive	It defines that the process variable fault and alarm should not actuate when the limit is exceeded
1 = Alarm	It defines that only the process variable alarm should actuated when the limit is exceeded
2 = Fault	It defines that the process variable fault should actuate when the limit is exceeded

A APPLICATION

Indication	Description
3 = Alarm and Fault	It defines that the process variable fault and alarm should actuate when the limit is exceeded

A2.3.6 Faults and Alarms

A2.3.6.5 Value for PV high level

Range: -32768 ... 32767

Default: 0

Properties:

Description:

It defines the value above which the control process variable high level alarm will be generated (A2432).

A2.3.6 Faults and Alarms

A2.3.6.6 Time for PV high level

Range: 0.0 ... 999.9 s

Default: 0.0 s

Properties:

Description:

Time for high level fault for the control process variable.

A2.3.7 Sleep mode

It allows setting the operating conditions of the PID controller sleep mode. This mode allows energy savings when the control action is not necessary to keep the process variable at the desired value.

Sleep Mode is a controlled system status in which the control demand is zero or almost zero, seeing that at this moment the motor driven by the MVW frequency inverter may be stopped. That prevents the motor from remaining running at a low speed, which does little or nothing for the controlled system. Even if the motor is apparently OFF, the process variable continues to be monitored so that, when necessary, the controlled system can start the motor again according to the conditions of the wake up mode.

The Wake Up Mode switches on the motor when the difference between the control process variable and the control setpoint is greater than a certain programmed value.



NOTE!

The sleep mode only actuates if the PID controller is enabled and in the automatic mode.



DANGER!

When the MVW inverter is in the sleep mode, the motor can spin at any moment because of the process conditions.

Figure 10.2 on page 10-21 shows an analysis of the operation of the PID controller programmed with direct control action and set to Sleep Mode.




Figure 10.2: PID sleep mode

1 – The Run/Stop command via digital input DI1 enables starting the motor. As the condition to wake up was not detected, it remains in sleep mode and the motor remains stopped;

2 – The process variable starts to decrease and becomes smaller than the deviation of the process variable programmed to wake up (A2.3.7.2); at this moment the countdown time to wake up (A2.3.7.3) is started;

3 – The process variable remains smaller than the deviation of the process variable to wake up (A2.3.7.2), and the time to wake up (A2.3.7.3) has elapsed; at this moment the command is given to start the motor and control the system with the variation of its speed;

4 – The inverter accelerates the motor to the minimum speed (C4.3.1.1.1). After that, the PID controller is enabled and starts to control the motor speed;

5 – Then it is possible to control the process variable so that it reaches the control setpoint required by the user. To that end, the PID controller output is increased causing the motor speed to increase until the control stabilizes;

6 – The value of the process variable remains above the required control setpoint due to a decrease in demand and the motor speed starts to slow down;

7 – The motor speed value is lower than the sleep value (A2.3.7.4); the countdown time to activate sleep mode (A2.3.7.5) starts;

A APPLICATION

8 – The motor speed remains below the sleep value (A2.3.7.4) and the time to activate the sleep mode (A2.3.7.5) has elapsed; at this moment the command to turn off the motor is given;

9 – The motor decelerates to 0 rpm and stops; at this moment the PID controller goes into sleep mode.

A2.3.7 Sleep mode

A2.3.7.1 Sleep mode config.

Range: 0 ... 1

Default: 0

Properties:

Description:

It defines whether the control will operate in sleep mode.

Indication	Description
0 = Disabled	It sets the sleep mode to be inactive
1 = Enabled	It sets the sleep mode to be active

A2.3.7 Sleep mode

A2.3.7.2 PV deviation to wake up

Range: -32768 ... 32767

Default: 500

Properties:

Description:

It defines the value to be decreased (direct PID) or added (reverse PID) to the control setpoint to turn on the motor and return to system control (exiting the sleep mode). This value is compared to the control process variable, and, if the control process variable value is smaller (direct PID) or greater (reverse PID) than this value, the wake up condition is enabled.

A2.3.7 Sleep mode

A2.3.7.3 Time to wake up

Range: 0.0 ... 999.9 s

Default: 5.0 s

Properties:

Description:

It sets the time to stay in the wake up mode condition to exit the sleep mode and allow control of the system by activating the motor. The control process variable must remain smaller (direct PID) or greater (reverse PID) than the deviation defined in A2.3.7.2 during the time set in A2.3.7.3 for the motor to be turned on and its speed controlled. If the condition to wake up (A2.3.7.3) is inactive for a while, the timer is reset and the time count is reinitialized.



NOTE!

If the "Run/Stop" command is active when the inverter is powered up and the Wake up condition is active, the time set in A2.3.7.3 will not be waited, and thus the motor starts instantly.

A2.3.7 Sleep mode

A2.3.7.4 Speed for sleep mode

Range: 0 ... 60000 rpm

Default: 100 rpm

Properties:

Description:

It sets the motor speed value to go into the sleep mode.

A2.3.7 Sleep mode

A2.3.7.5 Time for sleep mode

Range: 0.0 ... 999.9 s

Default: 10.0 s

Properties:

Description:

It defines the time for the motor speed to remain below the value set in A2.3.7.4 so that the motor will be switched off and go into the sleep mode.

A3 MILL

This section explains the start and stop process of mills controlled by WEG MVW inverters.

To start operation, the inverter must be in the *Ready* state and receive a *Start* command to accelerate the mill up to the speed reference.

Due to the high torque required to move the mill, strategies for frozen load detection (FCD) are required. Frozen load results from the solidification of the ore mixture after the mill remains stopped for a certain period of time.




Figure 10.3: Motor torque when driving a frozen load and a normal load

Frozen loads change the process dynamics and may prevent the load from slipping while the mill rotates.

The MVW frozen load release (FCR) function allows the load to be unfrozen, restoring proper system dynamics and enabling mill operation to resume.

A3.1 Configurations

General system settings, such as speed ratio, command sources and references.

A3.1 Configurations		
A3.1.1 Reduction of the motor and mill assembly		
Range:	0.01 ... 200.00	Default: 64.85
Properties:		

Description:

Defines the final reduction ratio of the motor–mill assembly.

$$\text{Reduction} = \text{Gearbox reduction} \times \frac{\text{Ring gear number of teeth}}{\text{Pinion number of teeth}}$$

A3.1 Configurations		
A3.1.3 HMI speed reference		
Range:	0.1 ... 100.0 %	Default: 80.0 %
Properties:		

A APPLICATION

Description:

Defines the speed reference value in remote mode 1, used when the reference source is set to HMI in A3.1.4.

A3.1 Configurations

A3.1.4 Commands and references

Range: 0 ... 2 Bit

Default: 0

Properties:

Description:

Defines the source of commands and speed references.

Bit	Value/Description
Bit 0 REM 1 speed reference source	0 = HMI: The HMI reference value is parameterized in A3.1.3 1 = Analog input
Bit 1 REM 2 speed reference source	0 = Fieldbus 1 = Analog input
Bit 2 REM 2 Start/Stop command source	0 = Fieldbus 1 = Digital input

A3.1 Configurations

A3.1.5 Remote 2 minimum speed reference

A3.1.6 Maximum value of the remote 2 speed reference

Range: 0.1 ... 100.0 %

Default: 30.0 % (A3.1.5)

100.0 % (A3.1.6)

Properties:

Description:

Defines the speed reference range when operating in remote mode 2.

A3.2 Frozen charge detection

When the frozen load detection (FCD) function is enabled, at startup the mill accelerates until it reaches the verification speed set in A3.2.2.

When the angular position A3.2.3 is reached, maximum torque monitoring starts and continues until position A3.2.4. The maximum torque value measured within this interval is stored and, when the displacement angle reaches A3.2.5, it is compared with the current torque value.

$$\Delta \text{Torque} = T_{\max} - T_{A3.2.5}$$

$$\text{Load state} = \begin{cases} \text{Unfrozen,} & \text{if } \Delta \text{Torque} > A3.2.6 \\ \text{Frozen,} & \text{if } \Delta \text{Torque} \leq A3.2.6 \end{cases}$$

If no frozen load is detected, the mill continues rotating until it reaches the angular position set in A3.2.7, where it then takes the operating speed reference defined in A3.1.4.




Figure 10.4: Start without frozen load, with FCD enabled

If a frozen load is detected, the motor rotation direction is reversed and the mill is stopped when it reaches approximately 0°.




Figure 10.5: Start with frozen load, with FCD enabled

A APPLICATION

A3.2 Frozen charge detection

A3.2.1 Enable function

Range: 0 ... 1

Default: 1

Properties:

Description:

Enable frozen charge detection function.

Indication	Description
0 = Disabled	Disables the function.
1 = Enabled	Enables the function.

A3.2 Frozen charge detection

A3.2.2 Verification speed

Range: 0.1 ... 10.0 %

Default: 10.0 %

Properties:

Description:

Defines the speed reference used for frozen load verification.

A3.2 Frozen charge detection

A3.2.3 Angle to enable maximum torque check

A3.2.4 Angle to disable maximum torque check

Range: 1 ... 90 °

Default: 30 ° (A3.2.3)

60 ° (A3.2.4)

Properties:

Description:

Defines the angles to enable and disable maximum torque verification.

A3.2 Frozen charge detection

A3.2.5 Angle to perform torque comparison

Range: 1 ... 90 °

Default: 80 °

Properties:

Description:

Defines the angle at which the comparison between the maximum torque measured between A3.2.3 and A3.2.4 and the current torque value is performed.

This comparison determines whether the mill load is frozen.

A3.2 Frozen charge detection

A3.2.6 Minimum torque reduction rate

Range: -30 ... 30 %

Default: 20 %

Properties:

Description:

Defines the minimum torque reduction rate required for frozen load verification.

This rate must be adjusted to allow detection of the load drop.

A3.2 Frozen charge detection

A3.2.7 Angle to change speed

Range: 1 ... 359 °

Default: 180 °

Properties:

Description:

Defines the angle at which the mill operating speed is enabled when no frozen load is detected.

A3.3 Frozen charge release

When a frozen load is detected, the system moves the mill to the zero angle position.

If the function is enabled in A3.3.1, the system is ready to receive the frozen load release command.

When the unfreezing process starts, the following steps are performed:

- The mill starts moving from the zero angle to the release angle set in A3.3.3, at the release speed A3.3.2.
- When the mill reaches the angle set in A3.3.3, the system stops and holds the mill in position until time A3.3.5 has elapsed.
- The mill reverses the rotation direction and is positioned to angle A3.3.3 in the opposite direction, holding this position for time A3.3.5.

Parameter A3.3.4 defines the number of cycles the inverter will perform to unfreeze the load. After this procedure, the mill returns to the zero angle and the inverter is disabled.




Figure 10.6: Frozen load release

A3.3 Frozen charge release**A3.3.1 Enable function**

Range: 0 ... 1

Default: 1

Properties:

Description:

Enables the frozen charge release function.

Indication	Description
0 = Disabled	Function disabled.
1 = Enable	Function enabled.

A3.3 Frozen charge release**A3.3.2 Speed reference**

Range: 0.1 ... 10.0 %

Default: 10.0 %

Properties:

Description:

Defines the motor speed reference during the frozen load release routine. This value is a percentage of the motor rated speed defined in C2.1.5.

A APPLICATION

A3.3 Frozen charge release

A3.3.3 Position to release the frozen charge

Range: 10 ... 90 °

Default: 80 °

Properties:

Description:

Defines the mill angular position used for frozen load release.

A3.3 Frozen charge release

A3.3.4 Number of cycles

Range: 1 ... 10

Default: 5

Properties:

Description:

Defines the number of cycles to unfreeze the load.

A3.3 Frozen charge release

A3.3.5 Time to release frozen cargo

Range: 0 ... 60 s

Default: 5 s

Properties:

Description:

Defines how long the mill will remain stopped at the position set in A3.3.3 before reversing the rotation direction.

A3.3 Frozen charge release

A3.3.6 Enable automatic release

Range: 0 ... 1

Default: 0

Properties:

Description:

Defines whether the frozen load release cycles will be executed automatically.



NOTE!

Automatic release will only be executed if load release is enabled in A3.3.1.

Indication	Description
0 = Disabled	After detecting a frozen load, the inverter moves the mill to the 0° angular position and waits for the frozen load release command.
1 = Enabled	Starts the defrost routine as soon as a frozen charge is detected

A3.3 Frozen charge release

A3.3.7 Regenerative torque setpoint

Range: 10 ... 120 %

Default: 100 %

Properties:

Description:

Defines the percentage of regenerative torque applied to the motor when Frozen Load Release is activated.



NOTE!

This setting helps prevent inverter overvoltage during deceleration of a frozen load. Adjust a value that also prevents DC bus undervoltage when the inverter decelerates during frozen load release.



BRAZIL

WEG DRIVES & CONTROLS - AUTOMAÇÃO LTDA.

Av. Prefeito Waldemar Grubba, 3000

89256-900 - Jaraguá do Sul - SC

Phone: 55 (47) 3276-4000

Fax: 55 (47) 3276-4060

www.weg.net/br