

Frequency Inverter

MVW01 V5.03.XX

Programming Manual





Programming Manual

MVW01

Software version: 5.03.XX

Document: 10013258572

Revision: 02

Date: 07/2026

SUMMARY OF REVISIONS

The information below describes the reviews made in this manual.

Version	Revision	Description
5.01.XX	R00	First edition
5.02.XX	R01	Added support for up to 6 thermal protection relays
5.03.XX	R02	Thermal relay status monitoring Arc fault configuration

1	PARAMETER STRUCTURE	1-1
2	FAULTS AND ALARMS	2-1
2.1	FAULT AND ALARM TABLE	2-1
3	SAFETY INSTRUCTIONS	3-1
3.1	SAFETY WARNINGS IN THE MANUAL	3-1
3.2	SAFETY WARNINGS ON THE PRODUCT	3-1
3.3	PRELIMINARY RECOMMENDATIONS	3-1
4	ABOUT THE MANUAL	4-1
4.1	TERMINOLOGY AND DEFINITIONS	4-1
4.1.1	Terms and Definitions Used in the Manual	4-1
5	ABOUT THE MVW.....	5-1
5.1	AVAILABLE MODELS	5-1
6	SOFTWARE VERSIONS	6-1
7	S STATUS	7-1
S1	INVERTER	7-1
S1.1	Status	7-1
S1.2	Software version	7-3
S1.4	Accessory data	7-3
S1.5	Date/Hour	7-4
S1.6	Control words	7-5
S2	MEASUREMENTS	7-7
S2.1	Motor speed	7-8
S2.2	Motor Torque	7-8
S2.3	Inverter Output	7-8
S2.4	Temperatures	7-10
S2.4.1	Temperature accessory	7-10
S2.4.2	Thermal protection relay	7-10
S2.4.3	Air temperature	7-11
S2.4.4	Inverter arms	7-11
S2.4.5	Rectifier temperature	7-11
S2.4.6	Braking arms	7-11
S2.4.7	Auxiliary measurements	7-12
S2.6	Inverter Input	7-12
S2.7	DC Link	7-12
S2.8	Torque Current Limitation	7-12
S3	I/OS	7-13
S3.1	Slot X Status	7-13
S3.1.1	Analog Inputs	7-13
S3.1.2	Analog Outputs	7-13
S3.1.3	Digital Inputs	7-14
S3.1.4	Digital Outputs	7-14
S3.1.5	Encoder	7-15
S3.2	Slot A Status	7-16
S3.2.1	Analog Inputs	7-16
S3.2.2	Analog Outputs	7-16
S3.2.3	Digital Inputs	7-17
S3.2.4	Digital Outputs	7-18
S3.2.5	Encoder	7-19
S3.2.6	Temperatures	7-20

CONTENTS

S3.9 Control board	7-20
S3.9.1 Analog inputs	7-20
S3.9.2 Analog Outputs	7-20
S3.9.3 Digital Inputs	7-21
S3.9.4 Digital Outputs	7-21
S3.9.5 Encoder	7-22
S5 COMMUNICATIONS	7-23
S5.1 Status and Commands	7-23
S5.2 Serial RS485	7-25
S5.3 Ethernet	7-26
S5.4 EtherNet/IP	7-28
S5.5 Modbus TCP	7-29
S5.6 Anybus	7-30
S5.7 CAN/CANopen/DNet	7-31
S6 SOFTPLC	7-34
S6.1 Program Execution	7-34
S6.2 Control and References	7-34
8 D DIAGNOSTICS	8-1
D1 FAULTS	8-1
D2 ALARMS	8-3
D3 HOUR CONTROL	8-5
D4 INVERTER AND ACCESS.	8-5
D4.1 Inverter	8-5
D4.2 Accessories	8-7
9 C CONFIGURATIONS	9-1
C1 INVERTER AND POWER SUPPLY	9-1
C1.2 Inverter use	9-1
C1.6 Other inverter settings	9-1
C1.7 Control Accessories	9-2
C1.8 Measurements	9-2
C1.9 Precharge	9-3
C1.14 Sine filter	9-4
C2 MOTOR	9-5
C2.1 Motor data	9-5
C2.2 Motor model	9-7
C3 CONTROL	9-8
C3.1 Configuration	9-9
C3.2 Scalar control	9-9
C3.3 Vector control	9-18
C3.4 Current Limiter	9-35
C3.5 DC Link	9-37
C3.8 Flying Start	9-42
C3.9 Ride-Through	9-45
C3.11 Synchronous transfer	9-48
C3.14 Zero speed disable	9-50
C4 COMMANDS AND REFERENCES	9-51
C4.1 LOC/REM Mode Config.	9-51
C4.2 Commands	9-53
C4.3 References	9-61
C5 I/OS	9-70
C5.1 Slot X	9-70
C5.1.1 Analog inputs	9-70
C5.1.2 Analog outputs	9-73
C5.1.3 Digital inputs	9-76
C5.1.4 Digital outputs	9-77

C5.2 Slot A	9-81
C5.9 DO Operation Levels	9-90
C5.10 DOs delay	9-91
C5.11 Control board	9-93
C5.11.1 Analog inputs	9-93
C5.11.2 Analog outputs	9-93
C5.11.3 Digital outputs	9-95
C5.11.4 Encoder	9-95
C6 RAMPS	9-97
C6.1 Speed control	9-97
C6.2 Torque control	9-99
C7 PROTECTIONS	9-99
C7.1 Power supply	9-99
C7.2 Ground fault	9-100
C7.3 Motor current	9-101
C7.4 Motor overload fault	9-101
C7.5 Overtemperature	9-103
C7.6 DC Link	9-105
C7.7 Motor Overspeed	9-106
C7.9 Auto-Reset	9-106
C7.10 External Fault/Alarm	9-106
C7.11 Thermal management	9-107
C7.14 Encoder	9-112
C7.15 History	9-112
C7.17 Electric arc	9-113
C9 COMMUNICATIONS	9-113
C9.1 Communication Errors	9-113
C9.2 I/O Data	9-115
C9.3 Serial RS485	9-116
C9.4 Ethernet	9-117
C9.5 EtherNet/IP	9-120
C9.6 Modbus TCP	9-121
C9.7 Anybus	9-122
C9.8 CAN/CANopen/DNet	9-124
C9.10 SymbiNet	9-127
C10 SOFTPLC	9-134
C10.1 Configuration	9-134
C10.2 Engineering unit	9-135
C12 BACKUP	9-137
C13 NOMINAL DATA	9-144
C13.1 Inverter	9-144
10 A APPLICATION	10-1
A1 USER PARAMETERS	10-1
A2 PID CONTROLLER	10-1
A2.1 Monitoring	10-2
A2.2 Regulation	10-4
A2.2.1 Setpoint	10-4
A2.2.2 Gains	10-4
A2.3 Configuration	10-5
A2.3.1 Controle	10-5
A2.3.2 Setpoint	10-6
A2.3.3 Process variable	10-6
A2.3.4 Mode of operation	10-8
A2.3.5 Source of the commands	10-9
A2.3.6 Falhas e Alarmes	10-19
A2.3.7 Sleep mode	10-20
A3 MILL	10-23

CONTENTS

A3.1 Configurations10-23

A3.2 Frozen charge detection10-24

A3.3 Frozen charge release10-27

1 PARAMETER STRUCTURE

S Status

- ─ S1 Inverter
 - ─ S1.1 Status
 - ─ S1.2 Software version
 - ─ S1.4 Accessory data
 - ─ S1.4.1 Backplane
 - ─ S1.4.2 Slot A
 - ─ S1.4.3 Slot B
 - ─ S1.4.4 Slot C
 - ─ S1.4.5 Slot D
 - ─ S1.4.6 Slot E
 - ─ S1.4.7 Slot F
 - ─ S1.4.8 Slot G
 - ─ S1.4.9 Control board
 - ─ S1.5 Date/Hour
 - ─ S1.6 Control words
- ─ S2 Measurements
 - ─ S2.1 Motor speed
 - ─ S2.2 Motor Torque
 - ─ S2.3 Inverter Output
 - ─ S2.4 Temperatures
 - ─ S2.4.1 Temperature accessory
 - ─ S2.4.2 Thermal protection relay
 - ─ S2.4.3 Air temperature
 - ─ S2.4.4 Inverter arms
 - ─ S2.4.5 Rectifier temperature
 - ─ S2.4.6 Braking arms
 - ─ S2.4.7 Auxiliary measurements
 - ─ S2.6 Inverter Input
 - ─ S2.7 DC Link
 - ─ S2.8 Torque Current Limitation
- ─ S3 I/Os
 - ─ S3.1 Slot X Status
 - ─ S3.1.1 Analog Inputs
 - ─ S3.1.2 Analog Outputs
 - ─ S3.1.3 Digital Inputs
 - ─ S3.1.4 Digital Outputs
 - ─ S3.1.5 Encoder
 - ─ S3.2 Slot A Status
 - ─ S3.2.1 Analog Inputs
 - ─ S3.2.2 Analog Outputs
 - ─ S3.2.3 Digital Inputs
 - ─ S3.2.4 Digital Outputs
 - ─ S3.2.5 Encoder

S Status (cont.)

- ─ S3 I/Os (cont.)
 - ─ S3.2 Slot A Status (cont.)
 - ─ S3.2.6 Temperatures
 - ─ S3.3 Slot B Status
 - ─ S3.4 Slot C Status
 - ─ S3.5 Slot D Status
 - ─ S3.6 Slot E Status
 - ─ S3.7 Slot F Status
 - ─ S3.8 Slot G Status
 - ─ S3.9 Control board
 - ─ S3.9.1 Analog inputs
 - ─ S3.9.2 Analog Outputs
 - ─ S3.9.3 Digital Inputs
 - ─ S3.9.4 Digital Outputs
 - ─ S3.9.5 Encoder
- ─ S5 Communications
 - ─ S5.1 Status and Commands
 - ─ S5.2 Serial RS485
 - ─ S5.3 Ethernet
 - ─ S5.4 EtherNet/IP
 - ─ S5.5 Modbus TCP
 - ─ S5.6 Anybus
 - ─ S5.7 CAN/CANopen/DNet
- ─ S6 SoftPLC
 - ─ S6.1 Program Execution
 - ─ S6.2 Control and References

D Diagnostics

- ─ D1 Faults
 - ─ D1.1 Current
 - ─ D1.3 History
- ─ D2 Alarms
 - ─ D2.1 Actual
 - ─ D2.3 History
- ─ D3 Hour Control
- ─ D4 Inverter and access.
 - ─ D4.1 Inverter
 - ─ D4.1.4 Control Voltages
 - ─ D4.1.5 Motor Overl. Fault
 - ─ D4.1.11 Configuration
 - ─ D4.1.12 Advanced
 - ─ D4.1.13 Others
 - ─ D4.2 Accessories

D Diagnostics (cont.)

- ─ D4 Inverter and access. (cont.)
 - ─ D4.2 Accessories (cont.)
 - ─ D4.2.1 Diag. Slot A
 - ─ D4.2.2 Diag. Slot B
 - ─ D4.2.3 Diag. Slot C
 - ─ D4.2.4 Diag. Slot D
 - ─ D4.2.5 Diag. Slot E
 - ─ D4.2.6 Diag. Slot F
 - ─ D4.2.7 Diag. Slot G

C Configurations

- ─ C1 Inverter and power supply
 - ─ C1.2 Inverter use
 - ─ C1.6 Other inverter settings
 - ─ C1.7 Control Accessories
 - ─ C1.7.1 Slot A
 - ─ C1.7.2 Slot B
 - ─ C1.7.3 Slot C
 - ─ C1.7.4 Slot D
 - ─ C1.7.5 Slot E
 - ─ C1.7.6 Slot F
 - ─ C1.7.7 Slot G
 - ─ C1.8 Measurements
 - ─ C1.9 Precharge
 - ─ C1.14 Sine filter
- ─ C2 Motor
 - ─ C2.1 Motor data
 - ─ C2.2 Motor model
- ─ C3 Control
 - ─ C3.1 Configuration
 - ─ C3.2 Scalar control
 - ─ C3.2.1 V/f Curve
 - ─ C3.2.2 Optimization
 - ─ C3.2.2.1 Induction motor
 - ─ C3.2.2.2 Synchronous motor
 - ─ C3.2.2.3 Sync.mot.external excitation
 - ─ C3.2.3 Current stabilization
 - ─ C3.2.4 Pre-magnetization
 - ─ C3.3 Vector control
 - ─ C3.3.1 Configuration
 - ─ C3.3.2 Regulators
 - ─ C3.3.2.1 Speed regulator
 - ─ C3.3.2.2 Torque regulator

PARAMETER STRUCTURE

C Configurations (cont.)

- ─ C3 Control (cont.)
 - ─ C3.3 Vector control (cont.)
 - ─ C3.3.2 Regulators (cont.)
 - ─ C3.3.2.3 Flux regulator
 - ─ C3.3.2.4 Current regulator
 - ─ C3.3.2.6 Regulators self-tuning
 - ─ C3.3.3 Output Voltage Limiter
 - ─ C3.3.4 Torque Mode
 - ─ C3.3.4.1 Speed Limiter
 - ─ C3.3.5 Speed Mode
 - ─ C3.3.5.1 Torque Limiter
 - ─ C3.3.7 Speed Steady State Estimator
 - ─ C3.3.9 Online Param. Estimator
 - ─ C3.3.10 Maximum torque by Ampere
 - ─ C3.4 Current Limiter
 - ─ C3.5 DC Link
 - ─ C3.5.1 Voltage limit
 - ─ C3.5.2 Scalar control
 - ─ C3.5.3 Vector Control
 - ─ C3.5.4 Modulation compensation
 - ─ C3.8 Flying Start
 - ─ C3.8.1 Configuration
 - ─ C3.8.2 Scalar control
 - ─ C3.8.3 Vector Control
 - ─ C3.9 Ride-Through
 - ─ C3.9.1 Configuration
 - ─ C3.9.2 Scalar control
 - ─ C3.9.3 Vector control
 - ─ C3.11 Synchronous transfer
 - ─ C3.14 Zero speed disable
- ─ C4 Commands and references
 - ─ C4.1 LOC/REM Mode Config.
 - ─ C4.2 Commands
 - ─ C4.2.1 Remote R1
 - ─ C4.2.2 Remote R2
 - ─ C4.2.3 DI for commands
 - ─ C4.2.4 Local HMI
 - ─ C4.3 References
 - ─ C4.3.1 Speed
 - ─ C4.3.1.1 Reference range
 - ─ C4.3.1.2 Reference source
 - ─ C4.3.1.3 Ref. HMI, Als and FIs
 - ─ C4.3.1.4 Ref. electronic pot.

C Configurations (cont.)

- ─ C4 Commands and references (cont.)
 - ─ C4.3 References (cont.)
 - ─ C4.3.1 Speed (cont.)
 - ─ C4.3.1.5 Multispeed reference
 - ─ C4.3.1.6 Skip speed
 - ─ C4.3.2 JOG Speed
 - ─ C4.3.3 Torque
- ─ C5 I/Os
 - ─ C5.1 Slot X
 - ─ C5.1.1 Analog inputs
 - ─ C5.1.2 Analog outputs
 - ─ C5.1.3 Digital inputs
 - ─ C5.1.4 Digital outputs
 - ─ C5.2 Slot A
 - ─ C5.2.1 Analog inputs
 - ─ C5.2.2 Analog outputs
 - ─ C5.2.4 Digital outputs
 - ─ C5.2.6 Temperatures
 - ─ C5.3 Slot B
 - ─ C5.3.1 Analog inputs
 - ─ C5.3.2 Analog outputs
 - ─ C5.3.4 Digital outputs
 - ─ C5.3.6 Temperatures
 - ─ C5.4 Slot C
 - ─ C5.4.1 Analog inputs
 - ─ C5.4.2 Analog outputs
 - ─ C5.4.4 Digital outputs
 - ─ C5.4.6 Temperatures
 - ─ C5.5 Slot D
 - ─ C5.5.1 Analog inputs
 - ─ C5.5.2 Analog outputs
 - ─ C5.5.4 Digital outputs
 - ─ C5.5.6 Temperatures
 - ─ C5.6 Slot E
 - ─ C5.6.1 Analog inputs
 - ─ C5.6.2 Analog outputs
 - ─ C5.6.4 Digital outputs
 - ─ C5.6.6 Temperatures
 - ─ C5.7 Slot F
 - ─ C5.7.1 Analog inputs
 - ─ C5.7.2 Analog outputs
 - ─ C5.7.4 Digital outputs
 - ─ C5.7.6 Temperatures

C Configurations (cont.)

- ─ C5 I/Os (cont.)
 - ─ C5.8 Slot G
 - ─ C5.8.1 Analog inputs
 - ─ C5.8.2 Analog outputs
 - ─ C5.8.4 Digital outputs
 - ─ C5.8.6 Temperatures
 - ─ C5.9 DO Operation Levels
 - ─ C5.10 DOs delay
 - ─ C5.11 Control board
 - ─ C5.11.1 Analog inputs
 - ─ C5.11.2 Analog outputs
 - ─ C5.11.3 Digital outputs
 - ─ C5.11.4 Encoder
 - ─ C5.11.4.1 Absolute
 - ─ C5.11.4.2 Incremental
- ─ C6 Ramps
 - ─ C6.1 Speed control
 - ─ C6.2 Torque control
- ─ C7 Protections
 - ─ C7.1 Power supply
 - ─ C7.2 Ground fault
 - ─ C7.3 Motor current
 - ─ C7.4 Motor overload fault
 - ─ C7.5 Overtemperature
 - ─ C7.6 DC Link
 - ─ C7.7 Motor Overspeed
 - ─ C7.9 Auto-Reset
 - ─ C7.10 External Fault/Alarm
 - ─ C7.11 Thermal management
 - ─ C7.14 Encoder
 - ─ C7.15 History
 - ─ C7.16 Electronics power supply
 - ─ C7.17 Electric arc
- ─ C9 Communications
 - ─ C9.1 Communication Errors
 - ─ C9.1.1 Master Offline
 - ─ C9.1.2 Master Idle/Prog
 - ─ C9.2 I/O Data
 - ─ C9.2.1 Reading data
 - ─ C9.2.2 Writing data
 - ─ C9.3 Serial RS485
 - ─ C9.4 Ethernet
 - ─ C9.5 EtherNet/IP

C Configurations (cont.)

- C9 Communications (cont.)
 - C9.6 Modbus TCP
 - C9.7 Anybus
 - C9.8 CAN/CANopen/DNet
 - C9.10 SymbiNet
- C10 SoftPLC
 - C10.1 Configuration
 - C10.2 Engineering unit
- C12 Backup
- C13 Nominal data
 - C13.1 Inverter

A Application

- A1 User Parameters
- A2 PID Controller
 - A2.1 Monitoring
 - A2.2 Regulation
 - A2.2.1 Setpoint
 - A2.2.2 Gains
 - A2.3 Configuration
 - A2.3.1 Control
 - A2.3.2 Setpoint
 - A2.3.3 Process variable
 - A2.3.4 Mode of operation
 - A2.3.5 Source of the commands
 - A2.3.6 Faults and Alarms
 - A2.3.7 Sleep mode
- A3 Mill
 - A3.1 Configurations
 - A3.2 Frozen charge detection
 - A3.3 Frozen charge release

2 FAULTS AND ALARMS

Faults and Alarms are a functionality of the MVW that allows viewing events, helping troubleshooting or identifying improvements in the inverter parameter settings.

Actuation of Faults and Alarms:

- Faults actuate by disabling the motor and indicating on the HMI, in the MVW status word (S1.1.1) and in the diagnosis of actual fault (D1.1) the reason for its occurrence. They are only removed by resetting or turning off the inverter.
- The alarms actuate by displaying an indication on the HMI, in the MVW status word (S1.1.1) and the actual alarm diagnostics (D2.1). They are removed automatically after exiting the alarm condition.

Faults and Alarms are presented to the user through codes. The codes are made up of three or four numbers preceded by the letters F (for fault) and A (for alarm), as shown in [Table 2.1 on page 2-1](#). In this table it is also possible to obtain more details about its causes and possible solutions.



NOTE!

The cause of most of the faults and alarms can be checked and solved following the instructions in this chapter; otherwise, contact WEG technical support or a representative.

2.1 FAULT AND ALARM TABLE

Fault/Alarm	Description	Possible Causes
F0003: Under Voltage / Phase Loss	Inverter input voltage less than 70 %.	- Undervoltage in the power supply network. - Incorrect adjustment of the transformer primary taps.
F0006: Mains Unbalance/ Phase Loss	Voltage difference between phases greater than 10 % of the nominal value.	- Lack of phase in the power supply network.
A0008: Timeout in the synchronism with the input line	It was not possible to synchronize the inverter output voltage with the grid voltage.	
F0009: Incorrect status of the input cubicle	Incoherent wiring of DI3 and/or DI4 inputs on the PIC board.	- Improper maneuvering of the input circuit breaker. - Faulty input circuit breaker. - Faulty wiring.
F0013: Output contactor feedback	Output contactor failed to close or open.	- Defect in the DI6/DO8 connections of the output contactor drive and feedback function.
F0014: Input cubicle closing failure	Input circuit breaker does not close when commanded.	- Defective circuit breaker. - Wiring of the DI3 input of the PIC board (XC7:3) open (does not return +24 V) when closing the cubicle.
F0015: Input cubicle opening failure	Input circuit breaker does not open when commanded.	- Defective circuit breaker. - Wiring of the DI4 input of the PIC board (XC7:4) open (does not return +24 V) in the circuit breaker opening.
F0016: Shutdown by input cubicle protection	Actuation of the input circuit breaker protection related to the inverter main transformer.	- Wiring at input DI5 of the PIC board (XC7:5) is open (does not return +24 V).
F0017: Inverter not ready to energize	Input circuit breaker not ready when commanded to close.	- Defective circuit breaker. - Attempt to turn on the circuit breaker via DI1, while the inverter is indicating via DO1 that it is not able to close the circuit breaker.
A0018: Inverter main transformer alarm	Alarm on the inverter main transformer.	- Wiring of input DI11 of the PIC board (XC7:16) open (does not return +24 V).

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0019: Inverter main transformer fault	Inverter main transformer failure.	- Wiring of the DI12 input of the PIC board (XC8:1) open (does not return +24 V).
F0020: Pre-charge fault	Voltages on the DC link did not rise to the level necessary to complete the pre-charge process within the specified time.	- Incorrect adjustment of the primary tap of the auxiliary transformer. - Low voltage or lack of phase in the auxiliary power supply. - Fault in the pre-charge circuit contactors. - Optical fiber communication of one of the cells not connected, broken or defective.
F0025: Inverter door locking fault	Attempt to energize the inverter with the panel doors unlocked.	- Unlocking the doors with the inverter enabled or with the DC link energized. - Wiring at DI16 input of PIC board (XC8:10) open (does not return +24 V with doors closed).
F0026: Input cubicle not ready fault	Input circuit breaker indicating via DI2 that it is not available for operation.	- Faulty input circuit breaker. - Wiring of the DI2 input of the PIC board (XC7:2) open (does not return +24 V).
F0027: Improper opening of the input cubicle	Command to open the input circuit breaker with the inverter enabled.	- Wiring of the DI1 input of the PIC board (XC7:1) open (does not return +24 V).
F0031: Sensor A - Electrical arcing detection fault	Electrical arcing detection by the panel sensor A.	- Optical fiber OPTO IN (3) on the CCE board not connected, broken or defective.
F0032: Sensor B - Electrical arcing detection fault	Electrical arcing detection by the panel sensor B.	- Optical fiber OPTO IN (2) on the CCE board not connected, broken or defective.
F0033: Sensor C - Electrical arcing detection fault	Electrical arcing detection by the panel sensor C.	- Optical fiber OPTO IN (1) on the CCE board not connected, broken or defective.
F0034: Sensor 1 - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 1.	- Optical fiber RX 53 of the CIB board of CN1 not connected, broken or defective.
F0035: Sensor 2 - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 2.	- Optical fiber RX 54 of the CIB board of CN1 not connected, broken or defective.
F0036: Sensor 3 - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 3.	- Optical fiber RX 55 of the CIB board of CN1 not connected, broken or defective.
F0037: Sensor 4 - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 4.	- Optical fiber RX 56 of the CIB board of CN1 not connected, broken or defective.
F0038: Sensor 5 - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 5.	- Optical fiber RX 57 of the CIB board of CN1 not connected, broken or defective.
F0039: Sensor 6 - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 6.	- Optical fiber RX 53 of the CIB board of CN2 not connected, broken or defective.
F0040: Sensor 7 - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 7.	- Optical fiber RX 54 of the CIB board of CN2 not connected, broken or defective.
F0041: Sensor 8 - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 8.	- Optical fiber RX 55 of the CIB board of CN2 not connected, broken or defective.
F0042: Sensor 9 - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 9.	- Optical fiber RX 56 of the CIB board of CN2 not connected, broken or defective.
F0043: Sensor 10 - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 10.	- Optical fiber RX 57 of the CIB board of CN2 not connected, broken or defective.
A0046: Motor lxt function overload	Motor shaft load too high.	- P0156, P0157 and P0158 settings too low for the motor used. - P0159 setting too low for the motor used. - P0136 and P0137 setting too high (valid for low speed operation).

Fault/Alarm	Description	Possible Causes
F0048: Forced ventilation fault	Forced ventilation failure.	- Blocked fans. - Clogged air intake filters.
A0049: Phase U heatsink overtemperature	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0050: Phase V heatsink overtemperature	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0051: Phase W heatsink overtemperature	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0052: Phase U heatsink overtemperature	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0053: Phase V heatsink overtemperature	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0054: Phase W heatsink overtemperature	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0055: Phase UB heatsink overtemperature	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0056: Phase VB heatsink overtemperature	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0057: Phase WB heatsink overtemperature	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0058: Phase UBp heatsink overtemperature	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0059: Phase VBp heatsink overtemperature	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0060: Phase WBp heatsink overtemperature	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
F0069: Calibration fault		
F0070: Overcurrent/short circuit	Instantaneous current at the inverter output greater than twice the nominal current (Hardware detection).	- Short circuit between two motor phases or power cables (hardware detection). - Load inertia too high or acceleration ramp too fast. - Incorrect regulation and/or configuration parameter(s). - Protection parameters set too high. - Cell IGBT modules short circuited.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0071: Overcurrent at output	Ixt function output overload.	- Short circuit between two phases of the motor or power cables (software detection). - Load inertia too high or acceleration ramp too fast. - Incorrect regulation and/or configuration parameter(s). - Protection parameters set too high.
F0072: Output over load Ixt function	Imbalance in output currents	- Bad contact or cable disconnected from the motor. - Current feedback circuit failure. - Difference between output currents greater than 12.5 % of the nominal current for a time longer than permitted.
F0073: Iu overcurrent	Instantaneous current value above the permissible limit.	- Inverter output overload. - Sudden load variation. - Inadequate acceleration or deceleration ramp. - Defect in current sensors.
F0074: Iv overcurrent	Instantaneous current value above the permissible limit.	- Inverter output overload. - Sudden load variation. - Inadequate acceleration or deceleration ramp. - Defect in current sensors.
F0075: Iw overcurrent	Instantaneous current value above the permissible limit.	- Inverter output overload. - Sudden load variation. - Inadequate acceleration or deceleration ramp. - Defect in current sensors.
F0076: Output current unbalanced	Difference between output currents greater than 12.5 % of the nominal current for a time longer than permitted.	- Bad contact or cable disconnected from the motor. - Current feedback circuit failure.
F0077: Failure feedback of voltage between the Medium Point DC Link and ground	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0078: Motor Over Temperature	Motor temperature higher than the fault level programmed in the thermal protection relay.	- Digital input signal, coming from the protection relay, programmed for "Motor failure" at low level.
F0079: Speed sensor	Faulty motor speed sensor signals.	- Defective wiring between motor speed sensor and inverter interface board. - Cable length greater than the specified maximum limit. - Motorspeed sensor mounting error. - Incorrect parameterization of the number of pulses per encoder revolution.
A0080: Speed sensor	Faulty motor speed sensor signals.	- Defective wiring between motor speed sensor and inverter interface board. - Cable length greater than the specified maximum limit. - Motorspeed sensor mounting error. - Incorrect parameterization of the number of pulses per encoder revolution.
F0085: Electronic power supply fault	Source monitoring signal remains indicating electronic sources not OK.	
F0087: Watchdog protection between control boards	Watchdog protection detected a break in the communication link between the control boards and restarted the system.	- Damaged communication cable and/or connector between control boards. - Cable disconnected or broken.
F0088: Watchdog protection on the control board	Watchdog protection detected an error and restarted the system.	

Fault/Alarm	Description	Possible Causes
F0092: Pre-charge power supply	PIC board DI7 input wiring (XC7:16) open (does not return +24 V).	- Short circuit in the pre-charge system. - Defective pre-charge capacitors and/or resistors. - Pre-charge circuit breaker open. - Problems with the auxiliary pre-charge inverter.
A0093: Rectifier ventilation failure - Set A	Redundant fan assembly A failure alarm.	- Clogged fans. - Clogged air inlet filters.
A0094: Cooling system supply fault	Power alarm in the refrigeration system.	- Short circuit in the ventilation system. - Fan blocked. - Circuit breakers supplying the inverter ventilation assembly open. - Wiring of the DI10 input of the PIC board (XC7:15) open (does not return +24 V).
F0095: PS1 power supply failure	- PIC board DI8 Wiring (XC7: 13) Open (does not return +24 V).	Broken or defective wiring.
F0099: Invalid output current offset	Output current measurement offset outside the allowable range.	- Defect in the output current measurement circuit.
F0100: Control board self-diagnosis	The control board application had execution problems.	
F0101: Communication failure with the aui board	Communication with the AUI user interface board was not performed correctly.	- AUI user interface board disconnected from CCE control board. - Defective connection cable between AUI and CCE.
F0102: Communication timeout with the AUI board	The CCE control board detected a loss of telegrams in communication with the AUI user interface board.	- AUI user interface board disconnected from CCE control board. - Problem with the power supply of the control boards. - Defective connection cable between AUI and CCE.
A0110: Motor overtemperature alarm	Motor temperature higher than the alarm level programmed in the thermal protection relay.	- Digital input signal, coming from the protection relay, programmed for "Motor alarm" at low level.
F0112: Motor Over Speed	Motorspeed above programmed limit.	- High mechanical acceleration torque under load.
A0118: Pre-charge power supply	PIC board DI7 input wiring (XC7:16) open (does not return +24 V).	- Short circuit in the pre-charge system. - Defective pre-charge capacitors. - Defective pre-charge resistors. - Pre-charge circuit breaker open. - Problems with the auxiliary pre-charge inverter.
F0119: Phase U heatsink overtemperature	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0120: Phase V heatsink overtemperature	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0121: Phase W heatsink overtemperature	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0122: Phase UAp heatsink overtemperature	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0123: Phase VAp heatsink overtemperature	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0124: Phase WAp heatsink overtemperature	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0125: Phase UB heatsink overtemperature	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0126: Phase VB heatsink overtemperature	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0127: Phase WB heatsink overtemperature	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0128: Phase UBp heatsink overtemperature	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0129: Phase VBp heatsink overtemperature	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0130: Phase WBp heatsink overtemperature	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0134: Phase U heatsink temperature feedback	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0135: Phase V heatsink temperature feedback	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0136: Phase W heatsink temperature feedback	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0137: Phase UAp heatsink temperature feedback	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0138: Phase VAp heatsink temperature feedback	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0139: Phase WAp heatsink temperature feedback	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.

Fault/Alarm	Description	Possible Causes
F0140: Phase UB heatsink temperature feedback	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0141: Phase VB heatsink temperature feedback	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0142: Phase WB heatsink temperature feedback	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0143: Phase UBp heatsink temperature feedback	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0144: Phase VBp heatsink temperature feedback	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0145: Phase WBp heatsink temperature feedback	The temperature of the superior 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0146: PS1 1 power supply failure		- Non connected, inverted or defective optical fiber.
F0147: PS1 2 power supply failure		- Non connected, inverted or defective optical fiber.
F0148: PS1 3 power supply failure		- Non connected, inverted or defective optical fiber.
F0149: PS1 4 power supply failure		- Non connected, inverted or defective optical fiber.
F0150: Positive DC link overvoltage	DC link overvoltage.	- Supply voltage too high, resulting in a DC link voltage (S2.7.1) above the maximum value: - Driven load inertia too high or deceleration ramp too fast. - Setting C3.5.2.1 or C3.5.3.2 too high.
F0151: Phase U positive DC link overvoltage	DC link overvoltage.	- Supply voltage too high, resulting in a DC link voltage (S2.7.1) above the maximum value: - Driven load inertia too high or deceleration ramp too fast. - Setting C3.5.2.1 or C3.5.3.2 too high.
F0152: Phase V positive DC link overvoltage	DC link overvoltage.	- Supply voltage too high, resulting in a DC link voltage (S2.7.1) above the maximum value: - Driven load inertia too high or deceleration ramp too fast. - Setting C3.5.2.1 or C3.5.3.2 too high.
F0153: Phase W positive DC link overvoltage	DC link overvoltage.	- Supply voltage too high, resulting in a DC link voltage (S2.7.1) above the maximum value: - Driven load inertia too high or deceleration ramp too fast. - Setting C3.5.2.1 or C3.5.3.2 too high.
F0154: Negative DC link overvoltage	DC link overvoltage.	- Supply voltage too high, resulting in a DC link voltage (S2.7.1) above the maximum value: - Driven load inertia too high or deceleration ramp too fast. - Setting C3.5.2.1 or C3.5.3.2 too high.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0155: Phase U negative DC link overvoltage	DC link overvoltage.	- Supply voltage too high, resulting in a DC link voltage (S2.7.1) above the maximum value: - Driven load inertia too high or deceleration ramp too fast. - Setting C3.5.2.1 or C3.5.3.2 too high.
F0156: Phase V negative DC link overvoltage	DC link overvoltage.	- Supply voltage too high, resulting in a DC link voltage (S2.7.1) above the maximum value: - Driven load inertia too high or deceleration ramp too fast. - Setting C3.5.2.1 or C3.5.3.2 too high.
F0157: Phase W negative DC link overvoltage	DC link overvoltage.	- Supply voltage too high, resulting in a DC link voltage (S2.7.1) above the maximum value: - Driven load inertia too high or deceleration ramp too fast. - Setting C3.5.2.1 or C3.5.3.2 too high.
F0158: DC link overvoltage	DC link overvoltage.	- Supply voltage too high, resulting in a DC link voltage (S2.7.1) above the maximum value: - Driven load inertia too high or deceleration ramp too fast. - Setting C3.5.2.1 or C3.5.3.2 too high.
F0159: Phase U DC link overvoltage	DC link overvoltage.	- Supply voltage too high, resulting in a DC link voltage (S2.7.1) above the maximum value: - Driven load inertia too high or deceleration ramp too fast. - Setting C3.5.2.1 or C3.5.3.2 too high.
F0160: Phase V DC link overvoltage	DC link overvoltage.	- Supply voltage too high, resulting in a DC link voltage (S2.7.1) above the maximum value: - Driven load inertia too high or deceleration ramp too fast. - Setting C3.5.2.1 or C3.5.3.2 too high.
F0161: Phase W DC link overvoltage	DC link overvoltage.	- Supply voltage too high, resulting in a DC link voltage (S2.7.1) above the maximum value: - Driven load inertia too high or deceleration ramp too fast. - Setting C3.5.2.1 or C3.5.3.2 too high.
F0162: Positive DC link undervoltage	Undervoltage on the DC link.	- Supply voltage too low, producing voltage on the DC link (S2.7.1) below the minimum value. - Input phase loss. - Fault on the pre-charge circuit. - Parameter C13.1.1 with a value above the rated grid voltage.
F0163: Phase U positive DC link undervoltage	Undervoltage on the DC link.	- Supply voltage too low, producing voltage on the DC link (S2.7.1) below the minimum value. - Input phase loss. - Fault on the pre-charge circuit. - Parameter C13.1.1 with a value above the rated grid voltage.
F0164: Phase V positive DC link undervoltage	Undervoltage on the DC link.	- Supply voltage too low, producing voltage on the DC link (S2.7.1) below the minimum value. - Input phase loss. - Fault on the pre-charge circuit. - Parameter C13.1.1 with a value above the rated grid voltage.
F0165: Phase W positive DC link undervoltage	Undervoltage on the DC link.	- Supply voltage too low, producing voltage on the DC link (S2.7.1) below the minimum value. - Input phase loss. - Fault on the pre-charge circuit. - Parameter C13.1.1 with a value above the rated grid voltage.

Fault/Alarm	Description	Possible Causes
F0166: Negative DC link undervoltage	Undervoltage on the DC link.	- Supply voltage too low, producing voltage on the DC link (S2.7.1) below the minimum value. - Input phase loss. - Fault on the pre-charge circuit. - Parameter C13.1.1 with a value above the rated grid voltage.
F0167: Phase U negative DC link undervoltage	Undervoltage on the DC link.	- Supply voltage too low, producing voltage on the DC link (S2.7.1) below the minimum value. - Input phase loss. - Fault on the pre-charge circuit. - Parameter C13.1.1 with a value above the rated grid voltage.
F0168: Phase V negative DC link undervoltage	Undervoltage on the DC link.	- Supply voltage too low, producing voltage on the DC link (S2.7.1) below the minimum value. - Input phase loss. - Fault on the pre-charge circuit. - Parameter C13.1.1 with a value above the rated grid voltage.
F0169: Phase W negative DC link undervoltage	Undervoltage on the DC link.	- Supply voltage too low, producing voltage on the DC link (S2.7.1) below the minimum value. - Input phase loss. - Fault on the pre-charge circuit. - Parameter C13.1.1 with a value above the rated grid voltage.
F0170: DC link undervoltage	Undervoltage on the DC link.	- Supply voltage too low, producing voltage on the DC link (S2.7.1) below the minimum value. - Input phase loss. - Fault on the pre-charge circuit. - Parameter C13.1.1 with a value above the rated grid voltage.
F0171: Phase U DC link undervoltage	Undervoltage on the DC link.	- Supply voltage too low, producing voltage on the DC link (S2.7.1) below the minimum value. - Input phase loss. - Fault on the pre-charge circuit. - Parameter C13.1.1 with a value above the rated grid voltage.
F0172: Phase V DC link undervoltage	Undervoltage on the DC link.	- Supply voltage too low, producing voltage on the DC link (S2.7.1) below the minimum value. - Input phase loss. - Fault on the pre-charge circuit. - Parameter C13.1.1 with a value above the rated grid voltage.
F0173: Phase W DC link undervoltage	Undervoltage on the DC link.	- Supply voltage too low, producing voltage on the DC link (S2.7.1) below the minimum value. - Input phase loss. - Fault on the pre-charge circuit. - Parameter C13.1.1 with a value above the rated grid voltage.
F0174: DC link unbalance	Voltage difference between positive and negative DC Link >15 % of the rated value.	
F0175: Phase U DC link unbalance	Voltage difference between positive and negative DC Link >15 % of the rated value.	
F0176: Phase V DC link unbalance	Voltage difference between positive and negative DC Link >15 % of the rated value.	
F0177: Phase W DC link unbalance	Voltage difference between positive and negative DC Link >15 % of the rated value.	

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0178: Positive DC link voltage feedback	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0179: Phase U positive DC link voltage feedback	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0180: Phase V positive DC link voltage feedback	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0181: Phase W positive DC link voltage feedback	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0182: Negative DC link voltage feedback	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0183: Phase U negative DC link voltage feedback	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0184: Phase V negative DC link voltage feedback	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0185: Phase W negative DC link voltage feedback	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0186: Verifying commands from switch A U1 on the interface	The verification routine detected an inconsistency in the switch commands between the control board and the interface board.	- Connection cable between the CCE board and CIB is defective or not properly connected. - Defect in the 50-way connector of the CCE board. - Defect in the 50-way connector of the CIB board.
F0187: Verifying commands from switch A U2 on the interface	The verification routine detected an inconsistency in the switch commands between the control board and the interface board.	- Connection cable between the CCE board and CIB is defective or not properly connected. - Defect in the 50-way connector of the CCE board. - Defect in the 50-way connector of the CIB board.
F0188: Verifying commands from switch A U3 on the interface	The verification routine detected an inconsistency in the switch commands between the control board and the interface board.	- Connection cable between the CCE board and CIB is defective or not properly connected. - Defect in the 50-way connector of the CCE board. - Defect in the 50-way connector of the CIB board.
F0189: Verifying commands from switch A U4 on the interface	The verification routine detected an inconsistency in the switch commands between the control board and the interface board.	- Connection cable between the CCE board and CIB is defective or not properly connected. - Defect in the 50-way connector of the CCE board. - Defect in the 50-way connector of the CIB board.
F0190: Verifying commands from switch A V1 on the interface	The verification routine detected an inconsistency in the switch commands between the control board and the interface board.	- Connection cable between the CCE board and CIB is defective or not properly connected. - Defect in the 50-way connector of the CCE board. - Defect in the 50-way connector of the CIB board.
F0191: Verifying commands from switch A V2 on the interface	The verification routine detected an inconsistency in the switch commands between the control board and the interface board.	- Connection cable between the CCE board and CIB is defective or not properly connected. - Defect in the 50-way connector of the CCE board. - Defect in the 50-way connector of the CIB board.
F0192: Verifying commands from switch A V3 on the interface	The verification routine detected an inconsistency in the switch commands between the control board and the interface board.	- Connection cable between the CCE board and CIB is defective or not properly connected. - Defect in the 50-way connector of the CCE board. - Defect in the 50-way connector of the CIB board.
F0193: Verifying commands from switch A V4 on the interface	The verification routine detected an inconsistency in the switch commands between the control board and the interface board.	- Connection cable between the CCE board and CIB is defective or not properly connected. - Defect in the 50-way connector of the CCE board. - Defect in the 50-way connector of the CIB board.
F0194: Verifying commands from switch A W1 on the interface	The verification routine detected an inconsistency in the switch commands between the control board and the interface board.	- Connection cable between the CCE board and CIB is defective or not properly connected. - Defect in the 50-way connector of the CCE board. - Defect in the 50-way connector of the CIB board.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0209: Verifying commands from switch B W4 on the interface	The verification routine detected an inconsistency in the switch commands between the control board and the interface board.	- Connection cable between the CCE board and CIB is defective or not properly connected. - Defect in the 50-way connector of the CCE board. - Defect in the 50-way connector of the CIB board.
F0256: Output transformer fault	Digital input programmed for "Transformer OK" Open (does not return +24 V).	- For more details on the function of this DI, consult the inverter design.
F0257: Pressurization system fault	Digital input programmed for "Pressurization system OK" Open (does not return +24 V).	- For more details on the function of this DI, consult the inverter design.
F0258: Output filter fault	Digital input programmed for "Output Filter OK" Open (does not return +24 V).	- For more details on the function of this DI, consult the inverter design.
F0259: Exciter fault	Digital input programmed for "Exciter OK" Open (does not return +24 V).	- For more details on the function of this DI, consult the inverter design.
F0260: Communication with the position sensor	Faulty speed sensor.	- Defective wiring between motor speed sensor and inverter interface board. - Cable length greater than the specified maximum limit. - Motorspeed sensor mounting error. - Incorrect encoder parameterization.
A0261: Direction of rotation between input voltage and current is inverted	Inverted connections between the terminals of the transformer auxiliary windings and the input voltage measuring ISOC2.	- Input CTs mounted on the wrong phases of the transformers. - Incorrect connection of the current transformers of the transformers in ISOC2. - Inverted measurement fibers between the input ISOC2 and the control rack. - See parameter D4.1.13.4 to check the direction of rotation identified by the software for the measurements.
A0262: Direction of rotation between the output current and voltage is inverted	Inverted connections between the output terminals and the electronic output voltage measurement board.	- Output CTs mounted on the wrong output phases. - Incorrect connection of the output current transformers on the PIC board. - Inverted measurement fibers between the output voltage measurement electronic board and the control rack. - See parameter D4.1.13.4 to check the direction of rotation identified by the software for the measurements.
F0263: Timeout on output contactor activation	The condition for commanding the closing of the output contactor was not met.	
F0269: Sensor 1E - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 1 extra.	- Optical fiber RX 15 of the CIB board of CN1 not connected, broken or defective.
F0270: Sensor 2E - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 2 extra.	- Optical fiber RX 30 of the CIB board of CN1 not connected, broken or defective.
F0271: Sensor 3E - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 3 extra.	- Optical fiber RX 31 of the CIB board of CN1 not connected, broken or defective.
F0272: Sensor 4E - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 4 extra.	- Optical fiber RX 51 of the CIB board of CN1 not connected, broken or defective.
F0273: Sensor 5E - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 5 extra.	- Optical fiber RX 52 of the CIB board of CN1 not connected, broken or defective.

Fault/Alarm	Description	Possible Causes
F0274: Sensor 6E - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 6 extra.	- Optical fiber RX 15 of the CIB board of CN2 not connected, broken or defective.
F0275: Sensor 7E - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 7 extra.	- Optical fiber RX 30 of the CIB board of CN2 not connected, broken or defective.
F0276: Sensor 8E - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 8 extra.	- Optical fiber RX 31 of the CIB board of CN2 not connected, broken or defective.
F0277: Sensor 9E - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 9 extra.	- Optical fiber RX 51 of the CIB board of CN2 not connected, broken or defective.
F0278: Sensor 10E - Electrical arcing detection fault	Electrical arcing detection by the panel sensor 10 extra.	- Optical fiber RX 52 of the CIB board of CN2 not connected, broken or defective.
A0301: Input undervoltage	Inverter input voltage less than 75.0 %.	- Undervoltage in the power supply network. - Incorrect adjustment of the transformer primary taps.
A0302: Input overvoltage	Inverter input voltage greater than 114 %.	- Overvoltage in the power supply network. - Incorrect adjustment of the transformer primary taps.
F0303: Input undervoltage	Inverter input voltage less than 70 %.	- Undervoltage in the power supply network. - Incorrect adjustment of the transformer primary taps.
F0304: Input overvoltage	Inverter input voltage greater than 117 %.	- Overvoltage in the power supply network. - Incorrect adjustment of the transformer primary taps.
F0305: Input unbalance/phase loss	Voltage difference between phases greater than 40 % of the nominal value. Voltage in any phase less than 30 % of nominal value.	- Lack of phase in the power supply network.
F0309: Timeout in Ride-Through state Waiting Line	Network return time greater than scheduled time. Voltage in any phase less than 30 % of nominal value.	- Inverter input voltage less than 80 %. - Undervoltage in the power supply network. - Incorrect adjustment of the transformer primary taps.
F0310: Short circuit on the transformer 1 secondary	Short circuit in the input transformer secondary cables.	- Short circuit in the input transformer secondary coils. - Defect in the transformer current measurement circuit. - Defect in the input voltage measurement circuit. - Incorrect configuration of input transformer parameters. - Inversion of the inverter input cables (RTS or 132 phase sequence).
A0315: Ground fault for neutral shift	Voltage between the motor virtual neutral and the system ground greater than 25 % of the motor phase voltage value.	- Failure in the ground insulation of the connection cables or the load driven by the inverter.
F0316: Ground fault for neutral shift	Voltage between the motor's virtual neutral and the system ground greater than 50 % of the motor's phase voltage value for a time greater than 0.5 s.	- Failure in the ground insulation of the connection cables or the load driven by the inverter.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0317: Ground fault for current leak	The sum of the three output currents is greater than 12.5 % of the inverter's rated current.	- Failure of the ground insulation in the connection cables or in the load driven by the inverter with the presence of current leakage. - Defective output current measurement sensors.
F0320: Vab measurement feedback fault	Fault in the line voltage feedback circuit between phases A and B at the inverter input.	- Vab optical fiber not connected, inverted or defective.
F0321: Vbc measurement feedback fault	Fault in the line voltage feedback circuit between phases B and C at the inverter input.	- Vbc optical fiber not connected, inverted or defective.
F0323: Ib_1 measurement feedback fault	Fault in the B phase current feedback circuit at the inverter input.	- Optical fiber Ib_1 not connected, inverted or defective.
F0324: Ic_1 measurement feedback fault	Fault in the C phase current feedback circuit at the inverter input.	- Optical fiber Ic_1 not connected, inverted or defective.
F0325: Vuv measurement feedback fault	Fault in the feedback circuit of the line voltage measured between phases U and V at the inverter output.	- Vuv optical fiber not connected, inverted or defective.
F0326: Vvw measurement feedback fault	Fault in the feedback circuit of the line voltage measured between phases V and W at the inverter output.	- Vvw optical fiber not connected, inverted or defective.
F0327: Vn_gnd measurement feedback fault	Fault in the voltage feedback circuit between the motor's virtual neutral and the system ground.	- Optical fiber N_GND not connected, inverted or defective.
F0328: Ib_2 measurement feedback fault	Fault in the B phase current feedback circuit at the inverter input.	- Optical fiber Ib_2 not connected, inverted or defective.
F0329: Ic_2 measurement feedback fault	Fault in the C phase current feedback circuit at the inverter input.	- Optical fiber Ic_2 not connected, inverted or defective.
F0330: Ib_3 measurement feedback fault	Fault in the B phase current feedback circuit at the inverter input.	- Optical fiber Ib_3 not connected, inverted or defective.
F0331: Ic_3 measurement feedback fault	Fault in the C phase current feedback circuit at the inverter input.	- Optical fiber Ic_3 not connected, inverted or defective.
F0333: Feedback failure in the Vab measurement of the connection to the output	Fault in the line voltage feedback circuit between phases A and B at the inverter output.	- Vab optical fiber not connected, inverted or defective.
F0334: Feedback failure in the Vbc measurement of the connection to the output	Fault in the line voltage feedback circuit between phases B and C at the inverter output.	- Vab optical fiber not connected, inverted or defective.
F0343: Short circuit on the transformer 2 secondary	Short circuit in the input transformer secondary cables.	- Short circuit in the input transformer secondary coils. - Defect in the transformer current measurement circuit. - Defect in the input voltage measurement circuit. - Incorrect configuration of input transformer parameters. - Inversion of the inverter input cables (RTS or 132 phase sequence).

Fault/Alarm	Description	Possible Causes
F0346: Short circuit on the transformer 3 secondary	Short circuit in the input transformer secondary cables.	- Short circuit in the input transformer secondary coils. - Defect in the transformer current measurement circuit. - Defect in the input voltage measurement circuit. - Incorrect configuration of input transformer parameters. - Inversion of the inverter input cables (RTS or 132 phase sequence).
F0353: Late response failure of CN1 connector cells	Cells linked to the CIB are showing inappropriate responses.	
F0354: Late response failure of CN2 connector cells	Cells linked to the CIB are showing inappropriate responses.	
F0355: CIB board improper response failure	The CIB board is responding inappropriately.	
F0356: Communication failure between CIB 1 and CCE	The CIB interface board's self-diagnosis routines detected communication problems with the CCE control board.	- Problems in the connection between the CIB and the CCE control board.
F0357: Communication Failure between CIB 2 and CCE	The CIB interface board's self-diagnosis routines detected communication problems with the CCE control board.	- Problems in the connection between the CIB and the CCE control board.
F0358: CIB execution failure of CN1 connector	The CIB interface board's self-diagnosis routines have detected a critical problem.	
F0359: CIB execution failure of CN2 connector.	The CIB interface board's self-diagnosis routines have detected a critical problem.	
F0360: Communication failure between CCE and CIB	The CCE control board's self-diagnosis routines have detected a critical problem in communication with the CIB board.	
F0361: CIB 1 board connection failure	The connection to the CIB interface board is not working properly.	- CIB interface board disconnected. - Problems with the connector between the CIB board and the CCE.
F0362: CIB 2 board Connection Failure	The connection to the CIB interface board is not working properly.	- CIB interface board disconnected. - Problems with the connector between the CIB board and the CCE. - Incorrect parameterization of the inverter's nominal voltage.
F0364: Modulator watchdog failure	Problems with the modulator control.	- Defect in the CCE electronic board.
F0365: Minimum time detection	Modulator command with shorter duration than allowed.	- Defect in the CCE electronic board.
F0366: Improper connection of a CIB interface board	An unconfigured CIB interface board communicated with the CCE control board.	- CIB interface board improperly connected to the control board.
F0400: Acknowledge fault gate driver A U1	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0401: Acknowledge fault gate driver A U2	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0402: Acknowledge fault gate driver A U3	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0403: Acknowledge fault gate driver A U4	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0404: Acknowledge fault gate driver A V1	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0405: Acknowledge fault gate driver A V2	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0406: Acknowledge fault gate driver A V3	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0407: Acknowledge fault gate driver A V4	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0408: Acknowledge fault gate driver A W1	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0409: Acknowledge fault gate driver A W2	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0410: Acknowledge fault gate driver A W3	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0411: Acknowledge fault gate driver A W4	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0412: Acknowledge fault gate driver Ap U1	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.

Fault/Alarm	Description	Possible Causes
F0413: Acknowledge fault gate driver Ap U2	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0414: Acknowledge fault gate driver Ap U3	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0415: Acknowledge fault gate driver Ap U4	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0416: Acknowledge fault gate driver Ap V1	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0417: Acknowledge fault gate driver Ap V2	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0418: Acknowledge fault gate driver Ap V3	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0419: Acknowledge fault gate driver Ap V4	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0420: Acknowledge fault gate driver Ap W1	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0421: Acknowledge fault gate driver Ap W2	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0422: Acknowledge fault gate driver Ap W3	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0423: Acknowledge fault gate driver Ap W4	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0424: Acknowledge fault gate driver B U1	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0425: Acknowledge fault gate driver B U2	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0426: Acknowledge fault gate driver B U3	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0427: Acknowledge fault gate driver B U4	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0428: Acknowledge fault gate driver B V1	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0429: Acknowledge fault gate driver B V2	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0430: Acknowledge fault gate driver B V3	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0431: Acknowledge fault gate driver B V4	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0432: Acknowledge fault gate driver B W1	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0433: Acknowledge fault gate driver B W2	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0434: Acknowledge fault gate driver B W3	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0435: Acknowledge fault gate driver B W4	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0436: Acknowledge fault gate driver Bp U1	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.

Fault/Alarm	Description	Possible Causes
F0437: Acknowledge fault gate driver Bp U2	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0438: Acknowledge fault gate driver Bp U3	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0439: Acknowledge fault gate driver Bp U4	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0440: Acknowledge fault gate driver Bp V1	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0441: Acknowledge fault gate driver Bp V2	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0442: Acknowledge fault gate driver Bp V3	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0443: Acknowledge fault gate driver Bp V4	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0444: Acknowledge fault gate driver Bp W1	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0445: Acknowledge fault gate driver Bp W2	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0446: Acknowledge fault gate driver Bp W3	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0447: Acknowledge fault gate driver Bp W4	The gate driver did not indicate that a switching command was received.	- Gate driver defect. - Optical fibers connecting the gate driver to the CIB board are disconnected or defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0448: IGBT A U1 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0449: IGBT A U2 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0450: IGBT A U3 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0451: IGBT A U4 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0452: IGBT A V1 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0453: IGBT A V2 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0454: IGBT A V3 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0455: IGBT A V4 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0456: IGBT A W1 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0457: IGBT A W2 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0458: IGBT A W3 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0459: IGBT A W4 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0460: IGBT Ap U1 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.

Fault/Alarm	Description	Possible Causes
F0461: IGBT Ap U2 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0462: IGBT Ap U3 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0463: IGBT Ap U4 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0464: IGBT Ap V1 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0465: IGBT Ap V2 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0466: IGBT Ap V3 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0467: IGBT Ap V4 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0468: IGBT Ap W1 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0469: IGBT Ap W2 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0470: IGBT Ap W3 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0471: IGBT Ap W4 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0472: IGBT B U1 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0473: IGBT B U2 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0474: IGBT B U3 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0475: IGBT B U4 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0476: IGBT B V1 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0477: IGBT B V2 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0478: IGBT B V3 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0479: IGBT B V4 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0480: IGBT B W1 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0481: IGBT B W2 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0482: IGBT B W3 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0483: IGBT B W4 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0484: IGBT Bp U1 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.

Fault/Alarm	Description	Possible Causes
F0485: IGBT Bp U2 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0486: IGBT Bp U3 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0487: IGBT Bp U4 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0488: IGBT Bp V1 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0489: IGBT Bp V2 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0490: IGBT Bp V3 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0491: IGBT Bp V4 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0492: IGBT Bp W1 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0493: IGBT Bp W2 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0494: IGBT Bp W3 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0495: IGBT Bp W4 failure	The gate driver indicated a short circuit in the IGBT.	- IGBT defect. - Optical fibers that connect the gate driver to the CIB board are not connected or are defective. - Maximum acknowledge signal waiting time parameter configured incorrectly.
F0496: Feedback failure in gate driver A U1	Problem found in the gate driver return optical fiber.	- Defective gate driver. - Gate driver return optical fiber disconnected or incorrectly connected to the CIB board.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0533: Feedback failure in gate driver Bp U2	Problem found in the gate driver return optical fiber.	- Defective gate driver. - Gate driver return optical fiber disconnected or incorrectly connected to the CIB board.
F0534: Feedback failure in gate driver Bp U3	Problem found in the gate driver return optical fiber.	- Defective gate driver. - Gate driver return optical fiber disconnected or incorrectly connected to the CIB board.
F0535: Feedback failure in gate driver Bp U4	Problem found in the gate driver return optical fiber.	- Defective gate driver. - Gate driver return optical fiber disconnected or incorrectly connected to the CIB board.
F0536: Feedback failure in gate driver Bp V1	Problem found in the gate driver return optical fiber.	- Defective gate driver. - Gate driver return optical fiber disconnected or incorrectly connected to the CIB board.
F0537: Feedback failure in gate driver Bp V2	Problem found in the gate driver return optical fiber.	- Defective gate driver. - Gate driver return optical fiber disconnected or incorrectly connected to the CIB board.
F0538: Feedback failure in gate driver Bp V3	Problem found in the gate driver return optical fiber.	- Defective gate driver. - Gate driver return optical fiber disconnected or incorrectly connected to the CIB board.
F0539: Feedback failure in gate driver Bp V4	Problem found in the gate driver return optical fiber.	- Defective gate driver. - Gate driver return optical fiber disconnected or incorrectly connected to the CIB board.
F0540: Feedback failure in gate driver Bp W1	Problem found in the gate driver return optical fiber.	- Defective gate driver. - Gate driver return optical fiber disconnected or incorrectly connected to the CIB board.
F0541: Feedback failure in gate driver Bp W2	Problem found in the gate driver return optical fiber.	- Defective gate driver. - Gate driver return optical fiber disconnected or incorrectly connected to the CIB board.
F0542: Feedback failure in gate driver Bp W3	Problem found in the gate driver return optical fiber.	- Defective gate driver. - Gate driver return optical fiber disconnected or incorrectly connected to the CIB board.
F0543: Feedback failure in gate driver Bp W4	Problem found in the gate driver return optical fiber.	- Defective gate driver. - Gate driver return optical fiber disconnected or incorrectly connected to the CIB board.
F0550: Rectifier feedback temperature 1	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0551: Rectifier feedback temperature 2	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0552: Rectifier feedback temperature 3	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0553: Rectifier feedback temperature 4	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0554: Rectifier feedback temperature 5	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0555: Rectifier feedback temperature 6	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
A0556: Overheating on sensor 1 of the rectifier	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.

Fault/Alarm	Description	Possible Causes
A0557: Overheating on sensor 2 of the rectifier	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0558: Overheating on sensor 3 of the rectifier	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0559: Overheating on sensor 4 of the rectifier	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0560: Overheating on sensor 5 of the rectifier	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
A0561: Overheating on sensor 6 of the rectifier	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
F0562: Overheating on sensor 1 of the rectifier	Temperature above 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0563: Overheating on sensor 2 of the rectifier	Temperature above 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0564: Overheating on sensor 3 of the rectifier	Temperature above 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0565: Overheating on sensor 4 of the rectifier	Temperature above 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0566: Overheating on sensor 5 of the rectifier	Temperature above 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0567: Overheating on sensor 6 of the rectifier	Temperature above 80 °C (176 °F).	- Clogged fans. - Clogged air intake filters. - High ambient temperature (> 40 °C or 104 °F) and high output current.
F0568: Phase U rectifier feedback temperature 1	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0569: Phase U rectifier feedback temperature 2	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0570: Phase V rectifier feedback temperature 1	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0571: Phase V rectifier feedback temperature 2	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0572: Phase W rectifier feedback temperature 1	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F0573: Phase W rectifier feedback temperature 2	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0574: Overtemperature in sensor 1 of the rectifier phase U	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
F0575: Overtemperature in sensor 2 of the rectifier phase U	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
F0576: Overtemperature in sensor 1 of the rectifier phase V	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
F0577: Overtemperature in sensor 2 of the rectifier phase V	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
F0578: Overtemperature in sensor 1 of the rectifier phase W	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
F0579: Overtemperature in sensor 2 of the rectifier phase W	Temperature exceeding 75 °C (167 °F).	- Clogged fans. - Clogged air inlet filters. - High ambient temperature (>40 °C or 104 °F) and high output current.
F0580: Auxiliary temperature measurement feedback 1	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0581: Auxiliary temperature measurement feedback 2	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
F0582: Auxiliary temperature measurement feedback 3	Feedback circuit failure.	- Optical fibers not connected, reversed or defective.
A0583: Overtemperature in the auxiliary measurement sensor 1		
A0584: Overtemperature in the auxiliary measurement sensor 2		
A0585: Overtemperature in the auxiliary measurement sensor 3		
F0586: Overtemperature in the auxiliary measurement sensor 1		
F0587: Overtemperature in the auxiliary measurement sensor 2		
F0588: Overtemperature in the auxiliary measurement sensor 3		

Fault/Alarm	Description	Possible Causes
A1388: Thermal protection relay 1 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
A1389: Thermal protection relay 2 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
A1390: Thermal protection relay 3 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
A1391: Thermal protection relay 4 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
A1392: Thermal protection relay 5 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
A1393: Thermal protection relay 6 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
F1394: Thermal protection relay 1 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
F1395: Thermal protection relay 2 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
F1396: Thermal protection relay 3 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
F1397: Thermal protection relay 4 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F1398: Thermal protection relay 5 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
F1399: Thermal protection relay 6 Communication timeout	Lack of communication for more than 10 seconds.	- Communication cable with protection relay disconnected or defective. - Incorrect protection relay communication parameters. - Relay in PRG (programming) or VIS (programming display) modes.
A1400: Thermal protection relay 1 - CH1 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1401: Thermal protection relay 1 - CH2 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1402: Thermal protection relay 1 - CH3 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1403: Thermal protection relay 1 - CH4 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1404: Thermal protection relay 1 - CH5 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1405: Thermal protection relay 1 - CH6 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1406: Thermal protection relay 1 - CH7 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1407: Thermal protection relay 1 - CH8 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
F1408: Thermal protection relay 1 - Overtemperature detected on CH1	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1409: Thermal protection relay 1 - Overtemperature detected on CH2	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1410: Thermal protection relay 1 - Overtemperature detected on CH3	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

Fault/Alarm	Description	Possible Causes
F1411: Thermal protection relay 1 - Overtemperature detected on CH4	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1412: Thermal protection relay 1 - Overtemperature detected on CH5	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1413: Thermal protection relay 1 - Overtemperature detected on CH6	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1414: Thermal protection relay 1 - Overtemperature detected on CH7	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1415: Thermal protection relay 1 - Overtemperature detected on CH8	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1416: Thermal protection relay 1 - Overtemperature detected on CH1	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1417: Thermal protection relay 1 - Overtemperature detected on CH2	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1418: Thermal protection relay 1 - Overtemperature detected on CH3	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1419: Thermal protection relay 1 - Overtemperature detected on CH4	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1420: Thermal protection relay 1 - Overtemperature detected on CH5	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1421: Thermal protection relay 1 - Overtemperature detected on CH6	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1422: Thermal protection relay 1 - Overtemperature detected on CH7	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A1423: Thermal protection relay 1 - Overtemperature detected on CH8	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1424: Thermal protection relay 2 - CH1 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1425: Thermal protection relay 2 - CH2 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1426: Thermal protection relay 2 - CH3 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1427: Thermal protection relay 2 - CH4 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1428: Thermal protection relay 2 - CH5 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1429: Thermal protection relay 2 - CH6 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1430: Thermal protection relay 2 - CH7 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1431: Thermal protection relay 2 - CH8 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
F1432: Thermal protection relay 2 - Overtemperature detected on CH1	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1433: Thermal protection relay 2 - Overtemperature detected on CH2	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1434: Thermal protection relay 2 - Overtemperature detected on CH3	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1435: Thermal protection relay 2 - Overtemperature detected on CH4	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

Fault/Alarm	Description	Possible Causes
F1436: Thermal protection relay 2 - Overtemperature detected on CH5	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1437: Thermal protection relay 2 - Overtemperature detected on CH6	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1438: Thermal protection relay 2 - Overtemperature detected on CH7	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1439: Thermal protection relay 2 - Overtemperature detected on CH8	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1440: Thermal protection relay 2 - Overtemperature detected on CH1	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1441: Thermal protection relay 2 - Overtemperature detected on CH2	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1442: Thermal protection relay 2 - Overtemperature detected on CH3	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1443: Thermal protection relay 2 - Overtemperature detected on CH4	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1444: Thermal protection relay 2 - Overtemperature detected on CH5	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1445: Thermal protection relay 2 - Overtemperature detected on CH6	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1446: Thermal protection relay 2 - Overtemperature detected on CH7	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1447: Thermal protection relay 2 - Overtemperature detected on CH8	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A1448: Thermal protection relay 3 - CH1 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1449: Thermal protection relay 3 - CH2 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1450: Thermal protection relay 3 - CH3 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1451: Thermal protection relay 3 - CH4 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1452: Thermal protection relay 3 - CH5 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1453: Thermal protection relay 3 - CH6 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1454: Thermal protection relay 3 - CH7 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1455: Thermal protection relay 3 - CH8 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
F1456: Thermal protection relay 3 - Overtemperature detected on CH1	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1457: Thermal protection relay 3 - Overtemperature detected on CH2	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1458: Thermal protection relay 3 - Overtemperature detected on CH3	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1459: Thermal protection relay 3 - Overtemperature detected on CH4	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1460: Thermal protection relay 3 - Overtemperature detected on CH5	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

Fault/Alarm	Description	Possible Causes
F1461: Thermal protection relay 3 - Overtemperature detected on CH6	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1462: Thermal protection relay 3 - Overtemperature detected on CH7	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1463: Thermal protection relay 3 - Overtemperature detected on CH8	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1464: Thermal protection relay 3 - Overtemperature detected on CH1	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1465: Thermal protection relay 3 - Overtemperature detected on CH2	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1466: Thermal protection relay 3 - Overtemperature detected on CH3	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1467: Thermal protection relay 3 - Overtemperature detected on CH4	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1468: Thermal protection relay 3 - Overtemperature detected on CH5	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1469: Thermal protection relay 3 - Overtemperature detected on CH6	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1470: Thermal protection relay 3 - Overtemperature detected on CH7	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1471: Thermal protection relay 3 - Overtemperature detected on CH8	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1472: Thermal protection relay 4 - CH1 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A1473: Thermal protection relay 4 - CH2 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1474: Thermal protection relay 4 - CH3 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1475: Thermal protection relay 4 - CH4 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1476: Thermal protection relay 4 - CH5 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1477: Thermal protection relay 4 - CH6 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1478: Thermal protection relay 4 - CH7 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1479: Thermal protection relay 4 - CH8 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
F1480: Thermal protection relay 4 - Overtemperature detected on CH1	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1481: Thermal protection relay 4 - Overtemperature detected on CH2	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1482: Thermal protection relay 4 - Overtemperature detected on CH3	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1483: Thermal protection relay 4 - Overtemperature detected on CH4	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1484: Thermal protection relay 4 - Overtemperature detected on CH5	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1485: Thermal protection relay 4 - Overtemperature detected on CH6	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

Fault/Alarm	Description	Possible Causes
F1486: Thermal protection relay 4 - Overtemperature detected on CH7	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1487: Thermal protection relay 4 - Overtemperature detected on CH8	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1488: Thermal protection relay 4 - Overtemperature detected on CH1	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1489: Thermal protection relay 4 - Overtemperature detected on CH2	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1490: Thermal protection relay 4 - Overtemperature detected on CH3	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1491: Thermal protection relay 4 - Overtemperature detected on CH4	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1492: Thermal protection relay 4 - Overtemperature detected on CH5	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1493: Thermal protection relay 4 - Overtemperature detected on CH6	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1494: Thermal protection relay 4 - Overtemperature detected on CH7	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1495: Thermal protection relay 4 - Overtemperature detected on CH8	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1496: Thermal protection relay 5 - CH1 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1497: Thermal protection relay 5 - CH2 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A1498: Thermal protection relay 5 - CH3 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1499: Thermal protection relay 5 - CH4 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1500: Thermal protection relay 5 - CH5 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1501: Thermal protection relay 5 - CH6 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1502: Thermal protection relay 5 - CH7 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1503: Thermal protection relay 5 - CH8 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
F1504: Thermal protection relay 5 - Overtemperature detected on CH1	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1505: Thermal protection relay 5 - Overtemperature detected on CH2	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1506: Thermal protection relay 5 - Overtemperature detected on CH3	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1507: Thermal protection relay 5 - Overtemperature detected on CH4	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1508: Thermal protection relay 5 - Overtemperature detected on CH5	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1509: Thermal protection relay 5 - Overtemperature detected on CH6	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1510: Thermal protection relay 5 - Overtemperature detected on CH7	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

Fault/Alarm	Description	Possible Causes
F1511: Thermal protection relay 5 - Overtemperature detected on CH8	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1512: Thermal protection relay 5 - Overtemperature detected on CH1	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1513: Thermal protection relay 5 - Overtemperature detected on CH2	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1514: Thermal protection relay 5 - Overtemperature detected on CH3	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1515: Thermal protection relay 5 - Overtemperature detected on CH4	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1516: Thermal protection relay 5 - Overtemperature detected on CH5	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1517: Thermal protection relay 5 - Overtemperature detected on CH6	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1518: Thermal protection relay 5 - Overtemperature detected on CH7	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1519: Thermal protection relay 5 - Overtemperature detected on CH8	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1520: Thermal protection relay 6 - CH1 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1521: Thermal protection relay 6 - CH2 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1522: Thermal protection relay 6 - CH3 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A1523: Thermal protection relay 6 - CH4 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1524: Thermal protection relay 6 - CH5 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1525: Thermal protection relay 6 - CH6 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1526: Thermal protection relay 6 - CH7 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
A1527: Thermal protection relay 6 - CH8 temperature sensor failure	Open circuit or short circuit in the temperature sensor.	- Broken wire on temperature sensor. - PT100 accessory connectors disconnected. - Active temperature channel without sensor connected to the PT100 accessory.
F1528: Thermal protection relay 6 - Overtemperature detected on CH1	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1529: Thermal protection relay 6 - Overtemperature detected on CH2	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1530: Thermal protection relay 6 - Overtemperature detected on CH3	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1531: Thermal protection relay 6 - Overtemperature detected on CH4	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1532: Thermal protection relay 6 - Overtemperature detected on CH5	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1533: Thermal protection relay 6 - Overtemperature detected on CH6	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1534: Thermal protection relay 6 - Overtemperature detected on CH7	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F1535: Thermal protection relay 6 - Overtemperature detected on CH8	Temperature higher than the fault level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.

Fault/Alarm	Description	Possible Causes
A1536: Thermal protection relay 6 - Overtemperature detected on CH1	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1537: Thermal protection relay 6 - Overtemperature detected on CH2	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1538: Thermal protection relay 6 - Overtemperature detected on CH3	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1539: Thermal protection relay 6 - Overtemperature detected on CH4	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1540: Thermal protection relay 6 - Overtemperature detected on CH5	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1541: Thermal protection relay 6 - Overtemperature detected on CH6	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1542: Thermal protection relay 6 - Overtemperature detected on CH7	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
A1543: Thermal protection relay 6 - Overtemperature detected on CH8	Temperature higher than the alarm level programmed in the thermal protection relay.	- Motor shaft load too high. - Very high load cycle (large number of starts and stops per minute). - High ambient temperature around the motor. - Motor shaft locked.
F2201: Timeout when energizing the inverter	The energization command was executed and the inverter did not energize within the predetermined time.	- Problem in the wiring between the inverter and the input cubicle.
F2203: Start command	The Start command was performed and the motor did not start.	- Incorrect parameterization.
F2205: Synchronization timeout reached	The Inverter was unable to synchronize the motor and grid voltages within the predetermined time.	
F2207: Disable command	The Inverter was not disabled after the motor synchronous transfer.	- Incorrect parameterization, check the electrical project.
F2209: Closing of the inverter output contactor	The inverter output contactor closing command was sent and the closed status was not received.	- Problem in the wiring between the inverter and the output contactor.
F2211: Opening of the inverter output contactor	The inverter output contactor opening command was sent and the open status was not received.	- Problem in the wiring between the inverter and the output contactor.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F2213: Incorrect state of inverter output contactor	The inverter output contactor status is neither open nor closed.	- Problem in the wiring between the inverter and the output contactor.
F2215: Inverter output contactor failure	The inverter output contactor is in fault state.	- Check the integrity of the inverter output contactor.
F2217: Closing of the transfer contactor to the grid	The transfer contactor close command to the mains was sent and the closed status was not received.	- Problem in the wiring between the inverter and the output contactor.
F2219: Opening of the transfer contactor to the grid	The transfer contactor open command to the mains was sent and the open status was not received.	- Problem in the wiring between the inverter and the output contactor.
F2221: Incorrect state of the transfer contactor to the grid	The status of the transfer contactor to the mains is neither open nor closed.	- Problem in the wiring between the inverter and the output contactor.
F2223: Fault in the transfer contactor to the grid	The transfer contactor to the mains is in a fault state.	- Problem in the wiring between the inverter and the output contactor.
F2225: Inverter is not ready to enable	PWM enable command received by the inverter with general enable inactive and/or the input circuit breaker open.	- Improper maneuvering of the input circuit breaker. - Faulty input circuit breaker. - Faulty wiring.
F2227: Emergency stop	Emergency button pressed while inverter is operating.	
F2229: Timeout in FIELD BUS communication	Loss of communication with the FIELD BUS communication network.	- Check the status of the network master. - Check the network installation, broken cable or poor contact in the network connections.
F2231: Incorrect parameterization	The inverter parameter setting is invalid.	- Check the incorrect parameter in the application HMI and parameterize as indicated in the electrical project.
F2233: Open doors	The inverter doors are open.	- Incorrect opening of the inverter doors. - Faulty wiring.
A2301: Low battery voltage	Low battery voltage.	- Replace the battery.
A2302: 24 Vdc power supply overvoltage	Overvoltage in the 24 Vdc power supply.	- Voltage of the 24 Vdc power supply that feeds the control above the maximum value of 26.4 Vdc.
F2322: Encoder/Motor wiring reversed	Fault related to the phase relation of the encoder signals, if C3.1.1 = 2 and C3.3.2.6.1 = 0 or 2. Note: - It is not possible to reset this fault during the self-tuning. - In this case, de-energize the inverter, solve the problem and then energize it.	- U, V, W wiring to the motor is reversed. - Encoder channels A and B are reversed. - Error in the encoder assembly position. - Motor with locked rotor or being dragged at the start.
F2328: Motor overtemp.	Overtemperature related to the PTC-type sensor installed in the motor. Note: - The fault can be disabled by setting C7.5.2 = 2 or 3. - It is necessary to program the analog input and output of Slot X for PTC function.	- Load on the motor shaft is too high. - Load cycle is too short (high number of starts and stops per minute). - High ambient temperature around the motor. - Poor contact or short circuit (resistance < 100 Ω) on the wiring connected to the motor thermistor. - Motor thermistor not installed. - Motor shaft locked.

Fault/Alarm	Description	Possible Causes
F2329: Encoder signals fault	Fault related to missing encoder signals.	- Wiring between encoder and encoder interface accessory interrupted. - Defective encoder. - Encoder accessory is defective or poorly installed on the product when the control is set to vector with encoder.
F2330: Self-diagnosis fault	Self-Diagnosis Fault.	- Defect on the inverter internal circuits.
A2331: External alarm	-External alarm via DI. Note: - Necessary to set the DI in C7.10.1.	- DI input wiring (set in C7.10.1 to generate external alarm) open.
F2332: External fault	External fault via DI. Note: - Necessary to set the DI in C7.10.2.	- DI input wiring (set in C7.10.2 to actuate external fault) open.
F2333: Communication failure with the CCE board	Communication with the CCE control board was not performed correctly.	- Defective connection cable between AUI and CCE.
A2334: High motor temperature	Alarm related to the PTC temperature sensor installed on the motor. Note: - The alarm can be disabled by setting C7.5.2. - It is necessary to program the analog input and output of Slot X for PTC function.	- Load on the motor shaft is too high. - Load cycle is too short (high number of starts and stops per minute). - High ambient temperature around the motor. - Poor contact or short circuit (resistance < 100 Ω) on the wiring connected to the motor thermistor. - Motor thermistor not installed. - Motor shaft locked.
A2335: Serial communication timeout	It indicates that the MVW stopped receiving telegrams on the serial interface for a period longer than the setting programmed in C9.3.5. Note: - Ensure that the master always sends telegrams to the equipment in a shorter time than that set in C9.3.5. - It can be disabled by setting C9.3.5=0.0 s.	- Check network installation, broken cable or fault/poor contact on the connections with the network, and grounding.
A2336: Anybus Module Off-line	Alarm that indicates interruption in the Anybus communication.	- PLC went to the idle state. - Programming error. Number of I/O words set on the slave differs from the setting on the master. - Loss of communication with the master (broken cable, connector disconnected etc.).
A2337: Anybus Module access error	Alarm that indicates error of access to the Anybus communication module.	- Faulty Anybus module, not recognized or incorrectly installed.
A2338: No power supply on the CAN interface	It actuates when the CAN interface is powered and lack of power supply to the interface is detected. Note: - Measure if there is voltage within the allowed range between pins 1 and 5 of the CAN interface connector.	- CAN interface without power supply between pins 1 and 5 of the connector. - Power cables mixed up or reversed. - Poor contact on the CAN interface cable or connector.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A2339: Bus Off	Bus off error detection on the CAN interface. If the number of reception or transmission errors detected by the CAN interface is too high, the CAN controller can be taken to the bus off state, where it interrupts the communication and disables the CAN interface. In order to restore communication, it is necessary to turn the product off and on again, or to remove and reconnect the power to the CAN interface, so that communication can be restarted.	- Short circuit in the CAN circuit transmission cables. - Changed or reversed cables. - Network devices with different baud rates. - Termination resistors with incorrect values. - Termination resistors installed at one end of the main bus only. - CAN network installation done improperly.
A2340: CANopen off-line	It occurs if the state of the CANopen node changes from operational to pre-operational. Note: - Check the operation of the error control mechanisms (Heartbeat/Node Guarding).	- The master is not sending the guarding/heartbeat telegrams at the programmed time. - Communication problems caused by lost telegrams or transmission delays.
A2341: Master in Idle	It actuates when communicating with the network master in Run mode, and transition to Idle mode is detected.	- Set the switch that controls the master operation of the master to Run or the corresponding bit on the configuration word of the master software. For further explanations, see the documentation of the master in use.
A2342: DeviceNet connection timeout	It indicates that one or more DeviceNet I/O connections has expired. It occurs when the cyclic communication between the master and the product is interrupted.	- Check the status of the network master. - Check the network installation, broken cable or poor contact on the connections with the network.
A2347: SNTP connection timeout	It indicates that the inverter tried to connect to the NTP server and got no response. It occurs after starting connection with the NTP server and the server has not returned the response requested by the inverter.	- Check the configuration and IP address. - Check if the NTP server is active.
A2349: EtherNet/IP Communication Offline	It indicates communication error with EtherNet/IP master. It occurs when, for any reason, after the cyclic communication of the master with the product is started, this communication is interrupted. This is detected if the I/O Exclusive Owner connection times out.	- Check the status of the network master. - Check the network installation, broken cable or failed/bad contact in the network connections.
A2350: Modbus TCP Timeout	It indicates that the equipment stopped receiving valid telegrams for a period longer than the setting in C9.6.3. The time counting starts after the first valid telegram is received.	- Check the network installation, broken cable or poor contact on the connections with the network, grounding. - Ensure that the Modbus TCP client always sends telegrams to the equipment in a shorter time than the set in C9.6.3. - Disable the Timeout function in C9.6.3.
F2351: Motor overspeed	Overspeed. Note: - Activated when the actual speed exceeds the value of $C4.3.1.1.2 \times (100 \% + C7.7.1)$ for more than 20 ms.	- Incorrect setting of C3.3.2.1.2 and/or C3.3.2.1.3. - Crane-type load trips.
F2358: Corrupted settings	Inverter settings are invalid. Note: - Restore the factory default in parameter C12.1. If the problem persists, contact WEG's technical support or representative.	- Parameter settings file cannot be restored correctly.

Fault/Alarm	Description	Possible Causes
F2373: Serial communication timeout	It indicates that the MVW stopped receiving telegrams on the serial interface for a period longer than the setting programmed in C9.3.5. Note: - Ensure that the master always sends telegrams to the equipment in a shorter time than that set in C9.3.5. - It can be disabled by setting C9.3.5=0.0 s.	- Check network installation, broken cable or fault/poor contact on the connections with the network, and grounding.
F2374: Bus Off	Bus off error detection on the CAN interface. If the number of reception or transmission errors detected by the CAN interface is too high, the CAN controller can be taken to the bus off state, where it interrupts the communication and disables the CAN interface. In order to restore communication, it is necessary to turn the product off and on again, or to remove and reconnect the power to the CAN interface, so that communication can be restarted.	- Short circuit in the CAN circuit transmission cables. - Changed or reversed cables. - Network devices with different baud rates. - Termination resistors with incorrect values. - Termination resistors installed at one end of the main bus only. - CAN network installation done improperly.
F2375: Anybus Module Off-line	Fault that indicates interruption in the Anybus communication.	- PLC went to the idle state. - Programming error. Number of I/O words set on the slave differs from the setting on the master. - Loss of communication with the master (broken cable, connector disconnected etc.).
F2376: CANopen Off-line	It occurs if the state of the CANopen node changes from operational to pre-operational. Note: - Check the operation of the error control mechanisms (Heartbeat/Node Guarding).	- The master is not sending the guarding/heartbeat telegrams at the programmed time. - Communication problems caused by lost telegrams or transmission delays.
F2377: Anybus Module access error	Fault that indicates error of access to the Anybus communication module.	- Faulty Anybus-CC module, not recognized or incorrectly installed.
F2378: No power supply on the CAN interface	It actuates when the CAN interface is powered and lack of power supply to the interface is detected. Note: - Measure if there is voltage within the allowed range between pins 1 and 5 of the CAN interface connector.	- CAN interface without power supply between pins 1 and 5 of the connector. - Power cables mixed up or reversed. - Poor contact on the CAN interface cable or connector.
F2379: Master in Idle	It actuates when communicating with the network master in Run mode, and transition to Idle mode is detected.	- Set the switch that controls the master operation of the master to Run or the corresponding bit on the configuration word of the master software. For further explanations, see the documentation of the master in use.
F2380: DeviceNet connection timed out	It indicates that one or more DeviceNet I/O connections has expired. It occurs when the cyclic communication between the master and the product is interrupted.	- Check the status of the network master. - Check the network installation, broken cable or poor contact on the connections with the network.
F2385: EtherNet/IP communication offline	It indicates communication error with EtherNet/IP master. It occurs when, for any reason, after the cyclic communication of the master with the product is started, this communication is interrupted. This is detected if the I/O Exclusive Owner connection times out.	- Check the status of the network master. - Check the network installation, broken cable or failed/bad contact in the network connections.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F2386: Modbus TCP Timeout	It indicates that the equipment stopped receiving valid telegrams for a period longer than the setting in C9.6.3. The time counting starts after the first valid telegram is received.	- Check the network installation, broken cable or poor contact on the connections with the network, grounding. - Ensure that the Modbus TCP client always sends telegrams to the equipment in a shorter time than the set in C9.6.3. - Disable the Timeout function in C9.6.3.
A2430: PID PV Low Level	It indicates that the control process variable (A2.1.3) is at a low level.	- Control process variable (A2.1.3) remained for 150 ms with the value lower than the value set in A2.3.6.2.
F2431: PID PV Low Level	It indicates the motor was switched off due to the low level of the control process variable	- Control process variable (A2.1.3) remained for a certain amount of time (A2.3.6.3) with the value lower than the value set in A2.3.6.2.
A2432: PID PV High Level	It indicates that the control process variable (A2.1.3) is at a high level.	- Control process variable (A2.1.3) remained for 150 ms with the value higher than the value set in A2.3.6.5.
F2433: PID PV High Level	It indicates the motor was switched off due to the high level of the control process variable	- Control process variable (A2.1.3) remained for a certain amount of time (A2.3.6.6) with the value higher than the value set in A2.3.6.5.
F2605: Power Circuit Off	Communication with the power module was interrupted while the output was enabled.	- Power board turned off while the output was enabled. - Defect on the inverter internal circuits.
F2608: Code Flow Failure	Internal fault during inverter operation. Note: Reset the inverter. - Load the factory default.	- If the problem persists, please contact technical support.
A2610: Parameter Storage Full	There is no more space in memory to store new user parameters. Note: - Any parameter changes made while this alarm is active may not be kept after restarting the inverter. - During the next power-up of the product, a routine indicated by the memory usage optimization screen frees up memory space to allow new settings.	- Many changes in configuration parameters (regardless of whether via HMI, WPS, networks or application) without restarting the product. - Many user parameter downloads via SoftPLC without restarting the product.
A2702: Inverter Disabled	Indicates that the General Enable command is Inactive.	- Run/Stop command of the SoftPLC application equal to Run, or the movement block was enabled with the "General Enable" command disabled.
A2703: Inverter in Safe Torque Off (STO) state	The system has the safe stop active and the inverter is in the STO (Safe Torque Off) state. For safety reasons, the inverter is prevented from generating motion until the safety conditions are verified and restored. Note: - STO does not brake the motor; it only disables torque generation, and the motor stops by inertia (coasting stop). - Once STO is activated, the inverter cannot restart the motor, even if it receives a RUN command, until the safety circuit is reset and restored.	- Wiring on input DIXXX of the PIC board (XC7:XXXX) is open (does not return +24 V).
A2706: SPLC Refer. Not Progr.	Indicates that the softPLC reference has not been programmed.	- It occurs when a movement block is enabled and the speed reference is not set for SoftPLC (check C4.3.1.2.1 or C4.3.1.2.2).

Fault/Alarm	Description	Possible Causes
A2708: SoftPLC Not Running	Indicates that the SoftPLC application is not running.	- Check the SoftPLC status in S6.1.1 and the action configuration for application not running in C10.1.3.
F2709: SoftPLC Not Running	Indicates that the SoftPLC application is not running.	- Check the SoftPLC status in S6.1.1 and the action configuration for application not running in C10.1.3.
F3000: Error During Accessory Update	Error during accessory firmware update.	- Outdated inverter firmware version.
A3012: Slot X AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3013: Slot X AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3014: Slot X AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3015: Slot X AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3100: Slot A Incompatible Accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3101: Slot A Initialization Error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3103: Slot A Accessory Connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3104: Slot A High Temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3105: Slot A Overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3106: Slot A Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3107: Slot A Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A3108: Slot A Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3109: Slot A Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3110: Slot A Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3111: Slot A Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3112: Slot A AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3113: Slot A AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3114: Slot A AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3115: Slot A AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3116: Slot A AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3117: Slot A AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3125: Slot A Temp. Sensor Wrong HW Config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3126: Slot A Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.

Fault/Alarm	Description	Possible Causes
F3127: Slot A Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3128: High Temperature on Slot A Sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3129: Slot A Sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3130: Slot A Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3131: Slot A Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3132: High Temperature on Slot A Sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3133: Slot A Sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3134: Slot A Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3135: Slot A Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3136: High Temperature on Slot A Sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3137: Slot A Sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3138: Slot A Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3139: Slot A Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3140: High Temperature on Slot A Sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3141: Slot A Sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3142: Slot A Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F3143: Slot A Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3144: High Temperature on Slot A Sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3145: Slot A Sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3146: Slot A Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3147: Slot A Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3148: High Temperature on Slot A Sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3149: Slot A Sensor 6 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
F3200: Slot B Incompatible Accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3201: Slot B Initialization Error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3203: Slot B Accessory Connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3204: Slot B High Temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3205: Slot B Overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3206: Slot B Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3207: Slot B Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3208: Slot B Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.

Fault/Alarm	Description	Possible Causes
F3209: Slot B Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3210: Slot B Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3211: Slot B Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3212: Slot B AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3213: Slot B AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3214: Slot B AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3215: Slot B AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3216: Slot B AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3217: Slot B AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3225: Slot B Temp. Sensor Wrong HW Config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3226: Slot B Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3227: Slot B Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A3228: High Temperature on Slot B Sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3229: Slot B Sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3230: Slot B Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3231: Slot B Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3232: High Temperature on Slot B Sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3233: Slot B Sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3234: Slot B Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3235: Slot B Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3236: High Temperature on Slot B Sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3237: Slot B Sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3238: Slot B Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3239: Slot B Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3240: High Temperature on Slot B Sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3241: Slot B Sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3242: Slot B Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3243: Slot B Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.

Fault/Alarm	Description	Possible Causes
A3244: High Temperature on Slot B Sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3245: Slot B Sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3246: Slot B Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3247: Slot B Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3248: High Temperature on Slot B Sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3249: Slot B Sensor 6 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
F3300: Slot C Incompatible Accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3301: Slot C Initialization Error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3303: Slot C Accessory Connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3304: Slot C High Temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3305: Slot C Overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3306: Slot C Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3307: Slot C Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3308: Slot C Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3309: Slot C Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A3310: Slot C Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3311: Slot C Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3312: Slot C AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3313: Slot C AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3314: Slot C AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3315: Slot C AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3316: Slot C AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3317: Slot C AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3325: Slot C Temp. Sensor Wrong HW Config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3326: Slot C Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3327: Slot C Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3328: High Temperature on Slot C Sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3329: Slot C Sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

Fault/Alarm	Description	Possible Causes
A3330: Slot C Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3331: Slot C Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3332: High Temperature on Slot C Sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3333: Slot C Sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3334: Slot C Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3335: Slot C Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3336: High Temperature on Slot C Sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3337: Slot C Sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3338: Slot C Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3339: Slot C Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3340: High Temperature on Slot C Sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3341: Slot C Sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3342: Slot C Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3343: Slot C Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3344: High Temperature on Slot C Sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3345: Slot C Sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A3346: Slot C Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3347: Slot C Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3348: High Temperature on Slot C Sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3349: Slot C Sensor 6 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
F3400: Slot D Incompatible Accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3401: Slot D Initialization Error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3403: Slot D Accessory Connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3404: Slot D High Temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3405: Slot D Overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3406: Slot D Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3407: Slot D Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3408: Slot D Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3409: Slot D Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3410: Slot D Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.

Fault/Alarm	Description	Possible Causes
F3411: Slot D Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3412: Slot D AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3413: Slot D AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3414: Slot D AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3415: Slot D AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3416: Slot D AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3417: Slot D AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3425: Slot D Temp. Sensor Wrong HW Config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3426: Slot D Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3427: Slot D Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3428: High Temperature on Slot D Sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3429: Slot D Sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3430: Slot D Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F3431: Slot D Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3432: High Temperature on Slot D Sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3433: Slot D Sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3434: Slot D Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3435: Slot D Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3436: High Temperature on Slot D Sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3437: Slot D Sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3438: Slot D Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3439: Slot D Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3440: High Temperature on Slot D Sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3441: Slot D Sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3442: Slot D Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3443: Slot D Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3444: High Temperature on Slot D Sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3445: Slot D Sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3446: Slot D Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.

Fault/Alarm	Description	Possible Causes
F3447: Slot D Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3448: High Temperature on Slot D Sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3449: Slot D Sensor 6 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
F3500: Slot E Incompatible Accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3501: Slot E Initialization Error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3503: Slot E Accessory Connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3504: Slot E High Temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3505: Slot E Overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3506: Slot E Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3507: Slot E Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3508: Slot E Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3509: Slot E Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3510: Slot E Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3511: Slot E Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A3512: Slot E AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3513: Slot E AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3514: Slot E AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3515: Slot E AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3516: Slot E AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3517: Slot E AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3525: Slot E Temp. Sensor Wrong HW Config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3526: Slot E Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3527: Slot E Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3528: High Temperature on Slot E Sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3529: Slot E Sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3530: Slot E Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3531: Slot E Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3532: High Temperature on Slot E Sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.

Fault/Alarm	Description	Possible Causes
F3533: Slot E Sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3534: Slot E Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3535: Slot E Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3536: High Temperature on Slot E Sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3537: Slot E Sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3538: Slot E Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3539: Slot E Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3540: High Temperature on Slot E Sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3541: Slot E Sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3542: Slot E Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3543: Slot E Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3544: High Temperature on Slot E Sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3545: Slot E Sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3546: Slot E Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3547: Slot E Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3548: High Temperature on Slot E Sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
F3549: Slot E Sensor 6 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
F3600: Slot F Incompatible Accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3601: Slot F Initialization Error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3603: Slot F Accessory Connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3604: Slot F High Temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3605: Slot F Overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3606: Slot F Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3607: Slot F Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3608: Slot F Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3609: Slot F Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3610: Slot F Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3611: Slot F Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3612: Slot F AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.

Fault/Alarm	Description	Possible Causes
F3613: Slot F AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3614: Slot F AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3615: Slot F AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3616: Slot F AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3617: Slot F AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3625: Slot F Temp. Sensor Wrong HW Config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3626: Slot F Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3627: Slot F Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3628: High Temperature on Slot F Sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3629: Slot F Sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3630: Slot F Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3631: Slot F Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3632: High Temperature on Slot F Sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3633: Slot F Sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A3634: Slot F Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3635: Slot F Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3636: High Temperature on Slot F Sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3637: Slot F Sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3638: Slot F Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3639: Slot F Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3640: High Temperature on Slot F Sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3641: Slot F Sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3642: Slot F Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3643: Slot F Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3644: High Temperature on Slot F Sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3645: Slot F Sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3646: Slot F Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3647: Slot F Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3648: High Temperature on Slot F Sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3649: Slot F Sensor 6 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

Fault/Alarm	Description	Possible Causes
F3700: Slot G Incompatible Accessory	Error during accessory firmware update.	- Outdated inverter firmware version.
F3701: Slot G Initialization Error	A resource required for the operation of the accessory could not be initialized.	- Resource already in use by another accessory. Only one communication network accessory can be used at a time.
F3703: Slot G Accessory Connection	Loss of communication with the accessory.	- Electromagnetic noise above the limit. - Vibration above supported limits causing connector problems. - Corrupted accessory firmware.
A3704: Slot G High Temperature	High temperature in the accessory.	- Temperature around the inverter close to 60 °C.
F3705: Slot G Overtemperature	Accessory overtemperature.	- Temperature around the inverter above 60 °C.
A3706: Slot G Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3707: Slot G Enc. A Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3708: Slot G Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3709: Slot G Enc. B Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3710: Slot G Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
F3711: Slot G Enc. Z Cable Disconnection	Encoder signal not detected. Note: It can be disabled by setting C5.n.5.2, where "n" is the number of the slot where the accessory is installed.	- Broken or disconnected signal cable. - Encoder connection error. - Encoder without power supply.
A3712: Slot G AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3713: Slot G AI1 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.

FAULTS AND ALARMS

Fault/Alarm	Description	Possible Causes
A3714: Slot G AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3715: Slot G AI2 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
A3716: Slot G AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3717: Slot G AI3 Cable Disconnection	Analog input signal configured in current mode is outside the 4 to 20 mA range.	- AI cable broken (the read value was less than 2 mA for 5 seconds). - Poor contact on the signal connection at the terminals.
F3725: Slot G Temp. Sensor Wrong HW Config.	Sensor type selected by the accessory DIP switches other than the sensor type configured by the parameters.	- DIP switch configured incorrectly. Check the MVW-TEMP-01 accessory guide. - "Sensor Type" parameter incorrectly configured. Check the description in C5.2.6.1.
A3726: Slot G Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3727: Slot G Temperature Sensor 1 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3728: High Temperature on Slot G Sensor 1	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3729: Slot G Sensor 1 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3730: Slot G Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3731: Slot G Temperature Sensor 2 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3732: High Temperature on Slot G Sensor 2	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3733: Slot G Sensor 2 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3734: Slot G Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.

Fault/Alarm	Description	Possible Causes
F3735: Slot G Temperature Sensor 3 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3736: High Temperature on Slot G Sensor 3	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3737: Slot G Sensor 3 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3738: Slot G Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3739: Slot G Temperature Sensor 4 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3740: High Temperature on Slot G Sensor 4	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3741: Slot G Sensor 4 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3742: Slot G Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3743: Slot G Temperature Sensor 5 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3744: High Temperature on Slot G Sensor 5	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3745: Slot G Sensor 5 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.
A3746: Slot G Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
F3747: Slot G Temperature Sensor 6 Error	The value measured by the temperature sensor is out of the expected range.	- Sensor cable is broken. - Short-circuited sensor. - Sensor located in an extremely low temperature environment.
A3748: High Temperature on Slot G Sensor 6	The temperature measured by the sensor is close to the threshold level.	- Monitored equipment with high temperature. - Configuration error of the alarm actuation level.
F3749: Slot G Sensor 6 Overtemperature	The temperature measured by the sensor is above the threshold level.	- Monitored equipment with high temperature. - Configuration error of the fault actuation level.

3 SAFETY INSTRUCTIONS

This manual contains the information necessary for setting the MVW frequency inverter. To commission the product correctly, it is necessary to follow the instructions described in this manual and to have proper training or technical qualification.

3.1 SAFETY WARNINGS IN THE MANUAL

The manual contains the following safety warnings:



DANGER!

This warning informs the user of the risk of death, serious injury or considerable property damage.



ATTENTION!

This warning informs the user of possible considerable property damage.



NOTE!

The information in this warning is important for the correct understanding and proper operation of the product.

3.2 SAFETY WARNINGS ON THE PRODUCT

The following symbols are attached to the product as safety warnings:



High voltages are present.



Components sensitive to electrostatic discharge. Do not touch them.



Mandatory connection to the protective earth (PE).



Connection of the shield to the ground.



Hot surface. Do not touch.

3.3 PRELIMINARY RECOMMENDATIONS



DANGER!

Only qualified personnel, familiar with the MVW inverter and related equipment must plan or perform the installation, commissioning, operation and maintenance of this equipment. All safety instructions contained in this manual and/or defined by local regulations must be followed. Failure to comply with the safety instructions may result in death, serious injury and/or equipment damage.



NOTE!

Read the whole MVW frequency inverter user manual before installing or operating the MVW.

SAFETY INSTRUCTIONS



NOTE!

For the purposes of this manual, qualified personnel are those trained and able to:

1. Install, ground, energize and operate the MVW in accordance with this manual and the legal safety procedures in force.
2. Use the protective equipment in accordance with the relevant standards.
3. Provide first aid.



DANGER!

Always disconnect the general power supply before touching any electrical component associated with the MVW inverter.

Several components may remain charged with high voltages and/or in movement (fans) even after the AC power supply has been disconnected or turned off.

Wait at least 10 minutes to ensure complete discharge of the capacitors.

Always connect the frame of the equipment to the protection grounding (PE) at the proper point.



ATTENTION!

Electronic boards have components that are sensitive to electrostatic discharges. Do not directly touch components or connectors. If necessary, first touch the grounded metallic frame or use a suitable grounding strap.

Do not perform any high pot tests with the MVW inverter!
If it is necessary consult WEG.



NOTE!

Frequency inverters can interfere with other electronic equipment. Follow the precautions recommended in the Installation and Connection Chapter of the user manual to minimize these effects.

4 ABOUT THE MANUAL

This manual presents the information required to configure the functions and parameters of the MVW frequency inverter. It must be used together with the MVW User Manual. It is prohibited the reproduction of the contents of this manual, in whole or in part, without the written permission of the manufacturer.

Due to the wide variety of functions of this product, it is possible to apply it in ways different from those presented hereby. It is not the purpose of this manual to exhaust all the MVW application possibilities. The manufacturer cannot assume any responsibility for the use of the MVW not based in this manual.



NOTE!

The text is intended to provide additional information in order to facilitate the use and programming of MVW in certain applications.

4.1 TERMINOLOGY AND DEFINITIONS

4.1.1 Terms and Definitions Used in the Manual

Normal duty (ND): *Normal duty* (ND) is the inverter operating rate that sets the maximum current values for continuous operation I_{nom-ND} and overload of 110 % for 1 minute. It is selected by programming C1.2.1 = 0 (Normal Duty (ND)). It must be used to drive motors that are not subject to high torques in relation to their rated torque when operating in steady state at start, acceleration or deceleration.

I_{nom-ND} : Inverter rated current for use under normal overload rating (ND= *Normal duty*). Overload: $1.1 \times I_{nom-ND} / 1 \text{ minute}$.

Heavy duty (HD): *Heavy duty* (HD) is the inverter operating rate that sets the maximum current values for continuous operation I_{nom-HD} and overload of 150 % for 1 minute. It is selected by programming C1.2.1 = 1 (Heavy Duty (HD)). It must be used to drive motors that are subject to high overload torques in relation to their rated torque when operating under constant speed at start, acceleration, or deceleration.

I_{nom-HD} : Inverter rated current for use under heavy overload rating (HD= *Heavy duty*). Overload: $1.5 \times I_{nom-HD} / 1 \text{ minute}$.

Rectifier: Input circuit of the inverters that transforms the input AC voltage into DC. It is formed by power diodes.

Pre-Charge Circuit: It charges the DC Link capacitors with limited current, reducing the current peaks when powering up the inverter.

IGBT: *Insulated Gate Bipolar Transistor*: it is a basic component of the output inverter bridge. It works as an electronic switch in the saturated (closed switch) and cut-off (open switch) modes.

PTC: Resistor whose resistance value in ohms increases proportionally with temperature; used as a temperature sensor in motors.

NTC: Resistor whose resistance value in ohms decreases proportionally to the increase of the temperature; it is used as a temperature sensor in power packs.

HMI: Human-Machine Interface; device that allows the control of the motor, the visualization and the modification of the inverter parameters. It presents keys for motor control, navigation keys and a graphic LCD display.

RAM Memory: *Random Access Memory* (volatile memory).

FLASH Memory: Nonvolatile memory.

RFI Filter: *Radio Frequency Interference Filter*. It is a filter that avoids interference in the radiofrequency range.

PWM: *Pulse Width Modulation*. It is a pulsing voltage that supplies the motor.

Switching frequency: Frequency of the PWM modulation carrier to generate the triggering pulses of the inverter bridge IGBTs, usually given in kHz.

General enable: When activated, it accelerates the motor with the acceleration ramp provided Run/Stop = Run. When deactivated, the PWM pulses are immediately locked. It can be commanded through digital input programmed for that function, via communication networks or via SoftPLC.

Run/Stop: Inverter function that when activated (Run) accelerates the motor by acceleration ramp to the reference speed, and when deactivated (Stop) decelerates the motor by deceleration ramp until it stops. It can be commanded via HMI keys (🟢 = Run and 🔴 = Stop), through digital input programmed for that function, via communication networks or via SoftPLC.

WPS: *WEG Programming Suite* (software).

Forward: Direction of rotation with positive speed reference.

Reverse: Direction of rotation opposite to forward.

SM: Synchronous Machine.

PM: Permanent-Magnet Synchronous Machine.

IPSM: Interior Permanent-Magnet Synchronous Machine.

ABOUT THE MANUAL

SPSM: Surface Permanent-Magnet Synchronous Machine.

HSRM: Hybrid Synchronous Reluctance Machine.

5 ABOUT THE MVW

The MVW may be engineered to meet the needs and technical specifications of our customers. Sizes, technical recommendations, performance data and optional items can be changed in relation to the information contained in this document.

In addition to the manual, the inverter detailed design is part of the documentation delivered to the customer. This design contains all the electrical, mechanical and setting information, as well as instructions for the interface/installation with other equipment.

The MVW, as well as other WEG products, is in constant evolution in relation to both internal parts (hardware) and programming (software/firmware). Any further explanation about the equipment and its documentation can be obtained by means of WEG communication channels.

WEG is not liable for the improper use of the information contained in this manual.

5.1 AVAILABLE MODELS

The MVW line of Medium Voltage inverters offers different models, classified according to their power cell rated voltage and current levels. Different models of the MVW may have different frames and codes. For constructive aspects of the available frames, check in [chapter 4 TECHNICAL SPECIFICATIONS of the User's Manual, Figure 4.3, page 4-3 and tables 4.1 to 4.12 on pages 4-3 and 4-4](#). For models with rated voltage above 8000 V, contact WEG.



Figure 5.1: General illustration of the panel



ATTENTION!

It is very important to check that the inverter software version is the same as indicated on the first page of this manual.

6 SOFTWARE VERSIONS

Software versions define the functions and programming of the MVW inverter. All software versions installed on the product are available for viewing. The set of all software versions is called a package. The package, according to (S1.2.1), identifies the set of software versions of all microcontrollers in the product, and should be used as a reference to identify the software version of the product. This manual is updated according to the software version of the package (indicated on the back cover).

The software versions have the format 00.00.00, and follow the following evolution rules:




Figure 6.1: Software version format

- Group 1: The first two digits are updated when it is necessary to define an important change, such as a change in the drive hardware that brings about some incompatibility with the software.
- Group 2: The middle two digits are updated when the software is updated with new functionality, such as a new function or new parameter.
- Group 3: The last two digits are updated when the software is updated with corrections or “Bug Fix”, for example corrections to a certain functionality or errors in the drive’s behavior in general.

7 S STATUS

This menu contains the status information of the inverter, motor, control accessories and networks. It is also possible to access information related to the functional safety of the inverter. It allows viewing the reading variables of the MVW.



NOTE!

All parameters present in this menu can only be seen on the HMI display and cannot be changed by the user unless they are linked to the parameters of the **Configurations** menu.

S1 INVERTER

It allows viewing the characteristics and status of the MVW.

S1.1 Status

It allows viewing the operating status of the MVW.

S1.1 Status

.1 Inverter	0 ... 10
.4 Config	0 ... 33
.5 Paralelism	0 ... 2 Bit

.1 Inverter It indicates one of the possible inverter status. The following table contains the description of each status.

Indication	Description
0 = Ready	It indicates that the inverter is ready to drive the motor Precharge OK, general enable active
1 = Run	It indicates that the inverter is driving the motor
2 = Undervoltage	It indicates that the inverter has insufficient supply voltage for operation (undervoltage) and will not accept a command to start the motor
3 = Fault	It indicates that the inverter has a fault active
4 = Configuration	It indicates that the inverter is running a wizard or with incompatible parameter programming
5 = Not used	Not used
6 = Booting	It indicates that communication with the power board has not been established
7 = Disabled	It indicates that the inverter is disabled Precharge OK, general enable inactive
8 ... 9 = Not used	Not used
10 = Sleep	It indicates that the sleep mode of the inverter PID controller is active

.4 Config It indicates if the MVW is in CONFIG status and, if so, which input condition is leading to this situation.

Indication	Description
0 = No Config	It indicates that the MVW is not in the CONFIG status
1 = Run/Stop DIx	It indicates that the Run/Stop command source of Remote 1 and/or Remote 2 mode has been set to Run/Stop via DI mode, but no DI has been specified
2 = Forward R1	It indicates that the Run/Stop command source of Remote 1 mode has been set to Forward/Reverse mode via DI, but no forward DI has been specified or the Direction of Rotation command source is not set to Forward/Reverse via DI mode
3 = Forward R2	It indicates that the Run/Stop command source of Remote 2 mode has been set to Forward/Reverse mode via DI, but but the forward DI was not specified
4 = Reverse R1	It indicates that the Run/Stop command source of Remote 1 mode has been set to Forward/Reverse mode via DI, but but the reverse DI was not specified
5 = Reverse R2	It indicates that the Run/Stop command source of Remote 2 mode has been set to Forward/Reverse mode via DI, but but the reverse DI was not specified
6 = 3-wire Start/Stop	It indicates that the Run/Stop command source of Remote 1 and/or Remote 2 mode has been set to 3-wire Start/Stop via DI mode, but no DI has been specified

Indication	Description
7 = Direction of Rotation Dlx	It indicates that the Direction of Rotation command source of Remote 1 and/or Remote 2 mode has been set to "Direction of Rotation DI", but no DI has been specified in C4.2.3.8
8 = JOG Dlx	It indicates that the JOG command source of Remote 1 and/or Remote 2 mode has been set to Digital Input (DI) mode, but no DI has been specified
9 = R1/R2 Dlx	It indicates that the selection command source between Remote 1 and Remote 2 modes has been set to Digital Input (DI) mode, but no DI has been specified
10 = Ramp selection Dlx	It indicates that the ramp selection command source has been set to Digital Input (DI) mode, but no DI has been specified
11 = Oriented Startup	It indicates that the Oriented Startup is running
12 = Backup	It indicates that the Parameter Copy functions are running
13 = Not used	Not used
14 = SS1 configuration	It indicates that the SS1 is not properly set
15 = Switching Frequency	It indicates that the user and/or minimum switching frequencies are not properly set
16 = Undefined model	It indicates that there is an incompatibility in the drive model recorded. Perform a factory default to fix this problem
17 = Encoder Vector Control	It indicates that the Vector Control with Encoder type has been selected, but there is no Encoder accessory defined in any slot
18 = ENC Acc. not configured	It indicates that the Encoder accessory was selected for one of the slots, but it is not connected or set to in the corresponding slot
19 = Alx/FIx Speed Ref.	It indicates that the speed reference source for Remote 1 and/or Remote 2 mode has been set to Analog Input (AI) or Frequency Input (FI) mode, but no AI or FI has been specified
20 = Not used	Not used
21 = General Enable Dlx	It indicates that the General Enable command source for Remote 1 and/or Remote 2 mode has been set to Digital Input (DI) mode, but no DI has been specified
22 = Multispeed	It indicates that the speed reference source of Remote 1 and/or Remote 2 mode has been set to Multispeed mode, but no DI has been specified
23 = Not used	Not used
24 = Electronic Potentiometer	It indicates that the speed reference source of Remote 1 and/or Remote 2 mode has been set to Electronic Potentiometer mode, but no DI has been specified
25 = FI used as DI	This status occurs when the user tries to configure some command that requires a DI with one that was previously configured to be an FI, and vice versa
26 = Alx/FIx Torque Ref.	It indicates that the torque reference source for Remote 1 and/or Remote 2 mode has been set to Analog Input (AI) or Frequency Input (FI) mode, but no AI or FI has been specified
27 = SP Source PID	It indicates that the PID Controller Setpoint source has been set to Analog Input (AI) mode, but no AI has been specified
28 = PV Source PID	It indicates that the PID Controller Process Variable source was set to Analog Input (AI) mode, but no AI was specified
29 = DI Source PID	It indicates that the Manual/Auto command source has been set to Digital Input (DI) mode, but no DI has been specified
30 = Supply Voltage	It indicates that the inverter supply voltage setting (type or rated voltage) is inappropriate for the model used
31 ... 33 = Not used	Not used

.5 Paralelism

Bit	Value/Description
Bit 0 ... 1 Mode	0 = Desativado 1 = Mestre 2 = Seguidor 3 = Rack mestre
Bit 2 ... 4 Synchronization	0 = Desativado 1 = Aguardando mestre 2 = Sincronizando com o mestre 3 = Sincronizado com o mestre 4 = Seguidor pronto 5 = Aguardando seguidor 6 = Sincronizando com os seguidores 7 = Mestre pronto
Bit 5 ... 7 Followers status	0 = Desativado 1 = Aguardando comunicação 2 = Sincronizando 3 = Sincronizado 4 = Pronto para habilitar 5 = PWM habilitado

S1.2 Software version

It indicates the software versions contained in all microcontrollers installed on the MVW.

S1.2 Software version

.1 AUI
.2 CCE CPU
to
.4 HMI
.8 CIB connector 1
.9 CIB connector 2

.1 AUI It indicates the version of the software package, which is formed by the set of program files saved in the MVW microcontrollers.

.2 CCE CPU to **.4 HMI** Indicates the software version.

.8 CIB connector 1 to **.9 CIB connector 2**

S1.4 Accessory data

It presents the control accessories that are installed in the MVW.

S1.4.1 Backplane

It allows viewing the model of the Backplane that is connected to the MVW.

S1.4.1 Backplane

.1 Model 0 ... 2

.1 Model Model of the Backplane installed.

Indication	Description
0 = Disconnected	It indicates that there is no Backplane connected to the MVW
1 = 4 SLOTS	It indicates that the 4-position (Slot) Backplane is connected to the MVW
2 = 7 SLOTS	It indicates that the 7-position (Slot) Backplane is connected to the MVW

S1.4.2 Slot A to S1.4.8 Slot G

It allows viewing Slot accessory information.

S STATUS

S1.4.2 Slot A

S1.4.3 Slot B

S1.4.4 Slot C

S1.4.5 Slot D

S1.4.6 Slot E

S1.4.7 Slot F

S1.4.8 Slot G

.1 Accessory Identified

0 ... 9

.1 Accessory Identified

Indication	Description
0 = Unknown	It indicates that the accessory installed in the Slot is not recognized by this MVW version
1 = No Accessory	It indicates that the Slot has no accessories
2 = IOAI-01	Accessory with analog inputs and outputs
3 = IOD-01	Accessory with digital inputs and outputs
4 = REL-01	Accessory with digital relay outputs
5 = TEMP-01	Accessory with isolated inputs for PTC/PT100/PT1000 sensors
6 = ENC-01	Accessory for incremental encoder connection
7 = Not used	Not used
8 = CCAN-W	Communication accessory for CAN interface
9 = C...-N (Anybus)	Communication accessory for Anybus-CC module



NOTE!

Control accessories can be installed in any available slot. It is only possible to use one communication module of each type. Except for explicitly listed cases, up to 7 accessories of the same type can be used.

S1.4.9 Control board

Allows you to view the status of the digital inputs and outputs used by the inverter control.

S1.4.9 Control board

.1 Accessory identified

0 ... 3 Bit

.1 Accessory identified

Bit	Value/Description
Bit 0 ... 1 Slot XC7	0 = Unknown: It indicates that the accessory installed in the Slot is not recognized by this MVW version 1 = No Accessory: It indicates that the Slot has no accessories 2 = Encoder: Accessory with analog inputs and outputs
Bit 2 ... 3 Slot XC8	0 = Unknown: It indicates that the accessory installed in the Slot is not recognized by this MVW version 1 = No Accessory: It indicates that the Slot has no accessories 2 = Encoder: Accessory with analog inputs and outputs
Bit 4 ... 5 Slot XC9	0 = Unknown: It indicates that the accessory installed in the Slot is not recognized by this MVW version 1 = No Accessory: It indicates that the Slot has no accessories 2 = Encoder: Accessory with analog inputs and outputs
Bit 6 ... 7 Slot XC10	0 = Unknown: It indicates that the accessory installed in the Slot is not recognized by this MVW version 1 = No Accessory: It indicates that the Slot has no accessories 2 = Encoder: Accessory with analog inputs and outputs

S1.5 Date/Hour

It allows viewing the date and time setting of the MVW.

S1.5 Date/Hour

.1 Actual	YYYY-MM-DD HH:MM:SS
.2 Time Zone	0 ... 52

.1 Actual It indicates the actual date (YYYY-MM-DD) and time (HH:MM:SS) of the MVW.

.2 Time Zone Setting of the time zone where the product is applied.

The options are shown in the table below.

Table 7.5: Time zone where the product is applied

Time Zone Options					
0 = UTC-12:00	9 = UTC-07:30	18 = UTC-03:00	27 = UTC+01:30	36 = UTC+06:00	45 = UTC+10:30
1 = UTC-11:30	10 = UTC-07:00	19 = UTC-02:30	28 = UTC+02:00	37 = UTC+06:30	46 = UTC+11:00
2 = UTC-11:00	11 = UTC-06:30	20 = UTC-02:00	29 = UTC+02:30	38 = UTC+07:00	47 = UTC+11:30
3 = UTC-10:30	12 = UTC-06:00	21 = UTC-01:30	30 = UTC+03:00	39 = UTC+07:30	48 = UTC+12:00
4 = UTC-10:00	13 = UTC-05:30	22 = UTC-01:00	31 = UTC+03:30	40 = UTC+08:00	49 = UTC+12:30
5 = UTC-09:30	14 = UTC-05:00	23 = UTC-00:30	32 = UTC+04:00	41 = UTC+08:30	50 = UTC+13:00
6 = UTC-09:00	15 = UTC-04:30	24 = UTC+00:00	33 = UTC+04:30	42 = UTC+09:00	51 = UTC+13:30
7 = UTC-08:30	16 = UTC-04:00	25 = UTC+00:30	34 = UTC+05:00	43 = UTC+09:30	52 = UTC+14:00
8 = UTC-08:00	17 = UTC-03:30	26 = UTC+01:00	35 = UTC+05:30	44 = UTC+10:00	

S1.6 Control words

It allows viewing the status of the HMI, DI and global control words. Each bit of this word represents a command that can be executed on the inverter.

S1.6 Control words

.1 Global	0 ... 7 Bit
.2 HMI	0 ... 7 Bit
.3 DI	0 ... 7 Bit

.1 Global Indicates the status of the MVW global control word.

This is the effective command word for the MVW.

The global control word bits are generated from the specific control words of each source according to the command mode (Local/Remote) and the settings in the C4.2.1 and C4.2.2 menus.

**NOTE!**

The general enable command may contain a digital input that acts together with the chosen command source. Both must be active/inactive simultaneously for the command to take place. When parameter is set C4.2.3.1 to "Inactive", the general enable command is assigned only by the source set (C4.2.1.1 or C4.2.2.1).

**NOTE!**

The quick stop command may contain a digital input that acts together with the chosen command source. Both must be active/inactive simultaneously for the command to take place. When parameter C4.2.3.7 is set to "Inactive", the fast stop command is assigned only by the source set (C4.2.1.2 or C4.2.2.2).

**NOTE!**

The fault reset command occurs through any command source, regardless of the command mode (Local/Remote 1/Remote 2) or source set.

S STATUS

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.2 HMI It indicates the status of the control word via HMI.

For the commands of this parameter to be executed, the inverter must be programmed to be controlled via HMI. This programming is done through the menuC4.

HMI Control Word:

- When pressing the HMI key, the command Enable Ramp is set to 1.
- When pressing the HMI key, the command Enable Ramp is set to 0.
- The General Enable command can be disabled when the key of the HMI is pressed and the parameter C4.2.4.1 is set to coast to stop.
- When pressing the HMI key , the Run Reverse command is alternated.
- As long as the HMI key is pressed, the Enable JOG command is kept at 1.
- When pressing the HMI key , the command mode is changed from local to remote or vice versa.
- The 2nd Ramp command is always kept at 0 (always 1st Ramp).
- The Quick Stop command can be activated when the key of the HMI is pressed and the parameter C4.2.4.1 is set to quick stop.
- When there is an fault active, by pressing the HMI key the Fault Reset command is set to 1.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 LOC/REM Mode	0 = REM: it selects the Remote command mode 1 = LOC: it selects the Local command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.3 DI It indicates the status of the control word via digital inputs.

For the commands written in this parameter to be executed, the inverter must be programmed to be controlled via Digital Input. This programming is done through the menus C4 and C4.2.3.

Control Word via DI:

- The Enable Ramp command depends on the configuration of parameters C4.2.1.2 or C4.2.2.2, according to options 7, 8 and 9 below.
 - For option 7: Run/Stop DI, the Enable Ramp command reflects the status of the digital input set in C4.2.3.2. Active DI means Enable Ramp and inactive DI means Disable Ramp.
 - For option 8: Forward/Reverse DI, the behavior of the Enable Ramp command is determined by a combination of the status of the digital inputs set in C4.2.3.5 and C4.2.3.6.
 - For option 9: 3-Wire Start/Stop DI, the Enable Ramp command has its behavior given by a combination of the status of the digital inputs set in C4.2.3.3 and C4.2.3.4.
- The General Enable command reflects the status of the digital input set in C4.2.3.1. Active DI means General Enabled and Inactive DI means General Disabled.
- The Run Reverse command depends on the settings made in parameters C4.2.1.3 and C4.2.2.3, according to options 7 and 8 below.
 - For option 7: Direction of Rotation DI, the Run Reverse command reflects the status of the digital input set in C4.2.3.8. Active DI means Reverse Direction and inactive DI means Forward Direction.
 - For option 8: Forward/Reverse DI, the behavior of the Run Reverse command is determined by a combination of the status of the digital inputs set in C4.2.3.5 and C4.2.3.6.
- The Enable JOG command reflects the status of the digital input set in C4.2.3.9. DI active means Enable JOG and DI inactive means Disable JOG.
- The 2nd Ramp command reflects the status of the digital input set in C4.2.3.10. Active DI means 2nd Ramp and inactive DI means 1st Ramp.
- The Fast Stop command reflects the status of the digital input set in C4.2.3.7. Active DI means No Fast Stop and Inactive DI means With Fast Stop.
- The Fault Reset command reflects the status of the digital input set in C4.2.3.11. Active DI means Reset of Fault and inactive DI means No Action.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

S2 MEASUREMENTS

It allows viewing the variables measured by the MVW.

S STATUS

S2.1 Motor speed

It indicates the variables related to the motor speed.

S2.1 Motor speed		
.1 Reference		0 ... 60000 rpm
.3 Motor speed		0 ... 60000 rpm
.4 Encoder		0 ... 65535 rpm
.5 Estimated Value		0 ... 60000 rpm

.1 Reference It indicates the speed reference value in RPM.

.3 Motor speed It indicates the actual motor speed value in RPM used by the controller module.

This value considers the control type selected in C3.1.1 to use either the estimated value in S2.1.5 or the speed measured by the encoder in S2.1.4.

.4 Encoder It indicates the actual encoder speed in RPM.

.5 Estimated Value It indicates the estimated motor speed value in RPM.

The estimation is based on the control type selected in C3.1.1, presenting the theoretical speed defined by the V/f curve or the value estimated by the speed observers.

S2.2 Motor Torque

It indicates the variables related to the motor torque.

S2.2 Motor Torque		
.1 Reference		-400.0 ... 400.0 %
.2 Total Reference		-400.0 ... 400.0 %
.3 Motor torque		-400.0 ... 400.0 %

.1 Reference It indicates the electrical torque reference on the motor in % based on the motor rated torque.

.2 Total Reference It indicates the value of the motor torque reference after the ramp.

.3 Motor torque It indicates the estimated electrical torque on the motor in % based on the rated motor torque.

S2.3 Inverter Output

It indicates the MVW output variables applied to the motor.

S2.3 Inverter Output

.1 Motor current	0.0 ... 6553.5 A
.2 Iu current	0.0 ... 6553.5 A
to	
.4 Iw current	0.0 ... 6553.5 A
.5 Output voltage	0.00 ... 655.35 kV
.6 Output voltage Vuv	0.00 ... 200.00 kV
to	
.8 Output voltage Vwu	0.00 ... 200.00 kV
.9 Frequency	0.0 ... 1020.0 Hz
.10 cos phi	-1.00 ... 1.00
.11 Power	0 ... 65535 kW
.12 Energy GWh	0 ... 999 GWh
.13 Energy MWh	0 ... 999 MWh
.14 Energy kWh	0.0 ... 999.9 kWh
.17 Voltage between the virtual neutral of the motor and the GND	0.0 ... 6553.5 %
.18 Use of the modulation index	0.0 ... 100.0 %
.19 Inverter current	0.0 ... 6553.5 A

.1 Motor current It indicates the RMS value of the fundamental component of the inverter output current, in Amperes (A).

.2 Iu current to .4 Iw current Indicates the effective value of the current of the respective output phase of the inverter, in Amperes (A).

.5 Output voltage It indicates the inverter output voltage in Volts (V).

.6 Output voltage Vuv to .8 Output voltage Vwu Indicates the line voltage measured at the inverter input, in kV effective value, of the respective phase.

.9 Frequency It indicates the motor synchronous frequency in Hz.

.10 cos phi It indicates the motor cos phi value.

.11 Power It indicates the electrical power at the inverter output in kW.

.12 Energy GWh It indicates the energy consumed by the motor in GWh.

.13 Energy MWh It indicates the energy consumed by the motor in MWh.

.14 Energy kWh It indicates the energy consumed by the motor in kWh.

**NOTE!**

The total energy consumed by the motor is the sum of the values given in GWh, MWh and kWh. However, these parameters are calculated indirectly and should not be used to measure energy consumption.

.17 Voltage between the virtual neutral of the motor and the GND It indicates the value of the voltage between the virtual motor neutral and the ground (GND) of the inverter, as a percentage of the nominal effective phase voltage of the inverter.

.18 Use of the modulation index Indicates the ratio between the current modulation index and the maximum allowed modulation index.

.19 Inverter current Indicates the inverter output current, in Amperes.

S STATUS

S2.4 Temperatures

Indicates the temperatures of the inverter, motor and transformer.

S2.4.1 Temperature accessory

S2.4.1 Temperature accessory	
.3 Sensor Measured Value	-100.0 ... 250.0 °C

.3 Sensor Measured Value It indicates the value of the motor temperature measured by the temperature accessory.

The value indicated considers the highest temperature measured by the first temperature accessory identified by the inverter. If no temperature accessory is identified, this parameter will remain hidden from view by the HMI.

S2.4.2 Thermal protection relay

S2.4.2 Thermal protection relay	
.1 Relay 1 Temperature CH1	-10 ... 250 °C
to	
.8 Relay 1 Temperature CH8	-10 ... 250 °C
.9 Relay 2 Temperature CH1	-10 ... 250 °C
to	
.16 Relay 2 Temperature CH8	-10 ... 250 °C
.17 Relay 3 Temperature CH1	-10 ... 250 °C
to	
.24 Relay 3 Temperature CH8	-10 ... 250 °C
.25 Relay 4 Temperature CH1	-10 ... 250 °C
to	
.32 Relay 4 Temperature CH8	-10 ... 250 °C
.33 Relay 5 Temperature CH1	-10 ... 250 °C
to	
.40 Relay 5 Temperature CH8	-10 ... 250 °C
.41 Relay 6 Temperature CH1	-10 ... 250 °C
to	
.48 Relay 6 Temperature CH8	-10 ... 250 °C

.1 Relay 1 Temperature CH1 to .8 Relay 1 Temperature CH8 Indicates the value of the motor temperature measured by the thermal protection relay.



ATTENTION!

During the use of functions **PRG** (programming) and **VIS** (viewing) of the relay, data exchange is interrupted, which may cause a time-out error in the communication with the inverter.



ATTENTION!

In case of sensor break (open circuit) in a temperature channel, the reading will indicate the full scale value.

.9 Relay 2 Temperature CH1 to .16 Relay 2 Temperature CH8 Indicates the value of the motor temperature measured by the thermal protection relay.

.17 Relay 3 Temperature CH1 to .24 Relay 3 Temperature CH8 Indicates the value of the motor temperature measured by the thermal protection relay.

.25 Relay 4 Temperature CH1 to .32 Relay 4 Temperature CH8 Indicates the value of the motor temperature measured by the thermal protection relay.

.33 Relay 5 Temperature CH1 to .40 Relay 5 Temperature CH8 Indicates the value of the motor temperature measured by the thermal protection relay.

.41 Relay 6 Temperature CH1 to .48 Relay 6 Temperature CH8 Indicates the value of the motor temperature measured by the thermal protection relay.

S2.4.3 Air temperature

It indicates the temperature of the inverter internal air.

S2.4.3 Air temperature

.2 AUI board CPU	-50.0 ... 250.0 °C
.3 CCE Control board	-50.0 ... 250.0 °C

.2 AUI board CPU Indicates the CPU temperature at the user interface board.

This temperature is used, together with other measurements, in falha de sobretemperatura da placa de controle.

The user's temperature offset adjustment impacts this temperature value.

.3 CCE Control board Indicates the temperature at the main control board sensor.

S2.4.4 Inverter arms

S2.4.4 Inverter arms

.1 Phase U temperature to .12 Phase WBp temperature	0.0 ... 300.0 °C
	0.0 ... 300.0 °C

.1 Phase U temperature to .12 Phase WBp temperature

S2.4.5 Rectifier temperature

It indicates the temperature of the inverter rectifiers.

S2.4.5 Rectifier temperature

.1 Rectifier temperature 1 to .6 Rectifier temperature 6	0.0 ... 300.0 °C
	0.0 ... 300.0 °C

.1 Rectifier temperature 1 to .6 Rectifier temperature 6 It indicates the temperature of the rectifier module.

S2.4.6 Braking arms

S2.4.6 Braking arms

.1 Braking arm temperature	0.0 ... 300.0 °C
----------------------------	------------------

.1 Braking arm temperature

S STATUS

S2.4.7 Auxiliary measurements

S2.4.7 Auxiliary measurements	
.1 Auxiliary sensor temperature 1 to .3 Auxiliary sensor temperature 3	0.0 ... 300.0 °C

.1 Auxiliary sensor temperature 1 to .3 Auxiliary sensor temperature 3

S2.6 Inverter Input

It indicates the current and voltage value of the inverter power supply.

S2.6 Inverter Input	
.4 Input voltage	0.00 ... 200.00 kV
.5 Input voltage Vab to .7 Input voltage Vca	0.00 ... 200.00 kV
.8 Frequency	0.00 ... 100.00 Hz

.4 Input voltage It indicates the voltage effective value at the inverter input, in kV.

.5 Input voltage Vab to .7 Input voltage Vca Indicates the line voltage measured at the inverter input, in kV effective value, of the respective phase.

.8 Frequency Indicates the input frequency of the inverter, in hertz (Hz).

S2.7 DC Link

It allows viewing the DC Link voltage value.

S2.7 DC Link	
.1 DC voltage	0 ... 20000 V
.2 Positive DC link voltage	0 ... 10000 V
.3 Negative DC link voltage	0 ... 10000 V
.4 Phase V positive DC link voltage	0 ... 10000 V
.5 Phase V negative DC link voltage	0 ... 10000 V
.6 Phase W positive DC link voltage	0 ... 10000 V
.7 Phase W negative DC link voltage	0 ... 10000 V

.1 DC voltage Indicates the calculated value across all currently active cells.

.2 Positive DC link voltage to .3 Negative DC link voltage Indicates the current DC link voltage, in Volts.

.4 Phase V positive DC link voltage to .5 Phase V negative DC link voltage Indicates the current DC link voltage, in Volts.

.6 Phase W positive DC link voltage to .7 Phase W negative DC link voltage Indicates the current DC link voltage, in Volts.

S2.8 Torque Current Limitation

It allows viewing the parameters related to the motor torque limiter via Analog Input.

S2.8 Torque Current Limitation	
.1 Alx Global Torque	0.0 ... 400.0 %

.1 AIx Global Torque It defines the maximum torque value in the four quadrants of motor operation via Analog Input (selected in parameter C3.3.5.1.6). If it is necessary to control the torque in the four motor operation quadrants, parameters C3.3.5.1.2 to C3.3.5.1.5 must be used.

S3 I/OS

It allows viewing the status of the I/O accessories installed on the MVW.

S3.1 Slot X Status

Allows you to view the status of the slot status parameters.




Figure 7.1: IOS Accessory, Slot X

S3.1.1 Analog Inputs

It allows viewing the value of the analog inputs of the accessory connected to the slot.

S3.1.1 Analog Inputs

.1 AI1	-100.00 ... 100.00 %
.2 AI2	-100.00 ... 100.00 %

.1 AI1, .2 AI2 Value of the analog input in percentage according to the type of signal configured.

Where 0 % = minimum value of the configured signal - includes gain and offsets (e.g. 4 mA for 4...20 mA signal) and 100 % = maximum value of the configured signal.

S3.1.2 Analog Outputs

It allows viewing the value of the analog outputs of the accessory connected to the slot.

The data source for each output is independently configured through specific parameters described in C5.1.2. The status indication may have percentage values relative to the full scale values. Such values depend on the function selected for the analog output and are also described in detail in item C5.1.2.

S3.1.2 Analog Outputs

.1 AO1	-100.00 ... 100.00 %
.2 AO1 Network	-100.00 ... 100.00 %
.3 AO1 SoftPLC	-100.00 ... 100.00 %
.4 AO2	-100.00 ... 100.00 %
.5 AO2 Network	-100.00 ... 100.00 %
.6 AO2 SoftPLC	-100.00 ... 100.00 %

.1 AO1 , .4 AO2 Value of the analog output in percentage according to the type of signal configured.

.2 AO1 Network, .5 AO2 Network Value of the analog output, when controlled by communication network, in percentage according to the type of signal configured.

.3 AO1 SoftPLC, .6 AO2 SoftPLC Value of the analog output, when controlled by SoftPLC, in percentage according to the type of signal configured.

S3.1.3 Digital Inputs

It allows viewing the value of the digital inputs of the accessory connected to the slot.

S3.1.3 Digital Inputs

.1 DI	0 ... 5 Bit
.2 FI5	-100.00 ... 100.00 %
.3 FI5 (Hz)	0 ... 32000 Hz
.4 FI6	-100.00 ... 100.00 %
.5 FI6 (Hz)	0 ... 32000 Hz

.1 DI It indicates the status of digital inputs.

Bit	Value/Description
Bit 0 DI1	It indicates the status of Digital Input DI1. 0 = Inactive: It indicates that Digital Input DI1 is inactive 1 = Active: It indicates that Digital Input DI1 is active
Bit 1 DI2	It indicates the status of Digital Input DI2. 0 = Inactive: It indicates that Digital Input DI2 is inactive 1 = Active: It indicates that Digital Input DI2 is active
Bit 2 DI3	It indicates the status of Digital Input DI3. 0 = Inactive: It indicates that Digital Input DI3 is inactive 1 = Active: It indicates that Digital Input DI3 is active
Bit 3 DI4	It indicates the status of Digital Input DI4. 0 = Inactive: It indicates that Digital Input DI4 is inactive 1 = Active: It indicates that Digital Input DI4 is active
Bit 4 DI5	It indicates the status of Digital Input DI5. 0 = Inactive: It indicates that Digital Input DI5 is inactive 1 = Active: It indicates that Digital Input DI5 is active
Bit 5 DI6	It indicates that Digital Input DI6 is inactive. 0 = Inactive: It indicates that Digital Input DI6 is inactive 1 = Active: It indicates that Digital Input DI6 is active

.2 FI5, .4 FI6 It indicates (in percentage of the full scale) the actual value of frequency input.

.3 FI5 (Hz), .5 FI6 (Hz) It indicates (in Hz) the actual value of frequency input.

S3.1.4 Digital Outputs

It allows viewing the value of the digital outputs of the accessory connected to the slot.

S3.1.4 Digital Outputs

.1 DO	0 ... 1 Bit
.4 FO1	-100.00 ... 100.00 %
.5 FO1 (Hz)	0 ... 32000 Hz
.6 FO1 Network	-100.00 ... 100.00 %
.7 FO1 SoftPLC	-100.00 ... 100.00 %
.8 FO2	-100.00 ... 100.00 %
.9 FO2 (Hz)	0 ... 32000 Hz
.10 FO2 Network	-100.00 ... 100.00 %
.11 FO2 SoftPLC	-100.00 ... 100.00 %

.1 DO It indicates the status of digital outputs.

Bit	Value/Description
Bit 0 DO1	It indicates the status of Digital Output DO1. 0 = Inactive: It indicates that Digital Output DO1 is inactive 1 = Active: It indicates that Digital Output DO1 is active
Bit 1 DO2	It indicates the status of Digital Output DO2. 0 = Inactive: It indicates that Digital Output DO2 is inactive 1 = Active: It indicates that Digital Output DO2 is active

.4 FO1, .8 FO2 It indicates (in percentage of the full scale) the actual value of frequency output.

.5 FO1 (Hz), .9 FO2 (Hz) It indicates (in Hz) the actual value of frequency output.

.6 FO1 Network, .10 FO2 Network It indicates (in percentage of the full scale) the actual value supplied via Networks to frequency output.

.7 FO1 SoftPLC, .11 FO2 SoftPLC It indicates (in percentage of the full scale) the actual value supplied via SoftPLC to frequency output.

S3.1.5 Encoder

It allows viewing the actual status of the encoder signal measurements carried out by the accessory.

S3.1.5 Encoder

.1 Number of Revolutions	0 ... 65535
.2 Revolution Fraction	0 ... 65535
.3 Speed	-60000 ... 60000 rpm

.1 Number of Revolutions Number of full revolutions measured by the encoder.

This parameter is reset to 0 during power up. When the zero search is completed this parameter is reset.

It increases when one complete revolution is measured in the forward direction and decreases when one complete revolution is measured in the reverse direction.

.2 Revolution Fraction Value proportional (from 0 to 65535) to the fraction of a revolution (incomplete revolution) measured by the encoder.

This parameter is reset to 0 during power up. When the zero search is completed this parameter is reset.

It increases when pulses are measured in the forward direction and decreases when pulses are measured in the reverse direction.

For example, for a 1024-pulse encoder that has rotated 3.5 revolutions in the forward direction (3584 pulses), this parameter will indicate 32768 (0.5 revolutions). If the encoder shaft rotates 0.75 revolutions in the reverse direction, totaling 2.75 revolutions (2816 pulses) the parameter will indicate 49152 (0.75 revolutions).

S STATUS

.3 Speed It indicates the speed, in rpm, measured by the encoder.

The speed indicated in this parameter is calculated by counting the encoder pulses occurred in a time frame of 1 ms. This parameter is updated every 1 ms.

Positive values indicate forward rotation, and negative values indicate reverse rotation.

The value of this parameter is presented without filters.

S3.2 Slot A Status

S3.3 Slot B Status

S3.4 Slot C Status

S3.5 Slot D Status

S3.6 Slot E Status

S3.7 Slot F Status

S3.8 Slot G Status

It allows viewing the state of the slot status parameters.

S3.2.1 Analog Inputs to S3.8.1 Analog Inputs

It allows viewing the value of the analog inputs of the accessory connected to the slot.

S3.2.1 Analog Inputs		
S3.3.1 Analog Inputs		
S3.4.1 Analog Inputs		
S3.5.1 Analog Inputs		
S3.6.1 Analog Inputs		
S3.7.1 Analog Inputs		
S3.8.1 Analog Inputs		
.1 AI1		-100.00 ... 100.00 %
to		
.3 AI3		-100.00 ... 100.00 %

.1 AI1, .2 AI2, .3 AI3 Value of the analog input in percentage according to the type of signal configured.

Where 0 % = minimum value of the configured signal - includes gain and offsets (e.g. 4 mA for 4...20 mA signal) and 100 % = maximum value of the configured signal.

S3.2.2 Analog Outputs to S3.8.2 Analog Outputs

It allows viewing the value of the analog outputs of the accessory connected to the slot.

The data source for each output is independently configured through specific parameters described in the configuration menu for the analog outputs of the accessory connected to the slot. Using Slot A as an example, the menu can be found in item C5.2. The status indication may have percentage values relative to the full scale values. Such values depend on the function selected for the analog output and are also described in detail in the menu of analog outputs of the accessory connected to the slot.

S3.2.2 Analog Outputs**S3.3.2 Analog Outputs****S3.4.2 Analog Outputs****S3.5.2 Analog Outputs****S3.6.2 Analog Outputs****S3.7.2 Analog Outputs****S3.8.2 Analog Outputs**

.1 AO1	-100.00 ... 100.00 %
.2 AO1 Network	-100.00 ... 100.00 %
.3 AO1 SoftPLC	-100.00 ... 100.00 %
.4 AO2	-100.00 ... 100.00 %
.5 AO2 Network	-100.00 ... 100.00 %
.6 AO2 SoftPLC	-100.00 ... 100.00 %

.1 AO1 , .4 AO2 Value of the analog output in percentage according to the type of signal configured.

.2 AO1 Network, .5 AO2 Network Value of the analog output, when controlled by communication network, in percentage according to the type of signal configured.

.3 AO1 SoftPLC, .6 AO2 SoftPLC Value of the analog output, when controlled by SoftPLC, in percentage according to the type of signal configured.

S3.2.3 Digital Inputs to S3.8.3 Digital Inputs

It allows viewing the value of the digital inputs of the accessory connected to the slot.

S3.2.3 Digital Inputs**S3.3.3 Digital Inputs****S3.4.3 Digital Inputs****S3.5.3 Digital Inputs****S3.6.3 Digital Inputs****S3.7.3 Digital Inputs****S3.8.3 Digital Inputs**

.1 DI	0 ... 7 Bit
-------	-------------

.1 DI It indicates the status of digital inputs.

S STATUS

Bit	Value/Description
Bit 0 DI1	It indicates the status of Digital Input DI1. 0 = Inactive: It indicates that Digital Input DI1 is inactive 1 = Active: It indicates that Digital Input DI1 is active
Bit 1 DI2	It indicates the status of Digital Input DI2. 0 = Inactive: It indicates that Digital Input DI2 is inactive 1 = Active: It indicates that Digital Input DI2 is active
Bit 2 DI3	It indicates the status of Digital Input DI3. 0 = Inactive: It indicates that Digital Input DI3 is inactive 1 = Active: It indicates that Digital Input DI3 is active
Bit 3 DI4	It indicates the status of Digital Input DI4. 0 = Inactive: It indicates that Digital Input DI4 is inactive 1 = Active: It indicates that Digital Input DI4 is active
Bit 4 DI5	It indicates the status of Digital Input DI5. 0 = Inactive: It indicates that Digital Input DI5 is inactive 1 = Active: It indicates that Digital Input DI5 is active
Bit 5 DI6	It indicates the status of Digital Input DI6. 0 = Inactive: It indicates that Digital Input DI6 is inactive 1 = Active: It indicates that Digital Input DI6 is active
Bit 6 DI7	It indicates the status of Digital Input DI7. 0 = Inactive: It indicates that Digital Input DI7 is inactive 1 = Active: It indicates that Digital Input DI7 is active
Bit 7 DI8	It indicates the status of Digital Input DI8. 0 = Inactive: It indicates that Digital Input DI8 is inactive 1 = Active: It indicates that Digital Input DI8 is active

S3.2.4 Digital Outputs to S3.8.4 Digital Outputs

It allows viewing the value of the digital outputs of the accessory connected to the slot.

S3.2.4 Digital Outputs	
S3.3.4 Digital Outputs	
S3.4.4 Digital Outputs	
S3.5.4 Digital Outputs	
S3.6.4 Digital Outputs	
S3.7.4 Digital Outputs	
S3.8.4 Digital Outputs	
.1 DO	0 ... 7 Bit
.2 DO Network	0 ... 7 Bit
.3 DO SoftPLC	0 ... 7 Bit

.1 DO It indicates the status of digital outputs.

.2 DO Network It indicates the Network command status to the digital outputs.

.3 DO SoftPLC It indicates the SoftPLC command status to the digital outputs.

Bit	Value/Description
Bit 0 DO1	It indicates the status of Digital Output DO1. 0 = Inactive: It indicates that Digital Output DO1 is inactive 1 = Active: It indicates that Digital Output DO1 is active
Bit 1 DO2	It indicates the status of Digital Output DO2. 0 = Inactive: It indicates that Digital Output DO2 is inactive 1 = Active: It indicates that Digital Output DO2 is active
Bit 2 DO3	It indicates the status of Digital Output DO3. 0 = Inactive: It indicates that Digital Output DO3 is inactive 1 = Active: It indicates that Digital Output DO3 is active
Bit 3 DO4	It indicates the status of Digital Output DO4. 0 = Inactive: It indicates that Digital Output DO4 is inactive 1 = Active: It indicates that Digital Output DO4 is active
Bit 4 DO5	It indicates the status of Digital Output DO5. 0 = Inactive: It indicates that Digital Output DO5 is inactive 1 = Active: It indicates that Digital Output DO5 is active
Bit 5 DO6	It indicates the status of Digital Output DO6. 0 = Inactive: It indicates that Digital Output DO6 is inactive 1 = Active: It indicates that Digital Output DO6 is active
Bit 6 DO7	It indicates the status of Digital Output DO7. 0 = Inactive: It indicates that Digital Output DO7 is inactive 1 = Active: It indicates that Digital Output DO7 is active
Bit 7 DO8	It indicates the status of Digital Output DO8. 0 = Inactive: It indicates that Digital Output DO8 is inactive 1 = Active: It indicates that Digital Output DO8 is active

S3.2.5 Encoder to S3.8.5 Encoder

It allows viewing the actual status of the encoder signal measurements carried out by the accessory.

S3.2.5 Encoder

S3.3.5 Encoder

S3.4.5 Encoder

S3.5.5 Encoder

S3.6.5 Encoder

S3.7.5 Encoder

S3.8.5 Encoder

.1 Number of Revolutions	0 ... 65535
.2 Revolution Fraction	0 ... 65535
.3 Speed	-60000 ... 60000 rpm
.4 Search Zero	0 ... 1

.1 Number of Revolutions Number of complete revolutions measured by the encoder.

This parameter is reset to 0 during power up. When the zero search is completed this parameter is reset.

It increases when one complete revolution is measured in the forward direction and decreases when one complete revolution is measured in the reverse direction.

.2 Revolution Fraction Value proportional (from 0 to 65535) to the fraction of a revolution (incomplete revolution) measured by the encoder.

This parameter is reset to 0 during power up. When the zero search is completed this parameter is reset.

It increases when pulses are measured in the forward direction and decreases when pulses are measured in the reverse direction.

For example, for a 1024-pulse encoder that has rotated 3.5 revolutions in the forward direction (3584 pulses), this parameter will indicate 32768 (0.5 revolutions). If the encoder shaft rotates 0.75 revolutions in the reverse direction, totaling 2.75 revolutions (2816 pulses) the parameter will indicate 49152 (0.75 revolutions).

.3 Speed It indicates the speed, in rpm, measured by the encoder.

S STATUS

The speed indicated in this parameter is calculated by counting the encoder pulses occurred in a time frame of 1 ms. This parameter is updated every 1 ms.

Positive values indicate forward rotation, and negative values indicate reverse rotation.

The value of this parameter is presented without filters.

.4 Search Zero It indicates whether the zero search function of the encoder has completed.

Indication	Description
0 = Inactive	It indicates that the search zero function has not been started or is in progress
1 = Completed	It indicates that the zero search function is complete

S3.2.6 Temperatures to S3.8.6 Temperatures

It allows viewing the temperature of the sensors connected to the slot accessory in °C.

S3.2.6 Temperatures	
S3.3.6 Temperatures	
S3.4.6 Temperatures	
S3.5.6 Temperatures	
S3.6.6 Temperatures	
S3.7.6 Temperatures	
S3.8.6 Temperatures	
.1 Sensor 1	-100.0 ... 250.0 °C
to	
.6 Sensor 6	-100.0 ... 250.0 °C

.1 Sensor 1, .2 Sensor 2, .3 Sensor 3, .4 Sensor 4, .5 Sensor 5, .6 Sensor 6 It indicates the temperature at the Slot sensor (°C).

S3.9 Control board

Allows you to view the status of the digital inputs and outputs used by the inverter control.

S3.9.1 Analog inputs

It allows viewing the value of the analog inputs of the accessory connected to the slot.

S3.9.1 Analog inputs	
.1 Value of AI1 from the control board	-250.00 ... 250.00 %
.2 Value of AI2 from the control board	-250.00 ... 250.00 %

.1 Value of AI1 from the control board to .2 Value of AI2 from the control board Value of the analog input in percentage according to the type of signal configured.

Where 0 % = minimum value of the configured signal - includes gain and offsets and 100 % = maximum value of the configured signal.

S3.9.2 Analog Outputs

It allows viewing the value of the analog outputs of the accessory connected to the slot.

The data source for each output is independently configured through specific parameters described in C5.11.2. The status indication may have percentage values relative to the full scale values. Such values depend on the function selected for the analog output and are also described in detail in item C5.11.2.

S3.9.2 Analog Outputs

.1 Value of AO1 from the control board	-100.00 ... 100.00 %
to	
.4 Value of AO4 from the control board	-100.00 ... 100.00 %

.1 Value of AO1 from the control board to .4 Value of AO4 from the control board It indicates the value of the respective analog output of the control board.

S3.9.3 Digital Inputs

It allows viewing the value of the digital inputs of the accessory connected to the slot.

S3.9.3 Digital Inputs

.1 Control board DI	0 ... 15 Bit
---------------------	--------------

.1 Control board DI Digital inputs located on the PIC board.

Bit	Value/Description
Bit 0 DI16 Closed Doors	0 = Inactive: Not mechanically locked 1 = Active: Mechanically locked
Bit 1 DI15 Spare	0 = Inactive 1 = Active
Bit 2 DI14 Exhaust duct pressure	0 = Inactive: The exhaust duct is without pressure 1 = Active: The pressure in the exhaust duct is OK
Bit 3 DI13 Enable inverter	0 = Inactive: Enable signal: OFF 1 = Active: Enable signal: ON
Bit 4 DI12 Transformer trip	0 = Inactive: Inactive fault 1 = Active: Active fault
Bit 5 DI11 Transformer alarm	0 = Inactive: Alarm inactive 1 = Active: Alarm active
Bit 6 DI10 Cooling system supply fault	0 = Inactive: Alarm inactive 1 = Active: Alarm active
Bit 7 DI9 Rectifier ventilation On	0 = Inactive: Ventilation Off 1 = Active: Ventilation On
Bit 8 DI8 Power supply PS1 OK	0 = Inactive: PS1 power supply failed 1 = Active: PS1 power supply OK
Bit 9 DI7 Pre-charge power supply	0 = Inactive: Precharge power failure 1 = Active: Precharge supply OK
Bit 10 DI6 Output contactor feedback	0 = Inactive: Signal inactive 1 = Active: Signal inactive
Bit 11 DI5 Circuit breaker trip	0 = Inactive: Active protection 1 = Active: Normal operation
Bit 12 DI4 Circuit breaker Off	0 = Inactive: Input circuit breaker ON 1 = Active: Input circuit breaker OFF
Bit 13 DI3 Circuit breaker On	0 = Inactive: Input circuit breaker OFF 1 = Active: Input circuit breaker ON
Bit 14 DI2 Circuit breaker ready	0 = Inactive: Input circuit breaker is not ready 1 = Active: Input circuit breaker ready
Bit 15 DI1 Power On	0 = Inactive: Power ON signal off 1 = Active: Power ON signal on

S3.9.4 Digital Outputs

It allows viewing the value of the digital outputs of the accessory connected to the slot.

S3.9.4 Digital Outputs

.1 Control board DO	0 ... 7 Bit
---------------------	-------------

S STATUS

.1 Control board DO Digital outputs located on the PIC board.

Bit	Value/Description
Bit 0 RL8	0 = Inactive: Ventilation off 1 = Active: Inverter ventilation on
Bit 1 RL7 Inverter ventilation	0 = Inactive: Inverter ventilation off 1 = Active:
Bit 2 RL6 Circuit break	0 = Inactive: Input circuit breaker open 1 = Active: Input circuit breaker closed
Bit 3 RL5 2nd stage pre-charge	0 = Inactive: Second stage of precharge turned off 1 = Active: Second stage of precharge on
Bit 4 RL4 Turns off input circuit breaker	0 = Inactive: Input circuit breaker opening command off 1 = Active: Input circuit breaker opening command on
Bit 5 RL3 Closes input circuit breaker	0 = Inactive: Input circuit breaker closing command off 1 = Active: Input circuit breaker closing command on
Bit 6 RL2 1st stage pre-charge	0 = Inactive: First stage of precharge turned off 1 = Active: First stage of precharge on
Bit 7 RL1 Inverter Ready	0 = Inactive: Inverter not ready to drive motor 1 = Active: Inverter is ready to drive the motor

S3.9.5 Encoder

It allows viewing the actual status of the encoder signal measurements carried out by the accessory.

S3.9.5 Encoder	
.1 Number of Revolutions	0 ... 65535
.2 Revolution Fraction	0 ... 65535
.3 Search Zero	0 ... 1
.4 Speed	-60000 ... 60000 rpm

.1 Number of Revolutions Number of whole turns measured by the encoder.

This parameter is initialized to 0 during power-up. When the zero search is complete this parameter is reset to zero.

It increases when a full turn is measured in the forward direction, and decreases when a full turn is measured in the reverse direction.

.2 Revolution Fraction Value proportional (from 0 to 65535) to the fraction of a revolution (incomplete revolution) measured by the encoder.

This parameter is reset to 0 during power up. When the zero search is completed this parameter is reset.

It increases when pulses are measured in the forward direction and decreases when pulses are measured in the reverse direction.

For example, for a 1024-pulse encoder that has rotated 3.5 revolutions in the forward direction (3584 pulses), this parameter will indicate 32768 (0.5 revolutions). If the encoder shaft rotates 0.75 revolutions in the reverse direction, totaling 2.75 revolutions (2816 pulses) the parameter will indicate 49152 (0.75 revolutions).

.3 Search Zero It indicates whether the zero search function of the encoder has completed.

Indication	Description
0 = Inactive	It indicates that the search zero function has not been started or is in progress
1 = Completed	It indicates that the zero search function is complete

.4 Speed It indicates the speed, in rpm, measured by the encoder.

The speed indicated in this parameter is calculated by counting the encoder pulses occurred in a time frame of

1 ms. This parameter is updated every 1 ms.

Positive values indicate forward rotation, and negative values indicate reverse rotation.

The value of this parameter is presented without filters.

S5 COMMUNICATIONS

It allows viewing the parameters used for monitoring and controlling the MVW inverter using communication interfaces.

S5.1 Status and Commands

It allows viewing the MVW logical status and commands.

S5.1 Status and Commands

.1 Status Word 1	0 ... 15 Bit
.2 Speed	-200.00 ... 200.00 %
.3 Status Word 2	0 ... 15 Bit
.4 Status Word 3	0 ... 2 Bit

.1 Status Word 1 It indicates the operating status of the inverter. Each bit represents a status.

Bit	Value/Description
Bit 0 Not used	Not used
Bit 1 Run Command	0 = No: no run command active 1 = Yes: run command active
Bit 2 Local	0 = No: inverter in Remote command mode 1 = Yes: inverter in Local command mode (via HMI)
Bit 3 Not used	Not used
Bit 4 No Quick Stop	0 = No: quick stop command active 1 = Yes: no quick stop command active
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration by C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration by C6.1.4 and C6.1.5
Bit 6 Config. Mode	0 = No: inverter in normal operation 1 = Yes: inverter in configuration status. It indicates a special condition in which the inverter cannot be enabled
Bit 7 Alarm	0 = No: without alarm 1 = Yes: with alarm active
Bit 8 Running	0 = No: motor is stopped 1 = Yes: motor is running according to reference and command
Bit 9 Enabled	0 = No: inverter is general disabled 1 = Yes: inverter is general enabled
Bit 10 Reverse	0 = No: motor running in the forward direction 1 = Yes: motor running in the reverse direction
Bit 11 JOG	0 = No: no JOG command active 1 = Yes: JOG command is active
Bit 12 Remote 2	0 = No: inverter in Remote 1 command mode 1 = Yes: inverter in Remote 2 command mode
Bit 13 Not used	Not used
Bit 14 Not used	Not used
Bit 15 Fault	0 = No: normal operation 1 = Yes: fault acting

.2 Speed It indicates the actual speed of the motor driven by the inverter in percentage of the maximum speed.

- S5.1.2 = 0.00 % ⇒ motor speed = 0 rpm
- S5.1.2 = 100.00 % ⇒ motor speed = C4.3.1.1.2

S STATUS

Intermediate or higher speed values can be obtained by using this scale. For example, if the value read is 25.0 %, considering $C4.3.1.1.2 = 1800 \text{ rpm}$, to obtain the value in rpm you must calculate:

100.00 % : 1800 rpm

25.00 % : Speed

$$\text{Speed} = \frac{25.00 \times 1800}{100.00}$$

Speed = 450 rpm

Negative values indicate motor rotating in the reverse direction of rotation.

.3 Status Word 2 It indicates other status of the inverter functions. Each bit represents a status.

Bit	Value/Description
Bit 0 Self-tuning	0 = No: inverter is not running the Self-tuning routine 1 = Yes: inverter is running the Self-tuning routine for estimating motor parameters
Bit 1 Field Weakening	0 = No: Control is not in the field weakening region 1 = Yes: Control is in the field weakening region
Bit 2 Pre-Charge OK	0 = No: pre-charge of the DC link capacitors not completed 1 = Yes: pre-charge of the DC link capacitors completed
Bit 3 Not used	Not used
Bit 4 Zero Speed	0 = No: Sleep mode inactive 1 = Yes: Sleep mode active
Bit 5 Decel. Ramp	0 = No: no deceleration 1 = Yes: inverter decelerating
Bit 6 Acc. Ramp	0 = No: no acceleration 1 = Yes: inverter accelerating
Bit 7 Freeze Ramp	0 = No: ramp in normal operation 1 = Yes: the path of the ramp is frozen by some command source or internal function
Bit 8 Setpoint OK	0 = No: motor speed has not reached the reference yet 1 = Yes: motor speed has reached the reference
Bit 9 DC Voltage Limitation	0 = No: DC link limitation or current limitation inactive 1 = Yes: DC link limitation or current limitation active
Bit 10 Current Limitation	0 = No: current limitation inactive 1 = Yes: current limitation active
Bit 11 Torque Limitation	0 = No: torque limitation inactive 1 = Yes: torque limitation active
Bit 12 Ride-Through	0 = No: Ride-Through not running 1 = Yes: running Ride-Through
Bit 13 Flying Start	0 = No: Flying start not running 1 = Yes: running Flying start
Bit 14 DC Braking	0 = No: DC breaking inactive 1 = Yes: DC breaking active
Bit 15 PWM pulses	0 = No: PWM voltage pulses at the output disabled 1 = Yes: PWM voltage pulses at the output enabled

.4 Status Word 3 Indicates other states of the inverter functions. Each bit represents a state.

Bit	Value/Description
Bit 0 SD Card	SD card is only detected during the inverter initialization, so the inverter will not detect SD card disconnection during operation. 0 = No: SD card not connected 1 = Yes: SD card connected
Bit 1 Not used	Not used
Bit 2 Param. Storage	Indicates the status of the storage memory for user parameter setting. When the memory reaches its maximum capacity, new parameter changes may not be retained after the inverter is restarted. The next time the product is powered on, a message will be displayed on the HMI, and memory space will be freed up to allow new parameter settings. The inverter operation is not affected when storage space is exhausted. 0 = Free: There is space available in the memory to store user parameters 1 = Limit: The memory for storing user parameters has reached its maximum capacity

S5.2 Serial RS485

It allows viewing the status of the RS485 serial interface and the commands received by this interface.

S5.2 Serial RS485

.1 Interface Status	0 ... 2
.2 Control Word	0 ... 7 Bit
.3 Speed Reference	-200.00 ... 200.00 %
.5 Received Telegrams	0 ... 65535
.6 Transmitted Telegrams	0 ... 65535
.7 Telegrams with Error	0 ... 65535
.8 Reception Errors	0 ... 65535

.1 Interface Status It indicates the status of the RS485 serial interface.

Indication	Description
0 = Inactive	Not used
1 = Active	Serial interface active
2 = Timeout Error	It indicates that the MVW did not receive valid telegrams for a time longer than the limit set

.2 Control Word It indicates the status of the control word via RS-485 serial interface. This parameter can only be changed via RS485 serial interface. For other sources, only read access is allowed.

For the commands written in this parameter to be executed, the inverter must be programmed to be commanded via Serial. This programming is done through menu C4.

Each bit of this word represents a command that can be executed on the inverter.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.3 Speed Reference It indicates the speed reference sent via RS-485 Serial interface to the motor driven by the inverter in percentage of the maximum speed. This parameter can only be changed via RS485 serial interface. For other sources, only read access is allowed.

For the reference written in this parameter to be used, the inverter must be programmed to use the speed reference via Serial. This programming is done through menu C4.

- S5.2.3 = 0.00 % ⇒ speed reference = 0 rpm
- S5.2.3 = 100.00 % ⇒ speed reference = C4.3.1.1.2

Intermediate or higher speed values can be obtained by using this scale. For example, if the desired value for the reference is 900 rpm, considering C4.3.1.1.2 = 1800 rpm, it should be calculated:

S STATUS

100.00 % : 1800 rpm
Reference % : 900 rpm

$$\text{Reference \%} = \frac{900 \times 100.00}{1800}$$

Reference % = 50 %

Negative values can be used to reverse the direction of rotation of the motor. The direction of rotation of the motor, however, also depends on the value of the rotation direction command bit in S1.6.1:

- Bit Rotation Direction = 1 and S5.2.3 > 0: reference for the forward direction
- Bit Rotation Direction = 1 and S5.2.3 < 0: reference for the reverse direction
- Bit Rotation Direction = 0 and S5.2.3 > 0: reference for the reverse direction
- Bit Rotation Direction = 0 and S5.2.3 < 0: reference for the forward direction

.5 Received Telegrams It indicates the number of telegrams received.

.6 Transmitted Telegrams It indicates the number of telegrams transmitted.

.7 Telegrams with Error It indicates the number of telegrams received with errors (CRC, Checksum).

.8 Reception Errors It indicates the number of bytes received with errors.

The counters are cyclic, that is, when it reaches 65535, it returns to 0.



NOTE!

These counters start at 0 whenever the product is powered on. They also return to 0 whenever the maximum limit of the parameter is reached.

S5.3 Ethernet

It allows viewing the status of the Ethernet network interface and the commands received by this interface.

S5.3 Ethernet

.1 Interface Status	0 ... 1 Bit
.2 Control Word	0 ... 7 Bit
.3 Speed Reference	-200.00 ... 200.00 %
.5 Actual IP Address	0.0.0.0 ... 255.255.255.255
.6 MQTT Status	0 ... 2
.7 Last Public. MQTT	YYYY-MM-DD HH:MM:SS
.8 SNTP - Status	0 ... 2
.9 SNTP - Last update	YYYY-MM-DD HH:MM:SS
.10 SymbiNet: Groups Status	0 ... 7 Bit

.1 Interface Status It indicates the status of the Ethernet network interface. Each bit represents a state.

Bit	Value/Description
Bit 0 Link 1	0 = No: Link active at port 1 1 = Yes: Link active at port 1
Bit 1 Link 2	0 = No: No link at port 2 1 = Yes: Link active at port 2

.2 Control Word It indicates the status of the control word via Ethernet network interface. This parameter can only be changed via Ethernet network interface. For other sources, only read access is allowed.

For the commands written in this parameter to be executed, the inverter must be programmed to be commanded via Ethernet. This programming is done through menu C4.

Each bit of this word represents a command that can be executed on the inverter.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.3 Speed Reference It indicates the speed reference sent via Ethernet network interface to the motor driven by the inverter in percentage of the maximum speed. This parameter can only be changed via Ethernet network interface. For other sources, only read access is allowed.

For the reference written in this parameter to be used, the inverter must be programmed to use the speed reference via Ethernet. This programming is done through menu C4.

- S5.3.3 = 0.00 % $\Rightarrow$ speed reference = 0 rpm
- S5.3.3 = 100.00 % $\Rightarrow$ speed reference = C4.3.1.1.2

Intermediate or higher speed values can be obtained by using this scale. For example, if the desired value for the reference is 900 rpm, considering C4.3.1.1.2 = 1800 rpm, it should be calculated:

100.00 % : 1800 rpm
Reference % : 900 rpm

$$\text{Reference \%} = \frac{900 \times 100.00}{1800}$$

Reference % = 50 %

Negative values can be used to reverse the direction of rotation of the motor. The direction of rotation of the motor, however, also depends on the value of the rotation direction command bit in S5.3.2 or S1.6.1:

- Bit Rotation Direction = 0 and S5.3.3 > 0: reference for the forward direction
- Bit Rotation Direction = 0 and S5.3.3 < 0: reference for the reverse direction
- Bit Rotation Direction = 1 and S5.3.3 > 0: reference for the reverse direction
- Bit Rotation Direction = 1 and S5.3.3 < 0: reference for the forward direction

.5 Actual IP Address It allows viewing the IP address in use by the device.

.6 MQTT Status It indicates the status of the MQTT communication, regarding settings and the sending of data to the server.

S STATUS

Indication	Description
0 = Inactive	It indicates that the Embedded Drive Scan function is not set; it is disabled
1 = No Connection	It indicates that the Embedded Drive Scan function has been set and is enabled, but there is currently no active connection to the configured Broker
2 = Connected	It indicates that the Embedded Drive Scan function has been set up and is enabled, and has an active connection to the configured Broker

.7 Last Public. MQTT It indicates the date and time of the last successful sending of collected data to the MQTT communication.

.8 SNTP - Status It indicates the status of the NTP server, regarding configuration and receiving data from the server.

Indication	Description
0 = Inactive	It indicates that the NTP server is not configured; it is disabled
1 = No Connection	It indicates that the NTP server has been set up and is enabled, but currently has no active connection
2 = Connected	It indicates that the NTP server has been set up and is enabled, and has active connection

.9 SNTP - Last update It indicates the date and time of the last NTP server update.

.10 SymbiNet: Groups Status Indicates the communication status for the groups programmed for SymbiNet communication. Each bit represents the state of one group, where bit 0 indicates the state of group 1, and bit 7 indicates the state of group 8.

Bit	Value/Description
Bit 0 Group 1 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 1 Group 2 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 2 Group 3 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 3 Group 4 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 4 Group 5 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 5 Group 6 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 6 Group 7 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update
Bit 7 Group 8 Status	0 = Inactive: Indicates the group for SymbiNet communication is inactive (no data received within the programmed period), or the group is not programmed 1 = Active: Indicates the group for SymbiNet communication is active, meaning the group data has been received and is update

S5.4 EtherNet/IP

It allows viewing information about the EtherNet/IP protocol.

S5.4 EtherNet/IP

.1 EIP Master Status	0 ... 1
.2 Communication Status	0 ... 4
.3 DLR Topology	0 ... 1
.4 DLR Status	0 ... 2

.1 EIP Master Status It indicates the status of the EtherNet/IP network master. It may be in operation mode (Run) or in configuration mode (Idle).

Indication	Description
0 = Run	Reading and writing telegrams are processed and updated normally by the master
1 = Idle	Only reading telegrams from the slaves are updated by the master. Writing, in this case, is disabled

.2 Communication Status It indicates the status of the Ethernet/IP network interface.

Indication	Description
0 = Inactive	Not used
1 = No Connection	It indicates that the EtherNet/IP network interface has been initialized, but is not communicating with the network master
2 = Connected	It indicates that communication with the network master has been established, and I/O data is being successfully communicated
3 = I/O Connection Timeout	I/O type connection has expired
4 = Duplicate IP	Not used

.3 DLR Topology Indicates the network topology.

Indication	Description
0 = Linear	Indicates linear topology
1 = Ring	Indicates ring topology

.4 DLR Status Indicates the status of the network.

Indication	Description
0 = Idle State	Ring Node is in Idle state
1 = Normal State	Ring Node is in Normal state
2 = Fault State	Ring Node is in Fault state

S5.5 Modbus TCP

It allows viewing information about the Modbus TCP protocol.

S5.5 Modbus TCP

.1 Communication Status	0 ... 3
.2 Received Telegrams	0 ... 65535
.3 Transmitted Telegrams	0 ... 65535
.4 Active Connections	0 ... 8

.1 Communication Status It allows to identify the communication status with Modbus TCP server.

Indication	Description
0 = Inactive	Not used
1 = No Connection	Communication enabled, but no Modbus TCP connection active
2 = Connected	At least one active Modbus TCP connection
3 = Timeout Error	The equipment detected timeout in the Modbus TCP communication

.2 Received Telegrams It indicates the number of telegrams received by the device as a server in the Modbus TCP network.

.3 Transmitted Telegrams It indicates the number of telegrams sent by the device as a server in the Modbus TCP network.

S STATUS



NOTE!

These counters start at 0 whenever the product is powered on. They also return to 0 whenever the maximum limit of the parameter is reached.

.4 Active Connections It indicates the number of Modbus TCP connections active in the product.

S5.6 Anybus

It allows viewing the status of the Anybus interface, the accessory model and the commands sent to the MVW.

S5.6 Anybus

.1 Identification	0 ... 5
.2 Communication Status	0 ... 4
.3 Control Word	0 ... 7 Bit
.4 Speed Reference	-200.00 ... 200.00 %

.1 Identification It identifies the model of the Anybus communication accessory connected to the MVW.

Indication	Description
0 = Inactive	No Anybus communication accessory installed
1 = PROFIBUS DP-V1	PROFIBUS DP accessory installed
2 = EtherCAT	EtherCAT accessory installed
3 = PROFINET IRT	PROFINET IRT active accessory installed
4 ... 5 = Not used	Not used

.2 Communication Status It informs the status of the communication accessory.

Indication	Description
0 = Inactive	No Anybus communication accessory detected
1 = Not Supported	Anybus accessory detected is not supported by the MVW inverter
2 = Access Error	Problem detected in data access between the inverter and the Anybus communication accessory
3 = Offline	Anybus accessory reporting problems. There is no cyclical data exchange with the master
4 = Online	Normal Anybus accessory communication. Effective cyclic and acyclic data exchange between the MVW and the network master

.3 Control Word It indicates the status of the control word via Anybus. This parameter can only be changed via Anybus. For other sources, only read access is allowed.

For the commands written in this parameter to be executed, the inverter must be programmed to be commanded via Anybus. This programming is done through the menu C4.

Each bit of this word represents a command that can be executed on the inverter.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.4 Speed Reference It indicates the speed reference sent via Anybus interface to the motor driven by the inverter in percentage of the maximum speed. This parameter can only be changed via Anybus interface. For other sources, only read access is allowed.

For the reference written in this parameter to be used, the inverter must be programmed to use the speed reference via Anybus. This programming is done through the menu C4.

- S5.6.4 = 0,00 % → speed reference = 0 rpm
- S5.6.4 = 100,00 % → speed reference = C4.3.1.1.2

Intermediate or higher speed values can be obtained using this scale. For example, if the desired value for the reference is 900 rpm, considering C4.3.1.1.2 = 1800 rpm, the following should be calculated:

100.00 % ⇒ 1800 rpm
Reference % ⇒ 900 rpm

$$\text{Reference \%} = \frac{900 \times 100.00}{1800}$$

Reference % = 50 %

Negative values can be used to reverse the direction of motor rotation. The direction of motor rotation, however, also depends on the value of the direction of rotation command bit in S1.6.1:

- Rotation Direction Bit = 1 and S5.6.4 > 0: reference to the forward direction
- Rotation Direction Bit = 1 and S5.6.4 < 0: reference for reverse direction
- Rotation Direction Bit = 0 and S5.6.4 > 0: reference for reverse direction
- Rotation Direction Bit = 0 and S5.6.4 < 0: reference for the direct direction

S5.7 CAN/CANopen/DNet

Status of the CAN communication accessory and the protocols that use this interface.

S5.7 CAN/CANopen/DNet

.1 CAN Controller Status	0 ... 6
.2 Control Word	0 ... 7 Bit
.3 Speed Reference	-200.00 ... 200.00 %
.5 Received Telegrams	0 ... 65535
.6 Transmitted Telegrams	0 ... 65535
.7 Bus Off Counter	0 ... 65535
.8 Lost Messages	0 ... 65535
.9 CANopen Comm. Status	0 ... 5
.10 CANopen Node Status	0 ... 4
.11 DNet Network Status	0 ... 5
.12 DNet Master Status	0 ... 1

.1 CAN Controller Status It allows identifying whether the CAN interface is properly installed, and whether the communication presents errors.

Indication	Description
0 = Inactive	CAN interface inactive. It occurs when the equipment does not have a CAN protocol programmed in C9.8.1
1 = Auto-Baud	Running function for automatic baud rate detection (only for DeviceNet protocol)
2 = CAN Active	CAN interface active and without error
3 = Warning	CAN controller has reached the warning status

S STATUS

Indication	Description
4 = Error Passive	CAN controller has reached error passive status
5 = Bus Off	CAN controller has reached bus off status
6 = No Bus Power	The CAN interface has no power supply between pins 1 and 5 of the connector

.2 Control Word It indicates the status of the control word via CAN interface. This parameter can only be changed via CAN interface. For other sources, only read access is allowed.

For the commands written in this parameter to be executed, the inverter must be programmed to be commanded via CAN/CO/DN. This programming is done through menu C4.

Each bit of this word represents a command that can be executed on the inverter.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.3 Speed Reference It indicates the speed reference sent via CAN interface to the motor driven by the inverter in percentage of the maximum speed. This parameter can only be changed via CAN interface. For other sources, only read access is allowed.

For the reference written in this parameter to be used, the inverter must be programmed to use the speed reference via CAN/CO/DNET. This programming is done through menu C4.

- S5.7.3 = 0.00 % $\Rightarrow$ speed reference = 0 rpm
- S5.7.3 = 100.00 % $\Rightarrow$ speed reference = C4.3.1.1.2

Intermediate or higher speed values can be obtained by using this scale. For example, if the desired value for the reference is 900 rpm, considering C4.3.1.1.2 = 1800 rpm, it should be calculated:

100.00 % : 1800 rpm
Reference % : 900 rpm

$$\text{Reference \%} = \frac{900 \times 100.00}{1800}$$

Reference % = 50 %

Negative values can be used to reverse the direction of rotation of the motor. The direction of rotation of the motor, however, also depends on the value of the rotation direction command bit in S1.6.1:

- Bit Rotation Direction = 1 and S5.7.3 > 0: reference for the forward direction
- Bit Rotation Direction = 1 and S5.7.3 < 0: reference for the reverse direction
- Bit Rotation Direction = 0 and S5.7.3 > 0: reference for the reverse direction
- Bit Rotation Direction = 0 and S5.7.3 < 0: reference for the forward direction

.5 Received Telegrams This parameter works as a cyclic counter that is incremented every time a CAN telegram is received. It provides feedback to the operator if the device is able to communicate with the network.

.6 Transmitted Telegrams This parameter works as a cyclic counter that is incremented every time a CAN telegram is transmitted. It provides feedback to the operator if the device is able to communicate with the network.

.7 Bus Off Counter Cyclic counter that indicates the number of times the equipment went into the bus off state on the CAN network.

.8 Lost Messages It is a cyclic counter that indicates the number of messages the CAN interface received but could not be processed. In case the number of lost messages frequently increases, it is recommended to reduce the baud rate used in the CAN network.



NOTE!

These counters are reset to zero whenever the equipment is turned off, reset or reach the maximum limit set in the parameter.

.9 CANopen Comm. Status It indicates the status of the CAN accessory in relation to the CANopen network, informing if the protocol has been enabled and if the error control service is active (*Node Guarding* or *Heartbeat*).

Indication	Description
0 = Inactive	CANopen protocol disabled
1 = Not used	
2 = Comm. Enabled	Communication enabled
3 = Error Ctrl. Enab.	Communication enabled and error control enabled (Node Guarding/Heartbeat)
4 = Guarding Error	Node Guarding error occurred
5 = Heartbeat Error	Heartbeat error occurred

.10 CANopen Node Status Each slave in the CANopen network has a state machine that controls its behavior in relation to communication. This parameter indicates which state the device is in, according to the protocol specification.

Indication	Description
0 = Inactive	CANopen protocol disabled
1 = Initialization	Communication with the device is not possible during this stage, which is completed automatically
2 = Stopped	Only the NMT object is available
3 = Operational	All communication objects are available
4 = Pre-Operational	It is possible to communicate with the slave but the PDOs are not yet available for operation

.11 DNet Network Status It indicates the DeviceNet network status.

Indication	Description
0 = Offline	No power supply or not online. Communication cannot be established
1 = Online Not Connec.	Device online but not connected. Slave has successfully completed the MacID verification procedure. This means that the baud rate setting is correct (or correctly detected in case of using autobaud) and that there are no other nodes in the network with the same address. However, at this stage, there is still no communication with the master
2 = Online, Connected	Device operational and under normal conditions. Master allocated a set of I/O type connections with the slave. In this step, the data exchange takes place through I/O type connections
3 = Connection Timed Out	One or more I/O type connections timed out
4 = Link Failure	It indicates that the slave cannot enter the network due to address problems or due to bus off. Check if the address is not already being used by another device, if the baud rate selected is correct or if there are problems in the installation
5 = Auto-Baud	Equipment running routine of the autobaud mechanism

.12 DNet Master Status It indicates the status of the DeviceNet network master. It may be in "operation mode" (Run) or in "configuration mode" (Idle).

S STATUS

Indication	Description
0 = Run	Reading and writing telegrams are processed and updated normally by the master
1 = Idle	Only reading telegrams from the slaves are updated by the master. Writing, in this case, is disabled



NOTE!

When communication is disabled, this parameter does not represent the actual status of the master.

S6 SOFTPLC

The SoftPLC function provides the MVW inverter with the functionalities of a PLC (Programmable Logic Controller), adding flexibility to the product and allowing the users to develop their own applications (user programs). See the WPS (WEG Programming Suite) manual for more details regarding the programming of the MVW PLC functions, available at www.weg.net.

S6.1 Program Execution

It allows viewing the status of the SoftPLC function status parameters.

S6.1 Program Execution

.1 Status	0 ... 4
.2 Time	0 ... 65535 ms

.1 Status It allows the user to view the SoftPLC status.

Indication	Description
0 = No Program	It indicates that there is no program saved in the SoftPLC memory area. User parameters will not be shown on the HMI
1 = Saving Program	It indicates that the program is being saved in the SoftPLC memory area
2 = Invalid Program	It indicates that the program is saved in the SoftPLC memory area and is not compatible with the firmware version (S1.2.1) of the MVW. In this case, the user must recompile the project in the WPS software considering the new firmware version of the MVW and redo the "download"
3 = Program Stopped	It indicates that there is a valid program in the SoftPLC memory area, but it is not running, that is, it is stopped
4 = Program Running	It indicates that there is a valid program in the SoftPLC memory area and it is running

.2 Time It indicates the program runtime in milliseconds. The larger the program, the longer the runtime (scan) tends to be.

S6.2 Control and References

It allows viewing the control and reference parameter status of the SoftPLC function.

S6.2 Control and References

.1 Control Word	0 ... 7 Bit
.3 Speed Reference	-200.00 ... 200.00 %

.1 Control Word It indicates the status of the control word via the SoftPLC function. This parameter can only be changed via SoftPLC function. For other sources, only read access is allowed.

For the commands written in this parameter to be executed, the inverter must be programmed to be commanded via SoftPLC. This programming is done through menu C4.

Each bit of this word represents a command that can be executed on the inverter.

Bit	Value/Description
Bit 0 Enable Ramp	0 = No: it stops the motor by deceleration ramp 1 = Yes: the motor turns according to the acceleration ramp until reaching the speed reference value
Bit 1 General Enable	0 = No: it disables the inverter completely, interrupting the motor power supply 1 = Yes: it enables the inverter completely, allowing the operation of the motor
Bit 2 Run Reverse	0 = No: turn the motor in the direction of the reference signal (forward direction) 1 = Yes: run the motor in the opposite direction of the reference signal (reverse direction)
Bit 3 Enable JOG	0 = No: it disables the JOG function 1 = Yes: it enables the JOG function
Bit 4 R1/R2 Mode	0 = R1: it selects the Remote 1 command mode 1 = R2: it selects the Remote 2 command mode
Bit 5 2nd Ramp	0 = No: 1st Ramp acceleration and deceleration according to parameters C6.1.1 and C6.1.2 1 = Yes: 2nd Ramp acceleration and deceleration according to parameters C6.1.4 and C6.1.5
Bit 6 No Quick Stop	0 = No: it enables quick stop 1 = Yes: it disables quick stop
Bit 7 Fault Reset	0 = No: not used 1 = Yes: in the transition, if a fault is active, it resets the fault

.3 Speed Reference It indicates the speed reference via SoftPLC function for the motor driven by the inverter in percentage of the maximum speed. This parameter can only be changed via SoftPLC function. For other sources, only read access is allowed.

For the reference written in this parameter to be used, the inverter must be programmed to use the speed reference via SoftPLC. This programming is done through menu C4.

- S6.2.3 = 0.00 % ⇒ speed reference = 0 rpm
- S6.2.3 = 100.00 % ⇒ speed reference = C4.3.1.1.2

Intermediate or higher speed values can be obtained by using this scale. For example, if the desired value for the reference is 900 rpm, considering C4.3.1.1.2 = 1800 rpm, it should be calculated:

100.00 % : 1800 rpm
Reference % : 900 rpm

$$\text{Reference \%} = \frac{900 \times 100.00}{1800}$$

Reference % = 50 %

Negative values can be used to reverse the direction of rotation of the motor. The direction of rotation of the motor, however, also depends on the value of the rotation direction command bit in S1.6.1:

- Bit Rotation Direction = 1 and S6.2.3 > 0: reference for the forward direction
- Bit Rotation Direction = 1 and S6.2.3 < 0: reference for the reverse direction
- Bit Rotation Direction = 0 and S6.2.3 > 0: reference for the reverse direction
- Bit Rotation Direction = 0 and S6.2.3 < 0: reference for the forward direction

8 D DIAGNOSTICS

It allows viewing variables and events that can help diagnose problems or improve the MVW operation.

D1 FAULTS

It allows viewing fault activation occurrences on the MVW.

D1.1 Current

It allows viewing the faults occurred on the MVW. If any fault is active, its number is displayed. If it is not active, 0 is displayed.

The faults act by disabling the motor. They are removed only with a reset or de-energizing command from the MVW control.

The fault occurrences are placed in a row following the sequence of the cause that generated them. In this menu the activation of up to 5 faults can be indicated simultaneously. Whenever a fault acts, it enters the first empty position and so on. The reset command will only reset Fault 1.

Visually on the HMI, if only one fault is activated, it will be in the first position (Fault 1).

D1.1 Current

.1 Fault 1	0 ... 4095
.2 Fault 2	0 ... 4095
.3 Fault 3	0 ... 4095
.4 Fault 4	0 ... 4095
.5 Fault 5	0 ... 4095

.1 Fault 1 First position of active fault indication.

.2 Fault 2 Second position of active fault indication.

.3 Fault 3 Third position of active fault indication.

.4 Fault 4 Fourth position of active fault indication.

.5 Fault 5 Fifth position of active fault indication.

D1.3 History

It indicates the code, date and time of the last 10 faults.

D1.3 History

.1 Last Fault	0 ... 9999	
.2 Date and Time Last Fault	YYYY-MM-DD	HH:MM:SS
.3 Second Fault	0 ... 9999	
.4 Date and Time Second Fault	YYYY-MM-DD	HH:MM:SS
.5 Third Fault	0 ... 9999	
.6 Date and Time Third Fault	YYYY-MM-DD	HH:MM:SS
.7 Fourth Fault	0 ... 9999	
.8 Date and Time Fourth Fault	YYYY-MM-DD	HH:MM:SS
.9 Fifth Fault	0 ... 9999	
.10 Date and Time Fifth Fault	YYYY-MM-DD	HH:MM:SS
.11 Sixth Fault	0 ... 9999	
.12 Date and Time Sixth Fault	YYYY-MM-DD	HH:MM:SS
.13 Seventh Fault	0 ... 9999	
.14 Date and Time Seventh Fault	YYYY-MM-DD	HH:MM:SS
.15 Eighth Fault	0 ... 9999	
.16 Date and Time Eighth Fault	YYYY-MM-DD	HH:MM:SS
.17 Ninth Fault	0 ... 9999	
.18 Date and Time Ninth Fault	YYYY-MM-DD	HH:MM:SS
.19 Tenth Fault	0 ... 9999	
.20 Date and Time Tenth Fault	YYYY-MM-DD	HH:MM:SS

- .1 Last Fault** It indicates the code of the last fault that happened.
- .2 Date and Time Last Fault** It indicates the date and time of the last fault that happened.
- .3 Second Fault** It indicates the code of the second fault that happened.
- .4 Date and Time Second Fault** It indicates the date and time of the second fault that happened.
- .5 Third Fault** It indicates the code of the third fault that happened.
- .6 Date and Time Third Fault** It indicates the date and time of the third fault that happened.
- .7 Fourth Fault** It indicates the code of the fourth fault that happened.
- .8 Date and Time Fourth Fault** It indicates the date and time of the fourth fault that happened.
- .9 Fifth Fault** It indicates the code of the fifth fault that happened.
- .10 Date and Time Fifth Fault** It indicates the date and time of the fifth fault that happened.
- .11 Sixth Fault** It indicates the code of the sixth fault that happened.
- .12 Date and Time Sixth Fault** It indicates the date and time of the sixth fault that happened.
- .13 Seventh Fault** It indicates the code of the seventh fault that happened.
- .14 Date and Time Seventh Fault** It indicates the date and time of the seventh fault that happened.
- .15 Eighth Fault** It indicates the code of the eighth fault that happened.
- .16 Date and Time Eighth Fault** It indicates the date and time of the eighth fault that happened.
- .17 Ninth Fault** It indicates the code of the ninth fault that happened.
- .18 Date and Time Ninth Fault** It indicates the date and time of the ninth fault that happened.
- .19 Tenth Fault** It indicates the code of the tenth fault that happened.
- .20 Date and Time Tenth Fault** It indicates the date and time of the tenth fault that happened.

D2 ALARMS

It allows viewing the alarms occurred in the MVW.

D2.1 Actual

It allows viewing the alarms occurred in the MVW. If any alarm is active, the alarm number is displayed; otherwise, 0 is displayed.

The alarms are displayed on the HMI and on the MVW status word. They are automatically removed after leaving the alarm condition.

Alarms are placed in a line, which can display up to 5 alarms simultaneously. Whenever an alarm occurs, it goes to the first empty position (if there is no indication of any previous alarm, it will be shown in Alarm 1).

Visually on the HMI, if only one alarm occurs, it will be in the first position (Alarm 1).

D2.1 Actual	
.1 Alarm 1	0 ... 4095
.2 Alarm 2	0 ... 4095
.3 Alarm 3	0 ... 4095
.4 Alarm 4	0 ... 4095
.5 Alarm 5	0 ... 4095

.1 Alarm 1 First position of alarm indication (Actual alarm).

.2 Alarm 2 Second position of alarm indication.

.3 Alarm 3 Third position of alarm indication.

.4 Alarm 4 Fourth position of alarm indication.

.5 Alarm 5 Fifth position of alarm indication.

D2.3 History

It indicates the code, date and time of the last 10 alarms.

D2.3 History

.1 Last Alarm	0 ... 9999	
.2 Date and Time Last Alarm	YYYY-MM-DD	HH:MM:SS
.3 Second Alarm	0 ... 9999	
.4 Date and Time Second Alarm	YYYY-MM-DD	HH:MM:SS
.5 Third Alarm	0 ... 9999	
.6 Date and Time Third Alarm	YYYY-MM-DD	HH:MM:SS
.7 Fourth Alarm	0 ... 9999	
.8 Date and Time Fourth Alarm	YYYY-MM-DD	HH:MM:SS
.9 Fifth Alarm	0 ... 9999	
.10 Date and Time Fifth Alarm	YYYY-MM-DD	HH:MM:SS
.11 Sixth Alarm	0 ... 9999	
.12 Date and Time Sixth Alarm	YYYY-MM-DD	HH:MM:SS
.13 Seventh Alarm	0 ... 9999	
.14 Date and Time Seventh Alarm	YYYY-MM-DD	HH:MM:SS
.15 Eighth Alarm	0 ... 9999	
.16 Date and Time Eighth Alarm	YYYY-MM-DD	HH:MM:SS
.17 Ninth Alarm	0 ... 9999	
.18 Date and Time Ninth Alarm	YYYY-MM-DD	HH:MM:SS
.19 Tenth Alarm	0 ... 9999	
.20 Date and Time Tenth Alarm	YYYY-MM-DD	HH:MM:SS

- .1 Last Alarm** It indicates the code of the last alarm that happened.
- .2 Date and Time Last Alarm** It indicates the date and time of the last alarm that happened.
- .3 Second Alarm** It indicates the code of the second alarm that happened.
- .4 Date and Time Second Alarm** It indicates the date and time of the second alarm that happened.
- .5 Third Alarm** It indicates the code of the third alarm that happened.
- .6 Date and Time Third Alarm** It indicates the date and time of the third alarm that happened.
- .7 Fourth Alarm** It indicates the code of the fourth alarm that happened.
- .8 Date and Time Fourth Alarm** It indicates the date and time of the fourth alarm that happened.
- .9 Fifth Alarm** It indicates the code of the fifth alarm that happened.
- .10 Date and Time Fifth Alarm** It indicates the date and time of the fifth alarm that happened.
- .11 Sixth Alarm** It indicates the code of the sixth alarm that happened.
- .12 Date and Time Sixth Alarm** It indicates the date and time of the sixth alarm that happened.
- .13 Seventh Alarm** It indicates the code of the seventh alarm that happened.
- .14 Date and Time Seventh Alarm** It indicates the date and time of the seventh alarm that happened.
- .15 Eighth Alarm** It indicates the code of the eighth alarm that happened.
- .16 Date and Time Eighth Alarm** It indicates the date and time of the eighth alarm that happened.
- .17 Ninth Alarm** It indicates the code of the ninth alarm that happened.
- .18 Date and Time Ninth Alarm** It indicates the date and time of the ninth alarm that happened.
- .19 Tenth Alarm** It indicates the code of the tenth alarm that happened.
- .20 Date and Time Tenth Alarm** It indicates the date and time of the tenth alarm that happened.

D3 HOUR CONTROL

It allows viewing the total running hours of some MVW conditions.

D3 Hour Control

.1 Time Powered	0 ... 65536 h
.2 Hours Enabled	0 ... 65536 h

.1 Time Powered It indicates the total hours that the inverter has been powered.

This value is kept even when the inverter is shut down.

.2 Hours Enabled It indicates the total number of hours that the inverter remained enabled.

It indicates up to 65536 hours, and then it returns to zero.

Setting parameter C1.6.2 option 3, the value of parameter D3.2 goes to zero.

This value is kept even when the inverter is shut down.

D4 INVERTER AND ACCESS.

It allows viewing the measurement of the MVW operating conditions.

D4.1 Inverter

It allows viewing the measurement of operating conditions related to the inverter.

D4.1.4 Control Voltages

It indicates the voltage of the MVW control board power supplies.

D4.1.4 Control Voltages

.1 Voltage 24V IO	0.00 ... 655.35 V
.2 Battery Voltage	0.00 ... 655.35 V
.3 Voltage 3.3V Control	0.00 ... 655.35 V
.4 Voltage 24V Control	0.00 ... 655.35 V
.5 Voltage 3.3V IO	0.00 ... 655.35 V
.6 Voltage 5V AUI	0.00 ... 655.35 V

.1 Voltage 24V IO It indicates the voltage value of the 24 V source for IO accessories (V).

.2 Battery Voltage It indicates the battery voltage value (V).

.3 Voltage 3.3V Control It indicates the 3.3 V source voltage value for the control board (V).

.4 Voltage 24V Control It indicates the 24 V source voltage value for the control board (V).

.5 Voltage 3.3V IO It indicates the voltage value of the 3.3 V source for IO accessories (V).

.6 Voltage 5V AUI It indicates the AUI 5V voltage value (V).

D4.1.5 Motor Overl. Fault

It indicates the control variable of the motor overload fault function.

D4.1.5 Motor Overl. Fault

.1 Ixt Motor Level	0 ... 100 %
--------------------	-------------

D DIAGNOSTICS

.1 Ixt Motor Level It indicates the actual status of the motor overload.

D4.1.11 Configuration

It allows viewing the status of the user settings storage system.

D4.1.11 Configuration

.1 Last backup operation 0 ... 12

.1 Last backup operation Indicates the last backup operation performed.

Operations that are not completed successfully, such as operations with an SD card without the card being inserted in the product or loading settings that have not been previously saved, return the value of this parameter to "Not Used".

Indication	Description
0 = Not Used	Not used
1 = Default 60 Hz	It loads the MVW settings with the default content of the parameters
2 = Default 50 Hz	It loads the MVW settings with the default content of the parameters All parameters are loaded with the default value of 60 Hz, with the exception of the following cases: ■ C4.3.2.1 set at 125 rpm; ■ C4.3.1.1.2 set at 1500 rpm; ■ C4.3.1.3.1 set at 75 rpm; ■ C5.9.3 set at 15 rpm; ■ C4.3.1.5.1 set at 75 rpm; ■ C5.9.4 set at 100 rpm; ■ C4.3.1.5.2 set at 250 rpm; ■ C5.9.5 set at 1500 rpm; ■ C4.3.1.5.3 set at 500 rpm; ■ C5.9.8 set at 15 rpm; ■ C4.3.1.5.4 set at 750 rpm; ■ C2.1.8 set at 1458 rpm; ■ C4.3.1.5.5 set at 1000 rpm; ■ C2.1.6 set at 50 Hz; ■ C4.3.1.5.6 set at 1250 rpm; ■ C3.3.4.1.1 set at 1500 rpm; ■ C4.3.1.5.7 set at 1500 rpm; ■ C3.3.4.1.2 set at 1500 rpm; ■ C4.3.1.5.8 set at 1375 rpm; ■ C4.3.1.1.1 set at 75 rpm;
3 = Param. Set 1 -> MVW	It loads the MVW settings with the content of parameter set 1
4 = Param. Set 2 -> MVW	It loads the MVW settings with the content of parameter set 2
5 = Param. Set 3 -> MVW	It loads the MVW settings with the content of parameter set 3
6 = MVW -> Param. Set 1	It saves the content of the MVW current settings for parameter set 1
7 = MVW -> Param. Set 2	It saves the content of the MVW current settings for parameter set 2
8 = MVW -> Param. Set 3	It saves the content of the MVW current settings for parameter set 3
9 = SD Card -> MVW	It loads the MVW settings with the content of parameter set imported from the SD card Additionally, it imports the settings of parameter sets 1, 2 and 3 from the SD card to the inverter memory
10 = MVW -> SD Card	It saves the content of the actual MVW settings on the SD card Additionally, it exports the settings from parameter sets 1, 2 and 3 to the SD card
11 ... 12 = Not used	Not used

D4.1.12 Advanced

Allows viewing parameters with advanced information to aid the inverter diagnosis.

D4.1.12 Advanced

.1 Last assert	0 ... 4294967295
.2 Code flow 1 Date time	YYYY-MM-DD HH:MM:SS
.3 Last reset reason (AUI)	0 ... 4294967295
.4 Code flow 2 Date time	YYYY-MM-DD HH:MM:SS

.1 Last assert It indicates the code related to the last assert that happened.

8-digit hexadecimal number arranged as follows:

0xABBBBCCC

A = 0[none]; 1[AUI] B = File name identification C = Line number identification

.2 Code flow 1 Date time Indicates the date and time at which parameter D4.1.12.1 was last updated.

.3 Last reset reason (AUI) It indicates the code related to the reason of the last CPU reset that happened.

8-digit hexadecimal number arranged as follows:

0xABBBCCCC

A = 0[none]; 1[AUI] B = Reset reason identification C = Additional information

.4 Code flow 2 Date time Indicates the date and time at which parameter D4.1.12.3 was last updated.

D4.1.13 Others

Other inverter diagnostics parameters, available for technical assistance.

D4.1.13 Others

.4 Rotation direction of voltage and current measurements	0 ... 65535
---	-------------

.4 Rotation direction of voltage and current measurements It displays the direction of rotation of the inverter voltage and current measurements.

For the input and output power measurements to operate correctly, the voltages and currents involved must be rotating in the same direction of rotation. Parameter C1.8.6 can be used to activate the alarms of reverse rotation between voltage and current of the same point.




Figure 8.1: Direction of rotation of the measurements

D4.2 Accessories

It allows viewing the data for diagnosing the control accessories installed in the MVW.

D4.2.1 Diag. Slot A to D4.2.7 Diag. Slot G

It allows viewing the diagnostics data of the accessory connected to the slot.




Figure 8.2: Examples of measurement problems

D4.2.1 Diag. Slot A	
D4.2.2 Diag. Slot B	
D4.2.3 Diag. Slot C	
D4.2.4 Diag. Slot D	
D4.2.5 Diag. Slot E	
D4.2.6 Diag. Slot F	
D4.2.7 Diag. Slot G	
.1 Status	0 ... 3
.3 Temperature	-100.0 ... 250.0 °C

.1 Status It shows the accessory status.

Indication	Description
0 = Not Connected	There is no accessory connected
1 = Initializing	There is an accessory connected, and it is initializing
2 = Active	There is an accessory connected, and it is communicating properly
3 = Error	There is an accessory connected, and it is presenting some error in the communication with the MVW

.3 Temperature It indicates the control temperature measured by the accessory.

9 C CONFIGURATIONS

It allows changing the MVW configuration parameters. Depending on the parameter property, it is possible to set its value according to the table below.

Property	Description
Stopped	Parameter can only be changed with the motor stopped
Model	Default value may change according to inverter model



NOTE!

Parameter options with the description “Not used” are for WEG’s exclusive use.

C1 INVERTER AND POWER SUPPLY

Configuration of inverter parameters related to power supply, utilization, switching frequency, fans and general settings.

C1.2 Inverter use

It allows setting the inverter operating duty.

C1.2 Inverter use

C1.2.1 Overload Type

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

It selects the inverter duty cycle between normal duty (ND) or heavy duty (HD).

This parameter directly influences the inverter rated current value (C13.1.2) used as a reference for the IGBTs overload and output overcurrent faults.

Indication	Description
0 = Normal Duty (ND)	It operates at 110 % of ND rated current for 1 minute
1 = Heavy Duty (HD)	It operates at 150 % of HD rated current for 1 minute

C1.6 Other inverter settings

It allows reversing the inverter output phase sequence, resetting the inverter counters and setting the inverter rated current reduction.

C1.6 Other inverter settings

C1.6.2 Reset Counters

Range:	0 ... 3	Default: 0
Properties:		

Description:

It allows resetting the values for the parameters of energy, fan running hours and inverter enabled hours.

Indication	Description
0 = Disabled	Disable function
1 = Energy	Reset energy parameters S2.3.12, S2.3.13 and S2.3.14
2 = Not used	Not used
3 = Inverter Enabled	Reset enabled inverter hours parameter D3.2

C CONFIGURATIONS

C1.7 Control Accessories

General settings of the accessories installed on the MVW.

C1.7.1 Slot A to C1.7.7 Slot G

It allows viewing the status of the configuration parameters of the Slot.

C1.7.1 Slot A

C1.7.2 Slot B

C1.7.3 Slot C

C1.7.4 Slot D

C1.7.5 Slot E

C1.7.6 Slot F

C1.7.7 Slot G

.1 Request Identification

Range: 0 ... 9

Default: 0

Properties: Stopped

Description:

It allows forcing the use of a certain accessory. If the accessory is not installed a fault will be generated.

Indication	Description
0 = Automatic	Automatic identification. It does not require using a certain accessory
1 = No Accessory	This Slot must not contain any accessory
2 = IOAI-01	Accessory with analog inputs and outputs
3 = IOD-01	Accessory with digital inputs and outputs
4 = REL-01	Accessory with digital relay outputs
5 = TEMP-01	Accessory with isolated inputs for PTC/PT100/PT1000 sensors
6 = ENC-01	Accessory for incremental encoder connection
7 = CFW900-CPDP-01	Communication accessory for Profibus-DP interface
8 = CCAN-W	Communication accessory for CAN interface
9 = C...-N (Anybus)	Communication accessory for Anybus-CC module

C1.8 Measurements

C1.8 Measurements

C1.8.2 Delay between I_{in} and V_{in} measurements

Range: -99.99 ... 99.99 ms

Default: 0.00 ms

Properties:

Description:

Delay between inverter input current and voltage measurements.

This parameter affects the measurement of input powers, acting directly on the relationship between active power and apparent power.



ATTENTION!

Incorrect setting will cause error in inverter input transformer protection actuation.

C1.8 Measurements

C1.8.5 Temperature measurements in the rectifier

Range: 1 ... 6

Default: 1

Properties:

Description:

Defines the number of temperature measurement sensors installed on the inverter's input rectifier.

C1.8 Measurements**C1.8.6 Alarm for voltage and current measurements**

Range: 0 ... 1

Default: 0

Properties:

Description:

Configures inverted direction of rotation alarms between input and output voltages and currents.

Incorrect assembly can result in:

- Problems in measuring output power.
- Instability in scalar control.
- Inability to operate vector control.
- Input power and PF measurement problems.
- Improper faults in input transformer protection.

See D4.1.13.4.

Indication	Description
0 = Disable	Alarm disabled
1 = Enable	Alarms A261 or A262 will be generated when an anomaly is detected in the measurements

C1.9 Precharge

During the first and second stages of pre-charge, all active cells should reach 50 and 90 % of the nominal DC link voltage, respectively.




Figure 9.1: Precharge stages

C CONFIGURATIONS

C1.9 Precharge		
C1.9.1 Maximum time for the first stage		
C1.9.2 Maximum time for the second stage		
Range:	0 ... 40 s	Default: 10 s (C1.9.1) 15 s (C1.9.2)
Properties:		

Description:
Time limits for precharge stages to complete.




Figure 9.2: Example of time-out in precharge

C1.9 Precharge		
C1.9.3 Maximum time for closing feedback		
C1.9.4 Maximum time for opening feedback		
Range:	0.0 ... 20.0 s	Default: 0.5 s
Properties:		

Description:
Time limits for receiving input cubicle closing confirmations before faults are triggered F0014 e F0015.

C1.9 Precharge		
C1.9.5 Second stage starting point		
Range:	45 ... 75	Default: 50
Properties:		

Description:
It sets the DC bus percentage value at which the second stage of precharge is initiated.

C1.14 Sine filter

Sine wave output filters are circuits installed between the frequency inverter and the electric motor.

Objective:

- Smooth the inverter output voltage waveform
- Reduce harmonics (high frequency components)
- Protect motor insulation against voltage spikes
- Allow longer cables between the inverter and the motor without causing problems such as reflections or overvoltages.

C1.14 Sine filter**C1.14.1 Settings****Range:** 0 ... 6**Default:** 0**Properties:****Description:**

Enables modulation suitable for sinusoidal filter operation.

Indication	Description
0 = Inactive	
1 = Active	
2 = With oversampling	
3 ... 6 = Not used	Not used

C1.14 Sine filter**C1.14.2 Capacitance****Range:** 0.1 ... 999.9 μF **Default:** 61.0 μF **Properties:****Description:**

Sets the capacitance value of the sinusoidal filter.

C1.14 Sine filter**C1.14.3 No-load power factor****C1.14.4 Power factor at 50% load****C1.14.5 Power factor at 75% load****C1.14.6 Power factor at 100% load****Range:** 0.000 ... 1.000**Default:** 0.500 (C1.14.3)

0.800 (C1.14.4)

0.860 (C1.14.5)

0.890 (C1.14.6)

Properties:**Description:**

Adjusts the model that estimates the motor current based on the PF when the inverter is operating with a sinusoidal output filter.

C2 MOTOR

Definition of the characteristics of the motor to be driven by the MVW inverter.

C2.1 Motor data

Definition of motor rated data.

**NOTE!**

The motor data set in C2.1 (from C2.1.1 to C2.1.12) must be exactly as shown on the motor nameplate.

C2.1 Motor data**C2.1.1 Motor Type****Range:** 0 ... 4**Default:** 0**Properties:** Stopped

C CONFIGURATIONS

Description:

Sets the type of motor to be driven by the MVW inverter.

Indication	Description
0 = Induction	It selects that it is an induction motor
1 = Internal permanent magnet synchronous	Selects that it is a synchronous motor with internal permanent magnets, Lq greater than Ld.
2 = Surface permanent magnet synchronous	Selects that it is a synchronous motor with surface permanent magnets, Ld and Lq equal
3 = EE synchronous with AC exciter	Selects that it is a synchronous motor with external excitation (EE) and field windings fed through an AC exciter.
4 = EE synchronous with brushes	Selects that it is a synchronous motor with external excitation (EE) and field windings fed through brushes.

C2.1 Motor data

C2.1.4 Rated Voltage

Range:	1 ... 19999 V	Default: 6600 V
Properties:	Stopped	

Description:

It sets the motor rated voltage value.

C2.1 Motor data

C2.1.5 Rated Current

Range:	0.0 ... 3705.0 A	Default: 140.0 A
Properties:	Stopped	

Description:

It sets the motor rated current value. The value must be set according to the motor nameplate data.

C2.1 Motor data

C2.1.6 Rated Frequency

Range:	0.1 ... 120.0 Hz	Default: 60.0 Hz
Properties:	Stopped	

Description:

It sets the motor rated frequency value.

C2.1 Motor data

C2.1.7 Number of Pole Pairs

Range:	1 ... 90	Default: 3
Properties:	Stopped	

Description:

It sets the number of poles of the motor.



NOTE!

Parameter available only for synchronous motors.

C2.1 Motor data

C2.1.8 Rated Speed

Range:	0 ... 32000 rpm	Default: 1750 rpm
Properties:	Stopped	

Description:

It sets the motor rated speed value.

C2.1 Motor data**C2.1.9 Rated Efficiency**

Range:	50.0 ... 99.9 %	Default: 99.9 %
Properties:	Stopped	

Description:

It sets the motor rated efficiency.

C2.1 Motor data**C2.1.10 Rated cos phi**

Range:	0.50 ... 0.99	Default: 0.82
Properties:	Stopped	

Description:

It sets the motor rated cos φ .

C2.1 Motor data**C2.1.11 Service Factor**

Range:	1.00 ... 1.50	Default: 1.15
Properties:	Stopped	

Description:

It sets the motor rated service factor (SF).

C2.1 Motor data**C2.1.12 Ventilation**

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

It defines the motor ventilation system arrangement.

Indication	Description
0 = Self-ventilated	Motor uses its own ventilation
1 = Independent	Motor uses external ventilation

The value set in C2.1.12 automatically modifies the parameters related to the motor overload fault as follows:

Table 9.9: Change of the motor overload fault

C2.1.12	C7.4.3 (100 %)	C7.4.4 (50 %)	C7.4.5 (5 %)
0	1.00 x C2.1.5	0.86 x C2.1.5	0.62 x C2.1.5
1	1.00 x C2.1.5	1.00 x C2.1.5	1.00 x C2.1.5

C2.2 Motor model

It allows viewing and changing the motor electrical parameters estimated by the Self-Tuning routine. The user can manually set the data if they have the motor data sheet.

C2.2 Motor model**C2.2.1 Stator Resistance**

Range:	0.000 ... 30.000 Ω	Default: 1.000 Ω
Properties:		

Description:

It sets the motor stator resistance value.

C CONFIGURATIONS

C2.2 Motor model

C2.2.2 Magnetizing Reactance

Range: 0.0 ... 800.0 Ω

Default: 1.0 Ω

Properties:

Description:

It defines the motor magnetization reactance value.

C2.2 Motor model

C2.2.3 Leakage Reactance

Range: 0.00 ... 100.00 Ω

Default: 1.00 Ω

Properties:

Description:

It sets the motor leakage reactance value.

C2.2 Motor model

C2.2.4 Rotor Resistance

Range: 0.000 ... 30.000 Ω

Default: 1.000 Ω

Properties:

Description:

It sets the motor rotor resistance value.

C2.2 Motor model

C2.2.5 Rotor Reactance

Range: 0.00 ... 100.00 Ω

Default: 1.00 Ω

Properties:

Description:

It sets the motor rotor reactance value.

C2.2 Motor model

C2.2.10 Ke Constant

Range: 0.0 ... 3000.0

Default: 0.0

Properties:

Description:

It sets the value of the Ke voltage constant generated by the motor. The engineering unit used is V/krpm (Volts/1000 rpm).

C3 CONTROL

The inverter supplies the motor with variable voltage, current and frequency, which enables the motor speed and torque control. The values applied to the motor follow a control strategy, depending on the selected control type and the inverter parameter settings.

In this menu, choose the control type according to the static and dynamic torque and speed demands of the driven load.

Control Types:

Scalar: scalar control; simpler control type by imposed voltage/frequency; speed regulation in open loop or with slip compensation (programmable); it allows multiple motor operation.

Sensorless vector: field-oriented control; no motor speed sensor; able to drive standard motors; speed control in the range of 1:100; 0.5 % static accuracy of rated speed in speed control; high control dynamics.

Vector with encoder: field-oriented control; requires encoder on the motor and interface module for encoder on the inverter (ENC-01); speed control up to 0 rpm; 0.01 % static accuracy of rated speed in speed control; high static and dynamic performance of speed and torque control.

C3.1 Configuration

It allows setting the control type used to drive the motor.

C3.1 Configuration

C3.1.1 Control Type

Range:	0 ... 3	Default: 0
Properties:	Stopped	

Description:

Defines the type of control that will be used to control the motor speed or torque.



NOTE!

For PM motors, only the Scalar or VVW+ options are available

Indication	Description
0 = Scalar or VVW	Voltage/frequency scalar control. VVW+ control for PM motors
1 = Not used	Not used
2 = Encoder Vector	Vector control with encoder (with speed sensor)
3 = Sensorless Vector	Sensorless vector control (without speed sensor)

C3.2 Scalar control

SCALAR CONTROL FOR INDUCTION MOTOR

This is the classic control for a three-phase induction motor, based on a curve that relates output frequency and voltage. The inverter works as a variable voltage and frequency source, generating frequency and voltage values according to this curve. Figure 9.3 shows the scalar control block diagram.

The scalar control is recommended for the following cases:

- Drive of several motors with the same inverter (multiple motor drive).
- Motor rated current below 1/3 of the inverter rated current.
- For test purposes, the inverter is turned on without motor or with a small motor with no load.
- Applications where the load connected to the inverter is not a three-phase induction motor.




Figure 9.3: Block diagram of scalar control for induction motors

C CONFIGURATIONS

C3.2.1 V/f Curve

It allows adjusting the curve defined by the inverter output voltage and frequency. Example of using this resource: when a transformer is used between the inverter and the motor, and you want to compensate the voltage drop in the cable used to connect the motor.

C3.2.1 V/f Curve		
C3.2.1.1 Manual Torque Boost		
Range:	0.0 ... 20.0 %	Default: 0.0 %
Properties:		

Description:
It acts at low frequencies, that is, in the range from 0 to C3.2.1.5, increasing the inverter output voltage to compensate for the voltage drop in the motor stator resistance in order to maintain a constant torque .

The optimum setting is the smallest value of C3.2.1.1 which allows the motor satisfactory start. A value greater than necessary will excessively increase the motor current at low speeds, which may lead the inverter to a fault condition (F0070, F0071 or F0072), as well as to the motor heating. Figure 9.4 shows the Torque Boost action region between points P₀ and P₁.




Figure 9.4: Torque boost region

C3.2.1 V/f Curve		
C3.2.1.2 Low Output Voltage		
Range:	0.0 ... 100.0 %	Default: 33.3 %
Properties:	Stopped	

Description:
It sets the voltage value of point P₁ to adjust the inverter V/F curve together with its pair C3.2.1.5.

C3.2.1 V/f Curve		
C3.2.1.3 Interm. Output Voltage		
Range:	0.0 ... 100.0 %	Default: 66.7 %
Properties:	Stopped	

Description:
It sets the voltage value of point P₂ to adjust the inverter V/F curve together with its pair C3.2.1.6.

C3.2.1 V/f Curve**C3.2.1.4 Maximum Output Voltage**

Range:	0.0 ... 100.0 %	Default: 100.0 %
Properties:	Stopped	

Description:

It sets the voltage value of point P₃ to adjust the inverter V/F curve together with its pair C3.2.1.7.

**NOTE!**

The maximum output voltage C3.2.1.4 at 100 % corresponds to the motor rated voltage C2.1.4. In cases where the inverter is being supplied with a line voltage above the motor rated voltage, the output voltage the inverter applies remains the value set in C2.1.4.

C3.2.1 V/f Curve**C3.2.1.5 Low Speed**

Range:	0.0 ... 200.0 %	Default: 33.3 %
Properties:	Stopped	

Description:

It sets the speed value of point P₁ to adjust the inverter V/F curve together with its pair C3.2.1.2.

C3.2.1 V/f Curve**C3.2.1.6 Intermediate Speed**

Range:	0.0 ... 200.0 %	Default: 66.7 %
Properties:	Stopped	

Description:

It sets the speed value of point P₂ to adjust the inverter V/F curve together with its pair C3.2.1.3.

C3.2.1 V/f Curve**C3.2.1.7 Field Weakening Start Speed**

Range:	0.0 ... 200.0 %	Default: 100.0 %
Properties:	Stopped	

Description:

It sets the speed value of point P₃ to adjust the inverter V/F curve together with its pair C3.2.1.4.

C3.2.1 V/f Curve**C3.2.1.8 Rated Flux**

Range:	0.0 ... 120.0 %	Default: 100.0 %
Properties:		

Description:

For scalar control, it allows to adjust a percentage of the motor stator flux in relation to the nominal stator flux.

**NOTE!**

In the scalar control type, the parameter C3.2.1.8 allows for regulation of the inverter output voltage after setting the V/F curve. This can be useful in applications that require output voltage compensation or field weakening.

C3.2.2 Optimization

It allows adjustments to the VVW+ control dynamics. The VVW+ control is factory set to suit most applications. If an improvement in the dynamic behavior of the control is required for induction and PM motors, the parameters below are available.

C CONFIGURATIONS

C3.2.2.1 Induction motor

It allows setting the VVW+ control parameters for induction motors.

C3.2.2.1 Induction motor

C3.2.2.1.1 Slip compensator gain

Range: -10.00 ... 10.00

Default: 0.00

Properties:

Description:

It allows applying a gain to the slip estimator of the VVW+ control.



NOTE!

This value should be adjusted gradually when there is a speed error in the system.

C3.2.2.1 Induction motor

C3.2.2.1.2 Voltage Comp. Gain

Range: 0.00 ... 5.00

Default: 1.00

Properties:

Description:

It allows applying a gain to the VVW+ scalar control voltage compensator.



NOTE!

This value should be adjusted gradually when there is a voltage error in the system.

C3.2.2.1 Induction motor

C3.2.2.1.3 Filter

Range: 1 ... 16000 ms

Default: 200 ms

Properties:

Description:

This parameter sets the low-pass filter used in the speed slip signal.

C3.2.2.2 Synchronous motor

The MTPA function determines the high efficiency region of the PM motor operation. This function guides the motor voltage vector so that it operates with the ratio between the maximum torque applied to the PM motor and its lowest possible current.



NOTE!

Function available only for PM motor.

C3.2.2.2 Synchronous motor

C3.2.2.2.3 MTPA Minimum Speed

Range: 0 ... 100 %

Default: 2 %

Properties:

Description:

It sets a percentage of the motor rated speed to activate the MTPA function. If S2.1.1 is greater than C3.2.2.2.3 x C2.1.8, the motor MTPA function will be activated.

C3.2.2.2 Synchronous motor**C3.2.2.2.5 Kp MTPA Gain****Range:** 0.000 ... 1.000**Default:** 0.010**Properties:****Description:**

It sets the proportional gain value of the MTPA regulator.

**NOTE!**

The gain values of this controller are automatically adjusted by the inverter.

C3.2.2.2 Synchronous motor**C3.2.2.2.6 Ki MTPA Gain****Range:** 0.000 ... 1.000**Default:** 0.002**Properties:****Description:**

It sets the integral gain value of the MTPA regulator.

**NOTE!**

The gain values of this controller are automatically adjusted by the inverter.

C3.2.2.2 Synchronous motor**C3.2.2.2.8 MTPA Minimum Voltage****Range:** 0 ... 100 %**Default:** 100 %**Properties:****Description:**

It defines the minimum voltage value at a given speed that will be applied to the motor when the MTPA function is active.

The minimum voltage value in Volts (V) is the percentage of the ratio $(C2.2.10 * S2.1.1)/1000$.

E.g.:

C2.2.10: Motor model - Ke Constant = 120 V/kRPM.

S2.1.1: Motor speed - Reference = 900 RPM.

C3.2.2.2.8: Synchronous motor - MTPA Minimum Voltage = 50.0 %.

Minimum MTPA Voltage (V) = $(C3.2.2.2.8 / 100) * (C2.2.10 * S2.1.1) / 1000 = 54 \text{ V}$.

C3.2.2.3 Synchronous motor with external excitation

Allows you to adjust the parameters related to the field regulation of the synchronous motor with external excitation, both with brushes and with a brushless AC exciter.

C3.2.2.3 Synchronous motor with external excitation**C3.2.2.3.1 Synchronous machine field controller****Range:** 0 ... 1**Default:** 1**Properties:****Description:**

Enables the field controller of the synchronous machine with external excitation.

C CONFIGURATIONS

Indication	Description
0 = Inactive	
1 = Reactive controller	The field reference comes from the stator reactive controller, which seeks to maintain the reactive reference configured by the user While the reactive regulator acts in the field, the stator follows the V/f ratio according to the motor data and the configured curve

C3.2.2.3 Synchronous motor with external excitation

C3.2.2.3.2 Reactive reference in the stator

Range: -2.00 ... 2.00 **Default:** 0.00

Properties:

Description:

Reactive current reference as a function of the motor's nominal current.

A negative reference value should result in a current lagging behind the voltage.

C3.2.2.3 Synchronous motor with external excitation

C3.2.2.3.3 Initial field reference

Range: 0.00 ... 1.00 **Default:** 0.20

Properties:

Description:

Defines the initial value of the field reference, which is applied before the field regulation step.

When enabling PWM, the field reference varies in a ramp, starting from zero, reaching the value configured in the initial reference parameter after the ramp time.

After the ramp is completed, the field reference value remains at the initial value until the frequency condition for starting regulation is met and the reactive controller starts regulating the field.

C3.2.2.3 Synchronous motor with external excitation

C3.2.2.3.4 Field entry ramp time

Range: 0.00 ... 200.00 s **Default:** 3.00 s

Properties:

Description:

Defines the ramp time applied to the field reference input.

During the ramp time the field reference varies from zero to the initial field reference.

The field input occurs when the PWM is ENABLED or when the RUN command occurs, according to the motor magnetization mode configuration.

C3.2.2.3 Synchronous motor with external excitation

C3.2.2.3.5 Minimum value of the field reference

C3.2.2.3.6 Maximum field reference value

Range: 0.00 ... 1.00 **Default:** 0.01 (C3.2.2.3.5)

1.00 (C3.2.2.3.6)

Properties:

Description:

Defines the range of the field reference, limiting the action of the reactive controller.

If the initial field reference exceeds the defined range, this will be used as the initial reference.

C3.2.2.3 Synchronous motor with external excitation**C3.2.2.3.7 Starting point of field regulation****Range:** 0 ... 200**Default:** 5**Properties:****Description:**

Defines the starting frequency of the closed-loop control of the field reference in relation to the nominal motor frequency.

Below the frequency defined by this parameter, the field reference is defined by the ramp. Even if the frequency condition is satisfied, regulation only starts after the input ramp is completed.

When the motor frequency drops below 90 % of the value set to start regulation, the ramp assumes the field reference, imposing the initial value again. This method seeks to ensure the proper behavior of the currents in stopping and reversing and motor speed.

C3.2.2.3 Synchronous motor with external excitation**C3.2.2.3.8 Field regulator gain****Range:** 0.000 ... 9.999**Default:** 0.070**Properties:****Description:**

Sets the gain of the field reference regulator.

C3.2.2.3 Synchronous motor with external excitation**C3.2.2.3.9 Full time of the field regulator****Range:** 0.000 ... 50.000 s**Default:** 0.030 s**Properties:****Description:**

Sets the integral time of the field regulator.

C3.2.3 Current stabilization

The Current Stabilization function is used to dampen electromechanical oscillations present in the motor when it is operating with a low load level and at low frequencies. These oscillations cause instability in the system that, in some occasions, can cause the overcurrent fault.

C3.2.3 Current stabilization**C3.2.3.1 Configuration****Range:** 0 ... 5**Default:** 4**Properties:****Description:**

It defines whether the motor current stabilization function will be active or not.

This function eliminates oscillations in the motor currents resulting from operation at low speeds and with little load.

Indication	Description
0 = Disable	Disable function
1 = PI	
2 = HPF method 1	
3 = HPF method 2	
4 = HPF method 3	
5 = Classic	

C CONFIGURATIONS

C3.2.3 Current stabilization

C3.2.3.2 Stabilization Kp Gain

C3.2.3.3 Stabilization Ki Gain

Range: 0.000 ... 1.999 **Default:** 0.150 (C3.2.3.2)
0.020 (C3.2.3.3)

Properties:

Description:

Defines the values of the respective Current Stabilizer gains. The gain values of this controller are automatically adjusted by the inverter, requiring no adjustment for general-purpose applications.



NOTE!

If you need to modify the earnings of this controlled entity, it is suggested that you first gradually increase the value of C3.2.3.3.

C3.2.3 Current stabilization

C3.2.3.4 Stab. PI Saturation

Range: 0.0 ... 5.0 % **Default:** 0.5 %

Properties:

Description:

It sets the saturation level of the motor current stabilization regulator output.

C3.2.3 Current stabilization

C3.2.3.5 High-pass filter gain

Range: 0.000 ... 9.999 ms **Default:** 0.050 ms

Properties:

Description:

Defines the values of the gain and time constant of the current stabilization loop through the high-pass filter.



NOTE!

Active only when current stabilization is configured to operate via the active current high-pass (C3.2.3.1>1).

C3.2.3 Current stabilization

C3.2.3.6 High-pass filter Tc

Range: 0 ... 9999 ms **Default:** 318 ms

Properties:

Description:

Defines the values of the gain and time constant of the current stabilization loop through the high-pass filter.



NOTE!

Active only when current stabilization is configured to operate via the active current high-pass (C3.2.3.1>1).

C3.2.3 Current stabilization

C3.2.3.7 Maximum operating frequency

Range: 0 ... 300 % **Default:** 0 %

Properties:

Description:

It disables the Current Stabilization function after the speed exceeds the value set in this parameter. When the value is set to zero, this functionality is disabled. This parameter is only available for induction motors.

C3.2.4 Pre-magnetization

The Pre-Magnetization function improves the dynamic behavior of the motor start when subjected to a very high load.

Figure 9.5 shows the operation flow of the Pre-Magnetization function together with the motor drive. In this activation, before the motor accelerates, the stator is magnetized so that it has energy for starting with load. Magnetization is performed by injecting a direct current (C3.2.4.2) for a programmed time (C3.2.4.3). The voltage boost during motor acceleration can be controlled by setting C3.2.4.4.




Figure 9.5: Illustrative diagram of the operation of the pre-magnetization function

C3.2.4 Pre-magnetization		
C3.2.4.1 Enable Function		
Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

It enables the motor pre-magnetization function.

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function

C CONFIGURATIONS

C3.2.4 Pre-magnetization

C3.2.4.2 Current

Range:	0 ... 350 %	Default: 100 %
Properties:		

Description:

It allows setting the current level applied during the motor pre-magnetization process. The full scale is the rated motor current set in C2.1.5.



NOTE!

If the value set in C3.2.4.2 is greater than the inverter current, it will be automatically limited to the inverter maximum current capacity.

C3.2.4 Pre-magnetization

C3.2.4.3 Time

Range:	0 ... 5000 ms	Default: 2000 ms
Properties:		

Description:

It allows setting the motor pre-magnetization time, which is the time that the inverter considers to indicate that the motor is general enabled (or magnetized) after receiving the general enable command.

C3.2.4 Pre-magnetization

C3.2.4.4 Gain

Range:	1.0 ... 7.0	Default: 3.5
Properties:		

Description:

It allows setting the voltage boost applied during the motor acceleration. See Figure 9.5 for further details.

C3.3 Vector control

VECTOR CONTROL FOR INDUCTION MOTOR

It is the type of control based on the separation of the motor current in two components:

- Direct current I_d (oriented with the electromagnetic flux vector of the motor);
- Quadrature current I_q (perpendicular to the flux vector of the motor).

The direct current is related to the motor electromagnetic flux, while quadrature current is directly related to the electromagnetic torque produced in the motor shaft. With this strategy you have the so-called decoupling, that is, you can independently control the flux and torque in the motor by controlling the currents I_d and I_q , respectively.

As these currents are represented by vectors that spin at synchronous speed, when viewed from a stationary frame of reference, the frame is transformed to change them for a synchronous frame of reference. In the synchronous frame, these vectors are turned into DC values proportional to the amplitude of the respective vectors. This considerably simplifies the control circuit.

When vector I_d is aligned with the motor flux, we can say that the vector control is oriented. To that end, it is necessary that the motor parameters be correctly set. These parameters must be set according to the motor nameplate data and other information obtained automatically by the Self-Tuning, or through the motor data sheet provided by the manufacturer.

Figures 9.6 and 9.7, on the page 9-19, show the block diagram for the vector control with encoder and sensorless in the speed and torque operating modes, respectively. The speed information, as well as the currents measured

by the inverter, will be used to obtain the correct direction of the vectors. In the case of vector control with encoder, the speed is obtained directly from the encoder signal, while in sensorless vector control there is an algorithm that estimates the speed based on the output currents and voltages.

The vector control measures the currents, separates the components into direct and quadrature portions and transforms these variables for the synchronous frame of reference. The motor is controlled by imposing the desired currents and comparing them to the actual values.




Figure 9.6: Block diagram of induction motor vector control in speed mode




Figure 9.7: Block diagram of induction motor vector control in torque mode

SENSORLESS VECTOR CONTROL

The Sensorless Vector Control is recommended for most applications as it allows operation in a 1:100 speed range, 0.5 % speed control accuracy of the rated speed, high starting torque and fast dynamic response.

Another advantage of this kind of control is greater robustness against sudden voltage variations of the power supply and load, preventing unnecessary shutdowns by overcurrent.

The necessary settings for the proper operation of the sensorless control are made automatically. To that end, the motor to be used must be connected to the MVW.

VECTOR CONTROL WITH ENCODER

The Vector Control with Encoder on the motor presents the same advantages as those of the sensorless previously mentioned with the following additional benefits:

- Speed and torque control up to 0 (zero) rpm.

C CONFIGURATIONS

- Precision of 0.01 % in the speed control (if digital references are used, for example, via HMI, Profibus DP, DeviceNet, etc.).

Vector control with encoder requires accessory for interfacing with incremental encoder (E.g. ENC-01). For more installation and connection details, refer to the accessory manual.

In order to perform the Self-tuning in the Running mode, it is necessary that the rotor shaft is free to spin (without application of load on the shaft). During this process, the motor will spin up to half the motor rated speed set in C2.1.8.

During the Self-tuning process in Stop mode, there may be small movements in the rotor during the identification of parameter T_r (rotor time constant). Therefore, if the application is sensitive to these small movements, it is recommended that the Self-tuning process be carried out with the motor disconnected from the system.

C3.3.1 Configuration

It defines some settings of the vector control.

C3.3.1 Configuration

C3.3.1.1 Control Mode

Range: 0 ... 2

Default: 0

Properties:

Description:

Sets the control mode for the motor.

Synchronous Machines - Torque Mode:

It is important that the first motor start-up is carried out with the motor stopped, due to the identification of the initial position of the rotor. However, for applications where it is not possible to perform the first actuation with the motor stopped, the Flying-Start function must be enabled.

Indication	Description
0 = Speed	Enable control in Speed mode
1 = Torque	Enable control in Torque mode
2 = Defined by DI	The control mode is defined by the status of the digital input set in (C3.3.1.2). Inactive input selects Speed mode and active input selects Torque mode



NOTE!

The torque mode only works when the control type is Vector w/ Encoder (C3.1.1 = 2).

C3.3.1 Configuration

C3.3.1.2 Control Mode DI Config.

Range: 0 ... 62

Default: 0

Properties: Stopped

Description:

It defines which digital input makes the transition from Speed mode to Torque mode or vice versa. Table 9.15 on page 9-21 shows the options.

Table 9.15: Values assigned to the Digital Inputs of X and A...G Slots for defining the Control Mode

Digital Inputs options for X and A...G Slots								
Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
DI1	X-1 (1)	A-1 (7)	B-1 (15)	C-1 (23)	D-1 (31)	E-1 (39)	F-1 (47)	G-1 (55)
DI2	X-2 (2)	A-2 (8)	B-2 (16)	C-2 (24)	D-2 (32)	E-2 (40)	F-2 (48)	G-2 (56)
DI3	X-3 (3)	A-3 (9)	B-3 (17)	C-3 (25)	D-3 (33)	E-3 (41)	F-3 (49)	G-3 (57)
DI4	X-4 (4)	A-4 (10)	B-4 (18)	C-4 (26)	D-4 (34)	E-4 (42)	F-4 (50)	G-4 (58)
DI5	X-5 (5)	A-5 (11)	B-5 (19)	C-5 (27)	D-5 (35)	E-5 (43)	F-5 (51)	G-5 (59)
DI6	X-6 (6)	A-6 (12)	B-6 (20)	C-6 (28)	D-6 (36)	E-6 (44)	F-6 (52)	G-6 (60)
DI7	–	A-7 (13)	B-7 (21)	C-7 (29)	D-7 (37)	E-7 (45)	F-7 (53)	G-7 (61)
DI8	–	A-8 (14)	B-8 (22)	C-8 (30)	D-8 (38)	E-8 (46)	F-8 (54)	G-8 (62)

C3.3.1 Configuration**C3.3.1.3 Control Encoder**

Range:	0 ... 8	Default: 8
Properties:	Stopped	

Description:

It defines which accessory Slot will be used for reading the encoder signals.

Indication	Description
0 = Slot X	Reading of the encoder signals via IO1 and IO2 of the Slot X accessory
1 = Slot A	Reading of the encoder signals via ENC-01 accessory in Slot A
2 = Slot B	Reading of the encoder signals via ENC-01 accessory in Slot B
3 = Slot C	Reading of the encoder signals via ENC-01 accessory in Slot C
4 = Slot D	Reading of the encoder signals via ENC-01 accessory in Slot D
5 = Slot E	Reading of the encoder signals via ENC-01 accessory in Slot E
6 = Slot F	Reading of the encoder signals via ENC-01 accessory in Slot F
7 = Slot G	Reading of the encoder signals via ENC-01 accessory in Slot G
8 = None	There is no accessory for reading the encoder signals installed on the MVW

C3.3.1 Configuration**C3.3.1.6 Magnetization Mode**

Range:	0 ... 1	Default: 1
Properties:		

Description:

Defines which command will be used to initiate motor magnetization.

In the Run/Stop option:

For synchronous machines, the process of identifying the initial rotor position will be performed whenever the RUN command is executed with the motor stopped. There will be no voltage or current signal applied to the motor when the motor is stopped or the inverter is in the READY state.

For induction machines, there will be no magnetizing current with the motor stopped. When the RUN command is executed, the motor will be magnetized and then the speed or torque reference ramp will be released.

In the General Enable option:

For synchronous machines, a high-frequency signal will be applied when the motor is stopped. The process The initial rotor position identification test will be performed only once.

For induction machines, a direct current (magnetizing current) will be applied to the motor when it is stopped.

C CONFIGURATIONS



NOTE!

For applications with on-load starts, the General-enabled option is recommended.

Indication	Description
0 = General Enable	Applies magnetizing current after General Enable ON
1 = Run/Stop	It applies magnetizing current after Run/Stop = Run

C3.3.1 Configuration

C3.3.1.7 Speed observer gain

C3.3.1.8 Speed observer full time

Range: 0.000 ... 9.999 **Default:** 0.165 (C3.3.1.7)
0.942 (C3.3.1.8)

Properties:

Description:

Induction motor speed observer PI regulator parameters.

C3.3.1 Configuration

C3.3.1.9 Motor model speed time constant

Range: 0.5 ... 12.0 ms **Default:** 2.0 ms

Properties:

Description:

Time constant of the filter used in the speed feedback of the current model.

C3.3.2 Regulators

It allows viewing and changing the parameters related to the vector control flux, current and speed regulators.

C3.3.2.1 Speed regulator

Regulator responsible for setting the motor speed dynamics. The speed regulator gains are automatically calculated according to parameter C2.2.5. Changing C2.2.5, parameters C3.3.2.1.2 and C3.3.2.1.3 are modified proportionally; however, these gains can be manually set to optimize the dynamic speed response.

The proportional gain (C3.3.2.1.2) stabilizes sudden changes in speed or reference, while the Integral gain (C3.3.2.1.3) corrects the error between reference and speed and improves torque response at low speeds. The Differential gain (C3.3.2.1.4) helps minimize variations in the motor speed produced by sudden load changes.

Manual Adjustment Procedure for Speed Regulator Optimization:

1. Select the acceleration (C6.1.1 or C6.1.4) and/or deceleration (C6.1.2 or C6.1.5) time according to the application.
2. Set the speed reference to 75 % of the maximum value.
3. Using the WPS software, set a trend to the "Effective Speed" variable.
4. Lock the speed ramp (Run/Stop = Stop) and wait for the motor to stop.
5. Release the speed ramp (Run/Stop = Run). Observe the motor speed signal with the WPS trend.
6. Check among the options in Figure 9.8 which waveform best represents the read signal.




Figure 9.8: (a), (b) and (c) - Types of speed regulator response

7. Set C3.3.2.1.2 and C3.3.2.1.3 according to the type of response shown in Figure 9.8.

- a. Decrease the proportional gain (C3.3.2.1.2) and/or increase the integral gain (C3.3.2.1.3).
- b. Speed regulator optimized.
- c. Increase the proportional gain (C3.3.2.1.2) and/or decrease the integral gain (C3.3.2.1.3).

In sensorless vector control the maximum typical value of the proportional gain C3.3.2.1.2 must not be greater than 9.0. Otherwise, strange behaviors can be observed in the motor, such as: motor remains still or spins at low speed, despite the output current being different from zero. It is recommended to reduce the setting in C3.3.2.1.2 until the motor behaves correctly.

C3.3.2.1 Speed regulator		
C3.3.2.1.2 Proportional Gain		
Range:	0.0 ... 50.0	Default: 5.0
Properties:		

Description:
It sets the value of the Speed Regulator proportional gain. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

NOTE!
If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.3.2.1.3.

C3.3.2.1 Speed regulator		
C3.3.2.1.3 Integral Gain		
Range:	0.001 ... 1.000	Default: 0.100
Properties:		

Description:
It sets the value of the Speed Regulator integral gain. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

C CONFIGURATIONS

C3.3.2.1 Speed regulator

C3.3.2.1.4 Differential Gain

Range:	0.00 ... 7.99	Default: 0.00
Properties:		

Description:

It sets the value of the Speed Regulator differential gain. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

C3.3.2.1 Speed regulator

C3.3.2.1.5 Filter

Range:	1 ... 1000 ms	Default: 12 ms
Properties:		

Description:

It sets the low-pass filter time constant value of the speed signal used in the Speed Regulator.



NOTE!

In general, this parameter must not be changed. Increasing its value makes the system response slower.

C3.3.2.2 Torque regulator

C3.3.2.2 Torque regulator

C3.3.2.2.1 Proportional Gain

Range:	0.00 ... 5.00	Default: 1.00
Properties:		

Description:

It sets the value of the Torque Regulator proportional gain.

The gain values of this controller are automatically set by the inverter. No settings are required for general purpose applications.



NOTE!

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.3.4.2.2.

C3.3.2.2 Torque regulator

C3.3.2.2.2 Integral Gain

Range:	0.000 ... 1.000	Default: 0.010
Properties:		

Description:

It sets the value of the Torque Regulator integral gain.

The gain values of this controller are automatically set by the inverter. No settings are required for general purpose applications.

C3.3.2.2 Torque regulator

C3.3.2.2.3 Differential Gain

Range:	0.00 ... 7.99	Default: 0.00
Properties:		

Description:

It sets the value of the Torque Regulator differential gain. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

C3.3.2.2 Torque regulator**C3.3.2.2.4 Filter**

Range:	12 ... 10000 ms	Default: 12 ms
Properties:		

Description:

It allows setting the low-pass filter time constant value of the torque signal.

C3.3.2.3 Flux regulator

It allows viewing and changing the parameters related to the vector control flux regulator.

C3.3.2.3 Flux regulator**C3.3.2.3.1 Proportional Gain**

Range:	0.0 ... 999.9	Default: 50.0
Properties:		

Description:

It sets the value of the Flux Regulator proportional gain. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

**NOTE!**

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.3.2.3.2.

C3.3.2.3 Flux regulator**C3.3.2.3.2 Integral time**

Range:	0.001 ... 50.000 s	Default: 0.900 s
Properties:		

Description:

It sets the value of the Flux Regulator integral gain. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

C3.3.2.3 Flux regulator**C3.3.2.3.3 Minimum flux**

Range:	0 ... 120 %	Default: 0 %
Properties:	Stopped	

Description:

It sets the value of flow reference for vector control. This value is a reference in percentage of the motor rated flux value.

C3.3.2.3 Flux regulator**C3.3.2.3.4 Rated Flux**

Range:	0 ... 120 %	Default: 100 %
Properties:	Stopped	

C CONFIGURATIONS

Description:

It sets the value of flow reference for vector control. This value is a reference in percentage of the motor rated flux value.

C3.3.2.3 Flux regulator

C3.3.2.3.5 Maximum flux

Range:	0 ... 200 %	Default: 120 %
Properties:	Stopped	

Description:

It sets the value of flow reference for vector control. This value is a reference in percentage of the motor rated flux value.

C3.3.2.3 Flux regulator

C3.3.2.3.6 Magnetization Time

Range:	0.01 ... 10.00	Default: 1.00
Properties:		

Description:

Adjusts the motor magnetization time. This value is proportional to the rotor time constant of the motor.

C3.3.2.4 Current regulator

It allows viewing and changing the parameters related to the vector control current regulator.

C3.3.2.4 Current regulator

C3.3.2.4.1 Id Prop. Gain

Range:	0.00 ... 5.00	Default: 1.00
Properties:		

Description:

It sets the value of the Current Regulator proportional gain (D axis of the synchronous reference frame). The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.



NOTE!

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.3.2.4.2.

C3.3.2.4 Current regulator

C3.3.2.4.2 Id Integral Gain

Range:	0.001 ... 1.000	Default: 0.050
Properties:		

Description:

It sets the value of the Current Regulator integral gain (D axis of the synchronous reference frame). The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

C3.3.2.4 Current regulator

C3.3.2.4.3 Iq Prop. Gain

Range:	0.00 ... 5.00	Default: 1.00
Properties:		

Description:

It sets the value of the Current Regulator proportional gain (Q axis of the synchronous reference frame). The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

**NOTE!**

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.3.2.4.4.

C3.3.2.4 Current regulator**C3.3.2.4.4 Iq Integral Gain**

Range: 0.001 ... 1.000

Default: 0.050

Properties:

Description:

It sets the value of the Current Regulator integral gain (Q axis of the synchronous reference frame). The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

C3.3.2.4 Current regulator**C3.3.2.4.5 Proportional gain**

Range: 0.000 ... 9.999

Default: 0.080

Properties:

Description:**C3.3.2.4 Current regulator****C3.3.2.4.6 Integral gain**

Range: 0.001 ... 65.535 s

Default: 0.123 s

Properties:

Description:**C3.3.2.6 Regulators self-tuning****C3.3.2.6 Regulators self-tuning****C3.3.2.6.1 Run Self-tuning**

Range: 0 ... 2

Default: 0

Properties: Stopped

Description:

Defines the motor parameter identification mode. After selected the identification method, self-tuning starts executing the steps automatically.

Indication	Description
0 = No	Function disabled.
1 = Stopped	Self-tuning with the motor stopped
2 = Running	Self-tuning with the motor running

C3.3.3 Output Voltage Limiter

It allows viewing and changing the parameters related to the output voltage limiter for proper control in the field

C CONFIGURATIONS

weakening region.

The Output Voltage Limiter prevents the voltage imposed by the inverter from exceeding a preset value set in C3.3.3.1. This will prevent electrical damage to the motor stator. This region of operation is commonly known as the field weakening region, because, in this region, the motor magnetic field is weakened to ensure that the voltage imposed on the stator be limited to the value C3.3.3.1. This will occur whenever the value set in C3.3.3.1 is equal to or greater than the value of the motor rated voltage (C2.1.4).

C3.3.3 Output Voltage Limiter

C3.3.3.1 Maximum Output Voltage

Range: 0.0 ... 120.0 %

Default: 100.0 %

Properties:

Description:

Allows setting the value of the maximum output voltage. The value set in this parameter corresponds to a percentage in relation to the motor rated voltage set in C2.1.4.

C3.3.3 Output Voltage Limiter

C3.3.3.2 Proportional Gain

Range: 0.00 ... 5.00

Default: 1.00

Properties:

Description:

It sets the proportional gain value of the Voltage Limiter regulator. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.



NOTE!

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.3.3.3.

C3.3.3 Output Voltage Limiter

C3.3.3.3 Integral Gain

Range: 0.00 ... 100.00

Default: 1.00

Properties:

Description:

It sets the integral gain value of the Voltage Limiter regulator. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

C3.3.3 Output Voltage Limiter

C3.3.3.4 Field weakening starting point

Range: 0 ... 120 %

Default: 90 %

Properties:

Description:

Expresses the percentage of the modulation index from which the motor field weakening occurs.

C3.3.3 Output Voltage Limiter

C3.3.3.5 Speed for MTPV

Range: 0 ... 600 %

Default: 250 %

Properties:

Description:

It allows defining the transition speed from field weakening mode to MTPV (Maximum Torque per Voltage). The value set in this parameter corresponds to a percentage in relation to the motor rated speed, which is set in C2.1.8.



NOTE!
Function available only for induction motor (C2.1.1 = 0).

C3.3.3 Output Voltage Limiter

C3.3.3.6 field weakening feedback

Range:	0 ... 1	Default: 0
Properties:		

Description:

Indication	Description
0 = Voltage reference	The current regulators output itself is fed back to field weakening
1 = Highest modulation index	The field weakening regulator receives the highest modulation rate among the phases, directly from the modulator This value already takes into account the maximum modulation index and the saturations that may occur within the modulator

C3.3.4 Torque Mode

Settings for torque control mode in vector control.

C3.3.4.1 Speed Limiter

Allows viewing and changing the parameters related to the motor speed limiters. These limiters prevent motor overspeed.

The Speed Limiter is enabled when in torque control mode (C3.3.1.1 = 1). The motor speed is monitored to prevent it from exceeding the values set in C3.3.4.1.1 and C3.3.4.1.2 (Figure 9.9). If the motor speed exceeds these values, the torque reference is decreased to keep the motor speed limited.




Figure 9.9: Speed behavior limited according to the settings

C3.3.4.1 Speed Limiter

C3.3.4.1.1 Forward Speed

Range:	0 ... 32000 rpm	Default: 1800 rpm
Properties:		

Description:

It sets the value of the maximum motor speed when running in the forward direction.

C CONFIGURATIONS

C3.3.4.1 Speed Limiter

C3.3.4.1.2 Reverse Speed

Range: 0 ... 32000 rpm

Default: 1800 rpm

Properties:

Description:

It sets the value of the maximum motor speed when running in the reverse direction.

C3.3.4.1 Speed Limiter

C3.3.4.1.3 Proportional Gain

Range: 0.00 ... 5.00

Default: 0.50

Properties:

Description:

It sets the proportional gain value of the Speed Limiter regulator.

The gain values of this controller are automatically set by the inverter. No settings are required for general purpose applications.

This parameter can be changed after the SELF-TUNING process.



NOTE!

If you need to change the gains of this controller, It is suggested that you first gradually increase the value of C3.3.4.1.4.

C3.3.4.1 Speed Limiter

C3.3.4.1.4 Integral Gain

Range: 0.000 ... 1.000

Default: 0.010

Properties:

Description:

It sets the integral gain value of the Speed Limiter regulator.

The gain values of this controller are automatically set by the inverter. No settings are required for general purpose applications.

This parameter can be changed after the SELF-TUNING process.

C3.3.5 Speed Mode

Settings for the speed mode in vector control.

C3.3.5.1 Torque Limiter

It allows viewing and changing the parameters related to the motor torque limiter.

The Torque Limiter is enabled when the selected control mode is the speed mode (C3.3.1.1). The torque limiter contains five parameters that enable operation in the four quadrants.

Parameters C3.3.5.1.2 (Torque Q1), C3.3.5.1.3 (Torque Q2), C3.3.5.1.4 (Torque Q3) and C3.3.5.1.5 (Torque Q4) limit the torque independently in each motor operating quadrant (Fig. 9.10).




Figure 9.10: Convention of the motor torque limiters in the four motor operation quadrants

It is also possible to limit the motor torque with parameter C3.3.5.1.1 (Global Torque). This parameter has priority over the others and acts in all four quadrants simultaneously. Figure 9.11 shows the torque of the monitored motor to prevent it from exceeding the values set in C3.3.5.1.1 to C3.3.5.1.5. If the motor is in torque limitation, the motor speed will be reduced.




Figure 9.11: Torque behavior limited according to the settings

C3.3.5.1 Torque Limiter		
C3.3.5.1.1 Global Torque		
Range:	0.0 ... 400.0 %	Default: 125.0 %
Properties:		

Description:
It sets the maximum torque in the four motor operating quadrants. If it is necessary to control the torque in the four motor operating quadrants, parameters C3.3.5.1.2 to C3.3.5.1.5 must be used.

C3.3.5.1 Torque Limiter		
C3.3.5.1.2 Torque Q1		
Range:	0.0 ... 400.0 %	Default: 400.0 %
Properties:		

Description:
It sets the maximum torque of the motor running in the forward direction and in the 'motoring' operating condition.

C CONFIGURATIONS

C3.3.5.1 Torque Limiter

C3.3.5.1.3 Torque Q2

Range: 0.0 ... 400.0 %

Default: 400.0 %

Properties:

Description:

It sets the maximum torque of the motor running in the reverse direction and in the regenerating operating condition.

C3.3.5.1 Torque Limiter

C3.3.5.1.4 Torque Q3

Range: 0.0 ... 400.0 %

Default: 400.0 %

Properties:

Description:

It sets the maximum torque of the motor running in the forward direction and in the regenerating operating condition.

C3.3.5.1 Torque Limiter

C3.3.5.1.5 Torque Q4

Range: 0.0 ... 400.0 %

Default: 400.0 %

Properties:

Description:

It sets the maximum torque of the motor running in the reverse direction and in the 'motoring' operating condition.

C3.3.5.1 Torque Limiter

C3.3.5.1.6 Global Torque AI Config.

Range: 0 ... 30

Default: 0

Properties: Stopped

Description:

It enables the use and defines the analog input that will be used to limit the motor maximum torque. Table 9.20 on page 9-32 shows the options.

Table 9.20: Values assigned to the Analog Inputs of X and A...G Slots

Analog Inputs options for X and A...G Slots								
Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
AI1	X-1 (1)	A-1 (3)	B-1 (7)	C-1 (11)	D-1 (15)	E-1 (19)	F-1 (23)	G-1 (27)
AI2	X-2 (2)	A-2 (4)	B-2 (8)	C-2 (12)	D-2 (16)	E-2 (20)	F-2 (24)	G-2 (28)
AI3	—	A-3 (5)	B-3 (9)	C-3 (13)	D-3 (17)	E-3 (21)	F-3 (25)	G-3 (29)



NOTE!

Example: To choose Analog Input AI3 from Slot D, select D-3 (17) option.

C3.3.5.1 Torque Limiter

C3.3.5.1.7 Proportional Gain

Range: 0.00 ... 5.00

Default: 1.00

Properties:

Description:

It sets the proportional gain value of the Torque Limiter regulator. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

**NOTE!**

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.3.5.1.8.

C3.3.5.1 Torque Limiter**C3.3.5.1.8 Integral Gain**

Range: 0.00 ... 100.00

Default: 1.00

Properties:

Description:

It sets the integral gain value of the Torque Limiter regulator.

The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

C3.3.7 Speed Steady State Estimator

It allows viewing and changing the parameters related to the vector control steady state speed estimator.

C3.3.7 Speed Steady State Estimator**C3.3.7.1 Speed Setting**

Range: 0.10 ... 10.00

Default: 1.00

Properties:

Description:

It allows correcting the estimated speed error.

C3.3.7 Speed Steady State Estimator**C3.3.7.2 Regenerative Compensator**

Range: 0.00 ... 2.00

Default: 1.00

Properties:

Description:

It allows to correct the estimated speed in regenerative mode application. This parameter must be increased in starting applications with load in regenerative mode. This parameter must be changed only when it is not possible to perform start under load or speed reversal in regenerative mode operation.

C3.3.7 Speed Steady State Estimator**C3.3.7.3 Proportional Gain**

Range: 0.00 ... 10.00

Default: 1.00

Properties:

Description:

It sets the proportional gain value of the Steady State Speed Estimator. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

**NOTE!**

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.3.7.4.

C CONFIGURATIONS

C3.3.7 Speed Steady State Estimator

C3.3.7.4 Integral Gain

Range:	0.00 ... 10.00	Default: 1.00
Properties:		

Description:

It sets the integral gain value of the Steady Speed Observer. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications.

C3.3.7 Speed Steady State Estimator

C3.3.7.5 Synchronous Angle Filter

Range:	1 ... 15 ms	Default: 2 ms
Properties:		

Description:

Set the Low Pass Filter frequency of the speed observer .

This parameter has functionality only when using the encoder vector control. In case of small oscillations present in the electrical torque signal, gradually increase the parameter value.

C3.3.7 Speed Steady State Estimator

C3.3.7.6 Observer transition speed

Range:	0 ... 50 %	Default: 10 %
Properties:		

Description:

This parameter sets the transition speed of the speed observers.

The value of this parameter refers to the transition speed between the low-speed observer (high-frequency method) and the medium- and high-speed observer (linear method) for synchronous machines. This parameter is recalculated at the end of the Oriented Start-up. For PM motors, the calculation is given by:

$$\text{RPM}_{\text{transition}} = \frac{10 \% \times 1000 \times \text{C2.1.4}}{\text{C2.2.10}}$$

A hysteresis (10 %) is used around the adjusted value so that unwanted transitions between observers will not occur.

C3.3.7 Speed Steady State Estimator

C3.3.7.7 Home Position Displacement

Range:	-50 ... 50 °	Default: 0 °
Properties:		

Description:

This parameter sets the estimated rotor initial position value.

This Parameter is only available for vector control with encoder for synchronous machines.

C3.3.9 Online Parameters Estimator

ONLINE ELECTRICAL PARAMETER ESTIMATOR

It allows viewing and changing the configuration of the functions responsible for estimating, online, the electrical parameters of the motor.

The Xm Estimator determines the magnetic impedance of the induction motor according to the system load level. The Taus Estimator determines the stator time constant of the induction motor according to the system load level. These functions are essential for the proper operation of the sensorless vector control at low frequencies.

The Taur Estimator determines the rotor time constant of the induction motor according to the system load level. This function is exclusive to vector control with encoder.

C3.3.9 Online Parameters Estimator

C3.3.9.1 Estimator Configuration

Range: 0 ... 2 Bit

Default: 3

Properties:

Description:

It allows to configure specific function modules for online parametric estimation. The Xm Online Estimator determines the magnetic impedance of the induction motor. This function is enabled only for operating frequency above 15 % of the rated frequency set in C2.1.6. The Taus Online Estimator determines the stator time constant of the induction motor. This function is enabled only for operating frequency below 15 % of the rated frequency set in C2.1.6. The online Taur Estimator determines the rotor time constant of the induction motor. This function is enabled only for encoder vector control.



NOTE!

This online parametric estimation module is only enabled for induction motors.

Bit	Value/Description
Bit 0 Enable Xm Estimator	Enables the online estimator of the magnetizing impedance (Xm) of the three-phase induction motor. 0 = Disabled: Loop disabled 1 = Enabled: Loop enabled
Bit 1 Enable Taus Estimator	It enables the online estimator of the stator time constant (Taus) of the three-phase induction motor. 0 = Disabled: Loop disabled 1 = Enabled: Loop enabled
Bit 2 Enable Taur Estimator	It enables the online estimator of the rotor time constant (Taur) of the three-phase induction motor. 0 = Disabled: Loop disabled 1 = Enabled: Loop enabled

C3.3.10 Maximum torque by Ampere

It allows changing the parameters related to the Maximum Torque per Ampere (MTPA) function.

C3.3.10 Maximum torque by Ampere

C3.3.10.1 MTPA Manual Setting

Range: 0.00 ... 2.00

Default: 1.00

Properties:

Description:

It allows manually setting the system MTPA operating point.

C3.4 Current Limiter

It allows viewing and changing the parameters related to the motor current limiter.

The current limiting function prevents failures, avoiding the actuation of the overcurrent fault in the inverter, during starts or stops with very short ramps. The function is also important to protect the motor in case of an overload, when it is operating at constant speed.

1 - Characteristics of the current limiting function when the motor is accelerating or decelerating:

The current limiting function always operates when the motor current exceeds the value set in C3.4.1. During the acceleration or deceleration process, the current limiting function controls the motor acceleration or deceleration rate to prevent the motor current from exceeding the value of C3.4.1. Figure 9.12 illustrates the function operation process during the motor acceleration and deceleration process.

2 - Current limitation characteristics when the motor is operating at constant speed:




Figure 9.12: Current limitation during the acceleration and deceleration process

During the steady state, in which the motor is operating at constant speed, the current limiting function acts on the speed reference to prevent the motor current from exceeding the value set in C3.4.1. Thus, when the system is operating under overload and the motor current exceeds the value set in C3.4.1, the motor goes into a controlled deceleration process to prevent the motor current from exceeding the value of C3.4.1. When the overload process ends, the motor accelerates up to its reference speed. Figure 9.13 shows the current limiting function actuation process when the motor is running at constant speed.




Figure 9.13: Current limitation when the motor is running at constant speed

C3.4 Current Limiter

C3.4.1 Actuation Level

Range: 0 ... 300 %

Default: 125 %

Properties:

Description:

This parameter defines the maximum value of current in the motor during system operation. The full-scale is the nominal current of the motor defined in C2.1.5.

**NOTE!**

If the value set in C3.4.1 is greater than the inverter current, it will be automatically limited to the maximum current capacity of the inverter.

C3.4 Current Limiter**C3.4.3 Proportional Gain**

Range: 0.00 ... 5.00

Default: -

Properties: Model

Description:

This parameter sets the Proportional Gain of the controller present in the current limiting function. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications. For applications with very short acceleration or deceleration ramps, the gains must be set to improve the controllers response, if necessary. In this case, it is recommended to gradually increase C3.4.3.

For applications with very short acceleration or deceleration ramps, there may be a need for a small adjustment in the gains.

In this case, it is recommended that the value be gradually increased.

C3.4 Current Limiter**C3.4.4 Integral Gain**

Range: 0.00 ... 100.00

Default: 1.00

Properties:

Description:

This parameter defines the Integral Gain of the controller existing in the current limiting function. The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications. For applications with very short acceleration or deceleration ramps, the gains must be set to improve the controllers response, if necessary. In this case, it is recommended to gradually increase C3.4.4.

C3.4 Current Limiter**C3.4.5 Overcurrent Fault Level**

Range: 100 ... 250 %

Default: 175 %

Properties:

Description:

It sets the current level to generate the software overcurrent fault - F0073. Thus, when the motor current is greater than the value set in (C3.4.5), an overcurrent fault will be enabled. The full scale is the rated motor current set in C2.1.5.

**NOTE!**

Function available only for HSRM motor (C2.1.1 = 3).

C3.5 DC Link

It allows viewing and changing the parameters related to the DC link limiting function.

During very short stops, in systems with high inertia, it is natural that the load regenerates a great amount of energy to the DC link, causing an increase in the DC voltage level. The DC link limiting function prevents the bus voltage from exceeding the value set in C3.5.2.1 for scalar and VVW+ control or C3.5.3.2 for vector control and causing overvoltage on the inverter.

1 - Characteristics of the DC link limiting function when the motor is decelerating:

The DC link limiting function changes the motor deceleration rate to control the increase in the bus voltage during the motor deceleration. Figure 9.14 illustrates the behavior of the function during the motor deceleration.




Figure 9.14: DC link limitation during deceleration process

2 - Characteristics of the DC link limiting function when the motor is operating at constant speed:

In certain applications, it is common for the load to operate in regenerative mode and the motor to be operating at constant speed. In this case, the DC link limiting function protects the inverter against bus overvoltage. Figure 9.15 illustrates the behavior of the function when the motor is operating at constant speed and the load in regenerative mode. In this situation, the DC link limiting function decelerates the motor in a controlled manner to prevent the bus voltage from exceeding the value set in C3.5.2.1 for scalar and VVW+ control or C3.5.3.2 for vector control. After the DC link voltage level returns to its rated value, the function accelerates the motor so that it returns to the speed set in S2.1.1.




Figure 9.15: DC link limitation when the motor is operating at constant speed

C3.5.1 Voltage limit

It allows setting the DC link voltage limiting function for all control types.

C3.5.1 Voltage limit

C3.5.1.1 Enable Function

Range: 0 ... 1 **Default:** 1

Properties:

Description:

It enables the DC Link Limiting function.

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function

C3.5.2 Scalar control

It allows viewing and changing the parameters related to the scalar and VVW+ control of the DC link voltage limiting function.

C3.5.2 Scalar control

C3.5.2.1 DC link limitation activation level

Range: 114.0 ... 130.0 % **Default:** 120.0 %

Properties:

Description:

Defines the actuation level of the DC link limitation function in scalar and VVW+ control types.

Adjustment of the value of C3.5.2.1:

The value of C3.5.2.1 corresponds to a percentage of the Nominal DC Bus Voltage.

The nominal DC link voltage of the cells is given by $690V \times 1.35 = 931V$.

If the inverter continues to block due to overvoltage on the DC link during deceleration, gradually reduce the value of C3.5.2.1 or increase the deceleration ramp time C6.1.2 or C6.1.5.

If the power supply is permanently at such a voltage level that it results in a DC link voltage value greater than the setting of C3.5.2.1, it will not be possible to decelerate the motor. In this case, reduce the mains voltage or increase the value of C3.5.2.1.

C3.5.2 Scalar control

C3.5.2.2 DC Link Volt. Lim.-Kp Gain

Range: 0.00 ... 9.99 **Default:** 0.15

Properties:

Description:

It sets the value of the DC link voltage regulator proportional gain.

The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications. In the case of applications with very short deceleration ramps, a small adjustment in the gains may be necessary. In this case, it is recommended that you gradually increase its value.

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.5.2.3.

C CONFIGURATIONS

C3.5.2 Scalar control

C3.5.2.3 DC Link Volt. Lim.-Ki Gain

Range: 0.000 ... 5.000

Default: 1.000

Properties:

Description:

It sets the integral gain value of the DC link voltage regulator.

The gain values of this controller are automatically set by the inverter, not requiring adjustment for general purpose applications. In the case of applications with very short deceleration ramps, a small adjustment in the gains may be necessary. In this case, it is recommended that you gradually increase its value.

C3.5.2 Scalar control

C3.5.2.4 DC Link Volt. Lim.-Est. Gain

Range: 0.000 ... 9.999

Default: 0.000

Properties:

Description:

Sets the DC link oscillation stabilizer gain.

This function works together with the controller used in the DC link limiting function. In applications where the deceleration ramp is very short, and the system inertia is high, it is common to have consistent oscillations in the DC link. bus In this case, this parameter adjusts the stabilizer gain to dampen DC link oscillations.

Its value must be gradually increased when the system presents sustained oscillations on the DC link. If there is no consistent effect, you must increase the value of the deceleration ramp C6.1.2 or C6.1.5.

C3.5.3 Vector Control

It allows viewing and changing parameters related to vector control.

C3.5.3 Vector Control

C3.5.3.1 Optim. Braking Func. Enable

Range: 0 ... 1

Default: 0

Properties:

Description:

It selects the type of braking used in the vector control for induction machines. Braking with losses (Optimal Braking) increases the stator current in the motor to increase losses during the deceleration period.



NOTE!

The process carried out by this type of braking increases the acoustic noise in the environment.

Indication	Description
0 = No	Disable function
1 = Yes	It enables function

C3.5.3 Vector Control

C3.5.3.2 DC Link Volt. Lim.-Level

Range: 114.0 ... 160.0 %

Default: 120.0 %

Properties:

Description:

It sets the DC link limiting function actuation level in the vector control.

Setting of the value of C3.5.3.2:

The value of C3.5.3.2 corresponds to a percentage of the DC Link Rated Voltage.

The DC Link Rated Voltage is typically given by $V_{\text{power supply}} \cdot 1.35$.

If the inverter keeps locking due to DC link overvoltage during deceleration, gradually reduce the value of C3.5.3.2 or increase the deceleration ramp time C6.1.2 or C6.1.5.

If the power supply is permanently at a voltage level so that it results in a DC link voltage value above the setting of C3.5.3.2, it will not be possible to decelerate the motor. In this case, reduce the supply voltage or increase the value of C3.5.3.2.

C3.5.3 Vector Control

C3.5.3.3 DC Link Volt. Lim.-Kp Gain

Range: 0.00 ... 6.39

Default: 0.30

Properties:

Description:

It sets the value of the DC link voltage regulator proportional gain.

The gain values of this controller are automatically adjusted by the inverter and do not need to be adjusted for general purpose applications. For applications with very short deceleration ramps, a small adjustment in the gains may be necessary. In this case, it is recommended that you gradually increase their value.

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.5.3.4.

C3.5.3 Vector Control

C3.5.3.4 DC Link Volt. Lim.-Ki Gain

Range: 0.000 ... 1.000

Default: 0.030

Properties:

Description:

It sets the integral gain value of the DC link voltage regulator.

The gain values of this controller are automatically adjusted by the inverter and do not need to be adjusted for general purpose applications. For applications with very short deceleration ramps, a small adjustment in the gains may be necessary. In this case, it is recommended that you gradually increase their value.

C3.5.4 Modulation compensation

Allows you to view and change parameters related to modulation compensation.

C3.5.4 Modulation compensation

C3.5.4.1 Output voltage compensation

Range: 0 ... 2

Default: 1

Properties:

Description:

Output voltage compensation applied to the motor as a function of the DC link voltages.

Indication	Description
0 = Inactive	Function inactive
1 = Active (method 1)	Compensation executed considering the total voltage of each phase independently; when there is parallelism of arms, the associated phases in parallel are treated individually
2 = Active (method 2)	Phases in parallel are treated as if they were just one phase, with the busbar voltage added

C3.5.4 Modulation compensation		
C3.5.4.2 DC link filter time constant		
Range:	0.0 ... 999.9 ms	Default: 13.3 ms
Properties:		

Description:
Adjusts the time constant of the first order filter applied to the total DC-link voltage signal.

Each phase has an individual DC-link; consequently, there will be three filters - one for each phase.

If the parameter value is null, the DC-link voltage will no longer be filtered, that is, its instant value will be used in the compensation.

Not used if parameter C3.5.4.1 = Inative.

C3.8 Flying Start

The Flying Star function allows driving a motor that is in free spinning, accelerating it from the speed in which it is. This function is suitable for applications in which the system inertia is very high, and the time for the motor to stop is very high. In this case, if the motor is started, there may be a high energy regeneration to the DC link. Such energy regeneration may cause overcurrent and thus the actuation of the overcurrent fault at the start. Thus, the Flying Start function must be used to identify the actual rotor speed and, from that, start the motor from the actual rotor speed. Figure 9.16 illustrates the Flying Start function actuation process in a simplified way.




Figure 9.16: Illustrative scheme of the Flying Start function

The Flying Start function performs a scan by applying a speed reference to determine the rotor speed. Figure 9.17 illustrates the method that the Flying Start function uses to determine the rotor speed. The scan starts from the value defined in C4.3.1.1.2 (maximum speed) and ends at zero. The first scan is carried out in the same direction as the motor direction of rotation command. If the rotor speed is not determined, a second scan is performed in the opposite direction of the direction of rotation command. At the end of this process, if the rotor speed is not determined, the function considers that the motor is stopped and ends the determination process.




Figure 9.17: Illustrative scheme of the rotor speed determination by the Flying Start function

C3.8.1 Configuration

It allows configuring the Flying Start function according to the system application type.

C3.8.1 Configuration		
C3.8.1.1 Function Reset		
Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:
It selects the type of Reset for the Flying Start function. Reset = Start/Stop causes the Flying Start function to act whenever the motor is started. Reset = General Enable causes the Flying Start function to act only when the inverter is general enabled.

Indication	Description
0 = General Enable	Enable Reset by General Enable
1 = Run/Stop	It enables Reset by Run/Stop

C3.8.1 Configuration		
C3.8.1.2 Tracking		
Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:
It allows locking the Flying Start function to track the rotor speed in the opposite direction to that defined in the motor direction of rotation command. See Figure 9.18 for further details.




Figure 9.18: Illustrative scheme of the rotor speed identification by the Flying Start function

Indication	Description
0 = Two Trackings	It tracks the speed in both directions of rotation
1 = One Tracking	It tracks the speed in only one direction of rotation

C CONFIGURATIONS

C3.8.1 Configuration

C3.8.1.3 Ramp

Range:	0.2 ... 60.0 s	Default: 10.0 s
Properties:		

Description:

It sets the rotor speed determination time. See Figure 9.17 for more details.

C3.8.1 Configuration

C3.8.1.4 Dead time

Range:	1.0 ... 40.0 s	Default: 10.0 s
Properties:		

Description:

Sets the dead time, or coast time, of the motor.

This time represents the period in which the motor rotor remains magnetized after the power supply ceases.

For a flying start, the coast time is counted before the motor can be started again after PWM is disabled.

C3.8.1 Configuration

C3.8.1.5 Enable Function

Range:	0 ... 1	Default: 0
Properties:		

Description:

It enables the Flying Start function.

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function

C3.8.1 Configuration

C3.8.1.6 Disable Flying Start

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used to disable the Flying Start function. Table 9.37 on page 9-57 shows the options.

C3.8.2 Scalar control

Flying Start function settings for scalar control.

C3.8.2 Scalar control

C3.8.2.1 Current

Range:	0.0 ... 100.0 %	Default: 70.0 %
Properties:		

Description:

Inverter current limitation during execution of the flying start function.

The current is expressed as a percentage of the motor's nominal current, defined in C2.1.5.

If the motor's rated current is greater than the inverter's rated current, the inverter's rated current will be used as a basis, seeking to avoid the occurrence of overcurrent faults.

C3.8.3 Vector Control

Flying Start function settings for vector control.

C3.8.3 Vector Control		
C3.8.3.1 Flux Reference		
Range:	0.0 ... 100.0 %	Default: 85.0 %
Properties:		

Description:
It defines the reference flux level that the Flying Start function will impose on the motor during the determination process. The flux level is a percentage of the motor rated flux.

C3.9 Ride-Through

The Ride-Through function makes it possible to recover the inverter, without undervoltage lockout, when there is a drop in the power supply for a short time.

Figure 9.19 illustrates the behavior of the Ride-Through function during a period of voltage drop in the power supply. At this moment, the inverter DC link voltage starts to decrease. Thus, the Ride-Through function starts decelerating the motor in a controlled way to regenerate energy to the DC link and keep the inverter active for a short period of time. After the power supply is restored, the motor is accelerated to the value set in C4.3.1.




Figure 9.19: Illustrative diagram of the Ride-Through function operation

C3.9.1 Configuration

Settings of the Ride-Through function for all control types.

C3.9.1 Configuration		
C3.9.1.1 Function Enable		
Range:	0 ... 1	Default: 0
Properties:		

Description:
It allows enabling the Ride-Through function.

C CONFIGURATIONS

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function

C3.9.1 Configuration

C3.9.1.3 Maximum Ride-Through time

Range:	0.5 ... 100.0 s	Default: 20.0 s
Properties:		

Description:

Defines the maximum time that the inverter can remain in Ride-Through condition before the fault occurs F0309.

The time count starts when there is a condition to enter the Ride-Through (see C3.9.1.1 and C3.9.1.3).

If the maximum time is reached during a pre-charge, while the inverter is performing the Ride-Through with interruption, the timeout will be extended until after the grid return check at the end of the pre-charge.

C3.9.2 Scalar control

Settings of the Ride-Through function for scalar and VVW+ control.

C3.9.2 Scalar control

C3.9.2.1 DC Link Volt.-Ride-Through

Range:	76.0 ... 95.0 %	Default: 82.5 %
Properties:		

Description:

It sets the voltage regulation level on the DC link for the Ride-Through function, which allows the inverter to keep running.

The value of C3.9.2.1 corresponds to a percentage of the DC Link Rated Voltage.



NOTE!

The DC link undervoltage fault occurs at 70 % of the DC Link Rated Voltage.

C3.9.2 Scalar control

C3.9.2.2 Ride-Through-Gain Kp

Range:	0.00 ... 2.00	Default: 0.50
Properties:		

Description:

It sets the proportional gain value of the DC link voltage regulator of the Ride-Through function.

The gain values of this controller are automatically adjusted by the inverter and do not need to be adjusted for general purpose applications. For applications with very short deceleration ramps, a small adjustment in the gains may be necessary. In this case, it is recommended that you gradually increase their value.

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.9.2.3.

C3.9.2 Scalar control

C3.9.2.3 Ride-Through-Gain Ki

Range:	0.000 ... 1.000	Default: 0.050
Properties:		

Description:

This parameter sets the integral gain of the DC link voltage regulator of the Ride-Through function.

The gain values of this controller are automatically adjusted by the inverter and do not need to be adjusted for general purpose applications. For applications with very short acceleration or deceleration ramps, a small adjustment in the gains may be necessary. In this case, it is recommended that you gradually increase their value.

C3.9.3 Vector control

Settings of the Ride-Through function for vector control.

C3.9.3 Vector control

C3.9.3.1 DC Link Volt.-Ride-Through

Range: 76.0 ... 95.0 %

Default: 82.5 %

Properties:

Description:

It sets the voltage regulation level on the DC link for the Ride-Through function, which allows the inverter to keep running.

The value of C3.9.3.1 corresponds to a percentage of the DC Link Rated Voltage.



NOTE!

This parameter works together with parameters C3.9.3.2 and C3.9.3.3 for the Ride-Through function in vector control.



NOTE!

The DC link undervoltage fault occurs at 70 % of the DC Link Rated Voltage.

C3.9.3 Vector control

C3.9.3.2 Ride-Through-Gain Kp

Range: 0.00 ... 2.00

Default: 0.10

Properties:

Description:

It sets the proportional gain value of the DC link voltage regulator of the Ride-Through function.

The gain values of this controller are automatically adjusted by the inverter and do not need to be adjusted for general purpose applications. For applications with very short deceleration ramps, a small adjustment in the gains may be necessary. In this case, it is recommended that you gradually increase their value.

If you need to change the gains of this controller, it is suggested that you first gradually increase the value of C3.9.3.3.

C3.9.3 Vector control

C3.9.3.3 Ride-Through-Gain Ki

Range: 0.000 ... 1.000

Default: 0.050

Properties:

Description:

This parameter sets the integral gain of the DC link voltage regulator of the Ride-Through function.

The gain values of this controller are automatically adjusted by the inverter and do not need to be adjusted for general purpose applications. For applications with very short acceleration or deceleration ramps, a small adjustment in the gains may be necessary. In this case, it is recommended that you gradually increase their value.

C3.11 Synchronous transfer

The synchronous transfer function enables the motor to be accelerated via the inverter to the nominal operating frequency, and then transferred to the power supply network.

In this way, it is possible to eliminate the effects of the starting current related to a direct start from the network.




Figure 9.20: Synchronous transfer diagram.




Figure 9.21: Operation diagram of the synchronous transfer function.

C3.11 Synchronous transfer

C3.11.1 Enable Function

Range:

0 ... 2

Default: 0

Properties:

Description:
Allows you to enable the synchronous transfer function.

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function
2 = Enable with regulation	Enables function with speed regulation

C3.11 Synchronous transfer**C3.11.2 Synchronism time****Range:** 0.0 ... 20.0 s**Default:** 1.0 s**Properties:****Description:**

Minimum time that the inverter must keep the phase error between the grid voltage and the inverter output voltage lower than the programmed time to signal OK synchronization.

C3.11 Synchronous transfer**C3.11.3 Synchronism timeout****Range:** 20 ... 240 s**Default:** 60 s**Properties:****Description:**

Grid synchronization timeout.

C3.11 Synchronous transfer**C3.11.4 Delay****Range:** 20 ... 3000 ms**Default:** 170 ms**Properties:****Description:**

Delay to disable the inverter after the transfer command to the grid, preventing the motor from remaining without voltage for a period of time.

C3.11 Synchronous transfer**C3.11.5 Maximum phase error****Range:** 0.0 ... 60.0 °**Default:** 5.0 °**Properties:****Description:**

Phase error between grid and inverter voltage used in conjunction with synchronization time to indicate OK synchronization.

C3.11 Synchronous transfer**C3.11.6 Speed limit****Range:** 0 ... 400**Default:** 18**Properties:****Description:**

Sets the maximum speed for synchronous transfer search based on the motor nominal frequency.

C3.11 Synchronous transfer**C3.11.7 Kp****Range:** 1 ... 500**Default:** 200**Properties:****Description:**

Proportional gain of the output voltage synchronization regulator with the mains voltage.

C3.11 Synchronous transfer**C3.11.8 Ti****Range:** 0.01 ... 20.00**Default:** 0.20**Properties:**

C CONFIGURATIONS

Description:

Integral time of the output voltage synchronization regulator with the mains voltage.

C3.11 Synchronous transfer

C3.11.9 Phase adjustment

Range: -180.0 ... 180.0 °

Default: 0.0 °

Properties:

Description:

It compensates for the phase error between the voltage that the inverter uses as a reference for synchronization and the actual voltage at the point where the transfer will occur.

C3.11 Synchronous transfer

C3.11.10 Minimum angle error to start the search

Range: 0 ... 360 °

Default: 10 °

Properties:

Description:

C3.11 Synchronous transfer

C3.11.11 Status

Range: 0 ... 4 Bit

Default: 0

Properties:

Description:

Bit	Value/Description
Bit 0 Function enabled	0 = No: Synchronous transfer disabled 1 = Yes: Synchronous transfer enabled
Bit 1 Synchronization command	0 = Not used: Not used 1 = Not used: Not used
Bit 2 ... 4 Synchronization status	0 = Inactive: Function disabled or missing synchronization command 1 = Checking synchronization: Waiting for minimum conditions for synchronization, minimum speed and in the same direction between input and output 2 = Pre-speed regulation: Adjusting the output frequency to reduce error relative to the input 3 = Pre-angular position regulation: Perturbing the output frequency to reduce the absolute error of the angle between output and input 4 = Angular position regulation: Perturbing the output frequency to reduce the absolute error of the angle between output and input 5 = Synchronized: Output angular position equal to input 6 = Timeout: Unable to adjust angle within maximum configured time

C3.14 Zero speed disable

The zero speed condition determines whether the drive is at zero speed based on the RUN command, speed ramp status, speed reference, and measured speed, according to the function settings.

C3.14 Zero speed disable

C3.14.1 Configuration

Range: 0 ... 2

Default: 1

Properties:

Description:

Allows you to configure the zero speed condition to enable the inverter PWM.

Indication	Description
0 = Inactive	PWM is enabled according to the user's PWM enable commands
1 = Reference and speed detection	The condition to enable PWM depends on the user's ENABLE command and the zero speed condition based on the RUN command, the reference and the measured speed
2 = Detection by reference	The condition to enable PWM depends on the user's ENABLE command and the zero speed condition based on the RUN command and the speed reference

C3.14 Zero speed disable**C3.14.2 Time to block****Range:** 0.00 ... 600.00 s**Default:** 0.00 s**Properties:****Description:**

Determines the time that the zero speed condition must remain active for PWM to be disabled.

If the condition is broken, the count restarts at the moment the configured conditions are met again.

C3.14 Zero speed disable**C3.14.3 Level for zero speed****Range:** 0.0 ... 100.0 %**Default:** 1.0 %**Properties:****Description:**

Determines the reference level and measured speed for detecting the zero speed condition.

The value is expressed as a percentage of the motor's synchronous speed.

C4 COMMANDS AND REFERENCES

It allows configuring the source of the frequency inverter commands and references in Local or Remote control mode.

The MVW has two control modes:

- **Local Mode:** When the inverter is operating in local control mode, all commands and reference are made via HMI (see S1.6.2 and C4.3.1.3.1). The HMI LOC/REM key allows switching between Local and Remote 1 / Remote 2 control modes. It can be set in C4.1.3.
- **Remote 1 / Remote 2 Mode:** In Remote 1 or Remote 2 mode, you can configure the inverter reference and command sources from the following options: communication networks, HMI, digital input and/or analog input.

C4.1 LOC/REM Mode Config.

It allows configuring what will define the local and remote operating mode. If set via digital input, you can choose the specific digital input for this function.

Options that do not depend on operating modes will be explained later.

C4.1 LOC/REM Mode Config.**C4.1.1 Command mode****Range:** 0 ... 9**Default:** 9**Properties:** Stopped**Description:**

It defines a fixed command mode (Local, Remote 1 or Remote 2) or the source that can change between Remote 1 and Remote 2 modes. Local mode can be only accessed through this parameter when it is set to Always Local. All other sources can only switch between Remote 1 and Remote 2 modes.

C CONFIGURATIONS

Indication	Description
0 = Always Local	Fixed in Local command mode
1 = Remote 1	Fixed in Remote 1 command mode
2 = Remote 2	Fixed in Remote 2 command mode
3 = Serial	Change via R1/R2 Mode command of the RS-485 Serial Control Word (S5.2.2)
4 = Anybus	Change via R1/R2 Mode command of the Anybus-CC Control Word
5 = CAN/CO/DN	Change via R1/R2 Mode command of the CAN/CANop/DNet Control Word (S5.7.2)
6 = SoftPLC	Change via SoftPLC command
7 = Not used	Not used
8 = Ethernet	Change via R1/R2 Mode command of the Ethernet Control Word (S5.3.2)
9 = Digital Input (DI)	Change via command of the digital input chosen by the user The digital input can be configured in C4.1.2



NOTE!

Example: By selecting the command source of this parameter as Serial, the Mode R1/R2 bit of the RS-485 Serial command word in S5.2.2 will cause the inverter to transition between Remote 1 and Remote 2.

C4.1 LOC/REM Mode Config.

C4.1.2 DI Remote 1/Remote 2

Range: 0 ... 62

Default: 2

Properties: Stopped

Description:

Defines which digital input will transition between Remote 1 or Remote 2 mode or vice versa.

Digital Inputs options for X and A...G Slots

Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
DI1	X-1 (1)	A-1 (7)	B-1 (15)	C-1 (23)	D-1 (31)	E-1 (39)	F-1 (47)	G-1 (55)
DI2	X-2 (2)	A-2 (8)	B-2 (16)	C-2 (24)	D-2 (32)	E-2 (40)	F-2 (48)	G-2 (56)
DI3	X-3 (3)	A-3 (9)	B-3 (17)	C-3 (25)	D-3 (33)	E-3 (41)	F-3 (49)	G-3 (57)
DI4	X-4 (4)	A-4 (10)	B-4 (18)	C-4 (26)	D-4 (34)	E-4 (42)	F-4 (50)	G-4 (58)
DI5	X-5 (5)	A-5 (11)	B-5 (19)	C-5 (27)	D-5 (35)	E-5 (43)	F-5 (51)	G-5 (59)
DI6	X-6 (6)	A-6 (12)	B-6 (20)	C-6 (28)	D-6 (36)	E-6 (44)	F-6 (52)	G-6 (60)
DI7	—	A-7 (13)	B-7 (21)	C-7 (29)	D-7 (37)	E-7 (45)	F-7 (53)	G-7 (61)
DI8	—	A-8 (14)	B-8 (22)	C-8 (30)	D-8 (38)	E-8 (46)	F-8 (54)	G-8 (62)

Table 9.31: Values assigned to the Digital Inputs of X and A...G Slots for Remote 1 / Remote 2 mode setting



NOTE!

Example: To choose digital input 2 of Slot B to switch between Remote 1 / Remote 2 mode, the parameter must be assigned the value B-2 (16).

C4.1 LOC/REM Mode Config.

C4.1.3 HMI LOC/REM Key

Range: 0 ... 1

Default: 1

Properties: Stopped

Description:

Defines the function of the LOC/REM HMI key. Pressing the  key toggles the command mode between Local (HMI) and the mode configured in C4.1.1 (Remote 1 or Remote 2). When the command mode is set to Local, all commands and references are performed via the HMI.

Indication	Description
0 = Disable	The  key is disabled
1 = Enable	The  key, toggles between Local and Remote command mode

C4.2 Commands

It allows setting the command source of the frequency inverter to Remote 1 or Remote 2 mode.

C4.2.1 Remote R1**C4.2.2 Remote R2**

It allows setting the source to the command mode.

C4.2.1 Remote R1**C4.2.2 Remote R2****.1 General Enable**

Range: 0 ... 8 **Default:** 1 (C4.2.1.1)

0 (C4.2.2.1)

Properties: Stopped

Description:

It sets the source for the general enable command.




Figure 9.22: Operation of the general enable command

**ATTENTION!**

The general enable command can contain a digital input (C4.2.3.1) that works together with the command source chosen in this menu. Both must be active/inactive simultaneously for the command to take place. For example, when you choose the command source as serial in the Remote 1 situation and any digital input, for the inverter to be enabled, the digital input and the serial input must be active. If either input (digital or serial) is inactive, the inverter will be general disabled. See S1.6.1.

Indication	Description
0 = Always enabled	General Enable command is always active Regardless of the digital input configured in C4.2.3.1
1 = HMI	General Enable command via HMI is always active
2 = Serial	General Enable command via RS-485 Serial Control Word
3 = Anybus	General Enable command via Anybus-CC Control Word

Indication	Description
4 = CAN/CO/DN	General Enable command via CAN/CANop/DNet Control Word
5 = SoftPLC	General Enable command via SoftPLC function
6 = Not used	Not used
7 = Ethernet	General Enable command via Ethernet Control Word
8 = Digital Input (DI)	General Enable command via digital input chosen by the user Digital input can be configured in C4.2.3.1

C4.2.1 Remote R1

C4.2.2 Remote R2

.2 Run/Stop

Range: 0 ... 9 **Default:** 0 (C4.2.1.2)

7 (C4.2.2.2)

Properties: Stopped

Description:

Sets the source for the start and stop commands, which encompass run/stop and quick stop.




Figure 9.23: Operation of the run/stop command




Figure 9.24: Operation of the quick stop command



ATTENTION!

The quick stop command may contain a digital input (C4.2.3.7) which acts in conjunction with the command source chosen in this menu. Both must be active/inactive simultaneously for the command to take place. For example, when you choose the command source as serial in Remote 1 mode and any digital input, for the inverter to be without quick stop, the digital input and the serial input must be active. If either input (digital or serial) is inactive, the quick stop command is executed. See S1.6.1.

Indication	Description
0 = HMI I/O Keys	Run/Stop command via HMI keys  and  In this case, the stop mode is always by ramp
1 = Serial	Enable Ramp and Quick Stop Command via RS-485 Serial Control Word
2 = Anybus	Enable Ramp and Quick Stop Command via Anybus-CC Control Word
3 = CAN/CO/DN	Enable Ramp and Quick Stop Command via CAN/CANop/DNet Control Word
4 = SoftPLC	Enable Ramp and Quick Stop Command via SoftPLC function
5 = Not used	Not used
6 = Ethernet	Enable Ramp and Quick Stop Command via Ethernet Control Word
7 = Run/Stop DI	Run/Stop command via digital input chosen by the user The digital input can be set in C4.2.3.2
8 = Forward/Reverse DI	Run/Stop command selected when using the Forward/Reverse function via digital inputs Digital inputs can be set in C4.2.3.5 and C4.2.3.6
9 = 3-Wire Start/Stop DI	Run/Stop command selected when using the 3-Wire Start/Stop function Digital inputs can be set in C4.2.3.3 and C4.2.3.4

C4.2.1 Remote R1**C4.2.2 Remote R2****.3 Direction of Rotation**

Range:	0 ... 10	Default: 1 (C4.2.1.3) 0 (C4.2.2.3)
Properties:	Stopped	

Description:

It sets the source for the direction of rotation command.




Figure 9.25: Operation of the direction of rotation command

Indication	Description
0 = Forward	Forward direction of rotation only. It is not possible to reverse the direction of rotation
1 = HMI DR Key	Rotation Direction control via HMI key  Forward Direction is selected at power up
2 = Serial	Reverse Command via RS-485 Serial Control Word
3 = Anybus	
4 = CAN/CO/DN	Reverse Command via CAN/CANop/DNet Control Word
5 = SoftPLC	Direction of Rotation Command via SoftPLC function
6 = Not used	Not used
7 = Ethernet	Reverse Command via Ethernet Control Word
8 = Direction of Rotation DI	Direction of Rotation command via user-selected digital input The digital input can be configured at C4.2.3.8
9 = Forward/Reverse DI	Direction of Rotation command selected when using the Forward/Reverse function via digital inputs The digital inputs can be configured in C4.2.3.5 and C4.2.3.6

C CONFIGURATIONS

Indication	Description
10 = Speed Reference	Direction of Rotation command defined by the polarity of the speed reference

C4.2.1 Remote R1

C4.2.2 Remote R2

.4 JOG

Range:	0 ... 8	Default: 1 (C4.2.1.4) 0 (C4.2.2.4)
Properties:	Stopped	

Description:

It sets the source for the JOG command.




Figure 9.26: Operation of the JOG command

Indication	Description
0 = Inactive	JOG command disabled
1 = HMI JOG Key	JOG command via HMI key 
2 = Serial	JOG command via RS-485 Serial Control Word
3 = Anybus	JOG command via Anybus-CC Control Word
4 = CAN/CO/DN	JOG command via CAN/CANop/DNet Control Word
5 = SoftPLC	JOG command via SoftPLC function
6 = Not used	Not used
7 = Ethernet	JOG command via Ethernet Control Word
8 = Digital Input (DI)	JOG command via digital input chosen by the user The digital input can be set in C4.2.3.9

C4.2.3 DI for commands

It allows defining the digital input used for each command with source via digital input. For further information on the control word via DI, see S1.6.3.

C4.2.3 DI for commands

C4.2.3.1 General Enable

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

Enables use and defines the digital input that will be used to enable the drive to run. The options are shown in the Table 9.37 on page 9-57.

Digital Inputs options for X and A...G Slots

Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
DI1	X-1 (1)	A-1 (7)	B-1 (15)	C-1 (23)	D-1 (31)	E-1 (39)	F-1 (47)	G-1 (55)
DI2	X-2 (2)	A-2 (8)	B-2 (16)	C-2 (24)	D-2 (32)	E-2 (40)	F-2 (48)	G-2 (56)
DI3	X-3 (3)	A-3 (9)	B-3 (17)	C-3 (25)	D-3 (33)	E-3 (41)	F-3 (49)	G-3 (57)
DI4	X-4 (4)	A-4 (10)	B-4 (18)	C-4 (26)	D-4 (34)	E-4 (42)	F-4 (50)	G-4 (58)
DI5	X-5 (5)	A-5 (11)	B-5 (19)	C-5 (27)	D-5 (35)	E-5 (43)	F-5 (51)	G-5 (59)
DI6	X-6 (6)	A-6 (12)	B-6 (20)	C-6 (28)	D-6 (36)	E-6 (44)	F-6 (52)	G-6 (60)
DI7	—	A-7 (13)	B-7 (21)	C-7 (29)	D-7 (37)	E-7 (45)	F-7 (53)	G-7 (61)
DI8	—	A-8 (14)	B-8 (22)	C-8 (30)	D-8 (38)	E-8 (46)	F-8 (54)	G-8 (62)

Table 9.37: Values assigned to the Digital Inputs of X and A...G Slots for defining command activation

**NOTE!**

Example: To choose digital input 4 of Slot C to trigger a command, the parameter must be assigned the value C-4 (26).

C4.2.3 DI for commands**C4.2.3.2 Run/Stop**

Range:	0 ... 62	Default: 1
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used to execute the start and stop commands. The options are shown in Table 9.37 on page 9-57.

C4.2.3 DI for commands**C4.2.3.3 3-Wire Start**

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used to execute the “Start” command of the 3-wire Start/Stop function. The options are shown in Table 9.37 on page 9-57.




Figure 9.27: 3-wire Start/Stop function via digital input

C4.2.3 DI for commands		
C4.2.3.4 3-Wire Stop		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the “Stop” command of the 3-wire Start/Stop function. The options are shown in Table 9.37 on page 9-57.

Figure 9.27 on page 9-57 illustrates the operation of the Start/Stop function.

C4.2.3 DI for commands		
C4.2.3.5 Forward		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the “Forward” command of the Forward/Reverse function.




Figure 9.28: Forward and Reverse function via digital input

C4.2.3 DI for commands		
C4.2.3.6 Reverse		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the “Reverse” command of the Forward/Reverse function. Table 9.37 on page 9-57 shows the options.

Figure 9.28 on page 9-58 illustrates the operation of the Forward/Reverse function.



NOTE!
When using the Forward/Reverse function, set C4.2.1.2 and C4.2.1.3= 8 or C4.2.2.2 and C4.2.2.3 = 8.

C4.2.3 DI for commands		
C4.2.3.7 Quick Stop		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the inverter quick stop. Table 9.37 on page 9-57 shows the options.

The Quick Stop consists of executing the “Stop” with null deceleration ramp command (C6.1.6 = 0s) or close to this value, regardless of the setting in C6.1.2 or C6.1.5. It is not recommended to use this function in scalar and VVW+ control types.




Figure 9.29: Operation of the Quick Stop command

C4.2.3 DI for commands		
C4.2.3.8 Direction of Rotation		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the direction of rotation command. Table 9.37 on page 9-57 shows the options.

C4.2.3 DI for commands		
C4.2.3.9 JOG		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the JOG command. Table 9.37 on page 9-57 shows the options.

C4.2.3 DI for commands		
C4.2.3.10 Ramp Selection		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used to execute the Second Ramp command. Table 9.37 on page 9-57 shows the options.

C4.2.3 DI for commands		
C4.2.3.11 Fault Reset		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used for the Fault Reset command. Table 9.37 on page 9-57 shows the options.

When a transition from 0 to 1 occurs on the digital input programmed for Fault Reset, the present fault reset command is executed. If the fault condition is still present, the reset will not be performed. Figure 9.30 on page 9-60 illustrates that.




Figure 9.30: Operation of the Fault Reset command

C4.2.4 Local HMI

It allows defining the behavior of commands via HMI.

C4.2.4 Local HMI		
C4.2.4.1 Stop Key Function		
Range:	0 ... 2	Default: 0
Properties:	Stopped	

Description:
It sets the motor stop mode for the HMI stop key.

This parameter indicates the method to be performed to stop the motor when the inverter is programmed to be commanded via HMI key.

The available stop modes are:

- Ramp to stop: the inverter uses the time defined in parameter C6.1.2 or C6.1.5 to perform the deceleration ramp.
- General Enable to Stop: the inverter instantly deactivates the general enable. In this mode, there is no set time for the motor to stop.
- Quick stop: the inverter uses the time set in parameter C6.1.6 to perform the deceleration ramp.



NOTE!
The general enable to stop mode works only if the general enable parameter (C4.2.1.1 for R1 mode and C4.2.2.1 for R2 mode) is set to HMI.

C4.3 References

It allows configuring the source and the speed and torque reference values for Remote 1 and Remote 2 modes. In Local mode, the speed reference via HMI will always be used.

C4.3.1 Speed

It allows setting the reference values for the motor speed.

C4.3.1.1 Reference range

It allows setting minimum and maximum speed reference values for any reference signal. If the reference signal set to be followed by the inverter is less than the minimum reference setting in C4.3.1.1.1, the inverter will limit to C4.3.1.1.1. If the reference signal set to be followed by the inverter is greater than the maximum reference setting in C4.3.1.1.2, the inverter will limit to C4.3.1.1.2.

C4.3.1.1 Reference range

C4.3.1.1.1 Minimum Reference

Range: 0 ... 60000 rpm

Default: 90 rpm

Properties:

Description:

It sets the minimum motor speed reference limit value when the inverter is enabled. Valid for any type of reference signal.

C4.3.1.1 Reference range

C4.3.1.1.2 Maximum Reference

Range: 1 ... 60000 rpm

Default: 1800 rpm

Properties:

Description:

It sets the maximum motor speed reference limit value when the inverter is enabled. Valid for any type of reference signal.

C4.3.1.2 Reference source

It allows setting the source for the speed reference in the Remote 1 and Remote 2 modes.

C4.3.1.2 Reference source

C4.3.1.2.1 Remote 1 Mode

Range: 0 ... 13

Default: 0

Properties: Stopped

Description:

It sets the source for the speed reference for Remote 1 mode.

Indication	Description
0 = HMI	Reference via HMI speed reference parameter (C4.3.1.3.1)
1 = E.P.	Reference via Electronic Potentiometer function
2 = Multispeed	Reference via Multispeed function
3 = Serial	Reference via RS-485 Serial speed reference parameter (S5.2.3)
4 = Anybus	Reference via Anybus-CC speed reference parameter (S5.6.4)
5 = CAN/CO/DN	Reference via CAN/CANop/DNet speed reference parameter (S5.7.3)
6 = Ethernet	Reference via Ethernet speed reference parameter (S5.3.3)
7 = Not used	Not used
8 = SoftPLC	Reference via SoftPLC function
9 = Analog Input (AI)	Reference via analog input chosen by the user The analog input can be set in C4.3.1.3.2

C CONFIGURATIONS

Indication	Description
10 = Frequency Input (FI)	Reference via frequency input chosen by the user The frequency input can be set in C4.3.1.3.3
11 = PID Controller	Reference via PID controller output parameter (A2.1.5)
12 = Sum AIs	Reference via sum of analog inputs AI X-1 and AI X-2
13 = Sum AIs > 0	Reference via sum of analog inputs AI X-1 and AI X-2 Negative results are stapled to 0.0 %

C4.3.1.2 Reference source

C4.3.1.2.2 Remote 2 Mode

Range:	0 ... 13	Default: 9
Properties:	Stopped	

Description:

It sets the source for the speed reference for Remote 2 mode.

Indication	Description
0 = HMI	Reference via HMI speed reference parameter (C4.3.1.3.1)
1 = E.P.	Reference via Electronic Potentiometer function
2 = Multispeed	Reference via Multispeed function
3 = Serial	Reference via RS-485 Serial speed reference parameter (S5.2.3)
4 = Anybus	Reference via Anybus-CC speed reference parameter (S5.6.4)
5 = CAN/CO/DN	Reference via CAN/CANop/DNet speed reference parameter (S5.7.3)
6 = Ethernet	Reference via Ethernet speed reference parameter (S5.3.3)
7 = Not used	Not used
8 = SoftPLC	Reference via SoftPLC function
9 = Analog Input (AI)	Reference via analog input chosen by the user The analog input can be set in C4.3.1.3.2
10 = Frequency Input (FI)	Reference via frequency input chosen by the user The frequency input can be set in C4.3.1.3.3
11 = PID Controller	Reference via PID controller output parameter (A2.1.5)
12 = Sum AIs	Reference via sum of analog inputs AI X-1 and AI X-2
13 = Sum AIs > 0	Reference via sum of analog inputs AI X-1 and AI X-2 Negative results are stapled to 0.0 %

C4.3.1.3 Reference HMI, AIs and FIs

It allows setting the speed reference value when the reference is HMI or analog input (AI) or frequency input (FI).

C4.3.1.3 Reference HMI, AIs and FIs

C4.3.1.3.1 Speed Ref. via HMI

Range:	0 ... 60000 rpm	Default: 90 rpm
Properties:		

Description:

Sets the motor speed reference value when the reference source is the HMI.

C4.3.1.3 Reference HMI, AIs and FIs

C4.3.1.3.2 R1 Speed Ref. AI Config.

Range:	0 ... 30	Default: 1
Properties:	Stopped	

Description:

Defines the analog input that will be used as the motor speed reference when the reference source is the Analog Input (AI).

Analog Inputs options for X and A...G Slots

Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
AI1	X-1 (1)	A-1 (3)	B-1 (7)	C-1 (11)	D-1 (15)	E-1 (19)	F-1 (23)	G-1 (27)
AI2	X-2 (2)	A-2 (4)	B-2 (8)	C-2 (12)	D-2 (16)	E-2 (20)	F-2 (24)	G-2 (28)
AI3	—	A-3 (5)	B-3 (9)	C-3 (13)	D-3 (17)	E-3 (21)	F-3 (25)	G-3 (29)

Table 9.40: Values assigned to the Analog Inputs of X and A...G Slots**NOTE!**

Example: To choose Analog Input AI3 from Slot D, select D-3 (17) option.

C4.3.1.3 Reference HMI, AIs and FIs**C4.3.1.3.3 Speed Ref. FI Config.**

Range:	0 ... 2	Default: 1
Properties:	Stopped	

Description:

It defines the frequency input that will be used as the motor speed reference when the reference source is the Frequency Input (FI).

C4.3.1.3 Reference HMI, AIs and FIs**C4.3.1.3.4 R2 Speed Ref. AI Config.**

Range:	0 ... 30	Default: 1
Properties:	Stopped	

Description:

It defines the analog input that will be used as a motor speed reference in Remote 2 mode when the reference source is the Analog Input (AI). The options are shown in Table 9.20 on page 9-32.

C4.3.1.4 Reference of the electronic potentiometer

The Electronic Potentiometer function (E.P.) allows the speed reference to be set by means of two digital inputs (one to increment it and another to decrement it).

To enable this function, you must first configure the speed reference via Electronic Potentiometer by setting C4.3.1.2.1 = E.P. and/or C4.3.1.2.2 = E.P. Next, you must also program which digital inputs will act as the "INCREASE" and "DECREASE" commands in parameters C4.3.1.4.1 and C4.3.1.4.2 respectively.

During the "INCREASE" command, the motor accelerates following the acceleration ramp until reaching the maximum speed reference defined in C4.3.1.1.2 if the command is not removed before. During "DECREASE" command, the motor decelerates following the deceleration ramp until reaching the minimum speed reference defined in C4.3.1.1.1 if the command is not removed before. If the "INCREASE" or "DECREASE" commands are removed before reaching the maximum or minimum speed reference, the new speed reference will be the instantaneous value of the output speed at the instant the command is removed.

The "INCREASE" or "DECREASE" commands are effective only when the Run/Stop command is active.

Figure 9.31 on page 9-64 illustrates the operation of this function. The reference increment is done by applying 24 V to the "INCREASE" digital input, while the decrement is done by applying 0 V to the "DECREASE" digital input.

To reset the reference to zero, apply 24 V to the "INCREASE" digital input and 0 V to the "DECREASE" digital input simultaneously with the MVW disabled.

If no digital inputs are set to the "INCREASE" and/or "DECREASE" function and the reference source selection

C CONFIGURATIONS

is set to Electronic Potentiometer (C4.3.1.2.1 = E.P. and/or C4.3.1.2.2 = E.P.), the MVW will go to CONFIG status. See parameter S1.1.4.




Figure 9.31: Electronic Potentiometer (E.P.) function

C4.3.1.4 Reference of the electronic potentiometer

C4.3.1.4.1 DI Increase E.P.

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used as “INCREASE” command by the Electronic Potentiometer. Table 9.37 on page 9-57 shows the options.

C4.3.1.4 Reference of the electronic potentiometer

C4.3.1.4.2 DI Decrease E.P.

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used as “DECREASE” command by the Electronic Potentiometer. Table 9.37 on page 9-57 shows the options.

C4.3.1.5 Multispeed reference

With the Multispeed function it is possible to select one of up to eight preset fixed speed references. The selection of one of the references is made according to the logical combination of the status of up to three digital inputs. This behavior can be seen in Figure 9.32 and in Table 9.41 on page 9-65.

To activate the Multispeed function it is necessary to configure parameter C4.3.1.2.1 = Multispeed and/or C4.3.1.2.2 = Multispeed (reference source selection).

It is possible to use only one or two digital inputs and thus select between up to two or four Multispeed references respectively. Digital inputs not configured for the Multispeed function are considered as 0 V in Table 9.41.

If no digital inputs are set to the Multispeed function and the reference source selection is set to Multispeed (C4.3.1.2.1 = Multispeed and/or C4.3.1.2.2 = Multispeed), the MVW will go to the CONFIG status. See parameter S1.1.4.

The Multispeed function provides the advantages of stability of the fixed preset references and immunity against electric noises (isolated digital inputs).




Figure 9.32: Multispeed

Below is a table with the selection of the speed reference according to the logical state of the digital inputs:

Table 9.41: Multispeed Reference

8 speed references			
4 speed references			
2 speed references			
3rd DI	2nd DI	1st DI	Speed Reference
0 V	0 V	0 V	C4.3.1.5.1
0 V	0 V	24 V	C4.3.1.5.2
0 V	24 V	0 V	C4.3.1.5.3
0 V	24 V	24 V	C4.3.1.5.4
24 V	0 V	0 V	C4.3.1.5.5
24 V	0 V	24 V	C4.3.1.5.6
24 V	24 V	0 V	C4.3.1.5.7
24 V	24 V	24 V	C4.3.1.5.8

C4.3.1.5 Multispeed reference		
C4.3.1.5.1 Multispeed Ref. 1		
C4.3.1.5.2 Multispeed Ref. 2		
C4.3.1.5.3 Multispeed Ref. 3		
C4.3.1.5.4 Multispeed Ref. 4		
C4.3.1.5.5 Multispeed Ref. 5		
C4.3.1.5.6 Multispeed Ref. 6		
C4.3.1.5.7 Multispeed Ref. 7		
C4.3.1.5.8 Multispeed Ref. 8		
Range:	0 ... 60000 rpm	Default: 90 rpm (C4.3.1.5.1)
		300 rpm (C4.3.1.5.2)
		600 rpm (C4.3.1.5.3)
		900 rpm (C4.3.1.5.4)
		1200 rpm (C4.3.1.5.5)
		1500 rpm (C4.3.1.5.6)
		1800 rpm (C4.3.1.5.7)
		1650 rpm (C4.3.1.5.8)
Properties:		

Description:
It sets the value of the multispeed speed reference according to the logical combination of the digital inputs. The digital inputs logics are presented in the Table 9.41.

C4.3.1.5 Multispeed reference		
C4.3.1.5.9 Multispeed 1 DI Config.		
C4.3.1.5.10 Multispeed 2 DI Config.		
C4.3.1.5.11 Multispeed 3 DI Config.		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:
It enables the use and defines the digital input that will be used for selecting the multispeed speed reference. Table 9.37 on page 9-57 shows the options.

C4.3.1.6 Skip speed

It allows setting up to three speed ranges in which the motor cannot operate continuously; for example, in a mechanical system that goes into resonance (causing excessive vibration or noise). Figure 9.33 on page 9-67 details the operation of this function.




Figure 9.33: Operation curve of the “Skip Speeds”

The function is disabled for C4.3.1.6.4=0.

The passage through the skip speed range (2 x C4.3.1.6.4) is done following the acceleration or deceleration ramp.

If the speed reference is within the range to be skipped, the new reference will go to the lower limit of the range in question.

In case of overlapping ranges, a single range will be considered, with limits defined by the smallest lowest limit and the highest upper limit.

If the range limits exceed the minimum and/or maximum reference values (C4.3.1.1.1 and C4.3.1.1.2), these limits will be saturated in the values of C4.3.1.1.1 and/or C4.3.1.1.2.



NOTE! If only one or two of the skip speed ranges are to be used, two or one of the ranges must be overlapped. For example, to use only one skip speed range, set parameters C4.3.1.6.1, C4.3.1.6.2 and C4.3.1.6.3 to the same value (overlapping ranges 1, 2 and 3).

C4.3.1.6 Skip speed		
C4.3.1.6.1 Speed 1		
Range:	0 ... 60000 rpm	Default: 600 rpm
Properties:		

Description:
It sets the value of skip speed 1.

C4.3.1.6 Skip speed		
C4.3.1.6.2 Speed 2		
Range:	0 ... 60000 rpm	Default: 900 rpm
Properties:		

Description:
It sets the value of skip speed 2.

C CONFIGURATIONS

C4.3.1.6 Skip speed

C4.3.1.6.3 Speed 3

Range: 0 ... 60000 rpm

Default: 1200 rpm

Properties:

Description:

It sets the value of skip speed 3.

C4.3.1.6 Skip speed

C4.3.1.6.4 Skip Range

Range: 0 ... 750 rpm

Default: 0 rpm

Properties:

Description:

Sets the value of the speed range that should be skipped. This value is subtracted and added to the value of the skipped speed, thus setting a range around the defined speed.

C4.3.2 JOG Speed

It allows setting the speed reference for the JOG command.

C4.3.2 JOG Speed

C4.3.2.1 JOG Reference

Range: 0 ... 60000 rpm

Default: 150 rpm

Properties:

Description:

It sets the motor speed reference value when the JOG command is executed.

During the JOG command, the motor accelerates following the acceleration ramp set until reaching the speed defined in this reference. The JOG command is only effective when the Run/Stop command is inactive.

C4.3.3 Torque

It allows setting the torque reference to operate in Torque Control mode.



NOTE!

The torque reference is only active when the control type is set to Vector with Encoder (C3.1.1 = 2) and the control mode is set to Torque (C3.3.1.1 = 1).

C4.3.3 Torque

C4.3.3.1 Torque Reference via HMI

Range: -400.0 ... 400.0 %

Default: 0.0 %

Properties:

Description:

It sets the torque reference value when the reference source is the HMI.

C4.3.3 Torque

C4.3.3.2 Maximum Torque

Range: 0.0 ... 400.0 %

Default: 400.0 %

Properties:

Description:

It allows you to set maximum torque reference value for any reference signal. If the reference signal configured to be followed by the inverter is greater than the maximum reference set in C4.3.3.2, the inverter will limit in C4.3.3.2.

C4.3.3 Torque**C4.3.3.3 Minimum Torque**

Range: 0.0 ... 400.0 %

Default: 0.0 %

Properties:

Description:

It allows you to set minimum torque reference value for any reference signal. If the reference signal configured to be followed by the inverter is less than the minimum reference set in C4.3.3.3, the inverter will limit in C4.3.3.3.

C4.3.3 Torque**C4.3.3.4 Torque Ref. Source**

Range: 0 ... 2

Default: 0

Properties: Stopped

Description:

It defines which source will determine the reference for torque control.

Indication	Description
0 = HMI	Torque Reference via HMI parameter (C4.3.3.1)
1 = Analog Input (AI)	Torque Reference via analog input chosen by the user The analog input can be set in C4.3.3.5
2 = Frequency Input (FI)	Torque Reference via frequency input chosen by the user The frequency input can be set in C4.3.3.6

**NOTE!**

If it is necessary to set the torque reference via Communication Networks or SoftPLC, this parameter must be set to HMI and the reference value set in C4.3.3.1.

C4.3.3 Torque**C4.3.3.5 Torque Ref. AI Config.**

Range: 0 ... 30

Default: 0

Properties: Stopped

Description:

Defines which analog input will be used as reference for torque control. Table 9.43 on page 9-69 shows the options.

Analog Inputs options for X and A...G Slots

Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
AI1	X-1 (1)	A-1 (3)	B-1 (7)	C-1 (11)	D-1 (15)	E-1 (19)	F-1 (23)	G-1 (27)
AI2	X-2 (2)	A-2 (4)	B-2 (8)	C-2 (12)	D-2 (16)	E-2 (20)	F-2 (24)	G-2 (28)
AI3	—	A-3 (5)	B-3 (9)	C-3 (13)	D-3 (17)	E-3 (21)	F-3 (25)	G-3 (29)

Table 9.43: Values assigned to the Analog Inputs of X and A...G Slots

**NOTE!**

Example: To choose Analog Input AI3 from Slot D, select D-3 (17) option.

C4.3.3 Torque		
C4.3.3.6 Torque Ref. FI Config.		
Range:	0 ... 2	Default: 0
Properties:	Stopped	

Description:
It defines which frequency input will be used as reference for torque control.

Indication	Description
0 = Inactive	It disables the use of the frequency input in this function
1 = FI X-5	It enables the use of frequency input FI5 of Slot X
2 = FI X-6	It enables the use of frequency input FI6 of Slot X

C5 I/OS

It allows configuring the I/O accessories installed on the MVW.

C5.1 Slot X

Allows you to view the status of the slot configuration parameters.




Figure 9.34: IOS Accessory, Slot X

C5.1.1 Analog inputs

It allows setting the analog inputs of the accessory connected to the corresponding slot.
Figure 9.35 on page 9-71 illustrates how the analog input works.




Figure 9.35: Block diagram of the analog input

Figure 9.36 on page 9-71 illustrates the analog input behavior for different configurations of gain, offset and dead zone with signal type set to 0 to 10 V. In addition, it is presented how saturation works for each configuration. The behavior of the signal may change slightly according to the signal type selected, but the effects of the settings shown remain the same.




Figure 9.36: Analog input signal types

C5.1.1 Analog inputs		
C5.1.1.1 AI1 Settings		
C5.1.1.6 AI2 Settings		
Range:	0 ... 5 Bit	Default: 16
Properties:		

Description:

It allows to configure the action to be taken in case of a broken wire and also the type of signal that is expected at the terminals.

C CONFIGURATIONS

Bit	Value/Description
Bit 0 ... 1 Detect Disconnection	Enabling broken wire detection when the analog input signal type is 4 to 20 mA or 20 to 4 mA. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 2 ... 5 Signal Config.	Selection of the analog input signal type. 0 = 0 to 20 mA: It indicates that the analog input signal is of 0 to 20 mA type 1 = 4 to 20 mA: It indicates that the analog input signal is of 4 to 20 mA type 2 = 20 to 0 mA: It indicates that the analog input signal is of 20 to 0 mA type 3 = 20 to 4 mA: It indicates that the analog input signal is of 20 to 4 mA type 4 = 0 to 10 V: It indicates that the analog input signal is of 0 to 10 mA type 5 = 10 to 0 V: It indicates that the analog input signal is of 10 to 0 V type 6 = -10 to 10 V: It indicates that the analog input signal is of -10 to 10 V type 7 = 10 to -10 V: It indicates that the analog input signal is of 10 to -10 V type 8 = PTC: It indicates that the analog input signal is of the PTC type

C5.1.1 Analog inputs

C5.1.1.2 AI1 Filter

C5.1.1.7 AI2 Filter

Range: 0.00 ... 16.00 s

Default: 0.10 s

Properties:

Description:

It allows to configure the RC constant of the low-pass filter present at the analog input.



NOTE!

The analog input signal is filtered before applying gain and offset to the signal.

C5.1.1 Analog inputs

C5.1.1.3 AI1 Gain

C5.1.1.8 AI2 Gain

Range: 0.000 ... 9.999

Default: 1.000

Properties:

Description:

Gain setting for analog input.

C5.1.1 Analog inputs

C5.1.1.4 AI1 Offset

C5.1.1.9 AI2 Offset

Range: -100.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Offset setting for analog input.

C5.1.1 Analog inputs

C5.1.1.5 AI1 Dead Zone

C5.1.1.10 AI2 Dead Zone

Range: 0.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Dead zone setting for analog input.

C5.1.2 Analog outputs

It allows setting the analog outputs of the accessory connected to the slot.

Figure 9.37 on page 9-73 illustrates how the analog output works.




Figure 9.37: Block diagram of the analog output

C5.1.2 Analog outputs		
C5.1.2.1 AO1 Signal Type		
C5.1.2.5 AO2 Signal Type		
Range:	0 ... 5	Default: 4
Properties:		

Description:
It allows to configure the signal type of analog output.

To set the type of output, it is also necessary to correctly position the “DIP switches” present on the accessory. For further details, refer to the specific accessory manual.

Indication	Description
0 = 0 to 20 mA	It indicates that the Analog Output signal of Slot X is 0 to 20 mA
1 = 4 to 20 mA	It indicates that the Analog Output signal of Slot X is 4 to 20 mA type
2 = 20 to 0 mA	It indicates that the Analog Output signal of Slot X is 20 to 0 mA type
3 = 20 to 4 mA	It indicates that the Analog Output signal of Slot X is 20 to 4 mA type
4 = 0 to 10 V	It indicates that the Analog Output signal of Slot X is 0 to 10 V type
5 = 10 to 0 V	It indicates that the Analog Output signal of Slot X is 10 to 0 V type

C5.1.2 Analog outputs		
C5.1.2.2 AO1 Gain		
C5.1.2.6 AO2 Gain		
Range:	0.000 ... 9.999	Default: 1.000
Properties:		

Description:
Gain setting for analog output.

C5.1.2 Analog outputs

C5.1.2.3 AO1 Function

C5.1.2.7 AO2 Function

Range: 0 ... 21 **Default:** 4 (C5.1.2.3)
7 (C5.1.2.7)

Properties:

Description:

Setting of the function to be used for the analog output.

Indication	Description
0 = Off (0%)	It imposes 0 % on the output, regardless of the set gain and offset values
1 = On (100%)	It imposes 100 % on the output, regardless of the set gain and offset values
2 = Speed Ref.	It imposes on the output a value proportional to the speed reference (S2.1.1)
3 = Inverter temperature	It imposes on the output a value proportional to the highest temperature value between the inverter arms
4 = Real Speed	It imposes on the output a value proportional to the current motor speed used by the control module (S2.1.3)
5 ... 6 = Not used	Not used
7 = Output Current	It imposes on the output a value proportional to the RMS value of the fundamental component of the inverter output current (S2.3.1)
8 = Process Var.	Process Variable
9 = Not used	Not used
10 = Output Power	It imposes on the output a value proportional to the electrical power at the inverter output (S2.3.11)
11 = PID Setpoint	PID Setpoint
12 = Not used	Not used
13 = Motor Torque	It imposes on the output a value proportional to the estimated electrical torque on the motor based on the nominal torque (S2.2.3)
14 = SoftPLC	It imposes on the output the value sent by SoftPLC. Gain and offset values do not affect the output
15 = PTC	It imposes on the output the recommended value for powering a PTC temperature sensor (10 %). Gain and offset values do not affect the output
16 = Motor Ixt	It imposes on the output a value proportional to the motor overload level (D4.1.5.1)
17 = Encoder Speed	It imposes on the output a value proportional to the encoder current speed (S2.1.4)
18 = Network	It imposes on the output the value sent by the network. Gain and offset values do not affect the output
19 = Not used	Not used
20 = Torque Ref.	It imposes on the output a value proportional to the electrical torque reference on the motor based on the nominal torque (S2.2.1)
21 = Total Torque Ref.	It imposes on the output a value proportional to the electrical torque reference of the motor after the ramp (S2.2.2)

Table 9.47 on page 9-75 illustrates the full scale of analog output functions.

Table 9.47: Full scale of AO functions

Scale of the analog outputs indications	
Variable	Full scale
Speed Ref. Total Speed Ref.	Maximum Speed Reference (C4.3.1.1.2)
Real Speed Encoder Speed	$2.0 \times [\text{Maximum Speed Reference (C4.3.1.1.2)}]$
Inverter temperature	200°C
Output Current	$1.5 \times [\text{Rated Current (C13.1.2)}]$
Output Power	$1.5 \times \sqrt{3} \times [\text{Rated Current (C13.1.2)}] \times [\text{Rated Voltage (C13.1.1)}]$
Torque Ref. Total Torque Ref.	Maximum Torque Reference (C4.3.3.2)
Motor Torque	400 %
Motor Ixt Network	100 %
SoftPLC	32767
Process Var. PID Setpoint	Process Variable Maximum Level (A2.3.3.5)

The analog outputs cannot reproduce negative values at their terminals even if the HMI status shows negative values. This is because all analog output signal types are not bipolar. If it is necessary to represent these negative values using analog outputs, it is possible to set an offset of +100 % and a gain of 0.500. The analog output will keep reproducing only non-negative values, but it will be possible to differentiate positive from negative values. Figure 9.38 on page 9-75 illustrates this behavior for torque reference function and signal type set to 0 to 10 V. This setting can be useful when the analog output function is set to any function that can return a negative value, such as motor torque and torque reference.




Figure 9.38: AO configurations to represent negative values

C5.1.2 Analog outputs

C5.1.2.4 AO1 Offset

C5.1.2.8 AO2 Offset

Range: -100.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Offset setting for analog output.

C CONFIGURATIONS

C5.1.3 Digital inputs

It allows configuring the digital inputs of the accessory connected to the slot.

Figure 9.39 on page 9-76 illustrates how the frequency input works.




Figure 9.39: Frequency input block diagram

C5.1.3 Digital inputs		
C5.1.3.4 DI5 Operation Mode		
C5.1.3.9 DI6 Operation Mode		
Range:	0 ... 3	Default: 0
Properties:	Stopped	

Description:
It allows to configure the operating mode of the digital input.



NOTE!
When the digital input is configured as a frequency input, it must be ensured that no command via DI is configured to use this same input. An example of a configuration that should be avoided would be to set the DI5 parameter of the Slot-X (C5.1.3.4) as frequency input and then set the general enable command parameter via DI (C4.2.3.1) to use this same input.

Indication	Description
0 = Polling	It indicates that the Digital Input is set for reading via scanning
1 = Not used	Not used
2 = Frequency	It indicates that the Digital Input is set to frequency input
3 = Encoder	It indicates that the Digital Input is set for reading the input signal frequency

C5.1.3 Digital inputs		
C5.1.3.5 FI5 Min Frequency		
C5.1.3.10 FI6 Min Frequency		
Range:	0 ... 32000 Hz	Default: 0 Hz
Properties:	Stopped	

Description:
It allows to configure the zero scale of the frequency input.

C5.1.3 Digital inputs		
C5.1.3.6 FI5 Max Frequency		
C5.1.3.11 FI6 Max Frequency		
Range:	0 ... 32000 Hz	Default: 32000 Hz
Properties:	Stopped	

Description:
It allows to configure the full scale of the frequency input.

C5.1.3 Digital inputs		
C5.1.3.7 FI5 Gain		
C5.1.3.12 FI6 Gain		
Range:	0.000 ... 9.999	Default: 1.000
Properties:	Stopped	

Description:
Frequency input gain setting.

C5.1.3 Digital inputs		
C5.1.3.8 FI5 Offset		
C5.1.3.13 FI6 Offset		
Range:	-100.00 ... 100.00 %	Default: 0.00 %
Properties:	Stopped	

Description:
Frequency input offset setting.

C5.1.4 Digital outputs

It allows configuring the digital outputs of the accessory connected to the slot.

Figure 9.40 on page 9-77 illustrates how the frequency output works.




Figure 9.40: Frequency output block diagram

C CONFIGURATIONS

C5.1.4 Digital outputs

C5.1.4.1 DO1 Operation Mode

C5.1.4.10 DO2 Operation Mode

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

It allows to configure the operating mode of the digital output.

Indication	Description
0 = Polling	It indicates that the Digital Output is set to the ON/OFF mode
1 = Frequency	It indicates that the Digital Output is set to the Frequency Output mode

C5.1.4 Digital outputs

C5.1.4.2 DO1 Function

C5.1.4.11 DO2 Function

Range:	0 ... 31	Default: 22 (C5.1.4.2) 19 (C5.1.4.11)
--------	----------	--

Properties:

Description:

Setting of the function to be used for the digital output.

Indication	Description
0 = Off	The Digital Output will always go to the inactive status
1 = On	The Digital Output will always go to the active status
2 = $N^* > N_x$	The Digital Output will go to the active status when the speed reference (N^*) is greater than the value set in N_x
3 = $N > N_x$	The Digital Output will go to the active status when the motor speed (N) is greater than the value set in N_x
4 = $N < N_y$	The Digital Output will go to the active status when the motor speed (N) is smaller than the value set in N_y
5 = $N = N^*$	The Digital Output will go to the active status when the motor speed (N) equals the speed reference value (N^*)
6 = Zero Speed	The Digital Output will go to the active status when the motor speed (N) is smaller than the value set in Zero Speed
7 = Not used	Not used
8 = $F > F_x$	The Digital Output will go to the active status when the motor frequency (F) is greater than the value set in F_x
9 = $I_s > I_x$	The Digital Output will go to the active status when the output current (I_s) is greater than the value set in I_x
10 = $I_s < I_x$	The Digital Output will go to the active status when the output current (I_s) is smaller than the value set in I_x
11 = Torque $> T_x$	The Digital Output will go to the active status when the motor torque (Torque) is greater than the value set in T_x
12 = Torque $< T_x$	The Digital Output will go to the active status when the motor torque (Torque) is smaller than the value set in T_x
13 = Hours Enabled $> H_x$	The Digital Output will go to the active status when the enabled hour counter is greater than the value set in H_x
14 ... 15 = Not used	Not used
16 = Local Mode	The Digital Output will go to the active status when the commands and references are defined by the Local mode
17 = Remote 1 Mode	The Digital Output will go to the active status when the commands and references are defined by the Remote 1 mode
18 = Remote 2 Mode	The Digital Output will go to the active status when the commands and references are defined by the Remote 2 mode
19 = Run	The Digital Output will go to the active status when the inverter is in the Run status
20 = Ready	The Digital Output will go to the active status when the inverter is in the Ready status
21 = STO	The Digital Output will go to the active status when the inverter is in the STO status

Indication	Description
22 = No Fault	The Digital Output will go to the active status when the inverter does not have a fault acting
23 = With Fault	The Digital Output will go to the active status when any fault acts on the inverter
24 = No Alarm	The Digital Output will go to the active status when the inverter is not indicating an alarm
25 = No Fault and Alarm	The Digital Output will go to the active status when a fault is not acting and is not indicating an alarm in the inverter
26 = Network	The Digital Output will go to the active status when the command received via Network is active
27 = SoftPLC	The Digital Output will go to the active status when the command received via SoftPLC is active
28 = Forward Direction	The Digital Output will go to the active state when the inverter is running in the forward direction
29 = Ride-Through	The Digital Output will go to the active status when the Ride-Through function is acting
30 = Pre-Charge OK	The Digital Output will go into the active state when the Pre-charge function indicates that it has been successfully executed
31 = Ready to start	The Digital Output will go to the active state when the inverter has completed the pre-charge and without a RUN command.

C5.1.4 Digital outputs

C5.1.4.3 FO1 Function

C5.1.4.12 FO2 Function

Range: 0 ... 21

Default: 0

Properties: Stopped

Description:

Setting of the function to be used for the frequency output.

Indication	Description
0 = Off (0%)	It imposes 0 % on the output, regardless of the set gain and offset values
1 = On (100%)	It imposes 100 % on the output, regardless of the set gain and offset values
2 = Speed Ref.	It imposes on the output a value proportional to the speed reference (S2.1.1)
3 = Total Speed Ref.	It imposes on the output a value proportional to the highest temperature value between the inverter arms
4 = Real Speed	It imposes on the output a value proportional to the current motor speed used by the control module (S2.1.3)
5 ... 6 = Not used	Not used
7 = Output Current	It imposes on the output a value proportional to the RMS value of the fundamental component of the inverter output current (S2.3.1)
8 = Process Var.	Process Variable
9 = Not used	Not used
10 = Output Power	It imposes on the output a value proportional to the electrical power at the inverter output (S2.3.11)
11 = PID Setpoint	PID Setpoint
12 = Not used	Not used
13 = Motor Torque	It imposes on the output a value proportional to the estimated electrical torque on the motor based on the nominal torque (S2.2.3)
14 = SoftPLC	It imposes on the output the value sent by SoftPLC. Gain and offset values do not affect the output
15 = Not used	Not used
16 = Motor Ixt	It imposes on the output a value proportional to the motor overload level (D4.1.5.1)
17 = Encoder Speed	It imposes on the output a value proportional to the encoder current speed (S2.1.4)
18 = Network	It imposes on the output the value sent by the network. Gain and offset values do not affect the output
19 = Not used	Not used
20 = Torque Ref.	It imposes on the output a value proportional to the electrical torque reference on the motor based on the nominal torque (S2.2.1)
21 = Total Torque Ref.	It imposes on the output a value proportional to the electrical torque reference of the motor after the ramp (S2.2.2)

C CONFIGURATIONS

Table 9.52 on page 9-80 illustrates the full scale of frequency output functions.

Table 9.52: Full scale of FO functions

Scale of frequency output indications	
Variable	Full scale
Speed Ref. Total Speed Ref.	Maximum Speed Reference (C4.3.1.1.2)
Real Speed Encoder Speed	$2.0 \times [\text{Maximum Speed Reference (C4.3.1.1.2)}]$
Inverter temperature	200°C
Output Current	$1.5 \times [\text{Rated Current (C13.1.2)}]$
Output Power	$1.5 \times \sqrt{3} \times [\text{Rated Current (C13.1.2)}] \times [\text{Rated Voltage (C13.1.1)}]$
Torque Ref. Total Torque Ref.	Maximum Torque Reference (C4.3.3.2)
Motor Torque	400 %
Motor Ixt Network	100 %
SoftPLC	32767
Process Var. PID Setpoint	Process Variable Maximum Level (A2.3.3.5)

The frequency outputs cannot reproduce negative values at their terminals even if the HMI status shows negative values. That happens because all frequency outputs respect their minimum value, and this value is reached at 0 %. If it is necessary to represent these negative values using frequency outputs, it is possible to set an offset of +100 % and a gain of 0.500. The frequency output will keep reproducing only non-negative values, but it will possible to differentiate positive from negative values. Figure 9.41 on page 9-80 illustrates this behavior for torque reference function. The minimum and maximum frequency limits are set according to the default value setting. This setting can be useful when the frequency output function is set to any function that can return a negative value, such as motor torque and torque reference.




Figure 9.41: FO configurations to represent negative values

C5.1.4 Digital outputs**C5.1.4.4 FO1 Min Frequency****C5.1.4.13 FO2 Min Frequency****Range:** 0 ... 32000 Hz**Default:** 0 Hz**Properties:** Stopped**Description:**

It allows to configure the frequency output zero scale.

C5.1.4 Digital outputs**C5.1.4.5 FO1 Max Frequency****C5.1.4.14 FO2 Max Frequency****Range:** 0 ... 32000 Hz**Default:** 32000 Hz**Properties:** Stopped**Description:**

It allows to configure the full scale for frequency output.

C5.1.4 Digital outputs**C5.1.4.6 FO1 Gain****C5.1.4.15 FO2 Gain****Range:** 0.000 ... 9.999**Default:** 1.000**Properties:** Stopped**Description:**

Frequency output gain setting.

C5.1.4 Digital outputs**C5.1.4.7 FO1 Offset****C5.1.4.16 FO2 Offset****Range:** -100.00 ... 100.00 %**Default:** 0.00 %**Properties:** Stopped**Description:**

Frequency output offset setting.

C5.2 Slot A

It allows viewing the status of the configuration parameters of the Slot.

C5.2.1 Analog inputs to C5.8.1 Analog inputs

It allows setting the analog inputs of the accessory connected to the corresponding slot.

C CONFIGURATIONS

C5.2.1 Analog inputs

C5.3.1 Analog inputs

C5.4.1 Analog inputs

C5.5.1 Analog inputs

C5.6.1 Analog inputs

C5.7.1 Analog inputs

C5.8.1 Analog inputs

1 AI1 Settings

6 AI2 Settings

11 AI3 Settings

Range: 0 ... 5 Bit

Default: 16

Properties:

Description:

It allows to configure the action to be taken in case of a broken wire and also the type of signal that is expected at the terminals.

Bit	Value/Description
Bit 0 ... 1 Detect Disconnection	Enabling broken wire detection when the analog input signal type is 4 to 20 mA or 20 to 4 mA. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 2 ... 5 Signal Config.	Selection of the analog input signal type. 0 = 0 to 20 mA: It indicates that the analog input signal is of 0 to 20 mA type 1 = 4 to 20 mA: It indicates that the analog input signal is of 4 to 20 mA type 2 = 20 to 0 mA: It indicates that the analog input signal is of 20 to 0 mA type 3 = 20 to 4 mA: It indicates that the analog input signal is of 20 to 4 mA type 4 = 0 to 10 V: It indicates that the analog input signal is of 0 to 10 V type 5 = 10 to 0 V: It indicates that the analog input signal is of 10 to 0 V type 6 = -10 to 10 V: It indicates that the analog input signal is of -10 to 10 V type 7 = 10 to -10 V: It indicates that the analog input signal is of 10 to -10 V type 8 = PTC: It indicates that the analog input signal is of the PTC type

C5.2.1 Analog inputs

C5.3.1 Analog inputs

C5.4.1 Analog inputs

C5.5.1 Analog inputs

C5.6.1 Analog inputs

C5.7.1 Analog inputs

C5.8.1 Analog inputs

.2 AI1 Filter

.7 AI2 Filter

.12 AI3 Filter

Range: 0.00 ... 16.00 s

Default: 0.10 s

Properties:

Description:

It allows to configure the RC constant of the low-pass filter present at the analog input.



NOTE!

The analog input signal is filtered before applying gain and offset to the signal.

C5.2.1 Analog inputs

C5.3.1 Analog inputs

C5.4.1 Analog inputs

C5.5.1 Analog inputs

C5.6.1 Analog inputs

C5.7.1 Analog inputs

C5.8.1 Analog inputs

.3 AI1 Gain**.8 AI2 Gain****.13 AI3 Gain****Range:** 0.000 ... 9.999**Default:** 1.000**Properties:****Description:**

Gain setting for analog input.

C5.2.1 Analog inputs

C5.3.1 Analog inputs

C5.4.1 Analog inputs

C5.5.1 Analog inputs

C5.6.1 Analog inputs

C5.7.1 Analog inputs

C5.8.1 Analog inputs

.4 AI1 Offset**.9 AI2 Offset****.14 AI3 Offset****Range:** -100.00 ... 100.00 %**Default:** 0.00 %**Properties:****Description:**

Offset setting for analog input.

C5.2.1 Analog inputs

C5.3.1 Analog inputs

C5.4.1 Analog inputs

C5.5.1 Analog inputs

C5.6.1 Analog inputs

C5.7.1 Analog inputs

C5.8.1 Analog inputs

.5 AI1 Dead Zone**.10 AI2 Dead Zone****.15 AI3 Dead Zone****Range:** 0.00 ... 100.00 %**Default:** 0.00 %**Properties:****Description:**

Dead zone setting for analog input.

C5.2.2 Analog outputs to C5.8.2 Analog outputs

It allows setting the analog outputs of the accessory connected to the slot.

C CONFIGURATIONS

C5.2.2 Analog outputs

C5.3.2 Analog outputs

C5.4.2 Analog outputs

C5.5.2 Analog outputs

C5.6.2 Analog outputs

C5.7.2 Analog outputs

C5.8.2 Analog outputs

.1 AO1 Signal Type

.5 AO2 Signal Type

Range: 0 ... 7

Default: 4

Properties:

Description:

It allows to configure the signal type of analog output.

To set the type of output, it is also necessary to correctly position the “DIP switches” present on the accessory. For further details, refer to the specific accessory manual.

Indication	Description
0 = 0 to 20 mA	It indicates that the Analog Output signal is 0 to 20 mA type
1 = 4 to 20 mA	It indicates that the Analog Output signal is 4 to 20 mA type
2 = 20 to 0 mA	It indicates that the Analog Output signal is 20 to 0 mA type
3 = 20 to 4 mA	It indicates that the Analog Output signal is 20 to 4 mA type
4 = 0 to 10 V	It indicates that the Analog Output signal is 0 a 10 V type
5 = 10 to 0 V	It indicates that the Analog Output signal is 10 a 0 V type
6 ... 7 = Not used	Not used

C5.2.2 Analog outputs

C5.3.2 Analog outputs

C5.4.2 Analog outputs

C5.5.2 Analog outputs

C5.6.2 Analog outputs

C5.7.2 Analog outputs

C5.8.2 Analog outputs

.2 AO1 Gain

.6 AO2 Gain

Range: 0.000 ... 9.999

Default: 1.000

Properties:

Description:

Gain setting for analog output.

C5.2.2 Analog outputs

C5.3.2 Analog outputs

C5.4.2 Analog outputs

C5.5.2 Analog outputs

C5.6.2 Analog outputs

C5.7.2 Analog outputs

C5.8.2 Analog outputs

.3 AO1 Function

.7 AO2 Function

Range: 0 ... 21

Default: 0

Properties:

Description:

Setting of the function to be used for the analog output.

Indication	Description
0 = Off (0%)	It imposes 0 % on the output, regardless of the set gain and offset values
1 = On (100%)	It imposes 100 % on the output, regardless of the set gain and offset values
2 = Speed Ref.	It imposes on the output a value proportional to the speed reference (S2.1.1)
3 = Inverter temperature	It imposes on the output a value proportional to the highest temperature value between the inverter arms
4 = Real Speed	It imposes on the output a value proportional to the current motor speed used by the control module (S2.1.3)
5 ... 6 = Not used	Not used
7 = Output Current	It imposes on the output a value proportional to the RMS value of the fundamental component of the inverter output current (S2.3.1)
8 = Process Var.	Process Variable
9 = Not used	Not used
10 = Output Power	It imposes on the output a value proportional to the electrical power at the inverter output (S2.3.11)
11 = PID Setpoint	PID Setpoint
12 = Not used	Not used
13 = Motor Torque	It imposes on the output a value proportional to the estimated electrical torque on the motor based on the nominal torque (S2.2.3)
14 = SoftPLC	It imposes on the output the value sent by SoftPLC. Gain and offset values do not affect the output
15 = PTC	It imposes on the output the recommended value for powering a PTC temperature sensor (10 %). Gain and offset values do not affect the output
16 = Motor Ixt	It imposes on the output a value proportional to the motor overload level (D4.1.5.1)
17 = Encoder Speed	It imposes on the output a value proportional to the encoder current speed (S2.1.4)
18 = Network	It imposes on the output the value sent by the network. Gain and offset values do not affect the output
19 = Not used	Not used
20 = Torque Ref.	It imposes on the output a value proportional to the electrical torque reference on the motor based on the nominal torque (S2.2.1)
21 = Total Torque Ref.	It imposes on the output a value proportional to the electrical torque reference of the motor after the ramp (S2.2.2)

C5.2.2 Analog outputs**C5.3.2 Analog outputs****C5.4.2 Analog outputs****C5.5.2 Analog outputs****C5.6.2 Analog outputs****C5.7.2 Analog outputs****C5.8.2 Analog outputs****.4 AO1 Offset****.8 AO2 Offset**

Range: -100.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Offset setting for analog output.

C5.2.4 Digital outputs to C5.8.4 Digital outputs

It allows configuring the digital outputs of the accessory connected to the slot.

C CONFIGURATIONS

C5.2.4 Digital outputs

C5.3.4 Digital outputs

C5.4.4 Digital outputs

C5.5.4 Digital outputs

C5.6.4 Digital outputs

C5.7.4 Digital outputs

C5.8.4 Digital outputs

.1 DO1 Function

.4 DO2 Function

.7 DO3 Function

.10 DO4 Function

.13 DO5 Function

.16 DO6 Function

.19 DO7 Function

.22 DO8 Function

Range:	0 ... 31	Default: 22 (C5.2.4.1)
		3 (C5.2.4.4)
		2 (C5.2.4.7)
		0 (Others)

Properties: Stopped

Description:

Setting of the function to be used for the digital output.

Indication	Description
0 = Off	The Digital Output will always go to the inactive status
1 = On	The Digital Output will always go to the active status
2 = $N^* > N_x$	The Digital Output will go to the active status when the speed reference (N^*) is greater than the value set in N_x
3 = $N > N_x$	The Digital Output will go to the active status when the motor speed (N) is greater than the value set in N_x
4 = $N < N_y$	The Digital Output will go to the active status when the motor speed (N) is smaller than the value set in N_y
5 = $N = N^*$	The Digital Output will go to the active status when the motor speed (N) equals the speed reference value (N^*)
6 = Zero Speed	The Digital Output will go to the active status when the motor speed (N) is smaller than the value set in Zero Speed
7 = Not used	Not used
8 = $F > F_x$	The Digital Output will go to the active status when the motor frequency (F) is greater than the value set in F_x
9 = $I_s > I_x$	The Digital Output will go to the active status when the output current (I_s) is greater than the value set in I_x
10 = $I_s < I_x$	The Digital Output will go to the active status when the output current (I_s) is smaller than the value set in I_x
11 = Torque > T_x	The Digital Output will go to the active status when the motor torque (Torque) is greater than the value set in T_x
12 = Torque < T_x	The Digital Output will go to the active status when the motor torque (Torque) is smaller than the value set in T_x
13 = Hours Enabled > H_x	The Digital Output will go to the active status when the enabled hour counter is greater than the value set in H_x
14 ... 15 = Not used	Not used
16 = Local Mode	The Digital Output will go to the active status when the commands and references are defined by the Local mode
17 = Remote 1 Mode	The Digital Output will go to the active status when the commands and references are defined by the Remote 1 mode
18 = Remote 2 Mode	The Digital Output will go to the active status when the commands and references are defined by the Remote 2 mode
19 = Run	The Digital Output will go to the active status when the inverter is in the Run status

Indication	Description
20 = Ready	The Digital Output will go to the active status when the inverter is in the Ready status
21 = STO	The Digital Output will go to the active status when the inverter is in the STO status
22 = No Fault	The Digital Output will go to the active status when the inverter does not have a fault acting
23 = With Fault	The Digital Output will go to the active status when any fault acts on the inverter
24 = No Alarm	The Digital Output will go to the active status when the inverter is not indicating an alarm
25 = No Fault and Alarm	The Digital Output will go to the active status when a fault is not acting and is not indicating an alarm in the inverter
26 = Network	The Digital Output will go to the active status when the command received via Network is active
27 = SoftPLC	The Digital Output will go to the active status when the command received via SoftPLC is active
28 = Forward Direction	The Digital Output will go to the active state when the inverter is running in the forward direction
29 = Ride-Through	The Digital Output will go to the active status when the Ride-Through function is acting
30 = Pre-Charge OK	The Digital Output will go into the active state when the Pre-charge function indicates that it has been successfully executed
31 = Ready to start	The Digital Output will go to the active state when the inverter has completed the pre-charge and without a RUN command.

C5.2.6 Temperatures to C5.8.6 Temperatures

It allows configuring the temperature accessory connected to the slot.

C5.2.6 Temperatures

C5.3.6 Temperatures

C5.4.6 Temperatures

C5.5.6 Temperatures

C5.6.6 Temperatures

C5.7.6 Temperatures

C5.8.6 Temperatures

.1 Sensor Type

Range:	0 ... 3	Default: 0
Properties:	Stopped	

Description:

It sets the sensor type that will be connected to the accessory.



NOTE!

Individual selection by sensor is not possible. All sensors connected to the same accessory must be of the same type.

Indication	Description
0 = PT100	PT100 Sensor
1 = PT1000	PT1000 Sensor
2 = Single PTC	Single PTC Sensor
3 = Triple PTC	Triple PTC Sensor

C CONFIGURATIONS

C5.2.6 Temperatures

C5.3.6 Temperatures

C5.4.6 Temperatures

C5.5.6 Temperatures

C5.6.6 Temperatures

C5.7.6 Temperatures

C5.8.6 Temperatures

.2 Overtemperature Config.

Range: 0 ... 11 Bit

Default: 0

Properties: Stopped

Description:

It enables the overtemperature faults for each temperature sensor.

Bit	Value/Description
Bit 0 ... 1 S1 Sensor F/A	It enables the overtemperature faults for temperature sensor 1. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Alarm and Fault: Alarm and fault enabled 3 = Inactive: Faults and alarms disabled
Bit 2 ... 3 S2 Sensor F/A	It enables the overtemperature faults for temperature sensor 2. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Alarm and Fault: Alarm and fault enabled 3 = Inactive: Faults and alarms disabled
Bit 4 ... 5 S3 Sensor F/A	It enables the overtemperature faults for temperature sensor 3. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Alarm and Fault: Alarm and fault enabled 3 = Inactive: Faults and alarms disabled
Bit 6 ... 7 S4 Sensor F/A	It enables the overtemperature faults for temperature sensor 4. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Alarm and Fault: Alarm and fault enabled 3 = Inactive: Faults and alarms disabled
Bit 8 ... 9 S5 Sensor F/A	It enables the overtemperature faults for temperature sensor 5. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Alarm and Fault: Alarm and fault enabled 3 = Inactive: Faults and alarms disabled
Bit 10 ... 11 S6 Sensor F/A	It enables the overtemperature faults for temperature sensor 6. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Alarm and Fault: Alarm and fault enabled 3 = Inactive: Faults and alarms disabled

C5.2.6 Temperatures

C5.3.6 Temperatures

C5.4.6 Temperatures

C5.5.6 Temperatures

C5.6.6 Temperatures

C5.7.6 Temperatures

C5.8.6 Temperatures

.3 Measurement Error Config.

Range: 0 ... 11 Bit

Default: 0

Properties: Stopped

Description:

It enables measurement error faults (broken sensor cable, short-circuit sensor) for each temperature sensor.

**NOTE!**

Faults and alarms will occur when the temperature read on the sensors is less than or equal to -20 °C during a 5 minute interval. Resetting of faults and alarms is enabled for temperature values greater than -15 °C.

Bit	Value/Description
Bit 0 ... 1 S1 Sensor F/A	It enables measurement error faults in the temperature sensor 1. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 2 ... 3 S2 Sensor F/A	It enables measurement error faults of temperature sensor 2. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 4 ... 5 S3 Sensor F/A	It enables measurement error faults of temperature sensor 3. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 6 ... 7 S4 Sensor F/A	It enables measurement error faults of temperature sensor 4. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 8 ... 9 S5 Sensor F/A	It enables error faults in the measurement of temperature sensor 5. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled
Bit 10 ... 11 S6 Sensor F/A	It enables error faults in the measurement of temperature sensor 6. 0 = Fault: Fault enabled 1 = Alarm: Alarm enabled 2 = Inactive: Fault and alarms disabled

C5.2.6 Temperatures**C5.3.6 Temperatures****C5.4.6 Temperatures****C5.5.6 Temperatures****C5.6.6 Temperatures****C5.7.6 Temperatures****C5.8.6 Temperatures****.4 Sensor 1 Temp. Setpoint****.5 Sensor 2 Temp. Setpoint****.6 Sensor 3 Temp. Setpoint****.7 Sensor 4 Temp. Setpoint****.8 Sensor 5 Temp. Setpoint****.9 Sensor 6 Temp. Setpoint**

Range: -100.0 ... 250.0 °C

Default: 0.0 °C

Properties: Stopped

Description:

It allows to configure the sensor overtemperature fault setpoint.

C5.3 Slot B

It allows viewing the status of the configuration parameters of the Slot.

C5.4 Slot C

It allows viewing the status of the configuration parameters of the Slot.

C CONFIGURATIONS

C5.5 Slot D

It allows viewing the status of the configuration parameters of the Slot.

C5.6 Slot E

It allows viewing the status of the configuration parameters of the Slot.

C5.7 Slot F

It allows viewing the status of the configuration parameters of the Slot.

C5.8 Slot G

It allows viewing the status of the configuration parameters of the Slot.

C5.9 DO Operation Levels

It allows viewing and configuring the operation conditions of the digital outputs (DOs).

C5.9 DO Operation Levels		
C5.9.1 Fx Frequency		
Range:	0.0 ... 300.0 Hz	Default: 4.0 Hz
Properties:		

Description:

It allows viewing and setting the frequency level (Fx) used in function (F > Fx) for Digital Outputs.

C5.9 DO Operation Levels		
C5.9.2 Fx Hysteresis		
Range:	0.0 ... 15.0 Hz	Default: 2.0 Hz
Properties:		

Description:

It allows viewing and setting the frequency hysteresis level used in function (F > Fx) for Digital Outputs.

C5.9 DO Operation Levels		
C5.9.3 Nx/Ny Hysteresis		
Range:	0 ... 900 rpm	Default: 18 rpm
Properties:		

Description:

It allows viewing and setting the speed hysteresis level used in functions ($N^* > N_x$), ($N > N_x$), ($N < N_y$) and ($N > N_x$ and $N_t > N_x$) for Digital Outputs.

C5.9 DO Operation Levels		
C5.9.4 Nx Speed		
Range:	0 ... 30000 rpm	Default: 120 rpm
Properties:		

Description:

It allows viewing and setting the speed level (Nx) used in function ($N > N_x$) for Digital Outputs.

C5.9 DO Operation Levels		
C5.9.5 Ny Speed		
Range:	0 ... 30000 rpm	Default: 1800 rpm
Properties:		

Description:
It allows viewing and setting the speed level (Ny) used in function (N < Ny) for Digital Outputs.

C5.9 DO Operation Levels		
C5.9.6 Ix Current		
Range:	0.0 ... 200.0 %	Default: 100.0 %
Properties:		

Description:
It allows viewing and setting the current level (Ix) used in functions (I > ix) and (I < ix) for Digital Outputs.

C5.9 DO Operation Levels		
C5.9.8 N = N* Band		
Range:	0 ... 30000 rpm	Default: 18 rpm
Properties:		

Description:
It allows viewing and setting the speed range within which the reference and speed will be considered to be at the same value. Used in function (N* = N) for Digital Outputs.

C5.9 DO Operation Levels		
C5.9.9 Tx Torque		
Range:	0.0 ... 200.0 %	Default: 100.0 %
Properties:		

Description:
It allows viewing and setting the torque level (Tx) used in functions (T > Tx) and (T < Tx) for Digital Outputs.

C5.9 DO Operation Levels		
C5.9.10 Hx Hours		
Range:	0 ... 65536 h	Default: 4320 h
Properties:		

Description:
It allows viewing and setting the number of hours (Hx) used in function (Hours enabled > Hx) for Digital Outputs.

C5.10 DOs delay

It allows setting a delay in the change of state of the digital outputs.

When the timing function is enabled, and the digital output function source undergoes a transition, the digital output will be enabled/disabled according to the time set in the timer.

Figure 9.42 on page 9-91 illustrates this behavior.




Figure 9.42: Example of digital output timer actuation

C CONFIGURATIONS



NOTE!

If more than one timer is set for the same digital output, only the first timer will actuate.

C5.10 DOs delay

C5.10.1 Timer 1 DO

C5.10.4 Timer 2 DO

C5.10.7 Timer 3 DO

Range: 0 ... 58

Default: 0

Properties:

Description:

It defines on which digital output the timer will be used. The options are shown in Table 9.57 on page 9-92.

Table 9.57: Selection of Digital Outputs from Slots X and A...G to set the timer

Digital Output Options for Slots X and A...G								
Indication	Slot X	Slot A	Slot B	Slot C	Slot D	Slot E	Slot F	Slot G
Inactive	0							
DO1	X-1 (1)	A-1 (3)	B-1 (11)	C-1 (19)	D-1 (27)	E-1 (35)	F-1 (43)	G-1 (51)
DO2	X-2 (2)	A-2 (4)	B-2 (12)	C-2 (20)	D-2 (28)	E-2 (36)	F-2 (44)	G-2 (52)
DO3	—	A-3 (5)	B-3 (13)	C-3 (21)	D-3 (29)	E-3 (37)	F-3 (45)	G-3 (53)
DO4	—	A-4 (6)	B-4 (14)	C-4 (22)	D-4 (30)	E-4 (38)	F-4 (46)	G-4 (54)
DO5	—	A-5 (7)	B-5 (15)	C-5 (23)	D-5 (31)	E-5 (39)	F-5 (47)	G-5 (55)
DO6	—	A-6 (8)	B-6 (16)	C-6 (24)	D-6 (32)	E-6 (40)	F-6 (48)	G-6 (56)
DO7	—	A-7 (9)	B-7 (17)	C-7 (25)	D-7 (33)	E-7 (41)	F-7 (49)	G-7 (57)
DO8	—	A-8 (10)	B-8 (18)	C-8 (26)	D-8 (34)	E-8 (42)	F-8 (50)	G-8 (58)

C5.10 DOs delay

C5.10.2 T1 Delay ON

C5.10.5 T2 Delay ON

C5.10.8 T3 Delay ON

Range: 0.0 ... 300.0 s

Default: 0.0 s

Properties:

Description:

It defines the time in seconds for activation of the digital output after a positive transition of the command (depending on the function of the digital output).

After a positive command transition, for the programmed output to be enabled, the command must remain active for at least the time set in this parameter. Otherwise, the timer will be reset and the output will not be enabled. See Figure 9.42 on page 9-91.

C5.10 DOs delay

C5.10.3 T1 Delay OFF

C5.10.6 T2 Delay OFF

C5.10.9 T3 Delay OFF

Range: 0.0 ... 300.0 s

Default: 0.0 s

Properties:

Description:

It defines the time in seconds for disabling the digital output after a negative transition of the command (depending on the function of the digital output).

After a negative transition of the command, for the programmed output to be disabled, the command must remain inactive for at least the time set in this parameter. Otherwise, the timer will be reset and the output will remain enabled. See Figure 9.42 on page 9-91.

C5.11 Control board

Allows you to configure the analog outputs and inputs of the control board.

C5.11.1 Analog inputs

C5.11.1 Analog inputs

C5.11.1.1 AI1 function

C5.11.1.4 AI2 function

Range: 0 ... 3

Default: 0

Properties:

Description:

Setting the function to be used for analog input.

Indication	Description
0 = Not used	
1 = Torque reference	
2 = Limit current	
3 = Field current	

C5.11.1 Analog inputs

C5.11.1.2 AI1 Gain

C5.11.1.5 AI2 Gain

Range: 0.000 ... 9.999

Default: 1.000

Properties:

Description:

Gain setting for analog input.

C5.11.1 Analog inputs

C5.11.1.3 AI1 Offset

C5.11.1.6 AI2 Offset

Range: -100.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Offset setting for analog input.

C5.11.2 Analog outputs

C5.11.2 Analog outputs

C5.11.2.1 AO1 function

C5.11.2.4 AO2 function

C5.11.2.7 AO3 function

C5.11.2.10 AO4 function

Range: 0 ... 254

Default: 0

Properties:

Description:

Setting the function to be used for the analog output.

C CONFIGURATIONS

Indication	Description
0 = 0 V	Constant 0 V
1 = 5 V	Constant 5 V
2 = -5 V	Constant -5 V
3 = 10 V	Constant 10 V
4 = -10 V	Constant -10 V
5 = Modulation index	Modulation index
6 = Frequency	Inverter output frequency
7 = Iout	Amplitude of output currents
8 = Ramp	Ramp exit
12 = Speed	Speed do motor
23 = Lower Vcc	Lower DC voltage of cells
24 = Highest Vcc	Higher DC voltage of cells
34 = Ib	Phase B input current
35 = Ic	C-phase input current
42 = Vab	AB input line voltage
43 = Vbc	BC input line voltage
45 = Ixt	Motor thermal overload protection value
86 = Pout (kW)	Active output power
88 = Pout (kVAr)	Output reactive power
89 = Pout (kVA)	Apparent output power
90 = FPout	Output power factor
91 = Torque	Torque do motor
93 = Pin (kW)	Active input power
94 = Pin (kVAr)	Input reactive power
95 = Pin (kVA)	Apparent input power
96 = FPin	Input power factor
100 = Vout RMS	RMS value of output voltage
101 = Vin RMS	RMS value of input voltage
107 = Iout RMS	RMS value of output current
111 = Iin RMS	RMS value of input current

C5.11.2 Analog outputs

C5.11.2.2 AO1 gain

C5.11.2.5 AO2 gain

C5.11.2.8 AO3 gain

C5.11.2.11 AO4 gain

Range: 0.000 ... 9.999

Default: 1.000

Properties:

Description:

Gain setting for analog output.

C5.11.2 Analog outputs

C5.11.2.3 AO1 offset

C5.11.2.6 AO2 offset

C5.11.2.9 AO3 offset

C5.11.2.12 AO3 offset

Range: -100.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Offset setting for analog output.

C5.11.3 Digital outputs

C5.11.3 Digital outputs

C5.11.3.1 RL8 Function

Range: 0 ... 3

Default: 0

Properties:

Description:

The state of the digital outputs can be monitored in the parameter S3.9.4.1.



NOTE!

When options 1 and 2 are selected to control the output contactor, DI6 on the control board is used to monitor the contactor, and its status can be checked in parameter S3.9.3.1.

Indication	Description
0 = Inactive	Function inactive
1 = Operation with filter type 2	
2 = Operation with permanent magnet machine	The opening of the output contactor is commanded whenever the PWM is disabled Closing is commanded when the inverter is enabled and the contactor is open
3 = Inverter doors lock	In option 3, the relay controls the locking of the doors when the DC link voltage of the cells is greater than 50V and the opening when all cells reach 0V

C5.11.4 Encoder

Allows you to configure the encoder connected to the control board.

C5.11.4.1 Absolute

The encoder baud rate is limited by the length of the cable connecting to the SSI encoder, or by the presence of other transducers on that communication line.

The longer the connection cable between the interface card and the encoder, the lower the baud rate should be.

C5.11.4.1 Absolute

C5.11.4.1.1 Measurement offset

Range: 0.0 ... 360.0 °

Default: 0.0 °

Properties:

Description:

Offset of the motor angular position measurement.

C5.11.4.1 Absolute

C5.11.4.1.2 Configuration

Range: 0 ... 10 Bit

Default: 0

Properties: Stopped

Description:

Absolute encoder SSI interface configuration.

C CONFIGURATIONS

Bit	Value/Description
Bit 0 ... 2 Clock frequency	Sets the communication clock frequency. 0 = 100 kHz 1 = 150 kHz 2 = 200 kHz 3 = 250 kHz 4 = 500 kHz
Bit 3 ... 6 Data bits	Sets the number of bits in the data packets. 0 = 8 bits 1 = 9 bits 2 = 10 bits 3 = 11 bits 4 = 12 bits 5 = 13 bits 6 = 14 bits 7 = 15 bits 8 = 16 bits 9 = 17 bits 10 = 18 bits 11 = 19 bits 12 = 20 bits
Bit 7 ... 8 Parity	Sets the parity of telegram checks. 0 = None 1 = Even 2 = Odd
Bit 9 Encoding	Configures the encoding of data packets. 0 = Binary 1 = Gray
Bit 10 Direction of rotation	Sets the rotation direction of the speed sensor. 0 = Reverse: Sensor installed at the rear of the load 1 = Direct: Sensor installed at the rear of the motor

C5.11.4.2 Incremental

Encoder accessory for control board expansion slot. For vector control with encoder, this accessory must be used.




Figure 9.43: Encoder accessory for speed control (ACCE-ENC item 16584196)

C5.11.4.2 Incremental		
C5.11.4.2.1 Number of Pulses		
Range:	1 ... 65535 ppr	Default: 1024 ppr
Properties:	Stopped	
Description:		
Setting of the number of pulses that the connected encoder generates during one complete revolution.		
C5.11.4.2 Incremental		
C5.11.4.2.2 Configurations		
Range:	0 ... 3 Bit	Default: 8
Properties:	Stopped	

Description:

It allows to configure the broken cable detection, zero search function, and encoder signal direction.

Bit	Value/Description
Bit 0 ... 1 Broken cable	It allows setting the fault action and alarm generation if a broken encoder cable is detected. Refer to the Encoder Input Accessory Manual for details on the technique used to detect broken cable. 0 = Fault: The Inverter will generate a fault if a broken encoder cable is detected 1 = Alarm: The Inverter will indicate an alarm if a broken encoder cable is detected 2 = Inactive: The broken cable detection is disabled
Bit 2 Not used	Not used
Bit 3 Direction of rotation	Sets the rotation direction of the speed sensor. 0 = Reverse: Sensor installed at the rear of the load 1 = Direct: Sensor installed at the rear of the motor

C6 RAMPS

It allows setting the acceleration and deceleration times for the speed or torque reference, defining the command selection between “1st Ramp” and “2nd Ramp” and selecting the desired ramp profile.

C6.1 Speed control

Setting of the speed ramps.

C6.1 Speed control**C6.1.1 Acceleration Time**

Range: 0.1 ... 999.9 s **Default:** 100.0 s

Properties:

Description:

It sets the “1st Ramp” acceleration time for the speed reference. This value corresponds to the time that the ramp varies from 0 rpm to the maximum value C4.3.1.1.2.

C6.1 Speed control**C6.1.2 Deceleration Time**

Range: 0.1 ... 999.9 s **Default:** 180.0 s

Properties:

Description:

It sets the “1st Ramp” deceleration time for the speed reference. This value corresponds to the time that the ramp varies from the maximum value C4.3.1.1.2 to 0 rpm.

C6.1 Speed control**C6.1.3 1st/2nd Ramp Selection**

Range: 0 ... 8 **Default:** 0

Properties: Stopped

C CONFIGURATIONS

Description:

It sets the source of the command for acceleration ramps that will select between the “1st Ramp” and the “2nd Ramp”.

- “1st Ramp” means that the acceleration and deceleration ramps are following the values set in C6.1.1 and C6.1.2 respectively.
- “2nd Ramp” means that the acceleration and deceleration ramps are following the values set in C6.1.4 and C6.1.5 respectively.




Figure 9.44: Command operation 1st/2nd ramp

Indication	Description
0 = 1st Ramp	Fixed at 1st Ramp
1 = 2nd Ramp	Fixed at 2nd Ramp
2 = Serial	Change via 2nd Ramp command of the RS-485 Serial Control Word
3 = Not used	Not used
4 = CAN/CO/DN	Change via 2nd Ramp command of the CAN/CANop/DNet Control Word
5 = SoftPLC	Change via SoftPLC function command
6 = Not used	Not used
7 = Ethernet	Change via 2nd Ramp command of the Ethernet Control Word
8 = DI Ramp Selection	Change via digital input command chosen by the user The digital input can be set in C4.2.3.10

C6.1 Speed control

C6.1.4 2nd Ramp Acceleration Time

Range: 0.1 ... 999.9 s

Default: 100.0 s

Properties:

Description:

It sets the “2nd ramp” acceleration time for the speed reference. This value corresponds to the time that the ramp varies from 0 rpm to the maximum value C4.3.1.1.2.

C6.1 Speed control

C6.1.5 2nd Ramp Deceleration Time

Range: 0.1 ... 999.9 s

Default: 180.0 s

Properties:

Description:

It sets the “2nd ramp” deceleration time for the speed reference. This value corresponds to the time that the ramp varies from the maximum value C4.3.1.1.2 to 0 rpm.

C6.1 Speed control**C6.1.6 Quick Stop Time****Range:** 0.1 ... 999.9 s**Default:** 5.0 s**Properties:****Description:**

It sets the time to linearly decelerate from the maximum speed (defined in C4.3.1.1.2) to 0 when the “Quick Stop” command is activated.

C6.1 Speed control**C6.1.7 Ramp Type****Range:** 0 ... 1**Default:** 0**Properties:** Stopped**Description:**

It sets the reference ramp type: Linear or “S” Curve.

Indication	Description
0 = Linear	It selects the linear profile for the motor acceleration and deceleration ramps
1 = S Ramp	It selects the “S” profile for the motor acceleration and deceleration ramps The “S” ramp reduces mechanical shock during acceleration/deceleration

C6.2 Torque control

It sets the acceleration and deceleration times of the torque reference signal.

C6.2 Torque control**C6.2.1 Increment Ramp****Range:** 0.1 ... 999.9 s**Default:** 20.0 s**Properties:****Description:**

It sets the acceleration time for the torque reference ramp. This value corresponds to the time that the ramp varies from the minimum value C4.3.3.3 to the maximum value C4.3.3.2.

C6.2 Torque control**C6.2.2 Decrement Ramp****Range:** 0.1 ... 999.9 s**Default:** 20.0 s**Properties:****Description:**

It sets the deceleration time for the torque reference ramp. This value corresponds to the time that the ramp varies from the maximum value C4.3.3.2 to the minimum value C4.3.3.3.

C7 PROTECTIONS

It allows configuring the operation, levels and tripping time of the MVW and motor protections.

C7.1 Power supply

It allows configuring the protections related to the power supply voltage.

C7.1 Power supply**C7.1.1 Line phase loss detection****Range:** 0 ... 1**Default:** 0**Properties:**

C CONFIGURATIONS

Description:

Enables the mains phase-loss fault.

Indication	Description
0 = Disabled	Protection disabled
1 = Enabled	Protection enabled The phase loss detector is authorized to operate when: 1. Inverter enabled. 2. Precharge complete.

C7.1 Power supply

C7.1.2 Phase loss detection time

Range: 0.1 ... 60.0 s **Default:** 0.1 s

Properties:

Description:

Defines the minimum time the power supply network must remain in an anomalous condition for the fault to be considered valid (F0303, F0304 and F0305).

C7.1 Power supply

C7.1.3 Level of phase imbalance protection

C7.1.4 Overvoltage level

C7.1.5 Undervoltage level

Range: 10.0 ... 70.0 % **Default:** 10.0 % (C7.1.3)

117.0 % (C7.1.4)

70.0 % (C7.1.5)

Properties:

Description:

It sets the protection tripping level.

C7.2 Ground fault

It allows setting the Ground Fault protection.

C7.2 Ground fault

C7.2.1 Maximum operating time

Range: 0.5 ... 60.0 s **Default:** 0.5 s

Properties:

Description:

Maximum time that the inverter will continue to operate after the value of S2.3.17 becomes greater than the value of C7.2.2.

If the value equal to 60.0 s is programmed, F0316 will no longer be indicated.

C7.2 Ground fault

C7.2.2 Voltage leakage alarm level

C7.2.3 Voltage leakage fault level

Range: 5.0 ... 50.0 % **Default:** 25.0 % (C7.2.2)

50.0 % (C7.2.3)

Properties:

Description:

Comparison levels with the value of S2.3.17 for the indications of A0315 and F0316.

C7.2 Ground fault**C7.2.4 Current leakage fault level**

Range:	1 ... 100 %	Default: 25 %
Properties:		

Description:

Comparison level with the sum value (with filter with time constant of 2 ms) of the three inverter output currents to indicate ground fault.

The fault current level is expressed as a percentage of the inverter's rated current.

See F0317.

C7.3 Motor current

Allows you to configure overcurrent protection on the motor.

C7.3 Motor current**C7.3.2 Motor overcurrent**

Range:	0 ... 1	Default: 1
Properties:		

Description:

Setting instantaneous overcurrent protection by software.

Indication	Description
0 = Inactive	Protection inactive
1 = Active	If the current in the motor reaches the set level, the fault (F0073, F0074 or F0075) will actuate, disabling the inverter

C7.4 Motor overload fault

It allows setting the Motor Overload fault.

C7.4 Motor overload fault**C7.4.1 Enable Fault**

Range:	0 ... 3	Default: 1
Properties:	Stopped	

Description:

It enables the fault and alarm of the motor overload function.

Indication	Description
0 = Disable	Overload fault is disabled. No faults or alarms will be generated for the motor operation in the overload condition
1 = Fault and Alarm	The inverter will display an alarm (A0046) when the motor overload reaches the level programmed in C7.4.2, and the fault will trip (F0072) when the motor overcurrent reaches the value set in the overload fault. Once the fault activates, the inverter will be disabled
2 = Fault	The fault will be activated (F0072) without generating alarms, when the motor overload reaches the level set in the overload fault and the inverter will be disabled
3 = Alarm	Only alarm (A0046) will be generated when the motor current reaches the value programmed in C7.4.2; the inverter will continue operating

C7.4 Motor overload fault**C7.4.2 Alarm Level**

Range:	10 ... 100 %	Default: 70 %
Properties:	Stopped	

C CONFIGURATIONS

Description:

It defines the motor overload fault alarm tripping level (A0046). It is expressed as a percentage of the Overload time limit value.

It will only be effective when C7.4.1 is set to 1 (Fault/Alarm) or 3 (Alarm).

C7.4 Motor overload fault

C7.4.3 Factor @ 100% Rat. Speed

Range: 0 ... 200 %

Default: 100 %

Properties:

Description:

It sets the value of the motor current used for the motor overload fault with 100 % of the rated speed. The full scale of this parameter is the rated motor current C2.1.5.

C7.4 Motor overload fault

C7.4.4 Factor @ 50% Rat. Speed

Range: 0 ... 200 %

Default: 86 %

Properties:

Description:

It sets the value of the motor current used for the motor overload fault with 50 % of the rated speed. The full scale of this parameter is the rated motor current C2.1.5.

C7.4 Motor overload fault

C7.4.5 Factor @ 5% Rat, Speed

Range: 0 ... 200 %

Default: 62 %

Properties:

Description:

It sets the value of the motor current used for the motor overload fault with 5 % of the rated speed. The full scale of this parameter is the rated motor current C2.1.5.

The motor overload current is the current value at which the inverter will understand that the motor is operating under overload, and it is given as a function of the speed being applied to the motor. Parameters C7.4.3, C7.4.4 and C7.4.5 are the three points used to form this curve, as shown in Figure 9.45 on page 9-103.

By adjusting the overload current curve, it is possible to set an overload value that varies according to the motor operating speed (this is the factory default setting), improving the fault for self-ventilated motors. It is also possible to set a constant overload level for any speed applied to the motor for motors with independent ventilation.




Figure 9.45: Overload fault levels



NOTE! The greater the difference between the motor current and the overload current, the faster the fault is activated F0072.

C7.5 Overtemperature

It allows configuring the Overtemperature and Undertemperature faults.

C7.5 Overtemperature		
C7.5.1 Auxiliary temperature measurements		
Range:	0 ... 11 Bit	Default: 0
Properties:	Stopped	

Description:

C CONFIGURATIONS

Bit	Value/Description
Bit 0 ... 3 Sensor overtemperature 1	0 = Protection disabled 1 = 55 °C / 131 °F 2 = 60 °C / 140 °F 3 = 65 °C / 149 °F 4 = 70 °C / 158 °F 5 = 75 °C / 167 °F 6 = 80 °C / 176 °F 7 = 85 °C / 185 °F 8 = 90 °C / 194 °F 9 = 95 °C / 203 °F 10 = 100 °C / 212 °F 11 = 105 °C / 221 °F 12 = 110 °C / 230 °F 13 = 115 °C / 239 °F 14 = 120 °C / 248 °F
Bit 4 ... 7 Sensor overtemperature 2	0 = Protection disabled 1 = 55 °C / 131 °F 2 = 60 °C / 140 °F 3 = 65 °C / 149 °F 4 = 70 °C / 158 °F 5 = 75 °C / 167 °F 6 = 80 °C / 176 °F 7 = 85 °C / 185 °F 8 = 90 °C / 194 °F 9 = 95 °C / 203 °F 10 = 100 °C / 212 °F 11 = 105 °C / 221 °F 12 = 110 °C / 230 °F 13 = 115 °C / 239 °F 14 = 120 °C / 248 °F
Bit 8 ... 11 Sensor overtemperature 3	0 = Protection disabled 1 = 55 °C / 131 °F 2 = 60 °C / 140 °F 3 = 65 °C / 149 °F 4 = 70 °C / 158 °F 5 = 75 °C / 167 °F 6 = 80 °C / 176 °F 7 = 85 °C / 185 °F 8 = 90 °C / 194 °F 9 = 95 °C / 203 °F 10 = 100 °C / 212 °F 11 = 105 °C / 221 °F 12 = 110 °C / 230 °F 13 = 115 °C / 239 °F 14 = 120 °C / 248 °F

C7.5 Overtemperature

C7.5.2 Motor Overtemp. Conf.

Range: 0 ... 3

Default: 3

Properties: Stopped

Description:

It defines the motor overtemperature fault behavior.



ATTENTION!

The PTC must feature reinforced insulation of the live parts of the motor and installation.

This function performs the motor overtemperature fault (F2328) and alarm generation (A2334). For the correct operation, the following items must be observed:

- Only the standard accessory (Slot X) can be used.
- Analog output AO1 set in the PTC function.
- Analog input AI1 set in PTC function.

Once the fault trips, it will be inactive only when the temperature reaches a certain level. The trip and inactivation levels of the alarm and fault can be seen in Table 9.66.

Table 9.66: Trip and inactivation levels of A2334 and F2328

Situation	PTC	Voltage at AI
Goes into alarm A2334 in the temperature rise	$R_{PTC} = 3.51k\Omega$	$V_{AI} > 7.0V$
Goes into fault status F2328 in the temperature rise	$R_{PTC} = 3.9k\Omega$	$V_{AI} > 7.8V$
It disables alarm A2334	$150\Omega < R_{PTC} < 1,6k\Omega$	$0.3 < V_{AI} < 3.2V$
It allows fault disabling F2328	$150\Omega < R_{PTC} < 1,6k\Omega$	$0.3 < V_{AI} < 3.2V$
Goes into fault status F2328 (minimum resistance detection)	$R_{PTC} < 60\Omega$	$V_{AI} < 0.12V$



NOTE!

For this function to work properly, it is important to keep the gain(s) and offset(s) values of the analog inputs and outputs at the factory setting values.

The fault can be disabled, generate only alarm, actuate fault only or actuate alarm and fault according to the table below.

Indication	Description
0 = Alarm and Fault	Alarm and fault enabled
1 = Fault	Fault enabled
2 = Alarm	Alarm enabled
3 = Disabled	Alarm and fault disabled

C7.6 DC Link

Allows you to configure the fault of the inverter's DC link undervoltage.

C7.6 DC Link

C7.6.1 Undervoltage level

Range: 50 ... 100 %

Default: 70 %

Properties:

Description:

Sets the level for the DC link undervoltage fault to occur.

When the Ride-Through feature is enabled (see C3.9.1.1), this is the level for Ride-Through entry.

C7.6 DC Link

C7.6.2 Unbalance level

Range: 10 ... 40 %

Default: 15 %

Properties:

Description:

Defines the maximum unbalance level between positive and negative DC buses; see F0174, F0175, F0176 and F0177.

C CONFIGURATIONS

C7.7 Motor Overspeed

It allows setting the Motor Overspeed fault.

C7.7 Motor Overspeed		
C7.7.1 Maximum Overspeed Level		
Range:	0 ... 100 %	Default: 10 %
Properties:	Stopped	

Description:

It sets the highest speed value the motor can operate at, and should be set as a percentage of the maximum speed limit. The maximum speed limit can be set in C4.3.1.1.2.

When the effective speed exceeds the value of C4.3.1.1.2 + C7.7.1 for more than 20 ms, the MVW will disable the PWM pulses and indicate fault (F2351).

If you want to disable this function, set C7.7.1 = 100 %.

C7.9 Auto-Reset

It allows configuring the inverter Auto-Reset function.

C7.9 Auto-Reset		
C7.9.1 Time		
Range:	0 ... 3600 s	Default: 0 s
Properties:		

Description:

It sets the time value for an automatic reset when a fault occurs.

After the auto-reset is performed, if the same fault actuates again for three consecutive times, the auto-reset function will be inhibited. The actuation of a fault is considered as recurrent if this same fault actuates again within 30 seconds after the auto-reset is performed. Therefore, if a fault operates four consecutive times, the inverter will remain disabled (general disable) and the fault will continue to be actuated.

If $C7.9.1 \leq 2$, no auto-reset will occur.

C7.10 External Fault/Alarm

It allows configuring the External Fault and Alarm functions activated via digital input.

C7.10 External Fault/Alarm		
C7.10.1 External Alarm DI		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

Enables use and defines the digital input that will be used for the No External Alarm function.

When a transition from 1 to 0 occurs in the digital input programmed for the function No External Alarm, alarm A2331 will be indicated. On transition from 0 to 1 on the programmed digital input, the alarm will be cleared. The motor continues to run normally, regardless of the status of the digital input.

The options are shown in the Table 9.15 on page 9-21.

C7.10 External Fault/Alarm		
C7.10.2 External Fault DI		
Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used to disable the External Fault function. Table 9.15 on page 9-21 shows the options.

When a transition from 1 to 0 occurs on the digital input programmed for External Fault, the inverter goes into fault indicating fault F2332 as shown in Figure 9.46 on page 9-107.




Figure 9.46: External fault via digital input

C7.11 Thermal management

The thermal management function is a set of faults and actions that the inverter performs as a function of measured and estimated temperatures of the IGBTs, rectifiers, heatsink and internal air to protect the equipment integrity and functionality.

C7.11 Thermal management		
C7.11.13 Thermal protection relay 1		
C7.11.14 Thermal protection relay 2		
C7.11.15 Thermal protection relay 3		
Range:	0 ... 9 Bit	Default: 1021
Properties:		

Description:

This parameter enables communication with the thermal protection relay and defines the inverter action upon detecting overtemperature or sensor fault.

If a channel temperature reaches the limit configured in the relay, the inverter will act according to the programming (e.g., disable the motor). The system indicates the fault, preventing overheating that could degrade insulation materials, damage the equipment, or cause accidents.

These relays are an integral part of the inverter protection system, playing a fundamental role in the safety and reliability of the electrical installation.

The module serial communication must be configured with the following parameters:

- Baudrate: 9600 bps
- Address: 1, 2, 3, 4, 5 or 6
- Parity: Even
- Stop bits: 1



ATTENTION!

During the use of functions **PRG** (programming) and **VIS** (viewing) of the relay, data exchange is interrupted, which may cause a time-out error in the communication with the inverter.

C CONFIGURATIONS



ATTENTION!

In case of sensor break (open circuit) in a temperature channel, the reading will indicate the full scale value.

Bit	Value/Description
Bit 0 Communication	Enables communication with the thermal protection relay. 0 = Disable: Communication with relay disabled 1 = Enable: Communication enabled, in case of overtemperature the inverter will protect the equipment according to the fault configuration of the respective channel
Bit 1 Communication lost action	0 = Fault trip: In case of loss of communication, it causes a fault in the inverter, requiring a fault reset to return to normal operation 1 = Alarm: In case of loss of communication, it signals an alarm
Bit 2 CH1 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 3 CH2 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 4 CH3 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 5 CH4 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 6 CH5 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 7 CH6 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 8 CH7 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 9 CH8 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment

C7.11 Thermal management

C7.11.16 Thermal protection relay 4

Range: 0 ... 9 Bit

Default: 1021

Properties:

Description:

This parameter enables communication with the thermal protection relay and defines the inverter action upon detecting overtemperature or sensor fault.

If a channel temperature reaches the limit configured in the relay, the inverter will act according to the programming (e.g., disable the motor). The system indicates the fault, preventing overheating that could degrade insulation materials, damage the equipment, or cause accidents.

These relays are an integral part of the inverter protection system, playing a fundamental role in the safety and reliability of the electrical installation.

The module serial communication must be configured with the following parameters:

- Baudrate: 9600 bps
- Address: 1, 2, 3, 4, 5 or 6
- Parity: Even
- Stop bits: 1



ATTENTION!

During the use of functions **PRG** (programming) and **VIS** (viewing) of the relay, data exchange is interrupted, which may cause a time-out error in the communication with the inverter.



ATTENTION!

In case of sensor break (open circuit) in a temperature channel, the reading will indicate the full scale value.

Bit	Value/Description
Bit 0 Communication	Enables communication with the thermal protection relay. 0 = Disable: Communication with relay disabled 1 = Enable: Communication enabled, in case of overtemperature the inverter will protect the equipment according to the fault configuration of the respective channel
Bit 1 Communication lost action	0 = Fault trip: In case of loss of communication, it causes a fault in the inverter, requiring a fault reset to return to normal operation 1 = Alarm: In case of loss of communication, it signals an alarm
Bit 2 CH1 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 3 CH2 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 4 CH3 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 5 CH4 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 6 CH5 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 7 CH6 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 8 CH7 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 9 CH8 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment

C7.11 Thermal management

C7.11.17 Thermal protection relay 5

Range: 0 ... 9 Bit

Default: 1021

Properties:

Description:

This parameter enables communication with the thermal protection relay and defines the inverter action upon detecting overtemperature or sensor fault.

C CONFIGURATIONS

If a channel temperature reaches the limit configured in the relay, the inverter will act according to the programming (e.g., disable the motor). The system indicates the fault, preventing overheating that could degrade insulation materials, damage the equipment, or cause accidents.

These relays are an integral part of the inverter protection system, playing a fundamental role in the safety and reliability of the electrical installation.

The module serial communication must be configured with the following parameters:

- Baudrate: 9600 bps
- Address: 1, 2, 3, 4, 5 or 6
- Parity: Even
- Stop bits: 1



ATTENTION!

During the use of functions **PRG** (programming) and **VIS** (viewing) of the relay, data exchange is interrupted, which may cause a time-out error in the communication with the inverter.



ATTENTION!

In case of sensor break (open circuit) in a temperature channel, the reading will indicate the full scale value.

Bit	Value/Description
Bit 0 Communication	Enables communication with the thermal protection relay. 0 = Disable: Communication with relay disabled 1 = Enable: Communication enabled, in case of overtemperature the inverter will protect the equipment according to the fault configuration of the respective channel
Bit 1 Communication action	0 = Fault trip: In case of loss of communication, it causes a fault in the inverter, requiring a fault reset to return to normal operation 1 = Alarm: In case of loss of communication, it signals an alarm
Bit 2 CH1 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 3 CH2 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 4 CH3 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 5 CH4 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 6 CH5 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 7 CH6 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 8 CH7 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 9 CH8 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment

C7.11 Thermal management

C7.11.18 Thermal protection relay 6

Range: 0 ... 9 Bit

Default: 1021

Properties:

Description:

This parameter enables communication with the thermal protection relay and defines the inverter action upon detecting overtemperature or sensor fault.

If a channel temperature reaches the limit configured in the relay, the inverter will act according to the programming (e.g., disable the motor). The system indicates the fault, preventing overheating that could degrade insulation materials, damage the equipment, or cause accidents.

These relays are an integral part of the inverter protection system, playing a fundamental role in the safety and reliability of the electrical installation.

The module serial communication must be configured with the following parameters:

- Baudrate: 9600 bps
- Address: 1, 2, 3, 4, 5 or 6
- Parity: Even
- Stop bits: 1

**ATTENTION!**

During the use of functions **PRG** (programming) and **VIS** (viewing) of the relay, data exchange is interrupted, which may cause a time-out error in the communication with the inverter.

**ATTENTION!**

In case of sensor break (open circuit) in a temperature channel, the reading will indicate the full scale value.

Bit	Value/Description
Bit 0 Communication	Enables communication with the thermal protection relay. 0 = Disable: Communication with relay disabled 1 = Enable: Communication enabled, in case of overtemperature the inverter will protect the equipment according to the fault configuration of the respective channel
Bit 1 Communication action	0 = Fault trip: In case of loss of communication, it causes a fault in the inverter, requiring a fault reset to return to normal operation 1 = Alarm: In case of loss of communication, it signals an alarm
Bit 2 CH1 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 3 CH2 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 4 CH3 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 5 CH4 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 6 CH5 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 7 CH6 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 8 CH7 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment
Bit 9 CH8 faults	0 = Inativas: Overtemperature protection inactive 1 = Ativas: In case of overtemperature or sensor failure, the inverter disables the PWM to protect the equipment

C CONFIGURATIONS

C7.11 Thermal management

C7.11.20 Thermal balance

Range: 0 ... 1

Default: 1

Properties:

Description:

Indication	Description
0 = Inactive	
1 = Active	

C7.14 Encoder

It allows setting the Encoder protections.

C7.14 Encoder

C7.14.1 Encoder Protection Config.

Range: 0 ... 1

Default: 1

Properties: Stopped

Description:

This parameter allows enabling or disabling the detection of the fault F2322 (Reversed Encoder/Motor Wiring) and is only used for vector control with Encoder (C3.1.1 = 2). This protection identifies whether the direction of rotation of the motor is in accordance with the direction of the Encoder A and B pulses. The protection can operate in two conditions: during the Self-Tuning routine with the motor spinning (C3.3.2.6.1 = 2) and with the motor running.



NOTE!

Some conditions must be observed:

- During Self-Tuning with the motor spinning (C3.3.2.6.1 = 2) and for any type of motor (C2.1.1), the protection will always be active (even if C7.14.1 = 0);
- With the motor running/spinning, the protection will only be active if C7.14.1 = 1 and C2.1.1 = 0 (Induction Motor), that is, it will not work for synchronous motors.

Indication	Description
0 = Inactive fault	The fault F2322 is disabled
1 = Active fault	The fault F2322 is enabled

C7.15 History

It allows setting options related to alarm history.

C7.15 History

C7.15.1 Enable Alarm Hist.

Range: 0 ... 1

Default: 0

Properties:

Description:

It enables the recording of alarms in the history.

If disabled, new entries will not be saved in the product memory.



NOTE!

Viewing the history captured before this parameter was disabled remains available for viewing via HMI or reading via WPS.

Indication	Description
0 = Disabled	It indicates that the alarm history is disabled New alarms are not saved in memory and only existing entries in the history are displayed on the HMI and read by the WPS
1 = Enabled	It indicates that the alarm history is enabled

C7.16 Electronics power supply

C7.16 Electronics power supply

C7.16.1 Number of electronics power supplies

Range: 0 ... 3

Default: 3

Properties:

Description:

Indication	Description
0 = None	No PS1 font installed
1 = One PS1	One PS1 power supply installed
2 = Two PS1	Two PS1 power supplies installed
3 = Three PS1	Three PS1 power supplies installed

C7.17 Electric arc

Configures protections related to arc fault detection in the panel

C7.17 Electric arc

C7.17.1 Electric arc detection

Range: 0 ... 2 Bit

Default: 7

Properties:

Description:

Allows configuring the electric arc detection function through the fiber optic receivers of the CCE and CIB boards.

The corresponding fields must be configured according to the sensor used in the detection process.

Bit	Value/Description
Bit 0 Sensor A	Electric arc detection by sensor A connected to the optical fiber OPTO IN (1) (F0031) on the CCE board 0 = Disabled: Function disabled 1 = Enabled: Enabled function
Bit 1 Sensor B	Electric arc detection by sensor B connected to the optical fiber OPTO IN (2) (F0032) on the CCE board 0 = Disabled: Function disabled 1 = Enabled: Enabled function
Bit 2 Sensor C	Electric arc detection by sensor C connected to the optical fiber OPTO IN (3) (F0033) on the CCE board 0 = Disabled: Function disabled 1 = Enabled: Enabled function

C9 COMMUNICATIONS

It sets the MVW to exchange information via communication network.

C9.1 Communication Errors

It allows setting the operation of the fault for the communication interfaces and related protocols.

C9.1.1 Master Offline

Communication interruption fault with the network master.

C CONFIGURATIONS

If for some reason the communication between the product and the network master is interrupted, a communication error will be issued, an alarm or fault will be displayed on the HMI, depending on the programming of this menu.

It only occurs after the device is online.

C9.1.1 Master Offline

C9.1.1.1 Mode

Range: 0 ... 2

Default: 2

Properties:

Description:

It allows configuring the fault tripping mode against interruption in the communication with the network master.

Indication	Description
0 = Inactive	Alarm and fault disabled
1 = Fault	Only fault enabled. It disables the motor
2 = Alarm	Alarm enabled. Acts as described in C9.1.1.2

C9.1.1 Master Offline

C9.1.1.2 Alarm Action

Range: 0 ... 4

Default: 2

Properties:

Description:

Action for offline communication alarm for any network interface - A2335, A2339, A2337, A2338, A2339, A2340, A2342, A2349 and A2350.

The actions described in this parameter are performed by writing the respective bits in the control word of the communication/interface protocol. Thus, for the commands to take effect, the equipment must be programmed to be controlled by the network interface used. This programming is done through menu C4.

Indication	Description
0 = Off	No action is taken; the equipment remains in the current status
1 = Stop by Ramp	The ramp to stop command is executed, and the motor stops according to the programmed deceleration ramp
2 = General Disable	The equipment is general disabled and the motor stops by inertia
3 = Go to R1	The equipment is commanded to the remote 1 status
4 = Go to R2	The equipment is commanded to the remote 2 status



NOTE!

The alarm action will only have a function if the error tripping mode in C9.1.1.1 is programmed for Alarm.

C9.1.2 Master Idle/Prog

Network master status fault.

If there is a transition of the network master status from the operation mode (Run) to the configuration mode (Idle/Prog), a communication error will be issued, an alarm or fault will be displayed on the HMI, depending on the programming made in this menu.

It only occurs after the network master Run mode is detected. The way to detect this condition depends on the communication protocol and the network master.

C9.1.2 Master Idle/Prog**C9.1.2.1 Mode****Range:** 0 ... 2**Default:** 2**Properties:****Description:**

It allows configuring the fault tripping mode when the network master is placed in programming mode (Idle/Prog).

Indication	Description
0 = Inactive	Alarm and fault disabled
1 = Fault	Only fault enabled. It disables the motor
2 = Alarm	Acts as an alarm. Action described in C9.1.2.2

C9.1.2 Master Idle/Prog**C9.1.2.2 Alarm Action****Range:** 0 ... 4**Default:** 2**Properties:****Description:**

Action for master alarm in programming mode (Idle/Prog) - A2341.

The actions described in this parameter are performed by writing the respective bits in the control word of the communication/interface protocol. Thus, for the commands to take effect, the equipment must be programmed to be controlled by the network interface used. This programming is done through menu C4.

Indication	Description
0 = Off	No action is taken; the equipment remains in the current status
1 = Stop by Ramp	The ramp to stop command is executed, and the motor stops according to the programmed deceleration ramp
2 = General Disable	The equipment is general disabled and the motor stops by inertia
3 = Go to R1	The equipment is commanded to the remote 1 status
4 = Go to R2	The equipment is commanded to the remote 2 status

**NOTE!**

The alarm action will only have a function if the error tripping mode in C9.1.2.1 is programmed for Alarm.

C9.2 I/O Data

It sets the cyclic data exchange area of the communication networks.

C9.2.1 Reading data

It configures a set of 16-bit parameters to be read via communication network.

C9.2.1 Reading data**C9.2.1.1 Word #1**

C9.2.1.1 to C9.2.1.100

C9.2.1 Reading data**C9.2.1.100 Word #100****Range:** 0 ... 9999**Default:** 0**Properties:** Stopped

C CONFIGURATIONS

Description:

It selects the address (Net Id) of the parameter whose content should be provided in the reading area for the fieldbus interfaces (input: sent to the network master).

The size of the referenced parameter must be taken into account. If the data size is greater than 16 bits, the configuration parameter of the next programmable word must be set to the same address.

C9.2.2 Writing data

It configures a set of 16-bit parameters to be written via communication network.

C9.2.2 Writing data		
C9.2.2.1 Update Delay		
Range:	0.0 ... 999.0 s	Default: 0.0 s
Properties:		

Description:

Whenever there is a transition from offline (without cyclic data) to online (with cyclic writing data), the data received via communication network (writing words) is ignored during this programmed time, remaining in the status it was before the beginning of the reception.




Figure 9.47: Delay in the update of the I/O words

C9.2.2 Writing data	
C9.2.2.2 Word #1	

C9.2.2.2 to C9.2.2.101

C9.2.2 Writing data		
C9.2.2.101 Word #100		
Range:	0 ... 9999	Default: 0
Properties:	Stopped	

Description:

It selects the address (Net Id) of the parameter whose content should be provided in the writing area for the fieldbus interfaces (output: received from the network master).

The size of the referenced parameter must be taken into account. If the data size is greater than 16 bits, the configuration parameter of the next programmable word must be set to the same address.

C9.3 Serial RS485

Configuration for the RS485 communication interface and the protocols that use this interface.

For a detailed description, refer to the MVW Modbus-RTU Communication Manual, available in electronic format.

C9.3 Serial RS485**C9.3.2 Address**

Range:	1 ... 247	Default: 1
Properties:	Stopped	

Description:

It select the address used for the serial communication.

It is necessary that each device on the network has a different address from all the others.

C9.3 Serial RS485**C9.3.3 Baud Rate**

Range:	0 ... 3	Default: 1
Properties:	Stopped	

Description:

Select the desired value for the baud rate of the serial interface in bit per second. This rate must be the same for all devices connected to the network.

Indication	Description
0 = 9600 bit/s	Rate of 9600 bits per second
1 = 19200 bit/s	Rate of 19200 bits per second
2 = 38400 bit/s	Rate of 38400 bits per second
3 = 57600 bit/s	Rate of 57600 bits per second

C9.3 Serial RS485**C9.3.4 Bytes Configuration**

Range:	0 ... 5	Default: 1
Properties:	Stopped	

Description:

Select the settings for the number of data bits, parity and stop bits in the serial interface bytes. This setting must be identical for all the devices connected to the network.

Indication	Description
0 = 8-bits, no, 1	8 bits, no parity, 1 stop bit
1 = 8-bits, even, 1	8 bits, with even parity, 1 stop bit
2 = 8-bits, odd, 1	8 bits, with odd parity, 1 stop bit
3 = 8-bits, no, 2	8 bits, no parity, 2 stop bit
4 = 8-bits, even, 2	8 bits, with even parity, 2 stop bit
5 = 8-bits, odd, 2	8 bits, with odd parity, 2 stop bit

C9.3 Serial RS485**C9.3.5 RS485 Timeout**

Range:	0.0 ... 999.0 s	Default: 0.0 s
Properties:	Stopped	

Description:

Maximum time without communication.

C9.4 Ethernet

Settings for the product built-in Ethernet port.

For a detailed description, refer to the MVW Modbus TCP Communication Manual, available in electronic format.

C CONFIGURATIONS

C9.4 Ethernet

C9.4.1 IP Address Settings

Range:	0 ... 1	Default: 1
Properties:	Stopped	

Description:

It allows setting the IP address for the built-in Ethernet interface.

Indication	Description
0 = Parameters	The IP address, subnet mask and gateway must be set through the product parameters
1 = DHCP	It enables the DHCP function. The IP address and other network settings are received from a DHCP server via network

C9.4 Ethernet

C9.4.2 IP Address

Range:	0.0.0.0 ... 255.255.255.255	Default: 192.168.0.10
Properties:	Stopped	

Description:

It allows programming the IP address of the Ethernet interface. It only takes effect if the address was set via parameters.

C9.4 Ethernet

C9.4.3 Network Mask

Range:	0 ... 31	Default: 24
Properties:	Stopped	

Description:

It allows programming the subnet mask used for the Ethernet interface. It only takes effect if the address was set via parameters.

The following table shows the allowable values for CIDR and the equivalent dot-separated notation for the subnet mask:

Indication	Description
0 = Not used	Subnet mask
1 = 128.0.0.0	Subnet mask
2 = 192.0.0.0	Subnet mask
3 = 224.0.0.0	Subnet mask
4 = 240.0.0.0	Subnet mask
5 = 248.0.0.0	Subnet mask
6 = 252.0.0.0	Subnet mask
7 = 254.0.0.0	Subnet mask
8 = 255.0.0.0	Subnet mask
9 = 255.128.0.0	Subnet mask
10 = 255.192.0.0	Subnet mask
11 = 255.224.0.0	Subnet mask
12 = 255.240.0.0	Subnet mask
13 = 255.248.0.0	Subnet mask
14 = 255.252.0.0	Subnet mask
15 = 255.254.0.0	Subnet mask
16 = 255.255.0.0	Subnet mask
17 = 255.255.128.0	Subnet mask
18 = 255.255.192.0	Subnet mask
19 = 255.255.224.0	Subnet mask
20 = 255.255.240.0	Subnet mask

Indication	Description
21 = 255.255.248.0	Subnet mask
22 = 255.255.252.0	Subnet mask
23 = 255.255.254.0	Subnet mask
24 = 255.255.255.0	Subnet mask. Factory setting
25 = 255.255.255.128	Subnet mask
26 = 255.255.255.192	Subnet mask
27 = 255.255.255.224	Subnet mask
28 = 255.255.255.240	Subnet mask
29 = 255.255.255.248	Subnet mask
30 = 255.255.255.252	Subnet mask
31 = 255.255.255.254	Subnet mask

C9.4 Ethernet**C9.4.4 Gateway**

Range:	0.0.0.0 ... 255.255.255.255	Default: 0.0.0.0
Properties:	Stopped	

Description:

It allows programming the IP address of the default gateway used by the Ethernet interface. It only takes effect if the address was set via parameters.

C9.4 Ethernet**C9.4.5 SNTP - Server 1**

Range:	0.0.0.0 ... 255.255.255.255	Default: 0.0.0.0
Properties:	Stopped	

Description:

It allows programming the IP address of the NTP primary server. If the value is zero, the NTP client is disabled.

C9.4 Ethernet**C9.4.6 SNTP - Server 2**

Range:	0.0.0.0 ... 255.255.255.255	Default: 0.0.0.0
Properties:	Stopped	

Description:

It allows programming the IP address of the NTP secondary server.

C9.4 Ethernet**C9.4.7 SNTP - Update**

Range:	0 ... 65535	Default: 0
Properties:	Stopped	

Description:

It indicates the NTP server date and time update interval. If the value is zero, the NTP client is disabled. The minimum interval is 15 seconds.

C9.4 Ethernet**C9.4.8 Enable protocols**

Range:	0 ... 2 Bit	Default: 3
Properties:		

C CONFIGURATIONS

Description:

It allows enabling and disabling functionalities of some protocols, limiting the exposure of the inverter via network.

Bit	Value/Description
Bit 0 Web Server	0 = Disabled: Protocol disabled 1 = Enabled: Protocol enabled
Bit 1 Not used	Not used
Bit 2 Not used	Not used

C9.5 EtherNet/IP

It allows programming how the EtherNet/IP network protocol writing and reading data exchange should be using the MVW built-in Ethernet port.

C9.5 EtherNet/IP

C9.5.1 EtherNet/IP I/O Instances

Range:	0 ... 10	Default: 0
Properties:	Stopped	

Description:

It allows selecting the Assembly class instance used during the exchange of I/O data with the network master.

The MVW frequency inverter has eleven setting options. Four of them follow the standard defined in the ODVA AC/DC Drive Profile. The others represent specific words for the MVW frequency inverter. The table below detail each of these control and status words.

Indication	Description
0 = 20/70 CIP	Basic Speed, these instances represent the simplest operation interface of a device according to the AC/DC Drive Profile
1 = 21/71 CIP	Extended Speed, these instances represent a slightly improved interface for operating the device that follows the AC/DC Device Profile
2 ... 3 = Not used	Not used
4 = 120/170 CIP + I/O data	They have the same data format as the 20/70 CIP Basic Speed Control instances. In addition, it is possible to program up to 48 parameters of the equipment itself for reading and/or 48 for writing via network
5 = 121/171 CIP + I/O data	They have the same data format as the 21/71 CIP Extended Speed Control instances. In addition, it is possible to program up to 48 parameters of the device itself for reading and/or 48 for writing via network
6 ... 7 = Not used	Not used
8 = 100/150 Manuf. + I/O data	These instances represent the operating interface of the device according to the MVW frequency inverter profile. Besides the control and status words, speed reference and effective value, it is possible to program up to 48 parameters of the device itself for reading and/or writing via network
9 = 101/151 Manuf. + I/O data	These instances represent an interface very similar to the 100/150 Manufacturer Speed Control + configurable I/O data, with the only difference being the possibility of sending the torque limit
10 = 102/152 Config I/O data	In these instances it is possible to program up to 50 parameters of the equipment itself for reading and/or 50 for writing via network

C9.5 EtherNet/IP

C9.5.2 Readings 1st Word

Range:	1 ... 100	Default: 1
Properties:	Stopped	

Description:

Sets the index of the first programmable reading word for data exchange with the network (input to the network master).

C9.5 EtherNet/IP**C9.5.3 Readings Quantity**

Range:	0 ... 50	Default: 0
Properties:	Stopped	

Description:

Sets the number of programmable reading words for data exchange with the network (input to the network master), from the first word set in C8.4.1.

C9.5 EtherNet/IP**C9.5.4 Writings 1st Word**

Range:	1 ... 100	Default: 1
Properties:	Stopped	

Description:

Sets the index of the first programmable writing word for data exchange with the network (output to the network master).

C9.5 EtherNet/IP**C9.5.5 Writings Quantity**

Range:	0 ... 50	Default: 0
Properties:	Stopped	

Description:

Sets the number of programmable writing words for data exchange with the network (output to the network master), from the first word set in C8.4.3.

C9.6 Modbus TCP

It allows setting the Modbus TCP network protocol using the MVW built-in Ethernet port.

C9.6 Modbus TCP**C9.6.1 TCP Port**

Range:	0 ... 65535	Default: 0
Properties:	Stopped	

Description:

It allows setting the number of the TCP port used for Modbus TCP connections.

Port 502 is the default TCP port for Modbus TCP connections, and it is always available. If you want an additional port to establish Modbus TCP connections, you can set the number of another TCP port in this parameter.

**NOTE!**

After changing this property, the device must be turned off and back on to effect the modifications.

C9.6 Modbus TCP**C9.6.3 Timeout**

Range:	0.0 ... 999.0 s	Default: 0.0 s
Properties:	Stopped	

Description:

Time to detect interruption in Modbus TCP communication.

After the Modbus TCP communication is started, if the device stops receiving valid telegrams for a period longer than the one programmed in this parameter, it will consider that the communication has been interrupted, and will indicate alarm/fault. For the case of an alarm, the action for communication error will also be performed.

C CONFIGURATIONS

Time counting will start from the first valid telegram received. The value 0.0 disables this function.

C9.6 Modbus TCP

C9.6.4 Connection Timeout

Range:	1 ... 65535 s	Default: 65 s
Properties:		

Description:

Time to detect interruption in Modbus TCP communication.

After the Modbus TCP communication is started, if the device stops receiving valid telegrams for a period longer than the one programmed in this parameter, it will consider that the communication has been interrupted, and will indicate alarm/fault. For the case of an alarm, the action for communication error will also be performed.

Time counting will start from the first valid telegram received. The value 0.0 disables this function.

C9.7 Anybus

Settings for the Anybus communication accessory and the protocols that use this interface.

For a detailed description, see the MVW Anybus Communication Manual, provided in electronic format.

C9.7 Anybus

C9.7.1 Readings 1st Word

Range:	1 ... 100	Default: 1
Properties:	Stopped	

Description:

It sets the index of the first programmable reading word for data exchange with the network (input to the network master).

C9.7 Anybus

C9.7.2 Readings Quantity

Range:	2 ... 50	Default: 2
Properties:	Stopped	

Description:

It sets the number of programmable reading words for data exchange with the network (input to the network master), from the first word set in C8.6.2.

C9.7 Anybus

C9.7.3 Writings 1st Word

Range:	1 ... 100	Default: 1
Properties:	Stopped	

Description:

It sets the index of the first programmable writing word for data exchange with the network (output to the network master).

C9.7 Anybus

C9.7.4 Writings Quantity

Range:	2 ... 50	Default: 2
Properties:	Stopped	

Description:

It sets the number of programmable writing words for data exchange with the network (output to the network master), from the first word set in C8.6.4.

C9.7 Anybus**C9.7.5 Address**

Range:	0 ... 255	Default: 0
Properties:	Stopped	

Description:

It selects the address used by the Anybus module on the network.

It is necessary that each device on the network have a different address from all the others. This setting is only used for Anybus PROFIBUS module. Allowed range of values is from 1 to 126.

**NOTE!**

After changing this configuration, for the change to take effect, the equipment must be turned off and on again, or the settings must be updated via C8.3.1.

C9.7 Anybus**C9.7.8 IP Address Settings**

Range:	0 ... 1	Default: 1
Properties:	Stopped	

Description:

It allows setting the IP address configuration for the Anybus EtherNet/IP, Modbus TCP and PROFINET IO modules.

Indication	Description
0 = Parameters	The IP address, subnet mask and gateway must be set through the product parameters
1 = DHCP	It enables the DHCP function. The IP address and other network settings are received from a DHCP server via network

C9.7 Anybus**C9.7.9 IP Address**

Range:	0.0.0.0 ... 255.255.255.255	Default: 192.168.0.10
Properties:	Stopped	

Description:

It allows programming the IP address of the Anybus EtherCAT or PROFINET IRT module. It only takes effect if C9.7.9 = Parameters.

**NOTE!**

After changing this configuration, for the change to take effect, the equipment must be turned off and on again, or the settings must be updated via C9.7.1.

C9.7 Anybus**C9.7.10 CIDR Subnet**

Range:	0 ... 31	Default: 24
Properties:	Stopped	

Description:

It allows programming the subnet mask used by the Anybus-CC EtherCAT or PROFINET IRT module. It only takes effect if C9.7.9 = Parameters.

C CONFIGURATIONS

Indication	Description
0 = Not used	Subnet mask
1 = 128.0.0.0	Subnet mask
2 = 192.0.0.0	Subnet mask
3 = 224.0.0.0	Subnet mask
4 = 240.0.0.0	Subnet mask
5 = 248.0.0.0	Subnet mask
6 = 252.0.0.0	Subnet mask
7 = 254.0.0.0	Subnet mask
8 = 255.0.0.0	Subnet mask
9 = 255.128.0.0	Subnet mask
10 = 255.192.0.0	Subnet mask
11 = 255.224.0.0	Subnet mask
12 = 255.240.0.0	Subnet mask
13 = 255.248.0.0	Subnet mask
14 = 255.252.0.0	Subnet mask
15 = 255.254.0.0	Subnet mask
16 = 255.255.0.0	Subnet mask
17 = 255.255.128.0	Subnet mask
18 = 255.255.192.0	Subnet mask
19 = 255.255.224.0	Subnet mask
20 = 255.255.240.0	Subnet mask
21 = 255.255.248.0	Subnet mask
22 = 255.255.252.0	Subnet mask
23 = 255.255.254.0	Subnet mask
24 = 255.255.255.0	Subnet mask. Factory setting
25 = 255.255.255.128	Subnet mask
26 = 255.255.255.192	Subnet mask
27 = 255.255.255.224	Subnet mask
28 = 255.255.255.240	Subnet mask
29 = 255.255.255.248	Subnet mask
30 = 255.255.255.252	Subnet mask
31 = 255.255.255.254	Subnet mask

C9.7 Anybus

C9.7.11 Gateway

Range:	0.0.0.0 ... 255.255.255.255	Default: 0.0.0.0
Properties:	Stopped	

Description:

It allows programming the IP address of the default gateway used by the Anybus EtherCAT or PROFINET IRT module. It only takes effect if C9.7.9 = Parameters.



NOTE!

After changing this configuration, for the modification to be effective, the equipment must be turned off and on again, or the settings must be updated via C9.7.1.

C9.8 CAN/CANopen/DNet

It configures CAN communication accessory and protocols that use this interface.

C9.8 CAN/CANopen/DNet**C9.8.1 Protocol**

Range:	0 ... 2	Default: 2
Properties:	Stopped	

Description:

It allows selecting the desired protocol for the CAN interface.

Indication	Description
0 = Disabled	It disables the CAN interface
1 = CANopen	It enables the CAN interface with CANopen protocol
2 = DeviceNet	It enables the CAN interface with DeviceNet protocol

C9.8 CAN/CANopen/DNet**C9.8.2 Address**

Range:	0 ... 127	Default: 63
Properties:	Stopped	

Description:

It allows programming the address used for CAN communication of the device. It is necessary that each device on the network has a different address from the others. Valid addresses for this parameter depend on the protocol selected in C9.8.1:

- C9.8.1 = 1 (CANopen): valid addresses: 1 to 127.
- C9.8.1 = 2 (DeviceNet): valid addresses: 0 to 63.

**NOTE!**

After changing this configuration, the modification will only take effect if the CAN interface is not exchanging cyclical data with the network.

C9.8 CAN/CANopen/DNet**C9.8.3 Baud Rate**

Range:	0 ... 5	Default: 0
Properties:	Stopped	

Description:

It allows programming the desired value for the baud rate of the CAN interface in bit per second. This rate must be the same for all devices connected to the network. The supported baud rates for the device depend on the protocol set in C9.8.1:

- C9.8.1 = 1 (CANopen): any rate indicated in this parameter can be used, but it does not have the automatic rate detection function (autobaud).
- C9.8.1 = 2 (DeviceNet): Only rates of 500, 250 and 125 Kbit/s are supported. Other options enable the automatic rate detection function (autobaud).

For the autobaud function, after a successful detection, the baud rate parameter (C9.8.3) automatically changes to the detected rate. To run the autobaud function again, it is necessary to change the parameter C9.8.3 to one of the autobaud options.

Indication	Description
0 = 1 Mbps/Auto	CAN baud rate (automatic detection for DeviceNet)
1 = Not used/Auto	Automatic detection for DeviceNet
2 = 500 Kbps	CAN baud rate
3 = 250 Kbps	CAN baud rate

C CONFIGURATIONS

Indication	Description
4 = 125 Kbps	CAN baud rate
5 = 100 Kbps/Auto	CAN baud rate (automatic detection for DeviceNet)



NOTE!

After changing this configuration, the modification will only take effect if the CAN interface is not exchanging cyclical data with the network.

C9.8 CAN/CANopen/DNet

C9.8.4 Bus Off Reset

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

It allows programming the behavior of the equipment when detecting a bus off error on the CAN interface.

Indication	Description
0 = Manual	If bus off occurs, A134/F234 will be displayed on the HMI and the communication will be disabled. In case of alarm, the action programmed in parameter C9.1.2.2 will be executed. For the equipment to communicate again via CAN interface, it will be necessary to disable and enable the interface, or restart the product
1 = Automatic	If bus off occurs, the communication will be automatically restarted, and the error will be ignored. In this case the alarm will not be displayed on the HMI and the device will not execute the action described in C9.1.2.2

C9.8 CAN/CANopen/DNet

C9.8.5 DeviceNet I/O Instances

Range:	0 ... 10	Default: 0
Properties:	Stopped	

Description:

It allows selecting the Assembly class instance used during the exchange of I/O data with the network master.

The MVW frequency inverter has eleven setting options. Four of them follow the standard defined in the ODVA AC/DC Drive Profile. The others represent specific words for the MVW frequency inverter. The table below detail each of these control and status words.

Indication	Description
0 = 20/70 CIP	Basic Speed, these instances represent the simplest operation interface of a device according to the AC/DC Drive Profile
1 = 21/71 CIP	Extended Speed, these instances represent a slightly improved interface for operating the device that follows the AC/DC Device Profile
2 ... 3 = Not used	Not used
4 = 120/170 CIP + I/O data	They have the same data format as the 20/70 CIP Basic Speed Control instances. In addition, it is possible to program up to 48 parameters of the equipment itself for reading and/or 48 for writing via network
5 = 121/171 CIP + I/O data	They have the same data format as the 21/71 CIP Extended Speed Control instances. In addition, it is possible to program up to 48 parameters of the device itself for reading and/or 48 for writing via network
6 ... 7 = Not used	Not used
8 = 100/150 Manuf. + I/O data	These instances represent the operating interface of the device according to the MVW frequency inverter profile. Besides the control and status words, speed reference and effective value, it is possible to program up to 48 parameters of the device itself for reading and/or writing via network
9 = 101/151 Manuf. + I/O data	These instances represent an interface very similar to the 100/150 Manufacturer Speed Control + configurable I/O data, with the only difference being the possibility of sending the torque limit
10 = 102/152 Config I/O data	In these instances it is possible to program up to 50 parameters of the equipment itself for reading and/or 50 for writing via network

**NOTE!**

After changing this configuration, the modification will only take effect if the CAN interface is not exchanging cyclical data with the network.

C9.8 CAN/CANopen/DNet**C9.8.6 DNet Reading 1st Word**

Range:	1 ... 100	Default: 1
Properties:	Stopped	

Description:

It sets the index of the first programmable reading word for data exchange with the network (input to the network master).

C9.8 CAN/CANopen/DNet**C9.8.7 DNet Reading Quantity**

Range:	0 ... 50	Default: 0
Properties:	Stopped	

Description:

It sets the number of programmable reading words for data exchange with the network (input to the network master), from the first configured word.

C9.8 CAN/CANopen/DNet**C9.8.8 DNet Writing 1st Word**

Range:	1 ... 100	Default: 1
Properties:	Stopped	

Description:

It sets the index of the first programmable writing word for data exchange with the network (output to the network master).

C9.8 CAN/CANopen/DNet**C9.8.9 DNet Writing Quantity**

Range:	0 ... 50	Default: 0
Properties:	Stopped	

Description:

It sets the number of programmable writing words for data exchange with the network (output to the network master), from the first configured word.

C9.10 SymbiNet

SymbiNet is a communication protocol that enables information exchange directly between devices that support such protocol. For the MVW, the communication is performed via Ethernet interface.

Characteristics:

- All data exchange is done directly between the devices in the network without the need of a master to manage communication.
- All the communication programming can be performed using parameters without the need of a configuration tool.
- Programming for data exchange is based on existing Modbus registers for the device. Therefore, the list of Modbus registers must be known for correct data addressing during programming.

C CONFIGURATIONS

- It uses the Publisher/Subscriber mechanism, where each device publishes its data so that one or more subscribers receive this information. Besides optimizing communication, it allows a decentralized communication control, allowing each device to identify problems and continue communication even if failures occur with one or more members of the network.

Typical applications:

- Load division
- Pumping system with multiple pumps
- Speed follower

SymbiNet communication normally operates in conjunction with SoftPLC, or with product embedded applications, such as load sharing or multipump functions, which make use of this communication to exchange the necessary data between products.

Operation principle:

To program data exchange, each member of the network has a set of data groups. Each group represents a sequence of data that the local station must receive from another network member. It means, when programming these groups, the user must indicate which data the local station must receive from the other stations.

The programming must be made for each member of the network, indicating all the groups that this member needs to receive from the other participants, and where this data must be saved locally. Once the groups are programmed in all the members, the devices themselves are responsible for establishing connections and requests for data exchange.

Each programmed group has a status indication, informing if the data received by that group is up to date. If any member of the network is powered off or disconnected, it stops transmitting the published data, and the groups that should receive data from this member will be flagged as outdated. The local application can use this information to perform some action relevant to that indication.

Restrictions:

- For the Ethernet network, all the members of the network must belong to the same sub-net, since the address programming is done by indicating only the last octet of the IP address of the remote stations.
- Each equipment has 8 data groups that can be programmed to request data from other stations, and each equipment can also respond to up to 8 different data groups requested by other stations.
- Some product features and applications make use of this communication, and cannot operate in conjunction with the protocol itself, programmed through parameters.

C9.10 SymbiNet

C9.10.1 Enable Protocol

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

Allows enabling SymbiNet protocol over Ethernet interface, for data exchange among SymbiNet devices.

Indication	Description
0 = Disable	Disable function
1 = Enable	It enables function

C9.10 SymbiNet**C9.10.2 Publication Time****Range:** 2 ... 100 ms**Default:** 20 ms**Properties:****Description:**

Allows you to program, in milliseconds, the time of publication of the data requested by the remote stations.

This time is also used as a basis for timeout detection of locally programmed groups. If the data programmed for a group is no longer received for more than 10 times the time programmed in this parameter, the group status is marked as inactive.

It is recommended that all participants of the SymbiNet network have equal times.

C9.10 SymbiNet**C9.10.3 Grp1: Source Addr.****Range:** 0 ... 254**Default:** 0**Properties:****Description:**

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet**C9.10.4 Grp1: Source Reg.****Range:** 0 ... 65535**Default:** 0**Properties:****Description:**

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet**C9.10.5 Grp1: Dest. Reg.****Range:** 0 ... 65535**Default:** 0**Properties:****Description:**

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet**C9.10.6 Grp1: Num. of Registers****Range:** 0 ... 8**Default:** 0**Properties:****Description:**

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet**C9.10.7 Grp2: Source Addr.****Range:** 0 ... 254**Default:** 0**Properties:****Description:**

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

C CONFIGURATIONS

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet

C9.10.8 Grp2: Source Reg.

Range: 0 ... 65535 Default: 0

Properties:

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet

C9.10.9 Grp2: Dest. Reg.

Range: 0 ... 65535 Default: 0

Properties:

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet

C9.10.10 Grp2: Num. of Registers

Range: 0 ... 8 Default: 0

Properties:

Description:

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet

C9.10.11 Grp3: Source Addr.

Range: 0 ... 254 Default: 0

Properties:

Description:

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet

C9.10.12 Grp3: Source Reg.

Range: 0 ... 65535 Default: 0

Properties:

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet

C9.10.13 Grp3: Dest. Reg.

Range: 0 ... 65535 Default: 0

Properties:

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet**C9.10.14 Grp3: Num. of Registers****Range:** 0 ... 8**Default:** 0**Properties:****Description:**

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet**C9.10.15 Grp4: Source Addr.****Range:** 0 ... 254**Default:** 0**Properties:****Description:**

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet**C9.10.16 Grp4: Source Reg.****Range:** 0 ... 65535**Default:** 0**Properties:****Description:**

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet**C9.10.17 Grp4: Dest. Reg.****Range:** 0 ... 65535**Default:** 0**Properties:****Description:**

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet**C9.10.18 Grp4: Num. of Registers****Range:** 0 ... 8**Default:** 0**Properties:****Description:**

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet**C9.10.19 Grp5: Source Addr.****Range:** 0 ... 254**Default:** 0**Properties:****Description:**

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C CONFIGURATIONS

C9.10 SymbiNet

C9.10.20 Grp5: Source Reg.

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet

C9.10.21 Grp5: Dest. Reg.

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet

C9.10.22 Grp5: Num. of Registers

Range: 0 ... 8

Default: 0

Properties:

Description:

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet

C9.10.23 Grp6: Source Addr.

Range: 0 ... 254

Default: 0

Properties:

Description:

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet

C9.10.24 Grp6: Source Reg.

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet

C9.10.25 Grp6: Dest. Reg.

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet

C9.10.26 Grp6: Num. of Registers

Range: 0 ... 8

Default: 0

Properties:

Description:

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet**C9.10.27 Grp7: Source Addr.**

Range: 0 ... 254

Default: 0

Properties:

Description:

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet**C9.10.28 Grp7: Source Reg.**

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet**C9.10.29 Grp7: Dest. Reg.**

Range: 0 ... 65535

Default: 0

Properties:

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet**C9.10.30 Grp7: Num. of Registers**

Range: 0 ... 8

Default: 0

Properties:

Description:

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C9.10 SymbiNet**C9.10.31 Grp8: Source Addr.**

Range: 0 ... 254

Default: 0

Properties:

Description:

Program the address of a remote station, responsible for publishing the Modbus registers programmed in this group.

For Ethernet, this address represents the last octet of the IP address. The other three octets are the same to the IP address of localhost.

C9.10 SymbiNet**C9.10.32 Grp8: Source Reg.**

Range: 0 ... 65535

Default: 0

Properties:

C CONFIGURATIONS

Description:

Program the initial address of the Modbus registers to be published by the remote station.

C9.10 SymbiNet		
C9.10.33 Grp8: Dest. Reg.		
Range:	0 ... 65535	Default: 0
Properties:		

Description:

Program the initial address of the Modbus registers where the received data will be saved locally.

C9.10 SymbiNet		
C9.10.34 Grp8: Num. of Registers		
Range:	0 ... 8	Default: 0
Properties:		

Description:

Program the number of Modbus registers that are going to be published by the remote station and saved locally.

C10 SOFTPLC

The SoftPLC provides the inverter with PLC functions (Programmable Logical Controller). For more details regarding the programming of these functions in the MVW, refer to the Help texts in the WPS software (WEG Programming Suite).

C10.1 Configuration

It allows setting parameters of the SoftPLC function.

C10.1 Configuration		
C10.1.1 Command		
Range:	0 ... 5	Default: 0
Properties:	Stopped	

Description:

Allow the user to execute commands for the application.

Indication	Description
0 = Stop	For the active application
1 = Run	It runs the active application
2 ... 4 = Not used	
5 = Erase	It deletes the active user application

C10.1 Configuration		
C10.1.2 Active Application		
Range:	0 ... 6	Default: 0
Properties:	Stopped	

Description:

It allows the user to select the active application.

Indication	Description
0 = User Application 1	When selected, it is possible to download, stop, run or delete the user application configured in the WPS software
1 = User Application 2	When selected, it is possible to download, stop, execute or delete another user program
2 ... 6 = Not used	Not used

C10.1 Configuration**C10.1.3 Application Stopped Action**

Range:	0 ... 2	Default: 0
Properties:		

Description:

Allow the user to set the action for when the SoftPLC application is not running.

Indication	Description
0 = Inactive	No action
1 = Generate Alarm	It generates the alarm A2708
2 = Trip Fault	It trips fault. F2709

C10.2 Engineering unit**C10.2 Engineering unit****C10.2.1 Engineering Unit 1**

Range:	0 ... 64	Default: 0
Properties:		

Description:

This parameter selects the engineering unit displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (engineering unit) will be displayed in this format.

The options are shown in the table below.

Engineering Unit Options

0 = No Unit	11 = m ³ /h	22 = gal/s	33 = kgf/m ²	44 = mca	55 = Nm
1 = A	12 = m ³ /min	23 = H	34 = kl/h	45 = m	56 = Pa
2 = bar	13 = m ³ /s	24 = Hz	35 = kPa	46 = m/h	57 = %
3 = °C	14 = °F	25 = HP	36 = kW	47 = m/min	58 = psi
4 = CPM	15 = ft	26 = h	37 = kWh	48 = m/s	59 = rpm
5 = CV	16 = ft/h	27 = in	38 = l	49 = mbar	60 = s
6 = ft ³	17 = ft/min	28 = lnWC	39 = l/h	50 = ms	61 = V
7 = ft ³ /h	18 = ft/s	29 = K	40 = l/min	51 = min	62 = W
8 = ft ³ /min	19 = gal	30 = kg	41 = l/s	52 = MPa	63 = W/m ²
9 = ft ³ /s	20 = gal/h	31 = kgf	42 = lbf	53 = mwc	64 = Wh/m ²
10 = m ³	21 = gal/min	32 = kgf/cm ²	43 = mA	54 = N	

Table 9.91: Engineering Units associated with the SoftPLC user parameter

C10.2 Engineering unit**C10.2.2 Dec. Point Eng. Unit 1**

Range:	0 ... 3	Default: 1
Properties:		

Description:

This parameter selects the decimal point displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (decimal point) will be displayed in this format.

C10.2 Engineering unit**C10.2.3 Engineering Unit 2**

Range:	0 ... 64	Default: 0
Properties:		

C CONFIGURATIONS

Description:

This parameter selects the engineering unit displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (engineering unit) will be displayed in this format.

Table 9.91 on page 9-135 shows the options.

C10.2 Engineering unit		
C10.2.4 Dec. Point Eng. Unit 2		
Range:	0 ... 3	Default: 1
Properties:		

Description:

This parameter selects the decimal point displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (decimal point) will be displayed in this format.

C10.2 Engineering unit		
C10.2.5 Engineering Unit 3		
Range:	0 ... 64	Default: 0
Properties:		

Description:

This parameter selects the engineering unit displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (engineering unit) will be displayed in this format.

Table 9.91 on page 9-135 shows the options.

C10.2 Engineering unit		
C10.2.6 Dec. Point Eng. Unit 3		
Range:	0 ... 3	Default: 1
Properties:		

Description:

This parameter selects the decimal point displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (decimal point) will be displayed in this format.

C10.2 Engineering unit		
C10.2.7 Engineering Unit 4		
Range:	0 ... 64	Default: 0
Properties:		

Description:

This parameter selects the engineering unit displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (engineering unit) will be displayed in this format.

Table 9.91 on page 9-135 shows the options.

C10.2 Engineering unit		
C10.2.8 Dec. Point Eng. Unit 4		
Range:	0 ... 3	Default: 1
Properties:		

Description:

This parameter selects the decimal point displayed on the HMI, that is, any SoftPLC user parameter associated with this parameter (decimal point) will be displayed in this format.

C12 BACKUP

It allows to perform operations related to copying or restoring MVW parameter sets. Among these operations are loading the factory default values and export of parameter sets via SD card and HMI.

C12 Backup

C12.1 Load Parameters

Range: 0 ... 12

Default: 0

Properties: Stopped

Description:

It selects what to load or save in the MVW settings.

It allows you to restore the factory default, as well as load or save parameter sets 1, 2, 3, SD card and HMI.

Indication	Description																						
0 = Not Used	Not used																						
1 = Default 60 Hz	It loads the MVW settings with the default content of the parameters																						
2 = Default 50 Hz	It loads the MVW settings with the default content of the parameters All parameters are loaded with the default value of 60 Hz, with the exception of the following cases: <table> <tr> <td>■ C4.3.2.1 set at 125 rpm;</td><td>■ C4.3.1.1.2 set at 1500 rpm;</td></tr> <tr> <td>■ C4.3.1.3.1 set at 75 rpm;</td><td>■ C5.9.3 set at 15 rpm;</td></tr> <tr> <td>■ C4.3.1.5.1 set at 75 rpm;</td><td>■ C5.9.4 set at 100 rpm;</td></tr> <tr> <td>■ C4.3.1.5.2 set at 250 rpm;</td><td>■ C5.9.5 set at 1500 rpm;</td></tr> <tr> <td>■ C4.3.1.5.3 set at 500 rpm;</td><td>■ C5.9.8 set at 15 rpm;</td></tr> <tr> <td>■ C4.3.1.5.4 set at 750 rpm;</td><td>■ C2.1.8 set at 1458 rpm;</td></tr> <tr> <td>■ C4.3.1.5.5 set at 1000 rpm;</td><td>■ C2.1.6 set at 50 Hz;</td></tr> <tr> <td>■ C4.3.1.5.6 set at 1250 rpm;</td><td>■ C3.3.4.1.1 set at 1500 rpm;</td></tr> <tr> <td>■ C4.3.1.5.7 set at 1500 rpm;</td><td>■ C3.3.4.1.2 set at 1500 rpm;</td></tr> <tr> <td>■ C4.3.1.5.8 set at 1375 rpm;</td><td></td></tr> <tr> <td>■ C4.3.1.1.1 set at 75 rpm;</td><td></td></tr> </table>	■ C4.3.2.1 set at 125 rpm;	■ C4.3.1.1.2 set at 1500 rpm;	■ C4.3.1.3.1 set at 75 rpm;	■ C5.9.3 set at 15 rpm;	■ C4.3.1.5.1 set at 75 rpm;	■ C5.9.4 set at 100 rpm;	■ C4.3.1.5.2 set at 250 rpm;	■ C5.9.5 set at 1500 rpm;	■ C4.3.1.5.3 set at 500 rpm;	■ C5.9.8 set at 15 rpm;	■ C4.3.1.5.4 set at 750 rpm;	■ C2.1.8 set at 1458 rpm;	■ C4.3.1.5.5 set at 1000 rpm;	■ C2.1.6 set at 50 Hz;	■ C4.3.1.5.6 set at 1250 rpm;	■ C3.3.4.1.1 set at 1500 rpm;	■ C4.3.1.5.7 set at 1500 rpm;	■ C3.3.4.1.2 set at 1500 rpm;	■ C4.3.1.5.8 set at 1375 rpm;		■ C4.3.1.1.1 set at 75 rpm;	
■ C4.3.2.1 set at 125 rpm;	■ C4.3.1.1.2 set at 1500 rpm;																						
■ C4.3.1.3.1 set at 75 rpm;	■ C5.9.3 set at 15 rpm;																						
■ C4.3.1.5.1 set at 75 rpm;	■ C5.9.4 set at 100 rpm;																						
■ C4.3.1.5.2 set at 250 rpm;	■ C5.9.5 set at 1500 rpm;																						
■ C4.3.1.5.3 set at 500 rpm;	■ C5.9.8 set at 15 rpm;																						
■ C4.3.1.5.4 set at 750 rpm;	■ C2.1.8 set at 1458 rpm;																						
■ C4.3.1.5.5 set at 1000 rpm;	■ C2.1.6 set at 50 Hz;																						
■ C4.3.1.5.6 set at 1250 rpm;	■ C3.3.4.1.1 set at 1500 rpm;																						
■ C4.3.1.5.7 set at 1500 rpm;	■ C3.3.4.1.2 set at 1500 rpm;																						
■ C4.3.1.5.8 set at 1375 rpm;																							
■ C4.3.1.1.1 set at 75 rpm;																							
3 = Param. Set 1 -> MVW	It loads the MVW settings with the content of parameter set 1																						
4 = Param. Set 2 -> MVW	It loads the MVW settings with the content of parameter set 2																						
5 = Param. Set 3 -> MVW	It loads the MVW settings with the content of parameter set 3																						
6 = MVW -> Param. Set 1	It saves the content of the MVW current settings for parameter set 1																						
7 = MVW -> Param. Set 2	It saves the content of the MVW current settings for parameter set 2																						
8 = MVW -> Param. Set 3	It saves the content of the MVW current settings for parameter set 3																						
9 = SD Card -> MVW	It loads the MVW settings with the content of parameter set imported from the SD card Additionally, it imports the settings of parameter sets 1, 2 and 3 from the SD card to the inverter memory																						
10 = MVW -> SD Card	It saves the content of the actual MVW settings on the SD card Additionally, it exports the settings from parameter sets 1, 2 and 3 to the SD card																						
11 ... 12 = Not used	Not used																						

Figure 9.48 on page 9-138 illustrates the operation of copying and restoring parameters. The current configuration is represented by the inverter. Each of the arrows indicates a possible operation. The side without the arrowhead indicates the parameter set to be copied, and the side with the arrowhead indicates the destination for this set. The parameter set that is already saved in the destination is overwritten during the operation.




Figure 9.48: Load settings



NOTE!

If the parameter set to be loaded is incompatible with the inverter version, the parameters are not loaded. If the parameter set to be loaded is from a different inverter model, model-specific parameters are not loaded.



ATTENTION!

Do not turn off the inverter while the parameter copy or restore command is being executed. If this happens, it is recommended that the command be carried out again.

C12 Backup

C12.2 DI Load User 1

Range: 0 ... 62

Default: 0

Properties: Stopped

Description:

It enables the use and defines the digital input that will be used to load the MVW settings with the contents of user memory 1. Table 9.15 on page 9-21 shows the options.

The loading process is carried out when the DIx status changes from low level to high level (transition from 0 to 24 V), provided that the content of the MVW current settings has been previously transferred to user memory 1.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X
7 = DI A-1	Enable use of digital input DI1 of Slot A

Indication	Description
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G
62 = DI G-8	Enable use of digital input DI8 of Slot G

C CONFIGURATIONS

C12 Backup

C12.3 DI Load User 2

Range: 0 ... 62

Default: 0

Properties: Stopped

Description:

It enables the use and defines the digital input that will be used to load the MVW settings with the contents of user memory 2. Table 9.15 on page 9-21 shows the options.

The loading process is carried out when the DIx status changes from low level to high level (transition from 0 to 24 V), provided that the content of the MVW current settings has been previously transferred to user memory 2.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X
7 = DI A-1	Enable use of digital input DI1 of Slot A
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E

Indication	Description
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G
62 = DI G-8	Enable use of digital input DI8 of Slot G

C12 Backup**C12.4 DI Load User 3**

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It enables the use and defines the digital input that will be used to load the MVW settings with the contents of user memory 3. Table 9.15 on page 9-21 shows the options.

The loading process is carried out when the DIx status changes from low level to high level (transition from 0 to 24 V), provided that the content of the MVW current settings has been previously transferred to user memory 3.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X
7 = DI A-1	Enable use of digital input DI1 of Slot A
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B

C CONFIGURATIONS

Indication	Description
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G
62 = DI G-8	Enable use of digital input DI8 of Slot G

C12 Backup

C12.5 Load sets 1/2 DI

Range: 0 ... 62

Default: 0

Properties: Stopped

Description:

Enables the use and defines the digital input that will be used to load the inverter settings with the contents of parameter group 1 or 2.

Parameter group 1 is loaded when the DIx state changes from low to high (0 to 24 V transition), while parameter group 2 is loaded when the DIx state changes from high to low (24 to 0 V transition). In both cases, loading is only performed if the contents of the current inverter settings have previously been transferred to the parameter group in question.

The options are shown in Table 9.15 on page 9-21.


NOTE!

If the digital input is powered by the IOS board voltage source, when the inverter is de-energized, the DI power supply will also be removed. A high-to-low transition can occur moments before the inverter is completely de-energized. The operation to load the parameter group will only be performed partially, resulting in unwanted parameter settings. Parameter D4.1.11.1 will indicate "Not Used". If this situation occurs, it is necessary to reload the desired parameter group.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X
7 = DI A-1	Enable use of digital input DI1 of Slot A
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E

C CONFIGURATIONS

Indication	Description
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G
62 = DI G-8	Enable use of digital input DI8 of Slot G

C13 NOMINAL DATA

Permite configurar os dados nominais do inversor.

C13.1 Inverter

Dados nominais do inversor.

C13.1 Inverter

C13.1.1 Rated output voltage

Range: 0 ... 9

Default: 4

Properties:

Description:

It defines the inverter rated voltage according to the available models.

Indication	Description
0 = 220 V	
1 = 380 V	
2 = 2300 V	
3 = 3300 V	
4 = 4160 V	
5 = 4600 V	
6 ... 8 = Not used	Not used
9 = 6900 V	

C13.1 Inverter

C13.1.2 Rated Current

Range: 24 ... 65530 A

Default: 140 A

Properties: Stopped

Description:

It defines the inverter rated current.

10 A APPLICATION

User applications.

Special functions for motor control, processes or user program.

A1 USER PARAMETERS

SoftPLC user parameter setting.

This menu is accessible on the HMI only if there is a program saved in the SoftPLC memory area with valid configuration of the user parameters.



NOTE!

Minimum, maximum, current and default values are not displayed on the HMI for user parameters whose value can exceed six digits.

A2 PID CONTROLLER

The PID CONTROLLER application can be used to control a process in closed loop. This application places a proportional, integral and derivative controller superimposed on the normal speed control of the MVW, with selection options for:

- Control setpoint source;
- Process variable source;
- Manual or automatic operation mode;
- Alarms due to low or high level of the process variable;
- Configuration of forward or reverse control action;
- Setting conditions to activate the sleep and wake mode.

Basically, the PID CONTROLLER application compares the control setpoint to the process variable and controls the motor speed to try to eliminate any errors so as to keep the process variable equal to the control setpoint required by the user. The setting of the gains P, I and D determine the speed at which the inverter will respond to eliminate that error. Figure 10.1 on page 10-1 shows the block diagram of the PID controller.




Figure 10.1: Block diagram of the PID controller

A APPLICATION

Application examples of the PID controller:

- Flow or pressure control in a pipe system.
- Temperature of a furnace or oven.
- Dosing of chemicals in tanks.

Academic PID Controller

The PID controller implemented on the MVW is academic. See below the equations that characterize the Academic PID controller, which is the base of this function algorithm.

The transfer function in the frequency domain of the Academic PID controller is:

$$y(s) = k_p \times e(s) \times \left[1 + \frac{1}{sT_i} + sT_d \right]$$

Replacing the integrator by a sum and the derivative by the incremental quotient, we obtain the approximation for the discrete (recursive) transfer equation presented below:

$$y(k) = i(k-1) + k_p \left[\left(1 + K_i T_a + \frac{K_d}{T_a} \right) . e(k) - \left(\frac{K_d}{T_a} \right) . e(k-1) \right]$$

where:

$y(k)$: PID controller actual output;

$i(k-1)$: integral value in the previous state of the PID controller;

k_p : Proportional gain = A2.2.2.1;

K_i : Integral gain = A2.2.2.2 = $\left[\frac{1}{T_i(s)} \right]$;

K_d : Differential Gain = A2.2.2.3 = $[T_d(s)]$;

T_a : PID controller sampling period = A2.3.1.2;

$e(k)$: actual error, being $[SP(k) - PV(k)]$ for forward action, and $[PV(k)] - SP(k)]$ for reverse action;

$e(k-1)$: previous error, being $[SP(k-1) - PV(k-1)]$ for forward action, and $[PV(k-1)] - SP(k-1)]$ for reverse action;

SP : actual control setpoint of the PID controller;

PV : PID controller process variable

A2.1 Monitoring

It allows viewing the reading parameters of the PID controller.

A2.1 Monitoring		
A2.1.1 Setpoint		
Range:	-32768 ... 32767	Default: 0
Properties:		

Description:

It indicates the PID controller setpoint value in automatic mode. Its source is defined by parameter A2.3.2.1, motor.ring unit by parameter A2.3.3.2, decimal place by parameter A2.3.3.3, and scale by parameters A2.3.3.4 and A2.3.3.5.

A2.1 Monitoring		
A2.1.2 Setpoint (%)		
Range:	0.00 ... 100.00 %	Default: 0.00 %
Properties:		

Description:

Indicates the control setpoint (reference) value of the PID Controller in %.

A2.1 Monitoring**A2.1.3 Process Variable**

Range: -32768 ... 32767

Default: 0

Properties:

Description:

It indicates the PID controller process variable value. Its source is defined by parameter A2.3.3.1, motor.ring unit by parameter A2.3.3.2, decimal place by parameter A2.3.3.3, and scale by parameters A2.3.3.4 and A2.3.3.5.

The conversion of the value read by the analog input in percentage into the value of the process variable shown in A2.1.3 according to the scale is done through the following formula:

$$A2.1.3 = [ValueAI(\%) \times (A2.3.3.5 - A2.3.3.4)] + [A2.3.3.4]$$

A2.1 Monitoring**A2.1.4 Process variable**

Range: 0.00 ... 100.00 %

Default: 0.00 %

Properties:

Description:

Indicates the value of the PID controller process variable in percentage and according to the source defined in A2.3.3.1.

A2.1 Monitoring**A2.1.5 Controller Output**

Range: 0 ... 60000 rpm

Default: 0 rpm

Properties:

Description:

It indicates the output value of the PID controller. This value is applied to the speed reference when the PID controller is operating in both automatic or manual mode. The PID controller operates (active state) when the motor is running (Run) and the speed reference source defined in C4.3.1.2.1 or C4.3.1.2.2 is in PID Controller.

A2.1 Monitoring**A2.1.6 Logical Status**

Range: 0 ... 6 Bit

Default: 0

Properties:

Description:

It allows monitoring the logical status of the PID Controller application. Each bit represents a status.

A APPLICATION

Bit	Value/Description
Bit 0 Operation State	0 = Inactive: It indicates that the PID controller is not controlling the process variable neither sending speed reference 1 = Active: It indicates that the PID controller is controlling the process variable in automatic or manual mode and sending speed reference
Bit 1 Sleep Mode	0 = No: It indicates that the PID controller is not in the sleep mode 1 = Yes: It indicates that the PID controller is in the sleep mode
Bit 2 Automatic Mode	0 = No: PID controller operating in manual mode 1 = Yes: PID controller operating in automatic mode
Bit 3 PV Low Level Alarm	0 = No: Inverter is not with alarm A2430 1 = Yes: Inverter is with alarm A2430
Bit 4 PV Low Level Fault	0 = No: Inverter is not with fault F2431 1 = Yes: Inverter is with fault F2431
Bit 5 PV High Level Alarm	0 = No: Inverter is not with alarm A2432 1 = Yes: Inverter is with alarm A2432
Bit 6 PV High Level Fault	0 = No: Inverter is not with fault F2433 1 = Yes: Inverter is with fault F2433

A2.2 Regulation

It allows setting the setpoint values and gains of the PID controller.

A2.2.1 Setpoint

A2.2.1 Setpoint

A2.2.1.1 Automatic Mode

Range: -32768 ... 32767

Default: 0

Properties:

Description:

It defines the PID controller setpoint value when it is in automatic mode, and the control source is programmed to be via parameter (A2.3.2.1 = 0).

A2.2.1 Setpoint

A2.2.1.2 Manual Mode

Range: 0 ... 60000 rpm

Default: 0 rpm

Properties:

Description:

It defines the value of the PID controller output when it is in the manual mode, that is, when the PID controller works in manual mode, the value defined as manual setpoint is transferred directly to the PID controller output.

A2.2.1 Setpoint

A2.2.1.3 Filter

Range: 0.000 ... 9.999 s

Default: 0.150 s

Properties:

Description:

It sets the time constant of the 1st order filter to be applied to the PID controller control setpoint and has the purpose of reducing sudden changes in the setpoint value.

A2.2.2 Gains

A2.2.2 Gains

A2.2.2.1 Proportional

Range: 0.00 ... 99.99

Default: 1.00

Properties:

Description:

They define the gains of the PID controller and must be set according to the quantity or process that is being controlled. Table 10.2 on page 10-6 shows suggestions for initial gain setting values for the PID controller according to the process to be controlled.

A2.2.2 Gains**A2.2.2.2 Integral****Range:** 0.00 ... 99.99**Default:** 5.00**Properties:****Description:**

They define the gains of the PID controller and must be set according to the quantity or process that is being controlled. Table 10.2 on page 10-6 shows suggestions for initial gain setting values for the PID controller according to the process to be controlled.

A2.2.2 Gains**A2.2.2.3 Derivative****Range:** 0.00 ... 99.99**Default:** 0.00**Properties:****Description:**

They define the gains of the PID controller and must be set according to the quantity or process that is being controlled. Table 10.2 on page 10-6 shows suggestions for initial gain setting values for the PID controller according to the process to be controlled.

A2.3 Configuration

It allows configuring how the PID controller will act in the control of the process variable.

A2.3.1 Controle

It allows configuring the PID controller control.

A2.3.1 Controle**A2.3.1.1 Action Control Selection****Range:** 0 ... 1**Default:** 0**Properties:** Stopped**Description:**

It defines how the control action of the PID controller will be.

Indication	Description
0 = Direct	It defines that the PID controller will be enabled and the control or regulation action will be direct. That is, the error will be the value of the control setpoint (A2.1.1) minus the value of the control process variable (A2.1.3)
1 = Reverse	It defines that the PID controller will be enabled and the control or regulation action will be reversed. That is, the error will be the value of the control process variable (A2.1.3) minus the control setpoint value (A2.1.1)



NOTE!

The control action of the PID controller must be direct when, in order to increase the value of the process variable, it is necessary to increase the output of the PID controller. E.g.: Pump driven by an inverter filling a tank. For the level of the tank (process variable) to increase, it is necessary that the flow increase, which is accomplished by increasing the speed of the motor.

The control action of the PID controller must be reversed when, to increase the value of the process variable, it is necessary to decrease the output of the PID controller. E.g.: Fan driven by an inverter cooling a cooling tower. When an increase in temperature is desired (process variable), it is necessary to reduce the ventilation by reducing the motor speed.

A2.3.1 Controle

A2.3.1.2 Sampling Period

Range:	0.050 ... 9.999 s	Default: 0.100 s
Properties:	Stopped	

Description:

It defines the PID controller sampling period. Table 10.2 on page 10-6 shows the suggestions of initial values of the sampling period for the PID controller according to the process to be controlled.

Table 10.2: Suggestions of setting the PID controller gains and sampling period

Quantity	Sampling Period A2.3.1.2	Gains		
		Proportional A2.2.2.1	Integral A2.2.2.2	Derivative A2.2.2.3
Pressure in pneumatic system	0,10 s	0,10	5,00	0,00
Flow in pneumatic system	0,10 s	0,10	5,00	0,00
Pressure in hydraulic system	0,10 s	0,10	5,00	0,00
Flow in hydraulic system	0,10 s	0,10	5,00	0,00
Temperature	0,50 s	0,20	0,50	0,10

A2.3.2 Setpoint

It allows setting the PID controller setpoint.

A2.3.2 Setpoint

A2.3.2.1 Source Selection

Range:	0 ... 2	Default: 0
Properties:	Stopped	

Description:

It defines the control setpoint source in automatic mode of the PID controller.

Indication	Description
0 = Parameter	It defines that the PID controller control setpoint source in automatic mode will be the value set in parameter A2.2.1.1 through the MVW frequency inverter HMI or written via communication networks or SoftPLC
1 = Analog Input	It defines that the PID controller control setpoint source in automatic mode will be the value read by the analog input configured in A2.3.5.1
2 = Not used	Not used

A2.3.3 Process variable

It allows setting the PID controller process variable.

A2.3.3 Process variable**A2.3.3.1 Source Selection**

Range:	0 ... 2	Default: 0
Properties:	Stopped	

Description:

It defines the source of the PID controller process variable.

Indication	Description
0 = Analog Input	It defines that the source of the process variable will be the value read by the analog input configured in A2.3.5.3 and displayed in parameter A2.1.3
1 = Not used	Not used
2 = AI Differential	It defines that the source of the process variable will be the value read by the analog input configured in A2.3.5.3 minus the value read by the analog input configured in A2.3.5.4 and displayed in parameter A2.1.3

A2.3.3 Process variable**A2.3.3.2 Unit**

Properties:	Default: %
--------------------	-------------------

Description:

It defines the motor.ring unit of the PID controller process variable. It can have up to 7 ASCII characters.

A2.3.3 Process variable**A2.3.3.3 Decimal Places**

Range:	0 ... 3	Default: 0
Properties:		

Description:

It sets the number of decimal places for values with motor.ring unit of the PID controller.

Indication	Description
0 = wxyz	No decimal places
1 = wxy.z	One decimal place
2 = wx.yz	Two decimal places
3 = w.xyz	Three decimal places

A2.3.3 Process variable**A2.3.3.4 Minimum Level**

Range:	-32768 ... 32767	Default: 0
Properties:	Stopped	

Description:

It defines the minimum value of the process variable in motor.ring units of the PID controller.

A2.3.3 Process variable**A2.3.3.5 Maximum Level**

Range:	-32768 ... 32767	Default: 10000
Properties:	Stopped	

Description:

It defines the maximum value of the process variable in motor.ring units of the PID controller.

A APPLICATION



NOTE!

Example: If a temperature sensor, with an operating range between -20 and +70 °C and a signal between 4 and 20 mA, is used by an analog input also set to 4 to 20 mA for obtaining the value of the process variable, the values that must be set in these parameters are -20 °C and 70 °C respectively.

A2.3.4 Mode of operation

It allows configuring the PID controller operating mode.

A2.3.4 Mode of operation

A2.3.4.1 MAN/AUTO Source

Range:	0 ... 1	Default: 0
Properties:	Stopped	

Description:

It defines the source of the PID controller operating mode.

- Manual mode: Speed reference defined directly by the manual setpoint set in A2.2.1.2.
- Automatic mode: Speed reference obtained through the PID controller based on the automatic setpoint displayed in A2.1.1.

Indication	Description
0 = Parameter	It defines that the PID controller operates in manual or automatic mode according to the parameter configured in A2.3.4.2
1 = Selection via DI	It defines that the PID controller operates in manual or automatic mode according to the state of the digital input configured in A2.3.5.6. That is, if the digital input is at logic level "0", the PID controller will operate in manual mode; if the digital input is at logic level "1", the PID controller will operate in automatic mode



NOTE!

The change from an operation mode to another with the motor running may cause disturbances on the system control. That can be optimized according to the automatic adjustment mode of the PID controller setpoint defined in parameter A2.3.4.3 together with the bumpless transfer characteristic from the manual mode to the automatic mode.

Bumpless transfer is merely making the transfer from the manual mode to the automatic mode without causing variation in the PID controller output. In other words, when the transition from the manual mode to the automatic mode occurs, the PID controller output value in manual mode is used to start the integral part of the PID controller in automatic mode. That ensures that the output will start from this value

A2.3.4 Mode of operation

A2.3.4.2 MAN/AUTO Selection

Range:	0 ... 1	Default: 0
Properties:		

Description:

It defines the PID controller operating mode in case A2.3.4.1 = 0.

Indication	Description
0 = Manual	It defines that the PID controller will operate in manual mode. In this mode, the manual mode setpoint value (A2.2.1.2) will be applied as the PID controller speed reference
1 = Automatic	It defines that the PID controller will operate in automatic mode. In this mode, the automatic mode setpoint value will be used as input to the PID controller to control the process variable

A2.3.4 Mode of operation**A2.3.4.3 SP Automatic Setting****Range:** 0 ... 3**Default:** 0**Properties:****Description:**

It defines whether the PID controller setpoint in automatic mode (A2.2.1.1) and/or manual mode (A2.2.1.2) will be changed or set automatically when the PID controller operating mode changes.

Indication	Description
0 = Both SP Inactive	It defines that the setpoint values in manual and automatic mode will not be modified
1 = Active Automatic SP	It defines that when the PID controller operating mode transitions from manual to automatic, the control setpoint value will be loaded with the current value of the control process variable (A2.1.3)
2 = Active Manual SP	It defines that in the transition of the PID controller operation mode from automatic to manual, the value of the PID controller setpoint in manual mode (A2.2.1.2) will be loaded with the actual motor speed value (S2.1.3)
3 = Both SP Active	It defines that in the transition of the PID controller operation mode from manual to automatic, the control setpoint value (A2.2.1.1) will be loaded with the current value of the control process variable (A2.1.3); and that in the transition of the PID controller operating mode from automatic to manual, the PID controller setpoint value in manual mode (A2.2.1.2) will be loaded with the current motor speed value (S2.1.3)

**NOTE!**

Setting the control setpoint in automatic mode is only valid when the source of the control setpoint is parameters (A2.3.2.1 = 0). For other control setpoint sources, the automatic adjustment is not executed.

A2.3.5 Source of the commands

It allows defining the analog or digital input used for each PID controller command.

A2.3.5 Source of the commands**A2.3.5.1 AI for Setpoint****Range:** 0 ... 30**Default:** 0**Properties:** Stopped**Description:**

It defines the analog input that will be used as a setpoint in the PID controller automatic mode. The options are shown in Table 9.20 on page 9-32.

Indication	Description
0 = Inactive	It disables the use of the analog input in this function
1 = AI X-1	Enable use of analog input AI1 of Slot X
2 = AI X-2	Enable use of analog input AI2 of Slot X
3 = AI A-1	Enable use of analog input AI1 of Slot A
4 = AI A-2	Enable use of analog input AI2 of Slot A
5 = AI A-3	Enable use of analog input AI3 of Slot A
6 = Not used	Not used
7 = AI B-1	Enable use of analog input AI1 of Slot B
8 = AI B-2	Enable use of analog input AI2 of Slot B
9 = AI B-3	Enable use of analog input AI3 of Slot B
10 = Not used	Not used
11 = AI C-1	Enable use of analog input AI1 of Slot C
12 = AI C-2	Enable use of analog input AI2 of Slot C
13 = AI C-3	Enable use of analog input AI3 of Slot C
14 = Not used	Not used
15 = AI D-1	Enable use of analog input AI1 of Slot D

A APPLICATION

Indication	Description
16 = AI D-2	Enable use of analog input AI2 of Slot D
17 = AI D-3	Enable use of analog input AI3 of Slot D
18 = Not used	Not used
19 = AI E-1	Enable use of analog input AI1 of Slot E
20 = AI E-2	Enable use of analog input AI2 of Slot E
21 = AI E-3	Enable use of analog input AI3 of Slot E
22 = Not used	Not used
23 = AI F-1	Enable use of analog input AI1 of Slot F
24 = AI F-2	Enable use of analog input AI2 of Slot F
25 = AI F-3	Enable use of analog input AI3 of Slot F
26 = Not used	Not used
27 = AI G-1	Enable use of analog input AI1 of Slot G
28 = AI G-2	Enable use of analog input AI2 of Slot G
29 = AI G-3	Enable use of analog input AI3 of Slot G
30 = Not used	Not used

A2.3.5 Source of the commands

A2.3.5.2 FI for Setpoint

Range:	0 ... 2	Default: 0
Properties:	Stopped	

Description:

It defines the frequency input that will be used as a setpoint in PID controller automatic mode.

Indication	Description
0 = Inactive	It disables the use of the frequency input in this function
1 = FI X-5	It enables the use of frequency input FI5 of Slot X
2 = FI X-6	It enables the use of frequency input FI6 of Slot X

A2.3.5 Source of the commands

A2.3.5.3 AI for Process Var. 1

Range:	0 ... 30	Default: 1
Properties:	Stopped	

Description:

It defines the analog input that will be used as the PID controller process variable if the variable source selection is configured for analog input or difference between analog inputs (A2.3.3.1 = 0 or 2). The options are shown in Table 9.20 on page 9-32.

Indication	Description
0 = Inactive	It disables the use of the analog input in this function
1 = AI X-1	Enable use of analog input AI1 of Slot X
2 = AI X-2	Enable use of analog input AI2 of Slot X
3 = AI A-1	Enable use of analog input AI1 of Slot A
4 = AI A-2	Enable use of analog input AI2 of Slot A
5 = AI A-3	Enable use of analog input AI3 of Slot A
6 = Not used	Not used
7 = AI B-1	Enable use of analog input AI1 of Slot B
8 = AI B-2	Enable use of analog input AI2 of Slot B
9 = AI B-3	Enable use of analog input AI3 of Slot B
10 = Not used	Not used
11 = AI C-1	Enable use of analog input AI1 of Slot C
12 = AI C-2	Enable use of analog input AI2 of Slot C
13 = AI C-3	Enable use of analog input AI3 of Slot C
14 = Not used	Not used

Indication	Description
15 = AI D-1	Enable use of analog input AI1 of Slot D
16 = AI D-2	Enable use of analog input AI2 of Slot D
17 = AI D-3	Enable use of analog input AI3 of Slot D
18 = Not used	Not used
19 = AI E-1	Enable use of analog input AI1 of Slot E
20 = AI E-2	Enable use of analog input AI2 of Slot E
21 = AI E-3	Enable use of analog input AI3 of Slot E
22 = Not used	Not used
23 = AI F-1	Enable use of analog input AI1 of Slot F
24 = AI F-2	Enable use of analog input AI2 of Slot F
25 = AI F-3	Enable use of analog input AI3 of Slot F
26 = Not used	Not used
27 = AI G-1	Enable use of analog input AI1 of Slot G
28 = AI G-2	Enable use of analog input AI2 of Slot G
29 = AI G-3	Enable use of analog input AI3 of Slot G
30 = Not used	Not used

A2.3.5 Source of the commands

A2.3.5.4 AI for Process Var. 2

Range: 0 ... 30

Default: 0

Properties: Stopped

Description:

It defines the analog input that will be used for calculating the value of the PID controller process variable if the variable source selection is configured for differences between analog inputs (A2.3.3.1 = 2). The options are shown in Table 9.20 on page 9-32.

Indication	Description
0 = Inactive	It disables the use of the analog input in this function
1 = AI X-1	Enable use of analog input AI1 of Slot X
2 = AI X-2	Enable use of analog input AI2 of Slot X
3 = AI A-1	Enable use of analog input AI1 of Slot A
4 = AI A-2	Enable use of analog input AI2 of Slot A
5 = AI A-3	Enable use of analog input AI3 of Slot A
6 = Not used	Not used
7 = AI B-1	Enable use of analog input AI1 of Slot B
8 = AI B-2	Enable use of analog input AI2 of Slot B
9 = AI B-3	Enable use of analog input AI3 of Slot B
10 = Not used	Not used
11 = AI C-1	Enable use of analog input AI1 of Slot C
12 = AI C-2	Enable use of analog input AI2 of Slot C
13 = AI C-3	Enable use of analog input AI3 of Slot C
14 = Not used	Not used
15 = AI D-1	Enable use of analog input AI1 of Slot D
16 = AI D-2	Enable use of analog input AI2 of Slot D
17 = AI D-3	Enable use of analog input AI3 of Slot D
18 = Not used	Not used
19 = AI E-1	Enable use of analog input AI1 of Slot E
20 = AI E-2	Enable use of analog input AI2 of Slot E
21 = AI E-3	Enable use of analog input AI3 of Slot E
22 = Not used	Not used
23 = AI F-1	Enable use of analog input AI1 of Slot F
24 = AI F-2	Enable use of analog input AI2 of Slot F
25 = AI F-3	Enable use of analog input AI3 of Slot F
26 = Not used	Not used

A APPLICATION

Indication	Description
27 = AI G-1	Enable use of analog input AI1 of Slot G
28 = AI G-2	Enable use of analog input AI2 of Slot G
29 = AI G-3	Enable use of analog input AI3 of Slot G
30 = Not used	Not used

A2.3.5 Source of the commands

A2.3.5.5 FI for Process Var.

Range:	0 ... 2	Default: 0
Properties:	Stopped	

Description:

It defines the frequency input that will be used as the PID controller process variable if the variable source selection is configured for frequency input (A2.3.3.1 = 1).

Indication	Description
0 = Inactive	It disables the use of the frequency input in this function
1 = FI X-5	It enables the use of frequency input FI5 of Slot X
2 = FI X-6	It enables the use of frequency input FI6 of Slot X

A2.3.5 Source of the commands

A2.3.5.6 DI for Manual/Automatic

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It defines the digital input that will be used for manual and automatic mode selection of the PID controller if parameter A2.3.4.1 is so configured (A2.3.4.1 = 1). The options are shown in Table 9.15 on page 9-21.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X
7 = DI A-1	Enable use of digital input DI1 of Slot A
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C

Indication	Description
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G
62 = DI G-8	Enable use of digital input DI8 of Slot G

A2.3.5 Source of the commands

A2.3.5.7 DI for Increment SP

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It defines the digital input that will be used to increase the value of the PID controller setpoint if parameter A2.3.2.1 is so configured. The options are shown in Table 9.15 on page 9-21.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X

A APPLICATION

Indication	Description
7 = DI A-1	Enable use of digital input DI1 of Slot A
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G

Indication	Description
62 = DI G-8	Enable use of digital input DI8 of Slot G

A2.3.5 Source of the commands

A2.3.5.8 DI for Decrement SP

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It defines the digital input that will be used to decrease the value of the PID controller setpoint if parameter A2.3.2.1 is so configured. The options are shown in Table 9.15 on page 9-21.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X
7 = DI A-1	Enable use of digital input DI1 of Slot A
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E

Indication	Description
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G
62 = DI G-8	Enable use of digital input DI8 of Slot G

A2.3.5 Source of the commands

A2.3.5.9 DI for Multi SP 1

Range:	0 ... 62	Default: 0
Properties:	Stopped	

Description:

It defines the digital input that will be used for the multisetpoint mode if parameter A2.3.2.1 is so configured. The options are shown in Table 9.15 on page 9-21.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X
7 = DI A-1	Enable use of digital input DI1 of Slot A
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C

Indication	Description
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G
62 = DI G-8	Enable use of digital input DI8 of Slot G

A2.3.5 Source of the commands

A2.3.5.10 DI for Multi SP 2

Range: 0 ... 62

Default: 0

Properties: Stopped

Description:

It defines the digital input that will be used for the multisetpoint mode if parameter A2.3.2.1 is so configured. The options are shown in Table 9.15 on page 9-21.

Indication	Description
0 = Inactive	It disables the use of the digital input in this function
1 = DI X-1	Enable use of digital input DI1 of Slot X
2 = DI X-2	Enable use of digital input DI2 of Slot X
3 = DI X-3	Enable use of digital input DI3 of Slot X
4 = DI X-4	Enable use of digital input DI4 of Slot X

A APPLICATION

Indication	Description
5 = DI X-5	Enable use of digital input DI5 of Slot X
6 = DI X-6	Enable use of digital input DI6 of Slot X
7 = DI A-1	Enable use of digital input DI1 of Slot A
8 = DI A-2	Enable use of digital input DI2 of Slot A
9 = DI A-3	Enable use of digital input DI3 of Slot A
10 = DI A-4	Enable use of digital input DI4 of Slot A
11 = DI A-5	Enable use of digital input DI5 of Slot A
12 = DI A-6	Enable use of digital input DI6 of Slot A
13 = DI A-7	Enable use of digital input DI7 of Slot A
14 = DI A-8	Enable use of digital input DI8 of Slot A
15 = DI B-1	Enable use of digital input DI1 of Slot B
16 = DI B-2	Enable use of digital input DI2 of Slot B
17 = DI B-3	Enable use of digital input DI3 of Slot B
18 = DI B-4	Enable use of digital input DI4 of Slot B
19 = DI B-5	Enable use of digital input DI5 of Slot B
20 = DI B-6	Enable use of digital input DI6 of Slot B
21 = DI B-7	Enable use of digital input DI7 of Slot B
22 = DI B-8	Enable use of digital input DI8 of Slot B
23 = DI C-1	Enable use of digital input DI1 of Slot C
24 = DI C-2	Enable use of digital input DI2 of Slot C
25 = DI C-3	Enable use of digital input DI3 of Slot C
26 = DI C-4	Enable use of digital input DI4 of Slot C
27 = DI C-5	Enable use of digital input DI5 of Slot C
28 = DI C-6	Enable use of digital input DI6 of Slot C
29 = DI C-7	Enable use of digital input DI7 of Slot C
30 = DI C-8	Enable use of digital input DI8 of Slot C
31 = DI D-1	Enable use of digital input DI1 of Slot D
32 = DI D-2	Enable use of digital input DI2 of Slot D
33 = DI D-3	Enable use of digital input DI3 of Slot D
34 = DI D-4	Enable use of digital input DI4 of Slot D
35 = DI D-5	Enable use of digital input DI5 of Slot D
36 = DI D-6	Enable use of digital input DI6 of Slot D
37 = DI D-7	Enable use of digital input DI7 of Slot D
38 = DI D-8	Enable use of digital input DI8 of Slot D
39 = DI E-1	Enable use of digital input DI1 of Slot E
40 = DI E-2	Enable use of digital input DI2 of Slot E
41 = DI E-3	Enable use of digital input DI3 of Slot E
42 = DI E-4	Enable use of digital input DI4 of Slot E
43 = DI E-5	Enable use of digital input DI5 of Slot E
44 = DI E-6	Enable use of digital input DI6 of Slot E
45 = DI E-7	Enable use of digital input DI7 of Slot E
46 = DI E-8	Enable use of digital input DI8 of Slot E
47 = DI F-1	Enable use of digital input DI1 of Slot F
48 = DI F-2	Enable use of digital input DI2 of Slot F
49 = DI F-3	Enable use of digital input DI3 of Slot F
50 = DI F-4	Enable use of digital input DI4 of Slot F
51 = DI F-5	Enable use of digital input DI5 of Slot F
52 = DI F-6	Enable use of digital input DI6 of Slot F
53 = DI F-7	Enable use of digital input DI7 of Slot F
54 = DI F-8	Enable use of digital input DI8 of Slot F
55 = DI G-1	Enable use of digital input DI1 of Slot G
56 = DI G-2	Enable use of digital input DI2 of Slot G
57 = DI G-3	Enable use of digital input DI3 of Slot G
58 = DI G-4	Enable use of digital input DI4 of Slot G
59 = DI G-5	Enable use of digital input DI5 of Slot G

Indication	Description
60 = DI G-6	Enable use of digital input DI6 of Slot G
61 = DI G-7	Enable use of digital input DI7 of Slot G
62 = DI G-8	Enable use of digital input DI8 of Slot G

A2.3.6 Falhas e Alarmes

It allows configuring the performance of the PID controller faults and alarms.

A2.3.6 Falhas e Alarmes

A2.3.6.1 Config. for PV Low Level

Range: 0 ... 3 Default: 0

Properties:

Description:

It defines whether the alarm and protection should actuate when the process variable level is low (A2.1.3 < A2.3.6.2).

Indication	Description
0 = Inactive	It defines that the process variable fault and alarm should not actuate when the limit is exceeded
1 = Alarm	It defines that only the process variable alarm should actuated when the limit is exceeded
2 = Fault	It defines that the process variable fault should actuate when the limit is exceeded
3 = Alarm and Fault	It defines that the process variable fault and alarm should actuate when the limit is exceeded

A2.3.6 Falhas e Alarmes

A2.3.6.2 Value for PV Low Level

Range: -32768 ... 32767 Default: 0

Properties:

Description:

It defines the value below which the control process variable low level alarm will be generated (A2430).

A2.3.6 Falhas e Alarmes

A2.3.6.3 Time for PV Low Level

Range: 0.0 ... 999.9 s Default: 0.0 s

Properties:

Description:

Time for low level fault for the control process variable.

A2.3.6 Falhas e Alarmes

A2.3.6.4 Config. for PV High Level

Range: 0 ... 3 Default: 0

Properties:

Description:

It defines whether the alarm and protection should actuate when the process variable level is high (A2.1.3 > A2.3.6.5).

Indication	Description
0 = Inactive	It defines that the process variable fault and alarm should not actuate when the limit is exceeded
1 = Alarm	It defines that only the process variable alarm should actuated when the limit is exceeded
2 = Fault	It defines that the process variable fault should actuate when the limit is exceeded

A APPLICATION

Indication	Description
3 = Alarm and Fault	It defines that the process variable fault and alarm should actuate when the limit is exceeded

A2.3.6 Falhas e Alarmes

A2.3.6.5 Value for PV High Level

Range: -32768 ... 32767

Default: 0

Properties:

Description:

It defines the value above which the control process variable high level alarm will be generated (A2432).

A2.3.6 Falhas e Alarmes

A2.3.6.6 Time for PV High Level

Range: 0.0 ... 999.9 s

Default: 0.0 s

Properties:

Description:

Time for high level fault for the control process variable.

A2.3.7 Sleep mode

It allows setting the operating conditions of the PID controller sleep mode. This mode allows energy savings when the control action is not necessary to keep the process variable at the desired value.

Sleep Mode is a controlled system status in which the control demand is zero or almost zero, seeing that at this moment the motor driven by the MVW frequency inverter may be stopped. That prevents the motor from remaining running at a low speed, which does little or nothing for the controlled system. Even if the motor is apparently OFF, the process variable continues to be monitored so that, when necessary, the controlled system can start the motor again according to the conditions of the wake up mode.

The Wake Up Mode switches on the motor when the difference between the control process variable and the control setpoint is greater than a certain programmed value.



NOTE!

The sleep mode only actuates if the PID controller is enabled and in the automatic mode.



DANGER!

When the MVW inverter is in the sleep mode, the motor can spin at any moment because of the process conditions.

Figure 10.2 on page 10-21 shows an analysis of the operation of the PID controller programmed with direct control action and set to Sleep Mode.




Figure 10.2: PID sleep mode

1 – The Run/Stop command via digital input DI1 enables starting the motor. As the condition to wake up was not detected, it remains in sleep mode and the motor remains stopped;

2 – The process variable starts to decrease and becomes smaller than the deviation of the process variable programmed to wake up (A2.3.7.2); at this moment the countdown time to wake up (A2.3.7.3) is started;

3 – The process variable remains smaller than the deviation of the process variable to wake up (A2.3.7.2), and the time to wake up (A2.3.7.3) has elapsed; at this moment the command is given to start the motor and control the system with the variation of its speed;

4 – The inverter accelerates the motor to the minimum speed (C4.3.1.1.1). After that, the PID controller is enabled and starts to control the motor speed;

5 – Then it is possible to control the process variable so that it reaches the control setpoint required by the user. To that end, the PID controller output is increased causing the motor speed to increase until the control stabilizes;

6 – The value of the process variable remains above the required control setpoint due to a decrease in demand and the motor speed starts to slow down;

7 – The motor speed value is lower than the sleep value (A2.3.7.4); the countdown time to activate sleep mode (A2.3.7.5) starts;

A APPLICATION

8 – The motor speed remains below the sleep value (A2.3.7.4) and the time to activate the sleep mode (A2.3.7.5) has elapsed; at this moment the command to turn off the motor is given;

9 – The motor decelerates to 0 rpm and stops; at this moment the PID controller goes into sleep mode.

A2.3.7 Sleep mode

A2.3.7.1 Sleep Mode Config.

Range: 0 ... 1 **Default:** 0

Properties:

Description:

It defines whether the control will operate in sleep mode.

Indication	Description
0 = Disabled	It sets the sleep mode to be inactive
1 = Enabled	It sets the sleep mode to be active

A2.3.7 Sleep mode

A2.3.7.2 PV Deviation to Wake up

Range: -32768 ... 32767 **Default:** 500

Properties:

Description:

It defines the value to be decreased (direct PID) or added (reverse PID) to the control setpoint to turn on the motor and return to system control (exiting the sleep mode). This value is compared to the control process variable, and, if the control process variable value is smaller (direct PID) or greater (reverse PID) than this value, the wake up condition is enabled.

A2.3.7 Sleep mode

A2.3.7.3 Time to Wake Up

Range: 0.0 ... 999.9 s **Default:** 5.0 s

Properties:

Description:

It sets the time to stay in the wake up mode condition to exit the sleep mode and allow control of the system by activating the motor. The control process variable must remain smaller (direct PID) or greater (reverse PID) than the deviation defined in A2.3.7.2 during the time set in A2.3.7.3 for the motor to be turned on and its speed controlled. If the condition to wake up (A2.3.7.3) is inactive for a while, the timer is reset and the time count is reinitialized.



NOTE!

If the "Run/Stop" command is active when the inverter is powered up and the Wake up condition is active, the time set in A2.3.7.3 will not be waited, and thus the motor starts instantly.

A2.3.7 Sleep mode

A2.3.7.4 Speed for Sleep Mode

Range: 0 ... 60000 rpm **Default:** 100 rpm

Properties:

Description:

It sets the motor speed value to go into the sleep mode.

A2.3.7 Sleep mode

A2.3.7.5 Time for Sleep Mode

Range: 0.0 ... 999.9 s **Default:** 10.0 s

Properties:

Description:

It defines the time for the motor speed to remain below the value set in A2.3.7.4 so that the motor will be switched off and go into the sleep mode.

A3 MILL

This section explains the starting and stopping process of mills controlled by WEG MVW inverters.

To start the inverter operation, it must be in the *Ready* state and receive a *Start* command to accelerate the mill to the speed reference.

Due to the high torque required to move the mill, strategies are required for frozen charge detection (FCD), which is the result of the solidification of the ore mixture after a certain period of mill downtime.




Figure 10.3: Motor torque driving a frozen charge and a normal load.

Frozen charges affect the dynamics of the load, which may prevent it from sliding when the mill rotates.

The MVW's frozen charge release (FCR) function enables the load to be defrosted, restoring the correct dynamics to the system and enabling the mill to resume operation.

A3.1 Configurations

General system settings, such as speed ratio, command sources and references.

A3.1 Configurations		
A3.1.1 Reduction of the motor and mill assembly		
Range:	0.01 ... 200.00	Default: 64.85
Properties:		

Description:

Defines the final reduction value of the motor and mill assembly.

$$\text{Reduction} = \text{Gearbox reduction} + \frac{\text{Number of pinion teeth}}{\text{Number of crown teeth}}$$

A3.1 Configurations		
A3.1.3 HMI speed reference		
Range:	0.1 ... 100.0 %	Default: 80.0 %
Properties:		

A APPLICATION

Description:

Defines the speed reference value in remote mode 1, used when the reference source is parameterized for HMI in A3.1.4

A3.1 Configurations

A3.1.4 Commands and references

Range: 0 ... 2 Bit

Default: 0

Properties:

Description:

Defines the source of speed commands and references.

Bit	Value/Description
Bit 0 REM 1 speed reference source	0 = HMI: The HMI reference value is parameterized in A3.1.3 1 = Analog input
Bit 1 REM 2 speed reference source	0 = Fieldbus 1 = Analog input
Bit 2 REM 2 Start/Stop command source	0 = Fieldbus 1 = Digital input

A3.1 Configurations

A3.1.5 Remote 2 minimum speed reference

A3.1.6 Maximum value of the remote 2 speed reference

Range: 0.1 ... 100.0 %

Default: 30.0 % (A3.1.5)

100.0 % (A3.1.6)

Properties:

Description:

Sets the speed reference range when operating in remote mode 2.

A3.2 Frozen charge detection

When the frozen charge detection function is enabled, when starting operation, the mill accelerates until it reaches the verification speed defined in A3.2.2.

Upon reaching the angular position A3.2.3 the maximum torque check is initiated up to position A3.2.4. The maximum torque value measured in this interval is stored and when the displacement angle reaches A3.2.5 it is compared with the current torque value.

$$\Delta\text{Torque} = (T_{max} - T_{A3.2.5})$$

$$\text{Load status} = \begin{cases} \text{Thawed,} & \text{if } \Delta\text{Torque} > A3.2.6 \\ \text{Frozen,} & \text{if } \Delta\text{Torque} \leq A3.2.6 \end{cases}$$

If no freezing of the load is detected, the mill continues to rotate until it reaches the angular position parameterized in A3.2.7 where it assumes the operating speed reference defined in A3.1.4.




Figure 10.4: Freeze no-load start, with FCD enabled.

If a frozen charge is detected, the direction of rotation of the motor will be reversed and the mill will be stopped when it reaches approximately 0°.




Figure 10.5: Starting with frozen charge, with FCD enabled.

A APPLICATION

A3.2 Frozen charge detection

A3.2.1 Enable function

Range: 0 ... 1

Default: 1

Properties:

Description:

Enable frozen charge detection function.

Indication	Description
0 = Disable	Disables the function
1 = Enable	Enables the function

A3.2 Frozen charge detection

A3.2.2 Verification speed

Range: 0.1 ... 10.0 %

Default: 10.0 %

Properties:

Description:

Sets the desired speed reference for the frozen charge check.

A3.2 Frozen charge detection

A3.2.3 Angle to enable maximum torque check

A3.2.4 Angle to disable maximum torque check

Range: 1 ... 90 °

Default: 30 ° (A3.2.3)

60 ° (A3.2.4)

Properties:

Description:

Sets the angle to activate/deactivate the maximum torque check.

A3.2 Frozen charge detection

A3.2.5 Torque offset

Range: 1 ... 90 °

Default: 80 °

Properties:

Description:

Defines the angle to perform the comparison between the maximum torque value read between A3.2.3 and A3.2.4 and the current torque value.

This comparison determines whether the mill charge is frozen.

A3.2 Frozen charge detection

A3.2.6 Minimum torque reduction rate

Range: -30 ... 30 %

Default: 20 %

Properties:

Description:

Sets the minimum torque reduction ratio required in the frozen charge check function.

This rate must be adjusted to detect load drop.

A3.2 Frozen charge detection

A3.2.7 Angle to change speed

Range: 1 ... 359 °

Default: 180 °

Properties:

Description:

Sets the angle to release the mill operating speed after a frozen charge is not detected.

A3.3 Frozen charge release

When a frozen charge is detected, the system takes the mill to the zero angular position.

If the function is enabled in A3.3.1, the system is ready to receive the frozen charge release command.

When starting the defrosting process, the steps below are carried out:

- Start of mill movement from zero angle to the release angle parameterized in A3.3.3, at release speed A3.3.2;
- When the mill reaches the angle parameterized in A3.3.3, the system stops and holds the mill in position until time A3.3.5 has elapsed.
- The mill reverses the direction of rotation and positions it at the angle A3.3.3 in the other direction, holding it in this position for the time A3.3.5.

The parameter A3.3.4 defines the number of cycles that the inverter will perform to defrost the load, after this procedure the mill will go to zero degrees and the inverter will be disabled.




Figure 10.6: Release of frozen cargo

A3.3 Frozen charge release**A3.3.1 Enable function**

Range: 0 ... 1

Default: 1

Properties:

Description:

Enables the frozen charge release function.

Indication	Description
0 = Disable	Disables the function
1 = Enable	Enables the function

A3.3 Frozen charge release**A3.3.2 Speed reference**

Range: 0.1 ... 10.0 %

Default: 10.0 %

Properties:

Description:

Sets the speed reference for the motor during the freeze load release routine. This value is a percentage of the motor rating defined in C2.1.5.

A APPLICATION

A3.3 Frozen charge release

A3.3.3 Position to release the frozen charge

Range: 10 ... 90 °

Default: 80 °

Properties:

Description:

Defines the angular position of the mill to release the frozen charge.

A3.3 Frozen charge release

A3.3.4 Number of cycles

Range: 1 ... 10

Default: 5

Properties:

Description:

Sets the number of cycles to defrost the load.

A3.3 Frozen charge release

A3.3.5 Time to release frozen cargo

Range: 0 ... 60 s

Default: 5 s

Properties:

Description:

Defines the time that the mill will remain stopped in the position defined in A3.3.3 and then reverse the direction of rotation.

A3.3 Frozen charge release

A3.3.6 Enable automatic release

Range: 0 ... 1

Default: 0

Properties:

Description:

Defines whether frozen charge release cycles will be executed automatically.



NOTE!

Automatic release will only be performed if load release is enabled in A3.3.1.

Indication	Description
0 = Disable	After detecting a frozen charge, the inverter moves the mill to the 0° angular position and waits for the frozen charge release command
1 = Enable	Starts the defrost routine as soon as a frozen charge is detected

A3.3 Frozen charge release

A3.3.7 Regenerative torque setpoint

Range: 10 ... 120 %

Default: 100 %

Properties:

Description:

Sets the percentage of regenerative torque applied to the motor when Freeze Load Release is activated.



NOTE!

Prevents inverter overvoltage problems when decelerating a frozen charge.
A gain must be set to prevent undervoltage from occurring on the inverter's DC link when it decelerates to release a frozen charge.



BRAZIL

WEG DRIVES & CONTROLS - AUTOMAÇÃO LTDA.

Av. Prefeito Waldemar Grubba, 3000

89256-900 - Jaraguá do Sul - SC

Phone: 55 (47) 3276-4000

Fax: 55 (47) 3276-4060

www.weg.net/br