


# Vector inverter for lifts with synchronous/asynchronous motors

ADL530

Functions description  
and parameters list

Language: English



## Information about this manual

---

This manual explains the functions and the description of the parameters.

The informations about mechanical installation, electrical connection and fast start-up can be found on the ADL550 HW+QS (Hardware and Quick start guide), it is available on WEG web site in the download section ([https://www.weg.net/catalog/weg/IT/en/p/MKT\\_WDC\\_GLOBAL\\_PRODUCT\\_INVERTER\\_FOR\\_ELEVATOR\\_ADL500](https://www.weg.net/catalog/weg/IT/en/p/MKT_WDC_GLOBAL_PRODUCT_INVERTER_FOR_ELEVATOR_ADL500)).

### Firmware version

This manual is updated according to:

- firmware version V 3.x.2
- lift application, EFC V 3.x.2

The firmware version identification number can be read in the data matrix (see section 2.3 of the ADL500 HW+QS manual) or in parameter **Firmware Version** PAR 174 (DRIVE INFO menu).

### General information

#### Note!

In industry, the terms "Inverter", "Regulator" and "Drive" are sometimes interchanged. In this document, the term "Drive" will be used.

Before using the product, read the safety instruction section carefully. Keep the manual in a safe place and available to engineering and installation personnel during the product functioning period.

WEG Automation Europe S.r.l. has the right to modify products, data and dimensions without notice. The data can only be used for the product description and they can not be understood as legally stated properties.

Thank you for choosing this WEG product.

We will be glad to receive any possible information which could help us improving this manual.

The e-mail address is the following: [techdoc@weg.net](mailto:techdoc@weg.net).

All rights reserved.

### Symbols used in the manual



Warning

Indicates a procedure, condition, or statement that, if not strictly observed, could result in personal injury or death.



Caution

Indicates a procedure, condition, or statement that, if not strictly observed, could result in damage to or destruction of equipment.



Attention

Indicates that the presence of electrostatic discharge could damage the appliance. When handling the boards, always wear a grounded bracelet.



#### Note !

Indicates a procedure, condition, or statement that should be strictly followed in order to optimize these applications.

## Table of Contents

---

<b>Information about this manual.....</b>	<b>2</b>
Symbols used in the manual.....	2
<b>A - Programming .....</b>	<b>5</b>
A.1 Asynchronous/Synchronous selection .....	5
A.2 Menu display modes .....	5
A.3 Programming of “function block” analog and digital input signals .....	5
A.4 Variable interconnections mode .....	5
<b>B - Parameters and functions description .....</b>	<b>7</b>
Legend .....	7
DRIVE SETUP .....	8
1. STARTUP WIZARD .....	9
1.1 Communication mode selection (Set comm mode)? .....	9
1.2 Encoder configuration (Set encoder param)? .....	10
1.3 Motor data configuration (Set motor data)? .....	11
1.4 Mechanical data setting (Set mechanical data)? .....	12
1.5 Speed setting (Set speed)? .....	12
1.7 Run Autotune still? .....	14
1.8 Save parameters? .....	14
2. OPTIMIZATION WIZARD (OPTIMIZ. WIZARD) .....	14
3. TROUBLESHOOTING .....	16
3.1 Start .....	16
3.2 Rollback .....	16
3.3 Too fast acceleration (Too fast accel.) .....	17
3.4 Slow speed vibrations (Slow speed vibr.) .....	17
3.5 High speed vibrations (High speed vibr.) .....	17
3.6 Too fast deceleration (Too fast dec.) .....	18
3.7 Floor leveling .....	18
3.8 Brake closing .....	18
3.9 Vibration analyzer .....	19
4. DRIVE .....	19
4.1 DRIVE MONITOR .....	19
4.2 DRIVE INFO .....	22
4.3 DRIVE CONFIG .....	24
4.4 ALARM CONFIG .....	27
4.8 DIGITAL INPUTS .....	35
4.9 DIGITAL OUTPUTS .....	36
4.10 ANALOG INPUTS .....	36
4.11 ALARM LOG .....	39
4.12 LIFE TIME .....	39
5. LIFT .....	40
5.1 LIFT MONITOR .....	40
5.2 MECHANICAL DATA .....	42
5.3 SPEED .....	44
5.4 RAMPS .....	46
5.5 LIFT SEQUENCES .....	48
5.6 LIFT OUT .....	52
5.7 LIFT IN .....	54
5.8 PRE TORQUE .....	57
5.9 EMERGENCY MODE .....	59
5.10 LIFT ALARMS .....	62
5.11 DISTANCE .....	66
5.14 DIRECT CNT .....	70
6. COMMUNICATION .....	73
6.1 CONTROL COMM .....	73
6.2 FIELDBUS M2S .....	75
6.3 FIELDBUS S2M .....	78
6.4 WORD COMP .....	80
6.5 WORD DECOMP .....	81
6.6 NETWORK AND ACCESS .....	82
7. MOTOR DATA .....	84
8. ENCODER .....	87
9. SAFETY .....	95
10. REGULATION MENU .....	97
10.1 SPEED REGULATION GAINS (SPEED REG GAINS) .....	97
10.2 VF CONTROL .....	100
10.3 REGULATOR PARAM .....	103
10.4 TORQUE CONFIG .....	105
11. FUNCTIONS .....	107
11.1 DC BRAKING .....	107
11.2 INERTIA COMP .....	109
11.3 ANTI ROLLBACK .....	109

---

11.4 VIBRATION ANALYSIS (VIBR. ANALYSIS) .....	110
11.5 MOTOR OVERLOAD .....	110
11.6 BRAKING RESISTOR OVERLOAD (BRES OVERLOAD) .....	112
11.7 ENERGY SAVING (ENER. SAVING) .....	113
PARAMETERS ON SELECTION LISTS, BUT NOT DISPLAYED ON KEYPAD .....	114
<b>C - Parameters list .....</b>	<b>117</b>
<b>D - Selection lists .....</b>	<b>146</b>
L_DIGSEL1 .....	146
L_DIGSEL2 .....	146
L_DIGSEL3 .....	146
L_LIM .....	147
L_MLTREF .....	147
L_SCOPE .....	147
L_VREF .....	147
L_WDECOMP .....	147
LiftInputAdlCmd .....	147
LiftInputDoorCmd .....	148
LiftInputAdlCmdEBC .....	148
<b>E - Block diagrams .....</b>	<b>149</b>
Drive .....	149
Drive overview .....	149
Digital Inputs .....	149
Expansion digital inputs .....	150
Digital outputs .....	150
Expansion digital outputs .....	150
Analog Inputs .....	151
Lift .....	152
EFC Overview .....	152
Multispeed .....	152
Ramps .....	153
Start sequences .....	153
Stop sequences .....	154
Pre torque .....	154
Regulations .....	155
Speed reg gains .....	155
Torque config .....	155
Functions .....	156
Motor overload Servofan .....	156
Motor overload Autofan .....	156
Bres overload .....	157
Anti Rollback .....	157
DC braking stop .....	158
DC braking on command .....	158
DC braking on cmd & at stop .....	159
<b>F - Appendix 1 - CANopen interface .....</b>	<b>160</b>
F.1.1 CANopen functions .....	160
F.1.2 CANopen management .....	163
F.1.3 Process data channel control .....	164
F.1.4 SDO management .....	165
F.1.5 Alarms .....	167
F.1.6 Configuration example .....	169
<b>G - Appendix 2 - Phasing .....</b>	<b>174</b>
G.2.1 Rotation phasing .....	174
G.2.2 Static phasing .....	174

### A.1 Asynchronous/Synchronous selection

The ADL550 is factory-set to operate in asynchronous motor control mode.

To switch to the synchronous motor control mode, set PAR 540 **Control type** (Menu 04.03 - DRIVE CONFIG).

For information on switching control mode via keypad, reference should be made to the ADL500 HW+QS Guide (see paragraph 8.2.15 Asynchronous/Synchronous selection).

### A.2 Menu display modes

The programming menu can be displayed in four modes, which can be selected using the parameter 554 **Access level** (04 - DRIVE CONFIG menu):

- |                  |  |
|------------------|--|
| (0) Readonly     | The read-only parameters are displayed.                                  |
| (1) Easy         | Only the main parameters required for a basic start up are displayed.    |
| (2) Intermediate | Only the parameters for initial optimization are displayed.              |
| (3) Expert       | All parameters are displayed except for the menu and service parameters. |
| (4) Service      | All parameters are displayed. Reserved for service.                      |

### A.3 Programming of “function block” analog and digital input signals

The signals, variables and parameters of each single “function block” of the drive are interconnected in order to achieve the configurations and controls inside the control system.

These can be managed and modified using the keypad, PC configurator or fieldbus programming.

The programming mode is based on the following logic:


**Src** (source; i.e.: **Fault reset src**, PAR: 4500)

This term defines **the source of the function block input**, i.e. the signal to be processed in the function block.

The different configurations are defined in the relative **selection lists**.

**Mon** (monitor; es.: **Mon ing digitale 1**, PAR: 1210)

Si definisce con tale denominazione **la variabile in uscita al blocco funzione, risultante dalle elaborazioni effettuate nel blocco stesso**.



### A.4 Variable interconnections mode

The **source (src)** allows the desired control signal to be assigned to the function block input.

This operation is performed by using specific selection lists.

Possible control signal sources:

#### 1 – Physical terminal

The analog and digital signals come from the terminal strip of the regulation card and/or from those of the expansion cards.

#### 2 – Drive internal variables

Internal drive control system variables, from “function block” calculations, sent via keypad, PC configurator or fieldbus.

#### Practical example


The following examples illustrate the philosophies and methods with which more or less complex operations are performed in the single “function blocks”, the results of which represent the output of the block.

• Example: Changing the digital outputs source

The main drive reference (in the default configuration) **Speed ref 1 mon** (PAR 660) is generated by the output of the function block “**Multispeed selector**”. Its default source is the multispeed 1, **Dig input 4 mon** signal (PAR 1216), provided from the output of the function block “**Digital Input 4 Block**”, which in this case refers to digital inout 4 of the signal terminal strip.

• Example: Inverting the digital input signal “Start fwd cmd src”

To invert the “**Start fwd cmd src**” digital input signal the value of the parameter **Dig inp 4 inversion** (PAR 1246), which has a default setting of **Null** (nessuna operazione/no operation), must be changed by selecting the source of the command signal from among those listed in the L\_DIGSEL 2 selection list, for example **Dig inp 4 inversion (PAR 1246)**, **One** (function always enabled), etc.



The diagrams above illustrate the internal processing philosophy of the single “function blocks” and the result of these changes on the other interconnected “function blocks”.

**Note!**

This section contains a brief description of the functions of the other parameters in the function blocks not included for the changes in the example.

The parameter **Speed ref invert src** (PAR: 654) can be used to select the source for the command to reverse the “**Multispeed selector**” function block output.

The output signal from the “**Speed setpoint**” block is displayed in the parameter **Speed ref 1 mon** (PAR 660).

## B - Parameters and functions description

### Legend

0	1	2	3	4	5	6	7	8	9	10	11		
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.		
<b>4 DRIVE</b>											( Level 1 menu )		
<b>4.1 DRIVE MONITOR</b>											( Level 2 menu )		
4.1.1	250	Output current	A	FLOAT	16/32BIT	0	0	0	R	ALL			
<b>4.4 ALARM CONFIG</b>													
4.4.1	4500	Fault reset src		LINK	16BIT	6000	0	16384	RW	FVY			
Selection of the origin (source) of the signal to be used for the command to reset the drive after an alarm. The terminal that can be used for this function can be selected from among those listed in the "L_DIGSEL2" selection list. [*]													
0	Indexing of the menu and parameter												
1	Parameter identifier												
2	Parameter description												
3	UM: unit of measure												
4	Type of parameter	BIT	Boolean, from modbus seen as 16 bits										
		ENUM	Selection list, from modbus seen as 16 bits										
		FLOAT	Real, from modbus seen as 32 bits										
		INT16	Integer with sign 16 bits, from modbus seen as 16 bits										
		INT32	Integer with sign 32 bits, from modbus seen as 32 bits										
		ILINK	Selection list, from modbus seen as 16 bits										
		LINK	Selection list, from modbus seen as 16 bits										
		UINT16	Integer without sign 16 bits, from modbus seen as 16 bits										
		UINT32	Integer without sign 32 bits, from modbus seen as 32 bits										
		STRING16	16 character string										
		FBM2SIPA	IPA of the parameter received from the CAN master										
		FBF2MIPA	IPA of the parameter sent to the CAN master										
5	Format of data exchanged on Fieldbus		16=16BIT, 32=32BIT, 16/32= 16/32BIT										
6	Default value (1)		CALCF CALCI SIZE	Value calculated as a number with floating point									
7	Minimum value			Value calculated as a whole number									
8	Maximum value			Value depending on the size of the drive									
9	Accessibility		R W Z	Read									
				Write									
				Parameters that can be modified ONLY with the drive disabled									
10	Level		RO INT EXP SRV ESY	Read Only									
				Intermediate									
				Expert									
				Service									
				Easy									
11	Visibility		F V Y	Open loop V/f mode control, asynchronous motor (PAR 540 = ASY SSC, Default).									
				Field oriented vector mode control, asynchronous motor (PAR 540 = ASY FOC).									
				Field oriented vector mode control for permanent magnet synchronous motor (PAR 540 = SYN FOC).									
[*]	Selection lists: The "Source.../Src..." format parameters are linked to a selection list. The source of the signal that will control the parameter can be selected from the list indicated. The lists are indicated in paragraph D of this manual.												


- (1) The default value is usually common for Synchronous and Asynchronous versions. When it is different, the value of the synchronous version is indicated into brackets: e.g.: PAR 11012 Pulley diameter, Def= 0.6 (0.32), 0.6 = default ver. asynchronous, (0.32)= default ver. synchronous.

## DRIVE SETUP

Il SETUP DRIVE è una procedura che viene presentata all'utente solo alla prima accensione del drive e permette di modificare le impostazioni base.

Nel caso in cui si fosse completato il setup ma si desiderasse visualizzarlo nuovamente è necessario eseguire la procedura di ripristino (**Parametri di default**, PAR 580 e **Salva Parametri**, PAR 550) quindi spegnere e riaccendere il drive.

Tutti i parametri presenti nel setup sono anche disponibili all'interno dei vari menu del drive.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1	<b>578</b>	<b>Language select</b>		ENUM		GB			RW	INT	FVY

Setting of the drive programming language.

**0** English  
**1** Italian  
**2** French  
**3** German  
**4** Spanish  
**5** Turkish

English and Italian are pre-installed in the drive, to select the Italian language set **1**.

To set a different language download from the WEG site (<https://www.weg.net/...>, DRIVE SET-UP folder) the available language file (wizard available in the ADL500 HW+QS manual, section 8.2.8.1 Language selection):

- Unzip and save files on a USB stick in a folder named "ADL500LN";
- Insert the stick into the USB port of the drive;
- Select parameter 570 Select language and set the new language;
- Start the language loading procedure, when finished the drive will be restarted.

**Note!**

The language file must be aligned to the firmware and application version of the drive, check the match!

The new language will be loaded into the memory of the drive and will replace the Italian language. The English language cannot be replaced by another language.

**Note!**

The **Load Default** command (PAR 580) does not modify this parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
2	<b>390</b>	<b>Load application</b>		UINT16		-	-	4	RW	INT	FVY

Sets the application used by the drive. Once the memory device has been connected to the drive's USB port, simply change the parameter to set the application chosen.

**0** No application  
**1** EFC  
**2** EPC (Under development)  
**3** DCP (Under development)  
**4** CAN417

EFC (Elevator Floor Control): application that uses multispeed to reach the floor.

EPC (Elevator Positioning Control): application that uses position references to manage direct access to the floor.

DCP: Application that uses DCP3 protocols for EFC management and the CP4 protocol for EPC management.

CAN417: Application that uses the CANopen CIA 417™ protocol for EFC and EPC management.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3	<b>598</b>	<b>Load from USB</b>		BIT		0	0	1	RWZ	INT	FVY

Transfers parameters previously stored in the memory connected to the drive's USB port.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4	2132	<b>Encoder mode</b>		ENUM		None			RWZ	INT	FVSY
The drive has a built-in encoder card. The encoder mode can be selected according to the following table:											
<p>0 None</p> <p>1 Digital</p> <p>2 Sinus</p> <p>3 Sinus SINCOS</p> <p>4 Sinus ENDAT</p> <p>5 Sinus BiSS</p> <p>6 ENDAT</p> <p>7 BiSS</p> <p>8 Sinus SSI</p>											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5	392	<b>Select motor</b>		BIT		0	0	1	RWZ	INT	FVY
This parameter is used to load motor data into the drive that are part of a library (.mot file extension).											
These files must be saved on a USB memory device in a folder named "ADL500MT". Once the memory device has been connected to the drive's USB port, simply select the motor whose parameters are to be imported from the appropriate menu. Contact WEG Technical Assistance for further information or to request the files.											
The motor data libraries are already available in the WEG Drivelabs configurator in the <b>Wizard / Setup-Wizard</b> menu.											

## 1 STARTUP WIZARD

Following the step-by-step procedure from this menu, the drive can be started up by setting the main parameters relating to communication, feedback, motor, main system mechanical data, speed and motor self-tuning.

### 1.1 Set comm mode?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.1.1	4000	<b>Communication mode</b>		ENUM		Parallel			RW	INT	FVSY
Setting the type of communication to be used.											
<p>0 Parallel I/O</p> <p>1 CanOpen</p> <p>2 DCP (Under development)</p> <p>3 CAN417 (Under development)</p>											
Setting <b>0</b> the drive communicates with the Controller through the <b>Parallel I/O</b> (analogue inputs and outputs). If set <b>1</b> the CANopen fieldbus is selected. If set to <b>2</b> the DCP communication is selected. If set to <b>3</b> the DS417 fieldbus is selected.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.1.2	3800	<b>Drive address</b>		UINT16		1	1	255	RW	INT	FVY
Setting of the address to which the drive responds when connected to the DCP serial line.											
Parameter available when PAR 4000 <b>Communication mode</b> = 2 (DCP).											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.1.3	3802	<b>Serial Baudrate</b>		ENUM		38400			RW	INT	FVSY
Setting of the DCP serial communication speed (Baud Rate).											
Parameter available when PAR 4000 <b>Communication mode</b> = 1 (DCP).											
<p>0 9600</p> <p>1 19200</p> <p>2 38400</p>											

## 1.2 Set encoder param?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.2.1	2102	Encoder supply	V	FLOAT		5.2	5.2	20.0	RW	INT	FVY

Setting of the encoder supply voltage. Min and max values are modified according to the selection of parameter 2104 **Encoder input config** as follows:

PAR 2104 Encoder input config	Def	Min	Max
[0] HTL	5.2 V	5.2 V	20.0 V
[1] TTL	5.2 V	5.2 V	6.0 V

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.2.2	2132	Encoder mode		ENUM		None			RWZ	INT	FVSY

The drive has an integrated encoder card. The encoder mode can be selected in accordance with the following table:

- 0 None
- 1 Digital
- 2 Sinus
- 3 Sinus SINCOS
- 4 Sinus ENDAT
- 5 Sinus BISS
- 6 ENDAT
- 7 BiSS
- 8 Sinus SSI

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.2.3	2100	Encoder pulses	ppr	UINT16		1024	4	16384	RWZ	INT	FVY

Setting of the number of feedback encoder impulses. During setup, for incremental sinusoidal encoders + absolute EnDat, encoder absolute EnDat Full digital and Hiperface encoders this value is set automatically by reading the number of incremental encoder impulses.

With the EnDat Full digital Encoder, the value set automatically may be below the minimum.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.2.4	2110	Encoder signal check		ENUM		Check A-B			RWZ	EXP	FVY

Configuration of which incremental digital encoder channels are to be controlled in order to process the [22] **Speed fbk loss** alarm signal.

- 1 Check A-B
- 2 Check A-B-Z

Set 1 to check for signal on channels A-B

Set 2 to check for signal on channels A-B-Z

If the application detects the absence of feedback the **Speed fbk loss** [22] is generated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.2.5	7106	BiSS N bit ST		UINT16		13	0	64	RW	EXP	FVY

This parameter allows setting of bit Number for single turn data. This parameter is automatically setted in case of encoder with EDS. This parameter must be setted manually in case of encoder without EDS.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.2.6	7108	BiSS N bit MT		UINT16		0	0	64	RW	EXP	FVY

This parameter allows setting of bit Number for multi turn data. This parameter is automatically setted in case of encoder with EDS. This parameter must be setted manually in case of encoder without EDS.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.2.7	7114	BiSS Crc polinomy		UINT16		67	1	65535	RW	EXP	FVY

This parameter allows setting the BiSS Crc polinomy. This parameter is automatically setted in case of encoder with EDS. This parameter must be setted manually in case of encoder without EDS.

## 1.3 Set motor data?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.3.1	540	<b>Control type</b>		ENUM		ASY_VF			RWZ	INT	FVSY
The control mode is displayed.											
0 ASY SSC 1 ASY FOC 2 SYN FOC											
1.3.2	2000	<b>Rated voltage</b>	V	FLOAT		SIZE	150	480	RWZ	INT	FVSY
Set the motor rated voltage as indicated on the data plate. This is the voltage the drive must supply at the motor rated frequency.											
1.3.3	2002	<b>Rated current</b>	A	FLOAT		SIZE	1	1500	RWZ	INT	FVSY
The motor rated current at its rated power (kW / Hp) and voltage (indicated on the motor data plate).											
1.3.4	2004	<b>Rated speed</b>	rpm	FLOAT		SIZE	10	32000	RWZ	INT	FVSY
Rated speed of the motor with full load in rpm. In some motors the synchronous speed (e.g. 1500 rpm for a 4-pole motor) and slippage, i.e. the loss of revolutions between the motor idling condition and the rated load condition (e.g. 80 rpm), is indicated. Enter the following: synchronous speed - slippage.											
1.3.5	2006	<b>Rated frequency</b>	Hz	FLOAT		SIZE	1	1000	RWZ	INT	FVS
Rated frequency of the motor expressed in Hz.											
1.3.6	2008	<b>Pole pairs</b>		UINT16		SIZE	1	60	RWZ	INT	FVSY
Motor pole pairs. The number of motor pole pairs is calculated using the motor plate data and applying the following formula:											
$p = \frac{60 [s] \times f [Hz]}{nN [rpm]}$											
Where: p = motor pole pairs; f = motor rated frequency (PAR 2006) Vn = motor rated speed (PAR 2004).											
1.3.7	2010	<b>Rated power</b>	kW	FLOAT		SIZE	0.1	1500	RWZ	INT	FVS
Rated power of the motor at the rated voltage and frequency. This value represents the mechanical power produced on the motor shaft.											
1.3.8	2012	<b>Cos phi</b>		FLOAT		SIZE	0.6	0.95	RWZ	INT	FVS
Motor power factor, as indicated on the data plate (Cos φ). This parameter is not always present on the motor data plate: in that case use the default value present in the drive.											
1.3.9	2014	<b>Torque constant</b>	Nm/A	FLOAT		SIZE	0	120	RWZ	INT	Y
Setting of the ratio between the torque generated and the rated current of the motor.											

## 1.4 Set mechanical data?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.4.1</b>	<b>11002</b>	<b>Travel units sel</b>		ENUM		Hz (m/s)			RWZ	INT	FVY

Selection of the unit of measure for speed references.

- 0** Hz (output frequency)
- 1** m/s (cabin speed and depends on the mechanical constant)
- 2** rpm (speed of the motor shaft)

When the unit of measure is modified the conversion constants are re-calculated, the units of measure are changed in the parameter list and the multispeed values are converted into the new unit of measure (the result may contain approximations due to the conversion calculations).

A variable representing the speed of the cabin in m/s (fpm) is always available (PAR 14242).

There are fixed units of measure for the acceleration and deceleration parameters m/s<sup>2</sup>, and for jerks m/s<sup>3</sup>.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.4.2</b>	<b>11006</b>	<b>Cabin speed</b>	m/s	FLOAT		1	0	10	RWZ	INT	FVY

Sets the maximum speed of system operation. This is also used for the recalculation of the full scale speed (PAR 680, **Full scale speed**).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.4.3</b>	<b>11010</b>	<b>Gearbox ratio</b>		FLOAT		45 (1)	1	200	RW	INT	FVY

Sets the reduction ratio between motor and pulley.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.4.4</b>	<b>11164</b>	<b>Rope ratio</b>		FLOAT		1 (2)	1	10	RWZ	INT	FVY

Sets the reduction ratio due to rope windings.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.4.5</b>	<b>11012</b>	<b>Pulley diameter</b>	m	FLOAT		0.6 (0.32)	0	5	RWZ	INT	FVY

Impostazione del diametro della puleggia.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.4.6</b>	<b>11150</b>	<b>Car weight</b>	kg	FLOAT		400	0	10000	RW	INT	FVY

Setting of the weight of the cabin (intended as the total empty weight of everything hanging from the ropes: frame, walls, door operator, appliances, etc.).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.4.7</b>	<b>11152</b>	<b>Counter weight</b>	kg	FLOAT		1000	0	10000	RW	INT	FVY

Setting of the weight of the counterweight, including its frame.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.4.8</b>	<b>11154</b>	<b>Load weight</b>	kg	FLOAT		450	0	10000	RW	INT	FVY

Setting of the weight of the maximum load for system dimensions.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.4.9</b>	<b>11156</b>	<b>Rope weight</b>	kg	FLOAT		20	0	1000	RW	INT	FVY

Setting of the weight of the cable (intended as the total weight of all car suspension ropes).

## 1.5 Set speeds?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>1.5.1</b>	<b>11020</b>	<b>Multi speed 0</b>		FLOAT		5 (0.1)	0	10000	RW	ESY	FVY

Setting of the multispeed 0 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp. This setting is taken as the default low speed value. If the **Multi speed 0** value is changed, it will only be acquired when the drive is rebooted.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.2	11022	<b>Multi speed 1</b>		FLOAT		47.73 (1.0)	0	10000	RW	ESY	FVY

Setting of the multispeed 1 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp. This setting is taken as the default high speed value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.3	11024	<b>Multi speed 2</b>		FLOAT		20 (0.4)	0	10000	RW	ESY	FVY

Setting of the multispeed 2 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp. This setting is taken as the default maintenance speed value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.4	11026	<b>Multi speed 3</b>		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 3 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.5	11028	<b>Multi speed 4</b>		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 4 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.6	11030	<b>Multi speed 5</b>		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 5 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.7	11032	<b>Multi speed 6</b>		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 6 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.8	11034	<b>Multi speed 7</b>		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 7 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

#### Note!

By default, the multispeed 0, 1 and 2 have the values 5.00Hz, 47.73Hz and 20Hz respectively referred to a cabin speed of 1m/s.

The first three multispeeds take the values of 10%, 100% and 45% of the cabin speed each time the mechanical data is changed.

In addition, each time mechanical data is changed, the drive performs a multispeed congruity check that works as follows:

a) where a multispeed is greater than the nominal speed, it shall be limited to that speed;

b) if the mechanical values are changed further and the previously limited speeds are now lower than the nominal speed, these multispeeds are not changed (bearing in mind that the first 3 multispeeds always take the values in %).

By manually entering values of multispeed these are limited to the cabin speed, while following a change in the mechanical parameters that change the cabin speed, will be returned to the default values percentages.

## 1.7 Run autotune still?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.7.1	2032	Autotune		BIT		0	0	1	RWZ	INT	FVSY

Performs self-tuning with the motor having ropes already wound on the traction pulley.

The self-tuning procedure may cause limited rotation of the motor shaft. To perform self-tuning, follow the procedure described on parameter PAR 2020 **Take parameters**.

## 1.8 Save parameters?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.8.1	550	Save parameters		BIT		0	0	1	RW	INT	FVSY



Any changes to parameter values immediately affect drive operations, but are not automatically saved in the permanent memory.

The "Save Parameters" command is used to save current parameter values in the permanent memory.

Any changes that are not saved will be lost when the drive is switched off.

To save parameters press the **E** key to start the save parameters procedure and press **E** again to confirm.

## 2 OPTIMIZATION WIZARD (OPTIMIZ. WIZARD)

Through this menu it is possible to immediately optimize the control response in order to maximise cabin comfort.

In addition to the automatic procedure (**Learning Trip** function), three or five levels of optimization are available for each of the **Rollback**, **Comfort low speed**, **Comfort high speed** parameters.

To avoid possible vibrations, the optimization level should not be increased if not necessary.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
2.1	9720	Learning trip		BIT		0	0	1	RWZ	INT	VSY

Launch the "Learning Trip" function, an automatic procedure to simplify commissioning and optimise the drive according to the system's mechanical parameters.




Before enabling the function:


- run the **Startup wizard**,
- check cabin movement in inspection mode to rule out any macroscopic data entry errors.

The function can be performed from the keypad and via the WEG\_DriveLabs configurator (Wizard menu / Optimization Wizard).

To facilitate operations, the configurator/keypad suggests what actions are to be performed (e.g. up one floor, down one floor, etc.), intercepting any incorrect actions and communicating them (e.g. call to floor short, calls always in the same direction, etc.) so as to recommend the corrective action.




Once the sequences envisaged by the function have been completed, the basic speed regulator gains are automatically recalculated. Therefore the user can run a test travel to evaluate the improvement in performance obtained and, if still not satisfied, the Learning Trip procedure can be repeated or the deficient aspects improved using the appropriate sections of the optimisation wizard (Rollback, Comfort low speed, Comfort high speed).





- (1) You are prompted to perform the first run (up or down).
- (2) Perform the up run.
- (3) You are prompted to perform a down run.
- (4) Perform the down run.
- (5) Repeat the operations (1) (2) (3) (4) several times.
- (6) Procedure successfully completed.

Other possible messages:



Procedure not successfully completed.

Short run error.

Wrong direction error.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>2.2</b>	<b>12000</b>	<b>Rollback at start</b>		UINT32		1	1	5	RW	ESY	FVY

In some applications, for a short time at the start of the stroke when the locking brake is lifted, the cab may move in the opposite direction to the controlled direction.

Selecting one of the five levels can reduce/eliminate the noise.



- 1 Basic level pre-selected as default level
- 2 Intermediate optimization level 2
- 3 Intermediate optimization level 3
- 4 Intermediate optimization level 4
- 5 High optimization level

To avoid possible vibrations, the optimization level should not be increased if not necessary.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>2.3</b>	<b>12006</b>	<b>Rollback at arrival</b>		UINT32		1	1	3	RW	ESY	FVY

In some applications, an undesired displacement of the cab may occur for a short time at the end of the stroke when the engine is held still while waiting for the brake to close.

Selecting one of the five levels can reduce/eliminate the noise.

- 1 Basic level pre-selected as default level
- 2 Intermediate optimization level 2
- 3 Intermediate optimization level 3
- 4 Intermediate optimization level 4
- 5 High optimization level

To avoid possible vibrations, the optimization level should not be increased if not necessary.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>2.4</b>	<b>12002</b>	<b>Comfort high spd</b>		UINT32		1	1	3	RW	ESY	FVY

During the high speed section there may be oscillations in the cabin or abrupt and sudden movements.

By selecting one of the five levels the disturbance can be reduced or eliminated.

- 1 Basic level pre-selected as default level
- 2 Intermediate optimization level 2
- 3 High optimization level

To avoid possible vibrations, the optimization level should not be increased if not necessary.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>2.5</b>	<b>12004</b>	<b>Comfort low spd</b>		UINT32		1	1	3	RW	ESY	FVY

During the low speed section there may be oscillations in the cabin or abrupt and sudden movements. By selecting one of the five levels the disturbance can be reduced or eliminated.

- 1 Basic level pre-selected as default level
- 2 Intermediate optimization level 2
- 3 High optimization level

To avoid possible vibrations, the optimization level should not be increased if not necessary.

## 3 TROUBLESHOOTING

For each typical problem of a Lift System, the parameter of the drive on which to act to solve the problem, are displayed by selecting the relative action.

### 3.1 Start

Problem			Solution								
The cabin doesn't start smoothly.			Increase the brake opening delay.								

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.1.1	11064	Brake open delay	ms	INT16/32		500	0	10000	RW	ESY	FVY

Setting of the brake opening delay time.

### 3.2 Rollback

Problem			Solution								
There is an unwanted movement of the cabin in the opposite direction to the commanded at the start.			Modify the proportional and /or integral speed gain at start.								

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.2.1	2200	Boost Voltage	%	FLOAT		3	0	20.0	RW	INT	F

Specifica il valore della tensione supplementare applicata ai morsetti del motore alle basse velocità al fine di incrementare la coppia erogata. Valori eccessivi producono un aumento della corrente assorbita e del riscaldamento del motore a causa delle perdite resistive nell'avvolgimento statorico.

Intervallo di valori possibili : 0...20% della tensione nominale del motore.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.2.2	2212	V/Hz Boost Mode		ENUM		Auto			RW	INT	F

This parameter can be used to select one of the following two boost voltage generation modes:

- 0 Fixed
- 1 Auto

In the "Fixed" mode, the boost voltage is defined by the user through parameter PAR 2200 **Boost voltage**.

At zero speed, the drive applies a voltage to the motor terminals equal to the value defined in parameter PAR 2200.

This additional voltage is gradually reduced for speeds higher than zero until it is eliminated for output frequencies above the threshold equal to half the rated frequency defined in parameter PAR 2204 **Base frequency** (see figure).

In "Auto" mode the boost voltage is dynamically adjusted by the drive.




Figure 11.4: V/f characteristic curve profile

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

3.2.3	2794	<b>SR-P gain at start</b>	%	FLOAT		150.0	0.0	400.0	RW	INT	VSY
-------	------	---------------------------	---	-------	--	-------	-----	-------	----	-----	-----

Defines the level of proportional control exercised by the PI regulator during the start phase.

In this initial phase the motor speed control loop must be sufficiently responsive to compensate for any load imbalance and thus counteract the roll-back effect.

An excessive increase of this parameter may generate system vibrations or unstable behaviour.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

3.2.4	2796	<b>SR-I gain at start</b>	%	FLOAT		110.0	0.0	400.0	RW	INT	VSY
-------	------	---------------------------	---	-------	--	-------	-----	-------	----	-----	-----

Defines the level of integral control exercised by the PI regulator during the start phase.

Increasing the value of this parameter improves the speed control response in compensating for any load imbalance when the brake is opened.

### 3.3 Too fast acceleration (Too fast accel.)

Problem				Solution							
The acceleration is too abrupt.				Decrease the value of the initial acceleration jerk and / or acceleration value.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

3.3.1	11040	<b>Accel initial jerk</b>	m/s <sup>3</sup>	FLOAT		0.2	0.001	20	RW	ESY	FVY
-------	-------	---------------------------	------------------	-------	--	-----	-------	----	----	-----	-----

Setting of the jerk value for the first part of the acceleration.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

3.3.2	11042	<b>Acceleration</b>	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY
-------	-------	---------------------	------------------	-------	--	-------	-------	----	----	-----	-----

Setting of the maximum acceleration value.

### 3.4 Slow speed vibrations (Slow speed vibr.)

Problem				Solution							
There are vibrations during the movement of the cabin at slow speed.				Modify the proportional and integral speed gain.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

3.4.1	2752	<b>SR-P gain low speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
-------	------	----------------------------	---	-------	--	-------	-----	-------	----	-----	-----

Defines the level of the proportional control action exercised by the PI regulator for operating speeds below the minimum threshold defined in parameter PAR 2760 **SR-low speed thrsd**.

For operating speeds above this threshold, the actual level of proportional action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2756 **SR-P gain high speed**.

In the speed range between the thresholds defined in PAR 2760 **SR-low speed thrsd** and PAR 2762 **SR-high speed thrsd** parameters, the weight of the proportional action varies linearly with the speed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

3.4.2	2754	<b>SR-I gain low speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
-------	------	----------------------------	---	-------	--	-------	-----	-------	----	-----	-----

Defines the level of the integral control action exercised by the PI regulator for operating speeds below the minimum threshold defined in parameter PAR 2760 **SR-low speed thrsd**.

For operating speeds above this threshold, the actual level of integral action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2758 **SR-I gain high speed**.

In the speed range between the thresholds defined in PAR 2760 **SR-low speed thrsd** and PAR 2762 **SR-high speed thrsd** parameters, the weight of the proportional action varies linearly with the speed.

### 3.5 High speed vibrations (High speed vibr.)

Problem				Solution							
There are vibrations during the movement of the cabin at high speed.				Modify the proportional and integral speed gain.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

3.5.1	2756	<b>SR-P gain high speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
-------	------	-----------------------------	---	-------	--	-------	-----	-------	----	-----	-----

Defines the level of the proportional control action exercised by the PI regulator for operating speeds above the maximum threshold defined in parameter PAR 2762 **SR-high speed thrsd**.

For operating speeds lower than this threshold, the actual level of proportional action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2752 **SR-P gain low speed**.

In the speed range between the minimum and maximum thresholds defined in PAR 2760 **SR-low speed thrsd** and PAR 2762 **SR-high speed thrsd** parameters, the weight of the proportional action varies linearly with the speed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.5.2	2758	<b>SR-I gain high speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY

Defines the level of the integral control action exercised by the PI regulator for operating speeds above the maximum threshold defined in parameter PAR 2760 **SR-low speed thrsd**.

For operating speeds lower than this threshold, the actual level of integral action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2754 **SR-I gain low speed**.

In the speed range between the thresholds defined in PAR 2760 **SR-low speed thrsd** and PAR 2762 **SR-high speed thrsd** parameters, the weight of the integral action varies linearly with the speed.

### 3.6 Too fast deceleration (Too fast dec.)

Problem				Solution							
The deceleration with which the cabin approaches the floor is too abrupt.				Decrease the value of the initial deceleration jerk and / or deceleration value.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.6.1	11046	<b>Decel initial jerk</b>	m/s <sup>3</sup>	FLOAT		0.6	0.001	20	RW	ESY	FVY

Setting of the jerk value for the first part of the deceleration.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.6.2	11048	<b>Deceleration</b>	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY

Setting of the maximum deceleration value.

### 3.7 Floor leveling

Problem				Solution							
During the arrival at the floor there is an abrupt stop.				Decrease the brake closing delay.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.7.1	11068	<b>Brake close delay</b>	ms	INT16/32		500	0	10000	RW	ESY	FVY

Setting of the delay time after closing the brake.

### 3.8 Brake closing

Problem				Solution							
There is a noise when the brake is closed after the arrival at the floor.				Increase the current down delay.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.8.1	11070	<b>Current down delay</b>	ms	INT16/32		0 (800)	0	10000	RW	INT	Y

The purpose of this function is to avoid that after the brake is closed, the motor torque is removed instantaneously, causing bothersome stress inside the cabin.

To avoid this phenomenon, after closing the brake, the current limits are brought from the active value during travel to zero in the time set here.

#### Note!

Function not active in asynchronous motor control mode.

In synchronous motor control mode the application automatically sets the parameter PAR 2354 Torque curr lim sel to "T limit src" and PAR 2358 Torque limit src to "Ramp down limit".

### 3.9 Vibration analyzer

Problem				Solution							
Vibration analyzer measures system vibration expressed in two most significant resonant frequencies.				Values greater than 0 may indicate system vibrations. Typical causes could be intrinsic resonances of the system itself. insufficient guides lubrication, ovalized guide wheels, etc. If you need any advice on vibration damping you can contact after-sale service.							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.9.1	9464	<b>Vibratio freq. 1</b>	Hz	FLOAT		0	0.0	0.0	R	INT	VSY
Indicates the value in Hz of the first measured resonance frequency. If two frequencies have been detected, <b>Vibration freq. 1</b> will be the one with the higher amplitude.											
A "0" value indicates that no resonance frequency is present in the measurement band.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.9.2	9466	<b>Vibration freq. 2</b>	Hz	FLOAT		0	0.0	0.0	R	INT	VSY
Indicates the value in Hz of the second measured resonance frequency. If two frequencies have been detected, <b>Vibration freq. 2</b> will be the one with the lower amplitude.											
A "0" value indicates that no second resonance frequency is present in the measurement band.											

## 4 DRIVE

### 4.1 DRIVE MONITOR

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.1	250	<b>Output current</b>	A	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
The drive output current is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.2	252	<b>Output voltage</b>	V	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
The drive line voltage output is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.3	254	<b>Output frequency</b>	Hz	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
The drive output frequency is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.4	664	<b>Speed setpoint</b>	rpm	INT16	16BIT_H	0	0	0	R	ESY	FVSY
The motor speed reference is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.5	260	<b>Motor speed</b>	rpm	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
The actual output speed of the motor is displayed (in ASY FOC/SYN = speed measured by the encoder, in ASY VF = speed estimated by the drive).											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.6	270	<b>DC link voltage</b>	V	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
The direct voltage of the intermediate circuit capacitors is displayed (DC-Bus).											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.7	272	<b>Heatsink temperature</b>	degC	FLOAT	16BIT_L	0	0	0	R	ESY	FVSY
The temperature measured by the linear sensor integrated in the IGBT modules is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.8	274	<b>Motor temp</b>	degC	INT16		0	0	0	R	ESY	

Motor temperature detected by the KTY external sensor. Parameter displayed only if the sensor is connected.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.9	280	<b>Torque current ref</b>	A	FLOAT	16BIT_H	0	0	0	R	EXP	FVSY
The current reference used for torque control is displayed (in the sensorless vector and field-oriented vector modes).											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.10	282	<b>Magnet current ref</b>	A	FLOAT	16BIT_H	0	0	0	R	EXP	FVSY
The magnetizing current reference is displayed (in the sensorless vector and field-oriented vector modes).											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.11	284	<b>Torque current</b>	A	FLOAT	16BIT_H	0	0	0	R	INT	FVSY
The actual torque current value is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.12	286	<b>Magnet current</b>	A	FLOAT	16BIT_H	0	0	0	R	INT	FVSY
The actual magnetizing current value is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.13	3212	<b>Motor overload</b>	%	UINT16	16BIT_H	0	0	100	R	ESY	FVSY
The motor overload level is displayed (100% = alarm threshold).											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.14	368	<b>Drive overload</b>	%	UINT16	16BIT_H	0	0	100	R	ESY	FVSY
The drive overload level is displayed. An instantaneous overload of 200% of the drive rated current is allowed for 10s. The thermal image $I^2t$ adjusts the drive output current thresholds. During normal operation, the instantaneous output current value can reach 200% of the drive rated current. When the overload level par. 368 <b>Drive overload</b> reaches 100%, the output current threshold is reduced to 100% of the rated current, and stays at that value until the $I^2t$ integrator cycle is complete. At this point the instantaneous overload of 200% or 150% (below 3Hz) will be re-activated.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.15	3260	<b>Bres overload</b>	%	UINT16	16BIT_H	0	0	100	R	ESY	FVSY
The braking resistor overload limit is displayed (100% = alarm threshold).											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.16	1066	<b>Enable state mon</b>	UINT16	16BIT_L	0	0	0	1	R	ESY	FVSY
The drive Enable command status is displayed. Voltage must be present on terminal 9, in the case of ADL550 also at the Safety enable terminals. The FR Forwardstart command is needed to start the inverter.											

**1** Enabled Drive enabled

**0** Disabled Drive disabled

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.17	1068	<b>Start state mon</b>	UINT16	16BIT_L	0	0	0	1	R	ESY	FVSY
The drive <b>Start</b> command status is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.18	1070	<b>FastStop state mon</b>	UINT16	16BIT_L	0	0	0	1	R	ESY	FVSY
The drive <b>FastStop</b> command status is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.19	2386	<b>Torque ref</b>	%	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY
The value of the torque reference is displayed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.20	2388	Torque	%	FLOAT	16BIT_H	0.0	0.0	0.0	R	INT	FVSY
Displays the current torque value.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.21	372	In use current limit	A	FLOAT	16BIT_H	0	0	0	R	EXP	FVSY
Displays the actual current limit.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.23	1200	Dig input mon		UINT16	16BIT_L	0	0	0	R	ESY	FVSY
The logic status of the digital inputs is displayed. It can also be read via a serial line or fieldbus. The data are contained in a word, where each bit is 1 if voltage is supplied to the corresponding input terminal.											

- 1 Input high.
- 0 Input low.

Example:

0	0	0	0	0	0	0	0	0	1	1	
Enable DI 1											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.24	1202	Dig input mon x		UINT16	16BIT_L	0	0	0	R	ESY	

The status of the digital inputs of the EXP-IO1-ADL500 expansion card is displayed. It can also be read via a serial line or fieldbus. The data are contained in a word, where each bit is 1 if voltage is supplied to the corresponding input terminal.

- 1 Input high.
- 0 Input low.

Example:

0	0	0	0	0	0	0	1	1	1	1	
DI 1X DI 2X DI 3X DI 4X											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.25	1400	Digital output mon		UINT16		0	0	0	R	ESY	FVSY

The status of the digital outputs is displayed. It can also be read via a serial line or fieldbus. The data are contained in a word, where each bit is 1 if the associated output relay is closed.

- 1 Output enabled.
- 0 Output disabled.

Example:

0	0	0	0	0	0	0	0	1	1		
DO 1 DO 2											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.26	1402	Digital output mon x		UINT16		0	0	0	R	ESY	

The status of the digital outputs of the EXP-IO1-ADL500 expansion card is displayed. It can also be read via a serial line or fieldbus. The data are contained in a word, where each bit is 1 if the associated output relay is closed.

- 1 Output enabled.
- 0 Output disabled.

Example:

0	0	0	0	0	0	0	0	1	1		
DO 1X DO 2X											

## 4.2 DRIVE INFO

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.2.1	172	<b>Drive type</b>		ENUM		ADL510			R	ESY	FVSY
The drive series identification code is displayed.											
1 ADL510 2 ADL530 3 ADL550											
4.2.2	482	<b>Drive size</b>		UINT16		0	0	0	R	ESY	FVSY
The drive power size is displayed.											
4.2.3	484	<b>Drive family</b>		ENUM		No Power			R	INT	FVSY
The mains voltage range accepted by the drive is displayed (e.g. 230V..480V). The undervoltage alarm refers to this voltage value. The condition <b>No power</b> occurs when the regulation board has just left from production and has never been configured for any power.											
0 No power 1 230V..480V											
4.2.4	488	<b>Drive cont current</b>	A	FLOAT		CALCF	0.0	0.0	R	ESY	FVSY
The current that the drive can deliver continuously according to size, supply voltage and programmed switching frequency is displayed.											
4.2.6	174	<b>Firmware version</b>		UINT32		0	0	0	R	ESY	FVSY
The HMI firmware version operating in the drive is displayed in the X.X.X format: the first is the (X.X.X) firmware version, the second the (X.X.X) firmware release, and the third is the (X.X.X) firmware type.											
On the keypad these are displayed in the version.release format. The parameter reading from the serial communication device or fieldbus returns the version in the high byte and the release in the low byte.											
4.2.7	176	<b>DSP Firmware version</b>		UINT32		0	0	0	R	ESY	FVSY
The firmware version of the DSP application operating in the drive is displayed in the X.X.X format: the first is the (X.X.X) firmware version, the second the (X.X.X) firmware release, and the third is the (X.X.X) firmware type..											
On the keypad these are displayed in the version.release format. The parameter reading from the serial communication device or fieldbus returns the version in the high byte and the release in the low byte.											
4.2.8	180	<b>DSP Boot version</b>		UINT32		0	0	0	R	ESY	FVSY
Processor boot version.											
4.2.9	182	<b>HMI Boot version</b>		UINT32		0	0	0	R	ESY	FVSY
Processor boot version.											
4.2.10	184	<b>Application name</b>		STRING16		0	0	0	R	ESY	FVSY
Displays the name of the installed application.											
4.2.11	192	<b>Application version</b>		UINT32		0	0	0	R	ESY	FVSY
The firmware version of the application operating in the drive is displayed in the XX.XX.XX format: the first is the (XX).											

XX.XX) firmware version, the second the (XX.XX.XX) firmware release, and the third is the (XX.XX.XX) firmware type.  
On the keypad these are displayed in the version.release format. The parameter reading from the serial communication device or fieldbus returns the version in the high byte and the release in the low byte.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.2.12</b>	<b>198</b>	<b>Hardware version</b>		UINT16		0	0	0	R	ESY	FVSY
The hardware version of the adjustment board is displayed.											
<b>4.2.13</b>	<b>520</b>	<b>Product S/N</b>		UINT32		0	0	0	R	ESY	FVSY
The drive serial number is displayed.											
<b>4.2.14</b>	<b>522</b>	<b>Regulation S/N</b>		UINT32		0	0	0	R	ESY	FVSY
The drive regulation card serial number is displayed.											
<b>4.2.15</b>	<b>524</b>	<b>Power S/N</b>		UINT32		0	0	0	R	ESY	FVSY
The drive power card serial number is displayed.											
<b>4.2.16</b>	<b>526</b>	<b>Power file ver.rel</b>		UINT16		0	0	0	R	ESY	FVSY
The drive power card configuration release is displayed.											
<b>4.2.17</b>	<b>9562</b>	<b>IP address</b>		UINT32		0	0	0	R	ESY	FVSY
Displays the IP address in use.											
<b>4.2.18</b>	<b>9600</b>	<b>MAC address</b>		STRING16		0	0	0	R	EXP	FVSY
Displays the drive's MAC address.											

## 4.3 DRIVE CONFIG

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.1	550	<b>Save parameters</b>		BIT		0	0	1	RW	ESY	FVSY

Any changes to parameter values immediately affect drive operations, but are not automatically saved in the permanent memory. The “Save Parameters” command is used to save current parameter values in the permanent memory.

Any changes that are not saved will be lost when the drive is switched off.

To save parameters follow the procedure described in STEP 7 of the **Startup wizard**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.2	580	<b>Load default</b>		BIT		0	0	1	RWZ	ESY	FVSY

Transfers the standard factory settings to the drive memory (“Def” column in the parameters table).

This does not apply to the access level and password parameters, for which see the menu “6.6 NETWORK AND ACCESS” on page 87).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.3	540	<b>Control type</b>		ENUM		ASY_VF			RWZ	INT	FVSY

The ADL550 can operate in different control modes:

- 0 ASY SSC
- 1 ASY FOC
- 2 SYN FOC

**ASY SSC**: the open loop V/f mode. It is the simplest type of asynchronous motor control, as the only parameters required are the rated voltage, current and frequency of the motor.

The ASY SSC control mode is factory-set and does not require any speed feedback. The natural variation in speed generated by machine load induction (slippage) can be compensated using PAR **2214 V/Hz Slip ctrl gain** and **2224 V/Hz slip filter constant**.

**ASY FOC**: in the **field oriented vector mode** an encoder is required for closed loop feedback. With this mode it is possible to achieve extremely high dynamic responses thanks to the regulation bandwidth, maximum torque even with the rotor blocked, speed and torque control. Numerous regulation parameters can be used to adjust the drive to each specific application, for instance adaptive gains, system inertia compensation, etc.

**SYN FOC**: in the **field oriented vector mode** for permanent magnet synchronous motor. An encoder is required for closed loop feedback. With this mode it is possible to achieve extremely high dynamic responses thanks to the regulation bandwidth, maximum torque even with the rotor blocked, speed and torque control. Numerous regulation parameters can be used to adjust the drive to each specific application, for instance adaptive gains, system inertia compensation, etc.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.4	554	<b>Access level</b>		ENUM		Intermediate			RW	ESY	FVSY

Determines the parameters that can be displayed and/or modified to suit the operator's needs and capabilities.

- 0 Readonly
- 1 Easy
- 2 INT
- 3 Expert
- 4 Service

**Readonly**: read-only level, where a limited number of parameters are displayed.

**Easy**: level that allows parameters to be displayed and modified for basic commissioning, in V/f control and without tuning.

**Intermediate**: level that allows parameters to be displayed and modified for complete commissioning and basic optimization.

**Expert**: level that allows parameters to be displayed and modified for advanced optimization.

**Service**: reserved for Service.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.5	568	<b>Enable password</b>		BIT		0	0	1	RW	EXP	FVSY

When this parameter is OFF (default), it is possible to change the selection of PAR 554 **Access level** (parameter access level, excluding Service level) without entering the password.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.7	560	<b>Mains voltage</b>		ENUM		400 V			RWZ	INT	FVSY

Setting of the available mains voltage value in Volts. Detection of the undervoltage alarm refers to this value.

- 1** 230 V
- 2** 380 V
- 3** 400 V
- 4** 415 V
- 5** 440 V
- 6** 460 V
- 7** 480 V

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.3.8</b>	<b>448</b>	<b>Emergency UV</b>	V	FLOAT		CALCF	0	CALCF	RWZ	INT	FVSY

This parameter enables for the undervoltage threshold to be configured during emergency conditions.

This parameter also identifies the voltage at which it is necessary to send the closing command of the precharge relay (which must take place when the voltage on the DC-link has exceeded approximately 70% of its final value). In the presence of batteries connected to the EM input, parameter 448 must be set manually to 70% of the minimum output voltage of the battery pack (or, more generally, of the power source used).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.3.9</b>	<b>450</b>	<b>Undervoltage</b>	V	FLOAT		300.0	0	0	RW	INT	FVSY

Lets you change the Undervoltage value. Minimum and maximum default values depend on line voltage.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.3.10</b>	<b>2690</b>	<b>Chopper ON</b>	V	FLOAT		CALCF	0	CALCF	RW	EXP	FVY

Corresponds to the threshold of activation of the braking resistance. It's so possible to increase this value to the level of the overvoltage threshold.

(ADL500-...-4 = 802 Vdc, ADL500-...-2T = 396 Vdc, ADL500-...-2M = 396 Vdc).

The range is defined by the parameter 560 Mains voltage.

**Note!**

If the mains voltage parameter is set to the maximum possible value, the brake resistance activation threshold can only take the maximum value and cannot be changed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.3.11</b>	<b>1010</b>	<b>Fast Start disable</b>	BIT			1	0	1	RW	EXP	FVSY

Changes the engine start mode after a drive restart. In ON mode the drive, after switching on, starts only if the direction input is activated after the drive signal Ok. With OFF mode the drive, after switching on, starts after the OK drive signal seeing the status of the direction signal even if this has been activated before the OK drive signal becomes high.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.3.12</b>	<b>574</b>	<b>Startup display</b>	INT16			-1	-1	20000	RW	INT	FVSY

It is possible to set the parameter number that will automatically be displayed when the drive is switched on.

If set to -1 the main menu is automatically displayed when the drive is turned on.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.3.13</b>	<b>576</b>	<b>Display backlight</b>	BIT			0	0	1	RW	INT	FVSY

Enabling of the backlight on the drive display.

If set to 0 (Off) the display backlight will go off when the drive has been on for three minutes.

If set to 1 (On) the backlight will stay on for as long as the drive is powered.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.3.14</b>	<b>578</b>	<b>Language select</b>	ENUM			GB			RW	INT	FVSY

Setting of the drive programming language.

- 0** English
- 1** Italian
- 2** French
- 3** German
- 4** Spanish
- 5** Turkish

English and Italian are pre-installed on the drive, to select Italian set **1**.

To set a different language, download the available languages file from the WEG site (<https://www.weg.net/...>, DRIVE SET-UP folder) (wizard available in manual ADL500 HW+QS, section 8.2.8.1 Language selection):

- Unzip and save the files on a USB flash drive, in a folder called "ADL500LN".
- Insert the flash drive into the drive's USB port.
- Select the **Language Select** parameter 570 and set the new language,
- Start the language loading procedure, after which the drive will reboot.

**Note!**

The language file must be aligned with the version of both the drive firmware and application. Check correspondence.

The new language will be loaded into the drive memory and replace the Italian. English cannot be replaced by another language.

**Note!**

The Load Default command (par. 580) does not modify this parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.15	7200	<b>Password recovery</b>		BIT		0	0	1	RW	ESY	FVSY

If executed, it generates a code in PAR 7210 **Recovery code** to be communicated to WEG to obtain a temporary Expert password. To be used in case the password is lost.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.16	7210	<b>Recovery code</b>		UINT32		0.0	0	0	R	ESY	FVSY

This parameter is used to write the code to be communicated to WEG to obtain a temporary Expert password (see PAR 7200 **Password recovery**). To be used in case the password is lost.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.17	7220	<b>Alarm time</b>	min	UINT16		60	0	1092	RW	EXP	FVSY

Sets the drive logout time, in minutes, calculated from the first start-up.

Once the activity time set in this parameter has elapsed the drive will be reset to Readonly level.

If set to 0, automatic logout is disabled.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.18	590	<b>Save par from keypad</b>		BIT		0	0	1	RWZ	INT	FVSY

Transfers the parameters currently stored in the drive and saves them in the keypad memory.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.19	592	<b>Load par from keypad</b>		BIT		0	0	1	RWZ	INT	FVSY

Transfers the parameters from the keypad memory to the drive.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.20	596	<b>Save to USB</b>		BIT		0	0	1	RWZ	INT	

Transfers the drive parameters to the memory connected to the USB port.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.21	598	<b>Load from USB</b>		BIT		0	0	1	RWZ	INT	

Transfers parameters previously stored in the memory connected to the drive's USB port.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.23	1560	<b>App update</b>		BIT		0	0	1	RWZ	INT	FVSY

Update the app files in the internal drive memory.

To perform this operation, a USB flash drive with the "web" folder containing the files to be uploaded must be present. If the flash drive is not present, a message is displayed on the keypad.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.24	9548	WiFi safe removal		BIT		0	0	1	RW	ESY	

To prevent drive malfunctions, this function must be performed before removing the Wi-Fi module.

## 4.4 ALARM CONFIG

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.1	4500	Fault reset src		LINK	16BIT_L	6000			RW	INT	FVSY

Selection of the origin (source) of the signal to be used for the command to reset the drive after an alarm. The terminal that can be used for this function can be selected from among those listed in the “L\_DIGSEL2” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.2	4502	ExtFlt src		LINK	16BIT_L	6000			RW	INT	FVSY

Selection of the origin (source) of the signal to be used as the input for the drive external fault alarm **External fault [21]**. The terminal that can be used for this function can be selected from among those listed in the “L\_DIGSEL2” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.3	4504	ExtFlt activity		ENUM		Disable			RW	INT	FVSY

Setting of the behaviour of the drive in the event of an external fault alarm **External fault [21]**. This alarm indicates the intervention of a drive external protection.

- 0 Ignore
- 1 Warning
- 2 Disable drive
- 3 Stop
- 4 Fast stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.4	4506	ExtFlt restart		ENUM		Disable			RW	EXP	FVSY

Enabling of automatic restart after the **External fault [21]** alarm.

- 0 Disable
- 1 Enable

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.5	4508	ExtFlt restart time	ms	UINT16		1000	120	30000	RW	EXP	FVSY

Setting of the time within which the **External fault [21]** alarm must be reset in order to perform automatic restart.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Liv.	Vis.
4.4.6	4510	ExtFlt holdoff	ms	UINT16		0	0	10000	RW	INT	FVSY

Setting of the delay between the signalling of the external fault alarm **External fault [21]** and enabling of the alarm. If an alarm condition occurs, the drive will wait for the set time before blocking is enabled. If the alarm is removed within the set time, the drive will not indicate any alarm condition.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.7	4518	MotorOT threshold	degC	INT16		150	0	200	RW	INT	

Motor overtemperature alarm threshold. Parameter visible only if KTY selection is set using PAR 4530 **Ptc type**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.8	4520	MotorOT src		LINK	16BIT_L	6000			RW	INT	FVSY

Selection of the origin (source) of the signal to be used for the motor overtemperature alarm **MotorOT [12]**. The terminal that can be used for this function can be selected from among those listed in the “L\_DIGSEL2” selection list”.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.9	4522	MotorOT activity		ENUM		Warning			RW	INT	FVSY

Setting of the behaviour of the drive in case of a motor overtemperature alarm **MotorOT [12]**. This alarm indicates that the motor temperature is too high.

- 0 Ignore
- 1 Warning
- 2 Disable drive

- 3** Stop
- 4** Fast stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.10</b>	<b>4524</b>	<b>MotorOT restart</b>		ENUM		Disable			RW	EXP	FVSY
Enabling of automatic restart after the motor overtemperature alarm <b>Motor OT [12]</b> .											
<b>0</b>	Disable										
<b>1</b>	Enable										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.11</b>	<b>4526</b>	<b>MotorOT restart time</b>	ms	UINT16		1000	120	30000	RW	EXP	FVSY
Setting of the time within which the <b>Motor OT [12]</b> alarm must be reset in order to perform automatic restart.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.12</b>	<b>4528</b>	<b>MotorOT holdoff</b>	ms	UINT16		1000	0	30000	RW	EXP	FVSY
Setting of the delay between the signalling of the motor overtemperature alarm <b>MotorOT [12]</b> and enabling of the alarm. If an alarm condition occurs, the drive will wait for the set time before enabling the alarm. If the alarm is removed within the set time, the drive will not indicate any alarm condition											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.13</b>	<b>4530</b>	<b>Ptc type</b>		ENUM		None			RW	INT	
Selects the sensor type to be used to measure the motor temperature.											
<b>0</b>	None										
<b>1</b>	PTC										
<b>2</b>	KTY84-130										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.14</b>	<b>4532</b>	<b>PtcFail activity</b>		ENUM		Warning			RW	INT	
PTC sensor activity failure alarm ( <b>PTC failure [11]</b> ).											
<b>0</b>	Ignore										
<b>1</b>	Warning										
<b>2</b>	Disable drive										
<b>3</b>	Stop										
<b>4</b>	Fast stop										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.15</b>	<b>4534</b>	<b>PtcFail restart</b>		ENUM		Disable			RW	EXP	
Enables automatic restart after <b>PTC failure [11]</b> alarm.											
<b>0</b>	Disable										
<b>1</b>	Enable										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.16</b>	<b>4536</b>	<b>PtcFail restart time</b>	ms	UINT16		1000	120	30000	RW	EXP	
Sets the time within which the <b>PTC failure [11]</b> alarm must be reset to perform automatic restart.											
<b>4.4.17</b>	<b>4538</b>	<b>PtcFail holdoff</b>	ms	UINT16		1000	0	30000	RW	EXP	
Sets the delay between the <b>PTC failure [11]</b> alarm being signalled and the alarm being tripped. If an alarm condition arises, the drive waits until the set time has elapsed before tripping the alarm. If the alarm is eliminated within the set time, the drive does not indicate any alarm condition.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.18</b>	<b>4540</b>	<b>Overspeed threshold</b>	rpm	INT16		CALCI	0	16000	RW	INT	FVSY
Setting of the threshold above which the overspeed alarm <b>Overspeed [23]</b> is enabled.											



**Note!** The Overspeed threshold value (together with the Full scale speed PAR 680), is automatically recalculated each time the mechanical data parameters are modified.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.19	4542	<b>Overspeed activity</b>		ENUM		Disable			RW	INT	FVSY
Setting of the behaviour of the drive in case of a motor overspeed alarm <b>Overspeed [23]</b> . This alarm indicates that the motor speed has exceeded the threshold set in PAR 4540 <b>Overspeed threshold</b> .											
<b>0</b> Ignore <b>1</b> Warning <b>2</b> Disable drive											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.20	4544	<b>Overspeed holdoff</b>	ms	UINT16		0	0	5000	RW	INT	FVSY
Setting of the delay between the signalling of the motor overspeed alarm <b>Overspeed [23]</b> and enabling of the alarm. If an alarm condition occurs, the drive will wait for the set time before enabling the alarm. If the alarm is removed within the set time, the drive will not indicate any alarm condition.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.21	4550	<b>SpdRefLoss threshold</b>	rpm	INT16		100 (*)	0	CALCI	RW	INT	FVSY
Setting of the threshold below which the speed reference loss alarm <b>Speed ref loss [24]</b> occurs.											
(*) Def: 100 = ASY FOC, 10 = SYN FOC											

**Note!** The Overspeed threshold value (together with the Full scale speed PAR 680), is automatically recalculated each time the mechanical data parameters are modified.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.22	4552	<b>SpdRefLoss activity</b>		ENUM		Disable			RW	INT	FVSY
Setting of the behaviour of the drive in case of a speed reference loss alarm <b>Speed ref loss [24]</b> . This alarm indicates that the difference between the speed regulator reference and the actual motor speed is more than 100 rpm.											
This alarm must be disabled (= 0 Ignore) when parameter <b>2354</b> is set to a value other than zero.											
<b>0</b> Ignore <b>1</b> Warning <b>2</b> Disable drive											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.23	4554	<b>SpdRefLoss holdoff</b>	ms	UINT16		1000	0	10000	RW	INT	FVSY
The delay between the <b>Speed ref loss [24]</b> alarm condition signal and activation of the actual alarm. If an alarm condition occurs, the drive will wait for the set time before enabling the alarm. If the alarm is removed within the set time, the drive will not indicate any alarm condition.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.24	4560	<b>SpdFbkLoss activity</b>		ENUM		Disable			RW	INT	FVSY
Drive behaviour in case of the <b>Speed ref loss [24]</b> alarm is displayed. This alarm indicates the loss of the encoder feedback signals. Each type of encoder generates the <b>Speed ref loss [24]</b> alarm differently (incremental signal error, absolute signal error, serial error).											
<b>0</b> Ignore <b>1</b> Warning <b>2</b> Disable drive											

For absolute Endat encoders and absolute Hiperface encoders, after the alarm is generated, the encoder reset command must be sent to the encoder: during this procedure the application verifies whether the encoder is signalling an encoder alarm condition to the drive and the alarm is acquired from this.

The causes of the **Speed ref loss [24]** alarm and the information acquired from the encoder are shown in the **SpdFbk-Loss code** parameter 2172.

**Note!** See menu "8 ENCODER" for further information.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.25	4562	<b>SpdFbkLoss holdoff</b>	ms	UINT16		200	0	10000	RW	INT	FVSY
		Setting of the delay between the signalling of the speed feedback loss alarm condition <b>Speed fbk loss [22]</b> and the enabling of the alarm. If an alarm condition occurs, the drive will wait for the set time before enabling the alarm. If the alarm is removed within the set time, the drive will not indicate any alarm condition.									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.26	4564	<b>SpdfbkLoss threshold</b>	rpm	INT16	100	0	CALCI	RW	INT	FVSY	
		Setting the minimum speed by which the <b>Speed fbk loss [22]</b> is bypassed.									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.27	4570	<b>Drive ovld activity</b>		ENUM		Disable			RW	EXP	FVSY
		Setting of the behaviour of the drive in case of a drive overload alarm <b>Drive ovld</b> . This alarm indicates that the drive overload threshold has been reached.									
		<ul style="list-style-type: none"> <li>0 Ignore</li> <li>1 Warning</li> <li>2 Disable drive</li> <li>3 Stop</li> <li>4 Fast stop</li> </ul>									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.28	4572	<b>Motor ovld activity</b>		ENUM		Warning			RW	EXP	FVSY
		Setting of the behaviour of the drive in case of a motor overload alarm <b>Motor overload [14]</b> . This alarm indicates that the motor overload threshold has been reached.									
		<ul style="list-style-type: none"> <li>0 Ignore</li> <li>1 Warning</li> <li>2 Disable drive</li> <li>3 Stop</li> <li>4 Fast stop</li> </ul>									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.29	4574	<b>Bres ovld activity</b>		ENUM		Disable			RW	EXP	FVSY
		Setting of the behaviour of the drive in case of a braking resistor overload alarm <b>Bres overload [15]</b> . This alarm indicates that the braking resistor overload threshold has been reached.									
		<ul style="list-style-type: none"> <li>0 Ignore</li> <li>1 Warning</li> <li>2 Disable drive</li> <li>3 Stop</li> <li>4 Fast stop</li> </ul>									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.30	4582	<b>HTsens restart</b>		ENUM		Disable			RW	EXP	FVSY
		Enabling of automatic restart after the drive heatsink overtemperature alarm <b>Heatsink OT [9]</b> .									
		<ul style="list-style-type: none"> <li>0 Disable</li> <li>1 Enable</li> </ul>									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.31	4584	<b>HTsens restart time</b>	ms	UINT16		20000	120	60000	RW	EXP	FVSY
		Setting of the time within which the <b>Heatsink OT [9]</b> alarm must be reset in order to perform automatic restart.									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.32	4610	<b>Desat restart</b>		ENUM		Disable			RW	EXP	FVSY
		Enabling of automatic restart after the desaturation alarm <b>Desaturation [5]</b> . This alarm indicates a short circuit between the motor phases or on the power bridge.									
		<ul style="list-style-type: none"> <li>0 Disable</li> <li>1 Enable</li> </ul>									

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.33	4612	<b>Desat restart time</b>	ms	UINT16		2000	1000	10000	RW	EXP	FVSY
		Setting of the time within which the <b>Desaturation [5]</b> alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 1000 msec).									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.34	4620	<b>IOverC restart</b>		ENUM		Disable			RW	EXP	FVSY
		Enabling of automatic restart after the drive <b>Overcurrent [4]</b> alarm. This alarm indicates an overcurrent (or short circuit between phases or towards the ground).									
	0	Disable									
	1	Enable									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.35	4622	<b>IOverC restart time</b>	ms	UINT16		2000	1000	10000	RW	EXP	FVSY
		Setting of the time within which the <b>Overcurrent [4]</b> alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 1000 msec).									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.36	4630	<b>OverV restart</b>		ENUM		Disable			RW	EXP	FVSY
		Enabling of automatic restart after the <b>Oversupply voltage [1]</b> alarm. This alarm indicates an oversupply voltage on the intermediate circuit (DC link).									
	0	Disable									
	1	Enable									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.37	4632	<b>OverV restart</b>	ms	UINT16		2000	1000	10000	RW	EXP	FVSY
		Setting of the time within which the <b>Oversupply voltage [1]</b> alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 1000 msec).									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.38	4640	<b>UnderV restart</b>		ENUM		Enable			RW	EXP	FVSY
		Enabling of automatic restart after the <b>Undervoltage [2]</b> alarm. This alarm indicates an undervoltage on the intermediate circuit (DC link).									
	0	Disable									
	1	Enable									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.39	4642	<b>UnderV restart time</b>	ms	UINT16		1000	120	10000	RW	EXP	FVSY
		Setting of the time within which the <b>Undervoltage [2]</b> alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 100 msec).									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.40	4650	<b>UVRep attempts</b>		UINT16		5	0	1000	RW	EXP	FVSY
		Setting of the maximum number of attempts at automatic restart after the <b>Undervoltage [2]</b> alarm before a <b>Mult Undervoltage alarm</b> is generated. If this parameter is set to 1000 an infinite number of attempts are available.									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.41	4652	<b>UVRep delay</b>	s	UINT16		240	0	300	RW	EXP	FVSY
		Setting of the time within which, if no automatic restarts are executed after the <b>Undervoltage [2]</b> alarm, the attempts counter is reset. In this way the number of attempts set in PAR 4650 <b>Underv res attempts</b> are still available.									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.42	4654	<b>Phloss mov activity</b>		ENUM		Warning	0	0	RW	EXP	FVSY
		Setting the drive behavior in case of "PhLoss mov" alarm that signals the disconnection of a phase of the engine during running condition. The "PhLoss mov" function detects the disconnection of one or more phases of connection of the drive to the engine. This function is only operational when the motor is rotating. The configuration parameters of this function are IPA 4654, 4656, 4674.									

- 0** Ignore
- 1** Warning
- 2** Disable

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.43</b>	<b>4656</b>	<b>Phloss mov holdoff</b>	ms	UINT32		200	0	2000	R	EXP	FVSY

Represents the time for which the alarm condition must remain before the alarm is actually generated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.44</b>	<b>4674</b>	<b>Phloss mov freq thr</b>	hz	FLOAT		0.5	0.1	5	RW	EXP	FVSY

It represents the minimum frequency threshold exceeded which the function of PhLoss mov becomes operational. Below this threshold the function of PhLoss mov is inactive.

It may be useful to increase this parameter to avoid false positives at low speeds.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.45</b>	<b>4678</b>	<b>Phloss mov code</b>				0	0	0	W	EXP	FVSY

The hexadecimal value indicates which engine steps have been disconnected.

- 0x001 Phase U disconnected
- 0x002 Phase V disconnected
- 0x004 Phase W disconnected
- 0x003 Phase U and V disconnected
- 0x005 Phase U and W disconnected
- 0x006 Phase V and W disconnected
- 0x007 Phase U, V, W disconnected

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.46</b>	<b>4670</b>	<b>Optionbus activity</b>		ENUM		Disable			RW	EXP	FVSY

Setting of the behaviour of the drive in case of an **Opt Bus Fault [17]** alarm.

- 0** Ignore
- 1** Warning
- 2** Disable drive
- 3** Stop
- 4** Fast stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.47</b>	<b>4660</b>	<b>PhLoss in activity</b>		ENUM		Disable			RW	EXP	FVSY

Setting of the behaviour of the drive in case of a **Phaseloss in [16]** alarm. This alarm indicates the absence of a drive power supply phase

- 0** Ignore
- 1** Warning
- 2** Disable drive

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.48</b>	<b>4662</b>	<b>PhLoss in restart</b>		ENUM		Disable			RW	EXP	FVSY

Enabling of automatic restart after the **Phaseloss in [16]** alarm.

- 0** Disable
- 1** Enable

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.49</b>	<b>4664</b>	<b>PhLoss in rest time</b>	ms	UINT16		1000	120	10000	RW	EXP	FVSY

Setting of the time within which the **Phaseloss in [16]** alarm must be reset in order to perform automatic restart. (Time with alarm signal active + 100 msec).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.50</b>	<b>4668</b>	<b>PhLoss output test</b>		ENUM		Enable			RW	EXP	FVSY

Enabling of the output phase loss test.

- 0** Disabled

- 1 Enable  
2 Powerup

If set to **0** the test is disable

If set to **1** the drive verifies the presence of all the output phases each time it receives the enable command.

If set to **2** the drive only verifies the presence of all the output phases the first time the enable command is sent after powering

**Note!** The motor brake must be closed while running this test!

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.51	4680	GroundFault thr	perc	FLOAT	10.0	0.0	150.0	RW	INT	FVSY	

Setting of the threshold for the ground short circuit alarm **Ground fault [3]**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.52	4700	Alarm dig out 1 sel		ENUM		No alarm			RW	INT	FVSY
4.4.53	4702	Alarm dig out 2 sel		ENUM		No alarm			RW	INT	FVSY
4.4.54	4704	Alarm dig out 3 sel		ENUM		No alarm			RW	INT	FVSY
4.4.55	4706	Alarm dig out 4 sel		ENUM		No alarm			RW	INT	FVSY

Setting of the alarm signal to enable on a digital output. The digital output is selected using parameters **Alarm dig out 1 sel...4**, which can be enabled in the L\_DIGSEL1 selection list.

- 0 No alarm
- 1 Overvoltage
- 2 Undervoltage
- 3 Ground fault
- 4 Overcurrent
- 5 Desaturation
- 6 MultiUndervolt
- 7 MultiOvercurr
- 8 MultiDesat
- 9 Heatsink OT
- 10 HeatsinkS OTUT
- 11 Ptc failure
- 12 Motor OT
- 13 Drive overload
- 14 Motor overload
- 15 Bres overload
- 16 Phaseloss in
- 17 Opt Bus fault
- 18 Opt 1 IO fault
- 19 Precharge faul
- 20 Opt enc fault
- 21 External fault
- 22 Speed fbk loss
- 23 Overspeed
- 24 Speed ref loss
- 25 Emg stop alarm
- 26 Power down
- 27 Phaseloss out
- 28 OV safety
- 29 Safety failure
- 30 Phaseloss mov
- 31 Ropes change
- 32 Enable missing
- 33 Plc1 fault
- 34 Plc2 fault
- 35 Plc3 fault
- 36 Plc4 fault
- 37 Plc5 fault
- 38 Plc6 fault
- 39 Plc7 fault
- 40 Plc8 fault
- 41 Plc9 fault
- 42 Plc10 fault

- 43** Plc11 fault
- 44** Plc12 fault
- 45** Plc13 fault
- 46** Plc14 fault
- 47** Plc15 fault
- 48** Plc16 fault

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.56</b>	<b>4720</b>	<b>Alm autoreset time</b>	s	FLOAT		0.0	0.0	60.0	RW	EXP	FVSY

Setting of the time interval that must pass before executing an automatic reset.

If no alarms are enabled the drive is set to restart.

If some alarms are still enabled the drive is set to execute a new attempt at automatic reset.

At each attempted reset a counter increases. If the limit set in the parameter **Alm autoreset number** (PAR 4722) is reached the drive is set to make no more attempts at reset and waits for a user reset.

The counter is set to zero when an automatic reset or user reset is performed and no alarms are enabled.

If the parameter is 0 the function is disabled.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>4.4.57</b>	<b>4722</b>	<b>Alm autoreset number</b>		UINT16		3	0	100	RW	EXP	FVSY

Setting of the maximum number of attempted automatic resets.

## 4.8 DIGITAL INPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.1	1240	Dig inp 1 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.2	1242	Dig inp 2 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.3	1244	Dig inp 3 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.4	1246	Dig inp 4 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.5	1248	Dig inp 5 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.6	1250	Dig inp 6 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.7	1252	Dig inp 7 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.8	1254	Dig inp 8 inversion		BIT		0	0	1	RW	INT	FVSY

Inversion of the logic status of the function associated with the digital input.

0 Off  
1 On

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.9	1260	Dig inp 1x inversion		BIT		0	0	1	RW	INT	
4.8.10	1262	Dig inp 2x inversion		BIT		0	0	1	RW	INT	
4.8.11	1264	Dig inp 3x inversion		BIT		0	0	1	RW	INT	
4.8.12	1266	Dig inp 4x inversion		BIT		0	0	1	RW	INT	

Inversion of the logic status of the function associated with the digital input of the EXP-IO1-ADL500 expansion card.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.13	1110	Dig input E mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY

These signals represent the state of the corresponding Enable digital input.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.14	1210	Dig input 1 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.15	1212	Dig input 2 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.16	1214	Dig input 3 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.17	1216	Dig input 4 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.18	1218	Dig input 5 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.19	1220	Dig input 6 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.20	1222	Dig input 7 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.21	1224	Dig input 8 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY

These signals represent the logic state of the corresponding digital input.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.22	1230	Dig input 1x mon		UINT16	16BIT_L	0	0	0	R	EXP	
4.8.23	1232	Dig input 2x mon		UINT16	16BIT_L	0	0	0	R	EXP	
4.8.24	1234	Dig input 3x mon		UINT16	16BIT_L	0	0	0	R	EXP	
4.8.25	1236	Dig input 4x mon		UINT16	16BIT_L	0	0	0	R	EXP	

These signals represent the logic state of the corresponding digital input on the EXP-IO1-ADL500 expansion card.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.26	1268	Dig input E dest		ILINK		0	0	0	R	EXP	FVSY
4.8.27	1270	Dig input 1 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.28	1272	Dig input 2 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.29	1274	Dig input 3 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.30	1276	Dig input 4 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.31	1278	Dig input 5 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.32	1280	Dig input 6 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.33	1282	Dig input 7 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.34	1284	Dig input 8 dest		ILINK		0	0	0	R	EXP	FVSY

Selection of the destination of the associated digital input.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.35	1290	Dig input 1x dest		ILINK		0	0	0	R	EXP	
4.8.36	1292	Dig input 2x dest		ILINK		0	0	0	R	EXP	
4.8.37	1294	Dig input 3x dest		ILINK		0	0	0	R	EXP	
4.8.38	1296	Dig input 4x dest		ILINK		0	0	0	R	EXP	

Selection of the destination of the digital input of the associated EXP-IO1-ADL500 expansion card.

## 4.9 DIGITAL OUTPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.9.1	1430	Dig out 1 inversion		BIT		0	0	1	RW	INT	FVSY
4.9.2	1432	Dig out 2 inversion		BIT		0	0	1	RW	INT	FVSY
4.9.3	1434	Dig out 3 inversion		BIT		0	0	1	RW	INT	FVSY
4.9.4	1436	Dig out 4 inversion		BIT		0	0	1	RW	INT	FVSY

Inversion of the logic status of the function associated with the digital output.

- 0** Off
- 1** On

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.9.5	1440	Dig out 1x inversion		BIT		0	0	1	RW	INT	
4.9.6	1442	Dig out 2x inversion		BIT		0	0	1	RW	INT	

Inversion of the logic status of the function associated with the digital output of the EXP-IO1-ADL500 expansion card.

- 0** Off
- 1** On

## 4.10 ANALOG INPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.1	1600	Analog input mon	cnt	INT16	16BIT_H	0	0	0	R	ESY	FVSY

The value of the voltage of the analog input is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.2	1602	Analog inp type		ENUM		-10V..+10V			RW	INT	FVSY

Selection of the type of input (voltage or current). Depending on the input signal, move the switches on the regulation card. The factory parameter is inputs set for differential voltage signals ( $\pm 10V$ ).

- 0** -10V..+10V
- 1** 0.20mA , 0.10V
- 2** 4..20mA


Select option **0** in order to connect a maximum voltage of  $\pm 12.5V$  (typically  $\pm 10V/5mA$ ) to the analog input. If the signal is used as a reference, reverse the direction of rotation by inverting the voltage polarity.

Select option **1** to connect a max voltage of  $12.5V$  (typically  $10V/5mA$ ) or a signal in current from  $0 \dots 20$  mA to the analog input. The signal must be positive.

Select option **2** to connect a current signal of  $4\dots20$  mA to the analog input. The signal must be positive.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.3	1604	Analog inp scale		FLOAT		1.0	-10.0	10.0	RW	INT	FVSY

Setting of a multiplier factor to be applied to the analog input.



**Example:**

The speed reference of a drive is assigned with a max external voltage of 5V. With this value the drive must reach the maximum speed allowed (set using PAR 680 **Full scale speed**).

As the **Analog inp scale** parameter the scale factor of 2 is entered (10V : 5V).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.4	1606	<b>An inp offset tune</b>		BIT		0	0	1	RW	INT	FVSY
Self-tuning command for the offset of the analog input. Automatic fine tuning of the input. To perform self-tuning, set the input signal to its minimum value and execute the command. The conditions containing an offset can be compensated. When this command is sent, PAR 1606 <b>An inp offset tune</b> is automatically selected so that the available input signal corresponds to the zero value of the variable.											

Automatic tuning can only be performed if the following condition is present:

- Input voltage less than 1V or input current less than 2 mA.

**Note!**

The value that is obtained automatically can be changed manually, if necessary, using **Offset ing an**.

If the voltage setting on the analog input is more than 1V the “**Input value too high**” message is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.5	1608	<b>An inp gain tune</b>		BIT		0	0	1	RW	INT	FVSY
Self-tuning command for the analog input gain. Automatic fine tuning of the input. When this command is sent, <b>An inp gain tune</b> is automatically selected so that the available input signal corresponds to the maximum value of the variable. Two conditions are necessary in order to perform automatic tuning:											

- Input voltage greater than 1V or input current greater than 2 mA
- Positive polarity. The value that is found is automatically accepted for the other direction of rotation.

**Note!**

If necessary, the value obtained automatically can be changed manually via **An inp gain tune**.

To perform self-tuning, set the input signal to its maximum value and execute the command. A multiplier factor is calculated to apply to the input signal value (not considering the **An inp gain tune** parameter) to reach the full scale value.

If the voltage setting on the analog input is less than 1V the “**Input value too low**” message is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.6	1610	<b>Analog inp filter</b>	ms	FLOAT		10	2	100	RW	EXP	FVSY
Filter on the measurement of the analog input. This parameter can be used to control the response of the analog input and reduce any possible noise and interference.											


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.7	1612	<b>Analog inp top</b>	cnt	INT16		16384	-32768	+32767	RW	EXP	FVSY
Setting of the upper speed reference limit as a function of the voltage (or current) of the analog reference.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.8	1614	Analog inp bottom	cnt	INT16		-16384	-32768	+32767	RW	EXP	FVSY

Setting of the lower speed reference limit as a function of the voltage (or current) of the analog reference.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.9	1616	Analog inp offset	cnt	INT16		0	-32768	+32767	RW	EXP	FVSY

Setting of an offset value to algebraically add to the analog input.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.10	1618	Analog inp gain		FLOAT		1.0	-10.0	10.0	RW	EXP	FVSY

This parameter contains the value of the multiplier factor to apply to the analog reference calculated using the **Analog inp gain tune** function.

Example :

An external analog reference only reaches a maximum of 9.8V instead of 10V. 1.020 (10V : 9.8V) is entered as the **An inp gain tune** (PAR 1608) parameter.

This parameter can be selected from the keypad menu. The maximum analog value available (in this case 9.8V) must be present on the terminal, with positive polarity. Press the **Enter** key on the keypad to start analog reference self-tuning.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.11	1626	An inp sign src		LINK	16BIT_L	6000			RW	INT	FVSY

Selection of the origin (source) of the signal to be assigned to the analog input for selecting the direction of rotation of the motor. The functions that can be associated with the outputs are listed in the “**L\_DIGSEL2**” selection list”.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.12	1632	Analog input dest		ILINK		0	0	0	R	EXP	FVSY

The function for which the analog input has been programmed and on which it acts is displayed.


## 4.11 ALARM LOG

This is the menu in which the log of previous alarms is saved, with the time the alarm occurred (in relation to the PAR 510 **Time drive power on** parameter). The alarms are displayed starting from the most recent (No. 1) up to the furthest back in time (No. 30).

Up to 30 alarm signals can be displayed.

The sub-code is used to identify the specific type of alarm.

Press the ▲ and ▼ keys to scroll the screen pages of the alarm log. The alarm log cannot be deleted.



## 4.12 LIFE TIME

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.12.1	510	Time drive power on	h:min	UINT32		0	0	0	R	ESY	FVSY

The total time for which the drive has been powered is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.12.2	512	Time drive enable	h:min	UINT32		0	0	0	R	ESY	FVSY

The time for which the drive has been enabled is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.12.3	514	Number power up		UINT16		0	0	0	R	ESY	FVSY

The number of times the drive has been powered on is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.12.4	516	Time fan on	h:min	UINT32		0	0	0	R	ESY	FVSY

The total time for which the drive fan has been running is displayed.

## 5 LIFT

### 5.1 LIFT MONITOR

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.1	14014	Trip number		UINT32			-	-	R	ESY	FVY

Displays the lift trip counter, which is incremented, when the Start lift signal is active, each time a start is signalled.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.2	14016	Sequence state		ENUM					R	ESY	FVY

View the logical state the drive is in.

The sequence of states where the drive can be found is listed below:

- 0 Idle
- 1 Cont close
- 2 Drive ready
- 3 Brake open
- 4 Smooth start
- 5 Multispeed
- 6 Waiting 0 spd
- 7 Zero speed
- 8 Brake close
- 9 Cont open
- 10 Not drive ok
- 91 SC cont mon


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.3	14030	Acceleration state	m	FLOAT			-	-	R	ESY	FVY

Displays the space required to accelerate from zero to the selected speed, considering the space due to the initial and final jerk. This does not include the space travelled at a constant speed due to activation of the soft start function.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.4	14032	Deceleration space	m	FLOAT			-	-	R	ESY	FVY

The distance necessary to stop from the high speed is displayed.

Different methods are used to calculate this distance, depending on the value of the relative parameters:




- **Case 1:** S-shaped ramp from high speed to zero speed

**Distance multispeed0** (PAR 11102) = 0, **Enable landing src** (PAR 11130) = Disabled, **Slow speed** (PAR 11120) = Zero.

**Deceleration space** (PAR 14032) the distance covered during the stop ramp from **PAR 11142 Calc space HiSpd sel = (1) Multispeed 1** (high speed) to zero speed.

The parameters that influence the calculation of this distance are: **Calc space HiSpd sel** (PAR 11142), **Percent dec factor** (PAR 11056), **Dec ini jerk** (PAR 11046), **Deceleration** (PAR 11048) and **Dec end jerk** (PAR 11050).




- **Case 2:** S-shaped ramp from high to low speed, low speed zone and subsequent stop

**Distance multispeed0** (PAR 11102) = 0, **Enable landing src** (PAR 11130) = Disabled, **Slow speed** (PAR 11120) = Multispeed 0.

**Deceleration space** (PAR 14032) is the distance covered during the slow down ramp from PAR 11142 **Calc space HiSpd sel = (1) Multispeed 1** (high speed) to PAR 11120 **Slow speed** and during the stop ramp from PAR 11120 **Slow speed** to zero speed.

If the sensors are positioned at a distance from the arrival floor greater than the distance indicated by PAR 14032 then a travel with low speed movement occurs with the value set in PAR 11120.

The parameters that influence the calculation of this distance are: **Calc space HiSpd sel** (PAR 11142), **Multispeed 0** (PAR 11120), **Percent dec factor** (PAR 11056), **Dec ini jerk** (PAR 11046), **Deceleration** (PAR 11048), **Dec end jerk** (PAR 11050) and **Stop deceleration** (PAR 11052).




- **Case 3:** S-shaped ramp from high to low speed, low speed zone and subsequent stop

**Distance multispeed0** (PAR 11102) ≠ 0 (es.0.5m), **Enable landing src** (PAR 11130) = Disabled, **Slow speed** (PAR 11120) = Multispeed 0.

**Deceleration space** (PAR 14032) is the distance covered during the slow down ramp from PAR 11142 **Calc space HiSpd sel = (1) Multispeed 1** to PAR 11120 **Slow speed** and during the stop ramp from PAR 11120 **Slow speed** to zero speed.

The parameters that influence the calculation of this distance are: **Calc space HiSpd sel** (PAR 11142), **Multispeed 0** (11020), **Percent dec factor** (PAR 11056), **Dec ini jerk** (PAR 11046), **Deceleration** (PAR 11048) and **Dec end jerk** (PAR 11050) and **Stop deceleration** (PAR 11052).



- **Case 4:** S-shaped ramp from high to low speed, low speed zone and subsequent stop with "landing control"

**Distance multispeed0** (PAR 11102) ≠ 0 (es.0.5m), **Enable landing src** (PAR 11130) = Enabled, **Slow speed** (PAR 11120) = Multispeed 0.

**Deceleration space** (PAR 14032) is the distance covered during the slow down ramp from **CPAR 11142 Calc space HiSpd sel = (1) Multispeed 1** (high speed) to PAR 11120 **Slow speed** plus **Landing zone dist** (PAR 11132).

The parameters that influence the calculation of this distance are: **Calc space HiSpd sel** (PAR 11142), **Multispeed 0** (PAR 11020), **Percent dec factor** (PAR 11056), **Dec ini jerk** (PAR 11046), **Deceleration** (PAR 11048) and **Dec end jerk** (PAR 11050).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.5	14034	Landing zone space	m	FLOAT			-	-	R	ESY	FVY

Displays the space required to reach the landing zone calculated from the deceleration and low speed values

(not multiplied by the percentage factor PAR 11056 **Percent dec factor**).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.6	14210	Actual speed ref	m/s	FLOAT			-	-	R	ESY	FVY

Displays the speed reference set in m/s.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.7	14242	Actual cabin spd	m/s	FLOAT			-	-	R	ESY	FVY

Displays the cabin speed in m/s. This speed value tends to follow the current speed reference.


## 5.2 MECHANICAL DATA

The parameters described in this menu are used to define the mechanical and physical features of the system.

### Mechanical constants

The mechanical constant defines the ratio between motor rpm and distance travelled by the cabin.

**Mechanical constant** =  $(\pi * \text{Pulley diameter}) / \text{Reduction ratio}$



The mechanical constant is calculated when the drive is turned on and re-calculated each time one of the parameters used to determine this value is modified (**Cabin speed**, **Pulley diameter**, **Gearbox ratio**).

The rewriting of the mechanical constant determines the recalculation of the full scale speed (PAR 680), which is set using the motor revs required to reach the maximum system speed through the mechanical ratios set.

### Weights and inertia

Entering the mechanical features of the system makes it possible to calculate the total inertia applied to the motor.

The calculated inertia value, is automatically written to the parameter (PAR 2240); this operation allows the basic speed loop gains to be recalculated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.2.1	11002	Travel unit sel		ENUM		Hz (m/s)	-	-	RWZ	INT	FVY

Selection of the unit of measure for speed references.

- 0 Hz (output frequency)
- 1 m/s (cabin speed and depends on the mechanical constant)
- 2 rpm (speed of the motor shaft)

When the unit of measure is modified the conversion constants are re-calculated, the units of measure are changed in the parameter list and the multispeed values are converted into the new unit of measure (the result may contain

approximations due to the conversion calculations). A variable representing the speed of the cabin in m/s (fpm) is always available (PAR 14242). There are fixed units of measure for the acceleration and deceleration parameters m/s<sup>2</sup>, and for jerks m/s<sup>3</sup>.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.2.2</b>	<b>11006</b>	<b>Cabin speed</b>	m/s	FLOAT		1	0	10	RWZ	INT	FVY
Sets the maximum speed of system operation. This is also used for the recalculation of the full scale speed (PAR 680).											
<b>5.2.3</b>	<b>11010</b>	<b>Gearbox ratio</b>		FLOAT		45 (1)	1	200	RW	INT	FVY
Sets the reduction ratio between motor and pulley.											
<b>5.2.4</b>	<b>11164</b>	<b>Rope ratio</b>		FLOAT		1 (2)	1	10	RWZ	INT	FVY
Sets the reduction ratio due to rope windings.											
<b>5.2.5</b>	<b>11012</b>	<b>Pulley diameter</b>	m	FLOAT		0.6 (0.32)	0	5	RWZ	INT	FVY
Setting of the diameter of the pulley.											
<b>5.2.6</b>	<b>11150</b>	<b>Car weight</b>	kg	FLOAT		400	0	10000	RW	INT	FVY
Setting of the weight of the cabin (intended as the total empty weight of everything hanging from the ropes: frame, walls, door operator, appliances, etc.).											
<b>5.2.7</b>	<b>11152</b>	<b>Counter weight</b>	kg	FLOAT		1000	0	10000	RW	INT	FVY
Setting of the weight of the counterweight, including its frame.											
<b>5.2.8</b>	<b>11154</b>	<b>Load weight</b>	kg	FLOAT		450	0	10000	RW	INT	FVY
Setting of the weight of the maximum load for system dimensions.											
<b>5.2.9</b>	<b>11156</b>	<b>Rope weight</b>	kg	FLOAT		20	0	1000	RW	INT	FVY
Setting of the weight of the cable (intended as the total weight of all car suspension ropes).											

## 5.3 SPEED



Attention

### Multi speed configuration table

Through the combination of “MtlSpd S0” (Digital input 4), “MtlSpd S1” (Digital input 5) and “MtlSpd S2” (Digital input 6) commands, is possible to select Multi speed desired, according to next table:

MtlSpd S2	MtlSpd S1	MtlSpd S0	ACTIVE SPEED
0	0	0	Multi speed 0, PAR 11020
0	0	1	Multi speed 1, PAR 11022
0	1	0	Multi speed 2, PAR 11024
0	1	1	Multi speed 3, PAR 11026
1	0	0	Multi speed 4, PAR 11028
1	0	1	Multi speed 5, PAR 11030
1	1	0	Multi speed 6, PAR 11032
1	1	1	Multi speed 7, PAR 11034

**Note!** The Multi-speed unit of measure is set with PAR 11002 Travel units sel.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.1	11020	Multi speed 0		FLOAT		5 (0.1)	0	10000	RW	ESY	FVY

Setting of the multispeed 0 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

This setting is taken as the default low speed value.

If the **Multi speed 0** value is changed, it will only be acquired when the drive is rebooted.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.2	11022	Multi speed 1		FLOAT		47.73 (1.0)	0	10000	RW	ESY	FVY

Setting of the multispeed 1 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

This setting is taken as the default high speed value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.3	11024	Multi speed 2		FLOAT		20 (0.4)	0	10000	RW	ESY	FVY

Setting of the multispeed 2 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

This setting is taken as the default maintenance speed value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.4	11026	Multi speed 3		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 3 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.5	11028	Multi speed 4		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 4 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.6	11030	Multi speed 5		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 5 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.7	11032	Multi speed 6		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 6 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.8	11034	Multi speed 7		FLOAT		0	0	10000	RW	ESY	FVY

Setting of the multispeed 7 value. Can be selected via digital input, fieldbus, etc.

The selected value is the reference for the S-shaped lift ramp.


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.10	14010	Actual multi spd sel		ENUM					R	ESY	FVY

The currently selected speed is displayed.

- 0 Multispeed 0
- 1 Multispeed 1
- 2 Multispeed 2
- 3 Multispeed 3
- 4 Multispeed 4
- 5 Multispeed 5
- 6 Multispeed 6
- 7 Multispeed 7
- 8 Null

## 5.4 RAMPS

The lift application envisages an S-shaped ramp function with the possibility of setting 4 independent jerks and linear acceleration and deceleration factors, as in the standard profile illustrated in the figure below.



The PAR 11040 **Accel initial jerk**, PAR 11042 **Acceleration** and PAR 11044 **Accel end jerk** values used to execute the acceleration ramp are calculated by multiplying the corresponding parameters by the acceleration ramp factor (**Percent acc factor**), while the PAR 11046 **Decel initial jerk**, PAR 11048 **Deceleration** and PAR 11050 **Decel end jerk** values used to execute the deceleration ramp are calculated by multiplying the corresponding parameters by the deceleration ramp factor (**Percent dec factor**, PAR 11056).

When the **Start** command is removed, the reference speed is zero regardless of the reference selected in the multispeeds. In this final part of the profile the jerk deceleration values are used directly (not multiplied by **Percent dec factor**, PAR 11056) with the **Stop deceleration** parameter as the linear deceleration. The factors for the final section of the profile are also used in case of a Stop lift emergency condition.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.1	11040	Accel initial jerk	m/s <sup>3</sup>	FLOAT		0.2	0.001	20	RW	ESY	FVY

Setting of the jerk value for the first part of the acceleration.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.2	11042	Acceleration	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY

Setting of the maximum acceleration value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.3	11044	Accel end jerk	m/s <sup>3</sup>	FLOAT		0.6	0.001	20	RW	ESY	FVY

Setting of the jerk value for the last part of the acceleration.

Menu	PAR	Description	UM	Tipo	FB BIT	Def	Min	Max	Acc	Liv.	Vis.
5.4.4	11054	Percent acc factor	%	FLOAT		100	10	1000	RW	INT	FVY

Setting of the acceleration factor multiplier.

If set to 100 the ramp uses the factors entered in the parameters.

If set to a value of less than 100 the lift will tend to accelerate over a longer distance.

If set to a value of more than 100 the lift will tend to accelerate over a shorter distance.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.5	11046	Decel initial jerk	m/s <sup>3</sup>	FLOAT		0.6	0.001	20	RW	ESY	FVY

Setting of the jerk value for the first part of the deceleration.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.6	11048	Deceleration	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY

Setting of the maximum deceleration value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.7	11050	Decel end jerk	m/s <sup>3</sup>	FLOAT		0.500	0.001	20	RW	ESY	FVY

Setting of the jerk value for the last part of the deceleration.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.8	11056	<b>Percent dec factor</b>	%	FLOAT		100	10	1000	RW	INT	FVY

Setting of the deceleration factor multiplier.

If set to 100 the ramp uses the factors entered in the parameters.

If set to a value of less than 100 the lift will tend to decelerate over a longer distance.


If set to a value of more than 100 the lift will tend to decelerate over a shorter distance.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.9	11052	<b>Stop deceleration</b>	m/s <sup>2</sup>	FLOAT		0.600	0.001	10.000	RW	ESY	FVY

Setting of the maximum deceleration value used when the start command is removed.

## 5.5 LIFT SEQUENCES

This menu shows the parameters used to manage and define the travel of the lift depending on the status of the inputs and alarms. The structure of the lift sequences is summarised below.



### Starting sequence:

- 1 Reading of the enable hardware input and checking for alarms (enabling is aborted in case of an alarm).
- 2 Detection of the **Enable** and **Start** commands as set in the **Sequence start stop** parameter.
- 3 When the **Start forward/reverse** command is received, a command is sent to close the contactors, depending on the direction of travel.
- 4 When the time set in **Contactor close dly** has elapsed the internal **Enable** lift signal is activated.
- 5 The system waits for the magnetisation signal from the drive (**Drive ready**).
- 6 At the end of magnetisation the open brake signal is activated.
- 7 The system waits for the brake to be opened (**Brake open delay**).
- 8 When the delay before opening the brake has elapsed the **Start** lift command is sent and movement is enabled.

#### **Sequence of movement:**

- 1 The motor is started and moves slowly at the speed set in Smooth start speed for the time indicated in **Smooth start delay** (PAR 11066).
- 2 At the end of **Smooth start time** (PAR 11066), movements are managed by the multispeeds and S-shaped ramp
- 3 When the set speed is exceeded, the **Brake mon** (PAR 3712) output signal can be used to check that the brake has actually been opened.
- 4 The EFC function with space control can be used to change to a slower speed.
- 5 When the **Start forward/reverse** signal is lowered the signal indicating arrival at the floor is enabled and the start lift signal is disabled.
- 6 The start command can be sent again until the drive reaches zero speed: the operating conditions are restored.

#### **Stopping sequence:**

- 1 When zero speed is reached the DC stop command is enabled (**ASY SSC** control).
- 2 The application waits the time needed to reach zero speed and sends the command to close brakes 1 and 2.
- 3 It waits the time necessary for the brakes to close ((**Brake close delay**, PAR 11068) and, if the current is to be reduced with a ramp, it waits for the current limit to reach zero. The internal **Enable lift**, arrival zone and DC brake signals are then lowered.
- 4 The application waits the time set in **Contactor open dly** (PAR 11072) and checks that the current supplied is zero, before sending a command to open the contactors.

It is essential to make sure that whenever a drive alarm condition is generated or the drive is disabled, the drive is stopped and a command is sent to open the contactors.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.1	<b>11060 Sequence start stop</b>			ENUM		Start fwd/rev	-	-	RWZ	ESY	FVY

Setting the PAR 3702 **Run cont mon** command activation mode.

- 0 Start fwd/rev
- 1 Enable
- 2 Mltspd out !=0

When set to 0, output command PAR 3702 **Run cont mon** is activated, giving as input only signal PAR 11222 **Start fwd cmd src** or PAR 11224 **Start rev cmd src**.

When set to 1, output command PAR 3702 **Run cont mon** is activated, giving as input both the enable signal and signal PAR 11222 **Start fwd cmd src** or PAR 11224 **Start rev cmd src**.

When set to 2, output command PAR 3702 **Run cont mon** is activated, giving as input signal PAR 11222 **Start fwd cmd src** or PAR 11224 **Start rev cmd src** and selecting a speed other than zero using the multi-speed selectors.

#### **Note!**

The sequence of operation is the same whether you use a traditional brake or the EBC device.


#### **Note!**

If EBC is used, in the absence of CAN communication between EBC and ADL, if the lack of communication occurs before you exceed the maximum time of the brake open delay then the drive stops in EBC alarm failure if instead the lack of communication CAN occurs after this time the drive tries to carry on the whole sequence until the stop sequence where, The Run Contactor command is also removed at the brake closing command and the EBC failure alarm is activated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.2	11084	Smooth start mode		ENUM		Variable jerk	-	-	RWZ	INT	FVY

Setting of the soft start mode.

- 1 Speed constant
- 2 Jerk variable



If set to 1 the soft speed is automatically selected after the start command regardless of the selected multispeed. This setting is used in systems with a reducer, as it helps to overcome initial friction before starting with the profile.

If set to 2 it uses a variable value jerk and obtains a variable start acceleration that follows a parabolic trajectory, enabling extremely reduced variations in initial speed. This setting is mainly used in systems with gearless motors.

The Smooth speed duration is dependent on parameter PAR 11066 **Smooth start time**: if this parameter is set to zero, the selected multi-speed is used and not the "Smooth" speed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.3	11082	Smooth start speed		FLOAT	0	0	0	10000	RW	INT	FVY

Setting of the speed in the smooth start phase.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.4	11066	Smooth start time	ms	INT16/32		0	0	10000	RW	INT	FVY

Setting of the time for which the **Smooth start speed** (PAR 11082) is enabled. If this parameter is set to zero, the S-shaped profile is executed directly at the start, and the soft start function is excluded.

Menu	PAR	Description	UM	Tipo	FB BIT	Def	Min	Max	Acc	Liv.	Vis.
5.5.5	11062	Contactor close dly	ms	INT16/32		200	0	10000	RW	ESY	FVY

Setting of the delay time after closing the contactor.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.6	11064	Brake open delay	ms	INT16/32		500	0	10000	RW	ESY	FVY

Setting of delay time after opening the brake.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.7	11078	Speed 0 threshold	rpm	INT16		30 (1)	0	10000	RW	INT	FVY

Setting of the zero speed threshold, below which the zero speed signal is activated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.8	11080	Speed 0 delay	ms	UINT16		400	0	10000	RW	INT	FVY

Setting of the zero speed delay. After the zero speed signal and after the time set in this parameter the zero speed signal is activated. These parameters are used to know the cabin stop.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.9	11086	Door open speed	m/s	FLOAT		0	-10000	10000	RWZ	EXP	FVY

Setting of the door opening speed.

Source to enable brake release through the digital input. In standard sequence brake release is controlled

by the drive and therefore this parameter is set to ONE. In case that brake release should be conditioned


by some external control (e.g. PLC), set this parameter to digital input controlled by PLC.

Internal sequence for brake release will wait until this input is asserted.

During run brake will be closed whenever this input becomes not asserted.

**Note!**

Under no circumstances can the drive bypass the safeties. This task is delegated to special safety modules external to the drive.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.10	11070	Current down delay	ms	INT16/32		0 (800)	0	10000	RW	INT	Y

The purpose of this function is to avoid that after the brake is closed, the motor torque is removed instantaneously, causing bothersome stress inside the cabin.

To avoid this phenomenon, after closing the brake, the current limits are brought from the active value during travel to zero in the time set here.

**Note!**

Function not active in asynchronous motor control mode.

In synchronous motor control mode the application automatically sets the parameter PAR 2354 **Torque curr lim** sel to "T limit src" and PAR 2358 **Torque limit src** to "Ramp down limit".

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.11	11068	Brake close delay	ms	INT16/32		500	0	10000	RW	ESY	FVY

Setting of the delay time after closing the brake.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.12	11072	Contactor open dly	ms	INT16/32		200	0	10.000	RW	ESY	FVY

Setting of the contactor opening delay time.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.13	11074	SC cont open delay	ms	INT16/32		0 (500)	0	2000	RW	EXP	Y

Setting of the delay for the opening of the short-circuit contactor between the motor phases.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.14	11826	Inspection behaviour		ENUM		None	-	-	RWZ	EXP	FVY

0 None

1 Fast Stop

2 Immediate

Manages the stop ramp in maintenance/inspection mode. If enabled, the function allows greater deceleration compared to nominal deceleration.

Setting 0: function disabled (default). The car stops with the normal ramps inserted.

Setting 1: the 200 ms stop function is enabled if the set maintenance speed (PAR 11828 **Inspection spd sel**) is below 0.63 m/s. If the set speed is higher it is automatically limited to 0.63 m/s.

Setting 3: the car stops immediately (with no ramp and with closing the brake) when the button on the maintenance button panel is released.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.15	11828	Inspection spd sel		ENUM		Multispeed 2	-	-	RWZ	INT	FVY

Maintenance speed value.

0 Multispeed 0

1 Multispeed 1

2 Multispeed 2

- 3** Multispeed 3
- 4** Multispeed 4
- 5** Multispeed 5
- 6** Multispeed 6
- 7** Multispeed 7
- 8** Null

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.5.16</b>	<b>11244</b>	<b>Inversion motor rot</b>		ENUM		Not inverted	-	-	RWZ	INT	FVY
---------------	--------------	----------------------------	--	------	--	--------------	---	---	-----	-----	-----

Reversal of the motor rotation direction.

**0** Not inverted

**1** Inverted

Setting **0** does not reverse the direction of rotation.

Setting **1** reverses the direction of rotation.

International standards require that a positive reference corresponds to the motor rotating in a clockwise direction as seen from the drive side (shaft).

For correct operation, the control algorithms provide that a positive speed reference corresponds to a positive speed measurement.

## 5.6 LIFT OUT

### Outputs

The lift control output signals are directly accessible from the selection lists used to configure the drive relay outputs, according to the following table:

PAR	Description
3700	Lift enable
3702	Run cont mon
3704	Up cont mon
3706	Down cont mon
3708	Brake cont mon
3710	Lift dc brake
3712	Brake mon
3714	Door open mon
3716	Lift start
3718	Safe Brake Test
3720	Lift statusWord
3722	Brake mon
3724	SC Cont mon
3726	Ramp down limit
3728	EBC Ok
3730	Lift wdec input

The set of lift output signals composes the "Lift statusWord"; below is the meaning of each single bit. This word is then indicated in parameter PAR 3720 **Lift statusWord** and in **DW1 fieldbus Tx**.

Bit	Description	Notes
0	<b>LiftEnable</b>	Enable lift command.
1	<b>RunCont</b>	Run command contactor
2	<b>UpCont</b>	Up command contactor
3	<b>DownCont</b>	Down command contactor
4	<b>BrakeCont</b>	Brake command contactor
5	<b>LiftDcBrake</b>	DC brake function command
6	<b>Brake2</b>	Brake control signal
7	<b>DoorOpen</b>	Open door command
8	<b>Drive Ok</b>	Drive not in alarm condition signal
9	<b>SpeedIsZero</b>	Speed less than 0 limit signal
10	<b>SpeedRefIsZero</b>	Speed reference less than 0 limit signal
11 ... 12		

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.6.1	1410	Dig output 1 src		LINK	16BIT_L	6000			RW	INT	
5.6.2	1412	Dig output 2 src		LINK	16BIT_L	6000			RW	INT	
5.6.3	1414	Dig output 3 src		LINK	16BIT_L	6000			RW	INT	
5.6.4	1416	Dig output 4 src		LINK	16BIT_L	6000			RW	INT	

Selection of the origin (source) of the destination associated with the digital output. The functions that can be associated with the digital outputs are listed in the “**L\_DIGSEL1**” selection list”.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.6.5	1420	Dig output 1x src		LINK	16BIT_L	6000			RW	INT	
5.6.6	1422	Dig output 1x src		LINK	16BIT_L	6000			RW	INT	

Selection of the origin (source) of the destination associated with the digital output of the expansion card. The functions that can be associated with the digital outputs are listed in the “**L\_DIGSEL1**” selection list”.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.6.7	11016	LiftEnable out delay		FLOAT	0	0	0	5	RW	EXP	FVY

Setting of the delay time of the enable lift output.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.6.8	14104	Command output mon	Hex			UINT32			R	ESY	FVY

Hexadecimal display of the status of outputs, see description “Lift status word” (table beginning section) for the meaning of individual bits.

## 5.7 LIFT IN

### Inputs

The lift application input commands can be connected to a signal via a selector in order to choose from a series of possibilities available in the input list.

Generally speaking a signal can be connected to a digital input, to certain internal signals and to a bit of the Decomp word bit. This word is connected to a fieldbus processing channel (**PDC FieldBus M->S1**).

The set of digital inputs in a word is displayed in the Lift control word.

The commands used in the lift application are listed below.

Bit	Command	Description	Default source
0	<b>EnableCmd</b>	Enable command	Dig input enable
1	<b>StartFwdCmd</b>	Start forward command	Dig input 1x
2	<b>StartRevCmd</b>	Start reverse command	Dig input 2x
3	<b>MltSpd S0</b>	Multispeed 0 sel	Dig input 4x
4	<b>MltSpd S1</b>	Multispeed 1 sel	Dig input 5x
5	<b>MltSpd S2</b>	Multispeed 2 sel	Dig input 6x
6	<b>ContFbk</b>	Contactor close contact	Run cont mon
7	<b>BrakeFbk</b>	Brake close contact	Brake cont mon
8	<b>DoorOpenEna</b>	Source for enabling the door open function	Null
9	<b>DoorFbk</b>	Door close contact	Null
10	<b>Emergency mode</b>	Emergency operation command	Dig input 3x
11	<b>InvRampSrc</b>	Command to invert the speed direction	Null
12	<b>UpperLimit</b>	Travel upper limit signal	Null
13	<b>LowerLimit</b>	Travel lower limit signal	Null
14	<b>Brake fbk A3</b>	Brake failure signal	Null
15	<b>Brake 2 fbk</b>	Second brake failure signal	Brake cont mon

### Multi speed configuration table

Multi speed S2 sel	Multi speed S1 sel	Multi speed S0 sel	ACTIVE RAMP REF
0	0	0	Multi speed 0
0	0	1	Multi speed 1
0	1	0	Multi speed 2
0	1	1	Multi speed 3
1	0	0	Multi speed 4
1	0	1	Multi speed 5
1	1	0	Multi speed 6
1	1	1	Multi speed 7

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

#### 5.7.1 11220 Lift enable cmd src

ENUM

Dig input E mon

-

RW INT FVY

Setting of the source for the enable command.

The list of functions that can be associated with the digital inputs are in the “**LiftInputAdICmd**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

#### 5.7.2 11222 Start fwd cmd src

ENUM

Dig input 1 mon

-

RW INT FVY

Setting of the source for the start forward command.

The list of functions that can be associated with the digital inputs are in the “**LiftInputAdICmd**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

#### 5.7.3 11224 Start rev cmd src

ENUM

Dig input 2 mon

-

RW INT FVY

Setting of the source for the start reverse command.

The list of functions that can be associated with the digital inputs are in the “**LiftInputAdICmd**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

#### 5.7.4 11256 Speed ref src

ENUM

Multispeed

-

RW INT FVY

Selection of the origin (source) of the signal to be used for the speed reference.

The signals that can be used are multispeed, analog inputs or fieldbus (except the PAR **4020 Fieldbus M->S1 ipa**).

By using the analogue input as the speed reference source, the entire speed profile from the cabin's start to its stop will be generated only by this input, bypassing the functions implemented here.

<b>640</b>	Multispeed
<b>1600</b>	Analog in 1
<b>4034</b>	Fieldbus M->S2
<b>4044</b>	Fieldbus M->S3
<b>4054</b>	Fieldbus M->S4
<b>4064</b>	Fieldbus M->S5
<b>4074</b>	Fieldbus M->S6
<b>4084</b>	Fieldbus M->S7
<b>4094</b>	Fieldbus M->S8
<b>4104</b>	Fieldbus M->S9
<b>4114</b>	Fieldbus M->S10
<b>4124</b>	Fieldbus M->S11
<b>4134</b>	Fieldbus M->S12
<b>4144</b>	Fieldbus M->S13
<b>4154</b>	Fieldbus M->S14
<b>4164</b>	Fieldbus M->S15
<b>4174</b>	Fieldbus M->S16

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.7.5</b>	<b>11226</b>	<b>Multi speed S0 src</b>		ENUM		Dig input 4 mon	-	-	RW	ESY	FVY
--------------	--------------	---------------------------	--	------	--	-----------------	---	---	----	-----	-----

Sets the source for the first bit for multi-speed selection.

The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.7.6</b>	<b>11228</b>	<b>Multi speed S1 src</b>		ENUM		Dig input 5 mon	-	-	RW	ESY	FVY
--------------	--------------	---------------------------	--	------	--	-----------------	---	---	----	-----	-----

Sets the source for the second bit for multi-speed selection.

The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.7.7</b>	<b>11230</b>	<b>Multi speed S2 src</b>		ENUM		Dig input 6 mon	-	-	RW	ESY	FVY
--------------	--------------	---------------------------	--	------	--	-----------------	---	---	----	-----	-----

Sets the source for the third bit for multi-speed selection.

The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.7.8</b>	<b>11232</b>	<b>Contactor fbk src</b>		ENUM		Run cont mon	-	-	RW	INT	FVY
--------------	--------------	--------------------------	--	------	--	--------------	---	---	----	-----	-----

Sets the source of contactor status signal.

The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.7.9</b>	<b>11236</b>	<b>Brake fbk src</b>		ENUM		Brake cont mon	-	-	RW	INT	FVY
--------------	--------------	----------------------	--	------	--	----------------	---	---	----	-----	-----

Sets the source of brake status signal.

The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.7.10</b>	<b>10096</b>	<b>Brake 2 fbk src</b>		ENUM		Brake cont mon	-	-	RW	INT	FVY
---------------	--------------	------------------------	--	------	--	----------------	---	---	----	-----	-----

Sets the source of the second brake status signal.

The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.7.11</b>	<b>11238</b>	<b>Door open src</b>		ENUM		Null	-	-	RW	EXP	FVY
---------------	--------------	----------------------	--	------	--	------	---	---	----	-----	-----

Sets of source to enable early door opening control.

The list of functions that can be associated with the digital inputs are in the "**LiftInputDoorCmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.7.12</b>	<b>11240</b>	<b>Door feedback src</b>		ENUM		Null	-	-	RW	EXP	FVY
---------------	--------------	--------------------------	--	------	--	------	---	---	----	-----	-----

Setting of the source of the door status signal.


The list of functions that can be associated with the digital inputs are in the "**LiftInputAdICmd**" selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.13</b>	<b>11242</b>	<b>Emergency mode src</b>		ENUM		Dig input 3 mon -	-	-	RW	INT	FVY
Setting of the source of the emergency operation signal.											
The list of functions that can be associated with the digital inputs are in the “ <b>LiftInputAdICmd</b> ” selection list.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.14</b>	<b>11246</b>	<b>Upper limit src</b>		ENUM		Null	-	-	RW	INT	FVY
Setting of the source of the upper limit enabling signal.											
The list of functions that can be associated with the digital inputs are in the “ <b>LiftInputAdICmd</b> ” selection list.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.15</b>	<b>11248</b>	<b>Lower limit src</b>		ENUM		Null	-	-	RW	INT	FVY
Setting of the source of the lower limit enabling signal.											
The list of functions that can be associated with the digital inputs are in the “ <b>LiftInputAdICmd</b> ” selection list.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.17</b>	<b>11274</b>	<b>Landing Cmd src</b>		ENUM		Null	-	-	RW	INT	FVY
Sets the source of Landing command.											
If you select Freeze inputs, the command is activated on the encoder inputs (see the ADL500 HW+QS manual to identify the encode Freeze inputs).											
Rising (rising/positive edge) means active on the rising edge of the signal; Falling (falling/negative edge) active on the falling edge.											
The list of functions that can be associated with the digital inputs are in the “ <b>LiftInputAdICmd</b> ” selection list.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.18</b>	<b>11820</b>	<b>Brake release src</b>		ENUM		Null	-	-	RW	EXP	VY
The assignable functions are on the “ <b>LiftInputAdICmd</b> ” selection list.											
Manual emergency manoeuvre. This function allows the cabin to move when there is a power failure in order to bring it to the closest floor by gravity.											
<ul style="list-style-type: none"> <li>• This manoeuvre can be performed only when the drive is in emergency mode, which the control card indicates with the “Emergency Mode” digital input. There must be a Brake Open digital input connected to a “Brake Open” button on the control panel that enables cabin movement. The command can be activated by simultaneous activation of the frw and rev inputs after setting parameter 11820 to the value FWD+REV.</li> <li>• When the button is pushed the inverter opens the brake contactor via the “Brake Contactor” Relay output. Parameter PAR 11094 set in Brake + Run mode also allows activation of the output of the run contactors located along the brake coil power supply line.</li> <li>• The operator has to keep pressed the “Brake Open” button to move the cabin.</li> <li>• PAR 11822 <b>Em Max spd</b> sets the maximum speed that the cabin (or the motor) can have during this manoeuvre.</li> <li>• If the cabin reaches the maximum allowed speed, the drive locks the brake for the time T set by parameter 11824 <b>Brake lock time</b>, disabling use of the button (which will not release the brake even if pushed).</li> <li>• When activating this manoeuvre, the display (both optional and built-in) shows the current cabin speed (or motor speed if set in rpm) and direction (Fwd or rev).</li> <li>• This manoeuvre is disabled in case of inspection.</li> </ul>											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.7.20</b>	<b>14102</b>	<b>Command input mon</b>	Hex	UINT32			-	-	R	ESY	FVY
Hexadecimal display of input status, see “Lift control word” description (table at the beginning of this section).											

## 5.8 PRE TORQUE

The Pre-torque function helps to guarantee a linear start without any initial jerk. This is possible by setting a torque value that corresponds to the load before opening the brake.

The initial torque value applied to the motor as well as the direction of the applied torque can be provided through an appropriately scaled analogue input (load cell on the lift cabin) or with a fixed torque value (in this case the value is optimised for one load condition only).



**Note!**

The pre-torque function is active in the SYN FOC motor control mode only.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.1	<b>11166 Pre-torque enable</b>			BIT		Off	-	-	RWZ	EXP	VY
Enabling of the pre-torque function.											
0 Off 1 On											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.2	<b>11168 Pre-torque source</b>			ENUM		Init PreTorque	-	-	RW	EXP	VY
Selection of the origin (source) of the signal used for the pre-torque function.											
1600 Analog in 1 4034 Fieldbus M->S2 4044 Fieldbus M->S3 4054 Fieldbus M->S4 4064 Fieldbus M->S5 4074 Fieldbus M->S6 4084 Fieldbus M->S7 4094 Fieldbus M->S8 4104 Fieldbus M->S9 4124 FieldbusM->S10 4114 FieldbusM->S11 4134 FieldbusM->S12 4144 FieldbuM->S13 4154 FieldbusM->S14 4164 FieldbusM->S15 4174 FieldbusM->S16 11170 Init pretorque											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.3	<b>11170 Init pre-torque</b>	%	INT16/32			0	-100	100	RWZ	EXP	VY
Setting of the reference value used in the pre-torque function only if the PAR 11168 Pre-torque source parameter is set to 11170 Init pre-torque.											
The value set in this parameter only enables the pre-torque function to be optimised for one load condition.											
The pre-torque function can also be optimised for different load conditions by using the fieldbus to modify the setting of this parameter.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.4	<b>11172 Pre-torque ramp up</b>	ms	INT16/32			0	0	10000	RWZ	EXP	VY
Setting of the ramp time for the rising edge of the torque value (before opening the brake): if this parameter is set to zero the constant feed-forward torque value is maintained during travel.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.5	11174	Pre-torque ramp down	ms	INT16/32		0	0	60000	RWZ	EXP	VY

Setting of the ramp time for the falling edge of the torque value: if this parameter is set to zero the constant feed-forward torque value is maintained during travel.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.6	11176	Pre-torque offset	%	FLOAT		0	-100	100	RWZ	EXP	VY

Setting of the offset value applied to the input reference of the pre-torque function.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.7	11178	Pre-torque gain		FLOAT		1.0	-100	100	RWZ	EXP	VY

Sets the gain to be applied to the source of the torque value to be used in the function.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.8	14040	Pre-torque input	%	INT16/32			-	-	R	EXP	VY

The reference value sampled at start is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.9	14056	Pre-torque out	%	INT16/32			-	-	R	EXP	VY

The feed forward torque value output of the pre-torque function is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.10	14058	Torque reference	%	INT16/32			-	-	R	EXP	VY

The torque reference value is displayed, given by the sum of the speed loop output and the torque feed forward.

## 5.9 EMERGENCY MODE

The possibility of operating on an emergency module power supply has been implemented in the drive, to overcome the problem of sudden power failures.

The emergency operation condition signal must be connected to the terminal relating to the source PAR 11242 **Emergency mode src**, which, if active, disables the antir rollback function (to limit power consumption) and the **Undervoltage [2]** alarm so that the drive can operate powered on the DC link by the EMS emergency module (which is in turn powered by a buffer battery pack).

In order to use batteries with a lower power rating, a function has been implemented to allow the desired direction of travel to be selected before starting an emergency start procedure.

The direction is carried out according to the selected mode (PAR 11262 **Autoselect direction**).

In case of a blackout the drive can be powered by an Emergency Module Supplier (EMS) or by an Uninterruptible Power Supply UPS.


### Operation with Emergency Module Supplier (EMS)

If the emergency mode is active, the Undervoltage [2] alarm will be disabled allowing the drive to operate powered on the DC link. See ADL500 HW+QS Manual section 7.3.3 and the EMS manual for the connection.

### EMS system management and monitoring function

This function allows the connection of the batteries to be checked.

This function is enabled with parameter PAR 11286 **Battery control**. If the batteries are disconnected for longer than the time set in parameter PAR 11852 **BatteryLow Hold off**, the [41] **No battery** alarm is tripped according to the action defined in parameter PAR 11852 **BatteryLow Activity**.



### Battery saving mode of operation

#### Operation with Uninterruptible Power Supply (UPS) Single-phase

When the emergency is activated, the Drive can be powered with 230V single-phase UPS. For connection see ADL500 HW+QS (Quick Start Guide) section 7.9.3.1.

The function can work with two modes: (3) "Battery Saving" and (4) "BattSav+Rec".

Depending on how you set the PAR 11262 **Autoselect direction** will be activated the first or the second new function.

The principle of operation of the function of replenishment to the floor in the event of a power outage with battery savings works as follows: with emergency input activated the drive tries to move the engine using only the imbalance as for a manoeuvre for unbalance that opens only the brake (and possibly also the gear switch setting the parameter PAR 11094 **Brake release type** = (1) Brake + Gear), if within a preset time from PAR 11092 **Em min spd time** the car moves and then stops once you reach the emergency speed set by PAR 11822 **Em max speed** (max speed in emergency) then the cabin continues for alternating imbalance to stop (when you reach the maximum speed in emergency). If, however, the cabin does not reach this speed within this time, the manoeuvre for imbalance is interrupted and then continue with the motor powered and with a maximum speed set through the parameter 11014 **Em max speed sav bat**.

Attention: the PAR 11824 **Brake lock time**, which defines the waiting time when the button is pressed between the release of the brake for reached max speed in emergency and the subsequent closing of the brake, must be less than PAR 11092 **Em min spd time** otherwise the maneuver turns into energized maneuver.

In the case of selection "Battery Saving" (3) the direction that the motor takes is that indicated by the input of ascent or descent.

In the case of selection "Battsav+Rec" (4) the direction taken by the motor is independent of the enabled input up or down and follows the recommended direction previously stored in the drive.

Summing up, in this maneuver first the emergency input must be activated, then the control board must command a movement of ascent or descent also enabling the enable as a normal maneuver (except that the multispeed inputs are not considered and the motor speed is regulated by the PAR 11260 **Emergency mode speed**), then the cabin will move for imbalance or so with energized motor.

Once the car has reached the floor is the control board that controls the engine stop by removing the climb or descent references and then the enable.

#### Manual emergency mode for imbalance

The purpose of the function is to allow the movement of the cabin when there is no network in order to bring it to the nearest floor by simple gravity.

The maneuver is possible only when the drive is in emergency condition, signaled by the control board through-towards the digital input "Emergency Mode". A digital input (Brake Open) must be connected to a "Brake Open" button in the control panel that enables the movement of the cab. The command can be activated by simultaneous activation of the inputs frw and rev after setting the parameter 11820 to the value "Av + Ind".

When the button is pressed, the inverter via the Relay output "Brake Contactor", will open the brake contactor. The PAR 11094 parameter set in "Brake + Gear" mode allows to activate also the output of the gear contactors located along the supply line of the brake coil.

The operator must press and hold the "Brake Open" button to move the car.

The PAR 11822 **Em max speed** sets the maximum speed that the car (or engine) can have during the maneuver.

If the car reaches the maximum speed allowed the drive locks the brake for the time T set in PAR 11824 **Brake lock time**, disabling the use of the button (even if pressed it does not release the brake).

By activating this operation, the display (both optional and integrated) displays the current cabin speed (or engine if rpm is set) and the Fwd or Rev direction. In case of an inspection, the manoeuvre is disabled.

#### Automatic emergency manoeuvre for imbalance

The manoeuvre is identical to the manual emergency manoeuvre and differs only in that input 11820 is activated automatically by the lift control board.

#### Emergency manoeuvre with engine energized by UPS or batteries + EMS module

Selecting in par 11262 the values 0 Off, 1 autosel or 2 Recommended, with emergency input activated, at the first driving control the drive controls a movement to the motor in the direction depending on the value chosen with the speed indicated in parameter 11260 **Emergency mode speed**.

#### Speed and direction display in case of emergency movement

In comparison to EN 81-20 in case of movement of the engine in emergency controlled by the drive, the keypad is always indicated the speed at which the motor is going and the direction of movement (through the positive or negative sign of speed). Both for closed-loop and open-loop configurations, the management of the arrival to the emergency plan is realized trying to optimize the power demand to the emergency modules.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.1	<b>11286 Battery control</b>			ENUM		Disable	-	-	RWZ	INT	FVY
Enables the continuous monitoring of the EMS system; in the event of a disconnection or low battery charge, the [41] <b>No battery</b> alarm is tripped, managed by the PAR 11850 <b>No battery activity</b> and the PAR 11852 <b>No battery hold off</b> parameters in the 5.10 LIFT ALARMS menu.											
0 Disable 1 Enable											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.2	<b>11260 Emergency mode speed</b>			FLOAT		4.77(0.1)	-10000	10000	RW	INT	FVY
Setting of the speed during movements in the emergency operation condition. The multi-speed is not considered.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.3	<b>11262 Autoselect direction</b>			ENUM		Recommended	-	-	RWZ	INT	FVY
Enables the automatic selection of the most favourable direction of movement before a start in the emergency mode.											

- 0 OFF
  - 1 AutoSelect
  - 2 Recommended
  - 3 Battery saving
  - 4 BattSav + Rec
- If 0 is selected: the drive does not calculate the more favorable direction, which is commanded manually.  
 If 1 is selected: as soon as the drive is in emergency condition it moves the motor with alternating forward and reverse movements, calculating the value of the current delivered in each direction, and selects the more favorable one (less current requested).  
 If 2 is selected: the drive assesses the most favourable direction based on the current supplied and the DC-Link voltage prior to the emergency. If the drive was in regenerative mode before the emergency, the same direction will be maintained even in an emergency, if the drive was not in regenerative mode but was supplying a current whose value is lower than the threshold set (PAR 11284 Detection Limit), it will maintain the same direction; otherwise, if the current supplied was higher than the threshold, the drive will reverse the direction of movement.  
 If 3 is selected: The "Battery saving" function allows you to manage the automatic return to the floor in an emergency by exploiting the movement of the car by gravity, and activating the motor only if necessary.  
 The maneuver is activated by configuring "Battery saving" (PAR 11262) as emergency mode and activating the Emergency function via the configured input.  
 The function works following this logic: a "manual release brake" maneuver is automatically launched, respecting the settings of the "manual release brake" function; if the car moves, the "manual release brake" maneuver continues, respecting

the conditions set by the function. If the car is in an equilibrium position or the car speed remains below the threshold (PAR 11090) for the pre-set time (PAR 11092) then the brake is closed and the electric running in emergency starts. The electric gear will take place following the commanded direction

If 4 is selected: The “BattSav + Rec” function allows you to manage the automatic return to the floor in an emergency, the maneuver takes place as in selection 3 “Battery saving” the difference is that in electric running in this mode it will take place following the recommended direction.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.4	11278	Em DC brk current	%	FLOAT		75.0	0	150	RW	INT	FV

The parameter lets you set the braking current value by injecting DC in the motor windings. You can limit this value and avoid overloading the emergency batteries.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.5	11284	Detection Limit	%	UINT32		20	0	100	RWZ	INT	FVY

This is the current limit value delivered by the drive (expressed as a percentage of nominal current) to select the more favorable riding direction in **Recommended** mode (see PAR 11262).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.6	14282	Chosen direction		ENUM		-	-	-	R	INT	

Indicates the direction selected by the drive during the emergency.

- 0 No direction (selected)
- 1 Forward
- 2 Reverse

The association of Forward/Reverse and Up/Down depends on how the motor connection is made.

See PAR 11092 Em min spd time (def = 6 sec) on menu “9 SAFETY”.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.7	11094	Brake release type		ENUM		Freno	-	-	RW	EXP	VY

Sets the mode by which the brake is released in the event that the emergency movement manoeuvre for imbalance is activated through the activation of the input set by par 11820.

- 0 Brake
- 1 Brake + Gear

0: only the brake contactor is controlled.

1: both brake and travel contactors are controlled (the short phase contactor is not controlled if it is wired to a different digital output from the gear contactor).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.8	11090	Em min speed		FLOAT		0.05	0	10000	RW	EXP	VY

Setting of the minimum cabin speed threshold, used in the “battery saving” emergency mode, to the below which, after the time defined in parameter 11092, the manual unlocking is deactivated and a emergency operation in the recommended direction.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.9	11092	Em min spd time	s	INT16/32		6	1	30	RW	EXP	VY

Time setting, used in the emergency mode “battery saver”, after which, if the speed of the cabin remains below the threshold defined in parameter 11090, manual unlocking is deactivated and a gear in emergency in the recommended direction.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.10	11108	Delay mot sav bat	m/s	INT32		1000	0	5000	RW	EXP	VY

Setting the delay time of the motor energization in the battery saving phase from the moment of the brake opening command.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.11	11822	Em max speed		UINT32		0.1	-	-	RW	EXP	VY

Set the maximum speed that the cab (or engine) can have during the maneuver.  
The speed can be expressed in m/s (if related to the cab) or in rpm (if related to the engine).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.12	11014	Em max speed sav bat	Hz	FLOAT		0.09	0.01	1000	RW	EXP	VY

Setting the maximum speed when releasing the brake in battery saving mode.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.13	11824	Brake lock time	s	UINT32		4	1	30	RW	EXP	VY

Setting the brake lock time when the car reaches the maximum speed allowed.

## 5.10 LIFT ALARMS

The drive manages and generates the following alarms:

Index	Error message shown on the display	Description
32	Enable missing	Condition: (ADL550 only) occurs if Enable is not activated within 4 seconds of the Safety Enable signal.  Solution: <ul style="list-style-type: none"><li>• check the Enable signal.</li><li>• check the SAFETY connector, contacts 1 and 2.</li><li>• check the electrical level and Safety Enable signal current capacity.</li></ul>
33	Cont feedback	Condition: The contactor feedback signal does not match its command.  Solution: Check contactor feedback wiring, check logic status of feedback input to drive, increase hold off time (PAR 11202).
34	Brake Feedback	Condition: The brake feedback signal does not match its command.  Solution: Check brake feedback wiring, check logic status of feedback input to drive, increase hold off time (PAR 11206).
35	Door Feedback	Condition: The door feedback signal does not match its command.  Solution: Check door feedback wiring, check logic status of feedback input to drive, increase hold off time (PAR 11212).
36	Brake Failure	Condition: Exceeding the Threshold A3 (PAR 11270).  Solution: Reset alarm using the reset parameter (PAR 11268), check that brake is intact, increase threshold (PAR 11270).
37	Safe Brake Test	Condition: Safe Brake Test failed.  Solution: Check that brake is intact, increase the maximum deviation threshold (PAR 11840).
38	Speed limit	Condition: Speed limitation warning to ensure stopping, enabling the DISTANCE function.  Solution: Check multi-speed selected for current distance.
39	Up/low limit	Condition: Speed threshold exceeded in limit switches zone (sensors installed at the top and bottom of the lift/elevator shaft).  Solution: Check speed set in limit switches zone, change speed limit (PAR 11216).
40	Lift ext fault	Condition: External alarm signal triggered (PAR 11258).  Solution: Check causes enabling external alarm signal, increase hold off time (PAR 11266).
41	No battery	Condition: Battery monitoring alarm triggered.  Solution: Check whether battery is properly connected to drive.
42	Batt assente	Condizione: Intervento dell'allarme di monitoraggio della batteria.  Soluzione: Verificare se la batteria è correttamente collegata al drive.

All alarms are associated with a parameter to configure the action taken when the alarm is activated.

Activity: used to set the action to be performed after activation of the alarm, as follows.

### Action

Ignore	The alarm is not included in the alarm list, it is not included in the alarm log, it is not signalled on the digital outputs, commands to the drive are not modified.
Warning	The alarm is included in the alarm list, it is included in the alarm log, it is signalled on the digital outputs, First alarm information is updated, Enabled alarms information is updated, commands to the drive are not modified.
Disable drive	The alarm is included in the alarm list, it is included in the alarm log, it is signalled on the digital outputs, First alarm information is updated, Enabled alarms information is updated, a stop command is sent, the motor is disabled and stops due to inertia.
Fast Stop	The alarm is included in the alarm list, it is included in the alarm log, it is signalled on the digital outputs, First alarm information is updated, Enabled alarms information is updated, a Stop command is sent. The drive is set to zero speed with the maximum available current; when the Speed 0 delay.

		signal is activated the drive is disabled.
Lift Fast stop		When there is an alarm occurrence, lift will be stopped (ramp reference is set to zero) immediately with fast ramp, after that it will remain in alarm state. Attention: this will cause the cabin to stop out of floor !
Lift stop		When there is an alarm occurrence, lift will continue to run until next stop condition, after that it will remain in alarm state.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.1	11058	Lift fast stop fact		FLOAT		10	1	50	RWZ	INT	FVY

Sets a multiplication factor that is applied to all ramps when the "Fast stop" alarm occurs.

Setting 1: Ramp values are not changed: 100% of the rated value is used

Setting 10: Ramp values are multiplied by 10: 1000% of the rated value is used.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.2	11200	Contactor activity		ENUM		Disable			RWZ	INT	FVY

Sets the drive behaviour in case the **Cont feedback** alarm is tripped.

This alarm indicates that contactor command and feedback are mismatched.

- 0 Ignore
- 1 Warning
- 2 Disable drive
- 3 Fast stop
- 4 Lift fast stop
- 5 Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.3	11202	Cont hold off	ms	INT32		1000	0	60000	RW	INT	FVY

Sets the allowed delay time if contactor command and feedback are mismatched.

If command and feedback are mismatched, the drive waits until the set time has elapsed before tripping the alarm.

If the alarm is removed within the set time, the drive will not activate the alarm.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.4	11204	Brake activity		ENUM		Disable			RWZ	INT	FVY

Setting of drive behaviour in case of a **Brake Feedback** alarm.

This alarm indicates that brake command and feedback are mismatched.

- 0 Ignore
- 1 Warning
- 2 Disable drive
- 3 Fast stop
- 4 Lift fast stop
- 5 Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.5	11206	Brake hold off	ms	INT32		1000	0	60000	RW	INT	FVY

Sets the delay time if brake command and feedback are mismatched.

If the alarm is removed within the set time, the drive will not activate the alarm.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.6	10094	Brake 2 hold off	ms	INT32		1000	0	60000	RW	INT	FVY

Sets the delay time if second brake command and feedback are mismatched. If the alarm is removed within the set time, the drive will not activate the alarm.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.7	11208	Brake run hold off		ENUM		Enable	-	-	RW	INT	FVY

Setting of drive behaviour when a possible **Brake Feedback** alarm is detected.

- 0 Disable
- 1 Enable

If set to 0 the brake feedback alarm is indicated immediately.

If set to 1 the possible brake feedback alarm is indicated at the end of travel: this allows the cabin to reach the floor in case of a faulty brake status signal.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.8	11210	Door activity		ENUM		Disable	-	-	RWZ	EXP	FVY

Setting of drive behaviour when a possible **Door Feedback** alarm is detected.


This alarm indicates that door command and feedback are mismatched.

- 0 Ignore
- 1 Warning
- 2 Disable drive
- 3 Fast stop
- 4 Lift fast stop
- 5 Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.9	11212	Door hold off	ms	INT32		1000	0	60000	RW	EXP	FVY

Sets the allowed delay time if contactor command and feedback are mismatched.

If command and feedback are mismatched, the drive waits for the set time to elapse before activating the alarm. If the alarm is removed within the set time, the drive will not activate the alarm.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.10	11214	Limit activity		ENUM		Lift fast stop	-	-	RWZ	INT	FVY

Setting of drive behaviour in case of the **Upper/Lower limit**.

The P AR 11246 **Upper limit src** and PAR 11248 **Lower limit src** digital inputs must be set to enable speed limit control. The **UpperLimit** must always correspond to the upper limit signal and the **LowerLimit** must always correspond to the lower limit signal.

This alarm occurs when the speed is greater than PAR 11216 **Limit speed thr** and are active sensors installed at the beginning and end of the space.

This function implemented in the drive provides an additional control to avoid overtravel.

The alarm condition is generated, when the set speed limit is exceeded.

- 0 Ignore
- 1 Warning
- 2 Disable drive
- 3 Fast stop
- 4 Lift fast stop
- 5 Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.11	11216	Limit speed thr	m/s	FLOAT		1	0	10	RW	INT	FVY

Sets the maximum speed allowed in the limit switches zone.

If this parameter is left at zero, the **Up/Low Limit** alarm will remain deactivated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.12	11218	Spd target activity		ENUM		Warning	-	-	RWZ	INT	FVY

Setting of drive behaviour in case of the **Speed limit** alarm.

This alarm is tripped if, when using the EFC function (see DISTANCE menu), the calculated deceleration distance is less than the actual available deceleration space.

The speed limiter is activated to always allow a correct stop.

- 0** Ignore
- 1** Warning
- 2** Disable drive
- 3** Fast stop
- 4** Lift fast stop
- 5** Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.10.13</b>	<b>11258</b>	<b>Lift EF alarm src</b>		ENUM		Null	-	-	RWZ	INT	FVY

Selects the origin of the “**Lift External Fault**” alarm signal; the alarm is intended to put the drive into an alarm condition, for faults detected by external controllers.

The list of functions that can be associated with the digital inputs are in the “**LiftInputAdICmd**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.10.14</b>	<b>11264</b>	<b>Lift EF al activity</b>		ENUM		Lift stop	-	-	RWZ	INT	FVY

Setting of “Lift EF alarm set” alarm.

- 0** Ignore
- 1** Warning
- 2** Disable drive
- 3** Fast stop
- 4** Lift fast stop
- 5** Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.10.15</b>	<b>11266</b>	<b>Lift EF hold off</b>	ms	UINT32		1000	0	60000	RW	INT	FVY

Sets the delay time between when the “**Lift EF alarm**” is received and the execution of the selected activity.

If, within the time set in this parameter, the alarm is eliminated, the drive will not perform the action.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.10.17</b>	<b>11850</b>	<b>No battery activity</b>		ENUM		Warning	-	-	RWZ	INT	FVY

Sets the drive behaviour in case the [41] **No battery** alarm is tripped.

If the battery management and monitoring function is used (see 5.9 EMERGENCY MODE menu).

- 0** Ignore
- 1** Warning
- 2** Disable drive
- 3** Fast stop
- 4** Lift fast stop
- 5** Lift stop

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.10.18</b>	<b>11852</b>	<b>No battery hold off</b>	ms	UINT32		1000	0	10000	RW	INT	FVY

Sets the delay time between when the [41] **No battery** alarm is received and the execution of the selected activity.


If the battery management and monitoring function is used (see 5.9 EMERGENCY MODE menu).

If, within the time set in this parameter, the alarm is eliminated, the drive will not perform the action.

## 5.11 DISTANCE


Use of the distances facilitates positioning of the deceleration sensors and is helpful for managing short floors.

The aim of the function that considers distances is to start decelerating from high speed in order to reach the approach speed in proximity to the landing zone.




Up to a maximum of 8 different slow down distances can be managed (real distance between the start of the sensor and the floor) associated with the different multispeeds. The distance to be used is selected after enabling the drive, before the cabin starts to move. Different distances cannot be selected while the cabin is travelling.

If the slow down distance is shorter than the real deceleration distance for the selected target speed, the speed is automatically limited so that the stop is always correct. When this speed limiter is enabled a **Speed Limit** alarm (warning) is generated.



If the slow down sensor is met during acceleration, the distance required to terminate the acceleration and deceleration phases may be greater than the distance available: in that case the last acceleration jerk is increased to enable correct landing.



Also note that when the position sensor is not enabled in the landing zone, its exact length is not known. To ensure correct deceleration this distance is estimated on the basis of the value entered in the PAR 11132 **Landing zone dist** parameter.

When this is equal to zero the distance is calculated on the basis of the value of the low speed and deceleration parameters and shown in the PAR 14034 **Landing zone space** parameter. The user should make sure this distance is approximately the real length of the landing zone.

In FOC mode the distance is calculated by reading the encoder position.

In the ASY SSC mode the distance is estimated ( $\text{SpdRef} * \text{Time}$ ) and is thus subject to errors due to the difference between the real speed of the motor and the speed reference.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.1	11102	<b>Distance multispeed 0</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.2	11104	<b>Distance multispeed 1</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.3	11106	<b>Distance multispeed 2</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.4	11110	<b>Distance multispeed 3</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.5	11112	<b>Distance multispeed 4</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.6	11114	<b>Distance multispeed 5</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.7	11116	<b>Distance multispeed 6</b>	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.8	11118	<b>Distance multispeed 7</b>	m	FLOAT		0.000	0	400	RW	INT	FVY

Setting of the value of the distance associated with **multispeed** (0...7).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.9	11120	<b>Slow speed</b>		ENUM		Autoselect	-	-	RW	INT	FVY

Setting of the floor approach speed.

The **Slow speed** is the speed of approach to the landing zone. When the multispeed associated with the **Slow speed** is selected the slow down space is checked in order to reach this speed in proximity to the landing zone.

- 0 Autoselect
- 1 Multispeed 0
- 2 Multispeed 1
- 3 Multispeed 2
- 4 Multispeed 3
- 5 Multispeed 4
- 6 Multispeed 5
- 7 Multispeed 6
- 8 Multispeed 7
- 9 Null

When mode 0 (**Autoselect**) is selected, **Slow speed** is automatically connected to the multispeed with absolute value of less and other than zero. If repositioning speeds with a value of less than the **Slow speed** are used, the multispeed corresponding to the floor approach speed must be set.

When mode 9 (**Null**) is selected the floor approach spaces are never controlled. In this case the profile depends exclusively on the multispeed selected.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.10	11130	<b>Enable landing src</b>		INT16		Off	-	-	RW	EXP	FVY

Setting for enabling space control in the landing zone.

This function enables the cabin to arrive exactly at floor level by controlling the position of the encoder in the landing zone sensor. Position control is only possible if an encoder is used (normally in SYN FOC). ASY SSC mode simply generate an appropriate profile on the position reference.

When the function is enabled, the speed at which the cabin enters the landing zone is that defined on PAR 11120 **Slow speed** and no longer depends on the relative multispeed but is calculated automatically according to the jerk and deceleration values to enable stopping without exceeding the set limits.

The value of **Slow speed** (PAR 11120 = 1...8) is calculated using the jerk and deceleration values not multiplied by the ramp factor.

Direct arrival at floor level is also possible, without using the **Slow speed**. This is done by setting the **Slow speed** multispeed value to zero.

- 0 Off
- 1 On

Given the solution that has been selected to calculate the speed profile, before enabling the landing zone function it is important to verify the exactness of the spaces that have been entered (for both slow down and landing), and of the mechanical constants. Incorrect spaces could result in sudden decelerations and errors in arrival at floor level.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.11	11132	Landing zone dist	m	FLOAT		0.120	0	10	RW	EXP	FVY

Setting of the landing zone distance.


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.12	11138	Out floor function		BIT		Off			RW	EXP	FVY

Enabling of the safe start function when not at floor level. This function enables recognition of arrival at floor level, which is assumed to be correct if the landing zone phase is performed.

If a correct stopping sequence is not recognised this means an emergency stop command has been sent, after which a low speed start is generated.

The restart procedure depends on the stop position as shown in the figure.

- 0 Off
- 1 On



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.13	11140	Delay acq time	ms	FLOAT		15	0	1000	RW	EXP	FVY

Setting of the delay time for sending the slow down signal.

The value of this parameter is used to compensate for the distance covered during the delay time between the passage of the cabin on the slow down sensor and receipt of the decelerate command by the drive. At high speeds this distance can have significant values: e.g. with a cabin travelling at 2 m/s and a delay time of 30 ms, the distance covered and to be

taken into consideration during the deceleration phase is 6 cm.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.14	11142	Calc space HiSpd sel		UINT16		Multispeed 1			RW	EXP	FVY

Setting of the high speed to be used to calculate distances.

- 0 Multispeed 0
- 1 Multispeed 1
- 2 Multispeed 2
- 3 Multispeed 3
- 4 Multispeed 4
- 5 Multispeed 5
- 6 Multispeed 6
- 7 Multispeed 7
- 8 Null

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.15	11276	Kp landing		FLOAT		0	0	100	RW	EXP	FVY


Lets you configure proportional gain to control the landing curve.

## 5.14 DIRECT CNT

The purpose of the “change ride direction count” function is to monitor the wear and tear of the ropes or belts, to indicate when to carry out the necessary maintenance/replacement and to stop the lift if the usage limits are reached. The change of direction counting function for coated ropes or belts is not required by EN 81.20 but it is up to the manufacturers of coated ropes and belts to define the method for indicating when replacement becomes mandatory. The most commonly used method is to count the changes of direction. To ensure that this count cannot be tampered with, the count itself must be protected against deletion. The most commonly used method is to use a password to gain access to data that cannot be deleted by mistake. There are two types of passwords: a password that is always valid until it is changed, and a password that becomes unusable after each use and must be regenerated using a decryption code. Passwords are not compulsory and the manufacturer can use whichever method he prefers to protect against accidental deletion, which is why the change counter can also be used without being put under a password.

A specific counter keeps count of direction changes and can be reset when the ropes are replaced.

The following signals, inserted in the L\_DIGSEL1 selection list, can be brought to a digital output: PAR 3420 **Ropes change req mon**, PAR 3422 **Dir change monitor** and PAR 3424 **Dir change cnt zero**.



### Firmware update

To keep them from being overwritten when using WEG\_DriveLabs, these parameters are not updated with the **Write all target parameters** operation.

### Replacing the drive

If the drive is replaced, you can save the configuration of the “Direction change count” function on a USB device (PAR 3434 **Save rope to USB**) and load it on the new drive (PAR 3436 **Load rope from USB**).

### Password

All parameters of this function, reserved for the lift maintenance mechanic, are only accessible at the Expert level, which can be password protected, see “**6.6 NETWORK AND ACCESS**”).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.14.1	3400	<b>Direction cnt enable</b>		ENUM		Disable			RW	EXP	FVSY
	0	Disable									
	1	Enable									
		Enables the “Direction change count” function.									

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.14.2	3402	<b>Max direction cnt</b>		UINT32		0	0	2147483647	RW	EXP	FVSY

Sets the maximum allowed number of direction changes.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.14.3</b>	<b>3404</b>	<b>Rope change thr</b>	%	UINT32		98	0	100	RW	EXP	FVSY
---------------	-------------	------------------------	---	--------	--	----	---	-----	----	-----	------

Sets a usage threshold beyond which the “Rope change” alarm is signalled to indicate that the ropes have to be replaced. When parameter 3412 **Ropes usage** exceeds this threshold, the drive keeps running but the alarm stays on to remind the operator to replace the ropes.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.14.4</b>	<b>3406</b>	<b>Direction cnt reset</b>		BIT		0	0	1	RW	EXP	FVSY
---------------	-------------	----------------------------	--	-----	--	---	---	---	----	-----	------

**0** Disable  
**1** Enable

Let you run a reset to return the direction change counter to the initial value of parameter 3402 **Max direction cnt** (value set by rope manufacturer).

This operation is password-protected and must be run when the ropes are changed.

Executing this command causes the following:

- the value of counter 3414 **Direction counter** is copied to parameter 3416 **Prev direct counter**,
- the value of parameter 3418 **No of cnt reset** is incremented,
- counter 3414 **Direction counter** is reset to value 3402 **Max direction cnt** and consequently parameter 3412 **Ropes usage** is reset to 0.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.14.5</b>	<b>3408</b>	<b>Dir cnt password</b>		UINT32		0	0	999999	RW	EXP	FVSY
---------------	-------------	-------------------------	--	--------	--	---	---	--------	----	-----	------

<b>5.14.6</b>	<b>3410</b>	<b>Dir cnt new password</b>		UINT32		0	0	999999	RW	EXP	FVSY
---------------	-------------	-----------------------------	--	--------	--	---	---	--------	----	-----	------

With parameters 3408 and 3410 the modification of parameters 3400, 3402, 3404, 3406, 3410 is protected.

The password is a numeric code of up to 6 digits.

To set a password, it must be entered twice in parameter 3410.

After the first entry, “Confirm password” is signaled, which means that the same value must be entered for confirmation.

If the second value is different from the first, “Password mismatch” is signalled, otherwise the new password becomes operative.

The password is retentive so it will not be necessary to save the parameters after changing it.

To enable changes to the protected parameters, the password must be entered in parameter 3408, which must correspond to what was programmed in parameter 3410.

The current values of parameters 3408 and 3410 are only visible while typing. When you press Enter, 0 is displayed to prevent them from being read by unauthorized persons.

After having modified one of the parameters 3400, 3406 and 3410, the entered password is invalidated therefore if you want to continue with other modifications you have to enter it again.

For one-time password management, see the instructions in the description of par 3440.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.14.7</b>	<b>3412</b>	<b>Ropes usage</b>	%	UINT16	16BIT_L	0	0	0	R	EXP	FVSY
---------------	-------------	--------------------	---	--------	---------	---	---	---	---	-----	------

Displays the ropes usage counter (as percentage) of parameter 3402 **Max direction cnt**.

When PAR 3412 = 100% (corresponds to PAR 3414 = 0), the ropes have reached their useful life and must be replaced: the drive finishes the current travel and then locks.

By switching the drive off and back on you can run a single travel to bring the car to a better position for the procedure.

To eliminate the lock condition, reset the direction change counter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.14.8</b>	<b>3414</b>	<b>Direction counter</b>		UINT32	32BIT	0	0	0	R	EXP	FVSY
---------------	-------------	--------------------------	--	--------	-------	---	---	---	---	-----	------

Displays the countdown of direction changes remaining until useful life of the ropes is reached.

When PAR 3414 = “0” the ropes must be replaced (corresponds to PAR 3412 = 100%): the drive finishes the current travel and then locks.

By switching the drive off and back on you can run a single travel to bring the car to a better position for the procedure.

To eliminate the lock condition, reset the direction change counter (see PAR 3406 **Direction cnt reset**).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

<b>5.14.9</b>	<b>3416</b>	<b>Prev direct counter</b>		UINT32	32BIT	0	0	0	R	EXP	FVSY
---------------	-------------	----------------------------	--	--------	-------	---	---	---	---	-----	------

Displays the number of direction changes remaining on the previous set of ropes (value of PAR 3414 **Direction counter** is copied before reset). This number will remain fixed until the next replacement of the ropes.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.14.10</b>	<b>3418</b>	<b>No of cnt reset</b>		UINT32	32BIT	0	0	0	R	EXP	FVSY
		Displays the number of rope changes made.									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.14.11</b>	<b>3420</b>	<b>Ropes change req mon</b>		BIT	16BIT_L	0	0	1	R	EXP	FVSY
		Activates when the percentage of rope usage (set in PAR 3412 <b>Ropes usage</b> ) exceeds the set threshold (PAR 3404 <b>Ropes change thr</b> ).									
		This signal is inserted in the L_DIGSEL1 selection list and can be brought to a digital output.									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.14.12</b>	<b>3422</b>	<b>Dir change monitor</b>		BIT	16BIT_L	0	0	1	R	EXP	FVSY
		This signal stays on for one second each time the drive detects a direction change and thus decrements the counter.									
		This signal is inserted in the L_DIGSEL1 selection list and can be brought to a digital output.									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.14.13</b>	<b>3424</b>	<b>Dir change cnt zero</b>		BIT	16BIT_L	0	0	1	R	EXP	FVSY
		This signal activates when the drive is locked because 3414 <b>Direction counter</b> has reached 0.									
		This signal is inserted in the L_DIGSEL1 selection list and can be brought to a digital output.									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.14.14</b>	<b>3434</b>	<b>Save rope to USB</b>		BIT		0	0	1	RWZ	EXP	
		Lets you save the configuration of the “Direction change count” function on the USB.									
		The set of parameters is saved in a dedicated area on the USB memory.									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.14.15</b>	<b>3436</b>	<b>Load rope from USB</b>		BIT		0	0	1	RWZ	EXP	
		Lets you load the configuration of the “Direction change count” function saved on the USB memory with PAR 3434 <b>Save rope to USB</b> on the new drive.									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.14.16</b>	<b>3440</b>	<b>Dircnt password type</b>		ENUM		Static			RWZ	EXP	FVSY
		This parameter allows you to select which type of password to use. By entering the value Static, the password entered does not expire and remains active until it is replaced with another password. By selecting One Time, a One Time password must be requested each time a password-protected value is to be changed.									
		The One Time password is generated in the following way:									
		parameter 3442 <b>Pwd code build</b> is selected and the value that is highlighted in parameter 3444 <b>Pwd code</b> is taken into account. The code must be entered into the application on the PC, which will return a password pair.									
		1) Password for resetting the counters.									
		Entering this password in parameter 3408 <b>Dir cnt password</b> will only enable resetting of the counters via command 3406 Direction cnt reset. Following this command, the password will be deactivated and can no longer be used.									
		2) Password for changing parameters.									
		By entering this password in parameter 3408 <b>Dir cnt password</b> , it will be possible to change the following parameters:									
		3400 <b>Direction cnt enable</b>									
		3402 <b>Max direction cnt</b>									
		3404 <b>Ropes change thr</b>									
		3440 <b>Dircnt password type</b>									
		This password will be disabled and will no longer be usable after the drive has been restarted.									
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>5.14.17</b>	<b>3442</b>	<b>PWD code build</b>		BIT		0	0	1	RW	EXP	FVSY
		Allows a one time code to be generated that is needed to generate the one time password to reset the counters. the value of the generalo code will be visible in parameter 3444.									

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.14.18	3444	PWD code		UINT32		0.0	0	0	R	EXP	

One time code generated by confirmation of parameter 3442 **Pwd code build**.

## 6 COMMUNICATION

### 6.1 CONTROL COMMUNICATION (CONTROL COMM)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

6.1.1	4000	Communication mode		ENUM		Parallel			RW	INT	FVSY
-------	------	--------------------	--	------	--	----------	--	--	----	-----	------

Setting the type of communication to be used.

- 0 Parallel I/O
- 1 CanOpen
- 2 DCP (Under development)
- 3 CAN417 (Under development)

Setting **0** the drive communicates with the Controller through Parallel I/O (physical inputs and outputs).

Setting **1** selects the CANopen fieldbus.

Setting **2** selects DCP communication.

Setting **3** selects the DS417 fieldbus profile.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

6.1.2	3800	Drive address		UINT16		1	1	255	RW	EXP	
-------	------	---------------	--	--------	--	---	---	-----	----	-----	--

Setting of the address to which the drive responds when connected to the DCP serial line.

Parameter available when PAR 4000 **Communication mode** = 2 (DCP).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

6.1.3	3802	Serial baudrate		ENUM		38400			RW	EXP	
-------	------	-----------------	--	------	--	-------	--	--	----	-----	--

Setting of the DCP serial communication speed (Baud Rate).

Parameter available when PAR 4000 Communication mode = 1 (DCP).

- 0 9600
- 1 19200
- 2 38400

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

6.1.4	3806	Serial delay	ms	UINT16		0	0	1000	RW	EXP	
-------	------	--------------	----	--------	--	---	---	------	----	-----	--

Setting of the minimum delay between the drive receiving the last byte and starting its response. This delay avoids conflicts on the serial line when the DCP interface that is used has not been pre-set for automatic Tx/Rx switching. The parameter only concerns the use of the standard DCP serial line. Only for PAR **Communication mode** = (2) DCP.

*Example:* if the delay in Tx/Rx switching on the master is a maximum of 20ms, the **Ser answer delay** parameter must be set to at least 20ms: 22ms.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

6.1.5	3810	Serial parameter		ENUM		N_8_1			RW	EXP	
-------	------	------------------	--	------	--	-------	--	--	----	-----	--

Setting of the format of the DCP serial line.

- 0 None,8,1
- 1 None,8,2
- 2 Even,8,1
- 3 Odd,8,1

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
------	-----	-------------	----	------	--------	-----	-----	-----	-----	------	------

6.1.6	4004	Fieldbus baudrate		ENUM		250k			RW	EXP	
-------	------	-------------------	--	------	--	------	--	--	----	-----	--

Setting of the communication network speed (Baud Rate).

Only for PAR **Communication mode** = (3) CAN417.

- 1 125k

- 2** 250k  
**3** 500k  
**4** 1M

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>6.1.7</b>	<b>4006</b>	<b>Fieldbus address</b>		INT16		2	1	127	RW	EXP	

Setting of the node address of the drive when connected to the network.

Only for PAR **Communication mode** = (3) CAN417.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>6.1.8</b>	<b>4010</b>	<b>Fieldbus M-&gt;S enable</b>		ENUM		Enable			RWZ	EXP	

Setting of fieldbus data updating.

Only for PAR **Communication mode** = (3) CAN417.

- 0** Disable  
**1** Enable

If set to **0**, the possibility of sending commands and references from the drive PLC via the fieldbus is disabled.

If set to **1** the possibility of sending commands and references from the drive PLC via the fieldbus is enabled.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>6.1.9</b>	<b>4012</b>	<b>Fieldbus alarm mode</b>		INT32		0	0	1	RWZ	EXP	

Setting of the **Opt Bus Fault** alarm generation mode.

Only for PAR **Communication mode** = (3) CAN417.

- 0** Disable  
**1** Enable

If set to 0 the alarm is only generated if the communication with the fieldbus is lost with the drive enabled.

If set to 1 the alarm is generated when the communication with the fieldbus is lost even if the drive is disabled.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>6.1.10</b>	<b>4014</b>	<b>Fieldbus state</b>		ENUM		Stop			R	EXP	

The logic status of the fieldbus connection is displayed. The value depends on the type of bus that is used.

Only for PAR **Communication mode** = (3) CAN417.

- 0** Stop  
**1** PreOperational  
**2** Operational

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>6.1.11</b>	<b>4338</b>	<b>Fieldbus error</b>		UINT16		0	0	0	R	EXP	

For the correct interpretation of the cause of the “**Opt Bus Fault** [17]” alarm trigger, it is necessary to read the hex code indicated in parameter 4338 **Fieldbus Error** and verify description and cause in the table of chapter “1.5 Alarms”.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>6.1.12</b>	<b>4008</b>	<b>Can termin.resistor</b>		ENUM		Off			RW	EXP	

Activation of the internal termination resistor.

- 0** Off  
**1** On

## 6.2 FIELDBUS M2S

Parameters visible only with PAR 4000 Communication mode = (1) CANopen.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.2.1	4020	Fieldbus M->S1 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.5	4030	Fieldbus M->S2 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.9	4040	Fieldbus M->S3 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.13	4050	Fieldbus M->S4 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.17	4060	Fieldbus M->S5 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.21	4070	Fieldbus M->S6 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.25	4080	Fieldbus M->S7 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.29	4090	Fieldbus M->S8 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.33	4100	Fieldbus M->S9 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.37	4110	Fieldbus M->S10 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.41	4120	Fieldbus M->S11 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.45	4130	Fieldbus M->S12 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.49	4140	Fieldbus M->S13 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.53	4150	Fieldbus M->S14 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.57	4160	Fieldbus M->S15 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.61	4170	Fieldbus M->S16 ipa		FBM2SIPA		0	0	20000	RW	EXP	

Setting of the parameter to associate with the bus channel. The default setting is 0, which means channel not active.

If the parameter to be connected is a **sorg** (source), the channel and parameter can also be associated by modifying the **sorg** parameter in its menu.

When setting a parameter, the format is also automatically set in the sys parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.2.2	4022	Fieldbus M->S1 sys		ENUM		Not assigned			RW	EXP	
6.2.6	4032	Fieldbus M->S2 sys		ENUM		Not assigned			RW	EXP	
6.2.10	4042	Fieldbus M->S3 sys		ENUM		Not assigned			RW	EXP	
6.2.14	4052	Fieldbus M->S4 sys		ENUM		Not assigned			RW	EXP	
6.2.18	4062	Fieldbus M->S5 sys		ENUM		Not assigned			RW	EXP	
6.2.22	4072	Fieldbus M->S6 sys		ENUM		Not assigned			RW	EXP	
6.2.26	4082	Fieldbus M->S7 sys		ENUM		Not assigned			RW	EXP	
6.2.30	4092	Fieldbus M->S8 sys		ENUM		Not assigned			RW	EXP	
6.2.34	4102	Fieldbus M->S9 sys		ENUM		Not assigned			RW	EXP	
6.2.38	4112	Fieldbus M->S10 sys		ENUM		Not assigned			RW	EXP	
6.2.42	4122	Fieldbus M->S11 sys		ENUM		Not assigned			RW	EXP	
6.2.46	4132	Fieldbus M->S12 sys		ENUM		Not assigned			RW	EXP	
6.2.50	4142	Fieldbus M->S13 sys		ENUM		Not assigned			RW	EXP	
6.2.54	4152	Fieldbus M->S14 sys		ENUM		Not assigned			RW	EXP	
6.2.58	4162	Fieldbus M->S15 sys		ENUM		Not assigned			RW	EXP	
6.2.62	4172	Fieldbus M->S16 sys		ENUM		Not assigned			RW	EXP	

Setting of the format of the datum received on the channel. When the src parameter is programmed, the format is automatically programmed on the relative sys. If the src parameter is reset to null, the format does not change. The value of the format can be selected from the following list, according to the parameter selected as the source:

- 0 Not assigned
- 1 Count 16
- 2 Count 32
- 3 Fill 16
- 4 Fill 32
- 5 Mdplc 16
- 6 Mdplc 32
- 7 Eu
- 8 Eu float
- 9 Par 16
- 10 Par 32

If set to **0** the channel is not assigned.  
 If set to **1** the datum is assigned a 16-bit count.  
 If set to **2** the datum is assigned a 32-bit count.  
 If set to **3** 16 bits on the channel are reserved for the datum, not used.  
 If set to **4** 32 bits on the channel are reserved for the datum, not used.  
 If set to **5** the datum is assigned a 16-bit count used by MDPLC.  
 If set to **6** the datum is assigned a 32-bit count used by MDPLC.  
 If set to **7** the datum is assigned engineering units on a 16-bit integer.  
 If set to **8** the datum is assigned engineering units on a 32-bit integer.  
 If set to **9**, the datum is assigned a 16-bit integer engineering unit format not in real time (5-10ms)  
 If set to **10** the datum is assigned a 32-bit integer engineering unit format or float format if the associated parameter is a float-type parameter not in real time (5-10ms)

**Note!**

If the sys parameter is not assigned, none of the subsequent fieldbus channels are read, even if programmed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.2.3	4024	Fieldbus M->S1 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.7	4034	Fieldbus M->S2 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.11	4044	Fieldbus M->S3 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.15	4054	Fieldbus M->S4 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.19	4064	Fieldbus M->S5 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.23	4074	Fieldbus M->S6 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.27	4084	Fieldbus M->S7 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.31	4094	Fieldbus M->S8 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.35	4104	Fieldbus M->S9 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.39	4114	Fieldbus M->S10 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.43	4124	Fieldbus M->S11 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.47	4134	Fieldbus M->S12 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.51	4144	Fieldbus M->S13 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.55	4154	Fieldbus M->S14 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.59	4164	Fieldbus M->S15 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.63	4174	Fieldbus M->S16 mon		INT32	32BIT	0	0	0	R	EXP	

The value received from the bus is displayed. This parameter must be associated with the src parameter to enable the **M->S** channel.

The user may modify the **M->S** and by **S->M** sys parameters. The consistency of the sys with the parameter assigned to the channel is checked.

**A Fieldbus M->S X Mon parameter can only be assigned to a single “src”. If assigned to more than one src, an error signal is generated during fieldbus initialization.**

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.2.4	4026	Fieldbus M->S1 div		FLOAT		1	1	1000	RW	EXP	
6.2.8	4036	Fieldbus M->S2 div		FLOAT		1	1	1000	RW	EXP	
6.2.12	4046	Fieldbus M->S3 div		FLOAT		1	1	1000	RW	EXP	
6.2.16	4056	Fieldbus M->S4 div		FLOAT		1	1	1000	RW	EXP	
6.2.20	4066	Fieldbus M->S5 div		FLOAT		1	1	1000	RW	EXP	
6.2.24	4076	Fieldbus M->S6 div		FLOAT		1	1	1000	RW	EXP	
6.2.28	4086	Fieldbus M->S7 div		FLOAT		1	1	1000	RW	EXP	
6.2.32	4096	Fieldbus M->S8 div		FLOAT		1	1	1000	RW	EXP	
6.2.36	4106	Fieldbus M->S9 div		FLOAT		1	1	1000	RW	EXP	
6.2.40	4116	Fieldbus M->S10 div		FLOAT		1	1	1000	RW	EXP	
6.2.44	4126	Fieldbus M->S11 div		FLOAT		1	1	1000	RW	EXP	
6.2.48	4136	Fieldbus M->S12 div		FLOAT		1	1	1000	RW	EXP	
6.2.52	4146	Fieldbus M->S13 div		FLOAT		1	1	1000	RW	EXP	
6.2.56	4156	Fieldbus M->S14 div		FLOAT		1	1	1000	RW	EXP	
6.2.60	4166	Fieldbus M->S15 div		FLOAT		1	1	1000	RW	EXP	
6.2.64	4176	Fieldbus M->S16 div		FLOAT		1	1	1000	RW	EXP	

the corresponding channel in EU and EU\_float exchange mode. The parameter value is used by the drive as the divider of the incoming datum, so that a number with decimal digits can be transferred.

**Note!**

You must check the size in bits of the datum that is sent to make sure that the maximum value in bits fits in a 16-bit integer. For example, if specifying the divider as "Fieldbus M->Sn div" = 1000, the maximum value that can be used for the exchanged datum is 32.768 (32768/1000).

Example : **Div M->Sx fieldbus** = 10, **M->S1 fieldbus par** = **Ramp ref src 1**, **Sys M->S1 fieldbus** = **EU**. If the PLC sends the decimal value 1000 on the first word the value of **ramp ref 1** on the drive is  $1000/10 = 100$ .

## 6.3 BUS CAMPO S2M

Parameters visible only with PAR 4000 Communication mode = (1) CANopen.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.3.1	4180	Fieldbus S->M1 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.5	4190	Fieldbus S->M2 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.9	4200	Fieldbus S->M3 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.13	4210	Fieldbus S->M4 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.17	4220	Fieldbus S->M5 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.21	4230	Fieldbus S->M6 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.25	4240	Fieldbus S->M7 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.29	4250	Fieldbus S->M8 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.33	4260	Fieldbus S->M9 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.37	4270	Fieldbus S->M10 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.41	4280	Fieldbus S->M11 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.45	4290	Fieldbus S->M12 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.49	4300	Fieldbus S->M13 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.53	4310	Fieldbus S->M14 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.57	4320	Fieldbus S->M15 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.61	4330	Fieldbus S->M16 ipa		FBS2MIPA		0	0	20000	RW	EXP	

Setting of the parameter to associate with the bus channel. The default setting is 0, which means channel not active.

When setting a parameter, the format is also automatically set in the sys parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.3.2	4182	Fieldbus S->M1 sys		ENUM		Not assigned			RW	EXP	
6.3.6	4192	Fieldbus S->M2 sys		ENUM		Not assigned			RW	EXP	
6.3.10	4202	Fieldbus S->M3 sys		ENUM		Not assigned			RW	EXP	
6.3.14	4212	Fieldbus S->M4 sys		ENUM		Not assigned			RW	EXP	
6.3.18	4222	Fieldbus S->M5 sys		ENUM		Not assigned			RW	EXP	
6.3.22	4232	Fieldbus S->M6 sys		ENUM		Not assigned			RW	EXP	
6.3.26	4242	Fieldbus S->M7 sys		ENUM		Not assigned			RW	EXP	
6.3.30	4252	Fieldbus S->M8 sys		ENUM		Not assigned			RW	EXP	
6.3.34	4262	Fieldbus S->M9 sys		ENUM		Not assigned			RW	EXP	
6.3.38	4272	Fieldbus S->M10 sys		ENUM		Not assigned			RW	EXP	
6.3.42	4282	Fieldbus S->M11 sys		ENUM		Not assigned			RW	EXP	
6.3.46	4292	Fieldbus S->M12 sys		ENUM		Not assigned			RW	EXP	
6.3.50	4302	Fieldbus S->M13 sys		ENUM		Not assigned			RW	EXP	
6.3.54	4312	Fieldbus S->M14 sys		ENUM		Not assigned			RW	EXP	
6.3.58	4322	Fieldbus S->M15 sys		ENUM		Not assigned			RW	EXP	
6.3.62	4332	Fieldbus S->M16 sys		ENUM		Not assigned			RW	EXP	

Setting of the format of the datum sent to the channel. When the src parameter is programmed, the format is programmed as EU or MDPLC 16. If the src parameter is reset to null, the datum format does not change. The value of the format can be selected from the following list:

- 0 Not assigned
- 1 Count 16
- 2 Count 32
- 3 Fill 16
- 4 Fill 32
- 5 Mdplc 16
- 6 Mdplc 32
- 7 EU
- 8 EU float
- 9 Par 16
- 10 Par 32

If set to 0 the channel is not assigned.

If set to **1** the datum is assigned a 16-bit count.  
 If set to **2** the datum is assigned a 32-bit count.  
 If set to **3** 16 bits on the channel are reserved for the datum, not used.  
 If set to **4** 32 bits on the channel are reserved for the datum, not used.  
 If set to **5** the datum is assigned a 16-bit count used by MDPLC.  
 If set to **6** the datum is assigned a 32-bit count used by MDPLC.  
 If set to **7** the datum is assigned engineering units on a 16-bit integer.  
 If set to **8** the datum is assigned engineering units on a 32-bit integer.  
 If set to **9**, the datum is assigned a 16-bit integer engineering unit format not in real time (5-10ms).  
 If set to **10** the datum is assigned a 32-bit integer engineering unit format or float format if the associated parameter is a float-type parameter not in real time (5-10ms).

**Note!**

If the sys parameter is not assigned, none of the subsequent channels are transferred to the fieldbus, even if programmed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.3.3	4184	Dig Fieldbus S->M1		INT32	32BIT	0	0	0	RW	EXP	
6.3.7	4194	Dig Fieldbus S->M2		INT32	32BIT	0	0	0	RW	EXP	
6.3.11	4204	Dig Fieldbus S->M3		INT32	32BIT	0	0	0	RW	EXP	
6.3.15	4214	Dig Fieldbus S->M4		INT32	32BIT	0	0	0	RW	EXP	
6.3.19	4224	Dig Fieldbus S->M5		INT32	32BIT	0	0	0	RW	EXP	
6.3.23	4234	Dig Fieldbus S->M6		INT32	32BIT	0	0	0	RW	EXP	
6.3.27	4244	Dig Fieldbus S->M7		INT32	32BIT	0	0	0	RW	EXP	
6.3.31	4254	Dig Fieldbus S->M8		INT32	32BIT	0	0	0	RW	EXP	
6.3.35	4264	Dig Fieldbus S->M9		INT32	32BIT	0	0	0	RW	EXP	
6.3.39	4274	Dig Fieldbus S->M10		INT32	32BIT	0	0	0	RW	EXP	
6.3.43	4284	Dig Fieldbus S->M11		INT32	32BIT	0	0	0	RW	EXP	
6.3.47	4294	Dig Fieldbus S->M12		INT32	32BIT	0	0	0	RW	EXP	
6.3.51	4304	Dig Fieldbus S->M13		INT32	32BIT	0	0	0	RW	EXP	
6.3.55	4314	Dig Fieldbus S->M14		INT32	32BIT	0	0	0	RW	EXP	
6.3.59	4324	Dig Fieldbus S->M15		INT32	32BIT	0	0	0	RW	EXP	
6.3.63	4334	Dig Fieldbus S->M16		INT32	32BIT	0	0	0	RW	EXP	

If associated with the relative src, the value of this parameter is sent to the bus.

The user may modify the M->S and by S->M sys parameters. The consistency of the sys with the parameter assigned to the channel is checked.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.3.4	4186	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.8	4196	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.12	4206	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.16	4216	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.20	4226	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.24	4236	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.28	4246	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.32	4256	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.36	4266	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.40	4276	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.44	4286	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.48	4296	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.52	4306	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.56	4316	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.60	4326	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.64	4336	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	

The “**Fieldbus S->Mx mul**” parameters are multipliers that the drive applies to the datum before sending it to the bus. It is therefore possible to increase the resolution of some values read in EU and EU\_float mode, also using decimal digits.

**Note!**

The drive does not check that the multiplied parameter expressed in bits fits in a 16-bit integer. You must make sure that the multiplier is compatible with the maximum value of the exchanged parameter and that it does not exceed the maximum size of 32768.

Example: **Fieldbus S->Mx mul = 10, S->M1 fieldbus par = Motor speed, Sys S->M1 fieldbus = EU.**

If the motor is running at 100 rpm, the PLC reads the value  $100 * 10 = 1000$  on the first word that is exchanged.


## 6.4 WORD COMP

Parameters visible only with PAR 4000 **Communication mode** = (1) CANopen.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.4.1	4400	Word bit0 src		LINK	16BIT_L	6000			RW	EXP	
6.4.2	4402	Word bit1 src		LINK	16BIT_L	6000			RW	EXP	
6.4.3	4404	Word bit2 src		LINK	16BIT_L	6000			RW	EXP	
6.4.4	4406	Word bit3 src		LINK	16BIT_L	6000			RW	EXP	
6.4.5	4408	Word bit4 src		LINK	16BIT_L	6000			RW	EXP	
6.4.6	4410	Word bit5 src		LINK	16BIT_L	6000			RW	EXP	
6.4.7	4412	Word bit6 src		LINK	16BIT_L	6000			RW	EXP	
6.4.8	4414	Word bit7 src		LINK	16BIT_L	6000			RW	EXP	
6.4.9	4416	Word bit8 src		LINK	16BIT_L	6000			RW	EXP	
6.4.10	4418	Word bit9 src		LINK	16BIT_L	6000			RW	EXP	
6.4.11	4420	Word bit10 src		LINK	16BIT_L	6000			RW	EXP	
6.4.12	4422	Word bit11 src		LINK	16BIT_L	6000			RW	EXP	
6.4.13	4424	Word bit12 src		LINK	16BIT_L	6000			RW	EXP	
6.4.14	4426	Word bit13 src		LINK	16BIT_L	6000			RW	EXP	
6.4.15	4428	Word bit14 src		LINK	16BIT_L	6000			RW	EXP	
6.4.16	4430	Word bit15 src		LINK	16BIT_L	6000			RW	EXP	

Selection of the origin (source) of the signal to be used for coding in **Word comp**. This function allows the user to compose a single word composed of 16 signals, each of which can be selected from among those listed in the “**L\_DIGSEL1**” selection list”.

The values of the sectioned sizes are converted into a single word.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.4.17	4432	Monitor comp mon		UINT32	16BIT_L	0	0	0	R	EXP	

The hexadecimal value of the **Word comp** output is displayed.

## 6.5 WORD DECOMP


Parameters visible only with PAR 4000 Communication mode = (1) CANopen.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.5.1	4450	Dig word decomp		UINT32	16BIT_L	0	0	0	RW	EXP	

Setting of the digital input decoded by the “Word decomp” block.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.5.2	4452	Word decomp src		LINK	16BIT_L	65535			RW	EXP	

Selection of the origin (source) of the word to be decoded by the “Word decomp” block. Each bit that is part of the word to be decoded is associated with the output channel of the “Word decomp” block. The variables that can be used for this function can be selected from among those listed in the “L\_WDECOMP” selection list”.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.5.3	4454	Bit0 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.4	4456	Bit1 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.5	4458	Bit2 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.6	4460	Bit3 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.7	4462	Bit4 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.8	4464	Bit5 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.9	4466	Bit6 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.10	4468	Bit7 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.11	4470	Bit8 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.12	4472	Bit9 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.13	4474	Bit10 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.14	4476	Bit11 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.15	4478	Bit12 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.16	4480	Bit13 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.17	4482	Bit14 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.18	4484	Bit15 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	

The single bits that make up the selected word are displayed.

## 6.6 NETWORK AND ACCESS

To enable password protection for access levels, change parameter PAR 568 **Enable password** to “ON”.

The user will then be asked to enter the password for their current access level; if the password has not been changed, its default value must be entered (visible in the DEFAULT column of the parameter description), then the user will be asked to enter a new password, which must be at least 8 characters long and alphanumeric.

For password recovery in the event of loss, see PAR 7200 **Password recovery**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>6.6.1</b>	<b>9610</b>	<b> Readonly Username</b>		STRING16		readonly	0	0	R	EXP	FVSY
Username assigned to the “ Readonly ” access level.											
<b>6.6.2</b>	<b>9626</b>	<b> Easy Username</b>		STRING16		easy	0	0	R	EXP	FVSY
Username assigned to the “ Easy ” access level.											
<b>6.6.3</b>	<b>9634</b>	<b> Easy Password</b>		STRING16		easy	0	0	RW	EXP	FVSY
Password used to access the “ Easy ” level.											
<b>6.6.4</b>	<b>9642</b>	<b> Interm Username</b>		STRING16		interm	0	0	R	EXP	FVSY
Username assigned to the “ INT ” (Intermediate) access level.											
<b>6.6.5</b>	<b>9650</b>	<b> Interm Password</b>		STRING16		interm	0	0	RW	EXP	FVSY
Password used to access the “ INT ” (Intermediate) access level.											
<b>6.6.6</b>	<b>9658</b>	<b> Expert Username</b>		STRING16		expert	0	0	RW	EXP	FVSY
Username assigned to the “ Expert ” access level.											
<b>6.6.7</b>	<b>9666</b>	<b> Expert Password</b>		STRING16		expert	0	0	RW	EXP	FVSY
Password used to access the “ Expert ” level.											
<b>6.6.8</b>	<b>9544</b>	<b> WiFi Fw version</b>		UINT32		0	0	0	R	EXP	
The firmware version operating in the WiFi Drive Link module is displayed.											
<b>6.6.9</b>	<b>9546</b>	<b> WiFi S/N</b>		UINT32		0	0	0	R	EXP	
The WiFi Drive Link module serial number is displayed.											
<b>6.6.10</b>	<b>9528</b>	<b> WiFi Network name</b>		STRING16		WEG wifi	0	0	R	EXP	
Name of the WiFi network generated by the Wi-Fi Drive Link dongle.											
<b>6.6.11</b>	<b>9536</b>	<b> WiFi Network Pass</b>		STRING16		0123456789	0	0	R	EXP	
Password used to connect to the network generated by the Wi-Fi Drive Link dongle.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>6.6.12</b>	<b>9554</b>	<b>WiFi Network Channel</b>		UINT16		11	0	12	R	EXP	
Wi-Fi network channel.											
<b>6.6.13</b>	<b>9556</b>	<b>IP Address set</b>		UINT32		169.254.10.10	0	0	RW	EXP	FVSY
Enters the network IP address.											
<b>6.6.14</b>	<b>9558</b>	<b>IP Netmask set</b>		UINT32		255.255.0.0	0	0	RW	EXP	FVSY
Enters the subnet IP address.											
<b>6.6.15</b>	<b>9560</b>	<b>IP Gateway set</b>		UINT32		0.0.0.0	0	0	RW	EXP	FVSY
Enters the gateway IP address.											
<b>6.6.16</b>	<b>9564</b>	<b>IP Netmask</b>		UINT32		255.255.0.0	0	0	R	EXP	FVSY
Subnet IP address in use.											
<b>6.6.17</b>	<b>9566</b>	<b>IP Gateway</b>		UINT32		0.0.0.0	0	0	R	EXP	FVSY
Gateway IP address in use.											
<b>6.6.18</b>	<b>9608</b>	<b>IP Assignment</b>		ENUM		Static	0	0	RW	EXP	FVSY
IP address assignment.											
<b>0</b> DHCP											
<b>1</b> Static											

**DHCP:** the drive IP address is assigned by the network DHCP server. If no DHCP server is present, the drive waits for about 3 min, after which it takes the static address configured via parameter (PAR 9556 IP Address set, default = 169.254.10.10) as the IP address. Typical use: drive connected to a network with several devices.

**Static:** The drive IP address is assigned via parameter PAR 9556 IP Address set, default = 169.254.10.10. Typical use: drive connected directly to the PC.

## 7 MOTOR DATA

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.1	392	<b>Select motor</b>		BIT		0	0	1	RWZ	INT	FVSY
This parameter is used to load motor data into the drive that are part of a library (.mot file extension). These files must be saved on a USB memory device in a folder named "ADL500MT". Once the memory device has been connected to the drive's USB port, simply select the motor whose parameters are to be imported from the appropriate menu. Contact WEG Technical Assistance for further information or to request the files.											
The motor data libraries are already available in the WEG DriveLabs configurator in the <b>Wizard / Setup-Wizard</b> menu.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.2	2000	<b>Rated voltage</b>	V	FLOAT		SIZE	150	480	RWZ	INT	FVSY
Set the motor rated voltage as indicated on the data plate. This is the voltage the drive must supply at the motor rated frequency.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.3	2002	<b>Rated current</b>	A	FLOAT		SIZE	1	1500	RWZ	INT	FVSY
The motor rated current at its rated power (kW / Hp) and voltage (indicated on the motor data plate).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.4	2004	<b>Rates speed</b>	rpm	FLOAT		SIZE	10	32000	RWZ	INT	FVY
Rated speed of the motor with full load in rpm. In some motors the asynchronous speed (e.g. 1500 rpm for a 4-pole motor) and slippage, i.e. the loss of revolutions between the motor idling condition and the rated load condition (e.g. 80 rpm), is indicated. Enter the following: synchronous speed - slippage.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.5	2006	<b>Rated frequency</b>	Hz	FLOAT		SIZE	1	1000	RWZ	INT	FVS
Rated frequency of the motor expressed in Hz.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.6	2008	<b>CPole pairs</b>		UINT16		SIZE	1	60	RWZ	INT	FVSY
Motor pole pairs. The number of motor pole pairs is calculated using the motor plate data and applying the following formula:											
$p = \frac{60 [s] \times f [Hz]}{Vn [rpm]}$											
Where: p = motor pole pairs; f = motor rated frequency (PAR 2006)											
nN = motor rated speed (PAR 2004).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.7	2010	<b>Rated power</b>	kW	FLOAT		SIZE	0.1	1500	RWZ	INT	FVS
Motor power factor, as indicated on the data plate ( $\cos \varphi$ ). This parameter is not always present on the motor data plate: in that case use the default value present in the drive.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.8	2012	<b>Rated power factor</b>		FLOAT		SIZE	0.6	0.95	RWZ	INT	FVS
Motor power factor, as indicated on the data plate ( $\cos \varphi$ ). This parameter is not always present on the motor data plate: in that case use the default value present in the drive.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.9	2014	<b>Torque constant</b>	Nm/A	FLOAT		SIZE	0	120	RWZ	INT	Y
Setting of the ratio between the torque generated and the rated current of the motor.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.10	2020	<b>Take parameters</b>	BIT			0	0	1	RWZ	INT	FVSY
Saves the set motor data in the drive. This command must be supplied last after entering the appropriate values of all the parameters listed above. This means calculating the normalization factors (a) and estimated values for the motor parameters (b). The drive cannot be started until the <b>Take parameters</b> command has been set.											

Use of the Startup wizard is recommended.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.11	2022	<b>Autotune rotation</b>		BIT		0	0	1	RWZ	INT	FVS

Performs self-tuning in rotation: the motor must be uncoupled from the load or the transmission must not represent more than 5% of the load. This procedure allows the greatest degree of accuracy in measuring the motor parameters.

To execute the command you must first open the hardware enabling. Self-tuning can now be performed.

Close the hardware enabling. At the end of the self-tuning procedure, open the hardware enabling.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.12	2024	<b>Autotune still</b>		BIT		0	0	1	RWZ	INT	FVSY

Performs self-tuning with the motor coupled to the transmission. The self-tuning procedure may cause limited rotation of the motor shaft. To perform self-tuning, follow the procedure described for the previous parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.13	2030	<b>Autotune status</b>		ENUM		Required			R	INT	FVSY

Indication of the status of parameter saving.

0 Required

1 Done

The parameter displays the **Required** message when the motor parameters that have been entered need to be saved. When they have been saved the parameter indicates **Done**.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.14	2050	<b>Measured Rs</b>	ohm	FLOAT		0	0	200	RW	EXP	FVSY

Measured value of the rotor resistance.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.15	2052	<b>Measured DTL</b>	V	FLOAT		0	0	100	RW	EXP	FVY

Measured value of dead time compensation.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.16	2054	<b>Measured DTS</b>	V/A	FLOAT		0	0	100	RW	EXP	FVSY

Measured compensation gradient value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.17	2056	<b>Measured Lsig</b>	mH	FLOAT		0.1	0.1	200	RW	EXP	FVS

Leakage inductance value measured (Only for asynchronous motors).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.18	2058	<b>Measured LsSyn</b>	mH	FLOAT		0.1	0.1	200	RW	EXP	Y

Stator inductance value measured (Only for synchronous motors).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.19	2060	<b>Measured LsMin Syn</b>	mH	FLOAT		0.1	0.1	200	RW	EXP	Y

Minimum stator leakage value measured (Only for synchronous motors).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.20	2062	<b>Measured ImN</b>	A	FLOAT		CALCF	0	1000	RW	EXP	FVS

Measured value of the rated magnetising current.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.21	2066	<b>Measured FlxN</b>	Wb	FLOAT		CALCF	0	10	RW	EXP	FVS

Measured flux saturation value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.22	2076	<b>Measured Rr</b>	ohm	FLOAT		CALCF	0	200	RW	EXP	FVS

Measured rotor resistance value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.23	2078	<b>Take tune paramenters</b>		BIT		0	0	1	RW	INT	FVSY

Saves the motor data calculated by the self-tuning procedure in the drive.

## 8 ENCODER

### Note!

The parameters of this menu will be available depending on the selection of parameter 2132 Encoder mode.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.1	2100	Encoder pulses	ppr	UINT16		1024	4	16384	RWZ	INT	

Setting of the number of feedback encoder impulses. During setup, for incremental sinusoidal encoders + absolute EnDat, encoder absolute EnDat Full digital and BiSS encoders this value is set automatically by reading the number of incremental encoder impulses.

With the EnDat Full digital Encoder, the value set automatically may be below the minimum.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.2	2102	Encoder supply	V	FLOAT		5.2	5.2	20.0	RW	INT	FVSY

Sets the encoder supply voltage. The min and max values will be changed depending on the selection of parameter 2104 **Encoder input config** as follows:

PAR 2104 Encoder input config	Def	Min	Max
[0] HTL	5.2 V	5.2 V	20.0 V
[1] TTL	5.2 V	5.2 V	6.0 V

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.3	2104	Encoder input config		ENUM		TTL			RWZ	INT	

Setting of the input configuration of the incremental digital encoder, TTL or HTL.

- 0 HTL
- 1 TTL

This parameter is automatically set to HTL when the value set in the **Encoder supply** parameter is more than 6.0V.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.4	2106	Encoder repetition		ENUM		No division			RWZ	INT	

Setting of the divider to apply to the encoder repeat output frequency.

- 0 No division
- 1 Divide 2
- 2 Divide 4
- 3 Divide 8
- 4 Divide16
- 5 Divide 32
- 6 Divide 64

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.5	2108	Encoder signal Vpp	V	FLOAT		0.8	0.5	1.2	RWZ	INT	

Setting of the peak-to-peak voltage value of the encoder signal. Incremental sinusoidal encoders and absolute SinCos encoders normally produce signals with a peak-to-peak voltage of 1 Vpp. Due to loss of voltage along the cable, the value of the peak-to-peak voltage signal received by the feedback card could be lower, generating a **Speed fbk loss [22]** alarm.

This parameter can be used to set the peak-to-peak voltage value of the incremental sinusoidal encoders and absolute SinCos encoders on the input terminals of the feedback card.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.6	2110	Encoder signal check		ENUM		Check A-B			RWZ	EXP	

Configuration of which incremental digital encoder channels are to be controlled in order to process the **Speed fbk loss [22]** alarm signal.

- 1 Check A-B
- 2 Check A-B-Z

Set 1 to check for signal on channels A-B

Set 2 to check for signal on channels A-B-Z

If the application detects the absence of feedback the **Speed fbk loss [22]** is generated.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.7	2116	ENC signal Vpp inc	V	FLOAT		0	0	0	R	EXP	

Displays the Vpp signal of the incremental tracks of the connected encoder.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.8	2118	ENC signal Vpp abs	V	FLOAT		0	0	0	R	EXP	

Displays the Vpp signal of the absolute tracks of the connected encoder (only if a SinCos encoder is connected).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.9	2130	Encoder direction		ENUM		Not inverted			RWZ	INT	

Setting of the sign of the information obtained from the incremental or absolute encoder.

- 0 Not inverted
- 1 Inverted

By setting 0 the encoder feedback signals are not inverted.

By setting 1 the encoder feedback signals are inverted

According to international standards, positive references are associated with clockwise motor rotation, seen from the control side (shaft). To ensure correct operation, the regulation algorithms ensure that positive speed references correspond to positive speed measurements.

If the motor pulley is mounted on the side opposite the command side, it will turn in an anticlockwise direction when the speed is positive: to make the pulley turn in a clockwise direction, the motor phase sequence is modified, which inverts the speed measurement sign. To restore the correct speed measurement sign, invert the incremental encoder A+ and A- signals and the absolute encoder Sin+ and Sin- signals on the encoder connections. The absolute part cannot be inverted with Endat and Hiperface absolute encoders.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.10	2132	Encoder mode		ENUM		None			RWZ	INT	FVSY

The drive has an integrated encoder card. The encoder mode can be selected in accordance with the following table:

- 0 None
- 1 Digital
- 2 Sinus
- 3 Sinus SINCOS
- 4 Sinus ENDAT
- 5 Sinus BISS
- 6 ENDAT
- 7 BiSS
- 8 Sinus SSI

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.11	2134	Encoder speed filter	ms	FLOAT		1.0	0.1	8.0	RW	EXP	

Setting of the time constant of the filter applied to the feedback encoder pulse reading. The parameter affects both the accuracy of the speed measurement and the dynamics obtainable in closed loop control. On the other hand, the use of a speed measurement filter introduces delays that do not permit high control loop dynamics. Low settings extend the regulation bandwidth but may accentuate any disturbance. The filter is applied to the speed reported in the **Encoder speed** (PAR 2150) parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.12	2136	Peripheral Encoder		BIT		0	0	1	RW	EXP	


- 0 No
- 1 Si

This parameter lets you select if the encoder is positioned on the tangent of the motor rotor

#### Note!

If peripheral encoder (option = 1) is selected, the parameter 4552 (SpdRefLoss activity) in the menu ALARM CONFIG must be set to "Disable drive". The motor setup uses the same procedure as for a standard brushless motor.

**Guidelines for configuring drive parameters in installations with a peripheral encoder, i.e., with the encoder positioned on the tangent of the motor rotor:**



Tachometric encoders can be replaced with digital incremental encoders, to be positioned on the tangent, by appropriately configuring the parameters shown below.

Menu	PAR	Description	UM	Type	Def	Min	Max	ACC	Liv	Vis.
8.1	2100	Encoder pulses	ppr	UINT16	1024	4	16384	RW	ESY	FVY
Configure the plate value of the incremental encoder used.										
8.9	2130	Encoder direction		ENUM	Not inverted	0	1	RW	INT	FV
The parameter must be configured to 0 or to 1 so that when the rotor turns clockwise the velocity reference value read at parameter 12210 is positive.										
8.10	2132	Encoder mode		ENUM	None	0	8	RW	INT	FVY
The parameter must be configured to "Digital F" (value 2)										
8.12	2136	Peripheral encoder		BIT	0.5	0.1	8.0	R	EXP	FVY
The parameter must be configured to 1.										
8.19	2184	Ext motor diam	mm	UINT16	1	1	65535	RW	EXP	FVY
Configure the value of the external diameter of the motor rotor (D).										
8.20	2186	Enc pulley diam	mm	UINT16	1	1	65535	RW	EXP	FVY
Configure the value of the diameter of the incremental encoder pulley (d).										
4.4.22	4552	SpdRefLoss activity		ENUM	Disable drive	0	4	RW	INT	FV
The parameter must be set to "Disable drive" (option 2)										

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.13	2150	Encoder speed	rpm	INT16	16BIT_H	0	0	0	R	ESY	

The motor speed measured by the incremental encoder is displayed, filtered by the PAR 2134 **Encoder speed filter** parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.14	2162	Encoder position	cnt	UINT16	16BIT_L	0	0	0	R	ESY	

The impulse count obtained from the incremental encoder reading is displayed: 1 encoder turn is equal to the value entered in Encoder pulses multiplied by 4.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.15	2164	Encoder abs position	cnt	UINT32	32BIT	0	0	0	R	EXP	

Displays the position of the absolute tracks read by the connected absolute encoder.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.16	2172	SpdFbkLoss code		UINT16		0	0	0	R	EXP	

The **Speed fbk loss** [22] alarm generated by an encoder fault is displayed. Each type of encoder generates the alarm differently (incremental signal error, absolute signal error, serial error), so this parameter is used to display information about the alarm that has been activated. In case of several concurrent causes, these are shown in this parameter.

Bit	Value	Name
0	0x01	CHA
1	0x02	CHB
2	0x04	CHZ
3	0x08	MOD_INCR
4	0x10	MOD_ABS
5	0x20	CRC_CKS_P
6	0x40	ACK_TMO
7	0x80	DT1_ERR
8	0x100	Setup Error
10..15		Free
16..31		Encoder-dependent

For further details reference should be made to the description of the **Speed fbk loss [22]** alarm and the chapter 10.2 Speed fbk loss alarm according to the type of feedback (ADL500 HW+QS manual).

**Note!**

For the correct interpretation of the cause of the alarm trigger, it is necessary to transform the hex code indicated in parameter SpdFbkLoss code, PAR 2172 , in the corresponding binary and verify in the encoder table that the active bits and related description are used.

Example with encoder Endat:

PAR 2172 = A0H (hex value)

In the table "Speed fbk loss [22] alarm with absolute encoder EnDat" A0 is not indicated in the value column.

A0 should be contemplated as a bitword with meaning A0 -> 10100000 -> bit 5 and bit 7 . The following causes simultaneously intervene:

Bit 5 = 20H Cause: the SSI signal interferences cause an error in the CKS or parity

Bit 7 = 80H Cause: The encoder has detected an incorrect operation and communicates it to the converter through the Error bit. Bits 16..31 present the type of incorrect encoder operation detected.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.17	2174	<b>Endat error code</b>		UINT16		0	0	0	R	EXP	

Displays the internal error code of the endat encoder in the event of a **Speed fbk loss [22]** alarm with code "DT1 error". See the ADL500 HW + SW manual, section "10.2 Speed fbk loss alarm according to the type of feedback".

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.18	2176	<b>Encoder sync mode</b>		UINT16		1	0	3	RWZ	EXP	Y

Setting of the rate of synchronisation between incremental and absolute tracks.

If set to **0** synchronisation is only performed once at power on.

If set to **1** synchronisation is performed each time the start command is entered.

If set to **2** synchronisation is performed every 128 ms.

If set to **3** synchronisation is always performed, using the absolute section.

This function can only be used with absolute encoders and the default, minimum and maximum values are modified according to the type of encoder.

Type of encoder option	Def	Min	Max
Enc 1	1	0	3
Enc 2	1	0	3
Enc 3	1	0	3
Enc 4	1	0	3
Enc 5	1	0	1

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.19	2184	<b>Ext motor diam</b>	mm	UINT16		1	1	65535	RWZ	EXP	

This is the diameter D of the motor rotor.

It must be set only if you use a peripheral encoder (PAR 2136).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.20	2186	<b>Enc pulley diam</b>	mm	UINT16		1	1	65535	RWZ	EXP	

This is the diameter d of the incremental encoder pulley. It must be set only if you use a peripheral encoder (PAR 2136).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.21	2190	Autophase rot		BIT		0	0	1	RWZ	EXP	Y

This parameter can be set to perform encoder phasing with the motor turning: the motor must be free to turn and with no load applied (the brake must be released). This procedure allows the greatest degree of accuracy.

In order to execute the command:

- open the enable command (Enable).
- set this parameter to 1.
- press Enter to confirm (if sending commands from the keypad).
- when asked to close the enabling contact apply the command to terminal 9 (Enable).
- at the end of the procedure you will be asked to re-open the enabling contact (Enable) to confirm completion.

**Note!**

See section "A.2.1 Rotation phasing" for further information.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.22	2192	Autophase still		BIT		0	0	1	RWZ	EXP	Y

This parameter can be set to perform encoder phasing without the motor running: the brake must be closed.

In order to execute the command:

- open the enable command (Enable).
- set this parameter to 1.
- press Enter to confirm.
- when prompted to close the enabling contact apply the command to terminal 9 (Enable).
- at the end of the procedure you will be asked to open the enabling contact (Enable) again to confirm completion.

**Note!**

See section "A.2.2 Static phasing" for further information.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.23	2748	Still phasing mode		ENUM		Mode 1			RW	EXP	Y

You can select two different static phasing methods based on the different characteristics of synchronous motors on the market. We recommend using **Mode 1** as the first option. If **Mode 1** does not run correctly, the motor (due to its constructive characteristics) requires a different mode (i.e., **Mode 2**).

Mode 2 is always required when the magnets are NOT on the rotor surface (immersed).

- |          |        |  |
|----------|--------|--|
| <b>0</b> | Mode 1 | This is the most versatile method and is suitable for most motors. |
| <b>1</b> | Mode 2 | Method developed for motors featuring strong anisotropy.           |

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.24	2194	Phasing repeat		ENUM		First enable			RW	EXP	Y

The encoder phasing procedure is run as follows (if the encoder is not absolute):

- |          |              |   |
|----------|--------------|---|
| <b>1</b> | First enable | first time enable is received after start                     |
| <b>2</b> | Each enable  | each time the drive receives an enable signal                 |
| <b>3</b> | Periodically | periodically at nth enable signal configurable with PAR 2198. |

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.25	9920	Autophase still type		ENUM		Standard			RW	EXP	Y

This parameter affects the parameters used during timing from standstill (still):

- |                 |   |
|-----------------|---|
| <b>Standard</b> | allows timing operation for most engines.   |
| <b>Reserved</b> | is used for specific motors and can be used after communication with the support team of WEG Automation Europe. |

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.26	9922	Autophase Imax gain		FLOAT		1	0.01	1.5	RW	EXP	Y

This parameter allows you to change the injected current amplitude during timing from standstill (still).

The parameter's default value allows the timing of most PM motors.

In the case of motors with a high magnetic saturation value, the recognition procedure may be less sensitive and lead to incorrect recognition of the motor pole direction. In such cases, it is possible to change the value of this parameter,

typically by increasing it, to enable correct timing.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.27	2198	Autophase cnt enable		UINT16		2	2	65535	RWZ	EXP	Y
Defines the number of enable signals (trips) after which encoder phasing must start.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.28	7100	BiSS encoder type		UINT16		0	0	0	R	EXP	


At power-on, it is checked whether the connected encoder has the incremented tracks and if it has an electronic data sheet (EDS).

The result of check is shows inside this parameter. In case of different value you have to perform the procedure to convert the drive.

Code	Description	Serial Error 0 = Serial Ok 1 = Serial Nok	BP3 0 = No BP3 1 = Yes BP3	Incremental signal 0 = No incremental signal 1 = Yes incremental signal
0	Serial Ok - No BP3 – No incremental signal	0	0	0
1	Serial Ok - No BP3 – Yes incremental signal	0	0	1
2	Serial Ok - Yes BP3 – No incremental signal	0	1	0
3	Serial Ok - Yes BP3 – Yes incremental signal	0	1	1
4	Serial Nok - No BP3 – No incremental signal	1	0	0
5	Serial Nok - No BP3 – Yes incremental signal	1	0	1
6	Serial Nok - Yes BP3 – No incremental signal	1	1	0
7	Serial Nok - Yes BP3 – Yes incremental signal	1	1	1

If the connected encodes has EDS than the communication channel is configured automatically.

If the connected encoder does not have EDS than the communication channel must be configured manually.



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.29	7102	BiSS manufacturer		UINT16		0	0	0	R	EXP	

This parameter shows the Encoder **BiSS Manufacturer** found. Some possible value are:

Code	Manufacturer
0x0000 (0)	Not available
0x4B55 (19285)	Kuebler
0x4855 (18517)	Hengstler
0x4C69 (19561)	Lika
0x5265 (21093)	Renishaw
0x4853 (18515)	Hohner
Other	Unknow

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.30	7104	<b>BiSS clock freq</b>		UINT16		7	0	15	RW	EXP	

This parameter allows setting of the BiSS sensor frequency.

Code	Sensor frequency	Sensor period
1	6,25 MHz	0,160 $\mu$ sec
2	4,16 MHz	0,240 $\mu$ sec
3	3,12 MHz	0,320 $\mu$ sec
4	2,50 MHz	0,400 $\mu$ sec
5	2,08 MHz	0,480 $\mu$ sec
6	1,78 MHz	0,560 $\mu$ sec
7	1,56 MHz	0,640 $\mu$ sec
8	1,38 MHz	0,724 $\mu$ sec
9	1,25 MHz	0,800 $\mu$ sec
10	1,13 MHz	0,884 $\mu$ sec
11	1,04 MHz	0,961 $\mu$ sec
12	0,96 MHz	1,041 $\mu$ sec
13	0,89 MHz	1,123 $\mu$ sec
14	0,83 MHz	1,204 $\mu$ sec
15	0,78 MHz	1,282 $\mu$ sec

The default value should guarantee the correct operating conditions with the most used encoders.

The rule to follow for a correct parameterization is show below.

The frame time is composed of three contributions:

Contributions	Typ Time	Min Time	Max Time
Processing time for single cycle data + Transmission delay	10 $\mu$ sec	0 $\mu$ sec	40 $\mu$ sec
Transmission data time $T = N \text{ Bit} * \text{"Sensor period"}$ $N \text{ Bit} = \text{BiSS data len} + \text{Crc(6)} + \text{Start}(1) + \text{Stop}(1)$			
Timeout BiSS TO_MAX	13 $\mu$ sec	0 $\mu$ sec	40 $\mu$ sec

The sum of the three contributions must be less than 100  $\mu$ sec.

If the sum of the three contributions exceeds 100  $\mu$ sec then the BiSS clock frequency must be increased.

i.e.:

**BiSS clock freq** = 7 = 0.640  $\mu$ sec

**BiSS data len** = 15

Contributions	Typ Time
Processing time for single cycle data + Transmission delay	10.00 $\mu$ sec
Transmission data time $T = N \text{ Bit} * \text{"Sensor period"}$ $N \text{ Bit} = \text{BiSS data len} + \text{Crc(6)} + \text{Start}(1) + \text{Stop}(1)$	14.74 $\mu$ sec
Timeout BiSS TO_MAX	13.00 $\mu$ sec
Total	37.74 $\mu$ sec

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.31	7106	<b>BiSS N bit ST</b>		UINT16		13	0	64	RW	EXP	

This parameter allows setting of bit Number for single turn data. This parameter is automatically setted in case of encoder with EDS. This parameter must be setted manually in case of encoder without EDS.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.32	7108	<b>BiSS N bit MT</b>		UINT16		0	0	64	RW	EXP	

This parameter allows setting of bit Number for multi turn data. This parameter is automatically setted in case of encoder with EDS. This parameter must be setted manually in case of encoder without EDS.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.33	7110	<b>BiSS data len</b>		UINT16		0	0	0	R	EXP	
This parameter shows the frame data length. This parameter is setted automatically.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.34	7112	<b>BiSS timeout</b>	us	FLOAT		13	0	65	RW	EXP	
This parameter allows setting the BiSS Timeout. This parameter is automatically setted in case of encoder with EDS. This parameter must bel setted manually in case of encoder without EDS. This parameter must be taken into account when checking whether the selected BiSS clock frequency guarantees correct timing.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.35	7114	<b>BiSS Crc polinomy</b>		UINT16		67	1	65535	RW	EXP	
This parameter allows setting the BiSS Crc polinomy. This parameter is automatically setted in case of encoder with EDS. This parameter must bel setted manually in case of encoder without EDS.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.36	7116	<b>BiSS data code</b>		ENUM		Binary			RW	EXP	
This parameter allows setting the BiSS data code format. <b>0</b> Binary <b>1</b> Gray											
Typically BiSS encoders use a binary data format. If you use an encoder with <b>Gray</b> data format, set <b>Gray</b> in this parameter.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.37	2178	<b>Abs offset memory</b>		ENUM		Drive memory			RW	EXP	
Only for Endat encoder. Selects the location where the phasing data is saved. <b>0</b> Drive memory <b>1</b> Encoder memory											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.38	7150	<b>SSI N bit ST</b>		UINT16		13	0	13	RW	EXP	
This parameter sets the number of position bits of SSI encoder.											
Menu	PAR	Descrizione	UM	Tipo	FB BIT	Def	Min	Max	Acc	Liv.	Vis.
8.39	7152	<b>SSI N bit MT</b>		UINT16		0	0	19	RW	EXP	
Number of bits for the single turn data (multiturn encoder only).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.40	7154	<b>SSI N bit TX</b>		UINT16		13	0	32	RW	EXP	
Setting of the length of the SSI package, defined as the number of clock cycles, in that the packages of the absolute SSI encoders available on the market vary in length from 13 to 25 bits.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.41	7156	<b>SSI data code</b>		ENUM		Gray			RW	EXP	
Data code. <b>0</b> Binary <b>1</b> Gray											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.42	2732	<b>Enc position offset</b>		INT16		0	0	0	RW	EXP	Y
Motor phasing position. This is calculated during the auto phasing procedure.											

## 9 SAFETY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
9.3	11252	Brake fbk A3 sel		ENUM		Null	-	-	RW	INT	FVY

Selection of the **Brake failure** alarm. In the default configuration the brake fault alarm function is disabled.

Setting of the source to enable between those available in the “**LiftInputAdICmd**” selection list.

- 1110 Dig input E mon
- 1210 Dig input 1 mon
- 1212 Dig input 2 mon
- 1214 Dig input 3 mon
- 1216 Dig input 4 mon
- 1218 Dig input 5 mon
- 1220 Dig input 6 mon
- 1222 Dig input 7 mon
- 1224 Dig input 8 mon
- 1230 Dig input 1x mon
- 1232 Dig input 2x mon
- 1234 Dig input 3x mon
- 1236 Dig input 4x mon
- 3702 Run cont mon
- 3706 Down cont mon
- 3708 Brake cont mon
- 3714 Door open mon
- 6000 Null
- 6002 One
- 8000 EBC SOK mon
- 8002 EBC Warning mon
- 8004 EBC Alarm mon
- 12250 B0 Lift decomp
- 12252 B1 Lift decomp
- 12254 B2 Lift decomp
- 12256 B3 Lift decomp
- 12258 B4 Lift decomp
- 12260 B5 Lift decomp
- 12262 B6 Lift decomp
- 12264 B7 Lift decomp
- 12266 B8 Lift decomp
- 12268 B9 Lift decomp
- 12270 B10 Lift decomp
- 12272 B11 Lift decomp
- 12274 B12 Lift decomp
- 12276 B13 Lift decomp
- 12278 B14 Lift decomp
- 12280 B15 Lift decomp

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
9.4	11268	Reset Brake Alarm		INT		0	-	-	RW	INT	FVY

Resets the **Brake feedback** alarm.

Reset procedure:

1. Open menu 5.10 LIFT ALARMS, and check that the **Brake feedback** alarm is on.
2. In the lift alarm menu, select parameter 11268 **Reset Brake Alarm** (default 0).
3. The system asks for a code, enter release code 5313.
4. Check again to see whether the **Brake feedback** alarm has been reset.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
9.5	11270	Threshold A3 A3	m	FLOAT		0.1	0	2	RW	INT	VY

When the brake is connected, the **Brake failure** alarm is activated if the movement (in metres) is more than the value set in parameter 11270 **Threshold A3**.

## 10 REGULATION MENU

### 10.1 SPEED REGULATION GAINS (SPEED REG GAINS)

#### Speed Reg Gains

This menu contains the parameters specific to the motor (synchronous or asynchronous) speed control loop illustrated in the figure.





Figure 11.1: Motor speed control loop block diagram



PAR 2794 SR-P gain at start; PAR 2796 SR-I gain at start; PAR 2752 SR-P gain low speed; PAR 2754 SR-I gain low speed; (1) Linear change of gains;

Figure 11.2: Adaptation of the control loop gains as a function of the speed reference

#### Torque Notch Filters

To attenuate possible resonance frequencies, in the 5...300Hz range, up to two cascade suppressor filters have been provided for. Both can be configured and enabled independently.




Figure 11.3: Suppressor filters in cascade

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.1	2240	Inerzia	$\text{kgm}^2$	FLOAT		0.8	0.001	1000	RW	INT	VSY
Specifies the actual value of the moment of inertia on the motor side. Based on the value defined in this parameter, the drive suitably sets the base gains of the Proportional + Integral controller of the speed control loop (PAR 2662 <b>SR-high speed thrsd</b> , PAR 2664 <b>SR-I time</b> ) to ensure stable operation.											
10.1.2	9702	Learning trip out	$\text{kgm}^2$	FLOAT		0	0	0	R	EXP	FVSY
Provides the value calculated by the Learning trip procedure (PAR 9720, menu 2 OPTIMIZ. WIZARD). At the end of the procedure, if successfully ending with the "Learning trip OK" message, this value is copied to parameter 2240 Inertia.											
10.1.3	2794	SR-P gain at start	%	FLOAT		150.0 (*)	0.0	400.0	RW	INT	VSY
Defines the level of proportional control exercised by the PI regulator during the start phase. In this initial phase the motor speed control loop must be sufficiently responsive to compensate for any load imbalance and thus counteract the roll-back effect. An excessive increase of this parameter may generate system vibrations or unstable behaviour. (*) Def: 150 = ASY FOC, 110 = SYN FOC											
10.1.4	2796	SR-I gain at start	%	FLOAT		110.0	0.0	400.0	RW	INT	VSY
Defines the level of integral control exercised by the PI regulator during the start phase. Increasing the value of this parameter improves the speed control response in compensating for any load imbalance when the brake is opened.											
10.1.5	2752	SR-P gain low speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
Defines the level of the proportional control exercised by the PI regulator for operating speeds below the minimum threshold defined in parameter PAR 2760 <b>SR-low speed thrsd</b> . For operating speeds above this threshold, the actual level of proportional action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2756 <b>SR-P gain high speed</b> . In the speed range between the thresholds defined in the PAR 2760 <b>SR-low speed thrsd</b> and the PAR 2762 <b>SR-high speed thrsd</b> parameters, the weight of the proportional action varies linearly with the speed.											
10.1.6	2754	SR-I gain low speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
Defines the level of the integral control exercised by the PI regulator for operating speeds below the minimum threshold defined in parameter PAR 2760 <b>SR-low speed thrsd</b> . For operating speeds above this threshold, the actual level of integral action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2758 <b>SR-I gain high speed</b> . In the speed range between the thresholds defined in the PAR 2760 <b>SR-low speed thrsd</b> and the PAR 2762 <b>SR-high speed thrsd</b> parameters, the weight of the proportional action varies linearly with the speed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.7	2756	<b>SR-P gain high speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
Defines the level of the proportional control action exercised by the PI regulator for operating speeds above the maximum threshold defined in parameter PAR 2762 <b>SR-high speed thrsd</b> .											
For operating speeds lower than this threshold, the actual level of proportional action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2752 <b>SR-P gain low speed</b> .											
In the speed range between the minimum and maximum thresholds defined in PAR 2760 <b>SR-low speed thrsd</b> and PAR 2762 <b>SR-high speed thrsd</b> parameters, the weight of the proportional action varies linearly with the speed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.8	2758	<b>SR-I gain high speed</b>	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
Defines the level of the integral control action exercised by the PI regulator for operating speeds above the maximum threshold defined in parameter PAR 2760 <b>SR-low speed thrsd</b> .											
For operating speeds lower than this threshold, the actual level of integral action becomes a linear combination between the value defined in this parameter and the value defined in parameter PAR 2754 <b>SR-I gain low speed</b> .											
In the speed range between the thresholds defined in PAR 2760 <b>SR-low speed thrsd</b> and PAR 2762 <b>SR-high speed thrsd</b> parameters, the weight of the integral action varies linearly with the speed.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.9	2760	<b>SR-low speed thrsd</b>	%	UINT16		30	1	100	RW	INT	VSY
Specifies the low speed threshold used for automatic gain adjustment of the speed controller.											
The value is expressed as a percentage of the rated speed.											
For motor speeds below this threshold, the speed controller uses the gains specified in the PAR 2752 <b>SR-P gain low speed</b> and the PAR 2754 <b>SR-I gain low speed</b> parameters.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.10	2762	<b>SR-high speed thrsd</b>	%	UINT16		70	1	100	RW	INT	VSY
Specifies the high speed threshold used for automatic gain adjustment of the speed controller.											
The value is expressed as a percentage of the rated speed.											
For motor speeds above this threshold, the speed controller uses the gains specified in the PAR 2756 <b>SR-P gain high speed</b> and the PAR 2758 <b>SR-I gain high speed</b> parameters.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.11	2662	<b>SR-P gain</b>	N/rpm	FLOAT		1.0	0	0	RW	INT	VSY
Specifies the base value of the speed controller's proportional gain.											
Its value is calculated by the drive as a function of the total moment of inertia declared in parameter PAR 2240 <b>Inertia</b> .											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.12	2664	<b>SR-I time</b>	ms	FLOAT		1.0	0	0	RW	INT	VSY
Specifies the base value of the speed controller's integral time. Its default value is 100 ms.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.13	9446	<b>TNF1-frequency</b>	Hz	FLOAT		100.0	5.0	350.0	RW	EXP	VSY
Specifies the value of the central frequency of the first TNF1 suppressor filter.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.14	9448	<b>TNF1-bandwidth</b>	Hz	FLOAT		4	1	20	RW	EXP	VSY
Defines the TNF1 suppressor filter's frequency band.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.15	9450	<b>TNF1-depth</b>	FLOAT			20	3	60	RW	EXP	VSY
Specifies the TNFR1 suppressor filter's attenuation value.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.16	9458	<b>Torque Notch Fltr 1</b>	ENUM			Disable			RW	EXP	VSY
This parameter activates/deactivates the filtering function of the first optional TNF 1 filter applied to the torque reference											

generated by the PI speed regulator.

- 0** - Disable
- 1** - Enable

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.1.17</b>	<b>9452</b>	<b>TNF2-frequency</b>	Hz	FLOAT		100.0	5.0	350.0	RW	EXP	VSY

Specifies the value of the central frequency of the second TNF2 suppressor filter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis..
<b>10.1.18</b>	<b>9454</b>	<b>TNF2-bandwidth</b>	Hz	FLOAT		4	1	20	RW	EXP	VSY

Defines the TNF2 suppressor filter's frequency band.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.1.16</b>	<b>9456</b>	<b>TNF2-depth</b>		FLOAT		20	3	60	RW	EXP	VSY

Specifies the TNF2 suppressor filter's attenuation value.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.1.20</b>	<b>9460</b>	<b>Torque Notch Fltr 2</b>		ENUM		Disable			RW	EXP	VSY

This parameter activates/deactivates the filtering function of the second optional TNF 2 filter applied to the torque reference generated by the PI speed regulator.

- 0** - Disable
- 1** - Enable

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.1.21</b>	<b>2806</b>	<b>SR-P gain in use</b>	%	FLOAT		100.0	0	0	R	INT	VSY

Read-only parameter. Contains the current value of the speed controller's proportional action level.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.1.22</b>	<b>2808</b>	<b>SR-I gain in use</b>	%	FLOAT		100.0	0	0	R	INT	VSY

Read-only parameter. Contains the current value of the speed controller's integral action level.

## 10.2 VF CONTROL

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.1	2200	<b>Boost voltage</b>	%	FLOAT		3	0	20.0	RW	ESY	F

Specifies the additional voltage value applied to the motor terminals at low speeds to increase the delivered torque. Excessive values produce an increase of current draw and motor heating due to the resistive losses in stator winding. Possible range of values: 0...20% of motor rated voltage.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.2	2202	<b>Base voltage</b>	V	FLOAT		0	0	0	RW	ESY	F

Specifies the maximum voltage value applicable to the motor terminals. This parameter's setting is defined by the drive automatically, based on the motor data plate, during the Wizard procedure.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.3	2204	<b>Base frequency</b>	Hz	FLOAT		0	0	0	RW	ESY	F

Specifies the rated motor frequency value at which the voltage applied to the motor terminals reaches the maximum value defined in parameter PAR 2202 **Base voltage**. For operating frequencies above this value the voltage applied to the motor is kept constant.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.4	2212	<b>V/Hz Boost most</b>		ENUM		Auto			RW	ESY	F

This parameter can be used to select one of the following two boost voltage generation modes:

- 0 Fixed
- 1 Auto

In the "Fixed" mode, the boost voltage is defined by the user through parameter PAR 2200 Boost voltage.

At zero speed, the drive applies a voltage to the motor terminals equal to the value defined in PAR 2200.

This additional voltage is gradually reduced for speeds higher than zero until it is eliminated for output frequencies above the threshold equal to half the rated frequency defined in PAR 2204 Base frequency (see figure).

In "Auto" mode the boost voltage is dynamically adjusted by the drive.




Figure 11.4: V/f characteristic curve profile

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.5	2214	<b>V/Hz Slip ctrl gain</b>		FLOAT		0	0	0	RW	EXP	F


This parameter influences the static accuracy of the open loop speed control. It is used for slip compensation under all load conditions. It is automatically defined by the drive based on the motor data plate and it can also be manually adjusted.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.6	2218	<b>V/Hz Stability gain</b>		FLOAT		0.0	0	0	RW	EXP	F

This parameter can be used to compensate for any current oscillations that may occur during travel and degrade comfort in the cabin. Its value is appropriately defined by the drive during the self-tuning procedure or after the "Take parameter" command.

V/f control can be made more stable by increasing this parameter.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.2.7</b>	<b>2220</b>	<b>V/Hz Limiter Kp</b>	Hz/A	FLOAT		0.2	0	0	RW	EXP	F
Defines the proportional gain of the current limiter in V/f mode. Its value is set by the drive after the self-tuning procedure or after the "Take parameter" command based on the motor data plate.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.2.8</b>	<b>2222</b>	<b>V/Hz Limiter Ti</b>	ms	FLOAT		50.0	0	0	RW	EXP	F
Defines the time constant of the integral action of the current limiter in V/f mode. Its value is set by the drive after the self-tuning procedure or after the "Take parameter" command based on the motor data plate.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.2.9</b>	<b>2224</b>	<b>V/Hz slip fltr const</b>	ms	FLOAT		10.0	1.0	1000.0	RW	EXP	F
Sets the filter for slip compensation. The value set in this parameter determines the reaction time of the slip compensation function. The lower this parameter's setting, the higher the slip compensation reaction. If this parameter is set too low, undesirable speed fluctuations.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.2.10</b>	<b>2230</b>	<b>V/Hz Boost gain</b>	V	FLOAT		0.0	0	0	RW	EXP	F
Defines the gain for automatic boost voltage adjustment in the "Automatic" mode. It is defined directly by the drive after the self-tuning procedure or after the "Take parameter" command based on the motor data plate.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.2.11</b>	<b>2480</b>	<b>Vf Min Freq</b>	Hz	FLOAT		0.5	0	5	RW	EXP	F
Minimum frequency setting in VF control mode. This is the minimum output frequency value; below this value no frequency adjustment is effective.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.2.12</b>	<b>2482</b>	<b>Vf Min Dly</b>	ms	FLOAT		800	0	5000	RW	EXP	F
Delay setting for minimum frequency signal in VF control mode.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.2.13</b>	<b>2206</b>	<b>Middle voltage</b>	V	FLOAT		0	0	0	RW	EXP	F
Setting an intermediate voltage value for the customised V/f property.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.2.14</b>	<b>2208</b>	<b>Middle frequency</b>	Hz	FLOAT		0	0	0	RW	EXP	F
Setting an intermediate frequency value for the customised V/f property.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.2.15</b>	<b>2232</b>	<b>Initial voltage</b>	V	FLOAT		0	0	60.0	RW	EXP	F
Setting the value for the initial voltage applied at zero frequency when using the customised V/f property.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
<b>10.2.16</b>	<b>2210</b>	<b>V/Hz Profile type</b>		ENUM		Linear			RW	EXP	F
Selection of the type of V/f property.											
0	Linear										
1	Custom										
Setting 0 (Linear) gives a V/f property that is linear, with midpoints set to half the value of parameters 2202 <b>Base voltage</b> and 2204 <b>Base frequency</b> . Setting 1 (Custom) provides a customised V/f property where the intermediate voltage and frequency values are defined by parameters 2206 <b>Middle voltage</b> and 2208 <b>Middle frequency</b> while the initial voltage (boost) value is given by parameter 2232 <b>Initial voltage</b> .											



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.17	2226	V/Hz Boost slope		FLOAT		0.0	0	0	RW	EXP	F

Slope of the initial section of the V/f property during which the boost voltage is applied.

Only valid for the linear V/f property. It is automatically defined by the drive following the self-tuning procedure.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.18	2228	Slip comp hold		ENUM			Disable		RW	EXP	F

Activates the slip compensation.

**0** - Disable

**1** - Enable

## 10.3 REGULATOR PARAM

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.1	2250	<b>CR-P gain</b>	V/A	FLOAT		1.0	0	0	RW	EXP	FVSY
Setting of the proportional gain of the current regulator (CR).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.2	2252	<b>CR-I time</b>	ms	FLOAT		1.0	0	0	RW	EXP	FVSY
Sets the integral time constant of the current regulator (CR).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.3	2260	<b>FR-P gain</b>	A/Wb	FLOAT		1.0	0	0	RW	EXP	FVSY
Sets the proportional gain value of the flux regulator (FR) used only in vector control ([1] ASY FOC, PAR 540 <b>Control type</b> ) for asynchronous motors.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.4	2262	<b>FR-I time</b>	ms	FLOAT		1.0	0	0	RW	EXP	FVSY
Sets the value of the integral time constant of the flux regulator (FR) used only in vector control ([1] ASY FOC, PAR 540 <b>Control type</b> ) for asynchronous motors.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.5	2272	<b>VR-I time</b>	ms	FLOAT		1.0	0	0	RW	EXP	FVSY
Sets the value of the integral time constant of the output voltage regulator (VR).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.6	2290	<b>Deflux voltage</b>	V	FLOAT		380	0	0	RW	EXP	FVSY
Defines the maximum AC voltage value applicable by the inverter. For speeds greater than the base speed (at the speed for which the applied voltage reaches its maximum value) the drive reduces the magnetic flux of the motor by entering the Flux weakening operating range.											
Flux reduction enables higher speeds to be reached at the expense of the maximum deliverable torque, which decreases accordingly.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.7	2292	<b>Voltage margin</b>	perc	FLOAT		5.0	0	30.0	RW	EXP	FVSY
Setting of the voltage regulation margin according to the available voltage. In case of a Deflux voltage setting close to or equal to the actual mains value, <b>Voltage margin</b> (PAR 2292) represents the margin allowable by the voltage regulation to perform rapid current variations when load steps are suddenly applied.											
A value of 5% allows a very fast response to load steps but with a loss of output voltage and thus power output (reduced power output).											
The minimum value (1%) allows a maximum output voltage (around 98%) of the mains voltage to be achieved but with loss of quality of the dynamic response.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.8	2308	<b>Over-flux level</b>	perc	FLOAT		100	100	150	RW	EXP	FVSY
The value is expressed as the percentage in excess of the rated flux.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.9	2312	<b>Over-flux spd thrsd</b>	rpm	FLOAT		400	1	1000	RW	EXP	FVSY
Speed limit below which the overflux value set in PAR 2308 <b>Over-flux level</b> .											
10.3.10	2314	<b>Over-flux step</b>		FLOAT		1	0.01	10	RW	EXP	FVSY
Setting of the ramp time in the transition between the rated flux and the overflux value set in PAR 2308 <b>Over-Flux level</b> .											
10.3.11	2724	<b>Defluxing curr lim</b>	A	FLOAT		0.0	0	0	RW	EXP	FVSY
This parameter specifies the maximum defluxing current (direct component of motor current) applicable by the drive in Flux Weakening operating range.											
Standard value 30% of the rated current. A null value disables the defluxing function.											

## 10.4 TORQUE CONFIG

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.1	2350	Torque cur lim Pos	A	FLOAT	16BIT_H	CALCF	0.0	CALCF	RW	EXP	FVSY

Setting of the active torque limit of the drive for the positive current direction (clockwise rotation and anti-clockwise braking).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.2	2352	Torque curr lim Neg	A	FLOAT	16BIT_H	CALCF	0.0	CALCF	RW	EXP	FVSY

Setting of the active torque limit of the drive for the negative current direction (anti-clockwise rotation and clockwise braking).


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.3	2354	Torque curr lim sel		ENUM		Off			RWZ	EXP	FVSY

Setting of the type of behaviour of the drive in the current limit condition.

- 0 Off
- 1 T clim +/-
- 2 T clim mot/gen
- 3 T limit src

If set to **0** no specific type of current limitation is set.

If set to **1** the active positive torque limit is **Torque curr lim Pos** (PAR 2350) and the active negative torque limit is **Torque curr lim Neg** (PAR 2352).



Torque limits with Torque curr lim Sel = 1

Torque limits with Torque curr lim sel = 2

If set to **2** three conditions are possible:

- 1 – If the motor speed is > +1% of **Rated speed** the active positive torque limit is **Torque curr lim Pos** (PAR 2350) and the active negative torque limit is **Torque curr lim Neg** (PAR 2352).
- 2 – If the motor speed is < -1% of **Rated speed** the active positive torque limit is **Torque curr lim Pos** (PAR 2350) and the active negative torque limit is **Torque curr lim Neg** (PAR 2352).
- 3 – If -1% of Motor non speed < motor speed < + 1% of **Rated speed** the active positive torque limit is **Torque curr lim Pos** (PAR 2350) and the active negative torque limit is **Torque curr lim Neg** (PAR 2352).

If set to **3** the torque limits are symmetrical. The torque limit is the value written in the source selected by **Torque limit src** (PAR 2358). This mode is not managed with ASY SSC control mode.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.4	2358	Torque limit src		LINK	16BIT_H	6000	0	2380	RWZ	EXP	FVSY

Selection of the origin (source) of the signal to be used for the torque current limit. The signals that can be associated with the function are listed in the “**L\_LIM**” selection list.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.5	2360	Torque climPos Inuse	A	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY

The positive torque limit value currently being used is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.6	2362	Torque climNeg Inuse	A	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY

The negative torque limit value currently being used is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.7	2380	Dig torque ref	%	FLOAT	16BIT_H	0.0	-300.0	300.0	RW	EXP	FVSY

Setting of a digital torque reference. The current reference value is proportional to the active motor current and determines the torque value. The sign determines the torque direction.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.8	2382	Torque ref src		LINK	16BIT_H	65535	2380	2380	RWZ	EXP	FVSY

Selection of the origin (source) of the signal to be used for the torque reference. The signals that can be associated with the function are listed in the "L\_VREF" selection list.

# 11 FUNCTIONS

## 11.1 DC BRAKING

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.1	3150	DC braking cmd src		LINK	16BIT_L	6000			RW	INT	FVS

Selection of the origin (source) of the signal to be used for the **DC braking command**. The terminal or signal that can be used for this function can be defined from among those available in the “**L\_DIGSEL2**” selection list”.


- |   |                    |            |
|---|--------------------|------------|
| 0 | DC braking command | not enable |
| 1 | DC braking command | enable     |

In default conditions the origin of the **DC braking command** signal is 0 (not enable).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.2	3152	DC brake mode		ENUM		Off			RW	INT	FVS

This parameter can be used to configure the DC braking activation modes.

- |   |                |
|---|----------------|
| 0 | Off            |
| 1 | At Stop        |
| 2 | On Command     |
| 3 | OnCmd & AtStop |



In "Off" mode the direct current injection phase is never executed.

In "At stop" mode the direct current injection phase is executed when the stop command is sent and the speed reference threshold = zero has been reached.

**Example:**

With the motor running at any speed, when the stop command is enabled the ramp output decreases according to the selected ramp time, when the speed reference threshold = zero is reached PAR 934 **Ref is 0** the direct current injection phase is enabled. When the command is enabled after the delay configured in PAR 3154 **DC brake delay** direct current injection starts. PAR 3156 **DC brake time** is used to configure the duration of the injection phase and PAR 3158 **DC brake curr** is used to configure the intensity of the injection phase current.

In "At command" mode the direct current injection phase is executed when the **DC braking command** configured using parameter PAR 3150 **DC braking command src** is sent.

**Example:**

Motor running driven by load. When the drive is enabled and the **DC braking command** is sent the direct current injection phase is activated. When the command is enabled after the delay configured in PAR 3154 **DC brake delay** direct current injection starts. PAR 3156 **DC brake time** is used to configure the duration of the injection phase and PAR 3158 **DC brake curr** is used to configure the intensity of the injection phase current.

If the command is an impulse shorter than the time programmed with PAR 3156 **DC brake time**, the direct current injection phase continues at least for the time set in parameter **DC brake time**.

If the command is an impulse longer than the time programmed with 3156 **DC brake time**, the direct current injection phase continues for as long as the command is present.

In "OnCmd & AtStop" modes the direct current injection phase is executed when one of the two conditions described in the "At stop" or "On command" modes is present.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.3	3154	<b>DC brake delay</b>	s	FLOAT		0.01	0.01	30.0	RW	INT	FVS

This parameter is used to configure the delay in seconds between the moment DC braking is requested and the moment direct current injection starts.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.4	3156	<b>DC brake duration</b>	s	FLOAT		1.0	0.01	30.0	RW	INT	FVS

This parameter is used to configure the duration of direct current injection.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.5	3158	<b>DC brake current</b>	%	FLOAT		75	0.0	150.0	RW	INT	FVS

This parameter is used to configure the value of the injected direct current.

This is expressed as a percentage of the rated current (PAR 2002 **Rated Current**).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.6	3160	<b>DC brake state</b>		ENUM	16BIT_L	Not active			R	INT	FVS

The status of direct current braking is displayed.

- 0 Not active
- 1 Active

**Note!**

During braking the Enable command must be enabled. If this command is not present or is removed during the braking process, the drive blocks the inverter bridge and the motor stops due to inertia, without braking.

During the direct current injection phase the Run command should not be enabled. If the Run command is sent to the drive, the ramp output starts following the set reference; direct current output is produced in any case. The moment the DC braking command is removed there is immediately a speed step without performing a change in the ramp.

During the direct current injection phase, for the Jog command follow the instructions provided for the Run command.

## 11.2 INERTIA COMP

An increase in the dynamic response of the speed regulator to a variation in the reference, can be modified by changing the current value during the acceleration/deceleration phase, to counter the machine inertia.

These parameters are calculated by the speed loop autotuning procedure but can also be set manually by the user.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.2.1	3100	Inertia comp	kgm <sup>2</sup>	FLOAT		0.1	0	0	RW	EXP	FVSY

Total value of the inertia on the motor shaft in Kgm<sup>2</sup> identified during the self-tuning procedure. If known, this value can also be set manually by the user.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.2.2	3102	Inertia comp filter	ms	FLOAT		4.0	2.0	20.0	RW	EXP	FVSY

Setting of a filter on the torque compensation. The filter reduces noise due to speed differentiation in the inertia block.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.2.3	3104	Inertia comp mon	%	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY

The value of inertia compensation on the function block output is displayed.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.2.4	3106	Inertia comp fcn		ENUM		Disable			RW	EXP	FVSY
	0	Disable									
	1	Enable									

## 11.3 ANTI ROLLBACK

It can only be activated in the synchronous FOC-CL control mode to reduce or eliminate the roll-back effect at start and finish without the need for prior load measurements by means of special sensors.

The anti roll-back function at start-up realises a control action that, when the brake is applied, compensates for the load imbalance by preventing unwanted rotor movements and ensures a smooth and comfortable start.

For satisfactory results, it is advisable to use an encoder with a resolution of at least 2048 sine/cosine periods per revolution.

Similarly, the anti-rollback on arrival function realises a control action that reduces or cancels unwanted movements on arrival at the plane. If the function is activated, the corresponding control action is automatically exercised on arrival at the landing when the speed reference becomes zero. In this way, in the time between reaching zero speed and closing the brake, the rotor is kept locked in torque, ensuring a comfortable and jolt-free stop of the car.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.3.1	2766	PR-P gain		FLOAT		500	0	20000	RW	EXP	Y

Defines the gain of the anti-rollback action at start.

Possible range of values: 0... 1000. A "0" value cancels the controller's action. High values improve the position controller's response in limiting possible rotation of the motor shaft in the opposite direction to that desired when the locking brake is opened (roll-back).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.3.2	2768	PR-enable		ENUM		Enable			RW	EXP	Y

This parameter enables/disables the anti rollback function at start-up.

0 - Disable  
1 - Enable

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.3.3	2812	PR-P End gain		FLOAT		500	0	20000	RW	EXP	Y

Defines the gain of the anti-rollback action on arrival.

Range of possible values : 0...1000 . The value "0" cancels the action of the function. High values improve the response of the function in limiting any rotation of the motor shaft in the opposite direction to that desired in the stopping phase.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.3.4	2814	PR End enable		ENUM		Enable			RW	EXP	Y
This parameter enables/disables the arrival anti rollback function.											
0 - Disable 1 - Enable											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.3.3	2810	Pos reg limit	rpm	FLOAT		10.0	-20	20	RW	EXP	Y
Specifies the maximum and minimum value of the positioner control action.											

## 11.4 VIBRATION ANALYSIS (VIBR. ANALYSIS)

This is a measurement tool that can be activated in FOC control modes, whether synchronous or asynchronous, to detect any mechanical vibration that occurs during movement at constant speed disturbing the comfort in the cabin. The measurement system for each movement is able to detect, if present, up to two resonance frequencies in the band between 5...300Hz and returns the values as output in two parameters. Any frequencies found can then be used to configure the notch filters in the SPEED REG GAINS menu.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.4.1	2288	Vibration analyzer		ENUM		Disable			RW	EXP	VSY
This parameter enables/disables the function for measuring resonance frequencies.											
0 - Disable 1 - Enable											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.4.2	9464	Vibration freq. 1	Hz	FLOAT		0	0.0	0.0	R	EXP	VSY
Indicates the value in Hz of the first measured resonance frequency. If two frequencies have been detected, <b>Vibration freq. 1</b> will be the one with the higher amplitude.											
A "0" value indicates that no resonance frequency is present in the measurement band.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.4.3	9466	Vibration freq. 2	Hz	FLOAT		0	0.0	0.0	R	EXP	VSY
Indicates the value in Hz of the second measured resonance frequency. If two frequencies have been detected, <b>Vibration freq. 2</b> will be the one with the lower amplitude.											
A "0" value indicates that no second resonance frequency is present in the measurement band.											

## 11.5 MOTOR OVERLOAD

The overload control function provides integrator logic to protect the motor against thermal overload. This protection emulates the thermal relay of the motor controlled by the ADL550 drive.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.1	3200	Motor ovld enable		ENUM		Off			RW	EXP	FVSY
Enabling of the motor overload control.											
0 Off 1 On											


Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.2	3202	Motor ovld factor	%	FLOAT		150	100	300	RW	EXP	FVSY
Setting of the motor overload value. Percentage value of the motor rated current (PAR 2002 <b>Rated current</b> ).											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.3	3204	Motor ovld time	s	FLOAT		30	10	300	RW	EXP	FVSY
Setting of the motor overload duration in seconds. It represents the moment in which the protection ("Motor Overload") is											

enabled, if the motor current value is above the overload set in the PAR 3202 **Motor ovlfd factor** parameter.

This alarm can be assigned to a programmable digital output (PAR 3214 **Motor overload trip**).

The trip time depends on the motor current value and is as follows:



Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.4	3206	<b>Motor service factor</b>	%	FLOAT		100	25	200	RW	EXP	FVSY

Setting of the motor service factor. This is the difference between the peak current and rated current. It is used to calculate the thermal image of the motor.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.5	3216	<b>Motor fan type</b>		ENUM		Auto fan			RW	EXP	FVSY

This parameter is used to set the type of motor cooling system.

- 0 Auto fan
- 1 Servo fan

**Auto fan** indicates the presence of a fan unit mounted on the motor shaft that therefore turns at a speed proportional to the motor speed. Cooling is not very effective at low motor speeds.

**Servo fan** indicates the presence of an independent fan unit that therefore always runs at the rated speed. It ensures optimum cooling efficiency at all motor speeds.

When the current motor speed is below (PAR 2004 **Rated speed** / 2) and PAR 3216 **Motor fan type** = Auto fan; , the MOTOR OVERLOAD protection intervention time must be reduced as cooling is insufficient.

At below (PAR 2004 **Rated speed** / 2) the protection intervention time is reduced by reducing the direct current of the MOTOR OVERLOAD function.

When the motor speed is equal to (PAR 2004 **Rated speed** / 2) the direct current of the MOTOR OVERLOAD function is equal to PAR 2002 **Rated current** \* PAR 3206 **Motor service factor** , whereas below that limit it is modified following a linear pattern until PAR 2002 **Rated current** \* 3206 **Motor service factor** \* PAR 3218 **Motor derat factor** when the motor speed reaches zero.

The overload current of the MOTOR OVERLOAD function is obtained by PAR 2002 **Rated current** \* 3206 **Motor service factor** \* PAR 3202 **Motor ovlfd factor** and is the maximum current that can circulate in the motor. If the MOTOR OVERLOAD function is enabled the drive automatically sets the torque current limit so that lout max. does not exceed this value.

With the MOTOR OVERLOAD function a current equal to the Overload level is supplied to the motor for the maximum time set in PAR 3204 **Motor ovlfd time**, The slower the motor speed, the shorter the time allowed (see figure at beginning of chapter).

After the set time, the MOTOR OVERLOAD function automatically sets the torque current limit so that lout max. does not exceed the direct current of the MOTOR OVERLOAD function.

When the motor current speed exceeds (PAR 2004 **Rated speed** / 2) and PAR 3216 **Motor fan type** = Auto fan, the direct current is not reduced as cooling is sufficient.

When PAR 3216 **Motor fan type** = Servo fan, the direct current is not reduced as cooling is sufficient.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.6	3218	<b>Motor derat factor</b>	%	FLOAT		50	0	100	RW	EXP	FVSY

This parameter is used to set the derating factor. The value is expressed as a percentage of PAR 2002 **Rated current** \* PAR 3206 **Motor service factor**.

When the current motor speed is below (PAR 2004 **Rated speed** / 2) and PAR 3216 **Motor fan type** = Auto fan, the protection intervention time must be reduced as cooling is insufficient.

At below (PAR 2004 **Rated speed** / 2) the protection intervention time is reduced by reducing the direct current of the MOTOR OVERLOAD function.

When the motor speed is equal to (PAR 2004 **Rated speed** / 2) the direct current of the MOTOR OVERLOAD function

is equal to PAR 2002 **Rated current** \* PAR 3206 **Motor service factor**, whereas below that limit it is modified following a linear pattern until PAR 2002 **Rated current** \* PAR 3206 **Motor service factor** \* PAR 3218 **Motor derat factor** when the motor speed reaches zero.

The overload current of the MOTOR OVERLOAD function is obtained by PAR 2002 **Rated current** \* PAR 3206 **Motor service factor** \* PAR 3202 **Motor ovlid factor** and is the maximum current that can circulate in the motor. If the MOTOR OVERLOAD function is enabled the drive automatically sets the torque current limit so that lout max. does not exceed this value.

With the MOTOR OVERLOAD function a current equal to the Overload level is supplied to the motor for the maximum time set in PAR 3204 **Motor ovlid time**. The slower the motor speed, the shorter the time allowed (see graphs).

After the set time, the MOTOR OVERLOAD function automatically sets the torque current limit so that lout max. does not exceed the direct current of the MOTOR OVERLOAD function.

When the motor current speed exceeds (PAR 2004 **Rated speed** / 2) and PAR 3216 **Motor fan type** = Auto fan, the direct current is not reduced as cooling is sufficient.

When PAR 3216 **Motor fan type** = Servo fan, the direct current is not reduced as cooling is sufficient.

If the value of parameter 3202 **Motor ovlid factor** is 100 % the overload current of the Motor Overload function is equal to the continuous current of the Motor Overload function. In this case the drive behaves as if the overload cycle has been executed and so sets the torque current limit so that lout max is not more than the continuous current, i.e. **Rated current** (PAR 2002) \* **Motor service factor** (PAR 3206) \* **Motor derat factor** (PAR 3218).

We recommend setting parameter 3218 **Motor derat factor** to a value so that **Rated current** (PAR 2002) \* **Motor service factor** (PAR 3206) \* **Motor derat factor** (PAR 3218) produces a result that is more than the motor magnetisation current.

## 11.6 BRAKING RESISTOR OVERLOAD (BRES OVERLOAD)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.6.1	3250	<b>Bres control</b>		ENUM		On			RW	INT	FVSY

Enabling of the external braking resistance and relative overload control.

- 0 Off
- 1 On

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.6.2	3252	<b>Bres value</b>	ohm	FLOAT		7.0	7.0	1000.0	RW	INT	FVSY

Setting of the ohm value of the external braking resistor.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.6.3	3254	<b>Bres cont power</b>	kW	FLOAT		0.1	0.1	100.0	RW	INT	FVY

Setting of the power that can be continuously dissipated by the external braking resistor.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.6.4	3256	<b>Bres overload factor</b>	%	FLOAT		1.5	1.5	10.0	RW	INT	FVSY

Setting of the external resistor overload factor.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.6.5	3258	<b>Bres overload time</b>	s	FLOAT		0.5	0.5	50.0	RW	INT	FVSY

Setting of the intervention time of the external braking resistor overload.

## 11.7 ENERGY SAVING (ENER. SAVING)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.7.1	3122	Saved energy	kWh	FLOAT		0	0	0	R	EXP	FVSY

Energy saved, starting from the first switch-on, by using the drive coupled with a regenerative unit. If the drive is not coupled to this product, the parameter calculates how much energy would have been saved.

The displayed value is never reset even when the drive is switch-off.

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.7.2	3124	Set energy val	kWh	FLOAT		0	0	0	RW	EXP	FVSY

Makes it possible to reset parameter 3122 **Saved energy** by entering "0" or a generic desired value.

(e.g. if 10 kWh is entered, parameter 3122 is automatically updated to 10 kWh and continues to accumulate from this value).

## PARAMETERS ON SELECTION LISTS, BUT NOT DISPLAYED ON KEYPAD

This list reports the parameters that are not displayed in the keyboard while they are part of the selection lists.

These parameters can be used as SOURCE of the input signals for the function block. (Refer to section A – Programming).

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>262</b>	<b>Motor speed no filter</b>	rpm	INT16	16BIT_H	0	0	0	R	SRV	
Indicates the unfiltered motor speed.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>626</b>	<b>Ramp ref out mon</b>	rpm	INT16	16BIT_H	0	0	0	R	SRV	
Displays the reference value output of the ramp reference function block.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>760</b>	<b>Ramp out mon</b>	rpm	INT16	16BIT_H	0	0	0	RW	SRV	
Displays the reference value output of the ramp function block.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>764</b>	<b>Ramp acc state</b>	BIT	16BIT_L	2	0	0	1	R	SRV	
Indicates whether the acceleration ramp is active.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>766</b>	<b>Ramp dec state</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
Indicates whether the deceleration ramp is active.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>934</b>	<b>Ref is 0</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
This signal is active when the reference is below the limit set in parameter 930 <b>Reference 0 threshold</b> .											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>936</b>	<b>Ref is 0 delay</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
It is active when the reference is below the threshold set in parameter 930 <b>Reference 0 threshold</b> . The signal is enabled after the delay set with parameter 932 <b>Reference delay 0</b> .											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>944</b>	<b>Speed is 0</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
It is active when the speed is below the threshold set in parameter 940 <b>Speed 0 threshold</b> .											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>946</b>	<b>Speed is 0 delay</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
It is active when the reference is below the threshold set in parameter 940 <b>Speed 0 threshold</b> . The signal is activated after the delay set in parameter 942 <b>Speed 0 delay</b> .											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>1024</b>	<b>Enable cmd mon</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
Enable signal monitor.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>1026</b>	<b>Start cmd mon</b>	BIT	16BIT_L	0	0	0	1	R	SRV	
Start signal monitor.											

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>1028</b>	<b>FastStop cmd mon</b> Fast Stop signal monitor.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>1060</b>	<b>SM1 status</b> Status of DSP machine state.  <b>255 - PSTART</b> <b>0 - N_RDY_TO_SW_ON</b> <b>64 - SWITCH_ON_DIS</b> <b>33 - RDY_TO_SWT_ON</b> <b>35 - SWITCHED_ON</b> <b>39 - OPER_ENABLED</b> <b>7 - QUICKSTOP_ACT</b> <b>15 - FLT.REACT_ACT</b> <b>8 - PFAULT</b>		ENUM		PSTART			R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>1062</b>	<b>Drive OK</b> It is active when the drive is in the “OK” condition and no alarms are present.		UINT16	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>1064</b>	<b>Drive ready</b> It is active when the drive reference is in the “Ready” to run condition.		UINT16	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>3214</b>	<b>Motor overload trip</b> It is active when the drive is in the motor overload alarm condition.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>3262</b>	<b>Bres overload trip</b> It is active when the drive is in the braking resistor overload alarm condition.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>4708</b>	<b>Alm dig out mon 1</b> It is activated when the alarm configured in parameter 4700 <b>Alarm dig sel 1</b> is active.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>4710</b>	<b>Alm dig out mon 2</b> It is activated when the alarm configured in parameter 4702 <b>Alarm dig sel 2</b> is active.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>4712</b>	<b>Alm dig out mon 3</b> It is activated when the alarm configured in parameter 4704 <b>alarm dig sel 3</b> is active.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>4714</b>	<b>Alm dig out mon 4</b> It is activated when the alarm configured in parameter 4706 <b>alarm dig sel 4</b> is active.		BIT	16BIT_L	0	0	1	R	SRV	
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>4770</b>	<b>First alarm</b> Displays the first alarm to be activated.		ENUM		No Alarms			R	SRV	

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>6000</b>	<b>Null</b>		UINT32	32BIT	0	0	0	R	SRV	
Forces the variable to the zero level (always disabled).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>6002</b>	<b>One</b>		UINT32	32BIT	1	1	1	R	SRV	
Forces the variable to level one (always active).											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>6372</b>	<b>DS417 status word</b>		UINT16	16BIT_L	0	0	65535	R	SRV	
Displays the status word according to the DS417 Profile. For more information reference should be made to the fieldbus manual.											
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
-	<b>12250</b>	<b>B0 Lift decomp</b>									
-	<b>12252</b>	<b>B1 Lift decomp</b>									
-	<b>12254</b>	<b>B2 Lift decomp</b>									
-	<b>12256</b>	<b>B3 Lift decomp</b>									
-	<b>12258</b>	<b>B4 Lift decomp</b>									
-	<b>12260</b>	<b>B5 Lift decomp</b>									
-	<b>12262</b>	<b>B6 Lift decomp</b>									
-	<b>12264</b>	<b>B7 Lift decomp</b>									
-	<b>12266</b>	<b>B8 Lift decomp</b>									
-	<b>12268</b>	<b>B9 Lift decomp</b>									
-	<b>12270</b>	<b>B10 Lift decomp</b>									
-	<b>12272</b>	<b>B11 Lift decomp</b>									
-	<b>12274</b>	<b>B12 Lift decomp</b>									
-	<b>12276</b>	<b>B13 Lift decomp</b>									
-	<b>12278</b>	<b>B14 Lift decomp</b>									
-	<b>12280</b>	<b>B15 Lift decomp</b>									

This signal is derived from the status of bit X (Bit 0 = PAR 12250 B0 Lift decomp ... Bit 15 = PAR 12280 B15 Lift decomp) of the word assigned to Fieldbus M->S1 ipa (PAR 4020).

## C - Parameters Lists

### DRIVE SETUP

#### Access setup ?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
0.1	578	Language select		ENUM		GB			RW	INT	FVSY
				0 - English							
				1 - Italian							
				2 - French							
				3 - German							
				4 - Spanish							
				5 - Turkish							
0.2	390	Load Application		UINT16		-	-	4	RW	INT	FVY
				0 - No applicat.							
				1 - EFC							
				2 - EPC		(Under development)					
				3 - DCP		(Under development)					
				4 - CAN417		(Under development)					
0.3	598	Load from USB		BIT		0	0	1	RWZ	INT	
0.4	2132	Encoder mode		ENUM		None			RWZ	INT	
				0 - None							
				1 - Digital							
				2 - Sinus							
				3 - Sinus SINCOS							
				4 - Sinus ENDAT							
				5 - Sinus BISS							
				6 - ENDAT							
				7 - BiSS							
				8 - Sinus SSI							
0.5	392	Select motor		BIT		0	0	1	RWZ	INT	

#### Leave setup ?

### 1 STARTUP WIZARD

#### 1.1 Set comm mode?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.1.1	4000	Communication mode		ENUM		Parallel			RW	INT	FVSY
				0 - Parallel I/O							
				1 - CanOpen							
				2 - DCP		(Under development)					
				3 - CAN417		(Under development)					
1.1.2	3800	Drive address		UINT16		1	1	255	RW	INT	
1.1.3	3802	Serial baudrate		ENUM		38400			RW	INT	
				0 - 9600							
				1 - 19200							
				2 - 38400							

#### 1.2 Set encoder param?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.2.1	2102	Encoder supply	V	FLOAT		5.2	5.2	20.0	RW	INT	FVSY
1.2.2	2132	Encoder mode		ENUM		None			RWZ	INT	
				0 - None							
				1 - Digital							
				2 - Sinus							
				3 - Sinus SINCOS							
				4 - Sinus ENDAT							
				5 - Sinus BISS							
				6 - ENDAT							
				7 - BiSS							
				8 - Sinus SSI							
1.2.3	2100	Encoder pulses	ppr	UINT16		1024	4	16384	RWZ	INT	
1.2.4	2110	Encoder signal check		ENUM		Check A-B			RWZ	EXP	
				1 - Check A-B							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
2 - Check A-B-Z											
1.2.5	7106	BiSS N bit ST		UINT16		13	0	64	RW	EXP	
1.2.6	7108	BiSS N bit MT		UINT16		0	0	64	RW	EXP	
1.2.7	7114	BiSS Crc polinomy		UINT16		67	1	65535	RW	EXP	

### 1.3 Set motor data?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.3.1	540	Control type		ENUM		ASY_VF			RWZ	INT	FVSY
0 - ASY SSC 1 - ASY FOC 2 - SYN FOC											
1.3.2	2000	Rated voltage	V	FLOAT		SIZE	150	480	RWZ	INT	FVSY
1.3.3	2002	Rated current	A	FLOAT		SIZE	1	1500	RWZ	INT	FVSY
1.3.4	2004	Rated speed	rpm	FLOAT		SIZE	10	32000	RWZ	INT	FVSY
1.3.5	2006	Rated frequency	Hz	FLOAT		SIZE	1	1000	RWZ	INT	FVS
1.3.6	2008	Pole pairs		UINT16		SIZE	1	60	RWZ	INT	FVSY
1.3.7	2010	Rated power	kW	FLOAT		SIZE	0.1	1500	RWZ	INT	FVS
1.3.8	2012	Rated power factor		FLOAT		SIZE	0.6	0.95	RWZ	INT	FVS
1.3.9	2014	Torque constant	Nm/A	FLOAT		SIZE	0	120	RWZ	INT	Y

### 1.4 Set mechanical data?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.4.1	11002	Travel units sel		ENUM		Hz (m/s)	-	-	RWZ	INT	FVY
0 - Hz 1 - m/s 2 - rpm											
1.4.2	11006	Cabin speed	m/s	FLOAT		1	0	10	RWZ	INT	FVY
1.4.3	11010	Gearbox ratio		FLOAT		45 (1)	1	200	RW	INT	FVY
1.4.4	11164	Rope ratio		FLOAT		1 (2)	1	10	RWZ	INT	FVY
1.4.5	11012	Pulley diameter	m	FLOAT		0.6 (0.32)	0	5	RWZ	INT	FVY
1.4.6	11150	Car weight	kg	FLOAT		400	0	10000	RW	INT	FVY
1.4.7	11152	Counter weight	kg	FLOAT		1000	0	10000	RW	INT	FVY
1.4.8	11154	Load weight	kg	FLOAT		450	0	10000	RW	INT	FVY
1.4.9	11156	Rope weight	kg	FLOAT		20	0	1000	RW	INT	FVY

### 1.5 Set speeds?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.5.1	11020	Multispeed 0		FLOAT		5 (0.1)	0	10000	RW	ESY	FVY
1.5.2	11022	Multispeed 1		FLOAT		47.73 (1.0)	0	10000	RW	ESY	FVY
1.5.3	11024	Multispeed 2		FLOAT		20 (0.4)	0	10000	RW	ESY	FVY
1.5.4	11026	Multispeed 3		FLOAT		0	0	10000	RW	ESY	FVY
1.5.5	11028	Multispeed 4		FLOAT		0	0	10000	RW	ESY	FVY
1.5.6	11030	Multispeed 5		FLOAT		0	0	10000	RW	ESY	FVY
1.5.7	11032	Multispeed 6		FLOAT		0	0	10000	RW	ESY	FVY
1.5.8	11034	Multispeed 7		FLOAT		0	0	10000	RW	ESY	FVY

### 1.7 Run autotune still?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.7.1	2032	Autotune		BIT		0	0	1	RWZ	INT	FVSY

### 1.8 Save parameters?

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1.8.1	550	Save parameters		BIT		0	0	1	RW	ESY	FVSY

## 2 OPTIMIZATION WIZARD

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
2.1	9720	Learning trip		BIT		0	0	1	RWZ	INT	VSY
2.2	12000	RollBack at start		UINT32		1	1	5	RW	ESY	FVY
2.3	12006	RollBack at arrival		UINT32		1	1	3	RW	ESY	FVY
2.4	12002	Comfort high spd		UINT32		1	1	3	RW	ESY	FVY
2.5	12004	Comfort low spd		UINT32		1	1	3	RW	INT	FVY

## 3 TROUBLESHOOTING

### 3.1 Start

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.1.1	11064	Brake open delay	ms	INT16/32		500	0	10000	RW	ESY	FVY

### 3.2 Rollback

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.2.1	2200	Boost voltage	%	FLOAT		3	0	20.0	RW	INT	F
3.2.2	2212	V/Hz Boost mode		ENUM 0 - Fisso 1 - Auto		Auto			RW	INT	F
3.2.3	2794	SR-P gain at start	%	FLOAT		150.0	0.0	400.0	RW	INT	VSY
3.2.4	2796	SR-I gain at start	%	FLOAT		110.0	0.0	400.0	RW	INT	VSY

### 3.3 Too fast acceleration (Too fast accel.)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.3.1	11040	Accel initial jerk	m/s <sup>3</sup>	FLOAT		0.2	0.001	20	RW	ESY	FVY
3.3.2	11042	Acceleration	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY

### 3.4 Slow speed vibrations (Slow speed vibr.)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.4.1	2752	SR-P gain low speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
3.4.2	2754	SR-I gain low speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY

### 3.5 High speed vibrations (High speed vibr.)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.5.1	2756	SR-P gain high speed	%	FLOAT		100	0.0	400.0	RW	INT	VSY
3.5.2	2758	SR-I gain high speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY

### 3.6 Too fast deceleration (Too fast dec.)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.6.1	11046	Decel initial jerk	m/s <sup>3</sup>	FLOAT		0.6	0.001	20	RW	ESY	FVY
3.6.2	11048	Deceleration	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY

### 3.7 Floor leveling

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.7.1	11068	Brake close delay	ms	INT16/32		500	0	10000	RW	ESY	FVY

### 3.8 Brake closing

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.8.1	11070	Current down delay	ms	INT16/32		0 (800)	0	10000	RW	INT	Y

### 3.9Vibrator analyzer

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3.9.1	9464	Vibration freq. 1	Hz	FLOAT		0	0.0	0.0	R	INT	VSY
3.9.2	9466	Vibration freq. 2	Hz	FLOAT		0	0.0	0.0	R	INT	VSY

## 4 DRIVE

### 4.1 DRIVE MONITOR

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.1.1	250	Output current	A	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
4.1.2	252	Output voltage	V	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
4.1.3	254	Output frequency	Hz	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
4.1.4	664	Speed setpoint	rpm	INT16	16BIT_H	0	0	0	R	ESY	FVSY
4.1.5	260	Motor speed	rpm	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
4.1.6	270	DC link voltage	V	FLOAT	16BIT_H	0	0	0	R	ESY	FVSY
4.1.7	272	Heatsink temperature	degC	FLOAT	16BIT_L	0	0	0	R	ESY	FVSY
4.1.8	274	Motor temp	degC	INT16		0	0	0	R	ESY	
4.1.9	280	Torque current ref	A	FLOAT	16BIT_H	0	0	0	R	EXP	FVSY
4.1.10	282	Magnet current ref	A	FLOAT	16BIT_H	0	0	0	R	EXP	FVSY
4.1.11	284	Torque current	A	FLOAT	16BIT_H	0	0	0	R	INT	FVSY
4.1.12	286	Magnet current	A	FLOAT	16BIT_H	0	0	0	R	INT	FVSY
4.1.13	3212	Motor overload	%	UINT16	16BIT_H	0	0	100	R	ESY	FVSY
4.1.14	368	Drive overload	%	UINT16	16BIT_H	0	0	100	R	ESY	FVSY
4.1.15	3260	Bres overload	%	UINT16	16BIT_H	0	0	100	R	ESY	FVSY
4.1.16	1066	Enable state mon		UINT16	16BIT_L	0	0	1	R	ESY	FVSY
4.1.17	1068	Start state mon		UINT16	16BIT_L	0	0	1	R	ESY	FVSY
4.1.18	1070	FastStop state mon		UINT16	16BIT_L	0	0	1	R	ESY	FVSY
4.1.19	2386	Torque ref	%	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY
4.1.20	2388	Torque	%	FLOAT	16BIT_H	0.0	0.0	0.0	R	INT	FVSY
4.1.21	372	In use current limit	A	FLOAT	16BIT_H	0	0	0	R	EXP	FVSY
4.1.23	1200	Dig input mon		UINT16	16BIT_L	0	0	0	R	ESY	FVSY
4.1.24	1202	Dig input mon x		UINT16	16BIT_L	0	0	0	R	ESY	
4.1.25	1400	Digital output mon		UINT16		0	0	0	R	ESY	FVSY
4.1.26	1402	Digital output mon x		UINT16		0	0	0	R	ESY	

### 4.2 DRIVE INFO

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.2.1	172	Drive type		ENUM		ADL510			R	ESY	FVSY
						1 - ADL510					
						2 - ADL530					
						3 - ADL550					
4.2.2	482	Drive Size		UINT16		0	0	0	R	ESY	FVSY
4.2.3	484	Drive Family		ENUM		No power			R	INT	FVSY
						0 - Ness Potenza					
						1 - 230V..480V					
4.2.4	488	Drive cont current	A	FLOAT	CALCF	0.0	0.0	0.0	R	ESY	FVSY
4.2.6	174	Firmware version		UINT32		0	0	0	R	ESY	FVSY
4.2.7	176	DSP Firmware version		UINT32		0	0	0	R	ESY	FVSY
4.2.8	180	DSP Boot version		UINT32		0	0	0	R	ESY	FVSY
4.2.9	182	HMI Boot version		UINT32		0	0	0	R	ESY	FVSY
4.2.10	184	Application name		STRING16		0	0	0	R	ESY	FVSY
4.2.11	192	Application version		UINT32		0	0	0	R	ESY	FVSY
4.2.12	198	Versione Hardware		UINT16		0	0	0	R	ESY	FVSY
4.2.13	520	Product S/N		UINT32		0	0	0	R	ESY	FVSY
4.2.14	522	Regulation S/N		UINT32		0	0	0	R	ESY	FVSY
4.2.15	524	Power S/N		UINT32		0	0	0	R	ESY	FVSY
4.2.16	526	Power file ver.rel		UINT16		0	0	0	R	ESY	FVSY
4.2.17	9562	IP address		UINT32		0	0	0	R	ESY	FVSY
4.2.18	9600	Mac address		STRING16		0	0	0	R	EXP	FVSY

### 4.3 DRIVE CONFIG \*

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.3.1	550	Save parameters		BIT		0	0	1	RWZ	ESY	FVSY
4.3.2	580	Load default		BIT		0	0	1	RWZ	ESY	FVSY
4.3.3	540	Control type		ENUM 0 - ASY SSC 1 - ASY FOC 2 - SYN FOC		ASY_VF			RWZ	INT	FVSY
4.3.4	554	Access level		ENUM 0 - Readonly 1 - Easy 2 - INT 3 - Expert 4 - Service		Intermediate			RW	ESY	FVSY
4.3.5	568	Enable Passwords		BIT		0	0	1	RW	EXP	FVSY
4.3.7	560	Mains voltage		ENUM 1 - 230 V 2 - 380 V 3 - 400 V 4 - 415 V 5 - 440 V 6 - 460 V 7 - 480 V		400 V			RWZ	INT	FVSY
4.3.8	448	Emergency UV	V	FLOAT	CALCF	0	CALCF	RWZ	INT	FVSY	
4.3.9	450	Undervoltage	V	FLOAT	300.0	0	0	RW	INT	FVSY	
4.3.10	2690	Chopper ON	V	FLOAT	CALCF	0	CALCF	RWZ	EXP	FVSY	
4.3.11	1010	Fast start disable		BIT		1	0	1	RW	EXP	FVSY
4.3.12	574	Startup display		INT16		-1	-1	20000	RW	INT	FVSY
4.3.13	576	Display backlight		BIT		0	0	1	RW	INT	FVSY
4.3.14	578	Language select		ENUM 0 - English 1 - Italian 2 - French 3 - German 4 - Spanish 5 - Turkish		GB			RW	INT	FVSY
4.3.15	7200	Password recovery		BIT		0	0	1	RW	ESY	FVSY
4.3.16	7210	Recovery code		UINT32		0.0	0	0	R	ESY	FVSY
4.3.17	7220	Logout time	min	UINT16		60	0	1092	RW	EXP	FVSY
4.3.18	590	Save par to keypad		BIT		0	0	1	RWZ	INT	FVSY
4.3.19	592	Load par from keypad		BIT		0	0	1	RWZ	INT	FVSY
4.3.20	596	Save to USB		BIT		0	0	1	RWZ	INT	
4.3.21	598	Load from USB		BIT		0	0	1	RWZ	INT	
4.3.23	1560	App Update		BIT		0	0	1	RWZ	INT	
4.3.24	9548	WiFi safe removal		BIT		0	0	1	RW	ESY	

\* Parameters 578, 590, 592, 596, 598, 1560, 9548 are only visible on keypad.

### 4.4 ALARM CONFIG

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.1	4500	Fault reset src		LINK L_DIGSEL2	16BIT_L	6000			RW	INT	FVSY
4.4.2	4502	ExtFlt src		LINK L_DIGSEL2	16BIT_L	6000			RW	INT	FVSY
4.4.3	4504	ExtFlt activity		ENUM 0 - Ignore 1 - Warning 2 - Disable drive 3 - Stop 4 - Fast stop		Disable			RW	INT	FVSY
4.4.4	4506	ExtFlt restart		ENUM 0 - Disable 1 - Enable		Disable			RW	EXP	FVSY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.4.5	4508	ExtFlt restart time	ms	UINT16		1000	120	30000	RW	EXP	FVSY
4.4.6	4510	ExtFlt holdoff	ms	UINT16		0	0	10000	RW	INT	FVSY
4.4.7	4518	MotorOT threshold	degC	INT16		150	0	200	RW	INT	
4.4.8	4520	MotorOT src		LINK	16BIT_L L_DIGSEL2	6000			RW	INT	FVSY
4.4.9	4522	MotorOT activity		ENUM		Warning			RW	INT	FVSY
						0 - Ignore					
						1 - Warning					
						2 - Disable drive					
						3 - Stop					
						4 - Fast stop					
4.4.10	4524	MotorOT restart		ENUM		Disable			RW	EXP	FVSY
						0 - Disable					
						1 - Enable					
4.4.11	4526	MotorOT restart time	ms	UINT16		1000	120	30000	RW	EXP	FVSY
4.4.12	4528	MotorOT holdoff	ms	UINT16		1000	0	30000	RW	EXP	FVSY
4.4.13	4530	Ptc type		ENUM		None			RW	INT	
						0 - None					
						1 - PTC					
						2 - KTY84-130					
4.4.14	4532	PtcFail activity		ENUM		Warning			RW	INT	
						0 - Ignore					
						1 - Warning					
						2 - Disable drive					
						3 - Stop					
						4 - Fast stop					
4.4.15	4534	PtcFail restart		ENUM		Disable			RW	EXP	
						0 - Disable					
						1 - Enable					
4.4.16	4536	PtcFail restart time	ms	UINT16		1000	120	30000	RW	EXP	
4.4.17	4538	PtcFail holdoff	ms	UINT16		1000	0	30000	RW	EXP	
4.4.18	4540	Overspeed threshold	rpm	INT16		CALCI	0	16000	RW	INT	FVSY
4.4.19	4542	Overspeed activity		ENUM		Disable			RW	INT	FVSY
						0 - Ignore					
						1 - Warning					
						2 - Disable drive					
4.4.20	4544	Overspeed holdoff	ms	UINT16		0	0	5000	RW	INT	FVSY
4.4.21	4550	SpdRefLoss threshold	rpm	INT16		100	0	CALCI	RW	INT	FVSY
4.4.22	4552	SpdRefLoss activity		ENUM		Disable			RW	INT	FVSY
						0 - Ignore					
						1 - Warning					
						2 - Disable drive9					
4.4.23	4554	SpdRefLoss holdoff	ms	UINT16		1000	0	10000	RW	INT	FVSY
4.4.24	4560	SpdFbkLoss activity		ENUM		Disable			RW	INT	FVSY
						0 - Ignore					
						1 - Warning					
						2 - Disable drive					
4.4.25	4562	SpdFbkLoss holdoff	ms	UINT16		200	0	10000	RW	INT	FVSY
4.4.26	4564	SpdFbkLoss Threshold	rpm	INT16		100	0	CALCI	RW	INT	FVSY
4.4.27	4570	Drive ovld activity		ENUM		Disable			RW	EXP	FVSY
						0 - Ignore					
						1 - Warning					
						2 - Disable drive					
						3 - Stop					
						4 - Fast stop					
4.4.28	4572	Motor ovld activity		ENUM		Warning			RW	EXP	FVSY
						0 - Ignore					
						1 - Warning					
						2 - Disable drive					
						3 - Stop					
						4 - Fast stop					
4.4.29	4574	Bres ovld activity		ENUM		Disable			RW	EXP	FVSY
						0 - Ignore					
						1 - Warning					
						2 - Disable drive					
						3 - Stop					
						4 - Fast stop					
4.4.30	4582	HTsens restart		ENUM		Disable			RW	EXP	FVSY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
				0 - Disable 1 - Enable							
4.4.31	4584	HTsens restart time	ms	UINT16		20000	120	60000	RW	EXP	FVSY
4.4.32	4610	Desat restart		ENUM		Disable			RW	EXP	FVSY
				0 - Disable 1 - Enable							
4.4.33	4612	Desat restart time	ms	UINT16		2000	1000	10000	RW	EXP	FVSY
4.4.34	4620	IOverC restart		ENUM		Disable			RW	EXP	FVSY
				0 - Disable 1 - Enable							
4.4.35	4622	IOverC restart time	ms	UINT16		2000	1000	10000	RW	EXP	FVSY
4.4.36	4630	OverV restart		ENUM		Disable			RW	EXP	FVSY
				0 - Disable 1 - Enable							
4.4.37	4632	OverV restart time	ms	UINT16		2000	1000	10000	RW	EXP	FVSY
4.4.38	4640	UnderV restart		ENUM		Enable			RW	EXP	FVSY
				0 - Disable 1 - Enable							
4.4.39	4642	UnderV restart time	ms	UINT16		1000	120	10000	RW	EXP	FVSY
4.4.40	4650	UVRep attempts		UINT16		5	0	1000	RW	EXP	FVSY
4.4.41	4652	UVRep delay	s	UINT16		240	0	300	RW	EXP	FVSY
4.4.42	4654	PhLoss mov activity		ENUM		Warning			RW	EXP	FVSY
				0 - Ignore 1 - Warning 2 - Disable							
4.4.43	4656	PhLoss mov HOLDOFF	ms	UINT32		200	0	2000	RW	EXP	FVSY
				0 - Ignore 1 - Warning 2 - Disable							
4.4.44	4674	PhLoss mov freq thr	Hz	FLOAT		0.5	0.1	5	RW	EXP	FVSY
4.4.45	4678	PhLoss mov freq thr	Hz	FLOAT		0	0	0	R	EXP	FVSY
4.4.46	4670	Optionbus activity		ENUM		Disable			RW	EXP	FVSY
				0 - Ignore 1 - Warning 2 - Disable drive 3 - Stop 4 - Fast stop							
4.4.47	4660	PhLoss in activity		ENUM		Disable			RW	EXP	FVSY
				0 - Ignore 1 - Warning 2 - Disable drive							
4.4.48	4662	PhLoss in restart		ENUM		Disable			RW	EXP	FVSY
				0 - Disable 1 - Enable							
4.4.49	4664	PhLoss in rest time	ms	UINT16		1000	120	10000	RW	EXP	FVSY
4.4.50	4668	PhLoss output test		ENUM		Enable			RW	EXP	FVSY
				0 - Disabled 1 - Enable 2 - Powerup							
4.4.51	4680	GroundFault thr	%	FLOAT		10.0	0.0	150.0	RW	INT	FVSY
4.4.52	4700	Alarm dig out 1 sel		ENUM		No alarm			RW	INT	FVSY
4.4.52	4702	Alarm dig out 2 sel		ENUM		No alarm			RW	INT	FVSY
4.4.53	4704	Alarm dig out 3 sel		ENUM		No alarm			RW	INT	FVSY
4.4.54	4706	Alarm dig out 4 sel		ENUM		No alarm			RW	INT	FVSY
				0 - No alarm 1 - Overvoltage 2 - Undervoltage 3 - Ground fault 4 - Overcurrent 5 - Desaturation 6 - MultiUndervolt 7 - MultiOvercurr 8 - MultiDesat 9 - Heatsink OT 10 - HeatsinkS OTUT 11 - Ptc failure 12 - Motor OT							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.	
					13 - Drive overload 14 - Motor overload 15 - Bres overload 16 - Phaseloss in 17 - Opt Bus fault 18 - Opt 1 IO fault 19 - Precharge faul 20 - Opt enc fault 21 - External fault 22 - Speed fbk loss 23 - Overspeed 24 - Speed ref loss 25 - Emg stop alarm 26 - Power down 27 - Phaseloss out 28 - OV safety 29 - Safety failure 30 - Phaseloss mov 31 - Ropes change 32 - Enable missing 33 - Plc1 fault 34 - Plc2 fault 35 - Plc3 fault 36 - Plc4 fault 37 - Plc5 fault 38 - Plc6 fault 39 - Plc7 fault 40 - Plc8 fault 41 - Plc9 fault 42 - Plc10 fault 43 - Plc11 fault 44 - Plc12 fault 45 - Plc13 fault 46 - Plc14 fault 47 - Plc15 fault 48 - Plc16 fault 49 - Watchdog 50 - Trap error 51 - System error 52 - User error 53 - Param error 54 - Load def par 55 - Plc cfg error 56 - Load def plc 57 - Key failed 58 - Encoder error 59 - Recovery mode							
4.4.55	4720	Alm autoreset time	s	FLOAT		0.0	0.0	60.0	RW	EXP	FVSY	
4.4.57	4722	Alm autoreset number		UINT16		3	0	100	RW	EXP	FVSY	

## 4.8 DIGITAL INPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.1	1240	Dig inp 1 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.2	1242	Dig inp 2 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.3	1244	Dig inp 3 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.4	1246	Dig inp 4 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.5	1248	Dig inp 5 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.6	1250	Dig inp 6 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.7	1252	Dig inp 7 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.8	1254	Dig inp 8 inversion		BIT		0	0	1	RW	INT	FVSY
4.8.9	1260	Dig inp 1x inversion		BIT		0	0	1	RW	INT	
4.8.10	1262	Dig inp 2x inversion		BIT		0	0	1	RW	INT	
4.8.11	1264	Dig inp 3x inversion		BIT		0	0	1	RW	INT	
4.8.12	1266	Dig inp 4x inversion		BIT		0	0	1	RW	INT	
4.8.13	1110	Dig input E mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.14	1210	Dig input 1 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.15	1212	Dig input 2 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.16	1214	Dig input 3 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.17	1216	Dig input 4 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.18	1218	Dig input 5 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.19	1220	Dig input 6 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.8.20	1222	Dig input 7 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.21	1224	Dig input 8 mon		UINT16	16BIT_L	0	0	0	R	EXP	FVSY
4.8.22	1230	Dig input 1x mon		UINT16	16BIT_L	0	0	0	R	EXP	
4.8.23	1232	Dig input 2x mon		UINT16	16BIT_L	0	0	0	R	EXP	
4.8.24	1234	Dig input 3x mon		UINT16	16BIT_L	0	0	0	R	EXP	
4.8.25	1236	Dig input 4x mon		UINT16	16BIT_L	0	0	0	R	EXP	
4.8.26	1268	Dig input E dest		ILINK		0	0	0	R	EXP	FVSY
4.8.27	1270	Dig input 1 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.28	1272	Dig input 2 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.29	1274	Dig input 3 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.30	1276	Dig input 4 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.31	1278	Dig input 5 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.32	1280	Dig input 6 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.33	1282	Dig input 7 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.34	1284	Dig input 8 dest		ILINK		0	0	0	R	EXP	FVSY
4.8.35	1290	Dig input 1x dest		ILINK		0	0	0	R	EXP	
4.8.36	1292	Dig input 2x dest		ILINK		0	0	0	R	EXP	
4.8.37	1294	Dig input 3x dest		ILINK		0	0	0	R	EXP	
4.8.38	1296	Dig input 4x dest		ILINK		0	0	0	R	EXP	

## 4.9 DIGITAL OUTPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.9.1	1430	Dig out 1 inversion		BIT		0	0	1	RW	INT	FVSY
4.9.2	1432	Dig out 2 inversion		BIT		0	0	1	RW	INT	FVSY
4.9.3	1434	Dig out 3 inversion		BIT		0	0	1	RW	INT	FVSY
4.9.4	1436	Dig out 4 inversion		BIT		0	0	1	RW	INT	FVSY
4.9.5	1440	Dig out 1x inversion		BIT		0	0	1	RW	INT	
4.9.6	1442	Dig out 2x inversion		BIT		0	0	1	RW	INT	

## 4.10 ANALOG INPUTS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.10.1	1600	Analog input mon	cnt	INT16	16BIT_H	0	0	0	R	ESY	FVSY
4.10.2	1602	Analog inp type		ENUM		-10V..+10V			RW	INT	FVSY
						0 - -10V..+10V					
						1 - 0.20mA , 0.10V					
						2 - 4..20mA					
4.10.3	1604	Analog inp scale		FLOAT		1.0	-10.0	10.0	RW	INT	FVSY
4.10.4	1606	An inp offset tune		BIT		0	0	1	RW	INT	FVSY
4.10.5	1608	An inp gain tune		BIT		0	0	1	RW	INT	FVSY
4.10.6	1610	Analog inp filter	ms	FLOAT		10	2	100	RW	EXP	FVSY
4.10.7	1612	Analog inp top	cnt	INT16		16384	-32768	+32767	RW	EXP	FVSY
4.10.8	1614	Analog inp bottom	cnt	INT16		-16384	-32768	+32767	RW	EXP	FVSY
4.10.9	1616	Analog inp offset	cnt	INT16		0	-32768	+32767	RW	EXP	FVSY
4.10.10	1618	Analog inp gain		FLOAT		1.0	-10.0	10.0	RW	EXP	FVSY
4.10.11	1626	An inp sign src		LINK	16BIT_L L_DIGSEL2	6000			RW	INT	FVSY
4.10.12	1632	Analog input dest		ILINK		0	0	0	R	EXP	FVSY

## 4.11 ALARM LOG

## 4.12 LIFE TIME

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
4.12.1	510	Time drive power on	h:min	UINT32		0	0	0	R	ESY	FVSY
4.12.2	512	Time drive enable	h:min	UINT32		0	0	0	R	ESY	FVSY
4.12.3	514	Number power up		UINT16		0	0	0	R	ESY	FVSY
4.12.4	516	Time fan on	h:min	UINT32		0	0	0	R	ESY	FVSY

## 5 LIFT

### 5.1 MONITOR

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.1.1	14014	Trip number		UINT32			-	-	R	ESY	FVY
5.1.2	14016	Sequence state		ENUM			-	-	R	ESY	FVY
				0 - Idle							
				1 - Cont close							
				2 - Drive ready							
				3 - Brake open							
				4 - Smooth start							
				5 - Multispeed							
				6 - Waiting 0 spd							
				7 - Zero speed							
				8 - Brake close							
				9 - Cont open							
				10 - Not drive ok							
				91- SC cont mon							
5.1.3	14030	Acceleration space	m	FLOAT			-	-	R	ESY	FVY
5.1.4	14032	Deceleration space	m	FLOAT			-	-	R	ESY	FVY
5.1.5	14034	Landing zone space	m	FLOAT			-	-	R	ESY	FVY
5.1.6	14210	Actual speed ref	m/s	FLOAT			-	-	R	ESY	FVY
5.1.7	14242	Actual cabin spd	m/s	FLOAT			-	-	R	ESY	FVY

### 5.2 MECHANICAL DATA

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.2.1	11002	Travel units sel		ENUM		Hz (m/s)	-	-	RWZ	INT	FVY
				0 - Hz							
				1 - m/s							
				2 - rpm							
5.2.2	11006	Cabin speed	m/s	FLOAT		1	0	10	RWZ	INT	FVY
5.2.3	11010	Gearbox ratio		FLOAT		45 (1)	1	200	RW	INT	FVY
5.2.4	11164	Rope ratio		FLOAT		1 (2)	1	10	RWZ	INT	FVY
5.2.5	11012	Pulley diameter	m	FLOAT		0.6 (0.32)	0	5	RWZ	INT	FVY
5.2.6	11150	Car weight	kg	FLOAT		400	0	10000	RW	INT	FVY
5.2.7	11152	Counter weight	kg	FLOAT		1000	0	10000	RW	INT	FVY
5.2.8	11154	Load weight	kg	FLOAT		450	0	10000	RW	INT	FVY
5.2.9	11156	Rope weight	kg	FLOAT		20	0	1000	RW	INT	FVY

### 5.3 SPEED

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.3.1	11020	Multi speed 0		FLOAT		5 (0.1)	0	10000	RW	ESY	FVY
5.3.2	11022	Multi speed 1		FLOAT		47.73 (1.0)	0	10000	RW	ESY	FVY
5.3.3	11024	Multi speed 2		FLOAT		20 (0.4)	0	10000	RW	ESY	FVY
5.3.4	11026	Multi speed 3		FLOAT		0	0	10000	RW	ESY	FVY
5.3.5	11028	Multi speed 4		FLOAT		0	0	10000	RW	ESY	FVY
5.3.6	11030	Multi speed 5		FLOAT		0	0	10000	RW	ESY	FVY
5.3.7	11032	Multi speed 6		FLOAT		0	0	10000	RW	ESY	FVY
5.3.8	11034	Multi speed 7		FLOAT		0	0	10000	RW	ESY	FVY
5.3.9	14010	Actual multi spd sel		ENUM					R	ESY	FVY
				0 - Multispeed 0							
				1 - Multispeed 1							
				2 - Multispeed 2							
				3 - Multispeed 3							
				4 - Multispeed 4							
				5 - Multispeed 5							
				6 - Multispeed 6							
				7 - Multispeed 7							
				8 - Null							

## 5.4 RAMPS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.4.1	11040	Accel initial jerk	m/s <sup>3</sup>	FLOAT		0.2	0.001	20	RW	ESY	FVY
5.4.2	11042	Acceleration	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY
5.4.3	11044	Accel end jerk	m/s <sup>3</sup>	FLOAT		0.6	0.001	20	RW	ESY	FVY
5.4.4	11054	Percent acc factor	%	FLOAT		100	10	1000	RW	INT	FVY
5.4.5	11046	Decel initial jerk	m/s <sup>3</sup>	FLOAT		0.6	0.001	20	RW	ESY	FVY
5.4.6	11048	Deceleration	m/s <sup>2</sup>	FLOAT		0.600	0.001	10	RW	ESY	FVY
5.4.7	11050	Decel end jerk	m/s <sup>3</sup>	FLOAT		0.600	0.001	20	RW	ESY	FVY
5.4.8	11056	Percent dec factor	%	FLOAT		100	10	1000	RW	INT	FVY
5.4.9	11052	Stop deceleration	m/s <sup>2</sup>	FLOAT		0.6	0.001	10000	RW	ESY	FVY

## 5.5 SEQUENCES

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.5.1	11060	Sequence start stop		ENUM		Start fwd/rev	-	-	RWZ	ESY	FVY
						0 - Start fwd/rev					
						1 - Enable					
						2 - Mltspd out != 0					
5.5.2	11084	Smooth start mode		ENUM		Variable jerk	-	-	RWZ	INT	FVY
						1 - Speed constant					
						2 - Jerk variable					
5.5.3	11082	Smooth start speed		FLOAT		0	0	10000	RW	INT	FVY
5.5.4	11066	Smooth start time	ms	INT16/32		0	0	10000	RW	INT	FVY
5.5.5	11062	Contactor close dly	ms	INT16/32		200	0	10000	RW	ESY	FVY
5.5.6	11064	Brake open delay	ms	INT16/32		500	0	10000	RW	ESY	FVY
5.5.7	11078	Speed 0 threshold	rpm	INT16		30 (1)	0	10000	RW	INT	FVY
5.5.8	11080	Speed 0 delay	ms	UINT16		400	0	10000	RW	INT	FVY
5.5.9	11086	Door open speed	m/s	FLOAT		0	-10000	10000	RWZ	EXP	FVY
5.5.10	11070	Current down delay	ms	INT16/32		0 (800)	0	10000	RW	INT	Y
5.5.11	11068	Brake close delay	ms	INT16/32		500	0	10000	RW	ESY	FVY
5.5.12	11072	Contactor open dly	ms	INT16/32		200	0	10.000	RW	ESY	FVY
5.5.13	11074	SC cont open delay	ms	INT16/32		0 (500)	0	2000	RW	EXP	Y
5.5.14	11826	Inspection behaviour		ENUM		None	-	-	RWZ	EXP	FVY
						0 - None					
						1 - Fast Stop					
						2 - Immediate					
5.5.15	11828	Inspection spd sel		ENUM		Multispeed 2	-	-	RWZ	INT	FVY
						0 - Multispeed 0					
						1 - Multispeed 1					
						2 - Multispeed 2					
						3 - Multispeed 3					
						4 - Multispeed 4					
						5 - Multispeed 5					
						6 - Multispeed 6					
						7 - Multispeed 7					
						8 - Null					
5.5.16	11244	Inversion motor rot		LINK		Not inverted			RWZ	INT	FVY
						0 - Not inverted					
						1 - Inverted					

## 5.6 LIFT OUT

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.6.1	1410	Dig output 1 src		LINK	16BIT_L	6000			RW	INT	FVSY
					L_DIGSEL1						
5.6.2	1412	Dig output 2 src		LINK	16BIT_L	6000			RW	INT	FVSY
					L_DIGSEL1						
5.6.3	1414	Dig output 3 src		LINK	16BIT_L	6000			RW	INT	FVSY
					L_DIGSEL1						
5.6.4	1416	Dig output 4 src		ENUM	16BIT_L	6000			RW	INT	FVSY
					L_DIGSEL1						
5.6.5	1420	Dig output 1x src		ENUM	16BIT_L	6000			RW	INT	
					L_DIGSEL1						
5.6.6	1422	Dig output 2x src		ENUM					RW	INT	
5.6.7	11016	Rit uscita Abil Lift	ms	UINT	0	0	5000		RW	EXP	FVY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.6.8	14104	Command output mon	Hex		UINT32				R	ESY	FVY

## 5.7 LIFT IN

Menu	PAR	Description	UM	Tipo	FB BIT	Def	Min	Max	Acc	Liv.	Vis.
5.7.1	11220	Lift enable cmd src		ENUM		Dig input E mon	-	-	RW	INT	FVY
				LiftInputAdlCmd							
5.7.2	11222	Start fwd cmd src		ENUM		Dig input 1 mon	-	-	RW	INT	FVY
				LiftInputAdlCmd							
5.7.3	11224	Start rev cmd src		ENUM		Dig input 2 mon	-	-	RW	INT	FVY
				LiftInputAdlCmd							
5.7.4	11256	Speed ref src		ENUM		Multispeed	-	-	RW	INT	FVY
				640 - Multispeed							
				1600 - Analog in 1							
				4034 - Fieldbus M->S2							
				4044 - Fieldbus M->S3							
				4054 - Fieldbus M->S4							
				4064 - Fieldbus M->S5							
				4074 - Fieldbus M->S6							
				4084 - Fieldbus M->S7							
				4094 - Fieldbus M->S8							
				4104 - Fieldbus M->S9							
				4114 - Fieldbus M->S10							
				4124 - Fieldbus M->S11							
				4134 - Fieldbus M->S12							
				4144 - Fieldbus M->S13							
				4154 - Fieldbus M->S14							
				4164 - Fieldbus M->S15							
				4174 - Fieldbus M->S16							
5.7.5	11226	Multi speed S0 src		ENUM		Dig input 4 mon	-	-	RW	ESY	FVY
				LiftInputAdlCmd							
5.7.6	11228	Multi speed S1 src		ENUM		Dig input 5 mon	-	-	RW	ESY	FVY
				LiftInputAdlCmd							
5.7.7	11230	Multi speed S2 src		ENUM		Dig input 6 mon	-	-	RW	ESY	FVY
				LiftInputAdlCmd							
5.7.8	11232	Contactor fbk src		ENUM		Run cont mon	-	-	RW	INT	FVY
				LiftInputAdlCmd							
5.7.9	11236	Brake fbk src		ENUM		Brake cont mon	-	-	RW	INT	FVY
				LiftInputAdlCmd							
5.7.10	10096	Brake 2 fbk src		ENUM		Brake cont mon	-	-	RW	INT	FVY
				LiftInputAdlCmd							
5.7.11	11238	Door open src		ENUM		Null	-	-	RW	EXP	FVY
				LiftInputDoorCmd							
5.7.12	11240	Door feedback src		ENUM		Null	-	-	RW	EXP	FVY
				LiftInputAdlCmd							
5.7.13	11242	Emergency mode src		ENUM		Dig input 3 mon	-	-	RW	INT	FVY
				LiftInputAdlCmd							
5.7.14	11246	Upper limit src		ENUM		Null	-	-	RW	INT	FVY
				LiftInputAdlCmd							
5.7.15	11248	Lower limit src		ENUM		Null	-	-	RW	INT	FVY
				LiftInputAdlCmd							
5.7.17	11274	Landing Cmd src		ENUM		Null	-	-	RW	INT	FVY
				LiftInputAdlCmd							
5.7.18	11820	Brake release src		LINK		Null	-	-	RW	EXP	VY
				LiftInputAdlCmd							
5.7.20	14102	Command input mon	Hex	UINT32			-	-	R	ESY	FVY

## 5.8 PRE TORQUE

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.8.1	11166	Pre-torque enable		BIT		Off	-	-	RWZ	EXP	VY
5.8.2	11168	Pre-torque source		ENUM		Init pretorque	-	-	RW	EXP	VY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
				1600 - Analog in 1							
				4034 - Fieldbus M->S2							
				4044 - Fieldbus M->S3							
				4054 - Fieldbus M->S4							
				4064 - Fieldbus M->S5							
				4074 - Fieldbus M->S6							
				4084 - Fieldbus M->S7							
				4094 - Fieldbus M->S8							
				4104 - Fieldbus M->S9							
				4114 - Fieldbus M->S10							
				4124 - Fieldbus M->S11							
				4134 - Fieldbus M->S12							
				4144 - Fieldbus M->S13							
				4154 - Fieldbus M->S14							
				4164 - Fieldbus M->S15							
				4174 - Fieldbus M->S16							
				11170 - Init pretorque							
5.8.3	11170	Init pre-torque	%	INT16/32	0	-100	100		RWZ	EXP	VY
5.8.4	11172	Pre-torque ramp up	ms	INT16/32	0	0	10000		RWZ	EXP	VY
5.8.5	11174	Pre-torque ramp down	ms	INT16/32	0	0	60000		RWZ	EXP	VY
5.8.6	11176	Pre-torque offset	%	FLOAT	0	-100	100		RWZ	EXP	VY
5.8.7	11178	Pre-torque gain		FLOAT	1.0	-100	100		RWZ	EXP	VY
5.8.8	14040	Pre-torque input	%	INT16/32		-	-		R	EXP	VY
5.8.9	14056	Pre-torque out	%	INT16/32		-	-		R	EXP	VY
5.8.10	14058	Torque reference	%	INT16/32		-	-		R	EXP	VY

## 5.9 LIFT EMERGENCY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.9.1	11286	Battery control		ENUM		Disable	-	-	RWZ	INT	FVY
				0 - Disable							
				1 - Enable							
5.9.2	11260	Emergency mode speed		FLOAT		4.77 (0.1)	-10000	10000	RW	INT	FVY
5.9.3	11262	Autoselect direction		ENUM		Recommended			RWZ	INT	FVY
				0 - OFF							
				1 - AutoSelect							
				2 - Recommended							
				3 - Battery saving							
				4 - BattSav + Rec							
5.9.4	11278	Em DC brk current	%	FLOAT	75.0	0	150		RW	INT	FV
5.9.5	11284	Detection limit	%	UINT32	20	0	100		RWZ	INT	FVY
5.9.6	14282	Chosen Direction		ENUM	-	-	-	-	R	INT	
				0 - No direction							
				1 - Forward							
				2 - Reverse							
5.9.7	11094	Brake release type		ENUM		Brake + Gear	-	-	RW	EXP	VY
				0 - Brake							
				1 - Brake + Gear							
5.9.8	11090	Em min speed		FLOAT	0.05	0	10000		RW	EXP	VY
5.9.9	11092	Em min spd time	s	INT16/32	6	1	30		RW	EXP	VY
5.9.10	11108	Delay mot sav bat	m/s	INT32	1000	0	5000		RW	EXP	VY
5.9.11	11822	Max vel em		UINT32	0.1	-	-		RW	EXP	VY
5.9.12	11014	Em mac speed sav bat	Hz	FLOAT	0.09	0.01	1000		RW	EXP	VY
5.9.13	11824	Brake lock time	s	UINT32	4	1	30		RW	EXP	VY

## 5.10 LIFT ALARMS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.1	11058	Lift fast stop fact		FLOAT		10	1	50	RWZ	INT	FVY
5.10.2	11200	Contactor activity		ENUM		Disable			RWZ	INT	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.10.3	11202	Cont hold off	ms	INT32		1000	0	60000	RW	INT	FVY
5.10.4	11204	Brake activity		ENUM		Disable			RWZ	INT	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							
5.10.5	11206	Brake hold off	ms	INT32		1000	0	60000	RW	INT	FVY
5.10.6	10094	Brake 2 hold off	ms	INT32		1000	0	60000	RW	INT	FVY
5.10.7	11208	Brake run hold off		ENUM		Enable	-	-	RW	INT	FVY
				0 - Disable							
				1 - Enable							
5.10.8	11210	Door activity		ENUM		Disable	-	-	RWZ	EXP	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							
5.10.9	11212	Door hold off	ms	INT32		1000	0	60000	RW	EXP	FVY
5.10.10	11214	Limit activity		ENUM		Lift fast stop	-	-	RWZ	INT	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							
5.10.11	11216	Limit speed thr	m/s	FLOAT		1	0	10	RW	INT	FVY
5.10.12	11218	Spd target activity		ENUM		Warning			RWZ	INT	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							
5.10.13	11258	Lift EF alarm src		ENUM		Null	-	-	RWZ	INT	FVY
				6000 - Null							
				6002 - One							
				12250 - B0 Lift decomp							
				12252 - B1 Lift decomp							
				12254 - B2 Lift decomp							
				12256 - B3 Lift decomp							
				12258 - B4 Lift decomp							
				12260 - B5 Lift decomp							
				12262 - B6 Lift decomp							
				12264 - B7 Lift decomp							
				12266 - B8 Lift decomp							
				12268 - B9 Lift decomp							
				12270 - B10 Lift decomp							
				12272 - B11 Lift decomp							
				12274 - B12 Lift decomp							
				12276 - B13 Lift decomp							
				12278 - B14 Lift decomp							
				12280 - B15 Lift decom							
				1110 - Dig input E mon							
				1210 - Dig input 1 mon							
				1212 - Dig input 2 mon							
				1214 - Dig input 3 mon							
				1216 - Dig input 4 mon							
				1218 - Dig input 5 mon							
				1220 - Dig input 6 mon							
				1222 - Dig input 7 mon							
				1224 - Dig input 8 mon							
				1230 - Dig input 1x mon							
				1232 - Dig input 2x mon							
				1234 - Dig input 3x mon							
				1236 - Dig input 4x mon							
				3702 - Run cont mon							
				3706 - Down cont mon							
				3708 - Brake cont mon							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
3714 - Door open mon											
5.10.14	11264	Lift EF al activity		ENUM		Lift stop	-	-	RWZ	INT	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							
5.10.15	11266	Lift EF hold off	ms	UINT32		1000	0	60000	RW	INT	FVY
5.10.17	11850	No battery activity		ENUM		Warning	-	-	RWZ	INT	FVY
				0 - Ignore							
				1 - Warning							
				2 - Disable drive							
				3 - Fast stop							
				4 - Lift fast stop							
				5 - Lift stop							
5.10.18	11852	No battery hold off	ms	UINT32		1000	0	10000	RW	INT	FVY

## 5.11 DISTANCE

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.11.1	11102	Distance multispeed0	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.2	11104	Distance multispeed1	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.3	11106	Distance multispeed2	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.4	11110	Distance multispeed3	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.5	11112	Distance multispeed4	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.6	11114	Distance multispeed5	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.7	11116	Distance multispeed6	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.8	11118	Distance multispeed7	m	FLOAT		0.000	0	400	RW	INT	FVY
5.11.9	11120	Slow speed		ENUM		Autoselect	-	-	RW	INT	FVY
				0 - Autoselect							
				1 - Multispeed 0							
				2 - Multispeed 1							
				3 - Multispeed 2							
				4 - Multispeed 3							
				5 - Multispeed 4							
				6 - Multispeed 5							
				7 - Multispeed 6							
				8 - Multispeed 7							
				9 - Null							
5.11.10	11130	Enable landing src		INT16		Off			RW	EXP	FVY
5.11.11	11132	Landing zone dist	m	FLOAT		0.120	0	10	RW	EXP	FVY
5.11.12	11138	Out floor function		BIT		Off			RW	EXP	FVY
5.11.13	11140	Delay acq time	ms	FLOAT		15	0	1000	RW	EXP	FVY
5.11.14	11142	Calc space HiSpd sel		UINT16		Multispeed 1	-	-	RW	EXP	FVY
				0 - Multispeed 0							
				1 - Multispeed 1							
				2 - Multispeed 2							
				3 - Multispeed 3							
				4 - Multispeed 4							
				5 - Multispeed 5							
				6 - Multispeed 6							
				7 - Multispeed 7							
				8 - Null							
5.11.15	11276	KP Landing		FLOAT		0	0	100	RW	EXP	FVY

## 5.14 DIRECTION CNT

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
5.14.1	3400	Direction cnt enable		ENUM		Disable			RW	EXP	FVSY
				0 - Off							
				1 - On							
5.14.2	3402	Max direcion cnt		UINT32		0	0	2147483647	RW	EXP	FVSY
5.14.3	3404	Ropes change thr	%	UINT32		98	0	100	RW	EXP	FVSY
5.14.4	3406	Direction cnt reset		BIT		0	0	1	RW	EXP	FVSY
				0 - Off							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
1 - On											
5.14.5	3408	Inser pssw dir cnt		UINT32		0	0	999999	RW	EXP	FVSY
5.14.6	3410	Nuova pssw dir cnt		UINT32		0	0	999999	RW	EXP	FVSY
5.14.7	3412	Ropes usage	%	UINT16	16BIT_L	0	0	0	R	EXP	FVSY
5.14.8	3414	Direction counter		UINT32	32BIT	0	0	0	R	EXP	FVSY
5.14.9	3416	Prev direct counter		UINT32	32BIT	0	0	0	R	EXP	FVSY
5.14.10	3418	No of cnt reset		UINT32	32BIT	0	0	0	R	EXP	FVSY
5.14.11	3420	Ropes change req mon		BIT	16BIT_L	0	0	1	R	EXP	FVSY
5.14.12	3422	Dir change monitor		BIT	16BIT_L	0	0	1	R	EXP	FVSY
5.14.13	3424	Dir change cnt zero		BIT	16BIT_L	0	0	1	R	EXP	FVSY
5.14.14	3434	Save rope to USB		BIT		0	0	1	RWZ	EXP	
5.14.15	3436	Load rope from USB		BIT		0	0	1	RWZ	EXP	
5.14.16	3440	Dircnt password type		ENUM		Static	-	-	RW	EXP	FVSY
5.14.17	3442	Pwd code build		BIT		0	0	1	RW	EXP	FVSY
5.14.18	3444	Pwd code		UINT32		0.0	0	0	R	EXP	

## 6 COMMUNICATION

### 6.1 CONTROL COMMUNICATION (CONTROL COMM)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.1.1	4000	Communication mode		ENUM		Parallel			RW	INT	FVSY
				0 - Parallel I/O							
				1 - CanOpen							
				2 - DCP		(Under development)					
				3 - CAN417		(Under development)					
6.1.2	3800	Drive address		UINT16		1	1	255	RW	EXP	
6.1.3	3802	Serial baudrate		ENUM		38400			RW	EXP	
				0 - 9600							
				1 - 19200							
				2 - 38400							
6.1.4	3806	Serial delay	ms	UINT16		0	0	1000	RW	EXP	
6.1.5	3810	Serial parameter		ENUM		N_8_1			RW	EXP	
				0 - None,8,1							
				1 - None,8,2							
				2 - Even,8,1							
				3 - Odd,8,1							
6.1.6	4004	Fieldbus baudrate		ENUM		250k	0	4	RW	EXP	
				1 - 125k							
				2 - 250k							
				3 - 500k							
				4 - 1M							
6.1.7	4006	Fieldbus address		INT16		2	1	127	RW	EXP	
6.1.8	4010	Fieldbus M->S enable		ENUM		Enable			RWZ	EXP	
				0 - Disable							
				1 - Enable							
6.1.9	4012	Fieldbus alarm mode		INT32		0	0	1	RWZ	EXP	
6.1.10	4014	Fieldbus state		ENUM		Stop			R	EXP	
				0 - Stop							
				1 - PreOperational							
				2 - Operational							
6.1.11	4338	Fieldbus error		UINT16		0	0	0	R	EXP	
6.1.12	4008	Can termin.resistor		ENUM		Off			RW	EXP	
				0 - Off							
				1 - On							

### 6.2 FIELDBUS M2S

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.2.1	4020	Fieldbus M->S1 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.2	4022	Fieldbus M->S1 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
				4 - Fill 32 5 - Mdplc 16 6 - Mdplc 32 7 - Eu 8 - Eu float 9 - Par 16 10 - Par 32							
6.2.3	4024	Fieldbus M->S1 mon	INT32	32BIT	0	0	0	R	EXP		
6.2.4	4026	Fieldbus M->S1 div	FLOAT		1	1	1000	RW	EXP		
6.2.5	4030	Fieldbus M->S2 ipa	FBM2SIPA		0	0	20000	RW	EXP		
6.2.6	4032	Fieldbus M->S2 sys	ENUM		Not assigned			RW	EXP		
			0 - Not assigned 1 - Count 16 2 - Count 32 3 - Fill 16 4 - Fill 32 5 - Mdplc 16 6 - Mdplc 32 7 - Eu 8 - Eu float 9 - Par 16 10 - Par 32								
6.2.7	4034	Fieldbus M->S2 mon	INT32	32BIT	0	0	0	R	EXP		
6.2.8	4036	Fieldbus M->S2 div	FLOAT		1	1	1000	RW	EXP		
6.2.9	4040	Fieldbus M->S3 ipa	FBM2SIPA		0	0	20000	RW	EXP		
6.2.10	4042	Fieldbus M->S3 sys	ENUM		Not assigned			RW	EXP		
			0 - Not assigned 1 - Count 16 2 - Count 32 3 - Fill 16 4 - Fill 32 5 - Mdplc 16 6 - Mdplc 32 7 - Eu 8 - Eu float 9 - Par 16 10 - Par 32								
6.2.11	4044	Fieldbus M->S3 mon	INT32	32BIT	0	0	0	R	EXP		
6.2.12	4046	Fieldbus M->S3 div	FLOAT		1	1	1000	RW	EXP		
6.2.13	4050	Fieldbus M->S4 ipa	FBM2SIPA		0	0	20000	RW	EXP		
6.2.14	4052	Fieldbus M->S4 sys	ENUM		Not assigned			RW	EXP		
			0 - Not assigned 1 - Count 16 2 - Count 32 3 - Fill 16 4 - Fill 32 5 - Mdplc 16 6 - Mdplc 32 7 - Eu 8 - Eu float 9 - Par 16 10 - Par 32								
6.2.15	4054	Fieldbus M->S4 mon	INT32	32BIT	0	0	0	R	EXP		
6.2.16	4056	Fieldbus M->S4 div	FLOAT		1	1	1000	RW	EXP		
6.2.17	4060	Fieldbus M->S5 ipa	FBM2SIPA		0	0	20000	RW	EXP		
6.2.18	4062	Fieldbus M->S5 sys	ENUM		Not assigned			RW	EXP		
			0 - Not assigned 1 - Count 16 2 - Count 32 3 - Fill 16 4 - Fill 32 5 - Mdplc 16 6 - Mdplc 32 7 - Eu 8 - Eu float 9 - Par 16 10 - Par 32								
6.2.19	4064	Fieldbus M->S5 mon	INT32	32BIT	0	0	0	R	EXP		
6.2.20	4066	Fieldbus M->S5 div	FLOAT		1	1	1000	RW	EXP		
6.2.21	4070	Fieldbus M->S6 ipa	FBM2SIPA		0	0	20000	RW	EXP		

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.2.22	4072	Fieldbus M->S6 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.2.23	4074	Fieldbus M->S6 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.24	4076	Fieldbus M->S6 div		FLOAT		1	1	1000	RW	EXP	
6.2.25	4080	Fieldbus M->S7 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.26	4082	Fieldbus M->S7 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.2.27	4084	Fieldbus M->S7 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.28	4086	Fieldbus M->S7 div		FLOAT		1	1	1000	RW	EXP	
6.2.29	4090	Fieldbus M->S8 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.30	4092	Fieldbus M->S8 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.2.31	4094	Fieldbus M->S8 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.32	4096	Fieldbus M->S8 div		FLOAT		1	1	1000	RW	EXP	
6.2.33	4100	Fieldbus M->S9 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.34	4102	Fieldbus M->S9 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.2.35	4104	Fieldbus M->S9 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.36	4106	Fieldbus M->S9 div		FLOAT		1	1	1000	RW	EXP	
6.2.37	4110	Fieldbus M->S10 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.38	4112	Fieldbus M->S10 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
				9 - Par 16							
				10 - Par 32							
6.2.39	4114	Fieldbus M->S10 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.40	4116	Fieldbus M->S10 div		FLOAT		1	1	1000	RW	EXP	
6.2.41	4120	Fieldbus M->S11 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.42	4122	Fieldbus M->S11 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.2.43	4124	Fieldbus M->S11 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.44	4126	Fieldbus M->S11 div		FLOAT		1	1	1000	RW	EXP	
6.2.45	4130	Fieldbus M->S12 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.46	4132	Fieldbus M->S12 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.2.47	4134	Fieldbus M->S12 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.48	4136	Fieldbus M->S12 div		FLOAT		1	1	1000	RW	EXP	
6.2.49	4140	Fieldbus M->S13 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.50	4142	Fieldbus M->S13 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.2.51	4144	Fieldbus M->S13 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.52	4146	Fieldbus M->S13 div		FLOAT		1	1	1000	RW	EXP	
6.2.53	4150	Fieldbus M->S14 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.54	4152	Fieldbus M->S14 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.2.55	4154	Fieldbus M->S14 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.56	4156	Fieldbus M->S14 div		FLOAT		1	1	1000	RW	EXP	
6.2.57	4160	Fieldbus M->S15 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.58	4162	Fieldbus M->S15 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.2.59	4164	Fieldbus M->S15 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.60	4166	Fieldbus M->S15 div		FLOAT		1	1	1000	RW	EXP	
6.2.61	4170	Fieldbus M->S16 ipa		FBM2SIPA		0	0	20000	RW	EXP	
6.2.62	4172	Fieldbus M->S16 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.2.63	4174	Fieldbus M->S16 mon		INT32	32BIT	0	0	0	R	EXP	
6.2.64	4176	Fieldbus M->S16 div		FLOAT		1	1	1000	RW	EXP	

### 6.3 FIELDBUS S2M

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.3.1	4180	Fieldbus S->M1 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.2	4182	Fieldbus S->M1 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.3.3	4184	Dig Fieldbus S->M1		INT32	32BIT	0	0	0	RW	EXP	
6.3.4	4186	Fieldbus S->M1 mul		FLOAT		1	1	1000	RW	EXP	
6.3.5	4190	Fieldbus S->M2 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.6	4192	Fieldbus S->M2 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.3.7	4194	Dig Fieldbus S->M2		INT32	32BIT	0	0	0	RW	EXP	
6.3.8	4196	Fieldbus S->M2 mul		FLOAT		1	1	1000	RW	EXP	
6.3.9	4200	Fieldbus S->M3 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.10	4202	Fieldbus S->M3 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
				9 - Par 16							
				10 - Par 32							
6.3.11	4204	Dig Fieldbus S->M3		INT32	32BIT	0	0	0	RW	EXP	
6.3.12	4206	Fieldbus S->M3 mul		FLOAT		1	1	1000	RW	EXP	
6.3.13	4210	Fieldbus S->M4 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.14	4212	Fieldbus S->M4 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.3.15	4214	Dig Fieldbus S->M4		INT32	32BIT	0	0	0	RW	EXP	
6.3.16	4216	Fieldbus S->M4 mul		FLOAT		1	1	1000	RW	EXP	
6.3.17	4220	Fieldbus S->M5 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.18	4222	Fieldbus S->M5 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.3.19	4224	Dig Fieldbus S->M5		INT32	32BIT	0	0	0	RW	EXP	
6.3.20	4226	Fieldbus S->M5 mul		FLOAT		1	1	1000	RW	EXP	
6.3.21	4230	Fieldbus S->M6 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.22	4232	Fieldbus S->M6 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.3.23	4234	Dig Fieldbus S->M6		INT32	32BIT	0	0	0	RW	EXP	
6.3.24	4236	Fieldbus S->M6 mul		FLOAT		1	1	1000	RW	EXP	
6.3.25	4240	Fieldbus S->M7 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.26	4242	Fieldbus S->M7 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.3.27	4244	Dig Fieldbus S->M7		INT32	32BIT	0	0	0	RW	EXP	
6.3.28	4246	Fieldbus S->M7 mul		FLOAT		1	1	1000	RW	EXP	
6.3.29	4250	Fieldbus S->M8 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.30	4252	Fieldbus S->M8 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
				4 - Fill 32 5 - Mdplc 16 6 - Mdplc 32 7 - Eu 8 - Eu float 9 - Par 16 10 - Par 32							
6.3.31	4254	S->M8 bus campo dig	INT32	32BIT	0	0	0	RW	EXP		
6.3.32	4256	Mol S->M8 bus campo	FLOAT		1	1	1000	RW	EXP		
6.3.33	4260	Ipa S->M9 bus campo	FBS2MIPA		0	0	20000	RW	EXP		
6.3.34	4262	Sys S->M9 bus campo	ENUM 0 - Non assegnato 1 - Count 16 2 - Count 32 3 - Fill 16 4 - Fill 32 5 - Mdplc 16 6 - Mdplc 32 7 - Eu 8 - Eu float 9 - Par 16 10 - Par 32		Non assegnato			RW	EXP		
6.3.35	4264	Dig Fieldbus S->M9	INT32	32BIT	0	0	0	RW	EXP		
6.3.36	4266	Fieldbus S->M9 mul	FLOAT		1	1	1000	RW	EXP		
6.3.37	4270	Fieldbus S->M10 ipa	FBS2MIPA		0	0	20000	RW	EXP		
6.3.38	4272	Fieldbus S->M10 sys	ENUM 0 - Not assigned 1 - Count 16 2 - Count 32 3 - Fill 16 4 - Fill 32 5 - Mdplc 16 6 - Mdplc 32 7 - Eu 8 - Eu float 9 - Par 16 10 - Par 32		Not assigned			RW	EXP		
6.3.39	4274	Dig Fieldbus S->M10	INT32	32BIT	0	0	0	RW	EXP		
6.3.40	4276	Fieldbus S->M10 mul	FLOAT		1	1	1000	RW	EXP		
6.3.41	4280	Fieldbus S->M11 ipa	FBS2MIPA		0	0	20000	RW	EXP		
6.3.42	4282	Fieldbus S->M11 sys	ENUM 0 - Not assigned 1 - Count 16 2 - Count 32 3 - Fill 16 4 - Fill 32 5 - Mdplc 16 6 - Mdplc 32 7 - Eu 8 - Eu float 9 - Par 16 10 - Par 32		Not assigned			RW	EXP		
6.3.43	4284	Dig Fieldbus S->M11	INT32	32BIT	0	0	0	RW	EXP		
6.3.44	4286	Fieldbus S->M11 mul	FLOAT		1	1	1000	RW	EXP		
6.3.45	4290	Fieldbus S->M12 ipa	FBS2MIPA		0	0	20000	RW	EXP		
6.3.46	4292	Fieldbus S->M12 sys	ENUM 0 - Not assigned 1 - Count 16 2 - Count 32 3 - Fill 16 4 - Fill 32 5 - Mdplc 16 6 - Mdplc 32 7 - Eu 8 - Eu float 9 - Par 16 10 - Par 32		Not assigned			RW	EXP		
6.3.47	4294	Dig Fieldbus S->M12	INT32	32BIT	0	0	0	RW	EXP		
6.3.48	4296	Fieldbus S->M12 mul	FLOAT		1	1	1000	RW	EXP		
6.3.49	4300	Fieldbus S->M13 ipa	FBS2MIPA		0	0	20000	RW	EXP		

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.3.50	4302	Fieldbus S->M13 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.3.51	4304	Dig Fieldbus S->M13		INT32	32BIT	0	0	0	RW	EXP	
6.3.52	4306	Fieldbus S->M13 mul		FLOAT		1	1	1000	RW	EXP	
6.3.53	4310	Fieldbus S->M14 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.54	4312	Fieldbus S->M14 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.3.55	4314	Dig Fieldbus S->M14		INT32	32BIT	0	0	0	RW	EXP	
6.3.56	4316	Fieldbus S->M14 mul		FLOAT		1	1	1000	RW	EXP	
6.3.57	4320	Fieldbus S->M15 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.58	4322	Fieldbus S->M15 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.3.59	4324	Dig Fieldbus S->M15		INT32	32BIT	0	0	0	RW	EXP	
6.3.60	4326	Fieldbus S->M15 mul		FLOAT		1	1	1000	RW	EXP	
6.3.61	4330	Fieldbus S->M16 ipa		FBS2MIPA		0	0	20000	RW	EXP	
6.3.62	4332	Fieldbus S->M16 sys		ENUM		Not assigned			RW	EXP	
				0 - Not assigned							
				1 - Count 16							
				2 - Count 32							
				3 - Fill 16							
				4 - Fill 32							
				5 - Mdplc 16							
				6 - Mdplc 32							
				7 - Eu							
				8 - Eu float							
				9 - Par 16							
				10 - Par 32							
6.3.63	4334	Dig Fieldbus S->M16		INT32	32BIT	0	0	0	RW	EXP	
6.3.64	4336	Fieldbus S->M16 mul		FLOAT		1	1	1000	RW	EXP	

## 6.4 WORD COMP

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.4.1	4400	Word bit0 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.2	4402	Word bit1 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.3	4404	Word bit2 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.4	4406	Word bit3 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.5	4408	Word bit4 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.6	4410	Word bit5 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.7	4412	Word bit6 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.8	4414	Word bit7 src		LINK	16BIT_L	6000	0	0	RW	EXP	

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.4.9	4416	Word bit8 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.10	4418	Word bit9 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.11	4420	Word bit10 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.12	4422	Word bit11 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.13	4424	Word bit12 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.14	4426	Word bit13 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.15	4428	Word bit14 src		LINK	16BIT_L	6000	0	0	RW	EXP	
6.4.16	4430	Word bit15 src		LINK	16BIT_L	6000	0	0	RW	EXP	
		L_DIGSEL1									
6.4.17	4432	Word comp mon		UINT32	16BIT_L	0	0	0	R	EXP	

## 6.5 WORD DECOMP

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.5.1	4450	Dig word decomp		UINT32	16BIT_L	0	0	0	RW	EXP	
6.5.2	4452	Word decomp src		LINK	16BIT_L	65535			RW	EXP	
		L_WDECOMP									
6.5.3	4454	Bit0 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.4	4456	Bit1 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.5	4458	Bit2 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.6	4460	Bit3 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.7	4462	Bit4 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.8	4464	Bit5 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.9	4466	Bit6 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.10	4468	Bit7 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.11	4470	Bit8 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.12	4472	Bit9 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.13	4474	Bit10 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.14	4476	Bit11 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.15	4478	Bit12 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.16	4480	Bit13 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.17	4482	Bit14 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	
6.5.18	4484	Bit15 decomp mon		UINT16	16BIT_L	0	0	1	R	EXP	

## 6.6 NETWORK AND ACCESS

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
6.6.1	9610	Readonly Username		STRING16		readonly	0	0	R	EXP	FVSY
6.6.2	9626	Easy Username		STRING16		easy	0	0	RW	EXP	FVSY
6.6.3	9634	Easy Password		STRING16		easy	0	0	RW	EXP	FVSY
6.6.4	9642	Interm Username		STRING16		interm	0	0	R	EXP	FVSY
6.6.5	9650	Interm Password		STRING16		interm	0	0	RW	EXP	FVSY
6.6.6	9658	Expert Username		STRING16		expert	0	0	R	EXP	FVSY
6.6.7	9666	Expert Password		STRING16		expert	0	0	RW	EXP	FVSY
6.6.8	9544	WiFi Fw version		UINT32		0	0	0	R	EXP	
6.6.9	9546	WiFi S/N		UINT32		0	0	0	R	EXP	
6.6.10	9528	WiFi Network Name		STRING16		WEG wifi	0	0	R	EXP	
6.6.11	9536	WiFi Network Pass		STRING16		0123456789	0	0	R	EXP	
6.6.12	9554	WiFi Network Channel		UINT16		11	0	12	R	EXP	
6.6.13	9556	IP Address set		UINT32		169.254.10.10	0	0	RW	EXP	FVSY
6.6.14	9558	IP Netmask set		UINT32		255.255.0.0	0	0	RW	EXP	FVSY
6.6.15	9560	IP Gateway set		UINT32		0.0.0.0	0	0	RW	EXP	FVSY
6.6.16	9564	IP Netmask		UINT32		255.255.0.0	0	0	R	EXP	FVSY
6.6.17	9566	IP Gateway		UINT32		0.0.0.0	0	0	R	EXP	FVSY
6.6.18	9608	Ip Assignment		ENUM 0 - DHCP 1 - Static		Static	0	0	RW	EXP	FVSY

## 7 MOTOR DATA

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.1	392	Select motor		BIT		0	0	1	RWZ	INT	FVSY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
7.2	2000	Rated voltage	V	FLOAT		SIZE	150	480	RWZ	INT	FVSY
7.3	2002	Rated current	A	FLOAT		SIZE	1	1500	RWZ	INT	FVSY
7.4	2004	Rated speed	rpm	FLOAT		SIZE	10	32000	RWZ	INT	FVSY
7.5	2006	Rated frequency	Hz	FLOAT		SIZE	1	1000	RWZ	INT	FVS
7.6	2008	Pole pairs	UINT16			SIZE	1	60	RWZ	INT	FVSY
7.7	2010	Rated power	kW	FLOAT		SIZE	0.1	1500	RWZ	INT	FVS
7.8	2012	Rated power factor		FLOAT		SIZE	0.6	0.95	RWZ	INT	FVS
7.9	2014	Torque constant	Nm/A	FLOAT		SIZE	0	120	RWZ	INT	Y
7.10	2020	Take parameters		BIT		0	0	1	RWZ	INT	FVSY
7.11	2022	Autotune rotation		BIT		0	0	1	RWZ	INT	FVS
7.12	2024	Autotune still		BIT		0	0	1	RWZ	INT	FVSY
7.13	2030	Autotune status		ENUM 0 - Required 1 - Done		Required			R	INT	FVSY
7.14	2050	Measured Rs	ohm	FLOAT		0	0	200	RW	EXP	FVSY
7.15	2052	Measured DTL	V	FLOAT		0	0	100	RW	EXP	FVSY
7.16	2054	Measured DTS	V/A	FLOAT		0	0	100	RW	EXP	FVSY
7.17	2056	Measured Lsig	mH	FLOAT		0.1	0.1	200	RW	EXP	FVS
7.18	2058	Measured LsSyn	mH	FLOAT		0.1	0.1	200	RW	EXP	Y
7.19	2060	Measured LsMin Syn	mH	FLOAT		0.1	0.1	200	RW	EXP	Y
7.20	2062	Measured ImN	A	FLOAT	CALCF	0	1000	RW	EXP	FVS	
7.21	2066	Measured FlxN	Wb	FLOAT	CALCF	0	10	RW	EXP	FVS	
7.22	2076	Measured Rr	ohm	FLOAT	CALCF	0	200	RW	EXP	FVS	
7.23	2078	Take tune parameters		BIT		0	0	1	RW	INT	FVSY

## 8 ENCODER

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.1	2100	Encoder pulses	ppr	UINT16		1024	4	16384	RWZ	INT	
8.2	2102	Encoder supply	V	FLOAT		5.2	5.2	20.0	RW	INT	FVSY
8.3	2104	Encoder input config		ENUM 0 - HTL 1 - TTL		TTL			RWZ	INT	
8.4	2106	Encoder repetition		ENUM 0 - No division 1 - Divide 2 2 - Divide 4 3 - Divide 8 4 - Divide 16 5 - Divide 32 6 - Divide 64		No division			RWZ	INT	
8.5	2108	Encoder signal Vpp	V	FLOAT		0.8	0.5	1.2	RWZ	INT	
8.6	2110	Encoder signal check		ENUM 1 - Check A-B 2 - Check A-B-Z		Check A-B			RWZ	EXP	
8.7	2116	ENC signal Vpp inc	V	FLOAT		0	0	0	R	EXP	
8.8	2118	ENC signal Vpp abs	V	FLOAT		0	0	0	R	EXP	
8.9	2130	Encoder direction		ENUM 0 - Not inverted 1 - Inverted		Not inverted			RWZ	INT	
8.10	2132	Encoder mode		ENUM 0 - None 1 - Digital 2 - Sinus 3 - Sinus SINCOS 4 - Sinus ENDAT 5 - Sinus BISS 6 - ENDAT 7 - BiSS 8 - Sinus SSI		None			RWZ	INT	FVSY
8.11	2134	Encoder speed filter	ms	FLOAT		1.0	0.1	8.0	RW	EXP	
8.12	2136	Peripheral encoder		BIT		0	0	1	RW	EXP	
8.13	2150	Encoder speed	rpm	INT16	16BIT_H	0	0	0	R	ESY	
8.14	2162	Encoder position	cnt	UINT16	16BIT_H	0	0	0	R	ESY	

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
8.15	2164	Encoder abs position	cnt	UINT32	32BIT	0	0	0	R	EXP	
8.16	2172	SpdFbkLoss code		UINT16		0	0	0	R	EXP	
8.17	2174	Endat error code		UINT16		0	0	0	R	EXP	
8.18	2176	Encoder sync mode		UINT16		1	0	3	RWZ	EXP	Y
8.19	2184	Ext motor diam	mm	UINT16		1	1	65535	RWZ	EXP	
8.20	2186	Enc pulley diam	mm	UINT16		1	1	65535	RWZ	EXP	
8.21	2190	Autophase rot		BIT		0	0	1	RWZ	EXP	Y
8.22	2192	Autophase still		BIT		0	0	1	RWZ	EXP	Y
8.23	2748	Still phasing mode		ENUM		Mode 1			RW	EXP	Y
						0 - Mode 1					
						1 - Mode 2					
8.24	2194	Phasing repeat		ENUM		First enable	0	1	RW	EXP	Y
						0 - First enable					
						1 - Each enable					
						2 - Count enable					
8.25	2198	Autophase cnt enable		UINT16		2	2	65535	RWZ	EXP	Y
8.26	7100	BiSS encoder type		UINT16		0	0	0	R	EXP	
8.27	7102	BiSS manufacturer		UINT16		0	0	0	R	EXP	
8.28	7104	BiSS clock freq		UINT16		7	0	15	RW	EXP	
8.29	7106	BiSS N bit ST		UINT16		13	0	64	RW	EXP	
8.30	7108	BiSS N bit MT		UINT16		0	0	64	RW	EXP	
8.31	7110	BiSS data len		UINT16		0	0	0	R	EXP	
8.32	7112	BiSS timeout	us	FLOAT		13	0	65	RW	EXP	
8.33	7114	BiSS Crc polinomy		UINT16		67	1	65535	RW	EXP	
8.34	7116	BiSS data code		ENUM		Binary			RW	EXP	
						0 - Binary					
						1 - Gray					
8.35	2178	Abs offset memory		ENUM		Drive_memory			RW	EXP	
						0 - Drive memory					
						1 - Encoder memory					
8.36	7150	SSI N bit ST		UINT16		13	0	13	RW	EXP	
8.37	7152	SSI N bit MT		UINT16		0	0	19	RW	EXP	
8.38	7154	SSI N bit TX		UINT16		13	0	32	RW	EXP	
8.39	7156	SSI data code		ENUM		Gray			RW	EXP	
						0 - Binary					
						1 - Gray					
8.40	2732	Enc position offset		INT16		0	0	0	RW	EXP	Y

## 9 SICUREZZA

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
9.3	11252	Brake fbk A3 sel		ENUM		Null	-	-	RW	INT	FVY
9.4	11268	Reset Brake Alarm		INT		0	-	-	RW	INT	FVY
9.5	11270	Threshold A3	m	FLOAT		0.1	0	2	RW	INT	VY

## 10 REGULATION MENU

### 10.1 SPEED REGULATION GAINS (SPEED REG GAINS)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.1	2240	Inertia	$\text{kgm}^2$	FLOAT		0.8	0.001	1000	RW	INT	VSY
10.1.2	9702	Learning trip out	$\text{kgm}^2$	FLOAT		0	0	0	R	EXP	FVSY
10.1.3	2794	SR-P gain at start	%	FLOAT		150.0	0.0	400.0	RW	INT	VSY
10.1.4	2796	SR-I gain at start	%	FLOAT		110.0	0.0	400.0	RW	INT	VSY
10.1.5	2752	SR-P gain low speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
10.1.6	2754	SR-I gain low speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
10.1.7	2756	SR-P gain high speed	%	FLOAT		80.0	0.0	400.0	RW	INT	VSY
10.1.8	2758	SR-I gain high speed	%	FLOAT		100.0	0.0	400.0	RW	INT	VSY
10.1.9	2760	SR-low speed thrsd	%	UINT16		30	1	100	RW	INT	VSY
10.1.10	2762	SR-high speed thrsd	%	UINT16		70	1	100	RW	INT	VSY
10.1.11	2662	SR-P gain	N/rpm	FLOAT		1.0	0	0	RW	INT	VSY
10.1.12	2664	SR-I time	ms	FLOAT		1.0	0	0	RW	INT	VSY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.1.13	9446	TNF1-frequency	Hz	FLOAT		100.0	5.0	350.0	RW	EXP	VSY
10.1.14	9448	TNF1-bandwidth	Hz	FLOAT		4	1	20	RW	EXP	VSY
10.1.15	9450	TNF1-depth		FLOAT		20	3	60	RW	EXP	VSY
10.1.16	9458	Torque Notch Fltr 1		ENUM 0 - Disable 1 - Enable		Disable			RW	EXP	VSY
10.1.17	9452	TNF2-frequency	Hz	FLOAT		100.0	5.0	350.0	RW	EXP	VSY
10.1.18	9454	TNF2-bandwidth	Hz	FLOAT		4	1	20	RW	EXP	VSY
10.1.19	9456	TNF2-depth		FLOAT		20	3	60	RW	EXP	VSY
10.1.20	9460	Torque Notch Fltr 2		ENUM 0 - Disable 1 - Enable		Disable			RW	EXP	VSY
10.1.21	2806	SR-P gain in use	%	FLOAT		100.0	0	0	R	INT	VSY
10.1.22	2808	SR-I gain in use	%	FLOAT		100.0	0	0	R	INT	VSY

## 10.2 VF CONTROL

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.2.1	2200	Boost voltage	%	FLOAT		3	0	20.0	RW	ESY	F
10.2.2	2202	Base voltage	V	FLOAT		0	0	0	RW	ESY	F
10.2.3	2204	Base frequency	Hz	FLOAT		0	0	0	RW	ESY	F
10.2.4	2212	V/Hz Boost mode		ENUM 0 - Fixed 1 - Auto		Auto			RW	ESY	F
10.2.5	2214	V/Hz Slip ctrl gain		FLOAT		0	0	0	RW	EXP	F
10.2.6	2218	V/Hz Stability gain		FLOAT		0.0	0	0	RW	EXP	F
10.2.7	2220	V/Hz Limiter Kp	Hz/A	FLOAT		0.2	0	0	RW	EXP	F
10.2.8	2222	V/Hz Limiter Ti	ms	FLOAT		50.0	0	0	RW	EXP	F
10.2.9	2224	V/Hz slip fltr const	ms	FLOAT		10.0	1.0	1000.0	RW	EXP	F
10.2.10	2230	V/Hz Boost gain	V	FLOAT		0.0	0	0	RW	EXP	F
10.2.11	2480	Vf Min Freq	Hz	FLOAT		0.5	0	5	RW	EXP	F
10.2.12	2482	Vf Min Dly	ms	FLOAT		800	0	5000	RW	EXP	F
10.2.13	2206	Middle voltage	V	FLOAT		0	0	0	RW	EXP	F
10.2.14	2208	Middle frequency	Hz	FLOAT		0	0	0	RW	EXP	F
10.2.15	2232	Initial voltage	V	FLOAT		0	0	60.0	RW	EXP	F
10.2.16	2210	V/Hz Profile type		ENUM 0 - Linear 1 - Custom		Linear			RW	EXP	F
10.2.17	2226	V/Hz Boost slope		FLOAT		0.0	0	0	RW	EXP	F
10.2.18	2228	Slip comp hold		ENUM 0 - Disable 1 - Enable		Disable			RW	EXP	F

## 10.3 REGULATOR PARAM

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.3.1	2250	CR-P gain	V/A	FLOAT		1.0	0	0	RW	EXP	FVSY
10.3.2	2252	CR-I time	ms	FLOAT		1.0	0	0	RW	EXP	FVSY
10.3.3	2260	FR-P gain	A/Wb	FLOAT		1.0	0	0	RW	EXP	FVSY
10.3.4	2262	FR-I time	ms	FLOAT		1.0	0	0	RW	EXP	FVSY
10.3.5	2272	VR-I time	ms	FLOAT		1.0	0	0	RW	EXP	FVSY
10.3.6	2290	Deflux voltage	V	FLOAT		380	0	0	RW	EXP	FVSY
10.3.7	2292	Voltage margin	%	FLOAT		5.0	0	30.0	RW	EXP	FVSY
10.3.8	2308	Over-flux level	%	FLOAT		100	100	150	RW	EXP	FVSY
10.3.9	2312	Over-flux spd thrsd	rpm	FLOAT		400	1	1000	RW	EXP	FVSY
10.3.10	2314	Over-flux step		FLOAT		1	0,01	10	RW	EXP	FVSY
10.3.11	2724	Defluxing curr lim	A	FLOAT		0.0	0	0	RW	EXP	FVSY

## 10.4 TORQUE CONFIG

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
10.4.1	2350	Torque curr lim Pos	A	FLOAT	16BIT_H	CALCF	0.0	CALCF	RW	EXP	FVSY
10.4.2	2352	Torque curr lim Neg	A	FLOAT	16BIT_H	CALCF	0.0	CALCF	RW	EXP	FVSY
10.4.3	2354	Torque curr lim sel 0 - Off		ENUM		Off			RWZ	EXP	FVSY
						1 - T clim +/- 2 - T clim mot/gen 3 - T limit src					
10.4.4	2358	Torque limit src		LINK	16BIT_H	6000 L_LIM			RWZ	EXP	FVSY
10.4.5	2360	Torque climPos Inuse	A	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY
10.4.6	2362	Torque climNeg Inuse	A	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY
10.4.7	2380	Dig torque ref	%	FLOAT	16BIT_H	0.0	-300.0	300.0	RW	EXP	FVSY
10.4.8	2382	Torque ref src		LINK	16BIT_H	65535 L_VREF			RWZ	EXP	FVSY

## 11 FUNCTIONS

### 11.1 DC BRAKING

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.1.1	3150	DC braking cmd src		LINK	16BIT_L	6000 L_DIGSEL2			RW	INT	FVS
11.1.2	3152	DC brake mode		ENUM		Off 0 - Off 1 - At Stop 2 - On Command 3 - OnCmd & AtStop			RW	INT	FVS
11.1.3	3154	DC brake delay	s	FLOAT		0.01	0.01	30.0	RW	INT	FVS
11.1.4	3156	DC brake duration	s	FLOAT		1.0	0.01	30.0	RW	INT	FVS
11.1.5	3158	DC brake current	%	FLOAT		75.0	0.0	150.0	RW	INT	FVS
11.1.6	3160	DC brake state		ENUM	16BIT_L	Not active 0 - Not active 1 - Active			R	INT	FVS

### 11.2 INERTIA COMP

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.2.1	3100	Inertia comp	$\text{kgm}^2$	FLOAT		0.1	0	0	RW	EXP	FVSY
11.2.2	3102	Inertia comp filter	ms	FLOAT		4.0	2.0	20.0	RW	EXP	FVSY
11.2.3	3104	Inertia comp mon	%	FLOAT	16BIT_H	0.0	0.0	0.0	R	EXP	FVSY
11.2.4	3106	Inertia comp fcn		ENUM		Disable 0 - Disable 1 - Enable			RW	EXP	FVSY

### 11.3 ANTI ROLLBACK

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.3.1	2766	PR-P gain		FLOAT		500	0	20000	RW	EXP	Y
11.3.2	2768	PR-enable		ENUM		Enable			RW	EXP	Y
11.3.3	2812	PR-P End gain		FLOAT		500	0	20000	RW	EXP	Y
11.3.4	2814	PR End enable		ENUM		Enable 0 - Disable 1 - Enable			RW	EXP	Y
11.3.5	2810	Pos reg limit	rpm	FLOAT		10.0	-20	20	RW	EXP	Y

### 11.4 VIBRATION ANALYSIS (VIBR. ANALYSIS)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.4.1	2288	Vibrations analyzer		ENUM		Disable 0 - Disable 1 - Enable			RW	EXP	VSY

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.4.2	9464	Vibration freq. 1	Hz	FLOAT		0	0.0	0.0	R	EXP	VSY
11.4.3	9466	Vibration freq. 2	Hz	FLOAT		0	0.0	0.0	R	EXP	VSY

## 11.5 MOTOR OVERLOAD

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.5.1	3200	Motor ovld enable		ENUM 0 - Off 1 - On		Off			RW	EXP	FVSY
11.5.2	3202	Motor ovld factor	%	FLOAT		150	100	300	RW	EXP	FVSY
11.5.3	3204	Motor ovld time	s	FLOAT		30	10	300	RW	EXP	FVSY
11.5.4	3206	Motor service factor	%	FLOAT		100	25	200	RW	EXP	FVSY
11.5.5	3216	Motor fan type		ENUM 0 - Auto fan 1 - Servo fan		Servo fan			RW	EXP	FVY
11.5.6	3218	Motor derat factor	%	FLOAT		50	0	100	RW	EXP	FVSY

## 11.6 BRAKING RESISTOR OVERLOAD (BRES OVERLOAD)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.6.1	3250	Bres control		ENUM 0 - Off 1 - On		On			RW	INT	FVSY
11.6.2	3252	Bres value	ohm	FLOAT		7.0	7.0	1000.0	RW	INT	FVSY
11.6.3	3254	Bres cont power	kW	FLOAT		0.1	0.1	100.0	RW	INT	FVSY
11.6.4	3256	Bres overload factor		FLOAT		1.5	1.5	10.0	RW	INT	FVSY
11.6.5	3258	Bres overload time	s	FLOAT		0.5	0.5	50.0	RW	INT	FVSY

## 11.7 ENERGY SAVING (ENER. SAVING)

Menu	PAR	Description	UM	Type	FB BIT	Def	Min	Max	Acc	Lev.	Vis.
11.7.1	3122	Energia recuperata	kWh	FLOAT		0	0	0	R	EXP	FVSY
11.7.2	3124	Set val. energia	kWh	FLOAT		0	0	0	RW	EXP	FVSY

## D - Selection Lists

### L\_DIGSEL1

PAR	Description	Menu
6000	Null	(*)
6002	One	(*)
1110	Dig input E mon	4.8.13
1210	Dig input 1 mon	4.8.14
1212	Dig input 2 mon	4.8.15
1214	Dig input 3 mon	4.8.16
1216	Dig input 4 mon	4.8.17
1218	Dig input 5 mon	4.8.18
1220	Dig input 6 mon	4.8.19
1222	Dig input 7 mon	4.8.20
1224	Dig input 8 mon	4.8.21
1230	Dig input 1x mon	4.8.22
1232	Dig input 2x mon	4.8.23
1234	Dig input 3x mon	4.8.24
1236	Dig input 4x mon	4.8.25
1062	Drive OK	4.7.14
1064	Drive ready	4.7.15
934	Ref is 0	(*)
936	Ref is 0 delay	(*)
944	Speed is 0	(*)
946	Speed is 0 delay	(*)
1066	Enable state mon	4.1.16
1068	Start state mon	4.1.17
1070	FastStop cmd mon	4.1.18
1024	Enable cmd mon	4.7.10
1026	Start cmd mon	4.7.11
1028	FastStop cmd mon	(*)
4708	Alm dig out mon 1	(*)
4710	Alm dig out mon 2	(*)
4712	Alm dig out mon 3	(*)
4714	Alm dig out mon 4	(*)
362	Drive overload trip	13.4.8
3214	Motor overload trip	(*)
3262	Bres overload trip	(*)
366	Drive overload 80%	13.4.9
4454	Bit0 decomp mon	6.5.3
4456	Bit1 decomp mon	6.5.4
4458	Bit2 decomp mon	6.5.5
4460	Bit3 decomp mon	6.5.6
4462	Bit4 decomp mon	6.5.7
4464	Bit5 decomp mon	6.5.8
4466	Bit6 decomp mon	6.5.9
4468	Bit7 decomp mon	6.5.10
4470	Bit8 decomp mon	6.5.11
4472	Bit9 decomp mon	6.5.12
4474	Bit10 decomp mon	6.5.13
4476	Bit11 decomp mon	6.5.14
4478	Bit12 decomp mon	6.5.15
4480	Bit13 decomp mon	6.5.16
4482	Bit14 decomp mon	6.5.17
4484	Bit15 decomp mon	6.5.18
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16
3732	Activation delay enable	13.7.17
3718	Safe brake test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe brake test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15

### L\_DIGSEL2

PAR	Description	Menu
6000	Null	(*)
6002	One	(*)
1110	Dig input E mon	4.8.13
1210	Dig input 1 mon	4.8.14
1212	Dig input 2 mon	4.8.15
1214	Dig input 3 mon	4.8.16
1216	Dig input 4 mon	4.8.17
1218	Dig input 5 mon	4.8.18
1220	Dig input 6 mon	4.8.19
1222	Dig input 7 mon	4.8.20
1224	Dig input 8 mon	4.8.21
1230	Dig input 1x mon	4.8.22
1232	Dig input 2x mon	4.8.23
1234	Dig input 3x mon	4.8.24
1236	Dig input 4x mon	4.8.25
1062	Drive OK	4.7.14
1064	Drive ready	4.7.15
934	Ref is 0	(*)
936	Ref is 0 delay	(*)
944	Speed is 0	(*)
946	Speed is 0 delay	(*)
1066	Enable state mon	4.1.16
1068	Start state mon	4.1.17
1070	FastStop state mon	4.1.18
1024	Enable cmd mon	4.7.10
1026	Start cmd mon	4.7.11
1028	FastStop cmd mon	(*)
4708	Alm dig out mon 1	(*)
4710	Alm dig out mon 2	(*)
4712	Alm dig out mon 3	(*)
4714	Alm dig out mon 4	(*)
362	Drive overload trip	13.4.8
3214	Motor overload trip	(*)
3262	Bres overload trip	(*)
366	Drive overload 80%	13.4.9
4454	Bit0 decomp mon	6.5.3
4456	Bit1 decomp mon	6.5.4
4458	Bit2 decomp mon	6.5.5
4460	Bit3 decomp mon	6.5.6
4462	Bit4 decomp mon	6.5.7
4464	Bit5 decomp mon	6.5.8
4466	Bit6 decomp mon	6.5.9
4468	Bit7 decomp mon	6.5.10
4470	Bit8 decomp mon	6.5.11
4472	Bit9 decomp mon	6.5.12
4474	Bit10 decomp mon	6.5.13
4476	Bit11 decomp mon	6.5.14
4478	Bit12 decomp mon	6.5.15
4480	Bit13 decomp mon	6.5.16
4482	Bit14 decomp mon	6.5.17
4484	Bit15 decomp mon	6.5.18
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16
3732	Activation delay enable	13.7.17
3718	Safe brake test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe brake test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15

### L\_DIGSEL3

PAR	Description	Menu
XXXX	( <sup>(2)</sup> )	
6000	Null	(*)
1218	Dig input 5 mon	4.8.18
1220	Dig input 6 mon	4.8.19
1014	Local/remote src	4.7.6
( <sup>(2)</sup> ) = 1012	Dig local/remote	4.7.5

<sup>(2)</sup> the XXXX parameter changes according to the src parameter used:

## D - Selection Lists

### L\_LIM

PAR	Description	Menu
6000	Null	(*)
1600	Analog input mon	4.10.1
4024	Fieldbus M->S1 mon	6.2.3
4034	Fieldbus M->S2 mon	6.2.7
4044	Fieldbus M->S3 mon	6.2.11
4054	Fieldbus M->S4 mon	6.2.15
4064	Fieldbus M->S5 mon	6.2.19
4074	Fieldbus M->S6 mon	6.2.23
4084	Fieldbus M->S7 mon	6.2.27
4094	Fieldbus M->S8 mon	6.2.31
4104	Fieldbus M->S9 mon	6.2.35
4114	Fieldbus M->S10 mon	6.2.39
4124	Fieldbus M->S11 mon	6.2.43
4134	Fieldbus M->S12 mon	6.2.47
4144	Fieldbus M->S13 mon	6.2.51
4154	Fieldbus M->S14 mon	6.2.55
4164	Fieldbus M->S15 mon	6.2.59
4174	Fieldbus M->S16 mon	6.2.63
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16

### L\_MLTREF

PAR	Description	Menu
XXXX	(*)	
1600	Analog input mon	4.10.1
2150	Encoder speed	8.13
4024	Fieldbus M->S1 mon	6.2.3
4034	Fieldbus M->S2 mon	6.2.7
4044	Fieldbus M->S3 mon	6.2.11
4054	Fieldbus M->S4 mon	6.2.15
4064	Fieldbus M->S5 mon	6.2.19
4074	Fieldbus M->S6 mon	6.2.23
4084	Fieldbus M->S7 mon	6.2.27
4094	Fieldbus M->S8 mon	6.2.31
4104	Fieldbus M->S9 mon	6.2.35
4114	Fieldbus M->S10 mon	6.2.39
4124	Fieldbus M->S11 mon	6.2.43
4134	Fieldbus M->S12 mon	6.2.47
4144	Fieldbus M->S13 mon	6.2.51
4154	Fieldbus M->S14 mon	6.2.55
4164	Fieldbus M->S15 mon	6.2.59
4174	Fieldbus M->S16 mon	6.2.63
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16
6000	Null	(*)
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16

3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16

(4) the XXXX parameter changes according to the src parameter used:

4452	Word decomp src	6.5.2
(6) = 4450	Dig word decomp	6.5.1

### L\_WDECOMP

PAR	Descrizione	Menu
XXXX	(6)	
6000	Null	(*)
6002	One	(*)
4432	Word comp mon	6.4.17
4024	Fieldbus M->S1 mon	6.2.3
4034	Fieldbus M->S2 mon	6.2.7
4044	Fieldbus M->S3 mon	6.2.11
4054	Fieldbus M->S4 mon	6.2.15
4064	Fieldbus M->S5 mon	6.2.19
4074	Fieldbus M->S6 mon	6.2.23
4084	Fieldbus M->S7 mon	6.2.27
4094	Fieldbus M->S8 mon	6.2.31
4104	Fieldbus M->S9 mon	6.2.35
4114	Fieldbus M->S10 mon	6.2.39
4124	Fieldbus M->S11 mon	6.2.43
4134	Fieldbus M->S12 mon	6.2.47
4144	Fieldbus M->S13 mon	6.2.51
4154	Fieldbus M->S14 mon	6.2.55
4164	Fieldbus M->S15 mon	6.2.59
4174	Fieldbus M->S16 mon	6.2.63
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16

### L\_SCOPE

PAR	Description	Menu
6000	Null	(*)

### L\_VREF

PAR	Description	Menu
XXXX	(6)	
1600	Analog input mon	4.10.1
4024	Fieldbus M->S1 mon	6.2.3
4034	Fieldbus M->S2 mon	6.2.7
4044	Fieldbus M->S3 mon	6.2.11
4054	Fieldbus M->S4 mon	6.2.15
4064	Fieldbus M->S5 mon	6.2.19
4074	Fieldbus M->S6 mon	6.2.23
4084	Fieldbus M->S7 mon	6.2.27
4094	Fieldbus M->S8 mon	6.2.31
4104	Fieldbus M->S9 mon	6.2.35
4114	Fieldbus M->S10 mon	6.2.39
4124	Fieldbus M->S11 mon	6.2.43
4134	Fieldbus M->S12 mon	6.2.47
4144	Fieldbus M->S13 mon	6.2.51
4154	Fieldbus M->S14 mon	6.2.55
4164	Fieldbus M->S15 mon	6.2.59
4174	Fieldbus M->S16 mon	6.2.63
3700	Lift enable	13.7.1
3702	Run cont mon	13.7.2
3704	Up cont mon	13.7.3
3706	Down cont mon	13.7.4
3708	Brake cont mon	13.7.5
3710	Lift dc brake	13.7.6
3712	Brake mon	13.7.7
3714	Door open mon	13.7.8
3716	Lift start	13.7.9
3718	Safe Brake Test	13.7.10
3720	Lift statusWord	13.7.11
3722	Brake mon	13.7.12
3724	SC Cont mon	13.7.13
3726	Ramp down limit	13.7.14
3728	EBC OK	13.7.15
3730	Lift wdec input	13.7.16
6000	Null	(*)

(6) the XXXX parameter changes according to the src parameter used:

4452	Word decomp src	6.5.2
(6) = 4450	Dig word decomp	6.5.1

### LIFTINPUTADLCMD

PAR	Description	Menu
1110	Dig input E	4.8.13
1210	Dig input 1	4.8.14
1212	Dig input 2	4.8.15
1214	Dig input 3	4.8.16
1216	Dig input 4	4.8.17
1218	Dig input 5	4.8.18
1220	Dig input 6	4.8.19
1222	Dig input 7	4.8.20
1224	Dig input 8	4.8.21
1230	Dig input 1x	4.8.22
1232	Dig input 2x	4.8.23
1234	Dig input 3x	4.8.24

## D - Liste di selezione


PAR	Description	Menu	LIFTINPUTADLCMDEBC		
PAR	Description	Menu	PAR	Description	Menu
1236	Dig input 4x	4.8.25	1110	Dig input E mon	4.8.13
3702	Run cont mon	12.7.2	1210	Dig input 1 mon	4.8.14
3706	Down cont mon	12.7.4	1212	Dig input 2 mon	4.8.15
3708	Brake cont mon	12.7.5	1214	Dig input 3 mon	4.8.16
3714	Door open mon	12.7.8	1216	Dig input 4 mon	4.8.17
6000	Null	(*)	1218	Dig input 5 mon	4.8.18
6002	One	(*)	1220	Dig input 6 mon	4.8.19
12250	B0 Lift decomp	(*)	1222	Dig input 7 mon	4.8.20
12252	B1 Lift decomp	(*)	1224	Dig input 8 mon	4.8.21
12254	B2 Lift decomp	(*)	1230	Dig input 1x mon	4.8.22
12256	B3 Lift decomp	(*)	1232	Dig input 2x mon	4.8.23
12258	B4 Lift decomp	(*)	1234	Dig input 3x mon	4.8.24
12260	B5 Lift decomp	(*)	1236	Dig input 4x mon	4.8.25
12262	B6 Lift decomp	(*)	3702	Run cont mon	13.7.2
12264	B7 Lift decomp	(*)	3706	Down cont mon	13.7.4
12266	B8 Lift decomp	(*)	3708	Brake cont mon	13.7.5
12268	B9 Lift decomp	(*)	3714	Door open mon	13.7.8
12270	B10 Lift dcomp	(*)	8000	EBC SOK mon	12.1.1
12272	B11 Lift dcomp	(*)	8002	EBC Warning mon	12.1.2
12274	B12 Lift dcomp	(*)	8004	EBC Alarm mon	12.1.3
12276	B13 Lift dcomp	(*)	6000	Null	(*)
12278	B14 Lift dcomp	(*)	6002	One	(*)
12280	B15 Lift dcomp	(*)	12250	B0 Lift decomp	(*)
			12252	B1 Lift decomp	(*)
			12254	B2 Lift decomp	(*)
			12256	B3 Lift decomp	(*)
			12258	B4 Lift decomp	(*)
			12260	B5 Lift decomp	(*)
			12262	B6 Lift decomp	(*)
			12264	B7 Lift decomp	(*)
			12266	B8 Lift decomp	(*)
			12268	B9 Lift decomp	(*)
			12270	B10 Lift dcomp	(*)
			12272	B11 Lift dcomp	(*)
			12274	B12 Lift dcomp	(*)
			12276	B13 Lift dcomp	(*)
			12278	B14 Lift dcomp	(*)
			12280	B15 Lift dcomp	(*)

(\*) Parameter not shown on the keypad. For information see the "PARAMETERS INCLUDED IN SELECTION LISTS BUT NOT SHOWN ON THE KEYPAD" section.


## E - Block diagrams

### DRIVE


#### DRIVE OVERVIEW




#### DIGITAL INPUTS




## EXPANSION DIGITAL INPUTS




## DIGITAL OUTPUTS



## EXPANSION DIGITAL OUTPUTS




## ANALOG INPUTS




# LIFT


## EFC OVERVIEW




## MULTISPEED




## RAMPS




## START SEQUENCES



## STOP SEQUENCES




## PRE-TORQUE




# REGULATIONS

## SPEED REG GAINS




## TORQUE CONFIG




## FUNCTIONS


### MOTOR OVERLOAD SEROVFAN




### MOTOR OVERLOAD AUTO FAN




## BRES OVERLOAD




## ANTI ROLLBACK




## DC BRAKING AT STOP



## DC BRAKING ON COMMAND



## DC BRAKING ON CMD & AT STOP



## F - Appendix 1 - CANopen interface

---

CANopen is a communication profile for CanApplicationLayer-based industrial systems.

The reference document is the “CANopen application layer and communication profile” CiA 301 Version 4.2.0 21 February 2011 by CAN in Automation e. V.

The drive also implements part of the DS417 Profile according to the specific CANopen Device Profile Drives and Motion Control V3.0.0 dated 14 December 2007.

The CAN protocol (ISO 11898) is CAN2.0A with an 11-bit identifier.

The integrated CANopen interface is developed as a “Minimum Field Device”.

The data exchange is cyclic; the Master unit reads the Slave input data and writes the Slave output data.

### F.1.1 CANopen functions

This chapter describes the controlled functions of the CANopen communication profile.

#### Main features:

- 1) The “Mandatory Protocol boot-up” is managed.
- 2) The SYNC function is implemented.
- 3) The PDO asynchronous assignment is managed.
- 4) The Node Guarding and HeartBeat protocols are managed.
- 5) The emergency message is managed (“EMERGENCY”).
- 6) The Dynamic ID distribution function (DBT slave) is not managed.
- 7) A “Generic Pre-Defined Master/Slave connection” is implemented to simplify the Master tasks during the initialization phase.
- 8) “Inhibit-Times” (in units of 100 uS) can be modified.
- 9) The high-resolution synchronization is not supported.
- 10) “TIME STAMP” is not managed.
- 11) On the access of the structured parameters, the OFFhex option subindex (access to the whole object) is not managed.
- 12) In order to obtain a higher efficiency level, only the “Expedited” data transfer (max. 4 Bytes) of the SDO services is managed.
- 13) The “communication profile area” parameters are not saved by a save command, which on the other hand works on the “manufacturer-specific” and “profile” areas.

#### F.1.1.1 Pre-defined Master/Slave Connection

The “Generic Pre-defined Master/Slave connection” allows a peer-to-peer communication between one Master and 127 Slaves; the Broadcast address is zero.

#### F.1.1.2 NMT Services (Network Management)

The NMT “mandatory” services are:

- Enter\_Pre-Operational\_State      CS = 128 (80h)
- Reset\_Node                          CS = 129 (81h)

Performs an adjustment software reset command.

- Reset\_Communication            CS = 130 (82h)

Also the following NMT services are managed:

- Start\_Remote\_Mode            CS = 1
- Stop\_Remote\_Mode            CS = 2

The COB-ID \* of an initialization NMT service is always at 0; CS is the Command Specifier defining the NMT service.

#### F.1.1.3 Monitoraggio

##### Monitoring

The ADL550 drive supports the Node Guarding and HeartBeat mechanism. The Node Guarding configuration can be performed through the master via the standard Object Dictionary elements (1006h, 100Ch, 100Dh).

The Node Guarding threshold (maximum time between two NodeGuarding messages received from ADL) is calculated as: “Guard time” x “LifeTime Factor”

The HeartBeat is configured by means of the objects 1016h and 1017h. The threshold in this case is calculated as: “HeartBeat Time” x “LifeTime Factor”.

Monitoring via NodeGuarding excludes monitoring via HeartBeat and vice versa: only one of the two systems can be active. The master must set the objects involved correctly.

The drive also checks the master's operation via the arrival of the Sync message (only if the "Communication Cycle period" is different from 0). The threshold (maximum time between two Sync messages received from ADL) is:

"Communication Cycle period" \* "LifeTime Factor"

If one of the thresholds is exceeded, the drive changes the Operational status to Pre-Operational status, consequently generating the BusLoss alarm if it is also enabled.

Index	Name	Default value
1006h	Communication Cycle Period	64ms
100Ch	Guard Time	100ms
100D	Life time factor	3 (N.B.: this must always be different from 0)
1016h	Consumer heartbeat time	Nodeld = 0 , time = 0
1017h	Producer heartbeat time	0

The default settings shown therefore correspond to the use of the NodeGuarding protocol with a threshold of 100ms x 3 and a threshold control even on Sync at 64ms x 3. The HeartBeat is disabled.

#### F.1.1.4 Communication objects

This chapter describes the communication objects of the CANopen protocol; they are managed by the interface card.

The managed communication objects are:

- 1) 1 SDO reception Server.
- 2) 1 SDO transmission Server.
- 3) reception PDOs.
- 4) transmission PDOs.
- 5) 1 Emergency Object.
- 6) 1 Node Guarding - Life Guarding.
- 7) 1 SYNC object.

The following table lists the used communication objects with their priority level and the Message Identifier; the "Resulting COB-ID" is obtained by adding the Node-ID (card address) to the number.

OBJECT	PRIORITY	MESSAGE ID
1st SDO rx	6	1792 700h+Nodeld
1st SDO tx	6	1536 600h+Nodeld
1st PDO rx	2	1408 580h+Nodeld
1st PDO tx	2	512 200h+Nodeld
2nd PDO rx	2	384 180h+Nodeld
2nd PDO tx	2	768 300h+Nodeld
3st PDO rx	2	640 280h+Nodeld
3st PDO tx	2	512 400h+Nodeld
4th PDO rx	2	384 380h+Nodeld
4th PDO tx	2	768 500h+Nodeld
EMERGENCY	1	480h+Nodeld
NODE GUARDING & HB	not used	220 600h+Nodeld
SYNC	0	128 80h

Table 1.4.1: Communication Objects

The master NodeGuarding message is a remote type (remote RTR bit set in COB-ID). All other messages used by this implementation of the CANopen are not RTR.

#### F.1.1.5 Object Dictionary Elements

The Object Dictionary is accessible from a master CANopen and represents the set of objects used to configure, send and monitor size.

The following table shows the communication objects used and accessibility with master CANopen.

Index (hex)	Name
1000	Device Type
1001	Error Register
1002	Manufacturer status register

Index (hex)	Name
1005	COB-ID SYNC Message
1006	Communication cycle period
1008	Manufacturer Device Name
1010	Store parameter
1009	Manufacturer Hardware Version
100A	Manufacturer Software Version
100C	Guard Time
100D	Life Time Factor
1014	COB-ID Emergency
1016	HeartBeat time consumer
1017	HeartBeat time producer
1018	Identity object
1029	Error behavior object
1400	1st Receive PDO
1401	2nd Receive PDO
1402	3rd Receive PDO
1403	4th Receive PDO
1600	Receive PDO1 mapping parameter
1601	Receive PDO2 mapping parameter
1602	Receive PDO3 mapping parameter
1603	Receive PDO4 mapping parameter
1A00	Transmit PDO1 mapping parameter
1A01	Transmit PDO2 mapping parameter
1A02	Transmit PDO3 mapping parameter
1A03	Transmit PDO4 mapping parameter
1800	1st Transmit PDO
1801	2nd Transmit PDO
1802	3rd Transmit PDO
1803	4th Transmit PDO

Table 1.5.1: Objects used by the CANopen communication profile

The objects shown in bold in the table allow writing of the parameters assigned with the exchange of data in the PDO.

The allocation criterion is variable, and depends on the size (in bytes) of the parameter exchanged.

#### F.1.1.6 RX PDO Entries

The structure of the PDO Communication Parameter (index 1400h, 1401h) is:

- 1) Subindex 0 (Number of supported entries ) = 2
- 2) The structure of Subindex 1 (COB-ID used by the PDO) is:
  - Bit 31 (valid/invalid PDO) can be set via SDO.
  - Bit 30 (RTR Remote Transmission Request) = 0 because this function is not supported.
  - Bit 29 = 0 because the 11-bit ID is used (CAN 2.0A).
  - Bits 11-28 are not used.
  - Bit 0-10 COB-ID (see table 1.4.1).
- 3) Cyclic-synchronous Subindex 2 (Transmission Type), or synchronous according to the master performed setting (1 if SYNC has been foreseen, 254...255 if asynchronous). If not stated, the synchronous mode is active.

#### F.1.1.7 TX PDO Entries

The structure of the PDO Communication Parameter (index 1800h, 1801h) is:

- 1) Subindex 0 (Number of supported entries ) = 3
- 2) The structure of Subindex 1 (COB-ID used by the PDO) is:
  - Bit 31 (valid/invalid PDO) can be set via SDO.
  - Bit 30 (RTR Remote Transmission Request) = 0 because this function is not supported.
  - Bit 29 = 0 because the 11-bit ID is used (CAN 2.0A).
  - Bits 11-28 are not used.
  - Bit 0-10 COB-ID (see table 1.4.1).
- 3) Cyclic-synchronous Subindex 2 (Transmission Type), or synchronous according to the master performed setting (1 if SYNC has been foreseen, 254...255 if asynchronous). If not stated, the synchronous mode is active.

- 4) Inhibit time

#### **F.1.1.8 SDO Entries**

Only the “Expedited” data transfer mode (max. 4 Bytes) is used.

- 1) Subindex 0 (Number of supported entries ) = 3 because the device is a Server of the SDO service.
- 2) The structure of the Subindex 1 and 2 (COB-ID used by the SDO) is:
  - Bit 31 (valid/invalid SDO); it is equal to 1 because just the Default SDOs are used.
  - Bit 30 reserved = 0.
  - Bit 29 = 0 because the 11-bit ID is used (CAN 2.0A).
  - Bits 11-28 are not used.
  - Bit 0-10 COB-ID (see table 1.4.1).

The element “node ID of SDO’s client resp. server” is not supported because just the Default SDOs are used.

#### **F.1.1.9 COB-ID SYNC Entries**

The structure of the 32 bits contained in the COB-ID SYNC communication parameter is:

- Bit 31 = 1 because the CANopen interface card is a “consumer” of SYNC messages.
- Bit 30 = 0 because the interface card does not create SYNC messages.
- Bit 29 = 0 because the 11-bit ID is used (CAN 2.0A).
- Bits 11-28 are not used.
- Bit 0-10 COB-ID (see table 1.4.1).

#### **F.1.1.10 COB-ID Emergency**

The structure of the 32 bits contained in the COB-ID Emergency Message communication parameter is:

- Bit 31 = 0 because the CANopen interface card is not a “consumer” of Emergency messages.
- Bit 30 = 0 because the interface card creates Emergency messages.
- Bit 29 = 0 because the 11-bit ID is used (CAN 2.0A).
- Bits 11-28 are not used.
- Bit 0-10 COB-ID (see table 1.4.1).

### **F.1.2 CANopen management**

The user interface of the CANopen protocol is performed via the drive parameters. The parameters are controlled via hierarchical menus. All the writing parameters referring to the field bus are active only after the drive reset. Here following is a list of drive parameters useful to control the CANopen protocol.

To enable CANopen, set parameter PAR 4000 **Fieldbus type** to CANopen or DS417.

The following parameters are available in the COMMUNICATION->CONTROL COMM menu:

PAR	Par Name	Type	Default value	Attr
4004	Fieldbus baudrate	Enum	None	Write
4006	Fieldbus address	2 byte unsigned	0	Write
4010	Fieldbus M->S enable	Enum	On	Write
4012	Fieldbus alarm mode	2 byte unsigned	0	Write
4014	Fieldbus state	Enum	Stop	Read only

- Fieldbus baudrate = Sets the network baud rate. Values available for CANopen: 125k, 250k, 500k, 1M
- Fieldbus address = address of this slave node in the network, accepted values from 1 to 127
- Fieldbus M->S enable = if set to Off data in the RPDOs are not processed by the drive
- Fieldbus alarm mode = if set to 1 the drive generates Opt Bus Fault errors relating to the loss of communication (Bus Loss) even when the drive is not enabled.
- Fieldbus state = state of the communication for this node on the CANopen network: Stop, Pre-Operational, Operational.

### F.1.3 Process Data Channel Control

This function allows to allocate the drive parameters or application variables to the Process Data Channel data.

As for the CANopen protocol, the PDC is performed via the PDO messages (Process data Object).

The CANopen protocol uses a number of words for the Process Data Channel (abbr. PDC Process Data Channel), which can always be set.

The fieldbus Process Data Channel configuration is the following:

Data 0      Data...      Data n

The drive can both read and write the Process Data Channel data.

A datum can be made both of 2 and 4 bytes. The word "data" refers to any quantity of bytes included between 0 and 16, if the byte total number required is not higher than 32.

*Example:*


It is possible to have:

- from 0 to 16 data with 2 bytes
- 1 datum with 4 bytes + from 0 to 14 data with 2 bytes
- 2 data with 4 bytes + from 0 to 12 data with 2 bytes
- ...
- 8 data with 4 bytes

The data exchanged via the PDC can be of two types:

- drive parameters
- variables of an MDPlc application. The use of the MDPlc variables is described in par. 1.3.1 and 1.3.2.

The master writes the data defined as PDC input and reads the data defined as PDC output.



#### F.1.3.1 PDC Input Configuration (FB XXX MS Parameter)

Data exchanged in RPDOs are configured using the parameters in the COMMUNICATION->FIELDBUS M2S menu.

PAR 4030 **Fieldbus M->S1 ipa** = IPA of the parameter to be exchanged.

Must contain a valid IPA corresponding to the parameter to be written or 0 if sys (PAR 4032...4172 **Fieldbus M->Sn sys**) is Fill or Mdplc; the parameter PAR 4020 **Fieldbus M->S1 ipa** must be assigned to the Lift Wdef Input, while the parameter PAR 4022 **Fieldbus M->S1 sys** must be set on Mdplc16

By selecting the corresponding enum PAR 4034 **Fieldbus M->S2 mon** for src type parameters (Source), the value of the parameter 4030 is automatically set at the IPA of the src.

For src type parameters with an FB type different from 0, the data arriving on the fieldbus is not written in the enum selection, but directly in the mon associated with the src.

If it contains a valid IPA and is forced to 0, the corresponding sys parameter takes on the Fill value (16 or 32 in relation to that shown before), ensuring that the structure of the exchanged data area is not modified.

PAR 4032 **Fieldbus M->S2 sys** = format of the data to be exchanged

This parameter is automatically changed to the recommended value when the corresponding PAR 4030...4170 **Fieldbus M->Sn ipa** is changed. The automatic value can be changed by the user, however, the permitted values depend on the parameter.

Data mapping in PDOs is performed on the basis of the data format set in Fieldbus M->Sn sys according to the following rules:

- PDOs are filled starting from RPDO1
- When the PDO contains 4 words it is full and the next RPDO is filled with a maximum of 4 PDOs
- 32-bit data (long or float) cannot be split among PDOs, they must be placed inside the PDO (an alarm is generated)
- PDOs containing fewer than 4 words can be created, using **Fieldbus M->Sn dest= None** but assigned (**Fieldbus M->Sn sys** other than Not Assigned, Fill16 or Fill32) after an assigned datum.  
(N.B.: if assigned as Fill16 or Fill32, the datum is included in the PDO anyway)
- At the first **Fieldbus M->Sn sys = Not Assigned** parameter the PDOs are complete. The size of the last PDO thus depends on the data that have been assigned.

- **Example : RPDO1 di 2 word and RPDO2 di 2 word:**
  - Fieldbus M->S1 dest** = Ramp ref 1 src
  - Fieldbus M->S1 sys** = EU
  - Fieldbus M->S2 dest** = Word decomp src
  - Fieldbus M->S2 sys** = Count 16
  - Fieldbus M->S3 dest** = None
  - Fieldbus M->S3 sys** = Count 32
  - Fieldbus M->S4 dest** = Compare 1 src
  - Fieldbus M->S4 sys** = Count32
  - Fieldbus M->S5 sys** = Not Assigned

#### F.1.3.2 PDC Output Configuration (FB XXX SM Parameter)

Data exchanged in RPDOs are configured using the parameters in the COMMUNICATION->FIELDBUS S2M menu (refer to the drive manual).

Data mapping in PDOs is performed on the basis of the data format set in **Fieldbus M->Sn sys** according to the following rules:

- PDOs are filled starting from TPDO1
- When the PDO contains 4 words it is full and the next TPDO is filled with a maximum of 4 PDOs.
- 32-bit data (long or float) cannot be split among PDOs, they must be placed inside the PDO (an alarm is generated).
- PDOs with fewer than 4 words can be created, using Fieldbus S->Mn src= None Used but assigned (**Fieldbus M->Sn sys** other than Not Assigned, Fill16 or Fill32) after an assigned datum.
- At the first **Fieldbus S->Mn sys** = Not Assigned parameter the PDOs are complete. The size of the last PDO thus depends on the data that have been assigned.

#### F.1.3.3 Use of the PDC in MDPlc Applications

It is possible to configure both the PDC input and output data in order to allow the data direct access via the MDPlc application code.

For read data simply set **Fieldbus M->Sn sys** to MDPLC16 or MDPLC32, leaving **Fieldbus M->Sn dest** = None.

The MDPLC application can now read the incoming datum directly from the **Fieldbus M->Sn mon** parameter.

Write data are configured by setting **Fieldbus S->Mn src** = Dig Fieldbus S->Mn.

**Fieldbus S->Mn sys** is automatically set to MDPLC. The application writes the datum in the **Dig Fieldbus S->Mn** parameter to send it to the bus.

### F.1.4 SDO management

The SDO service is always available.

The drive parameters can be accessed via the “MSPA” Manufacturer Specific Profile Area (2000hex< index <5FFFhex).

The index to be shown in the SDO command to access a drive parameter is obtained via the following rules:

SDO index = PAR + 2000h

SDO subindex = 1

The Data field must contain the value of the drive parameter.

*Example:*

Writing the value 1m/s in the PAR 11020 **Multi speed 0** (2B0C hex).

The following information is required:

- 1) The SDO index resulting from the formula is  
2000hex + 258hex = 2258h
- 2) The value to be written is 1, corresponding to 1 hex.
- 3) Parameter writing code = 22h
- 4) Parameter reading code = 40h
- 5) Sub-index = 01h

The ipaCan parameter and relative value is written by first inserting the lower part of the address in hexadecimal and then the higher part (Value to be written LL-LH-HL-HH).

**Example of value 1 writing:**

MessageID	Writing Code	Lower part IpaCan	Higher part IpaCan	Subindex	Value of parameter LL	Value of parameter LH	Value of parameter HL	Value of parameter HH
601h	22h	0Ch	43h	01h	01h	00h	00h	00h
	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7

In the event of success the following message is received:

MessageID	Writing Code	Lower part IpaCan	Higher part IpaCan	Subindex	Value of parameter LL	Value of parameter LH	Value of parameter HL	Value of parameter HH
601h	60h	0Ch	43h	01h	01h	00h	00h	00h
	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7

**Example of reading: with value 1**

MessageID	Writing Code	Lower part IpaCan	Higher part IpaCan	Subindex	Not significant	Not significant	Not significant	Not significant
601h	40h	0Ch	43h	01h	00h	00h	00h	00h
	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7

In the event of success the following message is received:

MessageID	Reading code	Lower part IpaCan	Higher part IpaCan	Subindex	Value of data			
601h	43h	0Ch	43h	01h	01h	00h	00h	00h
	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7

Index		Subindex						
0Ch	4Bh	01h	01h	00h	00h	00h		
Drive parameter index		Subindex	Drive parameter value to be assigned to SDO					

In case an error occurs during the parameter reading or setting, the CANopen interface sends an Abort domain transfer message; the value of Application-error-codes has the following meanings:

Error class	Error code	Additional code (hex)	Meaning
6	0	0	Parameter doesn't exist
8	0	22	Access failed because of present device state
6	1	2	Read/Write only error
8	0	0	Generic error
6	9	32	Minimum value
6	9	31	Maximum value
5	4	0	SDO time_out
5	4	1	Invalid command
3	9	30	Invalid value

## F.1.5 Alarms

### Fieldbus alarms

The bus failure is signaled via the **Opt Bus Fault [17]** alarm. As for CANopen, the possible failure causes are:

- “Bus-off” condition of the CAN line;
- the drive has not been enabled in the “Operational” mode;
- the “Life Guarding” threshold has been overcome.

This alarm becomes active only when the drive is enabled.

If 1 (Enabled), the PAR 4012 **Fieldbus alarm mode** parameter enables the generation of the “Field bus failure” alarm also when the drive is disabled.

Codice	Cfg	Description	Actions
0		Bus Loss	Check line for noise, terminations , problems with cabling
FF01	*	Fieldbus type does not match expansion card	Please contact Technical Assistance.
FF02	*	Wrong baudrate selected	Check “Fieldbus baudrate” is one of 125k, 250k, 500k, 1M
FF03	*	Invalid address for node	Check “Fieldbus address”
FF04	*	Error initializing CAN interface	Internal error, contact manufacturer
FF14..FF23	*	Wrong object selected for mapping in channel M2S n	Check “Fieldbus M->Sn Dest”
FF24..FF33	*	More than 1 Src pointing to M2S Channel n	Check for multiple destinations on “Fieldbus M->Sn Dest”
FF34..FF43	*	M2S Channel n , data size is wrong (16 bits on 32 bits or 32 bits on 16 bits parameter)	Check “Fieldbus M->Sn sys”
FF44..FF53	*	Invalid parameter in channel S2M n	Check “Fieldbus S->Mn src”
FF54..FF63	*	S2M Channel n , data size is wrong (16 bits on 32 bits or 32 bits on 16 bits parameter)	Check “Fieldbus S->Mn sys”
FF64..FF73	*	Wrong object selected for mapping in channel S2M n	Check “Fieldbus S->Mn src”
FF74..FF83	*	M2S Channel n : too many words in PDC	“Fieldbus M-Sn dest” & “Fieldbus M->Sn sys” address more than 16 words in PDC
FF84..FF93	*	S2M Channel n : too many words in PDC	“Fieldbus S->Mn src” & “Fieldbus S->Mn sys” address more than 16 words in PDC
FFB4..FFC3	*	Internal database error on channel n	Internal error, contact manufacturer
8110		CAN msg overflow	Too many packets for selected baudrate
8130		LifeGuard/HeartBeat error	Software timeout from master
FFC5		Wrong NMT message length	Check NMT packets
FFC6		Invalid NMT command	Check NMT packets
FFC7		CAN bus off	Check line state for problems

### Drive alarm handling

Drive alarms are managed by means of an Emergency message containing the error code relating to the alarm that is generated, according to the table below:

Selezione	Codice
No alarm	0
Oversvoltage	1
Undervoltage	2
Ground fault	3
Overcurrent	4
Desaturation	5
MultiUndervolt	6
MultiOvercurr	7
MultiDesat	8
Heatsink OT	9
Heatsinks OTUT	10
PTC failure	11
Motor OT	12
Drive overload	13
Motor overload	14
Bres overload	15
Phaseloss	16
Opt Bus fault	17
Opt 1 IO fault	18
Precharge fault	19
Not used	20

Selezione	Codice
External fault	21
Speed fbk loss	22
Overspeed	23
Speed ref loss	24
Not used	25
Power down	26
Phaseloss out	27
OV safety	28
Safety failure	29
Mot phase loss	30
Ropes change	31
Enable missing	32
Cont feedback	33
Brake Feedback	34
Door Feedback	35
Brake Failure	36
Safe Brake Test	37
Speed limit	38
Up/low limit	39
Lift ext fault	40
EBC fault	41

Selezione	Codice
No battery	42
Plc10 fault	42
Plc11 fault	43
Plc12 fault	44
Plc13 fault	45
Plc14 fault	46
Plc15 fault	47
Plc16 fault	48
Watchdog	49
Trap error	50
System error	51
User error	52
Param error	53
Load def par	54
Plc cfg error	55
Load def plc	56
Key failed	57
Encoder error	58
Recovery mode	59

## EBC Alarms

Malfunctions of the bus between EBC and ADL are signalled by the EBC fault alarm (41). This alarm is only active when parameter 8150 EBC enable is enabled, which activates communication with an EBC.

CODE	LABEL	DESCRIPTION
0x0000	ALM_no_alarms	No communication alarm
0x0001	ALM_ng_err_timeout	NodeGuarding time expired (canopen line interrupted)
0x0002	ALM_ng_err_generic	Unexpected error in NG management
0x0003	ALM_ng_err_toggle	NG toggle bit misaligned (serious problems on canopen communication line)
0x0004	ALM_fail_reset_node	NMT command to reset communication to EBC failed
0x0005	ALM_ebc_missing	"Device-type" request to EBC failed too many times. EBC NOT PRESENT on canopen line
0x0006	ALM_badline_ebc	"Device-type" request to EBC failed. Recovery test in progress
0x0007	ALM_ebc_preop_missing	EBC node in timeout when NG and PLC started
0x0008	ALM_ebc_product_error	EBC product information reading by SDO failed or EBC PRODUCT_TYPE and PROD-UCT_CONFIG are inconsistent
0x0009	ALM_ebc_config_error	Parameters were not transferred correctly from the ADL to the EBC
0x000a	ALM_ebc_initpdo1	PDO initialization failed
0x000b	ALM_ebc_initpdo2	PDO like SDO initialization failed
0x000c	ALM_ebc_startnode	Start remote node failed
0x000d	ALM_ebc_pdoNo_operative	EBC OPERATION did not cut in
0x000e	ALM_ebc_pdos_missing	No PDOs received from the EBC
0x000f	ALM_ebc_sys_fault	EBC node restart. Deleting old PDOs failed
0x0010	ALM_fail_stop_node	Stop mode command was sent to EBC, but transmission failed
0x0011	ALM_ebc_local_ON	EBC local switch set to local
0x0012	ALM_ebc_crypt_error	CRYPT sequence failed
0x0013	ALM_ebc_relocked_error	EBC passed the CRYPT phase but, during resetting or with EBC ready, it repeats the request for CRYPT sequence
0x0014	ALM_ebc_pdoReset_error	EBC final reset command failed.
0x0015	ALM_ebc_NowRemote	EBC with switch in local mode... If it is set to remote, it issues an alarm and stops the EBC

## F.1.6 Configuration example

This chapter provides an example of how to configure the parameters of ADL550 drives so that they can be read and written by a CANopen master via the processing channels (PDO). See the chapter 1.4 for the configuration channels (SDO). The paragraph 1.6.1 provides the information required on a CANopen master controlling a machine. The paragraph 1.6.2 contains basic information for programming the ADL550 drive starting from the factory settings. In this example, drive programming is performed using the WEG\_DriveLabs configurator. All operations can, of course, be performed via keypad.

### F.1.6.1 CANopen Master

This section contains an example of data exchange seen from the master side. This is the data normally contained in the machine specifications in the case of applications controlled by a CANopen master.

#### F.1.6.1.1 Description of Master -> Slave PDO Communication

There are two parameters to be written via the processing channels. The first is a control word, in which the single bits contain certain commands (e.g. enable, start, etc.). The second processing channel contains the ramp reference 1 (RampRef1) in rpm.

*CANopen PDO: Master -> Drive (max 16 word)*

Position	Description	Format	Unit of Measure
Word1 M -> S	Control word	16 bit Word	...
Word2 M -> S	Multi speed 7	Float	rpm
Word3 M -> S			
...			
...			
Word16 M -> S			

*CONTROL WORD, Example:*

Bit	Description	Remarks
0	EnableCmd	Enable command from CANopen master
1	StartFwdCmd	Start forward command
2	StartRevCmd	Start reverse command
3	Emergency mode	Emergency operation command
4	MltSpd S0	Multi speed 0 sel
5	MltSpd S1	Multi speed 1 sel
6	MltSpd S2	Multi speed 2 sel
7	Free	
8	Free	
9	Free	
10	Free	
11	Free	
12	Free	
13	Free	
14	Free	
15	Free	

#### F.1.6.1.2 Description of PDO Slave -> Master Communication

The can master reads three parameters from the drive: the first two contain, respectively the two status words (Lift Status Word1 and Lift Status Word2) whose individual bits contain information of the drive's status (e.g. LiftEnable.). Only Lift Status Word1 is used by this application, Lift statusWord 2 can be omitted. The third parameter is the current speed in rpm.

*CANopen PDO Slave > Master (max 16 Word)*

Position	Description	Format	Unit of Measure
Word1 S -> M	LiftStatus Word1	16 Bit Word	BitWide
Word2 S -> M	LiftStatus Word2	16 Bit Word	BitWide
Word3 S -> M	Actual Speed	Int 16 bit	rpm
Word4 S -> M			
...			
...			
Word16 S -> M			

Lift control outputs can usually be connected to the PAD parameters according to the table below:

Bit	Description	Remarks
0	LiftEnable	Lift enable command.
1	RunCont	Run command contactor
2	UpCont	Up command contactor
3	DownCont	Down command contactor
4	BrakeCont	Brake command contactor
5	LiftDcBrake	DC brake function command (firmware)
6	Brake2	Brake control signal (See sequences)
7	DoorOpen	Open door command
8	LiftStart	Lift start command
9	-----	
10	Lift statusWord	Contains copy of the StatusWord (selectable via SelLiftStatWord)
11	-----	
12	-----	
13	-----	
14	InputVariable	Connected to the input selector
15	LiftWdeInp	Connected to the LifWDecomp selector
16		

*LiftStatusWord (connected to Pad11)*

Bit	Description	Remarks
0	LiftEnable	Lift enable command.
1	RunCont	Run command contactor
2	UpCont	Up command contactor
3	DownCont	Down command contactor
4	BrakeCont	Brake command contactor
5	LiftDcBrake	DC brake function command (firmware)
6	Brake2	Brake control signal (See sequences)
7	DoorOpen	Open door command
8	Drive Ok	
9	SpeedIsZero	
10	SpeedRefIsZero	
11		
12		
13		
14		
15	(EPC Enable)	

Outputs available directly on the drive:

- Drive OK
- SpeedIsZero

#### F.1.6.2 ADL550 Configuration

The example given in this section is based on the assumption that the parameters of the ADL550 drive are the factory settings (**Default parameter** command). Use of the keypad is recommended for performing commissioning in the first phase (see the ADL500 HW + QS manual). Then the motor should be moved using the digital input commands.

Similarly, a system start-up wizard must be available on the WEG\_DriveLabs configurator .

The programming sequence is as follows:

- **Fieldbus configuration**
- **Fieldbus M2S configuration**
- **LIFT\LIFT IN\OUT configuration**
- **Fieldbus S2M configuration**


### F.1.6.2.1 FIELDBUS CONFIG

This example shows the parameter settings to be performed with 500Kbaud CANopen and address 1.

- Menù COMMUNICATION\CONTROL COMM.
- Example of configuration with **500Kbaud CANopen address 1**:

In the example, it is assumed that the drive is node 1 and the CANopen communication takes place with a baud rate of 500k. Make sure that all fieldbus settings and configurations are only effective after the drive's next reset.

Program the fieldbus menu parameters as shown in the following figure (“Expert” mode):



The status is pre-operational and the CAN led on the front is flashing.

Under these conditions, the process communication channels are not active.

At the end from the drive's programming (see below) and communication can be activated by the master through the NMT “start node” command.

Upon receipt of this command, the FieldBus parameter goes into the Operational condition and the CAN led goes from flashing to fixed. Only at this point are the process channels active.


LED	Meaning
CAN (verde)	
Off	Stop
Flashing	Pre-operational
On	Operational

### F.1.6.2.2 Fieldbus M2S configuration

As regards communication through process channels (PDC), in the configuration in this example, the first channel is reserved for writing lift commands (writing of the control word).


Control word configuration is achieved by using an internal Lift Decomp parameter. The following figure shows the programming of this control word on the first word M → S. On the second word M → S, the **Multi-speed 7** [11034] parameter is programmed:

"Expert" mode:



### F.1.6.2.3 LIFT IN/OUT configuration

At this point, simply connect the individual Lift Decomp bits. Programming from the digital input to LIFT DECOMP LIFT/IN bit as shown in the figure below:



Now all lift sequences are controlled via the LiftWdecomp bits in the same way as described in the manual using digital inputs.


Parameter 14102 **Command input mon**, displays state of word in Hex.

#### F.1.6.2.4 Fieldbus S2M configuration

The configuration of these channels takes place in the Fieldbus S2M menu. Lift statusWord 1 and 2 are used to program the first and second process channels. Word 2 status can be omitted.

The third channel is programmed on the 260 parameter (**Motor Speed**).

The following figure shows the S→M programming of the example:




#### F.1.6.2.5 Configuration check

A selection of communication checking notes/tips.

- PDO communication is only active in “Operational Mode”. Check the status via WEG\_DriveLabs or CAN led (lit) on drive front panel.
- For Master → Slave communication in FIELDBUS M2S menu, the value received from the communication channel can be checked (e.g. the parameter **Fieldbus M->S1 mon** [4024] is for the first channel).
- If communication is in EU (engineering units), remember that the value read on FIELDBUS M2S is in internal units.

#### F.1.6.2.6 Configuration errors

If a mistake has been made in configuring a channel, the “Option bus fault” drive alarm is activated upon starting up and provides an error code indicating the channel which has generated the alarm. The list of error codes is available in chapter 1.5 of this appendix.



## G - Appendix 2 - Phasing

---

In order for the ADL550 Brushless regulation algorithm to function correctly, it is necessary to know the position of the rotor with respect to the stator power phases. Therefore the 0° position provided by the absolute encoder must be known with respect to the position of a motor pole and the encoder count direction must match the motor power phases.

This is called phasing. Phasing can be performed manually, directly by means of the mechanical encoder assembly position on the motor shaft and on the phases, or using the STARTUP WIZARD FOR BRUSHLESS MOTORS an automatic procedures available in the drive (see Step 6 – Autotune with motor at stand-still and encoder phasing), ch. 9.3, ADL500 HW+QS manual).

Phasing must always be repeated whenever:

- the encoder assembly position is changed
- the phase sequence of the motor power supply connection is changed
- the encoder incremental signal connection is changed
- the encoder absolute signal connection is changed
- the value of the PAR 2008 **Pole pairs** parameter is changed
- the value of the PAR 2100 **Encoder pulses** parameter is changed
- the drive is replaced (alternatively, download parameters taken from previous drive)

There are two different procedures that can be launched by writing two different parameters:

- PAR 2190 **Autophase rotation** -> rotation phasing:  
this procedure must be performed with the motor free to turn and with no load applied.
- PAR 2192 **Autophase still** -> static phasing:  
this procedure must be performed with the motor still and brake applied.

### G.2.1 Rotation phasing

This procedure is based on the possibility of moving the motor, by a maximum angle of two pole pairs, to find correct encoder phasing, cross-check the available encoder and motor data and, if the encoder count direction does not match the phase sequence of the motor power supply, correct it by automatically modifying PAR 2130 **Encoder direction**.

**Note!**

In the case described above, a positive speed reference could generate a rotation in reverse with respect to that defined as positive for the encoder (usually clockwise), while still ensuring good motor control.

The encoder direction defined as positive can be stored as the positive reference direction by inverting two motor power phases and repeating the rotation phasing procedure.

If the procedure is terminated without any errors, code 0 is shown on the keypad, otherwise if any differences have been detected that cannot be corrected by the drive, one of the codes listed in Autotune (phasing) is shown, **see chapter 10.3 Messages** on ADL500 HW+QS manual.

- faults in electric signals not detected with a “**Speed fbk loss [22]**” alarm
- error in the PAR 2008 **Pole pairs** parameter setting
- error in the PAR 2100 **Encoder pulses** parameter setting

### G.2.2 Static phasing

Using this method, in which the motor cannot move, the encoder and motor data cannot be cross-checked to verify the matching of parameters or count direction.

This condition must therefore be checked before launching the procedure.

**Manuale SW**  
Serie: ADL530  
Revision: 1.0  
Data: 01/02/2024  
Codice: 1S93SWEN

[www.weg.net](http://www.weg.net)

WEG Automation Europe S.r.l.  
Via Giosuè Carducci, 24  
21040 Gerenzano (VA) · Italy

Technical Assistance: [technohelp@weg.net](mailto:technohelp@weg.net)  
Customer Service: [salesmotion@weg.net](mailto:salesmotion@weg.net)

Driving efficiency and sustainability

