

*User's guide*

*Guia del usuario*

*Manual do usuário*



**PLC<sup>2</sup>**

**Programmable Controller  
PLC2 Board**

**Controlador Programable  
Tarjeta PLC2**

**Controlador Programável  
Cartão PLC2**





# **MANUAL**

# **PLC2 BOARD**

**PROGRAMMABLE IN LADDER LANGUAGE**

**BY WLP SOFTWARE**

12/2006

---

**PLC2 Software: V1.5X**

0899.5550 E/2

## Summary of Revisions

---

The table below describes all revisions made to this manual.

<b>Revision</b>	<b>Description</b>	<b>Section</b>
1	First Edition	-
2	General Revision	-

### Quick Parameter Reference, Fault Messages

I Parameters .....	06
II Error Messages .....	10

---

#### **CHAPTER 1**

#### Safety Notices

1.1 Safety Notices in the Manual .....	11
1.2 Safety Notices on the Product .....	11
1.3 Preliminary Recommendations .....	12

---

#### **CHAPTER 2**

#### General Information

2.1 About this Manual .....	13
2.2 About the PLC2 Board .....	13
2.3 General Characteristics of the PLC2 .....	14
2.3.1 Hardware .....	14
2.3.2 Software .....	15

---

#### **CHAPTER 3**

#### Installation and Configuration

3.1 Installing the PLC Board on the Drive .....	16
3.2 Configuring the Jumpers .....	18
3.3 Connectors Description .....	18
3.4 Configuring the CFW-09 to Operate with PLC2 Board ..	23

---

#### **CHAPTER 4**

#### Detailed Parameter Description

Detailed Parameter Description .....	25
--------------------------------------	----

## QUICK PARAMETER REFERENCE, FAULT MESSAGES

Software: V1.5X

Application:

Model:

Serial Number:

Responsible:

Date:        /        /        .

### I. Parameters

The parameters presented hereby represent the functions provided by the PLC2 board. Besides them, the PLC2 also makes available a general-purpose range of parameters from P800 to P899, which can be programmed by the user (refer to the WLP manual).

Parameter	Description [Type]	Adjustable Range	Factory Setting	Unit	Page
P750	PLC2 firmware version [Read]	Related to the purchased board	-	-	25
P751	Scan cycle in 100µs units [Read]	0 to 65535	-	x100µs	25
P752 (*)	Resets the retentive markers [Configuration]	0=No action 1=Reset register	0 = No action	-	25
P753 (*)	Loads factory settings, if =1234 [Configuration]	0 to 65535	0	-	25
P754	Position reference (rotations) [Read]	0 to 65535	-	rotations	25
P755	Position reference (fraction of rotation) [Read]	0 to 3599	-	degrees / 10	25
P756	Real position signal [Read]	0=Negative 1=Positive	-	-	25
P757	Real position (rotations) [Read]	0 to 65535	-	rotations	26
P758	Real position (fraction of rot.) [Read]	0 to 3599	-	degrees / 10	26
P759	Lag error [Read]	0 to 3599	-	degrees / 10	26
P760	Proportional position gain (Kp) [Configuration]	0 to 200	50	-	26
P761	Integral position gain (Ki) [Configuration]	0 to 200	0	-	26
P762	Max. lag error [Configuration]	0 to 65535	1800	degrees / 10	26
P763	Disable user program [Configuration]	0=Program enable 1=Program disable	0=Program enable	-	26
P764 (*)	PLC address at network [Configuration]	1 to 247	1	-	26

(\*) IMPORTANT: To enable the system to operate according the parameter setting, the system must be reset after one or more parameters have been changed.

Parameter	Description [Type]	Adjustable Range	Factory Setting	Unit	Page
<b>P765</b> (*)	Baud rate of RS232 [Configuration]	1=1200bps 2=2400bps 3=4800bps 4=9600bps 5=19200bps 6=38400bps	4=9600bps	bits/second	27
<b>P766</b> (*)	PID sample time [Configuration]	1 to 10000	1	x1.2ms	27
<b>P767</b> (*)	Synchronous motor speed [Configuration]	0 to 10000	1800	rpm	27
<b>P768</b> (*)	Encoder 1 zero pulse (main) position [Configuration]	0 to 10000	1024	ppr = pulses per revolution	27
<b>P769</b> (*)	Encoder 1 zero pulse (master) position [Configuration]	0 to 3599	0	degrees / 10	27
<b>P770</b> (*)	CAN protocol [Configuration]	0=Disabled 1=CANopen 2=DeviceNet	0=Disabled	-	28
<b>P771</b> (*)	CAN address [Configuration]	0 to 127	63	-	28
<b>P772</b> (*)	CAN baud rate [Configuration]	0=1Mbit/s 1=Reserved 2=500 Kbit/s 3=250 Kbit/s 4=125 Kbit/s 5=100 Kbit/s 6=50 Kbit/s 7=20 Kbit/s 8=10 Kbit/s	0=1Mbit/s	Mbit/s or Kbit/s	28
<b>P773</b>	Bus off recovery [Configuration]	0=Manual 1=Automatic	0=Manual	-	29
<b>P774</b>	Action to be taken upon detection of a communication failure [Configuration]	0=Indicate the error 1=Cause a fatal error on the device	1=Cause a fatal error on the device.	-	29
<b>P775</b>	CAN status [Read]	0=Disable 1=Reserved 2=CAN enable 3=Warning 4=Error passive 5=Bus off 6=Not powered	-	-	29
<b>P776</b>	Counter of received telegrams [Read]	0 to 65535	-	-	30
<b>P777</b>	Counter of trasmitted telegrams [Read]	0 to 65535	-	-	30
<b>P778</b>	Counter of detected errors [Read]	0 to 65535	-	-	30

(\*) IMPORTANT: To enable the system to operate according the parameter seeting, the system must be reset after one or more parameters have been changed.

Parameter	Description [Type]	Adjustable Range	Factory Setting	Unit	Page
<b>P779</b>	Configuration status CANopen [Read]	0=Slave 1=Master	-	-	30
<b>P780</b>	CANopen communication status [Read]	0=Disabled 1=Reserved 2=CANopen enabled 3=Node guarding enabled 4=Node guarding error	-	-	30
<b>P781</b>	CANopen node status [Read]	0=Not initialized 4=Stopped 5=Operational 127=Pre-operational	-	-	31
<b>P782</b>	DeviceNet network status [Read]	0=Not powered / Not on-line 1=On-line / Not connected 2=Link OK / On-line and Connected 3=Connection timeout 4=Critical link failure 5=Running auto-baud	-	-	31
<b>P783</b>	DeviceNet master status [Read]	0=Master running 1=Idle master	-	-	31
<b>P784</b>	Number of input words [Configuration]	1 to 10	1	-	31
<b>P785</b>	Number of output words [Configuration]	1 to 10	1	-	31
<b>P786</b>	Fieldbus board status [Read]	0=Disable 1=Inactive 2=Active and Off-line 3=Active and On-line	-	-	32
<b>P788</b>	Operation mode for the Analog Output 1 [Configuration]	0=-10 to +10V (range from -32768 to +32767) 1=0 to 20mA (range from 0 to 32767) 2=0 to 20mA (range from 0 to 65535) 3=0 to 20mA (range from -32768 to +32767) 4=4 to 20mA (range from 0 to 32767) 5=4 to 20mA (range from 0 to 65535) 6=4 to 20mA (range from -32768 to +32767)	0	-	32

(\*) IMPORTANT: To enable the system to operate according the parameter setting, the system must be reset after one or more parameters have been changed.

Parameter	Description [Type]	Adjustable Range	Factory Setting	Unit	Page
<b>P789</b>	Operation mode for the analog output 2 [Configuration]	0= -10 to +10V (range from -32768 to +32767) 1=0 to 20mA (range from 0 to 32767) 2=0 to 20mA (range from 0 to 65535) 3=0 to 20mA (range from -32768 to +32767) 4=4 to 20mA (range from 0 to 32767) 5=4 to 20mA (range from 0 to 65535) 6=4 to 20mA (range from -32768 to +32767)	0	-	33
<b>P790<sup>(*)</sup></b>	Encoder 2 pulse number (auxiliary) [Configuration]	0 to 10000	1024	ppr (pulses per revolution)	33
<b>P791<sup>(*)</sup></b>	Enables the position feedback via encoder 2 (auxiliary) [Configuration]	0=Disable 1=Enable	0=Disable	-	33
<b>P792<sup>(*)</sup></b>	Direction of encoder 2 signal (auxiliary) [Configuration]	0=A→B 1=B→A	1=B→A	-	33
<b>P793<sup>(*)</sup></b>	Select serial protocol [Configuration]	0=ModBus no parity 1=WegTP no parity 2=ModBus even parity 3=WegTP even parity 4=ModBus odd parity 5=ModBus odd parity	0	-	34
<b>P794</b>	Operation mode for the analog output [Configuration]	0= -10 to +10V (range from -32768 to +32767) 1=0 to 20mA (range from 0 to 32767) 2=0 to 20mA (range from 0 to 65535) 3=0 to 20mA (range from -32768 to +32767) 4=4 to 20mA (range from 0 to 32767) 5=4 to 20mA (range from 0 to 65535) 6=4 to 20mA (range from -32768 to +32767)	0	-	34

(\*) IMPORTANT: To enable the system to operate according the parameter setting, the system must be reset after one or more parameters have been changed.



II. Error Messages

Display	Description	Note
E50	Lag error	Fatal Error, it disables the converter. Refer to Parameter P762.
E51	Error during program saving	Reset the systems and try again.
E52	Two or more movements enabled simultaneously	Check the user program logic.
E53	Movement data are not valid	Perhaps some speed, acceleration value, etc. was reset to zero.
E54	Inverter disabled	Attempt to execute some movement with disabled inverter.
E55	Incompatible program or out of memory limits	Check program and install it again. This error also occurs when there is no program installed in the PLC (PLC powered-up first time).
E56	Wrong CRC	Transmit it again.
E57	Shaft has not been referenced to absolute movement	Before an absolut movement, you must set the machine movement to zero position.
E58	Master Reference Fault	Fatal Error: after enabled initial communication, between master and slave, by any cause has been disabled.
E59	Fieldbus off-line	Specific error of Fieldbus communication. For further information, please, refer to the Fieldbus Communication User's Guide included in the product CD.
E60	Board access / connection fault	Specific error of Fieldbus communication. For further information, please, refer to the Fieldbus Communication User's Guide included in the product CD.
E61	Bus off	<i>Bus off</i> has been detected on the CAN bus due to a high number of transfer erros. These erros may be caused due to bus problems or due to improper installation.
E63	Transceiver not powered	CANopen or DeviceNet communication error. For further information, please, refer to the CANopen or DeviceNet Communication User's Guide included in the product CD.
E65	Node Guarding Error	Specific error for the CANopen communication. For further information, please, refer to the CANopen communication user's guide provided with the product CD.
E66	Master in IDLE mode	Specific error for the DeviceNet communication. For further information, please, refer to the DeviceNet communication user's guide provided with the product CD.
E67	Timeout de conexões I/O	Specific error for the DeviceNet communication. For further information, please, refer to the DeviceNet communication user's guide provided with the product CD.

Note: the drive is disabled with fatal errors E50 and E58 and must be reset. It is possible to use the system bit register SX2 to reset a fatal error.

## SAFETY NOTICES

This Manual contains all necessary information for the correct installation and operation of the PLC2 with the CFW-09 Variable Frequency Drive.

The PLC2 Manual has been written for qualified personnel with suitable training of technical qualifications to operate this type of equipment.

### 1.1 SAFETY NOTICES IN THE MANUAL

The following Safety Notices will be used in this Manual:



#### **DANGER!**

If the recommended Safety Instructions are not strictly observed, it can lead to serious or fatal injuries of personnel and/or equipment damage.



#### **ATTENTION!**

Failure to observe the recommended Safety Procedures can lead to material damage.



#### **NOTE!**

The content of this Manual supplies important information for the correct understanding of operation and proper performance of the equipment.

### 1.2 SAFETY NOTICES ON THE PRODUCT

The following symbols may be attached to the product, serving as Safety Notice:



**High Voltages.**



**Components are sensitive to electrostatic discharge. Do not touch them.**



**Mandatory connection to ground protection (PE).**



**Shield connection to ground.**

1.3 PRELIMINARY  
RECOMMENDATIONS



**DANGER!**

Only qualified personnel should plan or implement the installation, start-up, operation and maintenance of the CFW-09 and associated equipment.

The personnel must follow all safety instructions included in this Manual and/or defined by the local regulations.

Failure to comply with these instructions may result in personnel injury and/or equipment damage.



**NOTE!**

In this Manual, qualified personnel are defined as people that are trained to:

1. Install, ground, power up and operate the CFW-09, as well as the PLC2 board, according to this Manual and the local safety procedures;
2. Use the safety equipment according to the local regulations;
3. Give first aid.



**DANGER!**

Always disconnect the supply voltage before touching any electrical component inside the inverter.

Many components are charged with high voltages, even after the incoming AC power supply has been disconnected or switched OFF. Wait at least 10 minutes for the total discharge of the power capacitors.

Always connect the frame of the equipment to the ground (PE) at the suitable connection point.



**ATTENTION!**

All electronic boards have components that are sensitive to electrostatic discharges. Never touch any of the electrical components or connectors without following proper grounding procedures.

If necessary to do so, touch the properly grounded metallic frame or use a suitable ground strap.



**NOTE!**

Read this entire Manual carefully and completely before installing or operating PLC2 board with the CFW-09.



**ATTENTION!**

For correct use of PLC2 board it is necessary to know how to use the WLP software. Read the enclosed WLP software user's guide completely before using the PLC2 board on the drive.

**GENERAL INFORMATION**

This chapter defines the contents and purpose of this manual.

**2.1 ABOUT THIS MANUAL**

This manual provides instructions for installation and use of the PLC2 board.

Chapter 1 - Safety Notices;  
 Chapter 2 - General Information;  
 Chapter 3 - Installation and Configuration;  
 Chapter 4 - Detailed Parameter Description.

This Manual provides information required for the correct use of the PLC2. As the PLC2 is very flexible, it allows many different operation modes as described in this manual. As the PLC2 can be applied in several ways, it is impossible to describe here all application possibilities of this board. WEG does not assume any responsibility when the PLC2 is not used according to this manual.

No part of this Manual may be reproduced in any form, without written consent of WEG.

The communication user's guide for the PLC2 board presented in table 2.1 complements this user's guide. These user's guides are available in PDF format on the product CD and also at WEG website.

The compatibility of these user's guides and the product is directly related to the product software version. Hence, pay attention to the communication user's guide identification (E/1, E/2, ...) when downloading it from the WEG website.

	PLC2 V1.5X	Revision
User's Guide		
ModBus User's Guide		E/1
WegTP User's Guide		P/1
CANopen Slave User's Guide		E/2
DeviceNet Slave User's Guide		P/3
WLP User's Guide		E/2
WSCAN User's Guide		E/2

**Table 2.1** - Communication user's guide for the PLC2 board

**2.2 ABOUT THE PLC2 BOARD**

The PLC2 board adds important CLP (Programmable Logical Controller) functions to the CFW-09, enabling the execution of complex linkage program by using the digital board inputs and outputs as well as the digital and analog inputs and outputs of the own inverter which can be accessed by the user's program.

Among the several available functions we can mention simple contacts and coils up to functions that uses floating point, such as sum, subtraction, multiplication, division, trigonometry, square root functions, etc.

Other important functions are the PID blocks, high-pass and low-pass filters, saturation, comparison. All these functions operate with floating point.

Besides the functions mentioned above, the PLC2 provides blocks for motor speed and motor position control, that is a trapezoidal-profile positioning and a S-profile positioning, speed reference generation with trapezoidal acceleration ramp, etc. (Note: when positioning functions used, the coupling of an encoder on motor shaft is required).

All functions can interact with the user through the 100 programmable parameters that can be accessed directly through the inverter HMI. The texts and user units of the programmable parameters can be customized by the WLP.



**ATTENTION!**

- The **CFW-09** inverter software version should be the version **V2.64** or later.
- It is possible to use the set speed block with the V/Hz control mode (scalar) for CFW-09 drives with software version V3.70 or later.

2.3 GENERAL CHARACTERISTICS OF THE PLC2

2.3.1 Hardware

The PLC2 board has the following hardware characteristics:

- ☑ 9 isolated digital inputs, bi-directional, 24Vdc;
- ☑ 1 motor PTC input;
- ☑ 3 digital relay output 250V x 3A;
- ☑ 3 digital optocoupled outputs, bi-directional, 24Vdc x 500mA;
- ☑ 1 differential analog input (-10 to +10)Vdc or (-20 to +20)mA, 14 Bits;
- ☑ 2 analog outputs (-10 to +10)Vdc or (0 to +20)mA, 12bits;
- ☑ 2 isolated encoder input, with external supply of 5Vdc or 18Vdc to 24Vdc;
- ☑ 1 serial communication interface -- RS-232C (standard Protocol: MODBUS-RTU);
- ☑ All sizes compatible with CFW-09;

- ☑ It permits the use of digital and analog inputs/outputs of the CFW-09, comprising 15 digital inputs, 9 digital outputs, 3 analog inputs and 4 analog outputs, accessed by the ladder;
- ☑ CANopen Master/Slave and DeviceNet Slave communication;
- ☑ Option for Profibus DP Slave communication;
- ☑ Option for DeviceNet communication.

### 2.3.2 Software

The software for the PLC2 board has the following characteristics:

- ☑ The Parameter Range comprises the parameter from 750 to 899, totaling 150 parameters. The 50 first parameters are predefined by the system or are reserved parameters. The other 100 remaining parameters are for general use, i. e., they may be programmed by the user and can be used for the most different functions, as contactors, timers, speed, acceleration and position references, etc.;
- ☑ Volatile (zero-initialized) and retentive BIT, WORD and FLOAT registers;
- ☑ The programming of the PLC2 board is performed via WLP Software using the Ladder Logic Language, with specific blocks for positioning and CLP functions;
- ☑ Memory capacity for the user program: 64kB (65536 bytes);
- ☑ On-line monitoring.



#### **ATTENTION!**

The PLC2 version 1.5X is compatible only with the WLP software version 6.20 or higher.

**INSTALLATION AND CONFIGURATION**

This chapter is intended to describe the installation and configuration procedures for the PLC2 board.




**ATTENTION!**


Follow the instructions included in this user's guide to guarantee the correct installation and operation of the PLC2 board and the CFW-09 drive.

**3.1 INSTALLING THE PLC BOARD ON THE DRIVE**

The PLC2 board is directly installed on the CFW-09 control board (CC9 control board), as presented in figures 3.1 and 3.2.




Sizes 1 and 2



Sizes 3 to 10

**Figure 3.1** – Location of the PLC2 board installation on the CFW-09 drive



**Figure 3.2** - Seating the PLC2 on the CC9 control board

Follow the steps below for the proper installation of the board:

- Step 1** - Make sure the equipment is disconnected from the power supply and remove the frontal cover of the CFW-09.
- Step 2** - When using size 1 drives, remove the plastic side cover.
- Step 3** - Configure the jumpers of the board according to tables 3.1, 3.2 and 3.3 of the CONFIGURING THE JUMPERS section.
- Step 4** - Replace the metal and plastic spacers installed on the CC9 control board by the spacers provided with the PLC2 kit.
- Step 5** - Seat the PLC board on the CC9 control board aligning the terminals of the XC4 and XC5 connectors (on the PLC board) with the terminals of the female XC140 and XC3 connectors (on the CC9 control board).
- Step 6** - Check if all terminals of the XC4 and XC5 connectors are aligned.
- Step 7** - Press the center and the left up corner of the board until it is completely seated on the spacers.
- Step 8** - Insert and tighten the screws to firmly secure the board to the 2 metal spacers.
- Step 9** - When using the PTC input of the PLC2 board, plug the cable connected to connector XC11 of the PLC2 board into connector XC11 of the drive control board (CC9).



3.2 CONFIGURING THE JUMPERS

Some functions and characteristics of the PLC board operation are defined by the setting of the jumpers on the board (see figure 3.3). The following tables describe the possible configurations for the jumpers and their functions.

**XC1 Jumper: Selection of Encoder Power Supply Voltage**

XC1 Status	Encoder Power Supply
Open	(8 to 24)Vdc
Close	5Vdc

Table 3.1 - XC1 jumper



**ATTENTION!**

If XC1 is closed, do not supply the encoders with voltage higher than 5Vdc. Higher voltages will damage the circuitry.

**XC2 and XC6 Jumpers: Firmware Download**

XC2 and XC6 Status	Operation
Open	Normal operation
Close	Firmware download

Table 3.2 - XC2 and XC6 jumpers

**XC81 and XC82 Jumpers: Analog Outputs AO1 and AO2 Operation Mode**

XC81 and XC82 position	Analog output operation mode
1 and 2	Voltage (-10 to +10)Vdc
2 and 3	Current (0 to 20)mA

Table 3.3 – XC81 and XC82 jumpers

3.3 CONNECTORS DESCRIPTION

Figure 3.3 shows the connectors and jumpers available on the PLC2 board.




Figure 3.3 - Detailed view of the connectors and jumpers of the PLC2 board

The connectors and their terminals function are described below.

**XC21 Connector: Relay Outputs and Digital Inputs**

XC21 Connector			Function	Specification
1	C	DO1	Digital relay outputs	Contact capacity:  3A 250Vac
2	NO			
3	C	DO2		
4	NO			
5	C	DO3		
6	NO			
7	COM DO	Reference for digital outputs DO4, DO5, and DO6	-	
8	DO4	Bidirectional Opto-isolated Digital Outputs	Maximum Voltage: 48Vdc Current capacity: 500mA	
9	DO5			
10	DO6			
11	COM DI	Reference for digital inputs DI1 to DI9	-	
12	DI9	Bidirectional Isolated Digital Inputs	Input Voltage: (15 to 30Vdc) Input Current: 11mA@24Vdc	
13	DI8			
14	DI7			
15	DI6			

Figure 3.4 - Description of XC21 connector



**ATTENTION!**

(\*) External Power Supplies.

**XC22 Connector: 24Vdc Transistor Outputs and Digital Inputs**

XC22 Connector		Function	Specifications
16	PTC1	Motor thermistor input	Attention: 3,9k Release: 1,6k Minimum resistance: 100Ω
17	PTC2	PTC	
18	GND ENC	Reference for the power supply of the encoder input	-
19	+ ENC	Encoder input power supply	Controlled 5Vdc or (8 to 24)Vdc Current consumption: 50mA + encoders current (*).
20	-	AO2	(-10 to +10)Vdc or (0 to 20)mA 12 bits
21	+		
22	-	AO1	(-10 to +10)Vdc or (0 to 20)mA 12 bits
23	+		
24	-	AI1	(-10 to +10)Vdc or (-20 to +20)mA 14 bits (**)
25	+		
26	DI1	Bidirectional, Isolated Digital Inputs	Input voltage: (15 to 30)Vdc Input current: 11mA@24Vdc
27	DI2		
28	DI3		
29	DI4		
30	DI5		

Figure 3.5 - Description of XC22 connector



**ATTENTION!**

(\*) External Power Supply.

(\*\*) For current switch S1 to ON.

Figure 3.6 shows the PTC connection to terminals 16 and 17 of XC22 connector, its operation under a motor temperature raise condition, and its return to the regular operation.




Figure 3.6 - Using PTC

**XC3 Connector: Profibus of the HMS Board**

For the connection of the Anybus-S board, which enables the PLC to communicate in a Profibus DP or DeviceNet network.

**XC7 Connector: RS-232C**

XC7 Connector	Function	Specification
1	5Vdc	5Vdc supply Current capacity: 50mA
2	RTS	Request to send
3	GND	Reference
4	RX	Receives
5	GND	Reference
6	TX	Transmits

Table 3.4 - Description of XC7 connector

**XC11 connector: PTC Circuit power supply**

When the PTC sensor is used, the appropriated cable must be connected from PLC2 board XC11 connector to the XC11 from the control board (CC9).

**XC17 Connector: CAN Network**

XC17 Connector	Function	Specifications
1	V-	Reference (GND) for the CANopen power supply
2	CANL	CANL
3	SHEILD	Shield
4	CANH	CNAH
5	V+	CANopen power supply (11 to 25)Vdc 50mA@24Vdc

Table 3.5 - Description of XC17 connector



**ATTENTION!**

Both ends of the CAN network bus shall be terminated with a 120Ω resistor. The resistor should be connected between terminals CANL and CANH.

### XC9 Connector: Incremental Encoder 1 (Main)

Applications that require more speed or positioning accuracy, a speed feedback of the motor shaft by means of incremental encoder is required. The inverter connection is realized through the XC9 (DB9) connector of the PLC2 board. This input has no encoder fault detection


The used encoder should have following features:

- ☑ Supply voltage: 15 Vdc, with current consumption lower than 200 mA;
- ☑ 2 quadrature channels (90°) + zero pulse with supplementary outputs (differential): Signals A,  $\bar{A}$ , B,  $\bar{B}$ , Z and  $\bar{Z}$ ;
- ☑ “Linedriver” type or “Push-Pull” circuit;
- ☑ Electronic circuit isolated against encoder frame;
- ☑ Number of pulses recommended per revolution: 1024 ppr.

Follow the instructions below when mounting the encoder on the motor:

- ☑ Couple the encoder onto the motor shaft directly (by using a flexible coupling, but without torsional flexibility);
- ☑ Both motor shaft and metallic encoder frame must be isolated electrically against motor (min. spacing: 3 mm);
- ☑ Use flexible couplings of high quality to prevent mechanical oscillation or “backlash”.

For electrical connection use shielded cable and lay it separately (spacing >25cm) from the other wirings (power, control cables, etc). If possible, install it inside a metallic conduit.



\* Power supply connected to XC22: 18 and 19.  
 \*\* Referenced to ground via 1 $\mu$ F in parallel with 1k $\Omega$ .  
 \*\*\* Valid pin location for encoder HS35B-Dynapar. When other encoder models are used, check the correct connection to meet the required sequence.

Figure 3.7 - Encoder 1 connection

**XC10 Connector: Incremental Encoder 2 (Auxiliary)**

The connection of the auxiliary encoder 2 is made through the XC10 connector (DB9) of the PLC2 board.


This input can be used in applications where it is necessary to use an external encoder to perform positioning functions. However, this input shall not be used for motor speed feedback. Motor speed feedback is made through XC9 connector of the main encoder 1. This input has not encoder fault detection.

The used encoder should have following features:

- ☑ Supply voltage: 15 Vdc, with current consumption lower than 200mA;
- ☑ 2 quadrature channels (90°) + zero pulse with supplementary outputs (differential): Signals A,  $\bar{A}$ , B,  $\bar{B}$ , Z and  $\bar{Z}$ ;
- ☑ “Linedriver” type or “Push-Pull” (level 15VDC) circuit;
- ☑ Electronic circuit isolated against encoder frame;
- ☑ Number of pulses recommended per revolution: 1024 ppr.

Use shielded cable for the electrical connection and run it away (at least 25cm) from the other wiring (power, control cables, etc.). If possible, run the cables inside a metal conduit.

Set P791 to 1 in order to use this input as a position feedback.



\* Power supply connected to XC22: 18 and 19.  
 \*\* Referenced to ground via 1 $\mu$ F in parallel with 1k $\Omega$ .  
 \*\*\* Valid pin location for encoder HS35B-Dynapar. When other encoder models are used, check the correct connection to meet the required sequence.

Figure 3.8 – Encoder 2 connection



**NOTE!**

The maximum permitted frequency for the main/auxiliary encoder is 100 kHz.

### 3.4 CONFIGURING THE CFW-09 TO OPERATE WITH PLC2 BOARD

In order to enable the CFW-09 to be controlled by the PLC2 board it is necessary to perform the following configurations, depending on the desired functions:

#### **Control Type (P202):**

For the blocks that generate speed reference, you can use the converter in 'Sensorless' (**P202=3**) mode. Please consider that in this operation mode there is no high precision at low speed. In addition, the position gain Kp (P760) should be reset to zero to prevent instability when the motor is disabled.

For the position blocks, the inverter must be operated in vector mode with encoder (**P202 = 4**).

#### **Important Notes:**

- Always when possible, use the vector mode with encoder;
- The scalar mode operation (V/Hz) should be avoided if the PLC will generate speed reference and the CFW-09 firmware version is earlier than V3.70.
- Check the correct setting of the P161 and P162 parameters that are the proportional speed gain and the integral speed gain, respectively. The correct setting of these parameters are very important for a good inverter performance.

#### **Local / Remote Selection (P220):**

When the PLC is used as movement generator, this option must be set to 'Always Local' (**P220=0**).

#### **Local Reference Selection (P221):**

When the PLC is used as movement generator, this option must be set to 'PLC' (**P221=11**), i. e., the speed reference will be given by the PLC board.

#### **Local Run/Stop Selection (P224)**

To enable the PLC to control the converter through the run/stop options and also enable the PLC to disable the drive, this option must be set to 'PLC' (**P224=4**).

#### **AO1 Output Function (P251):**

To enable the PLC to control the analog inverter output 1 (AO1), set **P251=12**. Note that P252 is the gain of the analog output 1.

#### **AO2 Output Function (P253):**

To enable the PLC to control the analog inverter output 2 (AO2), set **P253=12**. Note that P254 is the gain of the analog output 2.

☑ **Digital Inputs DI101 to DI106, P263 to P268:**

There is no need of special CFW-09 programming to access the drive's digital inputs through the PLC board. In the PLC board programming, the digital inputs of the drive (DI1 to DI6) are named DI101 to DI106, respectively.

☑ **Digital Relay Outputs DO101 to DO103, P277, P279 and P280:**

These Parameters correspond to the RL1 to RL3 drive outputs. To enable the PLC to control these outputs, you must set these parameters to the function 'PLC', i. e. **P277=27, P279=27** and **P280=27**.

**DETAILED PARAMETER DESCRIPTION**

This chapter describes in details all the PLC programming and read parameters. Besides these parameters, the CFW-09 parameters must also be configured in accordance with the application (refer to the CFW-09 User's Guide for its parameter description).

<b>Parameter</b>	<b>Range [Factory Setting]</b>	<b>Description / Note</b>
<b>P750</b> Firmware version PLC2 [Read parameter]	- [-] -	<input checked="" type="checkbox"/> It shows the firmware version of the PLC board. Example: version 1.00. At the parameter you can read 100.
<b>P751</b> Scan cycle of the user program [Read parameter]	0 to 65535 [-] x100 µs	<input checked="" type="checkbox"/> It shows the duration of the user program cycle. Each unit corresponds to 100µs. To obtain the value of the scan cycle, divide the value of P751 by 10. Exemple: when 79 is read, this means that the program scan cycle is $79 \div 10 = 7,9\text{ms}$ .
<b>P752 (*)</b> Resets the retentive markers [Configuration parameter]	0 or 1 [0] -	<input checked="" type="checkbox"/> It reset the retentive markers, both bit type and word type. Set the parameter to 1 (one) and restart the system. The value of this parameter returns to 0 (zero) automatically.
<b>P753 (*)</b> Loads factory settings, if =1234 [Configuration parameter]	0 to 65535 [0] -	<input checked="" type="checkbox"/> It loads the factory setting to the system parameters (750 to P799). Set this parameter to 1234 and reset the system.
<b>P754</b> Position reference (rotations) [Read parameter]	0 to 65535 [-] rotations	<input checked="" type="checkbox"/> It shows the position reference in rotations. The position reference starts at zero and after the movement has been concluded, it returns to zero.
<b>P755</b> Position reference (fraction of rotation) [Read parameter]	0 to 3599 [-] degrees/10	<input checked="" type="checkbox"/> It shows the fraction of the revolution of the reference position in tenth of degree. The position reference starts at zero and after the movement has been concluded, it returns to zero.
<b>P756</b> Real position signal [Read parameter]	0 or 1 [-] -	<input checked="" type="checkbox"/> Signal of the real position shown at Parameters P757 and P758. 0 = negative 1 = positive

(\*) IMPORTANT: To enable the system to operate according the parameter setting, the system must be reset after one or more parameters have been changed.



Parameter	Range [Factory Setting] Unit	Description / Note
<b>P757</b> Real position (rotations) [Read parameter]	0 to 65535 [-] rotations	<input checked="" type="checkbox"/> It shows the real position in rotations.
<b>P758</b> Real position (fraction of rotation) [Read parameter]	0 to 3599 [-] degrees/10	<input checked="" type="checkbox"/> It shows the fraction of revolution of the real position in tenth of degree.
<b>P759</b> Lag error [Read parameter]	0 to 3599 [-] degrees/10	<input checked="" type="checkbox"/> Shows lag error in degrees/10.
<b>P760</b> Proportional position gain (Kp) [Configuration parameter]	0 to 200 [ 50 ] -	<input checked="" type="checkbox"/> Increase this gain to speed up the answer to a position error and decrease this gain when system vibrates or becomes unstable.
<b>P761</b> Integral position gain (Ki) [Configuration parameter]	0 to 200 [ 0 ] -	<input checked="" type="checkbox"/> It has the function to reset eventual position errors. In general, this gain is zero and may cause a position overshoot, i.e. to go beyond the desired position and return.
<b>P762</b> Max. lag error [Configuration parameter]	0 to 65535 [ 1800 ] degrees/10	<input checked="" type="checkbox"/> This is the max. permitted positioning error, i. e., the max. permitted difference between reference position and the real position, in degrees. The parameter and the lag values are divided by 10. For instance 10 at P762 means that the max. following error is 1 degree. When P762=0 (default setting), the lag error will not be checked.
<b>P763</b> Disables user program if=1 [Configuration parameter]	0 or 1 [ 0 ] -	<input checked="" type="checkbox"/> When this Parameter is set to 1, it disables the user program. This setting should be used in any abnormal condition only, where the program is causing some error type, for instance, when it prevents the communication with the serial interface. In this case, disable the program and install the new corrected version and then enable it again.
<b>P764 (*)</b> PLC address at network [Configuration parameter]	1 to 247 [ 1 ] -	<input checked="" type="checkbox"/> When, for instance, the MODBUS network connection is used through serial interface RS-485 (inverter RS-232 / RS-485), this parameter defines the address at the network board.

(\*) IMPORTANT: To enable the system to operate according the parameter setting, the system must be reset after one or more parameters have been changed.

Parameter	Range [Factory Setting] Unit	Description / Note														
<b>P765 (*)</b> Baud rate of RS-232 [Configuration parameter]	1 to 6 [ 4 (= 9600bps) ] -	<input checked="" type="checkbox"/> Sets the baud rate of the serial interface. The permitted settings are: <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>P765</th> <th>Baud-Rate (bps)</th> </tr> </thead> <tbody> <tr><td>1</td><td>1200</td></tr> <tr><td>2</td><td>2400</td></tr> <tr><td>3</td><td>4800</td></tr> <tr><td>4</td><td>9600</td></tr> <tr><td>5</td><td>19200</td></tr> <tr><td>6</td><td>38400</td></tr> </tbody> </table>	P765	Baud-Rate (bps)	1	1200	2	2400	3	4800	4	9600	5	19200	6	38400
P765	Baud-Rate (bps)															
1	1200															
2	2400															
3	4800															
4	9600															
5	19200															
6	38400															
<b>P766 (*)</b> PID sample time [Configuration parameter]	1 to 10000 [ 1 ] x 1.2 ms	<input checked="" type="checkbox"/> Defines the sampling time for the PID blocks in intervals of 1,2ms. Example: P766=10 means that the PID “sampling time” will be 12ms.														
<b>P767 (*)</b> Synchronous motor speed [Configuration parameter]	0 to 10000 [ 1800 ] rpm	<input checked="" type="checkbox"/> Set this parameter to the driven motor synchronous speed. In order to calculate the motor synchronous speed use the following equation: $n_s = \frac{120 \times f}{2p}$ Where: ns= Synchronous speed f= Motor frequency p= Number of pole pairs of the motor <input checked="" type="checkbox"/> For instance, a 4 pole motor / 50Hz has a synchronous speed of 1500rpm.														
<b>P768 (*)</b> Encoder 1 pulse number (main) [Configuration parameter]	0 to 10000 [ 1024 ] ppr	<input checked="" type="checkbox"/> It shows the number of pulses per encoder revolution.														
<b>P769 (*)</b> Encoder 1 zero pulse position (main) [Configuration parameter]	0 to 3599 [ 0 ] degrees/10	<input checked="" type="checkbox"/> The input value should be in tenth of degree. This value can be used to search for the machine zero and so set the zero position.														

**Table 4.1 - Baud rate of RS-232**

(\*) IMPORTANT: To enable the system to operate according to the parameter setting, the system must be reset after one or more parameters have been changed.

Parameter	Range [Factory Setting] Unit	Description / Note												
<b>P770 (*)</b> CAN protocol [Configuration parameter]	0 to 2 [ 0 ] -	<p><input checked="" type="checkbox"/> The setting of this parameter allows selecting the communication protocol that will be used for the CAN interface available at the PLC2 board.</p> <table border="1"> <thead> <tr> <th>P770</th> <th>Description</th> <th>Note</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disable</td> <td>CANopen and DeviceNet protocols are disabled. Setting P770 to '0' enables the speed synchronism via CAN, which is programmed via WLP software (FOLLOW and MSCANWEG function blocks).</td> </tr> <tr> <td>1</td> <td>CANopen</td> <td>Setting P770 to '1' makes the PLC2 board operate as master or slave on the CANopen network. Additional information about how using the PLC2 board with this protocol can be found on the CANopen communication user's guide provided with the product CD.</td> </tr> <tr> <td>2</td> <td>DeviceNet</td> <td>Setting P770 to '2' makes the PLC2 board operate as a slave on the DeviceNet network. Additional information about how using the PLC2 board with this protocol can be found on the DeviceNet communication user's guide provided with the product CD.</td> </tr> </tbody> </table>	P770	Description	Note	0	Disable	CANopen and DeviceNet protocols are disabled. Setting P770 to '0' enables the speed synchronism via CAN, which is programmed via WLP software (FOLLOW and MSCANWEG function blocks).	1	CANopen	Setting P770 to '1' makes the PLC2 board operate as master or slave on the CANopen network. Additional information about how using the PLC2 board with this protocol can be found on the CANopen communication user's guide provided with the product CD.	2	DeviceNet	Setting P770 to '2' makes the PLC2 board operate as a slave on the DeviceNet network. Additional information about how using the PLC2 board with this protocol can be found on the DeviceNet communication user's guide provided with the product CD.
P770	Description	Note												
0	Disable	CANopen and DeviceNet protocols are disabled. Setting P770 to '0' enables the speed synchronism via CAN, which is programmed via WLP software (FOLLOW and MSCANWEG function blocks).												
1	CANopen	Setting P770 to '1' makes the PLC2 board operate as master or slave on the CANopen network. Additional information about how using the PLC2 board with this protocol can be found on the CANopen communication user's guide provided with the product CD.												
2	DeviceNet	Setting P770 to '2' makes the PLC2 board operate as a slave on the DeviceNet network. Additional information about how using the PLC2 board with this protocol can be found on the DeviceNet communication user's guide provided with the product CD.												

**Table 4.2 - CAN interface available at the PLC2 board**



**NOTE!**

Change of parameter P770 is executed when the device is reset or at next power up.

<b>P771 (*)</b> CAN address [Configuration parameter]	0 to 127 [63] -	<p><input checked="" type="checkbox"/> P771 sets the address of the PLC2 board in the CAN network. The range of valid addresses is dependent on the selected protocol: CANopen: valid addresses from 1 to 127. DeviceNet: valid addresses from 0 to 63.</p> <p><input checked="" type="checkbox"/> It is not necessary to define the device address when the synchronism function via CAN is used.</p>
---	-----------------------	--




**NOTE!**

Change of parameter P771 (CAN address) is executed when the device is reset or at next power up.

<b>P772 (*)</b> CAN baud rate [Configuration parameter]	0 to 8 [ 0 ] bits/second	<p><input checked="" type="checkbox"/> Adjust CAN baud rate. Accept Values:</p> <table border="1"> <thead> <tr> <th>P772</th> <th>Description</th> <th>Maximum Cable Length</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1 Mbit/s</td> <td>25 m</td> </tr> <tr> <td>1</td> <td>Reservado</td> <td>-</td> </tr> <tr> <td>2</td> <td>500 Kbit/s</td> <td>100 m</td> </tr> <tr> <td>3</td> <td>250 Kbit/s</td> <td>250 m</td> </tr> <tr> <td>4</td> <td>125 Kbit/s</td> <td>500 m</td> </tr> <tr> <td>5</td> <td>100 Kbit/s</td> <td>600 m</td> </tr> <tr> <td>6</td> <td>50 Kbit/s</td> <td>1000 m</td> </tr> <tr> <td>7</td> <td>20 Kbit/s</td> <td>1000 m</td> </tr> <tr> <td>8</td> <td>10 Kbit/s</td> <td>1000 m</td> </tr> </tbody> </table>	P772	Description	Maximum Cable Length	0	1 Mbit/s	25 m	1	Reservado	-	2	500 Kbit/s	100 m	3	250 Kbit/s	250 m	4	125 Kbit/s	500 m	5	100 Kbit/s	600 m	6	50 Kbit/s	1000 m	7	20 Kbit/s	1000 m	8	10 Kbit/s	1000 m
P772	Description	Maximum Cable Length																														
0	1 Mbit/s	25 m																														
1	Reservado	-																														
2	500 Kbit/s	100 m																														
3	250 Kbit/s	250 m																														
4	125 Kbit/s	500 m																														
5	100 Kbit/s	600 m																														
6	50 Kbit/s	1000 m																														
7	20 Kbit/s	1000 m																														
8	10 Kbit/s	1000 m																														

**Table 4.3 - CAN baud rate**

(\*) IMPORTANT: To enable the system to operate according the parameter setting, the system must be reset after one or more parameters have been changed.

Parameter	Range [Factory Setting] Unit	Description / Note										
		<p><input checked="" type="checkbox"/> The DeviceNet protocol only supports three baud rates: 500 kbps, 250 kbps and 125 kbps. If any other option is chosen the auto-baud is selected.</p> <p> <b>NOTE!</b> Change of baud rate is valid only after the device is reset or at next power up.</p>										
<p><b>P773</b> Bus off recovery [Configuration parameter]</p>	<p>0 or 1 [ 0 ] -</p>	<p><input checked="" type="checkbox"/> This parameter allows the PLC2 action selection when a <i>bus off</i> error occurs. The permitted values are:</p> <table border="1"> <thead> <tr> <th>P773</th> <th>Description</th> <th>Note</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Manual</td> <td>After the <i>bus off</i> error has been detected, the device displays E61, the CAN communication will be disabled and the device must be reset manually to return to network operation.</td> </tr> <tr> <td>1</td> <td>Automatic</td> <td>The communication will be restart automatically after <i>bus off</i> error has been detected.</td> </tr> </tbody> </table> <p><b>Table 4.4 - Permitted values when a bus off error occurs</b></p>	P773	Description	Note	0	Manual	After the <i>bus off</i> error has been detected, the device displays E61, the CAN communication will be disabled and the device must be reset manually to return to network operation.	1	Automatic	The communication will be restart automatically after <i>bus off</i> error has been detected.	
P773	Description	Note										
0	Manual	After the <i>bus off</i> error has been detected, the device displays E61, the CAN communication will be disabled and the device must be reset manually to return to network operation.										
1	Automatic	The communication will be restart automatically after <i>bus off</i> error has been detected.										
<p><b>P774</b> Action to be taken upon detection of a communication failure [Configuration parameter]</p>	<p>0 or 1 [ 1 ] -</p>	<p><input checked="" type="checkbox"/> Setting of this parameter selects the action to be taken by the PLC2 board upon detection of a communication failure on the CAN interface:</p> <table border="1"> <thead> <tr> <th>P774</th> <th>Description</th> <th>Note</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Indicate the error</td> <td>Setting P774 to '0' displays the error code on the HMI upon detection of communication failure.</td> </tr> <tr> <td>1</td> <td>Cause a fatal error on the device</td> <td>Setting P774 to '1', besides displaying the error code on the HMI, disables the device upon detection of communication failure. Device needs to be reset in order to operate again.</td> </tr> </tbody> </table> <p><b>Table 4.5 - Action a communication failure</b></p> <p><input checked="" type="checkbox"/> Communication errors may be different according to the protocol used. Please, refer to the communication guide specific for the protocol in use.</p>	P774	Description	Note	0	Indicate the error	Setting P774 to '0' displays the error code on the HMI upon detection of communication failure.	1	Cause a fatal error on the device	Setting P774 to '1', besides displaying the error code on the HMI, disables the device upon detection of communication failure. Device needs to be reset in order to operate again.	
P774	Description	Note										
0	Indicate the error	Setting P774 to '0' displays the error code on the HMI upon detection of communication failure.										
1	Cause a fatal error on the device	Setting P774 to '1', besides displaying the error code on the HMI, disables the device upon detection of communication failure. Device needs to be reset in order to operate again.										
<p><b>P775</b> CAN status [Read parameter]</p>	<p>0 to 6 [ - ] -</p>	<p><input checked="" type="checkbox"/> Inform CAN status:</p> <table border="1"> <thead> <tr> <th>P775</th> <th>CAN Status</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disabled</td> </tr> <tr> <td>1</td> <td>Reserved</td> </tr> <tr> <td>2</td> <td>CAN enabled</td> </tr> <tr> <td>3</td> <td>Warning (some telegrams with error)</td> </tr> </tbody> </table> <p><b>Table 4.6 - CAN status</b></p>	P775	CAN Status	0	Disabled	1	Reserved	2	CAN enabled	3	Warning (some telegrams with error)
P775	CAN Status											
0	Disabled											
1	Reserved											
2	CAN enabled											
3	Warning (some telegrams with error)											

Parameter	Range [Factory Setting] Unit	Description / Note																		
		<table border="1"> <thead> <tr> <th>P775</th> <th>CAN Status</th> </tr> </thead> <tbody> <tr> <td>4</td> <td>Error Passive (Much telegrams with error or is the only network device with enabled CAN transmitting telegrams).</td> </tr> <tr> <td>5</td> <td>Bus Off (number of detected errors exceeded the internal device limit and the communication has been disabled)</td> </tr> <tr> <td>6</td> <td>Bus not powered</td> </tr> </tbody> </table> <p style="text-align: center;"><b>Table 4.6 (cont.) - CAN status</b></p>	P775	CAN Status	4	Error Passive (Much telegrams with error or is the only network device with enabled CAN transmitting telegrams).	5	Bus Off (number of detected errors exceeded the internal device limit and the communication has been disabled)	6	Bus not powered										
P775	CAN Status																			
4	Error Passive (Much telegrams with error or is the only network device with enabled CAN transmitting telegrams).																			
5	Bus Off (number of detected errors exceeded the internal device limit and the communication has been disabled)																			
6	Bus not powered																			
<b>P776</b> Counter of received telegrams [Read parameter]	0 to 65535 [-] -	<input checked="" type="checkbox"/> Cyclic counter is incremented at each CAN telegram received with success. Counting is restart each time the counter reaches to upper limit.																		
<b>P777</b> Counter of transmitted telegrams [Read parameter]	0 to 65535 [-] -	<input checked="" type="checkbox"/> Cyclic counter is incremented at each CAN telegram received with success. Counting is restart each time the counter reaches to upper limit.																		
<b>P778</b> Counter of detected errors [Read parameter]	0 to 65535 [-] -	<input checked="" type="checkbox"/> Cyclic counter is incremented each time an error is detected ( <i>bus off</i> ). Counting is restart each time the counter reaches to upper limit.																		
<b>P779</b> Configuration status CANopen [Read parameter]	0 to 65535 [-] -	<input checked="" type="checkbox"/> Shows the CANopen configuration Status. 0 = slave 1 = master																		
<b>P780</b> Status CANopen communication status [Read parameter]	0 to 4 [-] -	<input checked="" type="checkbox"/> Indicates the status of the CANopen communication, informing if the protocol was correctly initialized and the state of the slave node guarding service. <table border="1"> <thead> <tr> <th>P780</th> <th>Description</th> <th>Note</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disabled</td> <td>The CANopen protocol was not set in parameter P700 and it is disabled.</td> </tr> <tr> <td>1</td> <td>Reserved</td> <td>-</td> </tr> <tr> <td>2</td> <td>CANopen enabled</td> <td>The CANopen protocol was correctly started.</td> </tr> <tr> <td>3</td> <td>Node Guarding enabled</td> <td>Node guarding service was started by the master and it is properly working.</td> </tr> <tr> <td>4</td> <td>Node Guarding error</td> <td>Timeout for the node guard service. This event results in a PLC board error (E65).</td> </tr> </tbody> </table> <p style="text-align: center;"><b>Table 4.7 - Status of the CAN communication</b></p> <input checked="" type="checkbox"/> Refer to CANopen communication user's guide to obtain detailed description about the protocol.	P780	Description	Note	0	Disabled	The CANopen protocol was not set in parameter P700 and it is disabled.	1	Reserved	-	2	CANopen enabled	The CANopen protocol was correctly started.	3	Node Guarding enabled	Node guarding service was started by the master and it is properly working.	4	Node Guarding error	Timeout for the node guard service. This event results in a PLC board error (E65).
P780	Description	Note																		
0	Disabled	The CANopen protocol was not set in parameter P700 and it is disabled.																		
1	Reserved	-																		
2	CANopen enabled	The CANopen protocol was correctly started.																		
3	Node Guarding enabled	Node guarding service was started by the master and it is properly working.																		
4	Node Guarding error	Timeout for the node guard service. This event results in a PLC board error (E65).																		



Parameter	Range [Factory Setting] Unit	Description / Note															
<b>P781</b> CANopen node status [Read parameter]	0 to 127 [-] -	<p><input checked="" type="checkbox"/> Each device in the CANopen network has an associated status. The current status of the PLC2 board is displayed in this parameter.</p> <table border="1"> <thead> <tr> <th>P781</th> <th>Description</th> <th>Note</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Not initialized</td> <td>The CANopen protocol was not set in parameter P700 and it is disabled.</td> </tr> <tr> <td>4</td> <td>Stopped</td> <td>Data transfer between master and slave is not possible in this state</td> </tr> <tr> <td>5</td> <td>Operational</td> <td>All communication services are available in this state.</td> </tr> <tr> <td>127</td> <td>Pre-operational</td> <td>Only some CANopen communication services are available in this state.</td> </tr> </tbody> </table> <p><i>Table 4.8 - Status of the CANopen node</i></p> <p><input checked="" type="checkbox"/> Refer to CANopen communication user's guide to obtain detailed description about the protocol.</p>	P781	Description	Note	0	Not initialized	The CANopen protocol was not set in parameter P700 and it is disabled.	4	Stopped	Data transfer between master and slave is not possible in this state	5	Operational	All communication services are available in this state.	127	Pre-operational	Only some CANopen communication services are available in this state.
P781	Description	Note															
0	Not initialized	The CANopen protocol was not set in parameter P700 and it is disabled.															
4	Stopped	Data transfer between master and slave is not possible in this state															
5	Operational	All communication services are available in this state.															
127	Pre-operational	Only some CANopen communication services are available in this state.															
<b>P782</b> DeviceNet network status [Read parameter]	0 to 5 [-] -	<table border="1"> <thead> <tr> <th>P782</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Not Powered / Not On-line</td> </tr> <tr> <td>1</td> <td>On-line / Not Connected</td> </tr> <tr> <td>2</td> <td>Link Ok / On-line and Connected</td> </tr> <tr> <td>3</td> <td>Connection Timeout</td> </tr> <tr> <td>4</td> <td>Critical Link Failure</td> </tr> <tr> <td>5</td> <td>Running Auto-baud</td> </tr> </tbody> </table> <p><i>Table 4.9 - DeviceNet network status</i></p> <p><input checked="" type="checkbox"/> A detailed description of these items can be found on the DeviceNet user's guide for this product.</p>	P782	Description	0	Not Powered / Not On-line	1	On-line / Not Connected	2	Link Ok / On-line and Connected	3	Connection Timeout	4	Critical Link Failure	5	Running Auto-baud	
P782	Description																
0	Not Powered / Not On-line																
1	On-line / Not Connected																
2	Link Ok / On-line and Connected																
3	Connection Timeout																
4	Critical Link Failure																
5	Running Auto-baud																
<b>P783</b> DeviceNet master status [Read parameter]	0 or 1 [-] -	<table border="1"> <thead> <tr> <th>P783</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Master in run mode</td> </tr> <tr> <td>1</td> <td>Master in Idle mode</td> </tr> </tbody> </table> <p><i>Table 4.10 - Status of the DeviceNet master</i></p> <p><input checked="" type="checkbox"/> For a detailed description of these items, please, refer to the DeviceNet programming user's guide specific for this product.</p>	P783	Description	0	Master in run mode	1	Master in Idle mode									
P783	Description																
0	Master in run mode																
1	Master in Idle mode																
<b>P784</b> Number of input words [Configuration parameter]	0 to 10 [ 1 ] -	<p><input checked="" type="checkbox"/> The setting of this parameter defines the number of reading words exchanged with the master of the DeviceNet network.</p>															
<b>P785</b> Number of output words [Configuration parameter]	0 to 10 [ 1 ] -	<p><input checked="" type="checkbox"/> The setting of this parameter defines the number of writing words exchanged with the master of the DeviceNet network.</p>															

Parameter	Range [Factory Setting] Unit	Description / Note															
<b>P786</b> Fieldbus board status [Read parameter]	0 to 3 [-] -	☑ Indicates the status of the optional communication board. See below the status values and their description:															
		<table border="1"> <thead> <tr> <th>P786</th> <th>Description</th> <th>Note</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disabled: Indicates that the board was not enabled</td> <td>The board is enabled through the WLP software, by using the tool for fieldbus board configuration.</td> </tr> <tr> <td>1</td> <td>Inactive board: Indicates that the board was programmed, however, the PLC2 board could not access the fieldbus board</td> <td>This situation mainly happens during board initialization, (it can also happen during its operation), due to installation and bad connection problems. When the board is inactive, the drive shows an E60 error on the keypad, and it is only possible to enable the board again by resetting the drive.</td> </tr> <tr> <td>2</td> <td>Active and off-line board: indicates a communication error between the board and the network master</td> <td>This error causes the interruption of master-slave communication and may happen due to several reasons (master configuration problems, incorrect installation of communication cables, noise during data transmission, etc.). When the fieldbus board is off-line, the drive shows an E59 error on the keypad.</td> </tr> <tr> <td>3</td> <td>Active and on-line board: indicates that the master-slave communication was successfully established</td> <td>-</td> </tr> </tbody> </table>	P786	Description	Note	0	Disabled: Indicates that the board was not enabled	The board is enabled through the WLP software, by using the tool for fieldbus board configuration.	1	Inactive board: Indicates that the board was programmed, however, the PLC2 board could not access the fieldbus board	This situation mainly happens during board initialization, (it can also happen during its operation), due to installation and bad connection problems. When the board is inactive, the drive shows an E60 error on the keypad, and it is only possible to enable the board again by resetting the drive.	2	Active and off-line board: indicates a communication error between the board and the network master	This error causes the interruption of master-slave communication and may happen due to several reasons (master configuration problems, incorrect installation of communication cables, noise during data transmission, etc.). When the fieldbus board is off-line, the drive shows an E59 error on the keypad.	3	Active and on-line board: indicates that the master-slave communication was successfully established	-
		P786	Description	Note													
		0	Disabled: Indicates that the board was not enabled	The board is enabled through the WLP software, by using the tool for fieldbus board configuration.													
		1	Inactive board: Indicates that the board was programmed, however, the PLC2 board could not access the fieldbus board	This situation mainly happens during board initialization, (it can also happen during its operation), due to installation and bad connection problems. When the board is inactive, the drive shows an E60 error on the keypad, and it is only possible to enable the board again by resetting the drive.													
2	Active and off-line board: indicates a communication error between the board and the network master	This error causes the interruption of master-slave communication and may happen due to several reasons (master configuration problems, incorrect installation of communication cables, noise during data transmission, etc.). When the fieldbus board is off-line, the drive shows an E59 error on the keypad.															
3	Active and on-line board: indicates that the master-slave communication was successfully established	-															

**Table 4.11 - Status of the fieldbus board**

P788	Description
0	-10 to +10V (range from -32768 to +32767)
1	0 to 20mA (range from 0 to 32767)
2	0 to 20mA (range from 0 to 65535)
3	0 to 20mA (range from -32768 to +32767)
4	4 to 20mA (range from 0 to 32767)
5	4 to 20mA (range from 0 to 65535)
6	4 to 20mA (range from -32768 to +32767)

**Table 4.12 - Operation mode for the analog output 1**

Parameter	Range [Factory Setting] Unit	Description / Note																
<b>P789</b> Operation mode for the analog output 2 [Configuration parameter]	0 to 6 [-] -	<table border="1"> <thead> <tr> <th>P789</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>-10 to +10V (range from -32768 to +32767)</td> </tr> <tr> <td>1</td> <td>0 to 20mA (range from 0 to 32767)</td> </tr> <tr> <td>2</td> <td>0 to 20mA (range from 0 to 65535)</td> </tr> <tr> <td>3</td> <td>0 to 20mA (range from -32768 to +32767)</td> </tr> <tr> <td>4</td> <td>4 to 20mA (range from 0 to 32767)</td> </tr> <tr> <td>5</td> <td>4 to 20mA (range from 0 to 65535)</td> </tr> <tr> <td>6</td> <td>4 to 20mA (range from -32768 to +32767)</td> </tr> </tbody> </table>	P789	Description	0	-10 to +10V (range from -32768 to +32767)	1	0 to 20mA (range from 0 to 32767)	2	0 to 20mA (range from 0 to 65535)	3	0 to 20mA (range from -32768 to +32767)	4	4 to 20mA (range from 0 to 32767)	5	4 to 20mA (range from 0 to 65535)	6	4 to 20mA (range from -32768 to +32767)
		P789	Description															
		0	-10 to +10V (range from -32768 to +32767)															
		1	0 to 20mA (range from 0 to 32767)															
		2	0 to 20mA (range from 0 to 65535)															
		3	0 to 20mA (range from -32768 to +32767)															
		4	4 to 20mA (range from 0 to 32767)															
		5	4 to 20mA (range from 0 to 65535)															
6	4 to 20mA (range from -32768 to +32767)																	
<i>Table 4.13 - Operation mode for the analog output 2</i>																		
<b>P790<sup>(*)</sup></b> Encoder 2 pulse number (auxiliary) [Configuration parameter]	0 to 10000 [ 1024 ] ppr	<input checked="" type="checkbox"/> This parameter represents the number of pulses per revolution of encoder 2 (auxiliary).																
<b>P791<sup>(*)</sup></b> Enables the position feedback via encoder 2 (auxiliary) [Configuration parameter]	0 or 1 [ 0 ] -	<input checked="" type="checkbox"/> Enables the position feedback via encoder 2 (auxiliary).  <table border="1"> <thead> <tr> <th>P791</th> <th>Description</th> <th>Specification</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disabled</td> <td>Encoder 1 (main encoder) is responsible for the position feedback.</td> </tr> <tr> <td>1</td> <td>Enabled</td> <td>Encoder 2 (auxiliary encoder) is responsible for the position feedback.</td> </tr> </tbody> </table>	P791	Description	Specification	0	Disabled	Encoder 1 (main encoder) is responsible for the position feedback.	1	Enabled	Encoder 2 (auxiliary encoder) is responsible for the position feedback.							
P791	Description	Specification																
0	Disabled	Encoder 1 (main encoder) is responsible for the position feedback.																
1	Enabled	Encoder 2 (auxiliary encoder) is responsible for the position feedback.																
<i>Table 4.14 – Encoder 2</i>																		
<b>P792<sup>(*)</sup></b> Direction of encoder 2 signal (auxiliary) [Configuration parameter]	0 or 1 [ 1 ] -	<input checked="" type="checkbox"/> Defines the direction of the encoder signal:  <div style="text-align: center;"> <p>0 = A → B</p> <p><b>Direction of encoder signals</b></p>  <p><b>Encoder rotating in forward direction</b></p> <p>1 = B → A</p> <p><b>Direction of encoder signals</b></p>  <p><b>Encoder running clockwise</b></p> </div>																




Figure 4.1 - Direction of the encoder

(\*) IMPORTANT: To enable the system to operate according the parameter setting, the system must be reset after one or more parameters have been changed.



Parameter	Range [Factory Setting] Unit	Description / Note														
<b>P793</b> (*) Select serial protocol [Configuration parameter]	0 to 5 [-] -	<input checked="" type="checkbox"/> This parameter configures the serial communication: protocol, parity, and number of stop-bits, respectively. <table border="1" data-bbox="730 427 1359 672"> <thead> <tr> <th>P793</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Modbus, no parity and 2 stop-bits.</td> </tr> <tr> <td>1</td> <td>WegTP, no parity and 2 stop-bits.</td> </tr> <tr> <td>2</td> <td>ModBus, even parity and 1 stop-bit.</td> </tr> <tr> <td>3</td> <td>WegTP, even parity and 1 stop-bit.</td> </tr> <tr> <td>4</td> <td>ModBus, odd parity and 1 stop-bit.</td> </tr> <tr> <td>5</td> <td>WegTP, odd parity and 1 stop-bit.</td> </tr> </tbody> </table>	P793	Description	0	Modbus, no parity and 2 stop-bits.	1	WegTP, no parity and 2 stop-bits.	2	ModBus, even parity and 1 stop-bit.	3	WegTP, even parity and 1 stop-bit.	4	ModBus, odd parity and 1 stop-bit.	5	WegTP, odd parity and 1 stop-bit.
P793	Description															
0	Modbus, no parity and 2 stop-bits.															
1	WegTP, no parity and 2 stop-bits.															
2	ModBus, even parity and 1 stop-bit.															
3	WegTP, even parity and 1 stop-bit.															
4	ModBus, odd parity and 1 stop-bit.															
5	WegTP, odd parity and 1 stop-bit.															

**Table 4.15** - Select serial protocol

<b>P794</b> Operation mode for the analog input 1 [Configuration parameter]	0 to 6 [-] -	<table border="1" data-bbox="711 902 1366 1220"> <thead> <tr> <th>P794</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>-10 to +10V / -20 to +20mA (range from -32768 to +32767)</td> </tr> <tr> <td>1</td> <td>0 to 20mA (range from 0 to 32767)</td> </tr> <tr> <td>2</td> <td>0 to 20mA (range from 0 to 65535)</td> </tr> <tr> <td>3</td> <td>0 to 20mA (range from -32768 to +32767)</td> </tr> <tr> <td>4</td> <td>4 to 20mA (range from 0 to 32767)</td> </tr> <tr> <td>5</td> <td>4 to 20mA (range from 0 to 65535)</td> </tr> <tr> <td>6</td> <td>4 to 20mA (range from -32768 to +32767)</td> </tr> </tbody> </table>	P794	Description	0	-10 to +10V / -20 to +20mA (range from -32768 to +32767)	1	0 to 20mA (range from 0 to 32767)	2	0 to 20mA (range from 0 to 65535)	3	0 to 20mA (range from -32768 to +32767)	4	4 to 20mA (range from 0 to 32767)	5	4 to 20mA (range from 0 to 65535)	6	4 to 20mA (range from -32768 to +32767)
P794	Description																	
0	-10 to +10V / -20 to +20mA (range from -32768 to +32767)																	
1	0 to 20mA (range from 0 to 32767)																	
2	0 to 20mA (range from 0 to 65535)																	
3	0 to 20mA (range from -32768 to +32767)																	
4	4 to 20mA (range from 0 to 32767)																	
5	4 to 20mA (range from 0 to 65535)																	
6	4 to 20mA (range from -32768 to +32767)																	

**Table 4.16** - Operation mode for the analog input

(\*) IMPORTANT: To enable the system to operate according the parameter setting, the system must be reset after one or more parameters have been changed.