


# CANopen

CFW700

**User's Manual**





# **CANopen User's Manual**

Series: CFW700

Language: English

Document Number: 10001007966 / 00

Publication Date: 11/2010

# SUMMARY

<b>SUMMARY .....</b>	<b>3</b>
<b>ABOUT THE MANUAL .....</b>	<b>6</b>
<b>ABBREVIATIONS AND DEFINITIONS.....</b>	<b>6</b>
<b>NUMERICAL REPRESENTATION .....</b>	<b>6</b>
<b>DOCUMENTS.....</b>	<b>6</b>
<b>1 INTRODUCTION TO THE CANOPEN COMMUNICATION.....</b>	<b>7</b>
<b>1.1 CAN.....</b>	<b>7</b>
1.1.1 Data Frame .....	7
1.1.2 Remote Frame.....	7
1.1.3 Access to the Network.....	7
1.1.4 Error Control.....	7
1.1.5 CAN and CANopen .....	8
<b>1.2 NETWORK CHARACTERISTICS .....</b>	<b>8</b>
<b>1.3 PHYSICAL LAYER .....</b>	<b>8</b>
<b>1.4 ADDRESS IN THE CANOPEN NETWORK .....</b>	<b>8</b>
<b>1.5 ACCESS TO THE DATA .....</b>	<b>8</b>
<b>1.6 DATA TRANSMISSION.....</b>	<b>8</b>
<b>1.7 COMMUNICATION OBJECTS - COB .....</b>	<b>9</b>
<b>1.8 COB-ID .....</b>	<b>9</b>
<b>1.9 EDS FILE .....</b>	<b>10</b>
<b>2 CANOPEN COMMUNICATION ACCESSORY .....</b>	<b>11</b>
2.1 CAN-01 KIT .....	11
2.2 CONNECTOR PINOUT .....	11
2.3 POWER SUPPLY .....	11
2.4 INDICATIONS.....	11
<b>3 CANOPEN NETWORK INSTALLATION .....</b>	<b>12</b>
3.1 BAUD RATE .....	12
3.2 ADDRESS IN THE CANOPEN NETWORK .....	12
3.3 TERMINATION RESISTOR.....	12
3.4 CABLE .....	12
3.5 CONNECTION IN THE NETWORK .....	13
<b>4 PROGRAMMING .....</b>	<b>14</b>
<b>4.1 SYMBOLS FOR THE PROPERTIES DESCRIPTION.....</b>	<b>14</b>
P0105 – 1 <sup>ST</sup> /2 <sup>ND</sup> RAMP SELECTION .....	14
P0220 – LOCAL/REMOTE SELECTION SOURCE.....	14
P0221 – SPEED REFERENCE SELECTION – LOCAL SITUATION .....	14
P0222 – SPEED REFERENCE SELECTION – REMOTE SITUATION .....	14
P0223 – FORWARD/REVERSE SELECTION – LOCAL SITUATION.....	14
P0224 – RUN/STOP SELECTION – LOCAL SITUATION.....	14
P0225 – JOG SELECTION – LOCAL SITUATION .....	14
P0226 – FORWARD/REVERSE SELECTION – REMOTE SITUATION .....	14
P0227 – RUN/STOP SELECTION – REMOTE SITUATION .....	14
P0228 – JOG SELECTION – REMOTE SITUATION.....	14
P0313 – COMMUNICATION ERROR ACTION.....	14
P0680 – STATUS WORD .....	15
P0681 – MOTOR SPEED IN 13 BITS .....	16
P0684 – CANOPEN CONTROL WORD .....	17

P0685 – CANOPEN SPEED REFERENCE.....	17
P0695 – DIGITAL OUTPUT SETTING.....	18
P0696 – VALUE 1 FOR ANALOG OUTPUTS.....	19
P0697 – VALUE 2 FOR ANALOG OUTPUTS.....	19
P0700 – CAN PROTOCOL.....	19
P0701 – CAN ADDRESS.....	20
P0702 – CAN BAUD RATE.....	20
P0703 – BUS OFF RESET.....	20
P0705 – CAN CONTROLLER STATUS.....	21
P0706 – RECEIVED CAN TELEGRAM COUNTER.....	21
P0707 – TRANSMITTED CAN TELEGRAM COUNTER.....	22
P0708 – BUS OFF ERROR COUNTER.....	22
P0709 – LOST CAN MESSAGE COUNTER.....	22
P0721 – CANOPEN COMMUNICATION STATUS.....	22
P0722 – CANOPEN NODE STATUS.....	23
<b>5 OBJECT DICTIONARY.....</b>	<b>24</b>
5.1 DICTIONARY STRUCTURE.....	24
5.2 DATA TYPE.....	24
5.3 COMMUNICATION PROFILE – COMMUNICATION OBJECTS.....	24
5.4 MANUFACTURER SPECIFIC – CFW700 SPECIFIC OBJECTS.....	25
5.5 DEVICE PROFILE – COMMON OBJECTS FOR DRIVES.....	26
<b>6 COMMUNICATION OBJECTS DESCRIPTION.....</b>	<b>27</b>
6.1 IDENTIFICATION OBJECTS.....	27
6.1.1 Object 1000h – Device Type.....	27
6.1.2 Object 1001h – Error Register.....	27
6.1.3 Object 1018h – Identity Object.....	27
6.2 SERVICE DATA OBJECTS – SDOS.....	28
6.2.1 Object 1200h – SDO Server.....	29
6.2.2 SDOs Operation.....	29
6.3 PROCESS DATA OBJECTS – PDOS.....	30
6.3.1 Mappable Objects for the PDOs.....	31
6.3.2 Receive PDOs.....	31
6.3.3 Transmit PDOs.....	33
6.4 SYNCHRONIZATION OBJECT – SYNC.....	36
6.5 NETWORK MANAGEMENT – NMT.....	36
6.5.1 Slave State Control.....	36
6.5.2 Error Control – Node Guarding.....	38
6.5.3 Error Control – Heartbeat.....	39
6.6 INICIALIZATION PROCEDURE.....	41
<b>7 DESCRIPTION OF THE OBJECTS FOR DRIVES.....</b>	<b>42</b>
7.1 DEVICE CONTROL – OBJECTS FOR CONTROLLING THE DRIVE.....	43
7.1.1 Objeto 6040h – Controlword.....	44
7.1.2 Objeto 6041h – Statusword.....	45
7.1.3 Objeto 6060h – Modes of Operation.....	46
7.1.4 Objeto 6061h – Modes of Operation Display.....	46
7.2 VELOCITY MODE – OBJECTS FOR CONTROLLING THE DRIVE.....	46
7.2.1 Control and State Bits.....	46
7.2.2 Objeto 6042h – vl Target Velocity.....	47
7.2.3 Objeto 6043h – vl Velocity Demand.....	47
7.2.4 Objeto 6044h – vl Control Effort.....	47
7.2.5 Objeto 6046h – vl Velocity Min Max Amount.....	48
7.2.6 Objeto 6048h – vl Velocity Acceleration.....	48
7.2.7 Objeto 6049h – vl Velocity Deceleration.....	49
7.3 POSITION CONTROL FUNCTION – OBJECTS FOR POSITION CONTROL.....	49

---

7.3.1	Objeto 6063h – Position actual value.....	49
<b>8</b>	<b>FAULTS AND ALARMS RELATED TO THE CANOPEN COMMUNICATION .....</b>	<b>50</b>
	A133/F233 – CAN INTERFACE WITHOUT POWER SUPPLY .....	50
	A134/F234 – BUS OFF.....	50
	A135/F235 –NODE GUARDING/HEARTBEAT .....	50

## ABOUT THE MANUAL

This manual provides the necessary information for the operation of the CFW700 frequency inverter using the CANopen protocol. This manual must be used together with the CFW700 user manual.

### ABBREVIATIONS AND DEFINITIONS

<b>CAN</b>	Controller Area Network
<b>CiA</b>	CAN in Automation
<b>COB</b>	Communication Object
<b>COB-ID</b>	Communication Object Identifier
<b>SDO</b>	Service Data Object
<b>PDO</b>	Process Data Object
<b>RPDO</b>	Receive PDO
<b>TPDO</b>	Transmit PDO
<b>NMT</b>	Network Management Object
<b>ro</b>	Read only
<b>rw</b>	Read/write

### NUMERICAL REPRESENTATION

Decimal numbers are represented by means of digits without suffix. Hexadecimal numbers are represented with the letter 'h' after the number.

### DOCUMENTS

The CANopen protocol for the CFW700 was developed based on the following specifications and documents:

Document	Version	Source
CAN Specification	2.0	CiA
CiA DS 301 CANopen Application Layer and Communication Profile	4.02	CiA
CiA DRP 303-1 Cabling and Connector Pin Assignment	1.1.1	CiA
CiA DSP 306 Electronic Data Sheet Specification for CANopen	1.1	CiA
CiA DSP 402 Device Profile Drives and Motion Control	2.0	CiA

In order to obtain this documentation, the organization that maintains, publishes and updates the information regarding the CANopen network, CiA, must be consulted.

## 1 INTRODUCTION TO THE CANOPEN COMMUNICATION

In order to operate the equipment in a CANopen network, it is necessary to know the manner this communication is performed. Therefore, this section brings a general description of the CANopen protocol operation, containing the functions used by the CFW700. Refer to the protocol specification for a detailed description.

### 1.1 CAN

CANopen is a network based on CAN, i.e., it uses CAN telegrams for exchanging data in the network.

The CAN protocol is a serial communication protocol that describes the services of layer 2 of the ISO/OSI model (data link layer)<sup>1</sup>. This layer defines the different types of telegrams (frames), the error detection method, the validation and arbitration of messages.

#### 1.1.1 Data Frame

CAN network data is transmitted by means of a data frame. This frame type is composed mainly by an 11 bit<sup>2</sup> identifier (arbitration field), and by a data field that may contain up to 8 data bytes.

Identifier	8 data bytes							
11 bits	byte 0	byte 1	byte 2	byte 3	byte 4	byte 5	byte 6	byte 7

#### 1.1.2 Remote Frame

Besides the data frame, there is also the remote frame (RTR frame). This type of frame does not have a data field, but only the identifier. It works as a request, so that another network device transmits the desired data frame.

#### 1.1.3 Access to the Network

Any device in a CAN network can make an attempt to transmit a frame to the network in a certain moment. If two devices try to access the network simultaneously, the one that sends the message with the highest priority will be able to transmit. The message priority is defined by the CAN frame identifier, the smaller the value of this identifier, the higher the message priority. The telegram with the identifier 0 (zero) is the one with the highest priority.

#### 1.1.4 Error Control

The CAN specification defines several error control mechanisms, which makes the network very reliable and with a very low undetected transmission error rate. Every network device must be able to identify the occurrence of these errors, and to inform the other elements that an error was detected.

A CAN network device has internal counters that are incremented every time a transmission or reception error is detected, and are decremented when a telegram is successfully transmitted or received. If a considerable amount of errors occurs, the device can be led to the following states:

- **Error Active:** the internal error counters are at a low level and the device operates normally in the CAN network. You can send and receive telegrams and act in the CAN network if it detects any error in the transmission of telegrams.
- **Warning:** when the counter exceeds a defined limit, the device enters the *warning* state, meaning the occurrence of a high error rate.
- **Error Passive:** when this value exceeds a higher limit, the device enters the *error passive* state, and it stops acting in the network when detecting that another device sent a telegram with an error.
- **Bus Off:** finally, we have the *bus off* state, in which the device will not send or receive telegrams any more. The device operates as if disconnected from the network.

<sup>1</sup> In the CAN protocol specification, the ISO11898 standard is referenced as the definition of the layer 1 of this model (physical layer).

<sup>2</sup> The CAN 2.0 specification defines two data frame types, standard (11 bit) and extended (29 bit). For this implementation, only the standard frames are accepted.

## 1.1.5 CAN and CANopen

Only the definition of how to detect errors, create and transmit a frame, are not enough to define a meaning for the data transmitted via the network. It is necessary to have a specification that indicates how the identifier and the data must be assembled and how the information must be exchanged. Thus, the network elements can interpret the transmitted data correctly. In that sense, the CANopen specification defines exactly how to exchange data among the devices and how every one must interpret these data.

There are several other protocols based on CAN, as DeviceNet, CANopen, J1939, etc., which use CAN frames for the communication. However, those protocols cannot be used together in the same network.

## 1.2 NETWORK CHARACTERISTICS

Because of using a CAN bus as telegram transmission means, all the CANopen network devices have the same right to access the network, where the identifier priority is responsible for solving conflict problems when simultaneous access occurs. This brings the benefit of making direct communication between slaves of the network possible, besides the fact that data can be made available in a more optimized manner without the need of a master that controls all the communication performing cyclic access to all the network devices for data updating.

Another important characteristic is the use of the producer/consumer model for data transmission. This means that a message that transits in the network does not have a fixed network address as a destination. This message has an identifier that indicates what data it is transporting. Any element of the network that needs to use that information for its operation logic will be able to consume it, therefore, one message can be used by several network elements at the same time.

## 1.3 PHYSICAL LAYER

O meio físico para a transmissão de sinais em uma rede CANopen é especificado pela norma ISO 11898. Ela define como barramento de transmissão um par trançado com sinal elétrico diferencial.

## 1.4 ADDRESS IN THE CANOPEN NETWORK

Every CANopen network must have a master responsible for network management services, and it can also have a set of up to 127 slaves. Each network device can also be called node. Each slave is identified in a CANopen network by its address or Node-ID, which must be unique for each slave and may range from 1 to 127.

The CFW700 does not have functions for implementing the network management services; therefore, it must be used together with some equipment that has such services, generally a CANopen network master.

The address of frequency inverter CFW700 is programmed by the parameter P0701.

## 1.5 ACCESS TO THE DATA

Each slave of the CANopen network has a list called object dictionary that contains all the data accessible via network. Each object of this list is identified with an index, which is used during the equipment configuration as well as during message exchanges. This index is used to identify the object being transmitted.

A more detailed description on how the dictionary is structured is presented on section 7.

## 1.6 DATA TRANSMISSION

The transmission of numerical data via CANopen telegrams is done using a hexadecimal representation of the number, and sending the least significant data byte first.

E.g: The transmission of a 32 bit integer with sign (12345678h = 305419896 decimal), plus a 16 bit integer with sign (FF00h = -256 decimal), in a CAN frame.



Identifier	6 data bytes					
11 bits	Inteiro 32 bits				Inteiro 16 bits	
	byte 0	byte 1	byte 2	byte 3	byte 4	byte 5
	78h	56h	34h	12h	00h	FFh

## 1.7 COMMUNICATION OBJECTS - COB

There is a specific set of objects that are responsible for the communication among the network devices. Those objects are divided according to the type of data and the way they are sent or received by a device. The CFW700 supports the following communication objects (COB):

*Table 1.1: Types of Communication Objects (COB)*

Type of object	Description
Service Data Object (SDO)	SDO are objects responsible for the direct access to the object dictionary of a device. By means of messages using SDO, it is possible to indicate explicitly (by the object index) what data is being handled. There are two SDO types: Client SDO, responsible for doing a read or write request to a network device, and the Server SDO, responsible for taking care of that request. Since SDO are usually used for the configuration of a network node, they have less priority than other types of message. Only a Server SDO is available for the CFW700.
Process Data Object (PDO)	PDO are used for accessing equipment data without the need of indicating explicitly which dictionary object is being accessed. Therefore, it is necessary to configure previously which data the PDO will be transmitting (data mapping). There are also two types of PDO: Receive PDO and Transmit PDO. They are usually utilized for transmission and reception of data used in the device operation, and for that reason they have higher priority than the SDO.
Emergency Object (EMCY)	This object is responsible for sending messages to indicate the occurrence of errors in the device. When an error occurs in a specific device (EMCY producer), it can send a message to the network. In the case that any network device be monitoring that message (EMCY consumer), it can be programmed so that an action be taken (disabling the other devices, error reset, etc.). The CFW700 has only the EMCY producer functionality.
Synchronization Object (SYNC)	In the CANopen network, it is possible to program a device (SYNC producer) to send periodically a synchronization message for all the network devices. Those devices (SYNC consumers) will then be able, for instance, to send a certain datum that needs to be made available periodically. The CFW700 has the SYNC consumer function.
Network Management (NMT)	Every CANopen network needs a master that controls the other devices (slaves) in the network. This master will be responsible for a set of services that control the slave communications and their state in the CANopen network. The slaves are responsible for receiving the commands sent by the master and for executing the requested actions. The CFW700 operates as a CANopen network slave and makes available two types of service that the master can use: device control service, with which the master controls the state of each network slave, and error control service (Node Guarding), with which the slave sends periodic messages to the master informing that the connection is active.

All the communication of the inverter with the network is performed using those objects, and the data that can be accessed are the existent in the device object dictionary.

## 1.8 COB-ID

A telegram of the CANopen network is always transmitted by a communication object (COB). Every COB has an identifier that indicates the type of data that is being transported. This identifier, called COB-ID has an 11 bit size, and it is transmitted in the identifier field of a CAN telegram. It can be subdivided in two parts:

Function Code				Address						
bit 10	bit 9	bit 8	bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0

- Function Code: indicates the type of object that is being transmitted.
- Node Address: indicates with which network device the telegram is linked.

A table with the standard values for the different communication objects available in the CFW700 is presented next. Notice that the standard value of the object depends on the slave address, with the exception of the COB-ID for NMT and SYNC, which are common for all the network elements. Those values can also be changed during the device configuration stage.

*Table 1.2: COB-ID for the different objects*

COB	Function code (bits 10 – 7)	Resultant COB-ID (function + address)
NMT	0000	0
SYNC	0001	128 (80h)
EMCY	0001	129 – 255 (81h – FFh)
PDO1 (tx)	0011	385 – 511 (181h – 1FFh)
PDO1 (rx)	0100	513 – 639 (201h – 27Fh)
PDO2 (tx)	0101	641 – 767 (281h – 2FFh)
PDO2 (rx)	0110	769 – 895 (301h – 37Fh)
PDO3 (tx)	0111	897 – 1023 (381h – 3FFh)
PDO3 (rx)	1000	1025 – 1151 (401h – 47Fh)
PDO4 (tx)	1001	1153 – 1279 (481h – 4FFh)
PDO4 (rx)	1010	1281 – 1407 (501h – 57Fh)
SDO (tx)	1011	1409 – 1535 (581h – 5FFh)
SDO (rx)	1100	1537 – 1663 (601h – 67Fh)
Node Guarding/Heartbeat	1110	1793 – 1919 (701h – 77Fh)

## 1.9 EDS FILE


Each device in a CANopen network has an EDS configuration file that contains information about the operation of the device in the CANopen network, as well as the description of all the communication objects available. In general, this file is used by a master or by the configuration software for programming of devices present in the CANopen Network.

The EDS configuration file for the CFW700 is supplied together with the product, and it can also be obtained from the website <http://www.weg.net>. It is necessary to observe the inverter software version, in order to use an EDS file that be compatible with that version.

## 2 CANOPEN COMMUNICATION ACCESSORY

In order to make the CANopen communication possible with the product, it is necessary to use the CAN communication kit described next. Information on the installation of this module can be obtained in the guide that comes with the kit.


### 2.1 CAN-01 KIT



- WEG part number: 10051961.
- Composed by the CAN communication module (drawing at the left), mounting instruction and fixing screw.
- The interface is electrically isolated and with differential signal, which grants more robustness against electromagnetic interference.
- External 24V supply.
- It allows the connection of up to 64 devices to the same segment. More devices can be connected by using repeaters<sup>3</sup>.
- A maximum bus length of 1000 meters.

### 2.2 CONNECTOR PINOUT

The CAN communication module presents a 5-wire plug-in connector (XC5) with the following pinout:



*Table 2.1: CAN interface XC5 connector pinout*

Pin	Name	Function
1	V-	Power supply negative pole
2	CAN_L	CAN_L communication signal
3	Shield	Cable shield
4	CAN_H	CAN_H communication signal
5	V+	Power supply positive pole

### 2.3 POWER SUPPLY

The CAN interface needs an external power supply between the pins 1 and 5 of the network connector. The individual consumption and input voltage data are presented in the next table.

*Table 2.2: CAN interface supply characteristics*

Supply Voltage (V <sub>DC</sub> )		
Minimum	Maximum	Recommended
11	30	24
Current (mA)		
Typical		Maximum
30		50

### 2.4 INDICATIONS

The CAN interface module have a green LED to indicate that the interface is powered. Further details on the alarms, communications failures and communication states are made through the keypad (HMI) and product parameters.

<sup>3</sup> The maximum number of devices that can be connected to the network depends also on the used protocol.

### 3 CANOPEN NETWORK INSTALLATION

The CANopen network, such as several industrial communication networks, for being many times applied in aggressive environments with high exposure to electromagnetic interference, requires that certain precautions be taken in order to guarantee a low communication error rate during its operation. Recommendations to perform the connection of the product in this network are presented next.

#### 3.1 BAUD RATE

Equipments with CANopen interface generally allow the configuration of the desired baud rate, ranging from 10Kbit /s to 1Mbit /s. The *baud rate* that can be used by equipment in the CANopen network depends on the depends on the length of the cable used in the installation. The next table shows the baud rates available and the maximum cable length that can be used in the installation, according to the CiA recommendation.

*Table 3.1: Supported baud rates and installation size*

Baud Rate	Cable Length
1 Mbit/s	25 m
800 Kbit/s	50 m
500 Kbit/s	100 m
250 Kbit/s	250 m
125 Kbit/s	500 m
100 Kbit/s	600 m
50 Kbit/s	1000 m
20 Kbit/s	1000 m
10 Kbit/s	1000 m

All network equipment must be programmed to use the same communication baud rate. At the CFW700 frequency inverter the baud rate configuration is done through the parameter P0702.


#### 3.2 ADDRESS IN THE CANOPEN NETWORK

Each CANopen network device must have an address or Node ID, and may range from 1 to 127. This address must be unique for each equipment.

At the CFW700 frequency inverter the address configuration is done through the parameter P0701.

#### 3.3 TERMINATION RESISTOR

The CAN bus line must be terminated with resistors to avoid line reflection, which can impair the signal and cause communication errors. The extremes of the CAN bus must have a termination resistor with a 120Ω / 0.25W value, connecting the CAN\_H and CAN\_L signals.



*Figure 3.1: Termination resistor installation example*

#### 3.4 CABLE

The connection of CAN\_L and CAN\_H signals must done with shielded twisted pair cable. The following table shows the recommended characteristics for the cable.


*Table 3.2: CANopen cable characteristics*

Cable length (m)	Resistance per meter (mOhm/m)	Conductor cross section (mm <sup>2</sup> )
0 ... 40	70	0.25 ... 0.34
40 ... 300	<60	0.34 ... 0.60
300 ... 600	<40	0.50 ... 0.60
600 ... 1000	<26	0.75 ... 0.80

The use of a twisted pair cable to provide the additional 24Vdc power supply to the equipment that needs this signal is also recommended.

### 3.5 CONNECTION IN THE NETWORK

In order to interconnect the several network nodes, it is recommended to connect the equipment directly to the main line without using derivations. During the cable installation the passage near to power cables must be avoided, because, due to electromagnetic interference, this makes the occurrence of transmission errors possible. In order to avoid problems with current circulation caused by difference of potential among ground connections, it is necessary that all the devices be connected to the same ground point.



*Figure 3.2: CANopen network installation example*

To avoid voltage difference problems between the power supplies of the network devices, it is recommended that the network is fed by only one power supply and the signal is provided to all devices through the cable. If it is required more than one power supply, these should be referenced to the same point.

The maximum number of devices connected to a single segment of the network is limited to 127. Repeaters can be used for connecting a bigger number of devices.

## 4 PROGRAMMING

Next, only the CFW700 frequency inverter parameters related to the CANopen communication will be presented.

### 4.1 SYMBOLS FOR THE PROPERTIES DESCRIPTION

RO	Read-only parameter
CFG	Parameter that can be changed only with a stopped motor
CAN	Parameter visible on the HMI if the product has the CAN interface installed

#### P0105 – 1<sup>ST</sup>/2<sup>ND</sup> RAMP SELECTION

#### P0220 – LOCAL/REMOTE SELECTION SOURCE

#### P0221 – SPEED REFERENCE SELECTION – LOCAL SITUATION

#### P0222 – SPEED REFERENCE SELECTION – REMOTE SITUATION

#### P0223 – FORWARD/REVERSE SELECTION – LOCAL SITUATION

#### P0224 – RUN/STOP SELECTION – LOCAL SITUATION

#### P0225 – JOG SELECTION – LOCAL SITUATION

#### P0226 – FORWARD/REVERSE SELECTION – REMOTE SITUATION

#### P0227 – RUN/STOP SELECTION – REMOTE SITUATION

#### P0228 – JOG SELECTION – REMOTE SITUATION

These parameters are used in the configuration of the command source for the CFW700 frequency inverter local and remote situations. In order that the inverter be controlled through the serial interface, the options 'CANopen/DeviceNet/Profibus DP' available in these parameters, must be selected.

The detailed description of these parameters is found in the CFW700 Programming Manual.

#### P0313 – COMMUNICATION ERROR ACTION

<b>Range:</b>	0 = Inactive 1 = Disable via Run/Stop 2 = Disable via General Enable 3 = Change to Local 4 = Change to Local keeping commands and reference 5 = Causes a Fault	<b>Default:</b> 0
<b>Properties:</b>	CFG	
<b>Access groups via HMI:</b>	NET	

#### Description:

It allows the selection of the action to be executed by the inverter, if it is controlled via network and a communication error is detected.

**Table 4.1: P0313 options**

Options	Description
0 = Inactive	No action is taken and the inverter remains in the existing status.
1 = Disable via Run/Stop	A stop command with deceleration ramp is executed and the motor stops according to the programmed deceleration ramp.
2 = Disable via General Enable	The inverter is disabled by removing the General Enabling and the motor coasts to stop.
3 = Change to Local	The inverter commands change to Local.
4 = Change to Local keeping commands and reference	The inverter commands change to Local, but the status of the enabling and speed reference commands received via network are kept, providing that the inverter has been programmed to use in Local mode the commands via HMI and speed reference via either HMI.
5 = Causes a Fault	Instead of an alarm, the communication error causes an inverter fault, so that an inverter fault reset becomes necessary in order to restore normal operation.

The following events are considered communication errors:

CANopen/DeviceNet communication:

- A133 alarm/F233 fault: CAN interface not powered.
- A134 alarm/F234 fault: *bus off*.
- A135 alarm/F235 fault: CANopen communication error (*Node Guarding/Heartbeat*).
- A136 alarm/F236 fault: DeviceNet master in *Idle* mode.
- A137 alarm/F237 fault: Detected timeout in one or more DeviceNet I/O connections.

The actions described in this parameter are executed by means of the automatic writing of the selected actions in the respective bits of the interface control words. Therefore, in order that the commands written in this parameter be effective, it is necessary that the inverter be programmed to be controlled via the used network interface. This programming is achieved by means of parameters P0220 to P0228.

### P0680 – STATUS WORD

<b>Range:</b>	0000h to FFFFh	<b>Default:</b>	-
<b>Properties:</b>	RO		
<b>Access groups via HMI:</b>	NET		

**Description:**

It allows the inverter status monitoring. Each bit represents a specific status:

Bits	15	14	13	12	11	10	9	8	7	6	5	4	3 to 0
Function	Fault condition	Reserved	Undervoltage	LOC/REM	JOG	Speed direction	Active General Enable	Motor Running	Alarm condition	In configuration mode	Second ramp	Active fast stop	Reserved

**Table 4.2: P0680 parameter bit functions**

Bits	Values
Bits 0 to 3	Reserved
Bit 4 Active fast stop	0: The inverter fast stop command is not active. 1: The inverter is executing the fast stop command.
Bit 5 Second ramp	0: The inverter is configured to use the first ramp values, programmed in P0100 and P0101, as the motor acceleration and deceleration ramp times. 1: The inverter is configured to use the second ramp values, programmed in P0102 and P0103, as the motor acceleration and deceleration ramp times.
Bit 6 In configuration mode	0: The inverter is operating normally. 1: The inverter is in the configuration mode. It indicates a special condition during which the inverter cannot be enabled: Executing the self-tuning routine Executing the oriented start-up routine Executing the HMI copy function Executing the flash memory card self-guided routine There is a parameter setting incompatibility There is no power at the inverter power section Note: It is possible to obtain the exact description of the special operation mode at the parameter P0692.
Bit 7 Alarm condition	0: The inverter is not in alarm condition. 1: The inverter is in alarm condition. Note: The alarm number can be read by means of the parameter P0048 – Present Alarm.
Bit 8 Motor Running	0: The motor is stopped. 1: The inverter is driving the motor at the set point speed, or executing either the acceleration or the deceleration ramp.
Bit 9 Active General Enable	0: General Enable is not active. 1: General Enable is active and the inverter is ready to run the motor.
Bit 10 Speed direction	0: The motor is running in the reverse direction. 1: The motor is running in the forward direction.
Bit 11 JOG	0: Inactive JOG function. 1: Active JOG function.
Bit 12 LOC/REM	0: Inverter in Local mode. 1: Inverter in Remote mode.
Bit 13 Undervoltage	0: No Undervoltage. 1: With Undervoltage.
Bit 14 Reserved	Reserved
Bit 15 Fault condition	0: The inverter is not in a fault condition. 1: The inverter has detected a fault. Note: The fault number can be read by means of the parameter P0049 – Present Fault.

**P0681 – MOTOR SPEED IN 13 BITS**

<b>Range:</b>	- 32768 to 32767	<b>Default:</b>	-
<b>Properties:</b>	RO		
<b>Access groups via HMI:</b>	NET		

**Description:**

It allows monitoring the motor speed. This word uses 13-bit resolution with signal to represent the motor synchronous speed:

- P0681 = 0000h (0 decimal) → motor speed = 0
- P0681 = 2000h (8192 decimal) → motor speed = synchronous speed

Intermediate or higher speed values in rpm can be obtained by using this scale. E.g. for a 4 pole 1800 rpm synchronous speed motor, if the value read is 2048 (0800h), then, to obtain the speed in rpm one must calculate:

8192 => 1800 rpm 2048 => Speed in rpm
--

Speed in rpm = $\frac{1800 \times 2048}{8192}$
--

Speed in rpm = 450 rpm
------------------------

Negative values in this parameter indicate that the motor is running in the reverse direction.



**P0684 – CANOPEN CONTROL WORD**

<b>Range:</b>	0000h a FFFFh	<b>Default:</b> 0000h
<b>Properties:</b>	-	
<b>Access groups via HMI:</b>	NET	

**Description:**

It is the inverter CANopen interface control word. This parameter can only be changed via CANopen/DeviceNet/Profibus DP interface. For the other sources (HMI, etc.) it behaves like a read-only parameter.

In order to have those commands executed, it is necessary that the inverter be programmed to be controlled via CANopen/DeviceNet/Profibus DP. This programming is achieved by means of parameters P0105 and P0220 to P0228.

Each bit of this word represents an inverter command that can be executed.

Bits	15 to 8	7	6	5	4	3	2	1	0
Function	Reserved	Fault reset	Fast stop	Second ramp	LOC/REM	JOG	Speed direction	General enable	Run/Stop

*Table 4.3: P0684 parameter bit functions*

Bits	Values
Bit 0 Run/Stop	0: It stops the motor with deceleration ramp. 1: The motor runs according to the acceleration ramp until reaching the speed reference value.
Bit 1 General enable	0: It disables the inverter, interrupting the supply for the motor. 1: It enables the inverter allowing the motor operation.
Bit 2 Speed direction	0: To run the motor in a direction opposed to the speed reference. 1: To run the motor in the direction indicated by the speed reference.
Bit 3 JOG	0: It disables the JOG function. 1: It enables the JOG function.
Bit 4 LOC/REM	0: The inverter goes to the Local mode. 1: The inverter goes to the Remote mode.
Bit 5 Second ramp	0: The inverter uses the first ramp values, programmed in P0100 and P0101, as the motor acceleration and deceleration ramp times. 1: The inverter is configured to use the second ramp values, programmed in P0102 and P0103, as the motor acceleration and deceleration ramp times.
Bit 6 Fast stop	0: It does not execute the fast stop command. 1: It executes the fast stop command. Note: This function is not allowed with control types (P0202) V/f or VVV.
Bit 7 Fault reset	0: No function. 1: If in a fault condition, then it executes the inverter reset.
Bits 8 to 15	Reserved.

**P0685 –CANOPEN SPEED REFERENCE**

<b>Range:</b>	-32768 a 32767	<b>Default:</b> 0
<b>Properties:</b>	-	
<b>Access groups via HMI:</b>	NET	

**Description:**

It allows programming the inverter speed reference via the CANopen interface. This parameter can only be changed via CANopen/DeviceNet/Profibus DP interface. For the other sources (HMI, etc.) it behaves like a read-only parameter.

In order that the reference written in this parameter be used, it is necessary that the inverter be programmed to use the speed reference via CANopen/DeviceNet/Profibus DP. This programming is achieved by means of parameters P0221 and P0222.

This word uses a 13-bit resolution with signal to represent the motor synchronous speed.

- P0685 = 0000h (0 decimal) → speed reference = 0
- P0685 = 2000h (8192 decimal) → speed reference = synchronous speed

Intermediate or higher reference values can be programmed by using this scale. E.g. for a 4 pole 1800 rpm synchronous speed motor, to obtain a speed reference of 900 rpm one must calculate:

$\begin{array}{l} 1800 \text{ rpm} \Rightarrow 8192 \\ 900 \text{ rpm} \Rightarrow 13 \text{ bit reference} \end{array}$
$13 \text{ bit reference} = \frac{900 \times 8192}{1800}$
$13 \text{ bit reference} = 4096 \Rightarrow \text{Value corresponding to 900 rpm in a 13 bit scale}$

This parameter also accepts negative values to revert the motor speed direction. The reference speed direction, however, depends also on the control word - P0684 - bit 2 setting:

- Bit 2 = 1 and P0685 > 0: reference for forward direction
- Bit 2 = 1 and P0685 < 0: reference for reverse direction
- Bit 2 = 0 and P0685 > 0: reference for reverse direction
- Bit 2 = 0 and P0685 < 0: reference for forward direction

**P0695 – DIGITAL OUTPUT SETTING**

<b>Range:</b>	0000h to 001Fh	<b>Default:</b> 0000h
<b>Properties:</b>	Net	
<b>Access groups via HMI:</b>	NET	

**Description:**

It allows the control of the digital outputs by means of the network interfaces (Serial, CAN, etc.). This parameter cannot be changed via HMI.

Each bit of this parameter corresponds to the desired value for one digital output. In order to have the correspondent digital output controlled according to this content, it is necessary that its function be programmed for “P0695 Content” at parameters P0275 to P0279.

Bits	15 to 5	4	3	2	1	0
Function	Reserved	DO5 setting	DO4 setting	DO3 setting	DO2 setting	DO1 setting

*Table 4.4: P0695 parameter bit functions*

Bits	Values
Bit 0 DO1 setting	0: DO1 output open. 1: DO1 output closed.
Bit 1 DO2 setting	0: DO2 output open. 1: DO2 output closed.
Bit 2 DO3 setting	0: DO3 output open. 1: DO3 output closed.
Bit 3 DO4 setting	0: DO4 output open. 1: DO4 output closed.
Bit 4 DO5 setting	0: DO5 output open. 1: DO5 output closed.
Bits 5 to 15	Reserved

**P0696 – VALUE 1 FOR ANALOG OUTPUTS**
**P0697 – VALUE 2 FOR ANALOG OUTPUTS**

<b>Range:</b>	-32768 to 32767	<b>Default:</b> 0
<b>Properties:</b>	RW	
<b>Access groups via HMI:</b>	NET	

**Description:**

They allow the control of the analog outputs by means of network interfaces (Serial, CAN, etc.) These parameters cannot be changed via HMI.

The value written in these parameters is used as the analog output value, providing that the function for the desired analog output be programmed for “P0696 / P0697 value”, at the parameters P0251, P0254.

The value must be written in a 15-bit scale (7FFFh = 32767)<sup>4</sup> to represent 100% of the output desired value, i.e.:

- P0696 = 0000h (0 decimal) → analog output value = 0 %
- P0696 = 7FFFh (32767 decimal) → analog output value = 100 %

The showed example was for P0696, but the same scale is also used for the parameters P0697. For instance, to control the analog output 1 via serial, the following programming must be done:

- Choose a parameter from P0696, P0697 to be the value used by the analog output 1. For this example, we are going to select P0696.
- Program the option “P0696 value” as the function for the analog output 1 in P0254.
- Using the network interface, write in P0696 the desired value for the analog output 1, between 0 and 100%, according to the parameter scale.


**NOTE!**

If the analog output is programmed for working from -10V to 10V, negative values for this parameter must be used to command the output with negative voltage values, i.e., -32768 to 32767 represent a variation from -10V to 10V at the analog output.

**P0700 – CAN PROTOCOL**

<b>Range:</b>	1 = CANopen 2 = DeviceNet	<b>Default:</b> 2
<b>Properties:</b>	CFG	
<b>Access groups via HMI:</b>	NET	

**Description:**

It allows selecting the desired protocol for the CAN interface. If this parameter is changed, it becomes valid only after cycling power of the inverter.

If this parameter is changed, the change takes effect only if the CAN interface is not powered, auto-baud or after the equipment is switched off and on again.

<sup>4</sup> Refer to the CFW700 manual for the product actual output resolution.

**P0701 – CAN ADDRESS**

<b>Range:</b>	0 a 127	<b>Default:</b> 63
<b>Properties:</b>	CFG	
<b>Access groups via HMI:</b>	NET	

**Description:**

It allows programming the address used for the CAN communication. It is necessary that each element of the network has an address different from the others. The valid addresses for this parameter depend on the protocol programmed in P0700:

- P0700 = 1 (CANopen) → valid addresses: 1 to 127.
- P0700 = 2 (DeviceNet) → valid addresses: 0 to 63.

If this parameter is changed, the change takes effect only if the CAN interface is not powered, auto-baud or after the equipment is switched off and on again.

**P0702 – CAN BAUD RATE**

<b>Range:</b>	0 = 1 Mbit/s / <i>Autobaud</i> 1 = 800 Kbit/s / <i>Autobaud</i> 2 = 500 Kbit/s 3 = 250 Kbit/s 4 = 125 Kbit/s 5 = 100 Kbit/s / <i>Autobaud</i> 6 = 50 Kbit/s / <i>Autobaud</i> 7 = 20 Kbit/s / <i>Autobaud</i> 8 = 10 Kbit/s / <i>Autobaud</i>	<b>Default:</b> 0
<b>Properties:</b>	CFG	
<b>Access groups via HMI:</b>	NET	

**Description:**

It allows programming the desired baud rate for the CAN interface, in bits per second. This rate must be the same for all the devices connected to the network. The supported baud rates for the device depend on the protocol programmed in the parameter P0700:

- P0700 = 1 (CANopen): It is possible to use any rate specified in this parameter, but it does not have the automatic baud rate detection function - *autobaud*.
- P0700 = 2 (DeviceNet): only the 500, 250 and 125 Kbit/s rates are supported. Other options will enable the automatic baud rate detection function - *autobaud*.

If this parameter is changed, the change takes effect only if the CAN interface is not powered or after the equipment is switched off and on again.

After a successful detection, the baud rate parameter (P0702) changes automatically to the detected rate. In order to execute the autobaud function again, it is necessary to change the parameter P0702 to one of the '*Autobaud*' options.

**P0703 – BUS OFF RESET**

<b>Range:</b>	0 = Manual 1 = Automatic	<b>Default:</b> 0
<b>Properties:</b>	CFG	
<b>Access groups via HMI:</b>	NET	

**Description:**

It allows programming the inverter behavior when detecting a bus off error at the CAN interface:

**Table 4.5:** Options for the parameter P0703

Option	Description
0 = Manual Reset	If <i>bus off</i> occurs, the A134/F234 alarm will be indicated on the HMI, the action programmed in parameter P0313 will be executed and the communication will be disabled. In order that the inverter communicates again through the CAN interface, it will be necessary to cycle the power of the inverter.
1 = Automatic Reset	If <i>bus off</i> occurs, the communication will be reinitiated automatically and the error will be ignored. In this case the alarm will not be indicated on the HMI and the inverter will not execute the action programmed in P0313.

**P0705 – CAN CONTROLLER STATUS**

<b>Range:</b>	0 = Disabled 1 = <i>Autobaud</i> 2 = CAN Enabled 3 = <i>Warning</i> 4 = <i>Error Passive</i> 5 = <i>Bus Off</i> 6 = No Bus Power	<b>Default:</b> -
<b>Properties:</b>	RO	
<b>Access groups via HMI:</b>	NET	

**Description:**

It allows identifying if the CAN interface board is properly installed and if the communication presents errors.

**Table 4.6:** Values for the parameter P0705

Value	Description
0 = Disabled	Inactive CAN interface. It occurs when the inverter does not have the CAN interface installed.
1 = <i>Autobaud</i>	CAN controller is trying to detect baud rate of the network (only for DeviceNet communication protocol).
2 = CAN Enabled	CAN interface is active and without errors.
3 = <i>Warning</i>	CAN controller has reached the <i>warning</i> state.
4 = <i>Error Passive</i>	CAN controller has reached the <i>error passive</i> state.
5 = <i>Bus Off</i>	CAN controller has reached the <i>bus off</i> state.
6 = No Bus Power	CAN interface does not have power supply between the pins 1 and 5 of the connector.

**P0706 – RECEIVED CAN TELEGRAM COUNTER**

<b>Range:</b>	0 to 65535	<b>Default:</b> -
<b>Properties:</b>	RO	
<b>Access groups via HMI:</b>	NET	

**Description:**

This parameter works as a cyclic counter that is incremented every time a CAN telegram is received. It informs the operator if the device is being able to communicate with the network. This counter is reset every time the device is switched off, a reset is performed or the parameter maximum limit is reached.

**P0707 – TRANSMITTED CAN TELEGRAM COUNTER**

<b>Range:</b>	0 to 65535	<b>Default:</b> -
<b>Properties:</b>	RO	
<b>Access groups via HMI:</b>	NET	

**Description:**

This parameter works as a cyclic counter that is incremented every time a CAN telegram is transmitted. It informs the operator if the device is being able to communicate with the network. This counter is reset every time the device is switched off, a reset is performed or the parameter maximum limit is reached.

**P0708 – BUS OFF ERROR COUNTER**

<b>Range:</b>	0 a 65535	<b>Default:</b> -
<b>Properties:</b>	RO	
<b>Access groups via HMI:</b>	NET	

**Description:**

It is a cyclic counter that indicates the number of times the device entered the bus off state in the CAN network. This counter is reset every time the device is switched off, a reset is performed or the parameter maximum limit is reached.

**P0709 – LOST CAN MESSAGE COUNTER**

<b>Range:</b>	0 to 65535	<b>Default:</b> -
<b>Properties:</b>	RO	
<b>Access groups via HMI:</b>	NET	

**Description:**

It is a cyclic counter that indicates the number of messages received by the CAN interface, but could not be processed by the device. In case that the number of lost messages is frequently incremented, it is recommended to reduce the baud rate used in the CAN network. This counter is reset every time the device is switched off, a reset is performed or the parameter maximum limit is reached.

**P0721 – CANOPEN COMMUNICATION STATUS**

<b>Range:</b>	0 = Disable 1 = Reserved 2 = Communication Enable 3 = Error Control Enable 4 = Guarding Error 5 = Heartbeat Error	<b>Default:</b> -
<b>Access groups via HMI:</b>	NET	

**Description:**

It indicates the board state regarding the CANopen network, informing if the protocol has been enabled and if the error control service is active (*Node Guarding* or *Heartbeat*).

**P0722 – CANOPEN NODE STATUS**

<b>Range:</b>	0 = Disable 1 = Initialization 2 = Stopped 3 = Operational 4 = Preoperatinal	<b>Default:</b> -
---------------	--	-------------------

**Access groups via HMI:** NET

**Description:**

It operates as a slave of the CANopen network, and as such element it has a state machine that controls its behavior regarding the communication. This parameter indicates in which state the device is.

## 5 OBJECT DICTIONARY

The object dictionary is a list containing several equipment data which can be accessed via CANopen network. An object of this list is identified by means of a 16-bit index, and it is based in that list that all the data exchange between devices is performed.

The CiA DS 301 document defines a set of minimum objects that every CANopen network slave must have. The objects available in that list are grouped according to the type of function they execute. The objects are arranged in the dictionary in the following manner:

*Table 5.1: Object dictionary groupings*

Index	Objects	Description
0001h – 025Fh	Data type definition	Used as reference for the data type supported by the system.
1000h – 1FFFh	Communication objects	They are objects common to all the CANopen devices. They contain general information about the equipment and also data for the communication configuration.
2000h – 5FFFh	Manufacturer specific objects	In this range, each CANopen equipment manufacturer is free to define which data those objects will represent.
6000h – 9FFFh	Standardized device objects	This range is reserved to objects that describe the behavior of similar equipment, regardless of the manufacturer.

The other indexes that are not referred in this list are reserved for future use.

### 5.1 DICTIONARY STRUCTURE

The general structure of the dictionary has the following format:

Index	Object	Name	Type	Access
-------	--------	------	------	--------

- **Index:** indicates directly the object index in the dictionary.
- **Object:** describes which information the index stores (simple variable, array, record, etc.).
- **Name:** contains the name of the object in order to facilitate its identification.
- **Type:** indicates directly the stored data type. For simple variables, this type may be an integer, a float, etc. For arrays, it indicates the type of data contained in the array. For records, it indicates the record format according to the types described in the first part of the object dictionary (indexes 0001h – 0360h).
- **Access:** informs if the object in question is accessible only for reading (ro), for reading and writing (rw), or if it is a constant (const).

For objects of the array or record type, a sub-index that is not described in the dictionary structure is also necessary.

### 5.2 DATA TYPE

The first part of the object dictionary (index 0001h - 0360h) describes the data types that can be accessed at a CANopen network device. They can be basic types, as integers and floats, or compound types formed by a set of entries, as records and arrays.

### 5.3 COMMUNICATION PROFILE – COMMUNICATION OBJECTS

The indexes from 1000h to 1FFFh in the object dictionary correspond to the part responsible for the CANopen network communication configuration. Those objects are common to all the devices, however only a few are obligatory. A list with the objects of this range that are supported by the frequency inverter CFW700 is presented next.



**Table 5.2: Object list – Communication Profile**

Index	Object	Name	Type	Access
1000h	VAR	device type	UNSIGNED32	ro
1001h	VAR	error register	UNSIGNED8	ro
1005h	VAR	COB-ID SYNC	UNSIGNED32	rw
100Ch	VAR	guard time	UNSIGNED16	rw
100Dh	VAR	life time factor	UNSIGNED8	rw
1016h	ARRAY	Consumer heartbeat time	UNSIGNED32	rw
1017h	VAR	Producer heartbeat time	UNSIGNED16	rw
1018h	RECORD	Identity Object	Identity	ro
Server SDO Parameter				
1200h	RECORD	1st Server SDO parameter	SDO Parameter	ro
Receive PDO Communication Parameter				
1400h	RECORD	1st receive PDO Parameter	PDO CommPar	rw
1401h	RECORD	2nd receive PDO Parameter	PDO CommPar	rw
1402h	RECORD	3rd receive PDO Parameter	PDO CommPar	rw
1403h	RECORD	4th receive PDO Parameter	PDO CommPar	rw
Receive PDO Mapping Parameter				
1600h	RECORD	1st receive PDO mapping	PDO Mapping	rw
1601h	RECORD	2nd receive PDO mapping	PDO Mapping	rw
1602h	RECORD	3rd receive PDO mapping	PDO Mapping	rw
1603h	RECORD	4th receive PDO mapping	PDO Mapping	rw
Transmit PDO Communication Parameter				
1800h	RECORD	1st transmit PDO Parameter	PDO CommPar	rw
1801h	RECORD	2nd transmit PDO Parameter	PDO CommPar	rw
1802h	RECORD	3rd transmit PDO Parameter	PDO CommPar	rw
1803h	RECORD	4th transmit PDO Parameter	PDO CommPar	rw
Transmit PDO Mapping Parameter				
1A00h	RECORD	1st transmit PDO mapping	PDO Mapping	rw
1A01h	RECORD	2nd transmit PDO mapping	PDO Mapping	rw
1A02h	RECORD	3rd transmit PDO mapping	PDO Mapping	rw
1A03h	RECORD	4th transmit PDO mapping	PDO Mapping	rw

These objects can only be read and written via the CANopen network, it is not available via the keypad (HMI) or other network interface. The network master, in general, is the equipment responsible for setting up the equipment before starting the operation. The EDS configuration file brings the list of all supported communication objects.

Refer to item 6 for more details on the available objects in this range of the objects dictionary.

#### 5.4 MANUFACTURER SPECIFIC – CFW700 SPECIFIC OBJECTS

For indexes from 2000h to 5FFFh, each manufacture is free to define which objects will be present, and also the type and function of each one. In the case of the CFW700, the whole list of parameters was made available in this object range. It is possible to operate the CFW700 by means of these parameters, carrying out any function that the inverter can execute. The parameters were made available starting from the index 2000h, and by adding their number to this index their position in the dictionary is obtained. The next table illustrates how the parameters are distributed in the object dictionary.

**Table 5.3: CFW700 object list – Manufacturer Specific**

Index	Object	Name	Type	Access
2000h	VAR	P0000 – Access parameter	INTEGER16	rw
2001h	VAR	P0001 – Speed reference	INTEGER16	ro
2002h	VAR	P0002 – Motor speed	INTEGER16	ro
2003h	VAR	P0003 – Motor current	INTEGER16	ro
2004h	VAR	P0004 – DC voltage	INTEGER16	ro
...	...	...	...	...
2064h	VAR	P0100 – Acceleration time	INTEGER16	rw
2065h	VAR	P0101 – Deceleration time	INTEGER16	rw
...	...	...	...	...

Refer to the CFW700 manual for a complete list of the parameters and their detailed description. In order to be able to program the inverter operation correctly via the CANopen network, it is necessary to know its operation through the parameters.

## 5.5 DEVICE PROFILE – COMMON OBJECTS FOR DRIVES

The CANopen documentation also includes suggestions for standardization of certain device types. The CFW700 frequency inverter follows the *CiA DPS 402 – Device Profile Drives and Motion Control* description. This document describes a set of objects that must be common for drives, regardless of the manufacturer. This makes the interaction between devices with the same function easier (as for frequency inverters), because the data, as well as the device behavior, are made available in a standardized manner.

For those objects the indexes from 6000h to 9FFFh were reserved. It is possible to operate the inverter through the CANopen network via the parameters (located from the index 2000h on), as well as by means of these standardized objects.

Refer to the section 7 for a detailed description of which objects are available for this range of the object dictionary.

## 6 COMMUNICATION OBJECTS DESCRIPTION

This item describes in detail each of the communication objects available for the frequency inverter CFW700 . It is necessary to know how to operate these objects to be able to use the available functions for the inverter communication.

### 6.1 IDENTIFICATION OBJECTS

There is a set of objects in the dictionary which are used for equipment identification; however, they do not have influence on their behavior in the CANopen network.

#### 6.1.1 Object 1000h – Device Type

This object gives a 32-bit code that describes the type of object and its functionality.

Index	1000h
Name	Device type
Object	VAR
Type	UNSIGNED32
Access	ro
Mappable	No
Range	UNSIGNED32
Default value	0001.0192h

This code can be divided into two parts: 16 low-order bits describing the type of profile that the device uses, and 16 high-order bits indicating a specific function according to the specified profile.

#### 6.1.2 Object 1001h – Error Register

This object indicates whether or not an error in the device occurred. The type of error registered for the CFW700 follows what is described in the table 5.1.

Index	1001h
Name	Error register
Object	VAR
Type	UNSIGNED8
Access	ro
Mappable	Yes
Range	UNSIGNED8
Default value	0

*Table 6.1: Structure of the object Error Register*

Bit	Meaning
0	Generic error
1	Current
2	Voltage
3	Temperature
4	Communication
5	Reserved (always 0)
6	Reserved (always 0)
7	Specific of the manufacturer

If the device presents any error, the equivalent bit must be activated. The first bit (generic error) must be activated with any error condition.

#### 6.1.3 Object 1018h – Identity Object

It brings general information about the device.

Index	1018h
Name	Identity object
Object	Record
Type	Identity

Sub index	0
Description	Number of the last sub-index
Access	RO
Mappable	No
Range	UNSIGNED8
Default value	4

Sub index	1
Description	Vendor ID
Access	RO
Mappable	No
Range	UNSIGNED32
Default value	0000.0123h

Sub index	2
Description	Product code
Access	RO
Mappable	No
Range	UNSIGNED32
Default value	0000.0A00h

Sub index	3
Description	Revision number
Access	RO
Mappable	No
Range	UNSIGNED32
Default value	According to the equipment firmware version


Sub index	4
Description	Serial number
Access	RO
Mappable	No
Range	UNSIGNED32
Default value	Different for every CFW700

The vendor ID is the number that identifies the manufacturer at the CiA. The product code is defined by the manufacturer according to the type of product. The revision number represents the equipment firmware version. The sub-index 4 is a unique serial number for each frequency inverter CFW700 in CANopen network.

## 6.2 SERVICE DATA OBJECTS – SDOS

The SDOs are responsible for the direct access to the object dictionary of a specific device in the network. They are used for the configuration and therefore have low priority, since they do not have to be used for communicating data necessary for the device operation.

There are two types of SDOs: client and server. Basically, the communication initiates with the client (usually the master of the network) making a read (*upload*) or write (*download*) request to a server, and then this server answers the request.



**Figure 6.1:** Communication between SDO client and server

### 6.2.1 Object 1200h – SDO Server

The frequency inverter CFW700 has only one SDO of the server type, which makes it possible the access to its entire object dictionary. Through it, an SDO client can configure the communication, the parameters and the inverter operation. Every SDO server has an object, of the SDO\_PARAMETER type, for its configuration, having the following structure:

Index	1200h
Name	Server SDO Parameter
Object	Record
Type	SDO Parameter

Sub index	0
Description	Number of the last sub-index
Access	RO
Mappable	No
Range	UNSIGNED8
Default value	2

Sub index	1
Description	COB-ID Client - Server (rx)
Access	RO
Mappable	No
Range	UNSIGNED32
Default value	600h + Node-ID

Sub index	2
Description	COB-ID Server - Client (tx)
Access	RO
Mappable	No
Range	UNSIGNED32
Default value	580h + Node-ID

### 6.2.2 SDOs Operation

A telegram sent by an SDO has an 8 byte size, with the following structure:

Identifier 11 bits	8 data bytes							
	Command byte 0	Index byte 1   byte 2		Sub-index byte 3	Object data byte 4   byte 5   byte 6   byte 7			

The identifier depends on the transmission direction (rx or tx) and on the address (or Node-ID) of the destination server. For instance, a client that makes a request to a server which Node-ID is 1, must send a message with the identifier 601h. The server will receive this message and answer with a telegram which COB-ID is equal to 581h.

The command code depends on the used function type. For the transmissions from a client to a server, the following commands can be used:

**Table 6.2:** Command codes for SDO client

Command	Function	Description	Object data
22h	<i>Download</i>	Write object	Not defined
23h	<i>Download</i>	Write object	4 bytes
2Bh	<i>Download</i>	Write object	2 bytes
2Fh	<i>Download</i>	Write object	1 byte
40h	<i>Upload</i>	Read object	Not used
60h or 70h	<i>Upload segment</i>	Segmented read	Not used

When making a request, the client will indicate through its COB-ID, the address of the slave to which this request is destined. Only a slave (using its respective SDO server) will be able to answer the received telegram to the client. The answer telegram will have also the same structure of the request telegram, the commands however are different:

**Table 6.3:** Command codes for SDO server

Command	Function	Description	Object data
60h	<i>Download</i>	Response to write object	Not used
43h	<i>Upload</i>	Response to read object	4 bytes
4Bh	<i>Upload</i>	Response to read object	2 bytes
4Fh	<i>Upload</i>	Response to read object	1 byte
41h	<i>Upload segment</i>	Initiates segmented response for read	4 bytes
01h ... 0Dh	<i>Upload segment</i>	Last data segment for read	8 ... 2 bytes

For readings of up to four data bytes, a single message can be transmitted by the server; for the reading of a bigger quantity of bytes, it is necessary that the client and the server exchange multiple telegrams.

A telegram is only completed after the acknowledgement of the server to the request of the client. If any error is detected during telegram exchanges (for instance, no answer from the server), the client will be able to abort the process by means of a warning message with the command code equal to 80h.


**NOTE!**

When the SDO is used for writing in objects that represent the CFW700 parameters (objects starting from the index 2000h), this value is saved in the nonvolatile frequency inverter memory. Therefore, the configured values are not lost after the equipment is switched off or reset. For all the other objects these values are not saved automatically, so that it is necessary to rewrite the desired values

E.g.: A client SDO requests for a CFW700 at address 1 the reading of the object identified by the index 2000h, sub-index 0 (zero), which represents an 16-bit integer. The master telegram has the following format:

Identifier	Command	Index	Sub-index	Data
601h	40h	00h   20h	00h	00h   00h   00h   00h

The CFW700 responds to the request indicating that the value of the referred object is equal to 999<sup>5</sup>:

Identifier	Command	Index	Sub-index	Data
581h	4Bh	00h   20h	00h	E7   03h   00h   00h

### 6.3 PROCESS DATA OBJECTS – PDOS


The PDOs are used to send and receive data used during the device operation, which must often be transmitted in a fast and efficient manner. Therefore, they have a higher priority than the SDOs.

In the PDOs only data are transmitted in the telegram (index and sub-index are omitted), and in this way it is possible to do a more efficient transmission, with larger volume of data in a single telegram. However it is necessary to configure previously what is being transmitted by the PDO, so that even without the indication of the index and sub-index, it is possible to know the content of the telegram.

There are two types of PDOs, the receive PDO and the transmit PDO. The transmit PDOs are responsible for sending data to the network, whereas the receive PDOs remain responsible for receiving and handling these

<sup>5</sup> Do not forget that for any integer type of data, the byte transfer order is from the least significant to the most significant.

data. In this way it is possible to have communication among slaves of the CANopen network, it is only necessary to configure one slave to transmit information and one or more slaves to receive this information.



**Figure 6.2:** Communication using PDOs



**NOTE!**

PDOs can only be transmitted or received when the device is in the operational state. The Figure 6.2 illustrates the available states for CANopen network node.

**6.3.1 Mappable Objects for the PDOs**

In order to be able to be transmitted by a PDO, it is necessary that an object be mappable for this PDO content. In the description of communication objects (1000h – 1FFFh), the field “Mappable” informs this possibility. Usually only information necessary for the operation of the device is mappable, such as enabling commands, device status, reference, etc. Information on the device configuration are not accessible through PDOs, and if it is necessary to access them one must use the SDOs.

For CFW700 specific objects (2000h – 5FFFh), the next table presents some objects mappable for the PDOs. Read-only parameters (ro) can be used only by transmit PDOs, whereas the other parameters can be used only by receive PDOs. The CFW700 EDS file brings the list of all the objects available for the inverter, informing whether the object is mappable or not.

**Table 6.4:** Examples of mappable parameters for PDOs

Index	Object	Name	Type	Access
2002h	VAR	P0002 – Motor speed	UNSIGNED16	ro
2003h	VAR	P0003 – Motor current	UNSIGNED16	ro
2005h	VAR	P0005 – Motor frequency	UNSIGNED16	ro
2006h	VAR	P0006 – Inverter status	UNSIGNED16	ro
2007h	VAR	P0007 – Output voltage	UNSIGNED16	ro
2009h	VAR	P0009 – Motor torque	INTEGER16	ro
200Ah	VAR	P0010 – Output power	UNSIGNED16	ro
200Ch	VAR	P0012 – DI1 to DI8 status	UNSIGNED16	ro
2012h	VAR	P0018 – AI1 value	INTEGER16	ro
2013h	VAR	P0019 – AI2 value	INTEGER16	ro
2064h	VAR	P0100 – Acceleration time	UNSIGNED16	rw
2065h	VAR	P0101 – Deceleration time	UNSIGNED16	rw
22A8h	VAR	P0680 – Logical status	UNSIGNED16	ro
22A9h	VAR	P0681 – Motor speed in 13 bits	UNSIGNED16	ro
22ACh	VAR	P0684 – Control CANopen/DeviceNet	UNSIGNED16	rw
22ADh	VAR	P0685 – Speed reference CANopen/DeviceNet	UNSIGNED16	rw

The EDS file brings the list of all available objects informing whether the object is mappable or not.

**6.3.2 Receive PDOs**

The receive PDOs, or RPDOs, are responsible for receiving data that other devices send to the CANopen network. The frequency inverter CFW700 has 4 receive PDOs, each one being able to receive up to 8 bytes. Each RPDO has two parameters for its configuration, a PDO\_COMM\_PARAMETER and a PDO\_MAPPING, as described next.

**PDO\_COMM\_PARAMETER**

Index	1400h até 1403h
Name	Receive PDO communication parameter
Object	Record
Type	PDO COMM PARAMETER

Sub index	0
Description	Number of the last sub-index
Access	ro
Mappable	No
Range	UNSIGNED8
Default value	2

Sub index	1
Description	COB-ID used by the PDO
Access	rw
Mappable	No
Range	UNSIGNED32
Default value	1400h: 200h + Node-ID 1401h: 300h + Node-ID 1402h: 400h + Node-ID 1403h: 500h + Node-ID

Sub index	2
Description	Transmission Type
Access	rw
Mappable	No
Range	UNSIGNED8
Default value	254

The sub-index 1 contains the receive PDO COB-ID. Every time a message is sent to the network, this object will read the COB-ID of that message and, if it is equal to the value of this field, the message will be received by the device. This field is formed by an UNSIGNED32 with the following structure:

**Table 6.5:** COB-ID description

Bit	Value	Description
31 (MSB)	0	PDO is enabled
	1	PDO is disabled
30	0	RTR permitted
29	0	Identifier size = 11 bits
28 – 11	0	Not used, always 0
10 – 0 (LSB)	X	11-bit COB-ID

The bit 31 allows enabling or disabling the PDO. The bits 29 and 30 must be kept in 0 (zero), they indicate respectively that the PDO accepts remote frames (RTR frames) and that it uses an 11-bit identifier. Since the CFW700 frequency inverter does not use 29-bit identifiers, the bits from 28 to 11 must be kept in 0 (zero), whereas the bits from 10 to 0 (zero) are used to configure the COB-ID for the PDO.

The sub-index 2 indicates the transmission type of this object, according to the next table.

**Table 6.6:** Description of the type of transmission

Type of transmission	PDOs transmission				
	<i>Cyclic</i>	<i>Acyclic</i>	<i>Synchronous</i>	<i>Asynchronous</i>	<i>RTR</i>
0		•	•		
1 – 240	•		•		
241 – 251	Reserved				
252			•		•
253				•	•
254				•	
255				•	

- **Values 0 – 240:** any RPDO programmed in this range presents the same performance. When detecting a message, it will receive the data; however it won't update the received values until detecting the next SYNC telegram.



- **Values 252 and 253:** not allowed for receive PDOs.
- **Values 254 and 255:** they indicated that there is no relationship with the synchronization object. When receiving a message, its values are updated immediately.

## PDO\_MAPPING

Index	1600h up to 1603h
Name	Receive PDO mapping
Object	Record
Type	PDO MAPPING

Sub index	0
Description	Number of mapped objects
Access	RO
Mappable	No
Range	0 = disable 1 ... 4 = number of mapped
Default value	0

Sub index	1 up to 4
Description	1° up to 4 object mapped in the PDO
Access	Rw
Mappable	No
Range	UNSIGNED32
Default value	According EDS file

This parameter indicates the mapped objects in the CFW700 receive PDOs. It is possible to map up to 4 different objects for each RPDO, provided that the total length does not exceed eight bytes. The mapping of an object is done indicating its index, sub-index<sup>6</sup> and size (in bits) in an UNSIGNED32, field with the following format:

UNSIGNED32		
Index (16 bits)	Sub-index (8 bits)	Size of the object (8 bits)

For instance, analyzing the receive PDO standard mapping, we have:

- **Sub-index 0 = 2:** the RPDO has two mapped objects.
- **Sub-index 1 = 22AC.0010h:** the first mapped object has an index equal to 22ACh, sub-index 0 (zero), and a size of 16 bits. This object corresponds to the inverter parameter P0684, which represents the CANopen control word.
- **Sub-index 2 = 22AD.0010h:** the second mapped object has an index equal to 22ADh, sub-index 0 (zero), and a size of 16 bits. This object corresponds to the inverter parameter P0685, which represents the speed reference.

It is possible to modify this mapping by changing the quantity or the number of mapped objects. Remembering that only 4 objects or 8 bytes can be mapped at maximum.



### NOTE!

- In order to change the mapped objects in a PDO, it is first necessary to write the value 0 (zero) in the sub-index 0 (zero). In that way the values of the sub-indexes 1 to 4 can be changed. After the desired mapping has been done, one must write again in the sub-index 0 (zero) the number of objects that have been mapped, enabling again the PDO.
- Do not forget that PDOs can only be received if the CFW700 is in the operational state.

### 6.3.3 Transmit PDOs

The transmit PDOs, or TPDOs, as the name says, are responsible for transmitting data for the CANopen network. The frequency inverter CFW700 has 4 transmit PDOs, each one being able to transmit up to 8 data bytes. In a manner similar to RPDOs, each TPDO has two parameters for its configuration, a PDO\_COMM\_PARAMETER and a PDO\_MAPPING, AS DESCRIBED NEXT.

<sup>6</sup> If the object is of the VAR type and does not have sub-index, the value 0 (zero) must be indicated for the sub-index.

## PDO\_COMM\_PARAMETER

Index	1800h up to 1803h
Name	Transmit PDO Parameter
Object	Record
Type	PDO COMM PARAMETER

Sub index	0
Description	Number of the last sub-index
Access	ro
Mappable	No
Range	UNSIGNED8
Default value	5

Sub index	1
Description	COB-ID used by the PDO
Access	rw
Mappable	No
Range	UNSIGNED32
Default value	1800h: 180h + Node-ID 1801h: 280h + Node-ID 1802h: 380h + Node-ID 1803h: 480h + Node-ID

Sub index	2
Description	Transmission Type
Access	rw
Mappable	No
Range	UNSIGNED8
Default value	254

Sub index	3
Description	Time between transmissions
Access	rw
Mappable	No
Range	UNSIGNED16
Default value	-

Sub index	4
Description	Reserved
Access	rw
Mappable	No
Range	UNSIGNED8
Default value	-

Sub index	5
Description	Event timer
Access	rw
Mappable	No
Range	0 = disable UNSIGNED16
Default value	0

The sub-index 1 contains the transmit PDO COB-ID. Every time this PDO sends a message to the network, the identifier of that message will be this COB-ID. The structure of this field is described in table 5.5.

The sub-index 2 indicates the transmission type of this object, which follows the table 5.6 description. Its working is however different for transmit PDOs:

- **Value 0:** indicates that the transmission must occur immediately after the reception of a SYNC telegram, but not periodically.
- **Values 1 – 240:** the PDO must be transmitted at each detected SYNC telegram (or multiple occurrences of SYNC, according to the number chosen between 1 and 240).
- **Value 252:** indicates that the message content must be updated (but not sent) after the reception of a SYNC telegram. The transmission of the message must be done after the reception of a remote frame (RTR frame).
- **Value 253:** the PDO must update and send a message as soon as it receives a remote frame.
- **Values 254:** The object must be transmitted according to the timer programmed in sub-index 5.

- **Values 255:** the object is transmitted automatically when the value of any of the objects mapped in this PDO is changed. It works by changing the state (*Change of State*). This type does also allow that the PDO be transmitted according to the timer programmed in sub-index 5.

In the sub-index 3 it is possible to program a minimum time (in multiples of 100µs) that must elapse after the a telegram has been sent, so that a new one can be sent by this PDO. The value 0 (zero) disables this function.

The sub-index 5 contains a value to enable a timer for the automatic sending of a PDO. Therefore, whenever a PDO is configured as the asynchronous type, it is possible to program the value of this timer (in multiples of 1ms), so that the PDO is transmitted periodically in the programmed time.



**NOTE!**

- The value of this timer must be programmed according to the used transmission rate. Very short times (close to the transmission time of the telegram) are able to monopolize the bus, causing indefinite retransmission of the PDO, and avoiding that other less priority objects transmit their data.
- The minimum time allowed for this Function in the frequency inverter CFW700 é 2ms.
- It is important to observe the time between transmissions programmed in the sub-index 3, especially when the PDO is programmed with the value 255 in the sub-index 2 (*Change of State*).

PDO\_MAPPING

Index	1A00h up to 1A07h
Name	Transmit PDO mapping
Object	Record
Type	PDO MAPPING

Sub index	0
Description	Number of the last sub-index
Access	ro
Mappable	No
Range	0 = disable 1 ... 4 = number of mapped
Default value	0

Sub index	1 até 4
Description	1º até 4º object mapped in the PDO
Access	rw
Mappable	No
Range	UNSIGNED32
Default value	0

The PDO MAPPING for the transmission works in similar way than for the reception, however in this case the data to be transmitted by the PDO are defined. Each mapped object must be put in the list according to the description showed next:

UNSIGNED32		
Index (16 bits)	Sub-index (8 bits)	Size of the object (8 bits)

For instance, analyzing the standard mapping of the fourth transmit PDO, we have:

- **Sub- index 0 = 2:** This PDO has two mapped objects.
- **Sub- index 1 = 22A8.0010h:** the first mapped object has an index equal to 22A8h, sub-index 0 (zero), and a size of 16 bits. This object corresponds to the parameter P0680 that is inverter status.
- **Sub-índice 2 = 22A9.0010h:** the second mapped object has an index equal to 22A9h, sub- index 0 (zero), and a size of 16 bits. This object corresponds to the parameter P0681 that is motor speed.

Therefore, every time this PDO transmits its data, it elaborates its telegram containing four data bytes, with the values of the parameters P0680 and P0681. It is possible to modify this mapping by changing the quantity or the number of mapped objects. Remember that a maximum of 4 objects or 8 bytes can be mapped.



**NOTE!**

In order to change the mapped objects in a PDO, it is first necessary to write the value 0 (zero) in the sub-index 0 (zero). In that way the values of the sub-indexes 1 to 4 can be changed. After the desired mapping has been done, one must write again in the sub-index 0 (zero) the number of objects that have been mapped, enabling again the PDO.

**6.4 SYNCHRONIZATION OBJECT – SYNC**

This object is transmitted with the purpose of allowing the synchronization of events among the CANopen network devices. It is transmitted by a SYNC producer, and the devices that detect its transmission are named SYNC consumers

The frequency inverter CFW700 has the function of a SYNC consumer and, therefore, it can program its PDOs to be synchronous. As described in table 5.6, synchronous PDOs are those related to the synchronization object, thus they can be programmed to be transmitted or updated based in this object.



**Figure 6.3:** SYNC

The SYNC message transmitted by the producer does not have any data in its data field, because its purpose is to provide a time base for the other objects. There is an object in the CFW700 for the configuration of the COB-ID of the SYNC consumer.

Index	1015h
Name	COB-ID SYNC
Object	VAR
Type	UNSIGNED32

Access	rw
Mappable	No
Range	UNSIGNED32
Default value	80h


**NOTE!**


The period of the SYNC telegrams must be programmed in the producer according to the transmission rate and the number of synchronous PDOs to be transmitted. There must be enough time for the transmission of these objects, and it is also recommended that there is a tolerance to make it possible the transmission of asynchronous messages, such as EMCY, asynchronous PDOs and SDOs.

**6.5 NETWORK MANAGEMENT – NMT**

The network management object is responsible for a series of services that control the communication of the device in a CANopen network. For the CFW700 the services of node control and error control are available (using *Node Guarding* or *Heartbeat*).

**6.5.1 Slave State Control**

With respect to the communication, a CANopen network device can be described by the following state machine:



**Figure 6.4:** CANopen node state diagram

**Table 6.7:** Transitions Description

Transition	Description
1	The device is switched on and initiates the initialization (automatic).
2	Initialization concluded, it goes to the preoperational state (automatic).
3	It receives the Start Node command for entering the operational state.
4	It receives the Enter Pre-Operational command, and goes to the preoperational state.
5	It receives the Stop Node command for entering the stopped state.
6	It receives the Reset Node command, when it executes the device complete reset.
7	It receives the Reset Communication command, when it reinitializes the object values and the CANopen device communication.

During the initialization the Node-ID is defined, the objects are created and the interface with the CAN network is configured. Communication with the device is not possible during this stage, which is concluded automatically. At the end of this stage the slave sends to the network a telegram of the Boot-up Object, used only to indicate that the initialization has been concluded and that the slave has entered the preoperational state. This telegram has the identifier 700h + Node-ID, and only one data byte with value equal to 0 (zero).

In the preoperational state it is already possible to communicate with the slave, but its PDOs are not yet available for operation. In the operational state all the objects are available, whereas in the stopped state only the NMT object can receive or transmit telegrams to the network. The next table shows the objects available for each state.

**Table 6.8:** Objects accessible in each state

	Initialization	Preoperational	Operational	Stopped
PDO			•	
SDO		•	•	
SYNC		•	•	
EMCY		•	•	
Boot-up	•			
NMT		•	•	•

This state machine is controlled by the network master, which sends to each slave the commands so that the desired state change be executed. These telegrams do not have confirmation, what means that the slave does only receive the telegram without returning an answer to the master. The received telegrams have the following structure:

Identifier	byte 1	byte 2
00h	Command code	Destination Node-ID


**Table 6.9:** Commands for the state transition

Command code	Destination Node-ID
1 = <i>START node</i> (transition 3)	0 = All the slaves 1 ... 127 = Specific slave
2 = <i>STOP node</i> (transition 4)	
128 = <i>Enter pre-operational</i> (transition 5)	
129 = <i>Reset node</i> (transition 6)	
130 = <i>Reset communication</i> (transition 7)	

The transitions indicated in the command code correspond to the state transitions executed by the node after receiving the command (according to the Figure 6.4). The *Reset node* command makes the CFW700 execute a complete reset of the device, while the *Reset communication* command causes the device to reinitialize only the objects pertinent to the CANopen communication.

### 6.5.2 Error Control – Node Guarding

This service is used to make it possible the monitoring of the communication with the CANopen network, both by the master and the slave as well. In this type of service the master sends periodical telegrams to the slave, which responds to the received telegram. If some error that interrupts the communication occurs, it will be possible to identify this error, because the master as well as the slave will be notified by the *Timeout* in the execution of this service. The error events are called *Node Guarding* for the master and *Life Guarding* for the slave.


**Figure 6.5:** Error control service – Node Guarding

There are two objects of the dictionary for the configuration of the error detection times for the *Node Guarding* service:

Index	100Ch
Name	Guard Time
Object	VAR
Type	UNSIGNED16

Access	rw
Mappable	No
Range	UNSIGNED16
Default value	0

Index	100Dh
Name	Life Time Factor
Object	VAR
Type	UNSIGNED8

Access	rw
Mappable	No
Range	UNSIGNED8
Default value	0

The 100Ch object allows programming the time necessary (in milliseconds) for a fault occurrence being detected, in case the CFW700 does not receive any telegram from the master. The 100Dh object indicates how many faults in sequence are necessary until it be considered that there was really a communication error. Therefore, the multiplication of these two values will result in the total necessary time for the communication error detection using this object. The value 0 (zero) disables this function.

Once configured, the CFW700 starts counting these times starting from the first *Node Guarding* telegram received from the network master. The master telegram is of the remote type, not having data bytes. The identifier is equal to 700h + Node-ID of the destination slave. However the slave response telegram has 1 data byte with the following structure:

Identifier	byte 1	
	bit 7	bit 6 ... bit 0
700h + Node-ID	Toggle	Slave state

This telegram has one single data byte. This byte contains, in the seven least significant bits, a value to indicate the slave state (4 = stopped, 5 = operational and 127 = preoperational), and in the eighth bit, a value that must be changed at every telegram sent by the slave (*toggle bit*).


If the frequency inverter CFW700 detects an error using this mechanism, it will turn automatically to the preoperational state and indicate alarm A135 on its HMI.


**NOTE!**

- This object is active even in the stopped state (see table 5.8).
- The value 0 (zero) in any of these two objects will disable this function.
- If after the error detection the service is enabled again, then the error indication will be removed from the HMI.
- The minimum value accepted by the CFW700 is 2ms., but considering the transmission rate and the number of nodes in the network, the times programmed for this function must be consistent, so that there is enough time for the transmission of the telegrams and also that the rest of the communication be able to be processed.
- For any every slave only one of the two services - Heartbeat or Node Guarding – can be enabled.

### 6.5.3 Error Control – Heartbeat

The error detection through the *Heartbeat* mechanism is done using two types of objects: the *Heartbeat* producer and the *Heartbeat* consumer. The producer is responsible for sending periodic telegrams to the network, simulating a heartbeat, indicating that the communication is active and without errors. One or more consumers can monitor these periodic telegrams, and if they cease occurring, it means that any communication problem occurred.



**Figure 6.6:** Error control service – Heartbeat

One device of the network can be both producer and consumer of *heartbeat* messages. For example, the network master can consume messages sent by a slave, making it possible to detect communication problems with the master, and simultaneously the slave can consume *heartbeat* messages sent by the master, also making it possible to the slave detect communication fault with the master..

The CFW700 has the producer and consumer of *heartbeat* services. As a consumer, it is possible to program up to 4 different producers to be monitored by the inverter.

Index	1016h
Name	Consumer Heartbeat Time
Object	ARRAY
Type	UNSIGNED32

Sub index	0
Description	Number of the last sub-index
Access	ro
Mappable	No
Range	-
Default value	4

Sub index	1 – 4
Description	Consumer Heartbeat Time 1 – 4
Access	rw
Mappable	No
Range	UNSIGNED32
Default value	0

At sub-indexes 1 to 4, it is possible to program the consumer by writing a value with the following format:

UNSIGNED32		
Reserved (8 bits)	Node-ID (8 bits)	Heartbeat time (16 bits)

- **Node-ID:** it allows programming the Node\_ID for the *heartbeat* producer to be monitored.
- **Heartbeat time:** it allows programming the time, in 1 millisecond multiples, until the error detection if no message of the producer is received. The value 0 (zero) in this field disables the consumer.

Once configured, the *heartbeat* consumer initiates the monitoring after the reception of the first telegram sent by the producer. In case that an error is detected because the consumer stopped receiving messages from the *heartbeat* producer, the frequency inverter will turn automatically to the preoperational state and indicate alarm A135 in the HMI.



As a producer, the frequency inverter CFW700 has an object for the configuration of that service:

Index	1017h
Name	Producer Heartbeat Time
Object	VAR
Type	UNSIGNED16

Access	rw
Mappable	No
Range	UNSIGNED8
Default value	0

The 1017h object allows programming the time in milliseconds during which the producer has to send a *heartbeat* telegram to the network. Once programmed, the inverter initiates the transmission of messages with the following format:

Identifier	byte 1	
	bit 7	bit 6 ... bit 0
700h + Node-ID	Always 0	Slave state




**NOTE!**

- This object is active even in the stopped state (see table 5.8).
- The value 0 (zero) in the object will disable this function.
- If after the error detection the service is enabled again, then the error indication will be removed from the HMI.
- The time value programmed for the consumer must be higher than the programmed for the respective producer. Actually, it is recommended to program the consumer with a multiple of the value used for the producer.
- For any every slave only one of the two services - *Heartbeat* or *Node Guarding* – can be enabled.

**6.6 INICIALIZATION PROCEDURE**

Once the operation of the objects available for the frequency inverter CFW700 is known, then it becomes necessary to program the different objects to operate combined in the network. In a general manner, the procedure for the initialization of the objects in a CANopen network follows the description of the next flowchart:



*Figure 6.7: Initialization process flowchart*

It is necessary to observe that the frequency inverter CFW700 communication objects (1000h to 1FFFh) are not stored in the nonvolatile memory. Therefore, every time the equipment is reset or switched off, it is necessary to redo the communication objects parameter setting. The manufacturer specific objects (starting from 2000h that represents the parameters), they are stored in the nonvolatile memory and, thus, could be set just once.

## 7 DESCRIPTION OF THE OBJECTS FOR DRIVES

The objects that are common for drives, defined by the CANopen specification in the CiA DSP 402 document, are described in this section. Regardless of the drive manufacturer, the objects mentioned here have a similar description and operation. This makes it easier the interaction and the interchangeability between different devices.

The Figure 7.1 shows a diagram with the logic architecture and the operation of a drive through the CANopen network, with the different operation modes defined in this specification. Each operation mode has a set of objects that allows the configuration and operation of the drive in the network.




Figure 7.1: Communication architecture for a drive in the CANopen network

For the CFW700, only the *Velocity Mode* is supported. The Table 7.1 presents the list of the available objects for the CFW700, divided according to the different operation modes of the inverter.

Table 7.1: CFW700 Object list – Drive Profile

Index	Object	Name	Type	Access	Mappable
Device Control					
6040h	VAR	Controlword	UNSIGNED16	rw	Yes
6041h	VAR	Statusword	UNSIGNED16	ro	Yes
6060h	VAR	Modes of Operation	INTEGER8	rw	Yes
6061h	VAR	Modes of Operation Display	INTEGER8	ro	Yes
Velocity Mode					
6042h	VAR	vl target velocity	INTEGER16	rw	Yes
6043h	VAR	vl velocity demand	INTEGER16	ro	Yes
6044h	VAR	vl control effort	INTEGER16	ro	Yes
6046h	ARRAY	vl velocity min max amount	UNSIGNED32	rw	Yes
6048h	RECORD	vl velocity acceleration	vl vel. accel. decl. record	rw	Yes
6049h	RECORD	vl velocity deceleration	vl vel. accel. decl. record	rw	Yes
Position Control Function					
6063h	VAR	Position actual value	INTEGER32	Ro	Yes

Every time an object of that list is read or written, the CFW700 will map its functions in the inverter parameters. Thus, by operating the system through these objects, the value of the parameters can be changed according to the used function. In the next items a detailed description of each of these objects is presented, where the inverter parameters used to execute these object functions are indicated.

## 7.1 DEVICE CONTROL – OBJECTS FOR CONTROLLING THE DRIVE

Every drive operating in a CANopen network following the DSP 402 must be in accordance with the description of the following state machine:




Figure 7.2: State machine for drives

Estate descriptions:

- **Not ready to switch on:** The inverter is initializing, it cannot be commanded.
- **Switch on disabled:** Initialization complete, the inverter is able to receive commands.
- **Ready to switch on:** Command to allow powering up the drive has been received.
- **Switched on:** Command for powering up the drive has been received.
- **Operation enabled:** The drive is enabled, being controlled according to the programmed operation mode. Power is being applied to the motor.
- **Quick stop active:** During the operation, the quick stop command was received. Power is being applied to the motor.
- **Fault reaction active:** A fault has occurred and the drive is performing the action related to the type of fault.
- **Fault:** Drive with fault. Disabled function, without power being applied to the motor.



**NOTE!**

The frequency inverter CFW700 does not have a switch for disabling / enabling the power section supply of the equipment. Therefore, the states described in the Power disabled group were implemented for a matter of compatibility with the described state machine; however the power section supply remains active even in these states.

Description of the transitions:

- **Transition 0:** The drive is switched on and the initialization procedure starts. The power section supply of the drive is active.
- **Transition 1:** Initialization completed (automatic).
- **Transition 2:** The *Shutdown* command has been received. The state transition is performed, but no action is taken by the CFW700.
- **Transition 3:** The *Switch on* command has been received. The state transition is performed, but no action is taken by the CFW700.
- **Transition 4:** The *Enable operation* command has been received. the frequency inverter is enabled. It corresponds to activate the bit 1 of the control word of the frequency inverter via CAN – P0684.
- **Transition 5:** The *Disable operation* command has been received. the frequency inverter is disabled. It corresponds to reset the bit 1 of the control word of the inverter via CAN – P0684.
- **Transition 6:** The *Shutdown* command has been received. The state transition is performed, but no action is taken by the CFW700.
- **Transition 7:** The *Quick stop* and *Disable voltage* commands have been received. The state transition is performed, but no action is taken by the CFW700.
- **Transition 8:** The *Shutdown* command has been received. During the operation of the frequency inverter it is disabled, blocking the supply for the motor. It corresponds to reset the bit 1 of the control word of the frequency inverter via CAN – P0684.
- **Transition 9:** The *Shutdown* command has been received. During the operation of the frequency inverter it is disabled, blocking the supply for the motor. It corresponds to reset the bit 1 of the control word of the frequency inverter via CAN – P0684.
- **Transition 10:** The *Quick stop* or *Disable voltage* command has been received. The state transition is performed, but no action is taken by the CFW700.
- **Transition 11:** The *Quick stop* command has been received. the frequency inverter performs the stopping via ramp function. It corresponds to reset the bit 0 of the control word of the frequency inverter via CAN – P0684.
- **Transition 12:** The *Disable voltage* command has been received. the frequency inverter is disabled. It corresponds to reset the bit 1 of the control word of the inverter via CAN – P0684.
- **Transition 13:** A fault is detected and the frequency inverter is disabled.
- **Transition 14:** After disabling the drive, it goes to the fault state (automatic).
- **Transition 15:** The *Fault reset* command has been received. the frequency inverter performs the fault reset and returns to the disabled and without fault state.
- **Transition 16:** The *Enable operation* command has been received. the frequency inverter performs the start via ramp function. It corresponds to activate the bit 0 of the control word of the inverter via CAN – P0684.

This state machine is controlled by the 6040h object, and the other states can be monitored by the 6041h object. Both objects are described next.

### 7.1.1 Objeto 6040h – Controlword

It controls the frequency inverter state

Index	6040h
Name	Controlword
Object	VAR
Type	UNSIGNED16
Used parameter	P0684

Access	rw
Mappable	Yes
Range	UNSIGNED16
Default value	-

The bits of this word have the following functions:

15 – 9	8	7	6 – 4	3	2	1	0
Reserved	Halt	Fault reset	Operation mode specific	Enable operation	Quick stop	Enable voltage	Switch on

The bits 0, 1, 2, 3 and 7 allow controlling the drive state machine. The commands for state transitions are given by means of the bit combinations indicated in the table 6.2. The bits marked with “x” are irrelevant for the command execution.

**Table 7.2: Control word commands**

Command	Control word bits					Transitions
	Fault reset	Enable operation	Quick stop	Enable voltage	Switch on	
Shutdown	0	x	1	1	0	2, 6, 8
Switch on	0	0	1	1	1	3
Disable voltage	0	x	x	0	x	7, 9, 10, 12
Quick stop	0	x	0	1	x	7, 10, 11
Disable operation	0	0	1	1	1	5
Enable operation	0	1	1	1	1	4, 16
Fault reset	0 → 1	x	x	x	x	15

The bits 4, 5, 6 and 8 have different functions according to the used operation mode. The detailed description of the functions of these bits for the velocity mode is presented on the section 7.2.1.

### 7.1.2 Objeto 6041h – Statusword

It indicates the CFW700 present state.

Index	6041h
Name	Statusword
Object	VAR
Type	UNSIGNED16
Used parameter	P0680
Access	ro
Mappable	Yes
Range	UNSIGNED16
Default value	-

**Table 7.3: Statusword bit function**

Bit	Description
0	Ready to switch on
1	Switched on
2	Operation enabled
3	Fault
4	Voltage enabled
5	Quick stop
6	Switch on disabled
7	Warning
8	Reserved
9	Remote
10	Target reached
11	Internal limit active
12 – 13	Operation mode specific
14 – 15	Reserved

In this word the bits 0, 1, 2, 3, 5 and 6 indicate the state of the device according to the state machine described in the figure 6.2. The table 6.4 describes the combinations of these bits for the state indications. The bits marked with “x” are irrelevant for the state indication.

**Table 7.4: Drive states indicated through the Statusword**

Value (binary)	State
xxxx xxxx x0xx 0000	Not ready to switch on
xxxx xxxx x1xx 0000	Switch on disabled
xxxx xxxx x01x 0001	Ready to switch on
xxxx xxxx x01x 0011	Switched on
xxxx xxxx x01x 0111	Operation enabled
xxxx xxxx x00x 0111	Quick stop active
xxxx xxxx x0xx 1111	Fault reaction active
xxxx xxxx x0xx 1000	Fault

The other bits indicate a specific condition for the drive.

- **Bit 4 – Voltage enabled:** indicates that the drive power section is being fed.
- **Bit 7 – Warning:** It is not used for the CFW700.
- **Bit 9 – Remote:** indicates when the drive is in the remote mode and accepts commands via the CANopen<sup>7</sup> network. It represents the Statusword bit 4 value – P0680.
- **Bit 10 – Target reached:** indicates when the drive is operating at the reference value, which depends on the used operation mode. It is also set to 1 when the functions Quick stop or Halt are activated.
- **Bit 11 – Internal limit active:** Not is used for the frequency inverter CFW700.
- **Bits 12 e 13 – Operation mode specific:** they depend on the drive operation mode.

### 7.1.3 Objeto 6060h – Modes of Operation

It allows programming the CFW700 operation mode.

Index	6060h
Name	Modes of operation
Object	VAR
Type	INTEGER8
Used parameter	-

Access	rw
Mappable	Yes
Range	INTEGER8
Default value	-

The only mode supported by the CFW700 frequency inverter is the Velocity Mode, represented by the value 2.

### 7.1.4 Objeto 6061h – Modes of Operation Display

It indicates the CFW700 operation mode.

Index	6061h
Name	Modes of operation display
Object	VAR
Type	INTEGER8
Used parameter	-

Access	rw
Mappable	Yes
Range	INTEGER8
Default value	-

The only mode supported by the CFW700 frequency inverter is the Velocity Mode, represented by the value 2.

## 7.2 VELOCITY MODE – OBJECTS FOR CONTROLLING THE DRIVE

This operation mode allows the control of the inverter in a simple manner, making available functions of the following type:

- Reference value calculation.
- Capture and monitoring of the speed.
- Speed limitation.
- Speed ramps, among other functions.

These functions are executed based on a set of objects for the configuration of that operation mode.

### 7.2.1 Control and State Bits

The bits 4, 5, 6 and 8 of the control word (6040h object – Control word) have the following functions in the velocity mode:

<sup>7</sup> It depends on the inverter programming.

Bit	Name	Value	Description
4	Reserved		
5	Reserved		
6	<i>Reference ramp</i>	0	Ramp Disable – bit 0 do P0684 = 0
		1	Ramp Enable – bit 0 do P0684 = 1
8	Halt	0	Ramp Enable – bit 0 do P0684 = 1
		1	Ramp Disable – bit 0 do P0684 = 0

In order that the motor runs according to the acceleration ramp, it is necessary that the bit 4 be activated.

For the Statusword, the bits specified in the operation mode (bits 12 and 13) are reserved for future use.

### 7.2.2 Objeto 6042h – vl Target Velocity

It allows programming the speed reference for the inverter, in rpm:

Index	6042h
Name	vl target velocity
Object	VAR
Type	INTEGER16
Used parameter	P0684, P0685
Access	rw
Mappable	Yes
Range	INTEGER16
Default value	0

The object vl target velocity allows the writing of negative speed reference values in order to run the motor in the reverse speed direction. This change in the speed direction is performed through the writing of the bit 2 in the CAN control word - P0684.

### 7.2.3 Objeto 6043h – vl Velocity Demand

It indicates the value of the speed reference after the ramp, in rpm:

Index	6043h
Name	vl velocity demand
Object	VAR
Type	INTEGER16
Used parameter	-
Access	ro
Mappable	Yes
Range	INTEGER16
Default value	-

### 7.2.4 Objeto 6044h – vl Control Effort

It indicates the speed value according to the measured at the motor, in rpm. For the control modes without feedback, this object has the same value as the object 6043h.

Index	6044h
Name	vl control effort
Object	VAR
Type	INTEGER16
Used parameter	P0681
Access	ro
Mappable	Yes
Range	INTEGER16
Default value	-

**7.2.5 Objeto 6046h – vl Velocity Min Max Amount**

It allows programming the value of the minimum and the maximum speed for the inverter. Only positive values are accepted, however the programmed values are also valid for the reverse speed direction. The values are written in rpm.

Index	6046h
Name	vl velocity min max amount
Object	ARRAY
Type	UNSIGNED32
Used parameter	P0133, P0134

Sub-index	0
Description	Number of the last sub-index
Access	ro
Mappable	No
Range	2
Default value	2

Sub-index	1
Description	vl velocity min amount
Access	rw
Mappable	Yes
Range	UNSIGNED32
Default value	-

Sub-index	2
Description	vl velocity max amount
Access	rw
Mappable	Yes
Range	UNSIGNED32
Default value	-

**7.2.6 Objeto 6048h – vl Velocity Acceleration**

It allows programming the inverter acceleration ramp.

Index	6048h
Name	vl velocity acceleration
Object	RECORD
Type	VI velocity acceleration deceleration record
Used parameter	P100

Sub-index	0
Description	Number of the last sub-index
Access	ro
Mappable	No
Range	2
Default value	2

Sub-index	1
Description	Delta speed
Access	rw
Mappable	Yes
Range	UNSIGNED32
Default value	-

Sub-index	2
Description	Delta time
Access	rw
Mappable	Yes
Range	UNSIGNED32
Default value	-

The acceleration value is calculated dividing the speed programmed at the sub-index 1 by the time programmed at the sub-index 2. The programmed values must respect the parameter P0100 allowed value range.



### 7.2.7 Objeto 6049h – vl Velocity Deceleration

It allows programming the inverter deceleration ramp.

Index	6049h
Name	vl velocity deceleration
Object	RECORD
Type	VI velocity acceleration deceleration record
Used parameter	P100

Sub-index	0
Description	Number of the last sub-index
Access	ro
Mappable	No
Range	2
Default value	2

Sub-index	1
Description	Delta speed
Access	rw
Mappable	Yes
Range	UNSIGNED32
Default value	-

Sub-index	2
Description	Delta time
Access	rw
Mappable	Yes
Range	UNSIGNED32
Default value	-

The deceleration value is calculated dividing the speed programmed at the sub-index 1 by the time programmed at the sub-index 2. The programmed values must respect the parameter P0101 allowed value range.

## 7.3 POSITION CONTROL FUNCTION – OBJECTS FOR POSITION CONTROL

Objects were available for this function in the drive even it not supports the operation mode.

### 7.3.1 Objeto 6063h – Position actual value

It informs the encoder pulse counter value. This counter is valid only if the inverter has the accessory for the interface with the encoder. This object value is increased until reaching the encoder number of pulses, being reset when reaching this value.

Index	6063h
Name	Position actual value
Object	VAR
Type	INTEGER32
Used parameter	P0039

Sub-index	ro
Description	Yes
Access	0 up to the encoder number of pulses minus 1
Mappable	-
Range	
Default value	

In order to get more information on this function operation, refer to the parameters P0039, P0191 and P0405 in the frequency inverter CFW700 programming manual.

## 8 FAULTS AND ALARMS RELATED TO THE CANOPEN COMMUNICATION

### A133/F233 – CAN INTERFACE WITHOUT POWER SUPPLY

**Description:**

It indicates that the CAN interface does not have power supply between the pins 1 and 5 of the connector.

**Actuation:**

In order that it be possible to send and receive telegrams through the CAN interface, it is necessary to supply external power to the interface circuit.

If the CAN interface is connected to the power supply and the absence of power is detected, the alarm A133 – or the fault F233, depending on the P0313 programming, will be signaled through the HMI. If the circuit power supply is reestablished, the CAN communication will be reinitiated. In case of alarms, the alarm indication will also be removed from the HMI.

**Possible Causes/Correction:**

- Measure the voltage between the pins 1 and 5 of the CAN interface connector.
- Verify if the power supply cables have not been changed or inverted.
- Make sure there is no contact problem in the cable or in the CAN interface connector.

### A134/F234 – BUS OFF

**Description:**

The *bus off* error in the CAN interface has been detected.

**Actuation:**

If the number of reception or transmission errors detected by the CAN interface is too high<sup>8</sup>, the CAN controller can be taken to the *bus off* state, where it interrupts the communication and disables the CAN interface.

In this case the alarm A134 – or the fault F234, depending on the P0313 programming, will be signaled through the HMI. In order that the communication be reestablished, it will be necessary to cycle the power of the product, or remove the power supply from the CAN interface and apply it again, so that the communication be reinitiated.

**Possible Causes/Correction:**

- Verify if there is any short-circuit between the CAN circuit transmission cables.
- Verify if the cables have not been changed or inverted.
- Verify if all the network devices use the same baud rate.
- Verify if termination resistors with the correct values were installed only at the extremes of the main bus.
- Verify if the CAN network installation was carried out in proper manner.

### A135/F235 – NODE GUARDING/HEARTBEAT

**Description:**

The CANopen communication error control detected a communication error by using the guarding mechanism.

**Operation:**

By using the error control mechanisms – Node Guarding or Heartbeat – the master and the slave can exchange periodic telegrams, with a predetermined period. If the communication is interrupted by some reason, the master, as well as the slave, will be able to detect communication error through the timeout in the exchange of those messages.

<sup>8</sup> For more information on the error detection, refer to the CAN specification.

In this case the alarm A135 or the fault F235, depending on the P0313 programming, will be signaled through the HMI. In case of alarms, the alarm indication will be removed from the HMI if this error control is enabled again.

**Possible Causes/Correction:**

- Verify the times programmed in both master and slave, for the message exchanging. In order to avoid problems due to transmission delays and differences in the time counting, it is recommended that the values programmed for message exchanging in the master be a little bit shorter than the times programmed for the error detection by the slave.
- Verify if the master is sending the *guarding* telegrams in the programmed time.
- Verify communication problems that can cause telegram losses or transmission delays.



WEG Equipamentos Elétricos S.A.  
Jaraguá do Sul - SC - Brazil  
Phone 55 (47) 3276-4000 - Fax 55 (47) 3276-4020  
São Paulo - SP - Brazil  
Phone 55 (11) 5053-2300 - Fax 55 (11) 5052-4212  
automacao@weg.net  
[www.weg.net](http://www.weg.net)