


SoftPLC

SSW7000

User's Manual





SoftPLC User's Manual

Series: SSW7000

Language: English

Document no.: 10001038374 / 01

Publication date: 10/2011

Revision	Description	Chapter
01	First edition	-

Contents

- 1 ABOUT THE MANUAL.....6
 - 1.1 ABBREVIATIONS AND DEFINITIONS..... 6
 - 1.2 NUMERICAL REPRESENTATION 6
- 2 INTRODUCTION TO THE SOFTPLC.....7
 - 2.1 SYMBOLS AND DATA TYPES 7
- 3 SOFTPLC MEMORY8
 - 3.1 MEMORY DIVISION..... 8
 - 3.2 DATA MEMORY..... 8
 - 3.2.1 **CONSTANTS**8
 - 3.2.2 PHYSICAL INPUTS AND OUTPUTS (HARDWARE).....8
 - 3.2.3 VOLATILE MARKERS (VARIABLES)9
 - 3.2.4 SYSTEM MARKERS..... 10
 - 3.2.5 PARAMETERS 12
 - 3.3 **MODBUS**12
 - 3.3.1 SOFTPLC ADDRESSES IN THE MODBUS PROTOCOL..... 12
 - 3.3.2 PROTOCOL..... 12
- 4 SUMMARY OF THE FUNCTION BLOCKS 13
 - 4.1 **CONTACTS** 13
 - 4.1.1 NORMALLY OPEN CONTACT – NO CONTACT 13
 - 4.1.2 NORMALLY CLOSED CONTACT – NC CONTACT 13
 - 4.1.3 AND LOGIC WITH CONTACTS 13
 - 4.1.4 OR LOGIC WITH CONTACTS 14
 - 4.2 **COILS**..... 14
 - 4.2.1 NORMAL COIL – COIL..... 14
 - 4.2.2 NEGATED COIL – NEG COIL..... 14
 - 4.2.3 SET COIL – SET COIL 14
 - 4.2.4 RESET COIL – RESET COIL 14
 - 4.2.5 POSITIVE TRANSITION COIL – PTS COIL..... 15
 - 4.2.6 NEGATIVE TRANSITION COIL – NTS COIL 15
 - 4.3 **PLC BLOCKS**..... 15
 - 4.3.1 TIMER – TON 15
 - 4.3.2 REAL TIME CLOCK – RTC..... 15
 - 4.3.3 INCREMENTAL COUNTER – CTU 16
 - 4.3.4 PROPORTIONAL-INTEGRAL-DERIVATIVE CONTROLLER – PID 16
 - 4.3.5 LOW-PASS OR HIGH-PASS FILTER – FILTER..... 16
 - 4.4 **CALCULATION BLOCKS** 17
 - 4.4.1 COMPARATOR – COMP 17
 - 4.4.2 MATHEMATICAL OPERATION – MATH..... 17
 - 4.4.3 MATHEMATICAL FUNCTION – FUNC 18
 - 4.4.4 SATURATOR – SAT 18
 - 4.5 **TRANSFER BLOCKS** 19
 - 4.5.1 DATA TRANSFER – TRANSFER..... 19
 - 4.5.2 CONVERSION FROM INTEGER (16 BIT) TO FLOATING POINT – INT2FL..... 19
 - 4.5.3 USER FAULT OR ALARM GENERATOR – USERERR..... 19
 - 4.5.4 CONVERSION FROM FLOATING POINT TO INTEGER (16 BIT) – FL2INT 20
 - 4.5.5 INDIRECT DATA TRANSFER – IDATA 20
 - 4.5.6 MULTIPLEXER – MUX 20
 - 4.5.7 DEMULTIPLEXER – DMUX 21

5	SOFT-STARTER PARAMETER SETTINGS.....	22
5.1	SIMBOLS FOR PROPERTIES DESCRIPTION	22
5.2	SSW CONFIGURATION PARAMETERS	22
	P0220 – LOCAL/REMOTE MODE SELECTION.....	22
	P0229 – SOURCE COMMAND SELECTION IN LOCAL MODE.....	22
	P0230 – SOURCE COMMAND SELECTION IN REMOTE MODE.....	22
	P0251 – AO1 FUNCTION	22
	P0254 – AO2 FUNCTION	22
	P0275 – DO1 FUNCTION.....	22
	P0276 – DO2 FUNCTION.....	22
	P0277 – DO3 FUNCTION.....	22
	P0560 – TRACE AVAILABLE MEMORY	22
5.3	SOFTPLC EXCLUSIVE PARAMETERS.....	22
	P1000 – SOFTPLC STATUS	22
	P1001 – SOFTPLC CONTROL	23
	P1002 – SCAN CYCLE TIME	23
	P1010 TO P1059 – SOFTPLC PARAMETERS.....	23
6	SUMMARY OF THE WLP MAIN FUNCTIONS	24
6.1	PROJECT – NEW	24
6.2	PROJECT – OPEN	24
6.3	PROJECT – PROPERTIES.....	24
6.4	VIEW – COMPILATION INFORMATION	25
6.5	VIEW – USER PARAMETER CONFIGURATION	25
6.6	CONSTRUCT – COMPILE	26
6.7	COMMUNICATION – CONFIGURATION.....	26
6.8	COMMUNICATION – DOWNLOAD	27
6.9	COMMUNICATION – UPLOAD.....	27
7	FAULTS, ALARMS AND POSSIBLE CAUSES	28

1 ABOUT THE MANUAL

This manual provides the necessary description for the operation of the SSW7000 soft-starter using the user programming module denominated SoftPLC. This manual must be used together with the SSW7000 Soft-Starter User's Manual and with the WLP Software Manual.

1.1 ABBREVIATIONS AND DEFINITIONS

PLC: Programmable Logic Controller.
CRC: Cycling Redundancy Check.
RAM: Random Access Memory.
WLP: Ladder Language Programming Software.
USB: Universal Serial Bus.

1.2 NUMERICAL REPRESENTATION

Decimal numbers are represented by means of digits without suffix. Hexadecimal numbers are represented with the letter 'h' after the number.

2 INTRODUCTION TO THE SOFTPLC

The SoftPLC is a feature that incorporates to the SSW the functionalities of a PLC, adding flexibility to the product and allowing the user to develop applicative software (user programs).

The SoftPLC main features are:

- Ladder language programming, by using the WLP software.
- Access to all the SSW parameters and I/Os.
- 50 configurable user parameters.
- PLC, mathematical and control blocks.
- Applicative software transfer and on-line monitoring via USB.
- Transfer of the installed applicative software to the PC conditioned to a password.
- Storage of the applicative software in the FLASH memory board.
- Execution directly in the RAM memory.

2.1 SYMBOLS AND DATA TYPES

%KW	word type constants (16 bits).
%KF	float type constants (32 bits, floating point).
%MX	bit marker.
%MW	word marker (16 bits).
%MF	float marker (32 bits, floating point).
%SX	system bit marker.
%SW	system word marker (16 bits).
%IX	digital inputs.
%IW	analog inputs (16 bits).
%QX	digital outputs.
%QW	analog outputs (16 bits).

3 SOFTPLC MEMORY

The total size of the SoftPLC memory is 15360 bytes, divided between program memory and data memory. This amount can be reduced depending on the Trace function use.

3.1 MEMORY DIVISION

- Trace function: $15360 \times \frac{P0560}{100}$
- SoftPLC function: $15360 \times \frac{100 - P0560}{100}$


NOTE!

P0560 = "Trace Memory", given in percentage. 100.0% is equal to 15360 bytes.

3.2 DATA MEMORY

In the SoftPLC, the data memory area (user variables) is shared with the program memory area. Therefore, the total size of an applicative may vary as a function of the number of variables applied by the user.

The bit, word and float markers are allocated according to the **LAST** address used in the applicative, i.e., the higher the last address, the bigger the allocated area. Therefore, it is recommended to use the markers in a **SEQUENTIAL** manner.

The word and float constants do also use the program memory area.

3.2.1 Constants

Table 3.1 - Constant Memory Map

Sym.	Description	Bytes
%KW	Word Constants (16 bits)	It depends on the quantity of different word constants. E.g.: If there were used: - %KW: 327 = 2 bytes - %KW: 5; 67 = 4 bytes - %KW: 13; 1000; 4 = 6 bytes
%KF	Float Constants (32 bits – IEEE)	It depends on the quantity of different float constants. E.g.: If there were used: - %KF: -0,335 = 4 bytes - %KF: 5,1; 114,2 = 8 bytes - %KF: 0,0; 115,3; 13,333 = 12 bytes

3.2.2 Physical Inputs and Outputs (Hardware)

Table 3.2 - I/O Memory Map

Sym.	Description	Range	Bytes
%IX	Digital inputs	1 ... 6	2
%QX	Digital outputs	1 ... 3	2
%IW	Analog inputs	1 ... 2	4
%QW	Analog outputs	1 ... 2	4


NOTE!

The analog input (%IW) and analog output (%QW) values, respectively read and written via the SoftPLC, respect their gains (P0232, P0237: %IW1–%IW2 and P0252, P0255: %QW1–%QW2) and offsets (P0234, P0239: %IW1–%IW2).


NOTE!

The values read or written via SoftPLC obey the following rules, respecting the parameters related to the analog input and output signal types (P0233, P0238: %IW1–%IW2 and P0253, P0256: %QW1–%QW2):

- Option: 0 to 10 V/20 mA
 - 0 V or 0 mA = 0
 - 10 V or 20 mA = 32767
- Option: 4 to 20 mA
 - 4 mA = 0
 - 20 mA = 32767
- Option: 10 V/20 mA to 0
 - 10 V or 20 mA = 0
 - 0 V or 0 mA = 32767
- Option: 20 to 4 mA
 - 20 mA = 0
 - 4 mA = 32767
- Option: -10 to +10 V
 - 10 V = -32768 (or 32768 for a parameter without sign)
 - 5 V = -16384 (or 49152 for a parameter without sign)
 - 0 = 0
 - +10 V = 32767
- Option: 20 to 0 mA
 - 20 mA = 0
 - 0 mA = 32767

3.2.3 Volatile Markers (Variables)

They consist of variables that can be applied by the user to execute the applicative logics. They can be bit markers (1 bit), word markers (16 bit) or float markers (32 bit – IEEE).

Table 3.3 – Volatile Marker Memory Map

Sym.	Description	Range	Quantity of allocated bytes
%MX	Bit markers	5000 ... 6099	It depends on the last used marker. They are organized in byte pairs. E.g.: - last marker: %MX5000 = 2 bytes - last marker: %MX5014 = 2 bytes - last marker: %MX5016 = 4 bytes - last marker: %MX5039 = 6 bytes
%MW	Word markers	8000 ... 8199	It depends on the last used marker. E.g.: - last marker: %MX8000 = 2 bytes - last marker: %MX8001 = 4 bytes - last marker: %MX8007 = 16 bytes
%MF	Float markers	9000 ... 9199	It depends on the last used marker. E.g.: - last marker: %MX9000 = 4 bytes - last marker: %MX9001 = 8 bytes - last marker: %MX9007 = 32 bytes


NOTE!

In order to minimize the applicative size, use the markers in a sequential manner.

E.g.:

- Bit markers: %MX5000, %MX5001, %MX5002.
- Word markers: %MW8000, %MW8001, %MW8002.
- Float markers: %MF9000, %MF9001, %MF9002.

3.2.4 System Markers

They consist of special variables that allow the user to read and change soft-starter data that may or may not be available in the parameters. They can be: system bit markers (1 bit) or system word markers (16 bits).

Table 3.4.a - Memory Map for the Odd System Bits

Sym.	Description	Range	Bytes
Type	System bits	3000 ... 3040	4 bytes
%SX	Writing/Command (odd)		
	3001	Start/Stop	0: It stops the motor. 1: It starts the motor.
	3003	General Enable	0: It disables the soft-starter, interrupting the supply for the motor. 1: It enables the soft-starter allowing the motor operation.
	3005	JOG	0: It disables the JOG function. 1: It enables the JOG function.
	3007	Rotation Direction	0: It runs the motor in the forward direction. 1: It runs the motor in the reverse direction.
	3009	LOC/REM	0: The soft-starter goes to the LOCAL situation. 1: The soft-starter goes to the REMOTE situation.
	3011	Fault Reset	0: No function. 1: If in a fault condition, it executes the SSW reset. NOTE: When this command is executed the SSW and the SoftPLC applicative are reinitialized. This is also valid for the reset via HMI.

Table 3.4.b - Memory Map for the Even System Bits

Sym.	Description	Range	Bytes
Type	System bits	3000 ... 3040	4 bytes
%SX	Reading/Status (even)		
3000	Running Motor		0: The motor is stopped. 1: The motor is running, executing either the acceleration or the deceleration ramp, or braking.
3002	General Enabled		0: It is general disabled. 1: It is enabled and ready to run the motor.
3004	JOG		0: The JOG function is inactive. 1: The JOG function is active.
3006	In Acceleration		0: It is not executing the acceleration ramp. 1: It is executing the acceleration ramp.
3008	P0831 Time		0: It is not in the interval after stopping. 1: It is in the interval after stopping.
3010	Full Voltage		0: The motor is not with full voltage. 1: The motor is with full voltage.
3012	Alarm Condition		0: It is not in alarm condition. 1: It is in alarm condition. Note: The alarm number can be read by means of the parameter P0021 - Present Alarm.
3014	In Deceleration		0: It is not executing the deceleration ramp. 1: It is executing the deceleration ramp.
3016	In Remote		0: It is in Local mode. 1: It is in Remote mode.
3018	Braking		0: It is not braking. 1: It is braking.
3020	Changing the rotation direction		0: It is not executing the rotation direction change. 1: It is executing the rotation direction change.
3022	In Reverse		0: The motor is running in the forward direction. 1: The motor is running in the reverse direction.
3024	Closed By-pass		0: The by-pass is not closed. 1: The by-pass is closed.
3026	In Configuration Mode		0: The SSW is operating normally. 1: The SSW is in configuration mode. It indicates a special condition during which the soft-starter cannot be enabled: <ul style="list-style-type: none"> ■ Executing the oriented start-up routine. ■ Executing the HMI copy function. ■ Waiting for the communication between the two control boards. ■ There is a parameter setting incompatibility. Note: It is possible to obtain the exact description of the special operation mode at the parameter P0692.
3028	With power section supply		0: There is no voltage at the power section. 1: The three phases are powered up.
3030	Fault condition		0: It is not in a fault condition. 1: It is in fault condition.
3032	Start key (1)		0: Not pressed. 1: Pressed during 1 scan cycle.
3034	Stop key (0)		
3036	Rotation Direction key (↻)		
3038	Local/Remote key		
3040	JOG key		
			0: Not pressed. 1: Pressed.

3.2.5 Parameters

Parameters P1001 to P1059 do only appear on the SSW HMI when there is a valid applicative (user program) in the memory, i.e., P1000 > 0.

Table 3.6 - Memory Map of the Parameters

Sym.	Description	Range	Bytes	
%PW	System parameters (refer to the SSW7000 Programming Manual)	0... 999		
	SoftPLC Parameters	1000 ... 1059	6 bytes	
	P1000: SoftPLC Status [Read-only parameter]	0: No Applicative 1: Installing Applicative 2: Incompatible Applicative. 3: Stopped Applicative 4: Running Applicative		
	P1001: SoftPLC Control	0: Stop Applicative 1: Run Applicative 2: Delete Applicative		
	P1002: Scan Cycle Time [ms] [Read-only parameter]			
%UW	User Parameters	1010 ... 1059	100 bytes	

3.3 MODBUS

3.3.1 SoftPLC Addresses in the Modbus protocol

Table 3.7 – SoftPLC x Modbus Addresses Range

Sym.	Description	SoftPLC	Modbus
%IX	Digital inputs	1 ... 6	2201...2206
%QX	Digital outputs	1 ... 3	2401...2403
%IW	Analog inputs	1 ... 2	2601...2602
%QW	Analog outputs	1 ... 2	2801...2802



NOTE!

All the other data types have user addresses (SoftPLC) equal to the Modbus addresses. E.g., %PW100 = Modbus address 100; %MX5000 = Modbus address 5000; %SW3308 = Modbus address 3308.

3.3.2 Protocol

Refer to Modbus protocol chapter in the SSW7000 Modbus RTU User's Manual.

4 SUMMARY OF THE FUNCTION BLOCKS

A summary of the function blocks that are available for the user programming will be presented in this chapter.


4.1 CONTACTS

They send to the stack the content of a programmed data (0 or 1), which may be of the type:

- %MX: Bit Marker.
- %IX: Digital Input.
- %QX: Digital Output.
- %UW: User Parameter.
- %SX: System Bit Marker – Reading.

4.1.1 Normally Open Contact – NO CONTACT

%MX5000




Menu: Insert - Contacts - NO CONTACT.

E.g.: It sends to the stack the content of the bit marker 5000.

4.1.2 Normally Closed Contact – NC CONTACT

%QX1



Menu: Insert - Contacts - NC CONTACT.

E.g.: It sends to the stack the negated content of the digital output 1.

4.1.3 AND Logic with Contacts

When the contacts are in series, an AND logic is executed among them, storing the result in the stack. Examples:

Example	Truth Table		
	%IX1	%IX2	Stack
<div style="display: flex; justify-content: space-around; align-items: center;"> %IX1 %IX2</div> <div style="text-align: center; margin-top: 5px;">%IX1.%IX2</div>	0	0	0
	0	1	0
	1	0	0
	1	1	1
<div style="display: flex; justify-content: space-around; align-items: center;"> %UW1010 %QX1</div> <div style="text-align: center; margin-top: 5px;">%UW1010. (~%QX1)</div>	%UW1010	%QX1	Stack
	0	0	0
	0	1	0
	1	0	1
1	1	0	

4.1.4 OR Logic with Contacts

When the contacts are in parallel, an OR logic is executed among them, storing the result in the stack. Examples:

Example	Operation	Truth Table		
		%IX1	%IX2	Stack
	$%IX1 + %IX2$	0	0	0
		0	1	1
		1	0	1
		1	1	1
Example	Operation	Truth Table		
		%UW1010	%QX1	Stack
	$%UW1010 + (~%QX1)$	0	0	1
		0	1	0
		1	0	1
		1	1	1

4.2 COILS

They save the stack content (0 or 1) in the programmed element:

- %MX: Bit Marker.
- %QX: Digital Output.
- %UW: User Parameter.
- %SX: System Bit Marker – Writing.

It is allowed to add coils in parallel at the last column.

4.2.1 Normal Coil – COIL

%MX5001
Menu: Insert - Coils - COIL
 E.g.: It sets the bit marker 5001 with the stack content.

4.2.2 Negated Coil – NEG COIL

%QX2
Menu: Insert - Coils - NEG COIL
 E.g.: It sets the digital output 2 with the negated content of the stack.


4.2.3 Set Coil – SET COIL

%UW1011
Menu: Insert - Coils - SET COIL
 E.g.: It sets the user parameter P1011, provided that the content of the stack is not 0.


4.2.4 Reset Coil – RESET COIL

%UW1011
Menu: Insert - Coils - RESET COIL
 E.g.: It resets the user parameter P1011, provided that the content of the stack is not 0.

4.2.5 Positive Transition Coil – PTS COIL


%MX5002 **Menu:** Insert - Coils - PTS COIL
 E.g.: It sets the bit marker 5002 during 1 scan cycle, provided that a transition from 0 to 1 in the stack is detected.

4.2.6 Negative Transition Coil – NTS COIL

%SX3011 **Menu:** Insert - Coils - NTS COIL
 E.g.: It sets the system bit marker 3011 during 1 scan cycle, provided that a transition from 1 to 0 in the stack is detected.

4.3 PLC BLOCKS


4.3.1 Timer – TON



Menu: Insert - Function Blocks - PLC - TON
Input: IN: Enables the block
Output: Q: Goes to 1 when IN ≠ 0 and ET ≥ PT
Properties: PT: Programmed Time (Preset Time)
 ET: Elapsed Time

In the example above, if the IN input is active and the content of the word marker 8000 is higher or equal than the content of the user parameter P1010, the output Q is set.


4.3.2 Real Time Clock – RTC



Menu: Insert - Function Blocks - PLC - RTC
Input: EN: Enables the block
Output: Q: Goes to 1 when IN ≠ 0 and the current time is posterior to the turning on time and anterior to the turning off time.
Properties: WEEK: Days of the week
 H-T.ON: Turning on hour
 M-T.ON: Turning on minute
 S-T.ON: Turning on second
 H-T.OFF: Turning off hour
 M-T.OFF: Turning off minute
 S-T.OFF: Turning off second
 Q_OPT: 0: normal Q output, 1: inverted Q output
 ONERROR: 0: Generates A700 alarm, 1: Generates F701 fault
 ERROR: It goes to 1 when there is an error in the block.

In the example above, if the EN input is active, the output Q is set every day from Monday through Friday between 7:30 and 9:00.


4.3.3 Incremental Counter – CTU



- Menu:** Insert - Function Blocks - PLC - CTU
- Inputs:**
 - CU: Captures the transitions from 0 to 1 at this input (Counter Up)
 - R: Resets CV
- Output:**
 - Q: Goes to 1 when $CV \geq PV$
- Properties:**
 - PV: Programmed Value (Preset Value)
 - CV: Counter Value

In the example above, if the content of the word marker 8001 is higher or equal than 20, the output Q is set.


4.3.4 Proportional-Integral-Derivative Controller – PID



- Menu:** Insert - Function Blocks - PLC - PID
- Inputs:**
 - EN: Enables the block
- Output:**
 - ENO: EN input image
- Properties:**
 - TS: Sampling Time
 - SELREF: Automatic/manual reference
 - REF: Automatic reference
 - δREF: Automatic reference filter time constant
 - REFMANUAL: Manual reference
 - FEEDBACK: Process feedback
 - KP: Proportional gain
 - KI: Integral gain
 - KD: Derivative gain
 - MAX: Maximum output value
 - MIN: Minimum output value
 - TYPE: Academic/parallel
 - OPT: Direct/reverse
 - OUT: Controller output

In the example above, if the EN input is active, the controller starts its operation. The content of the user parameter P1010 selects the reference that is active, i.e., whether it is the float marker 9001 (automatic reference) or the 9003 (manual reference). There is a 0.05s filter for the automatic reference. Since the derivative gain is fixed in 0, this indicates that the PID was converted into a PI. The control output OUT, represented by the float marker 9004, has the maximum and minimum limits of 100 and -100.

4.3.5 Low-Pass or High-Pass Filter – FILTER




- Menu:** Insert - Function Blocks - PLC - FILTER
- Inputs:**
 - EN: Enables the block
- Output:**
 - ENO: EN input image
- Properties:**
 - TS: Sampling Time
 - IN: Input data
 - TIMECONST: Filter time constant
 - TYPE: Low-pass/High-pass
 - OUT: Input data filtered value

In the example above, if the EN input is active, the content of the float marker 9000 will be filtered with a time constant of 0.25s by means of a low-pass filter and will be transferred to the float marker 9001.

4.4 CALCULATION BLOCKS

4.4.1 Comparator – COMP



Menu: Insert - Function Blocks – Calculation - COMP

Input:

EN: Enables the block

Output:

ENO: Goes to 1 when the comparison condition is fulfilled

Properties:

FORMAT: Integer or floating point

DATA 1: Comparison data 1

OPERATOR: Comparison operator

DATA 2: Comparison data 2


In the example above, if the EN input is active and the content of the float marker 9000 is higher than the content of the float marker 9001, then the output ENO is set.



NOTE!

If the FORMAT is integer, all the numeric data are considered words of 15 bits + sign (-32768 to 32767).

4.4.2 Mathematical Operation – MATH



Menu: Insert - Function Blocks - Calculation - MATH

Input:

EN: Enables the block

Output:

ENO: Indicates whether the calculation has been executed

Properties:

FORMAT: Integer or floating point

DATA1: Calculation data 1. It may also appear as DATA1H and DATA1L (representing the high and low parts of the data 1)

OPERATOR: Mathematic operator (+, -, *, etc)

DATA2: Calculation data 2. It may also appear as DATA2H and DATA2L (representing the high and low parts of the data 2)

RES: Calculation result. It may also appear as RESH and RESL (representing the high and low parts of the result) and also as QUOC and REM (representing the quotient and the remainder of a division)

OVER: Indicates whether the result exceeded its limit

SIGNAL: Result sign


In the example above, if the EN input is active, the value of the word marker 8000 is incremented at each scan cycle. When the bit marker 5000 goes to 1, it indicates overflow and the word marker 8000 remains in 32767.



NOTE!

If the FORMAT is integer, all the numeric data are considered words of 15 bits + sign (-32768 to 32767).

4.4.3 Mathematical Function – FUNC



Menu: Insert - Function Blocks - Calculation - FUNC

Input:

EN: Enables the block

Output:

ENO: Indicates whether the calculation has been executed

Properties:

FORMAT: Integer or floating point

IN: Data to be calculated

FUNCTION: Mathematic function (sin, cos, etc)

OUT: Calculation result


In the example above, if the EN input is active, the float marker 9001 presents the result of the float marker 9000 sine calculation.



NOTE!

If the FORMAT is integer, all the numeric data are considered words of 15 bits + sign (-32768 to 32767).

4.4.4 Saturator – SAT



Menu: Insert - Function Blocks - Calculation - SAT

Input:

EN: Enables the block

Output:

ENO: Indicates whether saturation has occurred, provided that EN ≠ 0

Properties:

FORMAT: Integer or floating point

IN: Input data

MAX: Maximum allowed value

MIN: Minimum allowed value

OUT: Output data

In the example above, when the EN input is active, the word marker 8000 contains the user parameter P1010 value, limited however, between the maximum of 100 and the minimum of -100.



NOTE!

If the FORMAT is integer, all the numeric data are considered words of 15 bits + sign (-32768 to 32767).



NOTE!

If the MIN value is higher than the MAX value, the outputs OUT and ENO are zeroed.

4.5 TRANSFER BLOCKS


4.5.1 Data Transfer – TRANSFER



Menu: Insert - Function Blocks - Transfer - TRANSFER
Input:
 EN: Enables the block
Output:
 ENO: Indicates that the transfer has been done
Properties:
 SRC: Source data
 DST: Destination data

In the example above, if the EN input is active, the word constant 1 is transferred to the system bit marker 3001 (general enable).

4.5.2 Conversion from Integer (16 bit) to Floating Point – INT2FL



Menu: Insert - Function Blocks - Transfer - INT2FL
Input:
 EN: Enables the block
Output:
 ENO: Indicates that the transfer has been done
Properties:
 INT: Integer data
 FLOAT: Data converted into floating point


In the example above, if the EN input is active, the content of the word marker 8153 (taking into account its sign) is converted into floating point to the float marker 9005.



NOTE!

INT is treated as a word of 15 bits + sign (-32768 to 32767).

4.5.3 User Fault or Alarm Generator – USERERR



Menu: Insert - Function Blocks - Transfer - USERERR
Input:
 EN: Enables the block
Output:
 ENO: Indicates 1 when EN = 1 and the alarm or the fault was actually generated.
Properties:
 CODE: Alarm or fault code
 TYPE: 0: Generates alarm, 1: Generates fault
 TEXTL1: HMI line 1 text
 TEXTL2: HMI line 2 text


In the example above, if the EN input is active, A750 will appear with the “Low pressure” text on the HMI.



NOTE!

If this block is configured as Fault, it is necessary to reset the soft-starter to remove the text from the HMI and be able to enable it again.

4.5.4 Conversion from Floating Point to Integer (16 bit) – FL2INT




Menu: Insert - Function Blocks - Transfer - FL2INT
Input:
 EN: Enables the block
Output:
 ENO: Indicates that the transfer has been done
Properties:
 FLOAT: Floating point data
 INT: Data converted into integer

In the example above, if the EN input is active, the float constant 4.54×10^4 is converted into an integer with sign via the word marker 8000. However, after the conversion, the word marker 8000 will remain with the value of 32767, because this is the positive limit of a word.

NOTE! INT is treated as a word of 15 bits + sign (-32768 to 32767).


4.5.5 Indirect Data Transfer – IDATA



Menu: Insert - Function Blocks - Transfer - IDATA.
Input:
 EN: Enables the block.
Output:
 ENO: Indicates that the transfer has been done.
Properties:
 CMD: Read/Write command
 DATATYPE: Data type
 ADDRESS: User address
 VALUE: Read content/Value to be written

In the example above, if the EN input is active, the content of the bit marker 5000 is written to the digital output whose address is the content of the word marker 8000.


4.5.6 Multiplexer – MUX



Menu: Insert - Function Blocks - Transfer - MUX
Input:
 EN: Enables the mathematic operation
Output:
 ENO: Indicates that the transfer has been done
Properties:
 X0-X15: Binary data vector
 W: Resulting word

In the example above, when the EN input is active, the digital inputs 1, 2 and 3 transfer their content to the bits 0, 1 and 2 of the user parameter P1010.

4.5.7 Demultiplexer – DMUX



Menu: Insert - Function Blocks - Transfer - DMUX
Input:
 EN: Enables the mathematic operation
Output:
 ENO: Indicates that the transfer has been done
Properties:
 W: Source word
 X0-X15: Resulting binary data vector

In the example above, when the EN input is active, the bits 1, 2, 5, 6, 11, 13 and 15 of the word marker 8000 are transferred respectively to the bit markers 5001, 5002, 5005, 5006, 5011, 5013 and 5015.

5 SOFT-STARTER PARAMETER SETTINGS

Next, only the SSW soft-starter parameters related to the SoftPLC will be presented.

5.1 SIMBOLS FOR PROPERTIES DESCRIPTION

- RO:** Read-only parameter.
- CFG:** Parameter that can be changed only with a stopped motor.
- Net:** Parameter visible on the HMI if the soft-starter has a network interface installed – RS232, RS485, CAN, Anybus-CC, Profibus – or if the USB interface is connected.
- Serial:** Serial Parameters visible on the HMI if the soft-starter has the RS232 or the RS485 interface installed.
- USB:** Parameters visible on the HMI if the soft-starter USB interface is connected.

5.2 SSW CONFIGURATION PARAMETERS

P0220 – LOCAL/REMOTE Mode Selection

P0229 – Source Command Selection in LOCAL Mode

P0230 – Source Command Selection in REMOTE Mode

P0251 – AO1 Function

P0254 – AO2 Function

P0275 – DO1 Function

P0276 – DO2 Function

P0277 – DO3 Function

P0560 – Trace Available Memory



NOTE!

For further information, refer to the SSW7000 Soft-Starter Programming Manual.

5.3 SOFTPLC EXCLUSIVE PARAMETERS

P1000 – SoftPLC Status

Adjustable	0 = No Applicative	Factory Setting: -
Range:	1 = Installing Applicative	
	2 = Incompatible Applicative	
	3 = Stopped Applicative	
	4 = Running Applicative	

Properties: RO

Access groups via HMI: 01 PARAMETER GROUPS
 L 34 SoftPLC

Description:

It allows the user to visualize the SoftPLC status. If there is no installed applicative, the parameters from P1001 to P1059 will not be showed on the HMI.

If this parameter presents the option 2 (Incompatible App.), it indicates that the version that has been loaded in the flash memory board is not compatible with the current SSW firmware.

In this case, it is necessary to recompile the project in the WLP considering the new SSW version, and to download it again. If this is not possible, the upload of this applicative with the WLP can be done, provided that the applicative password is known or that the password is not enabled.

P1001 – SoftPLC Control

Adjustable 0 = Stop Applicative **Factory Setting:** 0
Range: 1 = Run Applicative
 2 = Delete Applicative

Properties: CFG

Access groups via HMI: 01 PARAMETER GROUPS
 L 34 SoftPLC

Description:

It allows stopping, running or deleting an installed applicative. Therefore, the motor must be disabled.

P1002 – Scan Cycle Time

Adjustable 0 to 65535 ms **Factory Setting:** -
Range:

Properties: RO

Access groups via HMI: 01 PARAMETER GROUPS
 L 34 SoftPLC

Description:

It consists in the applicative scanning time. The bigger the applicative, the longer the scanning time will be.

P1010 to P1059 – SoftPLC Parameters

Adjustable -32768 to 32767 **Factory Setting:** 0
Range:

Properties: CFG

Access groups via HMI: 01 PARAMETER GROUPS
 L 34 SoftPLC

Description:


They consist of parameters with functions defined by the user by means of the WLP software. It is also possible for the user to configure these parameters as described in the section 6.5.

6 SUMMARY OF THE WLP MAIN FUNCTIONS

This chapter brings basic information on the operations performed with the WLP software for the SSW soft-starter programming. Further information can be obtained in the WLP software help.


6.1 PROJECT – NEW

It creates a new project. Besides defining the project name, it is also necessary to configure the equipment and the respective firmware version.




6.2 PROJECT – OPEN

It opens the selected project.




6.3 PROJECT – PROPERTIES

It allows the user to redefine the equipment and the firmware version. In this box it is also configured whether the project will have an upload password.



6.4 VIEW – COMPILATION INFORMATION

It allows the user to know the size in bytes of the compiled applicative (<projectname>.bin) to be sent to the equipment.



6.5 VIEW – USER PARAMETER CONFIGURATION

It opens an attribute visualization window for all the user parameters. With a double click on the parameter, it is possible to configure these attributes, which include:

- Parameter descriptive text on the HMI (up to 21 characters).
- Text for the units (up to 5 characters).
- Maximum and minimum limits.
- Number of decimal positions.
- Hexadecimal or decimal format.
- Writing or read-only.
- Modifications only with a stopped motor, or online.
- With or without sign.
- Ignores the password (allows modification regardless of P0000) or normal.
- Visualizes or hides the parameter.
- Allows saving the parameter value on power down (retentive), when it is used in some blocks (PLC, Calculation and Transfer).
- Configuration parameter that allows modification with the motor running.


These configurations can be transferred to the SSW with the “Download key”.

Configuração dos Parâmetros do Usuário

Parâmetro	Nome	Unidade	Mínimo	Máximo	Casas Decimais	Hexadecimal	Somente Leitura	Motor Parado	Sinal	Ignora Senha	Visualiza na HMI	Retentivo
P1010	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0
P1011	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0
P1012	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0
P1013	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0
P1014	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0
P1015	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0
P1016	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0
P1017	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0
P1018	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0
P1019	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0
P1020	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0
P1021	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0
P1022	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0
P1023	Parametro SoftPLC		0	32767	0	0	0	0	0	0	1	0

6.6 CONSTRUCT – COMPILE

It analyses the applicative and generates the code for the specified equipment.



6.7 COMMUNICATION – CONFIGURATION

The USB port is used with the SSW. Therefore, the USB driver must be installed. The driver is found in the DRIVER_USB folder, inside the WLP V8.XX.




6.8 COMMUNICATION – DOWNLOAD

This command allows downloading the applicative and/or the user parameter configurations to the SSW.



6.9 COMMUNICATION – UPLOAD

This command makes it possible to upload and open the applicative that is installed in the SSW, provided that the password is valid.



7 FAULTS, ALARMS AND POSSIBLE CAUSES

Table 6.1 - Faults, alarms and possible causes

Fault/Alarm	Description	Possible causes
A700: Disconnected HMI	It is the alarm that occurs when the RTC block is active, the "Alarm" option is programmed and the HMI is not connected to the soft-starter.	Verify very the HMI is connected to the soft-starter. Search for unplugged connector, broken cable etc.
F701: Disconnected HMI	It is the fault that occurs when the RTC block is active, the "Fault" option is programmed and the HMI is not connected to the soft-starter.	Verify very the HMI is connected to the soft-starter. Search for unplugged connector, broken cable etc.



WEG Equipamentos Elétricos S.A.
Jaraguá do Sul - SC - Brazil
Phone 55 (47) 3276-4000 - Fax 55 (47) 3276-4020
São Paulo - SP - Brazil
Phone 55 (11) 5053-2300 - Fax 55 (11) 5052-4212
automacao@weg.net
www.weg.net