


Ethernet

SCA06

User's Guide





Ethernet User's Guide

Series: SCA06

Language: English

Document Number: 10004473905 / 00

Build 529

Publication Date: 09/2016

Contents

About the Manual	6
1 Equipment Characteristics in Ethernet Network	7
1.1 Modbus TCP specific characteristics	7
1.2 EtherNet/IP specific characteristics	7
1.3 PROFINET IO specific characteristics	7
2 Ethernet Overview	8
2.1 Ethernet Technology	8
3 Interfaces Description	9
3.1 Ethernet Accessory	9
3.2 Connectors	9
3.3 Indication LEDs	9
4 Network Installation	11
4.1 IP Address	11
4.2 Communication Rate	11
4.3 Cable	11
4.4 Network Topology	12
4.5 Recommendations for Grounding Connection and Cable Routing	13
5 Parameterization	14
5.1 Symbols for the Properties Description	14
P0202 – Operation Mode	14
P0662 – Communication Error Behavior	14
P0800 – Ethernet Module Identification	15
P0801 – Ethernet Communication Status	15
P0803 – Ethernet Baud Rate	16
P0806 – Modbus TCP Watchdog	16
P0810 – IP Address Configuration	16
P0811 – IP Address 1	17
P0812 – IP Address 2	17
P0813 – IP Address 3	17
P0814 – IP Address 4	17
P0815 – Subnet CIDR	17
P0816 – Gateway 1	18
P0817 – Gateway 2	18
P0818 – Gateway 3	18
P0819 – Gateway 4	18
P0820 ... P0831 – Ethernet Read Words #5 ... #16	18
P0835 ... P0846 – Ethernet Write Words #5 ... #16	19
P0849 – Update Ethernet Configuration	20
6 I/O Words with Specific Function	21
6.1 Input Words – (Slave → Master)	21
6.1.1 1 st – Status Word	21
6.1.2 2 nd – Motor Speed	21
6.1.3 3 rd – Torque Current	22

6.1.4	4 th – Present Control Mode	22
6.2	Output Words – (Master → Slave)	22
6.2.1	1 st – Control Word	22
6.2.2	2 nd – Speed Reference	23
6.2.3	3 rd – Torque Reference	23
6.2.4	4 th – Control Mode	23
7	Modbus TCP	24
7.1	Indication LEDs	24
7.2	Available Functions	24
7.3	Memory Map	24
7.3.1	Parameters	24
7.3.2	Memory Markers	25
7.4	Communication Errors	25
7.5	Startup Guide	26
7.5.1	Installing the Ethernet Module	26
7.5.2	Configuring the Drive	26
7.5.3	Configuring the Master	27
7.5.4	Communication Status	27
7.5.5	Operation Using Process Data	27
8	EtherNet/IP	28
8.1	Indication LEDs	28
8.2	Cyclic Data	28
8.3	Acyclic Data	28
8.4	EDS File	28
8.5	Modbus TCP Connections	29
8.6	Startup Guide	29
8.6.1	Installing the Ethernet Module	29
8.6.2	Configuring the Drive	29
8.6.3	Configuring the Master	29
8.6.4	Communication Status	30
8.6.5	Operation Using Process Data	30
9	PROFINET	31
9.1	Indication LEDs	31
9.2	Cyclic Data	31
9.3	Acyclic Data	31
9.4	XML File – GSDML	31
9.5	Modbus TCP Connections	32
9.6	Startup Guide	32
9.6.1	Installing the Ethernet Module	32
9.6.2	Configuring the Drive	32
9.6.3	Configuring the Master	32
9.6.4	Communication Status	33
9.6.5	Operation Using Process Data	33
10	WEB Server	34
11	Faults and Alarms	35
F0047/A0147	- Ethernet Offline	35

F0048/A0148 - Ethernet interface access error 35

ABOUT THE MANUAL

This manual supplies the necessary information for the operation of the SCA06 servo drive using the Ethernet interface. This manual must be used together with the SCA06 user's manual and programming manual.

1 EQUIPMENT CHARACTERISTICS IN ETHERNET NETWORK

Below are listed the main features for Ethernet communication module for SCA06 servo drive.

- There are 3 different accessories, according to the specified communication protocol:
 - ECO5: EtherNet/IP protocol.
 - ECO6: Modbus TCP protocol.
 - ECO7: PROFINET IO protocol.
- The interface follows the Fast Ethernet 100BASE-TX standard.
- It allows communication using the 10 or 100 Mbps rates in half or full duplex mode.
- It has a built-in, two-port Ethernet switch.
- The Ethernet ports work with Auto-MDIX (automatic medium-dependent interface crossover), a technology which automatically detects the type of cable used and configures the connection accordingly, eliminating the need of cross-over cables.
- The interface also makes available a Web server (HTTP).

1.1 MODBUS TCP SPECIFIC CHARACTERISTICS

- Operates as Modbus TCP server.
- The server provides up to 4 simultaneous Modbus TCP connections.
- Allows data communication for equipment operation and parameterization, as well as markers and data used for SCA06 ladder programming.

1.2 ETHERNET/IP SPECIFIC CHARACTERISTICS

- It is supplied with an EDS file for the network master configuration.
- Allows up to 16 input words and 16 output words for cyclic data communication.
- Acyclic data available for parameterization.
- Device Level Ring (DLR) and linear network topology supported.
- It features up to 2 Modbus TCP connections.

1.3 PROFINET IO SPECIFIC CHARACTERISTICS

- It is supplied with a XML file for the network master configuration.
- Allows up to 16 input words and 16 output words for cyclic data communication.
- Acyclic data available for parameterization.
- It features up to 2 Modbus TCP connections.

2 ETHERNET OVERVIEW

Following it is presented general information about the Ethernet technology.

2.1 ETHERNET TECHNOLOGY

Ethernet is a technology for interconnecting local area networks (LAN) based on frames forwarding. It defines wiring and electrical signals for the physical layer, the frame format and protocol for media access control layer (MAC) of the OSI model.


Ethernet, however, mainly defines the physical medium and the frame format. Based on Ethernet, multiple protocols and higher-level services were specified and developed in order to perform desired activities over a network, such as packet routing, connection establishment, sending and receiving files, etc. Several of these protocols have also been widely disseminated and employed, such as IP, TCP, UDP, FTP, HTTP.

Widely used to interconnect computers in the office environment, the Ethernet technology also started being used in industrial environments for interconnection of field devices. For industrial environment also emerged different communication protocols based on Ethernet, among which we can mention Modbus TCP, EtherNet/IP, PROFINET.

3 INTERFACES DESCRIPTION

The SCA06 servo drive uses an accessory to provide a Ethernet interface for communication.

3.1 ETHERNET ACCESSORY



- Supplied items:
 - Installation guide.
 - Ethernet accessory.



NOTE!

There are 3 different accessories, according to the specified communication protocol:

- ECO5: EtherNet/IP protocol.
- ECO6: Modbus TCP protocol.
- ECO7: PROFINET IO protocol.

It is important to use the accessory model according to the desired protocol for application.

3.2 CONNECTORS

The accessory for Ethernet communication has two RJ45 connectors for network connection. The connector pin out follows the Fast Ethernet 100BASE-TX standard, using two pairs of cables for data transmission and reception.

The housings of the Ethernet connectors, which are normally connected to the cable shield, have connections between themselves and to the protective earth via an RC circuit.

3.3 INDICATION LEDS

The Ethernet accessory has an LED indicator on the Ethernet port, and two bi-color status LEDs. These LEDs have the following functions and indications:




Figure 3.1: Ethernet Connectors and LEDs

Table 3.1: Ethernet Indication LEDs

LED	Color	Function
Link	Green	LED for link and activity indication.
Network Status (NS)	Bicolor (Green/Red)	Has a different behavior depending on the communication protocol, which is described in the section for each protocol.

Table 3.2: LED Link

State	Description
Off	No link or powered off.
Green, solid	Link up, no activity.
Green, flashing	Link up and activity.

4 NETWORK INSTALLATION

This chapter presents recommendations related to equipment installation in an Ethernet network.

4.1 IP ADDRESS

Every equipment in an Ethernet network needs an IP address and subnet mask.

The IP addressing is unique in the network, and each equipment must have a different IP. The subnet mask is used to define which IP address range is valid in the network.

The SCA06 servo drive allows the use of two methods for programming these features, programmable via P0810:

- DHCP: enable the configuration of the SCA06 via DHCP server. The DHCP can automatically assign IP addresses, subnet mask, etc. to the devices on the network. The configurations performed via parameters are disregarded.
- Parameters: uses the configurations of IP address, mask and gateway as programmed on equipment parameters.



NOTE!

After changing these properties, for the changes to take effect, the equipment must be turned off and on again, or requesting the Ethernet settings update via P0849.

4.2 COMMUNICATION RATE

The Ethernet interfaces of the SCA06 servo drive can communicate using the 10 or 100 Mbps rates in half or full duplex mode.

The baud rate is programmed at P0803.



NOTE!

- It is important that, for each Ethernet connection made between two points, the baud rate and the duplex mode are set to the same option. If the option AUTO is used in one of the points, you must set the other point also to AUTO, or to half duplex mode.
- For PROFINET IO interface, the baud rate is locked to 100 Mbps as required by the protocol.

4.3 CABLE

Recommended characteristics for the cable:

- Standard Ethernet cable, 100Base-TX (FastEthernet), CAT 5e or higher.
- Shielded cable.
- Maximum length between devices: 100 m.

For installation, it is recommended the use of shielded Ethernet cables specific for use in industrial environment.

4.4 NETWORK TOPOLOGY

To connect SCA06 servo drive in an Ethernet network, usually the star connection is made using an industrial switch.




Figure 4.1: Star topology

It is also possible to make the connection in daisy chain, allowing a topology equivalent to a bus.




Figure 4.2: Daisy chain topology



NOTE!

When the equipment is turned off, the built-in switch is also deactivated, preventing communication with the subsequent equipment.

A switch with support to the redundancy technology enables the use of the ring topology.




Figure 4.3: Ring topology

4.5 RECOMMENDATIONS FOR GROUNDING CONNECTION AND CABLE ROUTING

The correct connection with the ground decreases problems caused by interference in an industrial environment. The following are some recommendations about grounding and cable routing:

- Always use shielded twisted pair Ethernet cables and connectors with metallic housing.
- Connect the equipment grounding via grounding terminal. Avoid the cable connection on multiple grounding points, especially where there are grounds with different potentials.
- Pass signal cables and communication cables in dedicated pathways. Prevent laying these cables next to power cables.

5 PARAMETERIZATION

Next, the SCA06 servo drive parameters related to the Ethernet communication will be presented.

5.1 SYMBOLS FOR THE PROPERTIES DESCRIPTION

- **RO** Read-only parameter
- **RW** Read/write parameter
- **CFG** Parameter that can be changed only with motor stopped.
- **ETH** Parameter visible on the HMI if the product has the Ethernet interface installed

P0202 – OPERATION MODE

Range:	1 = Torque Mode 2 = Speed Mode 3 = No function 4 = Ladder Mode 5 = CANopen/DeviceNet/EtherCAT 6 = Profibus DP/Ethernet	Default: 2
Properties:	RW	

Description:

This parameter defines the operating mode for SCA06 servo drive, allowing to program which mode is desired for the motor control, and what is the control source for the device.

In order to control the equipment via Ethernet network, it's necessary to use mode 6 = Ethernet. In case this mode is programmed, commands and references for the product operation will be provided by cyclic data via Ethernet network.



NOTE!

- The control of equipment using these objects is only possible by selecting the desired option in this parameter, but Ethernet communication can be used in any operating mode.
- The Ethernet interface allows speed and torque control of the SCA06 servo drive. To perform positioning functions, the Ladder operating mode must be used, developing a Ladder application program and using user's parameters as the interface with the network master to control and monitor the equipment.

P0662 – COMMUNICATION ERROR BEHAVIOR

Range:	0 = Show Alarm 1 = Generate Fault 2 = Run STOP function 3 = Disable drive	Default: -
Properties:	RW	

Description:

This parameter allows selecting which action should be executed by the equipment, if it is controlled via network and a communication error is detected.

Table 5.1: Option for parameter P0662

Option	Description
0 = Show Alarm	If a communication error occurs, only indicates alarm in the keypad. If the communication is reestablished, the alarm indication is automatically removed.
1 = Generate Fault	Instead of an alarm, a communication error causes a fault in the equipment, and it is necessary to reset the failure to return to normal operation.
2 = Run STOP function	It will indicate an alarm along with the execution of the STOP command. To start operation again, it is necessary to run the fault reset or disable the drive.
3 = Disable drive	It will indicate an alarm along with the execution of the disable command.

The following events are considered communication errors:

Ethernet communication:

- Alarm A0147/Fault F0047: communication error with Ethernet master.
- Alarm A0148/Fault F0048: Ethernet interface error.

P0800 – ETHERNET MODULE IDENTIFICATION

Range:	0 = Not Identified 1 = Modbus TCP 2 = EtherNet/IP 3 = PROFINET IO	Default: -
Properties:	RO, ETH	

Description:

It allows identifying the Ethernet module type connected to the equipment.

Table 5.2: P0800 indications

Indication	Description
0 = Not Identified	Module not connected / not identified.
1 = Modbus TCP	Ethernet module for communication with Modbus TCP protocol.
2 = EtherNet/IP	Ethernet module for communication with EtherNet/IP protocol.
3 = PROFINET IO	Ethernet module for communication with PROFINET IO protocol.

P0801 – ETHERNET COMMUNICATION STATUS

Range:	0 = Setup 1 = Init 2 = Wait Comm 3 = Idle 4 = Data Active 5 = Error 6 = Reserved 7 = Exception 8 = Access Error	Default: -
Properties:	RO, ETH	

Description:

It allows identifying the Ethernet communication status.

Table 5.3: P0801 indications

Indication	Description
0 = Setup	Module identified, waiting configuration data (automatic).
1 = Init	Module performing interface initialization procedure (automatic).
2 = Wait Comm	Initialization finished, but no communication with master.
3 = Idle	Communication with master established, but in Idle mode or Program mode.
4 = Data Active	Communication with master established and performing normal I/O data handling. "On-line".
5 = Error	Communication error detected.
6	Reserved
7 = Exception	Major fault detected by the Ethernet interface. Requires interface reinitialization.
8 = Access error	Major fault detected between device and Ethernet interface. Requires interface reinitialization.

P0803 – ETHERNET BAUD RATE

Range:	0 = Auto 1 = 10Mbit/s, half duplex 2 = 10Mbit/s, full duplex 3 = 100Mbit/s, half duplex 4 = 100Mbit/s, full duplex	Default: 0
Properties:	RW, ETH	

Description:

It allows to set the desired baud rate for the Ethernet interface.


NOTE!

- For the changes in this parameter be effective, the equipment must be powered off and on again, or an update must be performed by P0849.
- For PROFINET interface, the baud is locked to 100Mbit/s as required by the protocol.

P0806 – MODBUS TCP WATCHDOG

Range:	0.0 to 65.5 s	Default: 0.0
Properties:	RW, ETH	

Description:

It allows programming a time limit for the detection of Ethernet offline error, for Modbus TCP protocol. If the SCA06 remains without receiving valid telegrams longer than the time programmed in this parameter, it will be considered that a communication error has occurred, the alarm A147 will be showed on the HMI and the option programmed in P0662 will be executed.

After being powered up, the SCA06 starts counting this time from the first received valid telegram. The value 0.0 disables this function.


NOTE!

For the changes in this parameter be effective, the equipment must be powered off and on again, or an update must be performed by P0849.

P0810 – IP ADDRESS CONFIGURATION

Range:	0 = Parameters 1 = DHCP	Default: 1
Properties:	RW, ETH	

Description:

It allows to choose how to set the IP address for the Ethernet modules.

Table 5.4: P0810 options

Option	Description
0 = Parameters	The settings for IP address, sub-net mask and gateway shall be done by means of parameters P0811 to P0819.
1 = DHCP	Enables DHCP function. A DHCP server should set the IP address, sub-net mask and gateway through network.



NOTE!

For the changes in this parameter be effective, the equipment must be powered off and on again, or an update must be performed by P0849.

P0811 – IP ADDRESS 1

P0812 – IP ADDRESS 2

P0813 – IP ADDRESS 3

P0814 – IP ADDRESS 4

Range:	0 ... 255	Default: 192.168.0.10
Properties:	RW, ETH	

Description:

If P0810 = 0 (parameters), these parameters allow you to program the IP address of the Ethernet module. For other option of P0810, these parameters have no function.

Each parameter programs one octet of the IP address, where the P0811 is the most significant octet. The programmed IP address, then, has the format "P0811.P0812.P0813.P0814".



NOTE!

For the changes in this parameter be effective, the equipment must be powered off and on again, or an update must be performed by P0849.

P0815 – SUBNET CIDR

Range:	1 ... 31	Default: 24
Properties:	RW, ETH	

Description:

If P0810 = 0 (parameters), this parameters allow you to program the sub-net mask for the Ethernet module. The subnet mask can usually be programmed using a notation with 4 octets separated by dots, or CIDR notation, in which the value is the number of bits with value "1" in the subnet mask. For other option of P0810, this parameter has no function.

The following table shows the allowed values for the CIDR notation and equivalent dot notation for the subnet mask:

Table 5.5: P0815 options

CIDR	Sub-net mask	CIDR	Sub-net mask
1	128.0.0.0	17	255.255.128.0
2	192.0.0.0	18	255.255.192.0
3	224.0.0.0	19	255.255.224.0
4	240.0.0.0	20	255.255.240.0
5	248.0.0.0	21	255.255.248.0
6	252.0.0.0	22	255.255.252.0
7	254.0.0.0	23	255.255.254.0
8	255.0.0.0	24	255.255.255.0
9	255.128.0.0	25	255.255.255.128
10	255.192.0.0	26	255.255.255.192
11	255.224.0.0	27	255.255.255.224
12	255.240.0.0	28	255.255.255.240
13	255.248.0.0	29	255.255.255.248
14	255.252.0.0	30	255.255.255.252
15	255.254.0.0	31	255.255.255.254
16	255.255.0.0		



NOTE!

For the changes in this parameter be effective, the equipment must be powered off and on again, or an update must be performed by P0849.

P0816 – GATEWAY 1

P0817 – GATEWAY 2

P0818 – GATEWAY 3

P0819 – GATEWAY 4

Range:	0 ... 255	Default: 0.0.0.0
Properties:	RW, ETH	

Description:

If P0810 = 0 (parameters), these parameters allow you to program the IP address of the default gateway for the Ethernet modules. For other option of P0810, these parameters have no function.

Each parameter programs one octet of the gateway address, where the P0816 is the most significant octet. The programmed gateway IP address, then, has the format “P0816.P0817.P0818.P0819”.



NOTE!

For the changes in this parameter be effective, the equipment must be powered off and on again, or an update must be performed by P0849.

P0820 ... P0831 – ETHERNET READ WORDS #5 ... #16

Range:	0 ... 9999	Default: 0
Properties:	RW, ETH	

Description:


These parameters allow programming the number of read words (inputs: slave → master), as well as the content of

each word.

The first four read words are pre-defined, representing the value of the status word, motor speed, torque current and present control mode (refer to item 6.1), and are always sent to the network master. The words #5 to #16 can be programmed by the user. By using these parameters it is possible to program the number of another parameter whose content must be made available at the network master input area. If, for instance, one wants to read from the SCA06 servo drive the motor current in Amps, one must program the value 3 in one of these parameters, because the parameter P0003 is the one that contains this information. It is worthwhile to remind that the value read from any parameter is represented with a 16 bit word. Even if the parameter has decimal resolution, the value is transmitted without the indication of the decimal places. E.g., if the parameter P0003 has the value 4.7A, the value supplied via the network will be 47.

The number of read words is defined by programming zero in the last parameter required for communication. Besides the four predefined words, it will also be added to the input area the words programmed in these parameters if the contents programmed for these parameters is different from zero. The first parameter set to zero disables the use of itself and the other parameters in the sequence. For example, if you set P0820 = 0, only four predefined read words (state, speed, torque current and present control mode) will be communicated with the master.

Table 5.6: Read words programming



The same number of words programmed into the equipment must be programmed in the master when configuring the network.



NOTE!

If, after parameter settings, the number of words changes, to make the new configuration effective the equipment must be powered off and on again, or an update must be performed by P0849.

P0835 ... P0846 – ETHERNET WRITE WORDS #5 ... #16

Range:	0 ... 9999	Default: 0
Properties:	RW, ETH	


Description:

These parameters allow programming the number of write words (outputs: master → slave), as well as the content of each word.

The first four write words are pre-defined, representing the value of the control word, speed reference, torque reference and control mode (refer to item 6.2), and are always received from the network master. The words #5 to #16 can be programmed by the user. By using these parameters it is possible to program the number of another parameter whose content must be made available at the network master output area. If, for instance, one wants to write to the SCA06 servo drive the ramp for STOP function, one must program the value 105 in one of these parameters, because the parameter P0105 is the one to program this information. It is worthwhile to remind that the value written from any parameter is represented with a 16 bit word. Even if the parameter has decimal resolution, the value is transmitted without the indication of the decimal places. E.g., if the parameter P0105 has the value 5.0s, the value supplied via the network will be 50.

The number of write words is defined by programming zero in the last parameter required for communication. Besides the four predefined words, it will also be added to the output area the words programmed in these parameters if the contents programmed for these parameters is different from zero. The first parameter set to zero disables the use of itself and the other parameters in the sequence. For example, if you set P0835 = 0, only four predefined write words (control, speed reference, torque reference and control mode) will be communicated with the master.

Table 5.7: Write words programming



The same number of words programmed into the equipment must be programmed in the master when configuring the network.



NOTE!

If, after parameter settings, the number of words changes, to make the new configuration effective the equipment must be powered off and on again, or an update must be performed by P0849.

P0849 – UPDATE ETHERNET CONFIGURATION

Range:	0 = Normal Operation 1 = Update configuration	Default: 0
Properties:	RW, ETH	

Description:

It allows you to force a reset of the Ethernet interface, to update the settings made in the device parameters. When setting this parameter to “1”, the Ethernet interface is restarted, resulting in loss of communication during this process. After the process is complete, the parameter switch automatically to “0”.

6 I/O WORDS WITH SPECIFIC FUNCTION

The servo drive SCA06 can communicate from 4 to 16 input/output words (I/O). The first four I/O words have pre-defined functions, whose formats and functions are described below.

6.1 INPUT WORDS – (SLAVE → MASTER)

6.1.1 1st – Status Word

Word that indicates the equipment status, providing information about licenses, faults, etc.

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Function	Limit switch counterclockwise active	Limit switch clockwise active	Reserved						In Alarm	Safety function active	In Stop	Energized Power	In Fault	Enabled	Reserved	

Table 6.1: Functions of the bits for the specific status word of the SCA06

Bit	Value/Description
Bit 0 ... 1	Reserved
Bit 2 Enabled	0: Drive disabled. 1: Drive enabled, it is driving the motor according to the control mode.
Bit 3 In Fault	0: No fault in the drive. 1: Drive in fault status.
Bit 4 Power Energized	0: No power on the power circuit or in undervoltage. 1: Power circuit of the drive fully energized, ready to enable.
Bit 5 In Stop	0: STOP function inactive. 1: STOP function active.
Bit 6 Safety Stop Active	0: Safety stop function (STO) inactive. 1: Safety stop function (STO) active.
Bit 7 In Alarm	0: No alarm. 1: Drive with some active alarm.
Bit 8 ... 13	Reserved
Bit 14 Limit switch clockwise active	0: No limit switch clockwise signal. 1: Limit switch clockwise signal was activated.
Bit 15 Limit switch counterclockwise active	0: No limit switch counterclockwise signal. 1: Limit switch counterclockwise signal was activated.

6.1.2 2nd – Motor Speed

Word that indicates the motor speed. Specific motor speed of the SCA06, where the value 7FFFh (32767) corresponds to 18750 rpm. Negative values represent the motor spinning counterclockwise.



NOTE!

In this word, it is indicated the instant speed value, without filter. For this reason, it is normal the oscillation of the value read around the operation point.

6.1.3 3rd – Torque Current

Word that indicates the torque current, proportional to the equipment current that generates torque. The indication is done in ampere (A), with one-decimal place resolution. Example: If the current value is 4.7A, the value read via network will be 47. Negative values represent negative torque current.

6.1.4 4th – Present Control Mode

It indicates which control mode is selected for the equipment:

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Function	Reserved												Control Mode			

Table 6.2: Functions of the bits for the control mode of the SCA06

Bit	Value/Description
Bit 0 ... 3 Control Mode	It defines present control mode of the equipment: 0: Torque mode. 1: Velocity mode. 3: Position mode.
Bit 4 ... 15	Reserved

6.2 OUTPUT WORDS – (MASTER → SLAVE)

6.2.1 1st – Control Word

Word that allows sending command to the equipment. Only used by the SCA06 if the operating mode is set for Ethernet (P0202 = 6).

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Function	Reserved								Fault Reset	Reserved			Enable	Activate STOP	Reserved	

Table 6.3: Functions of the bits for specific control word of the SCA06

Bit	Value/Description
Bit 0 ... 1	Reserved
Bit 2 Activate STOP	0: No STOP function. 1: Activates STOP function.
Bit 3 Enable	0: Disable drive. 1: Enable Drive.
Bit 4 ... 6	Reserved
Bit 7 Fault Reset	0: No function. 0 → 1: Resets the equipment faults.
Bit 8 ... 15	Reserved

6.2.2 2nd – Speed Reference

Word for programming the motor speed reference. Specific motor speed of the SCA06, where the value 7FFFh (32767) corresponds to 18750 rpm. Negative values represent counterclockwise reference.

6.2.3 3rd – Torque Reference

Word that allows programming the reference for the torque current of the servoconverter. The reference is programmed in ampere (A), with one-decimal place resolution. Example: when sending the value 47, the drive will take a reference equal to 4.7A. Negative values represent negative reference for the torque current.

6.2.4 4th – Control Mode

Allows programming the equipment control mode:

Bit	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Function	Reserved												Control Mode			

Table 6.4: Functions of the bits for the control mode of the SCA06

Bit	Value/Description
Bit 0 ... 3 Control mode	It defines the present control mode of the equipment: 0: Torque mode. 1: Velocity mode. Other values are reserved.
Bit 4 ... 15	Reserved



NOTE!

- The Ethernet interface allows speed and torque control of the servoconverter SCA06. To perform positioning functions, the Ladder operating mode must be used, developing a Ladder application program and using the user's parameter as interface with the network master to control and monitor the equipment.

7 MODBUS TCP

This chapter shows operating characteristics of the servo drive SCA06 using the accessory for communication as Modbus TCP server.

7.1 INDICATION LEDS

The NS LED have the following information for Modbus TCP protocol:

Table 7.1: Network Status LED (NS)

State	Description
Off	No power or no IP address.
Green, solid	Connection established.
Green, flashing	Waiting for connections.
Red, solid	Duplicate IP address, or fatal error (interface must be reinitialized).
Red, flashing	Modbus communication timed out.

7.2 AVAILABLE FUNCTIONS

In the Modbus specification are defined the functions used to access different types of data. In the SCA06, in order to access those data the following services (or functions) have been made available:

Table 7.2: Supported Modbus Functions

Code	Name	Description
01	Read Coils	Reading of bit blocks of the coil type.
02	Read Discrete Inputs	Reading of bit blocks of the discrete input type.
03	Read Holding Registers	Reading of register blocks of the holding register type.
04	Read Input Registers	Reading of register blocks of the input register type.
05	Write Single Coil	Writing in a single bit of the coil type.
06	Write Single Register	Writing in a single register of the holding type.
15	Write Multiple Coils	Writing in bit blocks of the coil type.
16	Write Multiple Registers	Writing in register blocks of the holding register type.
43	Read Device Identification	Identification of the device model.

7.3 MEMORY MAP

The servo drive SCA06 has different types of data accessible through the Modbus communication. These data are mapped at data addresses and access functions as described in the following items.

7.3.1 Parameters

The SCA06 Modbus communication is based on the reading/writing of the equipment parameters. All the drive parameters list is made available as 16-bit holding registers type. The data addressing is done with the offset equal to zero, which means that the parameter number corresponds to the register number. The following table illustrates the parameters addressing, which can be accessed as holding register:

Table 7.3: Parameters Access - Holding Registers

Parameter	Modbus data address (decimal)
P0000	0
P0001	1
⋮	⋮
P0100	100
⋮	⋮

It is necessary to know the device list of parameters to be able to operate the equipment. Thus, it is possible to identify what data are needed for the status monitoring and the control of the functions. The main parameters are:

Monitoring (reading):

- P0002 (holding register 2): Motor speed
- P0052 (holding register 52): Fractions of revolution

Command (writing):

- P0099 (holding register 99): Enable
- P0121 (holding register 121): Speed reference
- P1100 (holding register 1100): User parameter 1100

Refer to the Programming Manual for a complete parameter list of the equipment.



NOTE!

- All the parameters are treated as holding registers. Depending on the master that is used, those registers are referenced starting from the base address 40000 or 4x. In this case, the address that must be programmed in the master for a parameter is the address showed in the table above added to the base address. Refer to the master documentation to find out how to access holding registers.
- It should be noted that read-only parameters can only be read from the equipment, while other parameters can be read and written through the network.

7.3.2 Memory Markers

Besides the parameters, other types of data as bit markers, word or float, can also be accessed using the Modbus protocol. Those markers are used mainly by the SoftPLC function, available for the SCA06. Refer to the SoftPLC documentation for the description of those markers, as well as for the addresses via Modbus.

7.4 COMMUNICATION ERRORS

Communication errors may occur in the transmission of telegrams, as well as in the contents of the transmitted telegrams. Transmission and connection errors are directly processed by the Ethernet interface and by the TCP/IP protocol.

In the event of a successful reception, during the treatment of the telegram, the server may detect problems and send an error message, indicating the kind of problem found:

Table 7.4: Error codes for Modbus

Error Code	Description
1	Invalid function: the requested function is not implemented for the equipment.
2	Invalid data address: the data address (register or bit) does not exist.
3	Invalid data value: <ul style="list-style-type: none"> ▪ Value out of the allowed range. ▪ Writing on data that cannot be changed (read only register or bit).



NOTE!

It is important that it be possible to identify at the client what type of error occurred, in order to be able to diagnose problems during the communication.

7.5 STARTUP GUIDE

The following items describe main steps for SCA06 commissioning using the Modbus TCP protocol. These steps represent an example of use. Refer to specific chapters for details on the steps.

7.5.1 Installing the Ethernet Module

1. Install the Ethernet communication module, as indicated in the installation guide supplied with the module.
2. Connect the Ethernet cable to the module, considering the recommended instructions in network installation, as described in item 4:
 - Use shielded cable.
 - Properly ground network equipment.
 - Avoid laying communication cables next to power cables.

7.5.2 Configuring the Drive

1. Follow the recommendations described in the user's manual to program the device parameters related to motor settings, desired operation mode, I/O signs, etc.
2. Program command sources as desired for application.
3. Program communication parameters such as DHCP, IP address, baud rate, etc.
4. Program the timeout for Modbus TCP communication in parameter P0806.
5. Define which parameters will be read and written at SCA06 servo drive, based on its parameter list. It is not necessary to define I/O words. The Modbus TCP protocol enables direct access to any device parameter, and does not distinguish between cyclic and acyclic data. The main parameters that can be used to control the device, we can mention:
 - P0002 - Motor speed
 - P0052 - Fractions of revolution
 - P0099 - Enable
 - P0121 - Speed reference
 - P1100 - User parameter 1100
6. If necessary, restart the Ethernet module using P0849.

7.5.3 Configuring the Master

The way you do the network setup is highly dependent on the network master and the network configuration tool. It is important to know the tools used to perform this activity. In general, the following steps are required to perform the network configuration.

1. Program the master to read and write holding registers, based on the defined equipment parameters to read and write. The register number is based on the parameter number, as shown in table 7.3.
2. It is recommended that reading and writing are done in a cyclic manner, allowing detection of communication errors by timeout.

7.5.4 Communication Status

Once you install the network and program the master, you can use the LEDs and equipment parameters to identify some states related to communication.

- The LEDs "NS" and "Link" provide information about the state of the interface and communication.
- The parameter P0801 indicates the status of communication between the device and the network master.

The network master must also provide information about communication with slave.

7.5.5 Operation Using Process Data

Once communication is established, data is written and read by the Modbus TCP network master automatically. Using these parameters, the master is able to control the equipment and monitor its operation. It is important to know the device parameters to program the master as desired for the application.

8 ETHERNET/IP

Following it shows operating characteristics of the SCA06 servo drive using the accessory for EtherNet/IP communication.

8.1 INDICATION LEDS

The NS LED present on the Ethernet accessory, have the following information for EtherNet/IP protocol:

Table 8.1: Network Status LED (NS)

State	Description
Off	No power or no IP address.
Green, solid	Connection established.
Green, flashing	Waiting for connections.
Red, solid	Duplicate IP address, or fatal error (interface must be reinitialized).
Red, flashing	One or more I/O connection timed out.

8.2 CYCLIC DATA

Cyclic data is the data normally used for status monitoring and equipment control. For EtherNet/IP protocol, the interface supports an I/O connection that allows communication up to 16 input words and 16 output words.

It is necessary the configuration to be made both at the slave and master.

8.3 ACYCLIC DATA

In addition to the cyclic data, the interface also provides acyclic data via explicit messaging. Using this type of communication, you can access any equipment parameter. Access to this type of data is commonly done using instructions for reading or writing data, which should indicate the class, instance, and attribute to the desired parameter. The following table describes how to address the parameters for SCA06 servo drive.

Table 8.2: Parameter Addressing

Parameter	Class	Instance	Attribute
P0001	162 (A2h)	1	5
P0002	162 (A2h)	2	5
P0003	162 (A2h)	3	5
⋮	⋮	⋮	⋮
P0400	162 (A2h)	400	5
⋮	⋮	⋮	⋮

The data is transmitted as an integer value, without the indication of the decimal places.

8.4 EDS FILE

Each device on an EtherNet/IP network has an EDS configuration file, which contains information about the device functions on the network. This file is used by a master or configuration software to program devices present at EtherNet/IP network.

The EDS file is available from WEG website (<http://www.weg.net>). It is important to note if the EDS configuration file is compatible with the firmware version of the SCA06 servo drive.

8.5 MODBUS TCP CONNECTIONS

The accessory for EtherNet/IP also provides up to 2 Modbus TCP connections. These connections can be used for parameterization, as well as access to markers and data used for SCA06 ladder programming.

8.6 STARTUP GUIDE

Next it describes the main steps for commissioning SCA06 servo drive on Ethernet network using the EtherNet/IP protocol. These steps represent an example of use. Refer to specific chapters for details on the steps.

8.6.1 Installing the Ethernet Module

1. Install the Ethernet communication module, as indicated in the installation guide supplied with the module.
2. Connect the Ethernet cable to the module, considering the necessary care in network installation, as described in section 4:
 - Use shielded cable.
 - Properly ground the network devices.
 - Avoid laying communication cables next to power cables.

8.6.2 Configuring the Drive

1. Follow the recommendations described in the user's manual to program the related to device settings, motor parameters, desired functions for I/O signs, etc..
2. Program command sources as desired for application.
3. Program communication parameters such as DHCP, IP address, baud rate, etc.
4. Set the desired action for communication errors, through the P0662.
5. Set number of I/O words as well as the contents of each word using parameters P0820 to P0831 and P0835 to P0846.
6. If necessary, restart the Ethernet module using P0849.

8.6.3 Configuring the Master

The way you do the network setup depends largely on the master and the configuration tool. It is important to know these tools to perform this activity. In general, the following steps are required to do the network configuration.

1. Load the EDS file¹ to the list of devices in the network configuration tool.
2. Select SCA06 servo drive from the available list of devices on the network configuration tool. This can be done manually or automatically, if allowed by the tool.

¹The EDS file is available from WEG website (<http://www.weg.net>). It is important to note if the EDS configuration file is compatible with the firmware version of the SCA06 servo drive.

3. For the master configuration, in addition to the IP address used by the EtherNet/IP module, you must indicate the number of instances of I/O and the amount of data exchanged with the master in each instance. For the communication module for EtherNet/IP, the following values must be programmed:
 - Input instance: 100
 - Output instance: 150
4. The EtherNet/IP module is described as “Generic Ethernet Module” on the device list. Using these settings you can program the network master to communicate with the equipment.

8.6.4 Communication Status

Once you install the network and program the master, you can use the LEDs and equipment parameters to identify some states related to communication.

- The LEDs “NS” and “Link” provide information about the state of the interface and communication.
- The parameter P0801 indicates the status of communication between the device and the network master.

The network master must also provide information about the communication with slave.

8.6.5 Operation Using Process Data

Once the communication is established, the data mapped in the I/O area is automatically updated between master and slave. Among the main parameters that can be used to control the device, we can mention:

- Status Word
- Motor Speed
- Torque Current
- Present Control Mode
- Control Word
- Speed Reference
- Torque Reference
- Control Mode

It is important to know these parameters to program the master as desired for the application.

9 PROFINET

Following it shows operating characteristics of the servo drive SCA06 using plug-in module for PROFINET communication.

9.1 INDICATION LEDS

The NS LED present on the Ethernet accessory, have the following information for PROFINET protocol:

Table 9.1: Network Status LED (NS)

State	Description
Off	No power or no connection with controller.
Green, solid	Connection with controller established, controller in RUN mode.
Green, flashing	Connection with controller established, controller in STOP mode.

9.2 CYCLIC DATA

Cyclic data is the data normally used for status monitoring and equipment control. For PROFINET protocol, the interface supports an I/O connection that allows communication up to 16 input words and 16 output words.

It is necessary the configuration to be made both at the slave and master.

9.3 ACYCLIC DATA

In addition to the cyclic data, the PROFINET protocol also provides acyclic data, mainly used to communicate diagnoses data, parameterization and configuration. For the SCA06 servo drive using the Ethernet module, the parameter list is available using this communication method.

The PROFINET protocol defines the following structure to address the components for network configuration:

- AR (Application Relation)
- API (Application Process Identifier)
- Slot
- Subslot

The AR and API are used to identify the Ethernet module during the network configuration steps. Slot/subslot are not relevant for accessing acyclic data. Once the module is identified, the parameters are accessed indicating the index and the data length:

- Index: represents the parameter number;
- Length: the length of data, in bytes. All device parameter are 2 bytes in length (Word).

The data is transmitted as an integer value, without the indication of the decimal places.

9.4 XML FILE – GSDML

Each device on an PROFINET network has an GSDML configuration file, which contains information about the device functions on the network. This file is used by a master or configuration software to program devices present at PROFINET network.

The GSDML file is available from WEG website (<http://www.weg.net>). It is important to note if the GSDML configuration file is compatible with the firmware version of the SCA06 servo drive.

9.5 MODBUS TCP CONNECTIONS

The plug-in module for PROFINET IO also provides up to 2 Modbus TCP connections. These connections can be used for parameterization, as well as access to markers and data used for SCA06 ladder programming. The available Modbus functions and communication data are described in item 7.

9.6 STARTUP GUIDE

Next it describes the main steps for commissioning SCA06 servo drive on Ethernet network using the PROFINET protocol. These steps represent an example of use. Refer to specific chapters for details on the steps.

9.6.1 Installing the Ethernet Module

1. Install the Ethernet communication module, as indicated in the installation guide supplied with the module.
2. Connect the Ethernet cable to the module, considering the necessary care in network installation, as described in section 4:
 - Use shielded cable.
 - Properly ground the network devices.
 - Avoid laying communication cables next to power cables.

9.6.2 Configuring the Drive

1. Follow the recommendations described in the user's manual to program the related to device settings, motor parameters, desired functions for I/O signs, etc..
2. Program command sources as desired for application.
3. Program communication parameters such as DHCP, IP address, baud rate, etc.
4. Set the desired action for communication errors, through the P0662.
5. Set number of I/O words as well as the contents of each word using parameters P0820 to P0831 and P0835 to P0846.
6. If necessary, restart the Ethernet module using P0849.

9.6.3 Configuring the Master

The way you do the network setup depends largely on the master and the configuration tool. It is important to know these tools to perform this activity. In general, the following steps are required to do the network configuration.

1. Load the GSDML file² to the list of devices in the network configuration tool.
2. Select SCA06 servo drive from the available list of devices on the network configuration tool. This can be done manually or automatically, if allowed by the tool.

²The GSDML file is available from WEG website (<http://www.weg.net>). It is important to note if the GSDML configuration file is compatible with the firmware version of the SCA06 servo drive.

3. For the master configuration, you must indicate the number of I/O words exchanged with the master. It is necessary to select word by word, first selecting all input words and then all output words.
4. The PROFINET module is recognized as "SCA06", at the "General" category. Using these settings you can program the network master to communicate with the equipment.

9.6.4 Communication Status

Once you install the network and program the master, you can use the LEDs and equipment parameters to identify some states related to communication.

- The LEDs "NS" and "Link" provide information about the state of the interface and communication.
- The parameter P0801 indicates the status of communication between the device and the network master.

The network master must also provide information about the communication with slave.

9.6.5 Operation Using Process Data

Once the communication is established, the data mapped in the I/O area is automatically updated between master and slave. Among the main parameters that can be used to control the device, we can mention:

- Status Word
- Motor Speed
- Torque Current
- Present Control Mode
- Control Word
- Speed Reference
- Torque Reference
- Control Mode

It is important to know these parameters to program the master as desired for the application.

10 WEB SERVER

Besides the communication protocol, the Ethernet interface also provides a WEB server with a simple HTML page to access SCA06 servo drive data. If the IP address is known, you can use a web browser by typing the IP address in the browser address bar, and it will present a web page with links to interface settings and device data.




Figure 10.1: WEB page for interface configuration

In the interface settings, it presents several fields for programming the IP address, subnet, DHCP, among others. The parameter list of the equipment can also be accessed through the WEB browser via "Parameter Data" link. This list is presented in a simplified format, with only the integer values, with no indication of decimal places.

11 FAULTS AND ALARMS

F0047/A0147 - ETHERNET OFFLINE

Description:

Indicates communication failure between the slave and the network controller.

Actuation:

It occurs when, once established communication between the slave and the network master, there is an interruption in this communication. The method for detecting the interruption of communication depends on the network:

- Modbus TCP: not receiving a valid Modbus TCP telegram by preset period at P0806.
- EtherNet/IP: timeout in I/O connection, or master goes to IDLE state.
- PROFINET: timeout on the cyclic communication between master and slave, or master goes to STOP state.

In this case, the device will show in the HMI an alarm message A0147 - or fault F0047, depending on the P0662 programming. In case of alarm, the indication will automatically disappear at the moment when the communication is reestablished.

Possible Causes/Correction:

- Verify whether the network master is properly configured and operating normally.
- Search for short-circuit or bad contact in the communication cables.
- Verify the entire network installation – cable laying, grounding.

F0048/A0148 - ETHERNET INTERFACE ACCESS ERROR

Description:

Indicates error in data exchange between SCA06 servo drive and Ethernet module.

Actuation:

It occurs when the control board can not exchange data with the Ethernet module, when the Ethernet module identifies some internal error, or when there is a hardware incompatibility.

In this case, the device will show in the HMI an alarm message A0148 - or fault F0048, depending on the P0662 programming. You must reboot the Ethernet module, power cycling the product or using P0849.

Possible Causes/Correction:

- Check if Ethernet module is properly connected to product.
- Check if the device firmware version supports this module.
- Hardware errors caused by the improper handling or installation of the accessory can cause this error. If possible, test it by replacing the communication module.



WEG Drives & Controls - Automação LTDA.
Jaraguá do Sul – SC – Brazil
Phone 55 (47) 3276-4000 – Fax 55 (47) 3276-4020
São Paulo – SP – Brazil
Phone 55 (11) 5053-2300 – Fax 55 (11) 5052-4212
automacao@weg.net
www.weg.net