



Mounting kit Guide

Guía kit de Montaje

Guia Kit Montagem

MVW-01



- ① Apply neoprene profile dimensions 15x10x414 mm.
- ① Aplicar perfil de neopreno dimensiones 15x10x414 mm.
- ① Aplicar perfil de neopreme com dimensões 15x10x414 mm.

