



Application Information

Dancer Surface Winder

Equipment: CFW-11

Firmware Version: V2.00 or higher

WLP Software Version: V8.21 or higher

New Application Version: SWDA-1_10.apl

Old Application Version: SWDA-1_01.apl

Document: 10000285200 / 01

Functional deviations in the old application version

1)

Changes in the new application version

- 1) Inserted timer in the first SoftPLC scan cycle marker;
- 2) Inserted the Step 15 (HMI Monitoring) on the Configuration Wizard and compiled to CFW-11 V2.00.

Notes!

- 1) Appendix 1 shows how to import Dancer Surface Winder application to WLP.

Appendix 1 – How to Import Application to WLP

- 1) In the WLP Ladder Programmer, in "Tools" menu, select the "Import Application to WLP" option;
- 2) Search "SWDA-1_10.apl" archive and press "OK";
- 3) The Dancer Surface Winder will be imported to WLP;
- 4) To select the application, in "Tools" menu, "Application" option, "CFW11", "Create", "Surface Winder", select "Dancer" option.