



## Pump Genius Simplex V1.00 Application Information

Equipment: CFW500

Firmware Version: V1.50 or higher

WLP Software Version: V10.00 or higher

New Application Version: PGSPX\_CFW500\_en\_V1\_00.apl

Old Application Version: -

Document Number (Application Manual): 10004314066 / 00

### Functional deviations in the old application version

- 1) There is not

### Changes in the new application version

- 1) It was implemented the Pump Genius Simplex application in WLP.



**NOTE!**

Appendix 1 shows how to import Pump Genius Simplex application to WLP.

## Appendix 1 – How to Import Application to WLP

- 1) In the WLP Ladder Programmer, in “Tools” menu, select the “Import Application to WLP” option;
- 2) Search “PGSPX\_CFW500\_en\_V1\_00.apl” archive and press “OK”;
- 3) The Pump Genius Simplex application will be imported to WLP;
- 4) To select the application, in “Tools” menu, “Application” option, “CFW500”, “Create”, “Pump Genius”, select “Simplex” option.