



Pump Genius Simplex V1.03 Application Information

Equipment: CFW500

Firmware Version: V2.06 or higher

WLP Software Version: V11.10 or higher

New Application Version: PGSPX_CFW500_en_V1_03.apl

Old Application Version: PGSPX_CFW500_en_V1_01.apl

Document Number (Application Manual): 10004314066 / 00

Functional deviations in the old application version

- 1) There is not.

Changes in the new application version

- 1) Corrected version to adequate according to other languages
- 2) Fixed and included options on configuration wizard P510, P512.



NOTE!

Appendix 1 shows how to import Pump Genius Simplex application to WLP.

Appendix 1 – How to Import Application to WLP

- 1) In the WLP Ladder Programmer, in “Tools” menu, select the “Import Application to WLP” option;
- 2) Search “PGSPX_CFW500_en_V1_03.apl” archive and press “OK”;
- 3) The Pump Genius Simplex application will be imported to WLP;
- 4) To select the application, in “Tools” menu, “Application” option, “CFW500”, “Create”, “Pump Genius”, select “Simplex” option.