



## Pump Genius Simplex V1.05 Application Information

Equipment: CFW500

Firmware Version: V2.06 or higher

WLP Software Version: V11.11 or higher

New Application Version: PGSPX\_CFW500\_en\_V1\_05.apl

Old Application Version: PGSPX\_CFW500\_en\_V1\_04.apl

Document Number (Application Manual): 10004314066/00

### Functional deviations in the old application version

- 1) Changed the minimum values of P133, P134 and P1054 in the configuration wizard.
- 2) Fixed the Sleep Boost alarm value.

### Changes in the new application version

- 1) Compatible for CFW500 G1 and G2.



#### NOTE!

Appendix 1 shows how to import Pump Genius Simplex application to WLP.

## Appendix 1 – How to Import Application to WLP

- 1) In the WLP Ladder Programmer, in “Tools” menu, select the “Import Application to WLP” option;
- 2) Search “PGSPX\_CFW500\_en\_V1\_05.apl” archive and press “OK”;
- 3) The Pump Genius Simplex application will be imported to WLP;
- 4) To select the application, in “Tools” menu, “Application” option, “CFW500”, “Create”, “Pump Genius”, select “Simplex” option.