



Pump Genius Multipump V2.01 Application Information

Equipment: CFW500

Firmware Version: V1.50 or higher

WLP Software Version: V10.00 or higher

New Application Version: PGMPPM_CFW500_en_V2_01.apl

Old Application Version: PGMPPM_CFW500_en_V2_00.apl

Document Number (Application Manual): 10004314066 / 00

Functional deviations in the old application version

1) When the Setpoint Control was selected via HMI (1020 = 4), the value defined by user in the P1011 parameter was changed to other values randomly. Since only happens in firmware versions V1.8X the CFW500.

Changes in the new application version

1) There is not.



NOTE!

Appendix 1 shows how to import Pump Genius Multipump application to WLP.

Appendix 1 – How to Import Application to WLP

- 1) In the WLP Ladder Programmer, in “Tools” menu, select the “Import Application to WLP” option;
- 2) Search “PGMPM_CFW500_en_V2_01.apl” archive and press “OK”;
- 3) The Pump Genius Multipump application will be imported to WLP;
- 4) To select the application, in “Tools” menu, “Application” option, “CFW500”, “Create”, “Pump Genius”, select “Multipump” option.