



Pump Genius Simplex V1.00 Application Information

Equipment: CFW503

Firmware Version: V2.00 or higher

WLP Software Version: V11.18 or higher

New Application Version: PGSPX_CFW503_en_V1_00.apl

Old Application Version: -

Document Number (Application Manual): 10014089993/00

Functional deviations in the old application version

- 1) There is not

Changes in the new application version

- 1) It was implemented the Pump Genius Simplex application in WLP.



NOTE!

Appendix 1 shows how to import Pump Genius Simplex application to WLP.

Appendix 1 – How to Import Application to WLP

- 1) In the WLP Ladder Programmer, in “Tools” menu, select the “Import Application to WLP” option;
- 2) Search “PGSPX_CFW503_en_V1_00.apl” archive and press “OK”;
- 3) The Pump Genius Simplex application will be imported to WLP;
- 4) To select the application, in “Tools” menu, “Application” option, “CFW503”, “Create”, “Pump Genius”, select “Simplex” option.