



Pump Genius Simplex V1.34 Application Information

Equipment: CFW-11

Firmware Version: Ve5.38

WLP Software Version: V11.11 or higher

New Application Version: PGSPX_CFW11_en_V1_34.apl

Old Application Version: PGSPX_CFW11_en_V1_33.apl

Document Number (Application Manual): 10003799455 / 00

Functional deviations in the old application version

- 1) Incorrect operation with minimum level with a non-zero value.

Changes in the new application version

- 1) Added offset for setpoint and process variable for non-zero minimum level values;
- 2) Some corrections in the parameter table.



NOTE!

Appendix 1 shows how to import Pump Genius Simplex application to WLP.

Appendix 1 – How to Import Application to WLP

- 1) In the WLP Ladder Programmer, in “Tools” menu, select the “Import Application to WLP” option;
- 2) Search “PGSPX_CFW11_en_V1_34.apl” archive and press “OK”;
- 3) The Pump Genius Simplex application will be imported to WLP;
- 4) To select the application, in “Tools” menu, “Application” option, “CFW11”, “Create”, “Pump Genius”, select “Simplex” option.