



## Crane Vertical Motion V2.13 Application Information

Equipment: CFW-11

Firmware Version: V5.19 or higher

WLP Software Version: V10.00 or higher

New Application Version: CRVM\_CFW11\_en\_V2\_13.apl

Old Application Version: CRVM\_CFW11\_en\_V2\_12.apl

Document Number (Application Manual): 10001257576 / 03

### Functional deviations in the old application version

1) Impossibility of triggering alarm A762 (Stop hoisting limit switch) after removal of the command load hoisting.

### Changes in the new application version

1) It was removed the interlock that only allows activation of alarm A762 (Stop hoisting limit switch) with command load hoisting.



**NOTE!**

Appendix 1 shows how to import Crane Vertical Motion application to WLP.

## Appendix 1 – How to Import Application to WLP

- 1) In the WLP Ladder Programmer, in “Tools” menu, select the “Import Application to WLP” option;
- 2) Search “CRVM\_CFW11\_en\_V2\_13.apl” archive and press “OK”;
- 3) The Crane Vertical Motion application will be imported to WLP;
- 4) To select the application, in “Tools” menu, “Application” option, “CFW11”, “Create”, “Crane”, select “Vertical Motion” option.