



Application Information

Load Cell Surface Winder

Equipment: CFW-11

Firmware Version: V1.30 or higher

WLP Software Version: V7.22 or higher

New Application Version: SWLC-1_01.apl

Old Application Version: -

Document: 10000123067 / 00

Functional deviations in the old application version

1) -

Changes in the new application version

1) Implemented the Load Cell Surface Winder application in WLP.

Notes!

1) Appendix 1 shows how to import Load Cell Surface Winder application to WLP.

Appendix 1 – How to Import Application to WLP

- 1) In the WLP Ladder Programmer, in "Tools" menu, select the "Import Application to WLP" option;
- 2) Search "SWLC-1_01.apl" archive and press "OK";
- 3) The Load Cell Surface Winder will be imported to WLP;
- 4) To select the application, in "Tools" menu, "Application" option, "CFW11", "Create", "Surface Winder", select "Load Cell" option.